

DSEAts®



DEEP SEA ELECTRONICS PLC

DSE335 Operator Manual

Document Number 057-158

Author: Ashley Senior

DEEP SEA ELECTRONICS PLC

Highfield House
 Hunmanby
 North Yorkshire
 YO14 0PH
 ENGLAND



Sales Tel: +44 (0) 1723 890099
 Sales Fax: +44 (0) 1723 893303

E-mail : sales@deepseapl.com
 Website : www.deepseapl.com

DSE335 Operator Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo is a UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments List

Issue	Comments	Minimum Module version required	Minimum Configuration Suite Version required
1	Initial release	V3.0.0	2011.10v1.0.7
1.1	Added terminal numbers for alternative topologies	V3.0.0	2011.10v1.0.7

Typeface: The typeface used in this document is *Arial*. Care should be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

Clarification of notation used within this publication.




	NOTE:	Highlights an essential element of a procedure to ensure correctness.
	CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
	WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

TABLE OF CONTENTS

Section	Page
1 BIBLIOGRAPHY	6
1.1 INSTALLATION INSTRUCTIONS.....	6
1.2 TRAINING GUIDES	6
1.3 MANUALS	6
1.4 THIRD PARTY DOCUMENTS.....	6
2 INTRODUCTION	7
3 SPECIFICATIONS.....	8
3.1 PART NUMBERING	8
3.2 TERMINAL SPECIFICATION	9
3.3 POWER SUPPLY REQUIREMENTS	9
3.3.1 PLANT SUPPLY INSTRUMENTATION DISPLAY	9
3.4 S1 & S2 VOLTAGE / FREQUENCY SENSING.....	9
3.5 LOAD CURRENT SENSING	10
3.5.1 VA RATING OF THE CTS	10
3.5.2 CT POLARITY	11
3.5.3 CT PHASING	11
3.5.4 CT CLASS	11
3.6 DIGITAL INPUTS.....	12
3.7 OUTPUTS.....	12
3.7.1 CONFIGURABLE OUTPUTS A & E	12
3.7.2 CONFIGURABLE OUTPUTS B & F	12
3.7.3 CONFIGURABLE OUTPUTS C & D.....	12
3.7.4 CONFIGURABLE OUTPUTS G,H,I,J,K & L	12
3.8 COMMUNICATION PORTS	13
3.8.1 USB CONNECTION	13
3.8.2 RS232	14
3.8.2.1 RECOMMENDED PC RS232 SERIAL PORT ADD-ONS	14
3.8.2.2 RECOMMENDED EXTERNAL MODEMS:	15
3.8.3 RS485	16
3.8.3.1 RECOMMENDED PC RS485 SERIAL PORT ADD-ONS	16
3.8.4 DSENET® FOR EXPANSION MODULES	17
3.9 ADDING AN EXTERNAL SOUNDER TO THE APPLICATION	17
3.10 DIMENSIONS AND MOUNTING	18
3.10.1 DIMENSIONS	18
3.10.2 PANEL CUTOUT	18
3.10.3 WEIGHT	18
3.10.4 FIXING CLIPS.....	19
3.10.5 CABLE TIE FIXING POINTS	20
3.10.6 SILICON SEALING GASKET	20
3.11 APPLICABLE STANDARDS	21
3.11.1 ENCLOSURE CLASSIFICATIONS.....	23
3.11.2 NEMA CLASSIFICATIONS.....	24
4 INSTALLATION	25
4.1 TERMINAL DESCRIPTION	25
4.1.1 DC SUPPLY, OUTPUTS G-L	26
4.1.2 CONFIGURABLE DIGITAL INPUTS A-I.....	26
4.1.3 CONFIGURABLE DIGITAL INPUTS J-K, DSENET	27
4.1.4 CONFIGURABLE VOLT-FREE OUTPUTS E & F	27
4.1.5 LOAD SWITCHING AND S2 VOLTAGE SENSING	27
4.1.6 S1 VOLTAGE SENSING	28
4.1.7 LOAD CURRENT TRANSFORMERS	28
4.1.7.1 CONNECTION TO TERMINALS 45 & 46/47	29
4.1.7.2 CT CONNECTIONS	29

4.1.8	CONFIGURABLE VOLT-FREE CHANGEOVER OUTPUTS C & D.....	30
4.1.9	PC CONFIGURATION INTERFACE CONNECTOR.....	30
4.1.10	RS485 CONNECTOR.....	31
4.1.11	RS232 CONNECTOR.....	31
4.2	TYPICAL WIRING DIAGRAMS.....	32
4.2.1	DSE335 3 PHASE, 4 WIRE WITH RESTRICTED EARTH FAULT PROTECTION... 33	33
4.3	ALTERNATIVE TOPOLOGIES.....	34
4.3.1	3 PHASE, 4 WIRE WITHOUT EARTH FAULT PROTECTION.....	34
4.3.2	SINGLE PHASE WITH RESTRICTED EARTH FAULT.....	35
4.3.3	SINGLE PHASE WITHOUT EARTH FAULT.....	35
4.3.4	2 PHASE (L1 & L2) 3 WIRE WITH RESTRICTED EARTH FAULT.....	36
4.3.5	2 PHASE (L1 & L2) 3 WIRE WITHOUT EARTH FAULT.....	36
4.3.6	2 PHASE (L1 & L3) 3 WIRE WITH RESTRICTED EARTH FAULT.....	37
4.3.7	2 PHASE (L1 & L3) 3 WIRE WITHOUT EARTH FAULT MEASURING.....	37
4.3.8	3 PHASE 4 WIRE WITH UNRESTRICTED EARTH FAULT MEASURING.....	38
4.4	EARTH SYSTEMS.....	39
4.4.1	NEGATIVE EARTH.....	39
4.4.2	POSITIVE EARTH.....	39
4.4.3	FLOATING EARTH.....	39
4.5	TYPICAL ARRANGEMENT OF DSENET®.....	39
5	DESCRIPTION OF CONTROLS.....	40
5.1	DSE335 ATS MODULE.....	40
5.2	QUICKSTART GUIDE.....	41
5.2.1	STARTING THE S2.....	41
5.2.2	STOPPING S2.....	41
5.3	VIEWING THE INSTRUMENT PAGES.....	42
5.3.1	STATUS.....	43
5.3.2	S1.....	44
5.3.3	S2.....	44
5.3.4	EXPANSION.....	44
5.3.5	ALARMS.....	44
5.3.6	EVENT LOG.....	45
5.3.7	SERIAL PORT.....	46
5.3.7.1	RS232 SERIAL PORT.....	46
5.3.7.2	RS485 SERIAL PORT.....	49
5.3.8	SCHEDULER.....	50
5.3.9	ABOUT.....	50
5.4	VIEWING LATEST TRANSFER INFORMATION PAGE.....	50
5.5	USER CONFIGURABLE INDICATORS.....	51
6	OPERATION.....	52
6.1	CONTROL.....	52
6.2	CONTROL PUSH-BUTTONS.....	53
6.3	LOAD SHEDDING CONTROL.....	55
6.4	START INHIBIT/RESET.....	56
6.5	MANUAL MODE.....	57
6.5.1	STARTING SEQUENCE.....	57
6.5.2	S2 AVAILABLE.....	57
6.5.3	STOPPING SEQUENCE.....	58
6.6	AUTOMATIC MODE.....	59
6.6.1	WAITING IN AUTO MODE.....	59
6.6.2	STARTING SEQUENCE.....	59
6.6.3	S2 AVAILABLE.....	60
6.6.4	STOPPING SEQUENCE.....	60
6.7	MODE SELECTION.....	61
6.7.1	TEST ON LOAD.....	61
6.7.1.1	STARTING SEQUENCE.....	61
6.7.1.2	S2 AVAILABLE.....	61
6.7.1.3	STOPPING SEQUENCE.....	61

6.7.2	TEST OFF LOAD.....	62
6.7.2.1	STARTING SEQUENCE.....	62
6.7.2.2	S2 AVAILABLE.....	62
6.7.2.3	STOPPING SEQUENCE.....	62
6.7.3	PROHIBIT RETURN.....	63
6.7.3.1	WAITING IN PROHIBIT RETURN.....	63
6.7.3.2	STARTING SEQUENCE.....	63
6.7.3.3	S2 AVAILABLE.....	64
6.7.3.4	STOPPING SEQUENCE.....	64
7	PROTECTIONS.....	65
7.1	INDICATIONS.....	66
7.2	WARNINGS.....	67
7.3	ELECTRICAL TRIPS.....	68
8	SCHEDULER.....	69
8.1	STOP MODE.....	69
8.2	MANUAL MODE.....	69
8.3	AUTO MODE.....	69
9	FRONT PANEL CONFIGURATION.....	70
9.1	ACCESSING THE MAIN FRONT PANEL CONFIGURATION EDITOR.....	71
9.1.1	EDITING A PARAMETER.....	72
9.2	ADJUSTABLE PARAMETERS.....	73
10	COMMISSIONING.....	75
10.1	PRE-COMMISSIONING.....	75
11	FAULT FINDING.....	76
11.1	STARTING.....	76
11.2	LOADING.....	76
11.3	ALARMS.....	76
11.4	COMMUNICATIONS.....	77
11.5	INSTRUMENTS.....	77
11.6	MISCELLANEOUS.....	78
12	MAINTENANCE, SPARES, REPAIR AND SERVICING.....	79
12.1	PURCHASING ADDITIONAL CONNECTOR PLUGS FROM DSE.....	79
12.1.1	PACK OF PLUGS.....	79
12.1.2	INDIVIDUAL PLUGS.....	79
12.2	PURCHASING ADDITIONAL FIXING CLIPS FROM DSE.....	79
12.3	PURCHASING ADDITIONAL SEALING GASKET FROM DSE.....	79
12.4	DSENET EXPANSION MODULES.....	80
13	WARRANTY.....	81
14	DISPOSAL.....	81
14.1	WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT).....	81
14.2	ROHS (RESTRICTION OF HAZARDOUS SUBSTANCES).....	81

1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which can be obtained from the DSE website: www.deepseapl.com

1.1 INSTALLATION INSTRUCTIONS

Installation instructions are supplied with the product in the box and are intended as a 'quick start' guide only.

DSE Part	Description
053-135	DSE335 Installation Instructions
053-032	DSE2548 LED Expansion Annunciator Installation Instructions
053-033	DSE2130 Input Expansion Installation Instructions
053-034	DSE2157 Output Expansion Installation Instructions

1.2 TRAINING GUIDES

Training Guides are produced to give 'handout' sheets on specific subjects during training sessions

DSE Part	Description
056-005	Using CTs With DSE Products
056-022	Breaker Control
056-024	GSM Modem
056-030	Module PIN Codes

1.3 MANUALS

Product manuals are can be downloaded from the DSE website: www.deepseapl.com

DSE Part	Description
057-156	DSE335 Configuration Suite PC Software Manual
057-082	DSE2130 Input Expansion Manual
057-083	DSE2157 Output Expansion Manual
057-084	DSE2548 Annunciator Expansion Manual

1.4 THIRD PARTY DOCUMENTS

The following third party documents are also referred to:

Reference	Description
ISBN 1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Institute of Electrical and Electronics Engineers Inc
ISBN 0-7506-1147-2	Diesel generator handbook. L.L.J.Mahon
ISBN 0-9625949-3-8	On-Site Power Generation. EGSA Education Committee.

2 INTRODUCTION

This document details the installation and operation requirements of the DSE335 module, part of the **DSEAts®** range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. You will not be automatically informed of updates. Any future updates of this document will be included on the DSE website at www.deepseapl.com

The module is designed to provide differing levels of functionality across a common platform. This allows the OEM greater flexibility in the choice of controller to use for a specific application.

The module has been designed to allow the operator to control the transfer of the load from Source 1 (S1) to Source 2 (S2), typically the mains supply and a standby generator either manually (via fascia mounted push-buttons) or automatically upon S1 failure. Additionally if configured too, the module automatically starts and stops the generator set (S2) depending upon the status of S1.

The user also has the facility to view the system operating parameters via the LCD display to monitor the supplies and indicating the operational status and fault conditions of the module.

The powerful ARM microprocessor contained within the module allows for incorporation of a range of complex features:

- *Text based LCD display (supporting multiple languages).*
- **True RMS Voltage, Current and Power monitoring.**
- *Communications capability (RS485 or RS232)*
- *Multiple AC supply monitoring.*
- *Fully configurable inputs for use as alarms or a range of different functions.*

Using a PC and the DSE Configuration Suite PC Software allows alteration of selected operational sequences, timers, alarms and operational sequences. Additionally, the module's integral fascia configuration editor allows adjustment of a subset of this information.


A robust plastic case designed for front panel mounting houses the module. Connections are via locking plug and sockets..

Access to critical operational sequences and timers for use by qualified engineers, can be protected by a security code. Module access can also be protected by PIN code. Selected parameters can be changed from the module's front panel.

The module is housed in a robust plastic case suitable for panel mounting. Connections to the module are via locking plug and sockets.


3 SPECIFICATIONS

3.1 PART NUMBERING



At the time of this document production, there have been no revisions to the module hardware.

3.2 TERMINAL SPECIFICATION

Connection type	Two part connector. <ul style="list-style-type: none"> Male part fitted to module Female part supplied in module packing case - Screw terminal, rising clamp, no internal spring. 	 <p>Example showing cable entry and screw terminals of a 10 way connector</p>
Minimum cable size	0.5mm ² (AWG 24)	
Maximum cable size	2.5mm ² (AWG 10)	

NOTE: For purchasing additional connector plugs from DSE, please see the section entitled **Maintenance, Spares, Repair and Servicing** elsewhere in this document.

3.3 POWER SUPPLY REQUIREMENTS

Minimum supply voltage	8V continuous
Cranking dropouts	Able to survive 0V for 50mS providing the supply was at least 10V before the dropout and recovers to 5V afterwards.
Maximum supply voltage	35V continuous (60V protection)
Reverse polarity protection	-35V continuous
Maximum operating current	360mA at 24V 480mA at 12V
Maximum standby current	96mA at 24V 126mA at 12V

3.3.1 PLANT SUPPLY INSTRUMENTATION DISPLAY

Range	0V-70V DC (note Maximum continuous operating voltage of 35V DC)
Resolution	0.1V
Accuracy	1% full scale ($\pm 0.7V$)

3.4 S1 & S2 VOLTAGE / FREQUENCY SENSING

Measurement type	True RMS conversion
Sample Rate	5KHz or better
Harmonics	Up to 10 th or better
Input Impedance	300K Ω ph-N
Phase to Neutral	15V (minimum required for sensing frequency) to 333V AC (absolute maximum) Suitable for 110V to 277V nominal ($\pm 20\%$ for under/overvoltage detection)
Phase to Phase	26V (minimum required for sensing frequency) to 576V AC (absolute maximum) Suitable for 190V ph-ph to 479V ph-ph nominal ($\pm 20\%$ for under/overvoltage detection)
Common mode offset from Earth	100V AC (max)
Resolution	1V AC phase to neutral 2V AC phase to phase
Accuracy	$\pm 1\%$ of full scale phase to neutral $\pm 2\%$ of full scale phase to phase
Minimum frequency	3.5Hz
Maximum frequency	75.0Hz
Frequency resolution	0.1Hz
Frequency accuracy	$\pm 0.2Hz$

3.5 LOAD CURRENT SENSING

Measurement type	True RMS conversion
Sample Rate	5KHz or better
Harmonics	Up to 10 th or better
Nominal CT secondary rating	5A
Maximum continuous current	5A
Overload Measurement	15A for 100ms
Absolute maximum overload	50A for 1 second
Burden	0.5VA (0.02Ω current shunts)
common mode offset	±2V peak plant ground to CT common terminal
Resolution	25ma
Accuracy	±1% of Nominal (5A) (excluding CT error)

3.5.1 VA RATING OF THE CTS


The VA burden of the module on the CTs is 0.5VA. However depending upon the type and length of cabling between the CTs and the module, CTs with a greater VA rating than the module are required.

The distance between the CTs and the measuring module should be estimated and cross-referenced against the chart opposite to find the VA burden of the cable itself.

If the CTs are fitted within the alternator top box, the star point (common) of the CTs should be connected to system ground (earth) as close as possible to the CTs. This minimises the length of cable used to connect the CTs to the DSE module.

Example.

If 1.5mm² cable is used and the distance from the CT to the measuring module is 20m, then the burden of the cable alone is approximately 15VA. As the burden of the DSE controller is 0.5VA, then a CT with a rating of at least 15+0.5V = 15.5VA must be used. If 2.5mm² cables are used over the same distance of 20m, then the burden of the cable on the CT is approximately 7VA. CT's required in this instance is at least 7.5VA (7+0.5).




NOTE: Details for 4mm² cables are shown for reference only. The connectors on the DSE modules are only suitable for cables up to 2.5mm².

NOTE: CTs with 5A secondary windings are recommended with DSE modules. 1A CTs can be used if necessary however, the resolution of the readings is 5 times better when using 5A CTs.

3.5.2 CT POLARITY

Take care to ensure the correct polarity of the CTs. Incorrect CT orientation will lead to negative kW readings when the set is supplying power. Take note that paper stick-on labels on CTs that show the orientation are often incorrectly placed on the CT (!). It is more reliable to use the labelling in the case moulding as an indicator to orientation (if available).

To test orientation, place S1/S2 on load to around 10% of their rating. Ensure the DSE module shows positive kW for all three individual phase readings.



NOTE: Take care to ensure correct polarity of the CT primary as shown above. If in doubt, check with the CT supplier.

3.5.3 CT PHASING

Take particular care that the CTs are connected to the correct phases. For instance, ensure that the CT on phase 1 is connected to the terminal on the DSE module intended for connection to the CT for phase 1.

Additionally ensure that the voltage sensing for phase 1 is actually connected to S1/S2r phase 1.

Incorrect connection of the phases as described above will result in incorrect power factor (pf) measurements, which in turn results in incorrect kW measurements.

One way to check for this is to make use of a single-phase load. Place the load on each phase in turn of S1/S1 and ensure the kW value appears in the correct phase. For instance if the load is connected to phase 3, ensure the kW figure appears in phase 3 display and not in the display for phase 1 or 2.

3.5.4 CT CLASS

Ensure the correct CT type is chosen. For instance if the DSE module is providing overcurrent protection, ensure the CT is capable of measuring the overload level you wish to protect against, and at the accuracy level you require.

For instance, this may mean fitting a protection class CT (P10 type) to maintain high accuracy while the CT is measuring overload currents.

Conversely, if the DSE module is using the CT for instrumentation only (current protection is disabled or not fitted to the controller), then measurement class CTs can be used. Again, bear in mind the accuracy you require. The DSE module is accurate to better than 1% of the full-scale current reading. To maintain this accuracy you should fit Class 0.5 or Class 1 CTs.

You should check with your CT manufacturer for further advice on selecting your CTs

3.6 DIGITAL INPUTS

Number	12 Configurable negative or positive switching inputs in banks of 3 through PC Software
Arrangement	Contact between input terminal and the module's plant supply negative or positive terminal.
Low level threshold	3.2V minimum
High level threshold	8.1V maximum
Maximum input voltage	+60V DC with respect to module's plant supply negative terminal
Minimum input voltage	-2V DC with respect to module's plant supply negative terminal
Contact wetting current	7mA typical
Open circuit voltage	12V typical for negative activation. 0V typical for positive activation.

3.7 OUTPUTS

Twelve (12) outputs are fitted to the controller.

▲NOTE: Refer to Breaker Control Training Document (DSE part 056-022) for further details on configuring and control different type of load switching devices.

3.7.1 CONFIGURABLE OUTPUTS A & E

Number	2
Type	Fully configurable normally closed volt-free contacts.
Rating	8A resistive at 250V AC

3.7.2 CONFIGURABLE OUTPUTS B & F

Number	2
Type	Fully configurable normally open volt-free contacts.
Rating	8A resistive at 250V AC

3.7.3 CONFIGURABLE OUTPUTS C & D

Number	2
Type	Fully configurable volt-free changeover contacts.
Rating	8A resistive at 250V AC

3.7.4 CONFIGURABLE OUTPUTS G,H,I,J,K & L

Number	6
Type	Fully configurable DC Outputs
Rating	2A resistive at DC supply voltage.

3.8 COMMUNICATION PORTS

USB Port	USB2.0 Device for connection to PC running DSE configuration suite only Max distance 6m (yards)
Serial Communication	RS232 and RS485 are both fitted but and provide independent operation
RS232 Serial port	Non – Isolated port Max Baud rate 115200 baud subject to S/W TX, RX, RTS, CTS, DSR, DTR, DCD Male 9 way D type connector Max distance 15m (50 feet)
RS485 Serial port	Isolated Data connection 2 wire + common Half Duplex Data direction control for Transmit (by s/w protocol) Max Baud Rate 115200 External termination required (120Ω) Max common mode offset 70V (on board protection transorb) Max distance 1.2km (¾ mile)

3.8.1 USB CONNECTION

The USB port is provided to give a simple means of connection between a PC and the controller. Using the DSE Configuration Suite Software, the operator is then able to control the module, selecting operating modes, etc.

Additionally, the various operating parameters (such as output volts, current, etc.) of the remote ATS are available to be viewed or changed.

To connect a module to a PC by USB, the following items are required:

- DSE335 module
- DSE Configuration Suite PC Software (Supplied on configuration suite software CD or available from www.deepseapl.com).
- USB cable Type A to Type B.
(This is the same cable as often used between a PC and a USB printer)



DSE can supply this cable if required :
PC Configuration interface lead (USB type A – type B) DSE Part No 016-125

NOTE: The DC supply must be connected to the module for configuration by PC.

NOTE: Refer to DSE335 Series Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.

3.8.2 RS232

The RS232 port on the controller supports the Modbus RTU protocol. The Gencomm register table for the controller is available upon request from the DSE Technical Support Department.

RS232 is for short distance communication (max 15m) and is typically used to connect the controller to a telephone or GSM modem for more remote communications.

Many PCs are not fitted with an internal RS232 serial port. DSE DOES NOT recommend the use of USB to RS232 converters but can recommend PC add-ons to provide the computer with an RS232 port.

3.8.2.1 RECOMMENDED PC RS232 SERIAL PORT ADD-ONS

Remember to check these parts are suitable for your PC. Consult your PC supplier for further advice.

- Brainboxes PM143 PCMCIA RS232 card (for laptop PCs)
- Brainboxes VX-001 Express Card RS232 (for laptops and nettops PCs)
- Brainboxes UC246 PCI RS232 card (for desktop PCs)
- Brainboxes PX-246 PCI Express 1 Port RS232 1 x 9 Pin (for desktop PCs)



Supplier:

Brainboxes

Tel: +44 (0)151 220 2500

Web: <http://www.brainboxes.com>

Email: Sales: sales@brainboxes.com

NB DSE Have no business tie to Brainboxes. Over many years, our own engineers have used these products and are happy to recommend them.

3.8.2.2 RECOMMENDED EXTERNAL MODEMS:

- Multitech Global Modem – MultiModem ZBA (PSTN)
DSE Part Number 020-252
(Contact DSE Sales for details of localisation kits for these modems)
- Sierra Fastrak Xtend GSM modem kit (PSU, Antenna and modem)*
DSE Part number 0830-001-01



▲ NOTE: For GSM modems a SIM card is required, supplied by your GSM network provider

- For SMS only, a 'normal' voice SIM card is required. This enables the controller to send SMS messages to designated mobile phones upon status and alarm conditions.
- For a data connection to a PC running DSE Configuration Suite Software, a 'special' CSD (Circuit Switched Data) SIM card is required that will enable the modem to answer an incoming data call. Many 'pay as you go' services will not provide a CSD (Circuit Switched Data) SIM card.

3.8.3 RS485

The RS485 port on the series controller supports the Modbus RTU protocol.

The DSE Gencomm register table for the controller is available upon request from the DSE Technical Support Department.

RS485 is used for point-to-point cable connection of more than one device (maximum 32 devices) and allows for connection to PCs, PLCs and Building Management Systems (to name just a few devices).

One advantage of the RS485 interface is the large distance specification (1.2km when using Belden 9841 (or equivalent) cable. This allows for a large distance between the module and a PC running the DSE Configuration Suite software. The operator is then able to control the module, selecting operating modes, etc.

The various operating parameters (such as output volts, currents, etc.) of the remote ATS can be viewed or changed.

NOTE: For a single module to PC connection and distances up to 6m (8yds) the USB connection method is more suitable and provides for a lower cost alternative to RS485 (which is more suited to longer distance connections).

3.8.3.1 RECOMMENDED PC RS485 SERIAL PORT ADD-ONS

Remember to check these parts are suitable for your PC. Consult your PC supplier for further advice.

- Brainboxes PM154 PCMCIA RS485 card (for laptops PCs)
Set to 'Half Duplex, Autogating" with 'CTS True' set to 'enabled'
- Brainboxes VX-023 ExpressCard 1 Port RS422/485 (for laptops and nettop PCs)
- Brainboxes UC320 PCI Velocity RS485 card (for desktop PCs)
Set to 'Half Duplex, Autogating" with 'CTS True' set to 'enabled'
- Brainboxes PX-324 PCI Express 1 Port RS422/485 (for desktop PCs)



Supplier:

Brainboxes

Tel: +44 (0)151 220 2500

Web: <http://www.brainboxes.com>

Email: Sales: sales@brainboxes.com

NB DSE have no business tie to Brainboxes. Over many years,our own engineers have used these products and are happy to recommend them.

3.8.4 DSENET® FOR EXPANSION MODULES

DSENet® is the interconnection cable between the host controller and the expansion module(s) and must not be connect to any device other than DSE equipment designed for connection to the DSENet®

Cable type	Two core screened twisted pair
Cable characteristic impedance	120Ω
Recommended cable	Belden 9841 Belden 9271
Maximum cable length	1200m (¾ mile) when using Belden 9841 or direct equivalent. 600m (666 yds) when using Belden 9271 or direct equivalent.
DSENet® topology	“Daisy Chain” Bus with no stubs (spurs)
DSENet® termination	120Ω. Fitted internally to host controller. Must be fitted externally to the ‘last’ expansion module by the customer.
Maximum expansion modules	Total 6 devices made up of DSE2130 (up to 2), DSE2157 (up to 2), DSE2548 (up to 2) This gives the possibility of : Maximum 16 additional inputs (DSE2130) Maximum 20 additional relay outputs (DSE2157) Maximum 20 additional LED indicators (DSE2548)


NOTE: As a termination resistor is internally fitted to the host controller, the host controller must be the ‘first’ unit on the DSENet®. A termination resistor **MUST** be fitted to the ‘last’ unit on the DSENet®. For connection details, you are referred to the section entitled ‘typical wiring diagram’ elsewhere in this document.

3.9 ADDING AN EXTERNAL SOUNDER TO THE APPLICATION

Should an external alarm or indicator be required, this can be achieved by using the DSE Configuration Suite PC software to configure an auxiliary output for “Audible Alarm”, and by configuring an auxiliary input for “Alarm Mute” (if required).

The audible alarm output activates and de-activates at the same time as the module’s internal sounder. The Alarm mute input and internal alarm mute button activate ‘in parallel’ with each other. Either signal will mute both the internal sounder and audible alarm output.

Example of configuration to achieve external sounder with external alarm mute button:



3.10 DIMENSIONS AND MOUNTING

3.10.1 DIMENSIONS


240.0mm x 181.1mm x 41.7mm (9.4" x 7.1" x 1.6")

3.10.2 PANEL CUTOUT

220mm x 160mm (8.7" x 6.3")

3.10.3 WEIGHT


0.7kg (1.4lb)



3.10.4 FIXING CLIPS

The module is held into the panel fascia using the supplied fixing clips.

- Withdraw the fixing clip screw (turn anticlockwise) until only the pointed end is protruding from the clip.
- Insert the three 'prongs' of the fixing clip into the slots in the side of the module case.
- Pull the fixing clip backwards (towards the back of the module) ensuring all three prongs of the clip are inside their allotted slots.
- Turn the fixing clip screws clockwise until they make contact with the panel fascia.
- Turn the screws a little more to secure the module into the panel fascia. Care should be taken not to over tighten the fixing clip screws.



NOTE: In conditions of excessive vibration, mount the module on suitable anti-vibration mountings.


3.10.5 CABLE TIE FIXING POINTS

Integral cable tie fixing points are included on the rear of the module's case to aid wiring. This additionally provides strain relief to the cable loom by removing the weight of the loom from the screw connectors, thus reducing the chance of future connection failures.

Care should be taken not to over tighten the cable tie (for instance with cable tie tools) to prevent the risk of damage to the module case.



Cable tie fixing point




With cable and tie in place

3.10.6 SILICON SEALING GASKET

The supplied silicon gasket provides improved sealing between module and the panel fascia.

The gasket is fitted to the module before installation into the panel fascia.

Take care to ensure the gasket is correctly fitted to the module to maintain the integrity of the seal.



3.11 APPLICABLE STANDARDS

BS 4884-1	This document conforms to BS4884-1 1992 Specification for presentation of essential information.
BS 4884-2	This document conforms to BS4884-2 1993 Guide to content
BS 4884-3	This document conforms to BS4884-3 1993 Guide to presentation
BS EN 60068-2-1 (Minimum temperature)	-30°C (-22°F)
BS EN 60068-2-2 (Maximum temperature)	+70°C (158°F)
BS EN 60950	Safety of information technology equipment, including electrical business equipment
BS EN 61000-6-2	EMC Generic Immunity Standard (Industrial)
BS EN 61000-6-4	EMC Generic Emission Standard (Industrial)
BS EN 60529 (Degrees of protection provided by enclosures)	IP65 (front of module when installed into the control panel with the supplied sealing gasket) IP42 (front of module when installed into the control panel WITHOUT being sealed to the panel)
UL508 NEMA rating (Approximate)	12 (Front of module when installed into the control panel with the supplied sealing gasket). 2 (Front of module when installed into the control panel WITHOUT being sealed to the panel)
IEEE C37.2 (Standard Electrical Power System Device Function Numbers and Contact Designations)	<p>Under the scope of IEEE 37.2, <i>function numbers can also be used to represent functions in microprocessor devices and software programs.</i> The controller is device number 11L-8000 (Multifunction device protecting Line (generator) –module).</p> <p>As the module is configurable by the OEM, the functions covered by the module will vary. Under the module's factory configuration, the device numbers included within the module are :</p> <ul style="list-style-type: none"> 2 – Time delay starting or closing relay 3 – Checking or interlocking relay 8 – Control power disconnecting device 11 – Multifunction device 23 – Temperature control device (USING EXPANTION MODULE) 26 – Apparatus thermal device (USING EXPANTION MODULE) 27AC – AC undervoltage relay 27DC – DC undervoltage relay 29 – Isolating contactor or switch 30 – Annunciator relay 37 – Undercurrent or underpower relay (USING INTERNAL PLC EDITOR) 42 – Running circuit breaker 44 – Unit sequence relay 48 – Incomplete sequence relay 49 – Machine or transformer thermal relay (USING EXPANTION MODULE)

Continued overleaf.

Specification

IEEE C37.2 (Standard Electrical Power System Device Function Numbers and Contact Designations)	Continued... 50 – Instantaneous overcurrent relay (USING INTERNAL PLC EDITOR) 52 – AC circuit breaker 55 – Power factor relay (USING INTERNAL PLC EDITOR) 59AC – AC overvoltage relay 59DC – DC overvoltage relay 62 – Time delay stopping or opening relay 63 – Pressure switch (USING EXPANTION MODULE) 71 – Level switch (USING EXPANTION MODULE) 74 – Alarm relay 78 – Phase-angle measuring relay 79 – Reclosing relay (USING INTERNAL PLC EDITOR) 81 – Frequency relay 83 – Automatic selective control or transfer relay 86 – Lockout relay
---	---

In line with our policy of continual development, Deep Sea Electronics, reserve the right to change specification without notice.

3.11.1 ENCLOSURE CLASSIFICATIONS

IP CLASSIFICATIONS

The modules specification under **BS EN 60529** Degrees of protection provided by enclosures

IP65 (Front of module when module is installed into the control panel with the optional sealing gasket).

IP42 (front of module when module is installed into the control panel WITHOUT being sealed to the panel)

First Digit	Second Digit
Protection against contact and ingress of solid objects	Protection against ingress of water
0 No protection	0 No protection
1 Protected against ingress solid objects with a diameter of more than 50 mm. No protection against deliberate access, e.g. with a hand, but large surfaces of the body are prevented from approach.	1 Protection against dripping water falling vertically. No harmful effect must be produced (vertically falling drops).
2 Protected against penetration by solid objects with a diameter of more than 12 mm. Fingers or similar objects prevented from approach.	2 Protection against dripping water falling vertically. There must be no harmful effect when the equipment (enclosure) is tilted at an angle up to 15° from its normal position (drops falling at an angle).
3 Protected against ingress of solid objects with a diameter of more than 2.5 mm. Tools, wires etc. with a thickness of more than 2.5 mm are prevented from approach.	3 Protection against water falling at any angle up to 60° from the vertical. There must be no harmful effect (spray water).
4 Protected against ingress of solid objects with a diameter of more than 1 mm. Tools, wires etc. with a thickness of more than 1 mm are prevented from approach.	4 Protection against water splashed against the equipment (enclosure) from any direction. There must be no harmful effect (splashing water).
5 Protected against harmful dust deposits. Ingress of dust is not totally prevented but the dust must not enter in sufficient quantity to interfere with satisfactory operation of the equipment. Complete protection against contact.	5 Protection against water projected from a nozzle against the equipment (enclosure) from any direction. There must be no harmful effect (water jet).
6 Protection against ingress of dust (dust tight). Complete protection against contact.	6 Protection against heavy seas or powerful water jets. Water must not enter the equipment (enclosure) in harmful quantities (splashing over).

3.11.2 NEMA CLASSIFICATIONS

The modules NEMA Rating (Approximate)

12 (Front of module when module is installed into the control panel with the optional sealing gasket).

2 (front of module when module is installed into the control panel WITHOUT being sealed to the panel)



NOTE: There is no direct equivalence between IP / NEMA ratings. IP figures shown are approximate only.

1 IP30	Provides a degree of protection against contact with the enclosure equipment and against a limited amount of falling dirt.
2 IP31	Provides a degree of protection against limited amounts of falling water and dirt.
3 IP64	Provides a degree of protection against windblown dust, rain and sleet; undamaged by the formation of ice on the enclosure.
3R IP32	Provides a degree of protection against rain and sleet;; undamaged by the formation of ice on the enclosure.
4 (X) IP66	Provides a degree of protection against splashing water, windblown dust and rain, hose directed water; undamaged by the formation of ice on the enclosure. (Resist corrosion).
12/12K IP65	Provides a degree of protection against dust, falling dirt and dripping non corrosive liquids.
13 IP65	Provides a degree of protection against dust and spraying of water, oil and non corrosive coolants.


4 INSTALLATION

The module is designed to be mounted on the panel fascia. For dimension and mounting details, see the section entitled *Specification, Dimension and mounting* elsewhere in this document.



4.1 TERMINAL DESCRIPTION

To aid user connection, icons are used on the rear of the module to help identify terminal functions. An example of this is shown below.


NOTE: Availability of some terminals depends upon module version. Full details are given in the section entitled *Terminal Description* elsewhere in this manual.





4.1.1 DC SUPPLY, OUTPUTS G-L

	Pin No.	Description	Cable Size	Notes
	1	DC Plant Supply Input (Negative)	2.5mm ² AWG 13	
	2	DC Plant Supply Input (Positive)	2.5 mm ² AWG 13	(Recommended Maximum Fuse 15A anti-surge) Supplies the module (2A anti-surge requirement) and Output relays G,H,I, J, K & L
	3	Output relay G	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.
	4	Output relay H	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.
	5	Output relay I	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.
	6	Output relay J	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.
	7	Output relay K	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.
	8	Output relay L	1.0mm ² AWG 18	Plant Supply Positive from terminal 2. 2 Amp rated.

4.1.2 CONFIGURABLE DIGITAL INPUTS A-I



	Pin No.	Description	Cable Size	Notes
	9	Configurable digital input A	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	10	Configurable digital input B	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	11	Configurable digital input C	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	12	Configurable digital input D	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	13	Configurable digital input E	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	14	Configurable digital input F	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	15	Configurable digital input G	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	16	Configurable digital input H	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	17	Configurable digital input I	0.5mm ² AWG 20	Switch to negative or positive depending on configuration

4.1.3 CONFIGURABLE DIGITAL INPUTS J-K, DSENET

	Pin No.	Description	Cable Size	Notes
	18	Configurable digital input A	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	19	Configurable digital input B	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	20	Configurable digital input C	0.5mm ² AWG 20	Switch to negative or positive depending on configuration
	21	DSENet expansion B (+)	0.5mm ² AWG 20	Use only 120Ω RS485 approved cable
	22	DSENet expansion A (-)	0.5mm ² AWG 20	Use only 120Ω RS485 approved cable
	23	DSENet expansion SCR	0.5mm ² AWG 20	Use only 120Ω RS485 approved cable



 **NOTE: Terminal 24 is not used, do not connect.**

4.1.4 CONFIGURABLE VOLT-FREE OUTPUTS E & F

	Pin No.	Description	Cable Size	Notes
	25	Output relay E	1.0mm AWG 18	Normally closed volt-free relay user configured (8A resistive at 250V AC rated)
	26	Output relay E	1.0mm AWG 18	Normally closed volt-free relay user configured (8A resistive at 250V AC rated)
	28	Output relay F	1.0mm AWG 18	Normally open volt-free relay user configured (8A resistive at 250V AC rated)
	29	Output relay F	1.0mm AWG 18	Normally open volt-free relay user configured (8A resistive at 250V AC rated)

 **NOTE: Terminal 27 is not used, do not connect.**

4.1.5 LOAD SWITCHING AND S2 VOLTAGE SENSING

	Pin No.	Description	Cable Size	Notes
	30	Output relay A	1.0mm AWG 18	Normally configured to control S1 contactor coil (Recommend 10A fuse)
	31	Output relay A	1.0mm AWG 18	Normally configured to control S1 contactor coil
	32	Output relay B	1.0mm AWG 18	Normally configured to control S2 contactor coil (Recommend 10A fuse)
	33	Output relay B	1.0mm AWG 18	Normally configured to control S2 contactor coil
S2	34	S2 L1 (U) voltage monitoring	1.0mm ² AWG 18	Connect to S2 L1 (U) output (AC) (Recommend 2A fuse)
	35	S2 L2 (V) voltage monitoring input	1.0mm ² AWG 18	Connect to S2 L2 (V) output (AC) (Recommend 2A fuse)
	36	S2 L3 (W) voltage monitoring input	1.0mm ² AWG 18	Connect to S2 L3 (W) output (AC) (Recommend 2A fuse)
	37	S2 Neutral (N) input	1.0mm ² AWG 18	Connect to S2 Neutral terminal (AC)


 **NOTE: The above table describes connections to a three phase, four wire alternator. For alternative wiring topologies, please see the ALTERNATIVE AC TOPOLOGIES section of this manual.**


4.1.6 S1 VOLTAGE SENSING


	Pin No.	Description	Cable Size	Notes
S1	38	S1 L1 (R) voltage monitoring	1.0mm AWG 18	Connect to S1 L1 (R) incoming supply (AC) (Recommend 2A fuse)
	39	S1 L2 (S) voltage monitoring	1.0mm AWG 18	Connect to S1 L1 (S) incoming supply (AC) (Recommend 2A fuse)
	40	S1 L3 (T) voltage monitoring	1.0mm AWG 18	Connect to S1 L1 (T) incoming supply (AC) (Recommend 2A fuse)
	41	S1 Neutral (N) input	1.0mm AWG 18	Connect to S1 N incoming supply (AC)

 **NOTE:** The above table describes connections to a three phase, four wire alternator. For alternative wiring topologies, please see the **ALTERNATIVE AC TOPOLOGIES** section of this manual.

4.1.7 LOAD CURRENT TRANSFORMERS


 **WARNING!** Do not disconnect this plug when the CTs are carrying current. Disconnection will open circuit the secondary of the C.T.'s and dangerous voltages may then develop. Always ensure the CTs are not carrying current and the CTs are short circuit connected before making or breaking connections to the module.

 **NOTE:** The module has a burden of 0.5VA on the CT. Ensure the CT is rated for the burden of the controller, the cable length being used and any other equipment sharing the CT. If in doubt, consult your CT supplier.

	Pin No.	Description	Cable Size	Notes
	42	CT Secondary for Load L1	2.5mm ² AWG 13	Connect to s1 secondary of L1 monitoring CT
	43	CT Secondary for Load L2	2.5mm ² AWG 13	Connect to s1 secondary of L2 monitoring CT
	44	CT Secondary for Load L3	2.5mm ² AWG 13	Connect to s1 secondary of L3 monitoring CT

4.1.7.1 CONNECTION TO TERMINALS 45 & 46/47

The function of terminals 45 & 46/47 change position depending upon wiring topology as follows:

	Topology	Pin No.	Description	Cable Size
	No earth fault measuring	45	DO NOT CONNECT	
		46/47	Connect to s2 of the CTs connected to L1,L2,L3,N	2.5mm ² AWG 13
	Restricted earth fault measuring	45	Connect to s2 of the CTs connected to L1,L2,L3,N	2.5mm ² AWG 13
		46/47	Connect to s1 of the CT on the neutral conductor	2.5mm ² AWG 13
	Un-restricted earth fault measuring (Earth fault CT is fitted in the neutral to earth link)	45	Connect to s1 of the CT on the neutral to earth conductor.	2.5mm ² AWG 13
		46/47	Connect to s2 of the CT on the neutral to earth link. Also connect to the s2 of CTs connected to L1, L2, L3.	2.5mm ² AWG 13


4.1.7.2 CT CONNECTIONS

p1, κ or K is the primary of the CT that 'points' towards the SUPPLY



p2, ℓ or L is the primary of the CT that 'points' towards the LOAD

s1 is the secondary of the CT that connects to the DSE Module's input for the CT measuring (I1,I2,I3)

s2 is the secondary of the CT that should be commoned with the s2 connections of all the other CTs and connected to the CT common terminal of the module.





4.1.8 CONFIGURABLE VOLT-FREE CHANGEOVER OUTPUTS C & D

	Pin No.	Description	Cable Size	Notes
	48	Output C Normally Open	1.0mm ² AWG 18	Volts free relay change-over relay user configured (8A resistive at 250V AC rated)
	49	Output C Common	1.0mm ² AWG 18	
	50	Output C Normally Closed	1.0mm ² AWG 18	
	51	Output D Normally Open	1.0mm ² AWG 18	Volts free relay change-over relay user configured (8A resistive at 250V AC rated)
	52	Output D Common	1.0mm ² AWG 18	
	53	Output D Normally Closed	1.0mm ² AWG 18	

NOTE: Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for the full range of configurable outputs available.

4.1.9 PC CONFIGURATION INTERFACE CONNECTOR

	Description	Cable Size	Notes
	Socket for connection to PC with DSE Configuration Suite Software	0.5mm ² AWG 20	This is a standard USB type A to type B connector. 


NOTE: The USB connection cable between the PC and the module must not be extended beyond 5m (yards). For distances over 5m, it is possible to use a third party USB extender. Typically, they extend USB up to 50m (yards). The supply and support of this type of equipment is outside the scope of Deep Sea Electronics PLC.

CAUTION!: Care must be taken not to overload the PC's USB system by connecting more than the recommended number of USB devices to the PC. For further information, consult your PC supplier.

CAUTION!: This socket must not be used for any other purpose.


4.1.10 RS485 CONNECTOR

Pin No.	Notes
A (-)	Two core screened twisted pair cable. 120Ω impedance suitable for RS485 use. Recommended cable type - Belden 9841 Max distance 1200m (1.2km) when using Belden 9841 or direct equivalent.
B (+)	
SCR	



4.1.11 RS232 CONNECTOR

Pin No.	Notes
1	Received Line Signal Detector (Data Carrier Detect)
2	Received Data
3	Transmit Data
4	Data Terminal Ready
5	Signal Ground
6	Data Set Ready
7	Request To Send
8	Clear To Send
9	Ring Indicator



View looking into the male connector on the module

4.2 TYPICAL WIRING DIAGRAMS


As every system has different requirements, these diagrams show only a TYPICAL system and do not intend to show a complete system.

Panel builders may use these diagrams as a starting point; however, you are referred to the completed system diagram provided by your system manufacturer for complete wiring detail.

Further wiring suggestions are available in the following DSE publications, available at www.deepseapl.com to website members.

DSE Part	Description
056-022	Breaker Control (Training guide)

4.2.1 DSE335 3 PHASE, 4 WIRE WITH RESTRICTED EARTH FAULT PROTECTION




NOTE: Earthing the neutral conductor ‘before’ the neutral CT allows the module to read earth faults ‘after’ the CT only (Restricted to load / downstream of the CT)
 Earthing the neutral conductor ‘after’ the neutral CT allows the module to read earth faults ‘before’ the CT only (Restricted to source / upstream of the CT)

4.3 ALTERNATIVE TOPOLOGIES

The controller is factory configured to connect to a 3 phase, 4 wire Star connected alternator. This section details connections for alternative AC topologies. Ensure to configure the controller to suit the required topology.


NOTE: Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.

4.3.1 3 PHASE, 4 WIRE WITHOUT EARTH FAULT PROTECTION




4.3.2 SINGLE PHASE WITH RESTRICTED EARTH FAULT

NOTE: Earthing the neutral conductor 'before' the neutral CT allows the module to read earth faults 'after' the CT only (Restricted to load / downstream of the CT)
 Earthing the neutral conductor 'after' the neutral CT allows the module to read earth faults 'before' the CT only (Restricted to source / upstream of the CT)




4.3.3 SINGLE PHASE WITHOUT EARTH FAULT




4.3.4 2 PHASE (L1 & L2) 3 WIRE WITH RESTRICTED EARTH FAULT

NOTE: Earthing the neutral conductor 'before' the neutral CT allows the module to read earth faults 'after' the CT only (Restricted to load / downstream of the CT)
 Earthing the neutral conductor 'after' the neutral CT allows the module to read earth faults 'before' the CT only (Restricted to source / upstream of the CT)




4.3.5 2 PHASE (L1 & L2) 3 WIRE WITHOUT EARTH FAULT




4.3.6 2 PHASE (L1 & L3) 3 WIRE WITH RESTRICTED EARTH FAULT

NOTE: Earthing the neutral conductor 'before' the neutral CT allows the module to read earth faults 'after' the CT only (Restricted to load / downstream of the CT)
 Earthing the neutral conductor 'after' the neutral CT allows the module to read earth faults 'before' the CT only (Restricted to source / upstream of the CT)




4.3.7 2 PHASE (L1 & L3) 3 WIRE WITHOUT EARTH FAULT MEASURING



4.3.8 3 PHASE 4 WIRE WITH UNRESTRICTED EARTH FAULT MEASURING

NOTE: Unrestricted Earth Fault Protection detects earth faults in the load and in the sources. Be sure to measure the natural earth fault of the site before deciding upon an earth fault alarm trip level.



4.4 EARTH SYSTEMS

4.4.1 NEGATIVE EARTH

The typical wiring diagrams located within this document show connections for a negative earth system (the battery negative connects to Earth)

4.4.2 POSITIVE EARTH

When using a DSE module with a Positive Earth System (the battery positive connects to Earth), the following points must be followed:

- Follow the typical wiring diagram as normal for all sections EXCEPT the earth points
- All points shown as Earth on the typical wiring diagram should connect to BATTERY NEGATIVE (not earth).

4.4.3 FLOATING EARTH

Where neither the battery positive nor battery negative terminals are connected to earth the following points must be followed


- Follow the typical wiring diagram as normal for all sections EXCEPT the earth points
- All points shown as Earth on the typical wiring diagram should connect to BATTERY NEGATIVE (not earth).

4.5 TYPICAL ARRANGEMENT OF DSENET®

Six (6) devices can be connected to the DSENet®, made up of the following devices :



Device	Max Number Supported
DSE2130 Input Expansion	2
DSE2157 Relay Output Expansion	2
DSE2548 LED Expansion	2

For part numbers of the expansion modules and their documentation, see section entitled *DSENet Expansion Modules* elsewhere in this manual.



5 DESCRIPTION OF CONTROLS

5.1 DSE335 ATS MODULE



5.2 QUICKSTART GUIDE

This section provides a quick start guide to the module's operation.

5.2.1 STARTING THE S2

NOTE: This only applies when S2 is configured as a generator supply.



NOTE: For further details, see the section entitled 'OPERATION' elsewhere in this manual.


5.2.2 STOPPING S2



NOTE: For further details, see the section entitled 'OPERATION' elsewhere in this manual.

5.3 VIEWING THE INSTRUMENT PAGES

It is possible to scroll to display the different pages of information by repeatedly operating the next /



Example




The complete order and contents of each information page are given in the following sections

Once selected the page will remain on the LCD display until the user selects a different page, or after an extended period of inactivity (*LCD Page Timer*), the module will revert to the status display.



If no buttons are pressed upon entering an instrumentation page, the instruments will be displayed automatically subject to the setting of the *LCD Scroll Timer*.

The *LCD Page* and *LCD Scroll* timers are configurable using the DSE Configuration Suite Software or by using the Front Panel Editor.



The screenshot shows the factory settings for the timers, taken from the DSE Configuration Suite Software.

Alternatively, to scroll manually through all instruments on the currently selected page, press the scroll



To re-enable 'autoscroll' press the scroll buttons to scroll to the 'title' of the instrumentation page (ie S1). A short time later (the duration of the *LCD Scroll Timer*), the instrumentation display will begin to autoscroll.

When scrolling manually, the display will automatically return to the Status page if no buttons are pressed for the duration of the configurable *LCD Page Timer*.

If an alarm becomes active while viewing the status page, the display shows the Alarms page to draw the operator's attention to the alarm condition.

5.3.1 STATUS

This is the 'home' page, the page that is displayed when no other page has been selected, and the page that is automatically displayed after a period of inactivity (*LCD Page Timer*) of the module control buttons.

This page will change with the action of the controller, when S1 is on load, S1 parameters will be seen and when changing to S2 on load, the S2 parameters will be shown.


No Start Request		
S1 Closed		
L-N	230V	40A
L-L	400V	50.0Hz

Example of the first status screen showing no start request to S2 and S1 closed supplying the load...

S2 Available		
S2 Closed		
L-N	229V	40A
L-L	399V	50.1Hz

... and showing S2 on load.



Press  to access more status information about two supplies.

S1	Auto	S2
230v		229v
50.0Hz		50.1Hz
40A		0A

Example of the second status screen which shows which mode the controller is in and an overview of each supply

5.3.2 S1

Contains electrical values of S1 measured or derived from the module's voltage and current inputs.

- S1 Voltage (ph-N)
- S1 Voltage (ph-ph)
- S1 Frequency
- S1 Current
- S1 Earth Current
- S1 Load (ph-N kW)
- S1 Load (Total kW)
- S1 Load (ph-N kVA)
- S1 Load (Total kVA)
- S1 Power Factor
- S1 Power Factor Average
- S1 Load (ph-N kVAr)
- S1 Load (Total kVAr)
- S1 Load (kWh, kVAh, kVArh)
- Battery Voltage

5.3.3 S2

Contains electrical values of S2 measured or derived from the module's voltage and current inputs.

- S2 Voltage (ph-N)
- S2 Voltage (ph-ph)
- S2 Frequency
- S2 Current
- S2 Earth Current
- S2 Load (ph-N kW)
- S2 Load (Total kW)
- S2 Load (ph-N kVA)
- S2 Load (Total kVA)
- S2 Power Factor
- S2 Power Factor Average
- S2 Load (ph-N kVAr)
- S2 Load (Total kVAr)
- S2 Load (kWh, kVAh, kVArh)

5.3.4 EXPANSION

Contains the measured value of the expansion module's analogue inputs, this could be pressure, percentage or temperature for example '*Bulk Fuel Level*'.

5.3.5 ALARMS

Contains the alarms currently present on the module. For more information please see the section entitled '*Protections*' else where in this manual.

5.3.6 EVENT LOG

The module maintains a log of past alarms and/or selected status changes. At the time of writing, the modules log is capable of storing the last 250 log entries.

Under default factory settings, the event log only includes shutdown and electrical trip alarms logged (The event log does not contain Warning alarms); however, this is configurable by the system designer using the DSE Configuration Suite software.





Example showing the possible configuration of the modules event log (DSE Configuration Suite Software) This also shows the factory settings of the module (Only shutdown alarms and the mains status are logged).

Once the log is full, any subsequent shutdown alarms will overwrite the oldest entry in the log. Hence, the log will always contain the most recent shutdown alarms. The module logs the alarm, along with the date and time of the event (or engine running hours if configured to do so). If the module is configured and connected to send SMS text

To view the event log, repeatedly press the next page button



until the LCD screen displays the Event log :



Press down to view the next most recent shutdown alarm:

Continuing to press down cycles through the past alarms after which the display shows the most recent alarm and the cycle begins again.

To exit the event log and return to viewing the instruments, press the next page button to select the next instrumentation page.



5.3.7 SERIAL PORT

5.3.7.1 RS232 SERIAL PORT

This section is included to give information about the RS232 serial port and external modem (if connected).

The items displayed on this page will change depending upon configuration of the module. You are referred to your system supplier for further details.

NOTE:- Factory Default settings are for the RS232 port to be enabled with no modem connected, operating at 19200 baud, modbus slave address 10.

Example 1 – Module connected to an RS232 telephone modem.

When the module is powered up, it will send 'initialisation strings' to the connected modem. It is important therefore that the modem is already powered, or is powered up at the same time as the module. At regular intervals after power up, the modem is reset, and reinitialised, to ensure the modem does not 'hang up'.

If the module does not correctly communicate with the modem, "Modem initialising" appears on the Serial Port instrument screen as shown overleaf.

If the module is set for "incoming calls" or for "incoming and outgoing calls", then if the modem is dialled, it will answer after two rings (using the factory setting 'initialisation strings'). Once the call is established, all data is passed from the dialling PC and the module.

If the module is set for "outgoing calls" or for "incoming and outgoing calls", then the module will dial out whenever an alarm is generated. Note that not all alarms will generate a dial out; this is dependant upon module configuration of the event log. Any item configured to appear in the event log will cause a dial out.

Serial Port	
Baud	9600
SlaveID	10
Modem	




Press down  to view the modem status....

Indicates that a modem is configured. Shows 'RS232' if no modem is configured.

Example 1 continued – Modem diagnostics



Modem diagnostic screens are included; press  when viewing the *RS232 Serial Port* instrument to cycle the available screens. If you are experiencing modem communication problems, this information will aid troubleshooting.

Serial Port	
RTS	DTR
CTS	DCD
DSR	

Shows the state of the modem communication lines. These can help diagnose connection problems.

Example:

RTS A dark background shows the line is active.

RTS a grey background shows that the line is toggling high and low.


RTS No background indicates that the line is inactive

Line	Description	
RTS	Request To Send	Flow control
CTS	Clear To Send	Flow control
DSR	Data Set Ready	Ready to communicate
DTR	Data Terminal Ready	Ready to communicate
DCD	Data Carrier Detect	Modem is connected


Modem Commands
Rx: OK
Tx: AT+IPR=9600
Rx: OK

Shows the last command sent to the modem and the result of the command.


Modem Setup Sequence



If the Modem and module communicate successfully:




In case of communication failure between the modem and module, the modem is automatically reset and initialisation is attempted once more:



In the case of a module that is unable to communicate with the modem, the display will continuously cycle between 'Modem Reset' and 'Modem Initialising' as the module resets the modem and attempts to communicate with it again, this will continue until correct communication is established with the modem.


In this instance, you should check connections and verify the modem operation.

Example 2 – Module connected to a modem.



Example 3 – Modem status of a GSM modem

Currently connected GSM operator and signal strength.



Many GSM modems are fitted with a status LED to show operator cell status and ringing indicator. These can be a useful troubleshooting tool.

In the case of GSM connection problems, try calling the DATA number of the SIMCARD with an ordinary telephone. There should be two rings, followed by the modem answering the call and then 'squealing'. If this does not happen, you should check all modem connections and double check with the SIM provider that it is a DATA SIM and can operate as a data modem. DATA is NOT the same as FAX or GPRS and is often called Circuit Switched Data (CSD) by the SIM provider.

NOTE: In the case of GSM modems, it is important that a DATA ENABLED SIM is used. This is often a different number than the 'voice number' and is often called Circuit Switched Data (CSD) by the SIM provider.

If the GSM modem is not purchased from DSE, ensure that it has been correctly set to operate at 9600 baud.

5.3.7.2 RS485 SERIAL PORT

This section is included to give information about the currently selected serial port and external modem (if connected).

The items displayed on this page will change depending upon configuration of the module. You are referred to your system supplier for further details.

NOTE: Factory Default settings are for the RS485 port to operating at 19200 baud, modbus slave address 10.

Module RS485 port configured for connection to a modbus master.

The modules operate as a modbus RTU slave device. In a modbus system, there can be only one Master, typically a PLC, HMI system or PC SCADA system.

Serial Port	
Baud	19200
SlaveID	1
	RS485

This master requests for information from the modbus slave (The module) and may (in control systems) also send request to change operating modes etc. Unless the Master makes a request, the slave is 'quiet' on the data link.

The factory settings are for the module to communicate at 19200 baud, modbus slave address 10. To use the RS485 port, ensure that 'port usage' is correctly set using the DSE Configuration Suite Software.

Required settings are shown below.

The screenshot shows a 'Serial Port Configuration' window with three settings: 'Slave ID' is set to 1, 'Baud Rate' is set to 19200, and 'Port Usage' is set to RS485.

'Master inactivity timeout' should be set to at least twice the value of the system scan time. For example if a modbus master PLC requests data from the module once per second, the timeout should be set to at least 2 seconds.

The DSE Modbus Gencomm document containing register mappings inside the DSE module is available upon request from support@deepseapl.com. Email your request along with the serial number of your DSE module to ensure the correct information is sent to you.

Typical requests (using Pseudo code)

BatteryVoltage=ReadRegister(10,0405,1) : reads register (hex) 0405 as a single register (battery volts) from slave address 10.

WriteRegister(10,1008,2,35701, 65535-35701) : Puts the module into AUTO mode by writing to (hex) register 1008, the values 35701 (auto mode) and register 1009 the value 65535-35701 (the bitwise opposite of auto mode)

Shutdown=(ReadRegister(10,0306,1) >> 12) & 1) : reads (hex) 0306 and looks at bit 13 (shutdown alarm present)

Warning=(ReadRegister(10,0306,1) >> 11) & 1) : reads (hex) 0306 and looks at bit 12 (Warning alarm present)

ElectricalTrip=(ReadRegister(10,0306,1) >> 10) & 1) : reads (hex) 0306 and looks at bit 11 (Electrical Trip alarm present)

ControlMode=ReadRegister(10,0304,2); reads (hex) register 0304 (control mode).

5.3.8 SCHEDULER

Contains the current schedule plan for S2 configured in module.

2/3	Schedule	10:39
Off Load		Week 3
On 12:00	Run Time	00:30
	M T W T F S S	

Example of the 3rd scheduled operation in bank 2 for S2.


5.3.9 ABOUT

Contains important information about the module and the firmware versions. This information may be asked for when contacting DSE Technical Support Department for advice.

About	
Variant	335
Application	V3.0.20
USB ID	BC614E

- Variant – 335
- Application Version – The version of the module's main firmware file (Updatable using the Firmware Update Wizard in the DSE Configuration Suite Software).
- USB ID – Unique identifier for PC USB connection




Press  to access more information about the module.

About	
Bootloader	V1.3.4
Analogue	V2.0.0

- Bootloader - Firmware Update bootloader software version
- Analogue – Analogue measurements software version

5.4 VIEWING LATEST TRANSFER INFORMATION PAGE

It is possible to view the reason, time, date and duration of the latest transfer by pressing and holding the 'LATEST TRANSFER INFORMATION '. The page will stay displayed for the duration the button is held in.

Latest Transfer
S1 Under Voltage
22 Mar 2012, 12:59:47
00:27:13

Example of the Latest Transfer page which shows that there was a transfer cause by an S1 Under Voltage failure which lasted for 27 minutes and 13 seconds.

5.5 USER CONFIGURABLE INDICATORS

These LEDs can be configured by the user to indicate any one of **100+ different functions** based around the following:-

- **Indications** - Monitoring of a digital input and indicating associated functioning user's equipment - *Such as Battery Charger On or Louvres Open, etc.*
- **WARNINGS & ELECTRICAL TRIPS** - Specific indication of a particular warning or electrical trip condition, backed up by LCD indication - *Such as S2 Under Voltage Trip, Transformer Over Temperature, etc.*
- **Status Indications** - Indication of specific functions or sequences derived from the modules operating state - *Such as, Panel Locked, S2 Available, etc.*



6 OPERATION

6.1 CONTROL

Control of the module is via push buttons mounted on the front of the module with **START INHIBIT/RESET** (⊘), **MANUAL** (☞), **AUTO** (AUTO), **MODE** (Mode), **ALARM MUTE** (🔇), **LATEST TRANSFER INFORMATION** (i), **CLOSE/OPEN S1** (S1) and **CLOSE/OPEN S2** (S2) functions. For normal operation, these are the only controls which need to be operated. The smaller push buttons are used to access further information such as mains voltage or to change the state of the load switching devices when in manual mode. Details of their operation are provided later in this document.













The following descriptions detail the sequences followed by a module containing the standard 'factory configuration'. Always refer to your configuration source for the exact sequences and timers observed by any particular module in the field.












⚠ CAUTION: - The module may instruct an engine start event due to external influences. Therefore, it is possible for the engine to start at any time without warning. Prior to performing any maintenance on the system, it is recommended that steps are taken to remove the battery and isolate supplies.

⚠ NOTE: - This control module has PLC functionality built in. This can have change the standard operation when used. (Default configuration the no PLC is set. See software manual for more information)

6.2 CONTROL PUSH-BUTTONS

Description	Button
<p>Start Inhibit/Reset</p> <p>This button places the module into its ‘START INHIBIT/RESET ’ mode. This will clear any alarm conditions for which the triggering criteria have been removed. If S2 is on load and the module is placed into Stop mode, the module will automatically instruct the changeover device to unload S2 (‘Close S2 Output’ becomes inactive (if used)). If S2 is configured for a generator, the start signal given to the generator controller will also be removed. Should a remote start signal be present while operating in this mode, a remote start will <u>not</u> occur.</p>	
<p>Manual</p> <p>This button places the module into its ‘MANUAL ’ mode to allow manual control of the ATS functions. This will start S2 if configured as a generator, and run it off load.</p> <p>If the S2 is available off-load in the ‘MANUAL ’ mode and a remote start on load signal becomes present, the module will automatically instruct the changeover device to place S2 on load (‘Close S2 Output’ becomes active (if used)). Upon removal of the remote start signal, S2 remains on load until either selection of the ‘START INHIBIT/RESET ’ or ‘AUTO ’ modes.</p> <p><i>For further details, please see the more detailed description of ‘Manual operation’ elsewhere in this manual.</i></p>	
<p>Auto</p> <p>This button places the module into its ‘AUTO ’ mode. This mode allows the module to control the function of S1 and S2 automatically. The module will monitor the <i>remote start</i> input and S1 supply status and once a start request is made, a start request will be given to S2 if configured to a generator and once available, placed on load.</p> <p>Upon removal of the starting signal, the module will automatically transfer the load from S2 and remove the start signal to the generator observing the <i>stop delay</i> timer and <i>cooling</i> timer as necessary. The module will then await the next start event.</p> <p><i>For further details, please see the more detailed description of ‘Auto operation’ elsewhere in this manual.</i></p>	
<p>Mode</p> <p>This button allows the user to cycle through different operating ‘MODE ’ and press the TICK ‘’ to accept the mode change.</p> <p>The modes available are:</p> <p>Test On Load: This mode allows the module start and load S2 for test purposes.</p> <p>Test Off Load: This mode allows the module start S2 and leave off load for test purposes.</p> <p>Prohibit Return: This mode is used to prevent the module from returning load the S1 until instructed.</p> <p><i>For further details, please see the more detailed description of ‘Mode operation’ elsewhere in this manual.</i></p>	

Description	Button
<p>Mute / Lamp Test This button silences the audible alarm if it is sounding and illuminates all of the LEDs as a lamp test feature.</p>	
<p>Latest Transfer Information Whilst pressing this button, the module will display the reason, time, date and duration for the latest transfer that occurred.</p> <p><i>For further details, please see the more detailed description of 'Viewing Latest Transfer Information Page' elsewhere in this manual.</i></p>	
<p>Close/Open to S1</p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 10px;"> <p>NOTE: - This button will only operate in manual mode.</p> </div> <p>Pressing the 'CLOSE/OPEN S1 ' button when S1 is on load will open the S1 load switch.</p> <p>Pressing the 'CLOSE/OPEN S1 ' button when S2 is on load and S1 is healthy, the S2 load switch will open, wait for the duration of the <i>transfer delay</i>, then close the S1 load switch.</p> <p><i>For further details, please see the more detailed description of 'Manual operation' elsewhere in this manual.</i></p>	
<p>Close/Open to S2</p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 10px;"> <p>NOTE: - This button will only operate in manual mode.</p> </div> <p>Pressing the 'CLOSE/OPEN S2 ' button when S2 is on load will open the S2 load switch.</p> <p>Pressing the 'CLOSE/OPEN S2 ' button when S1 is on load and S2 is healthy, the S1 load switch will open, wait for the duration of the <i>transfer delay</i>, then close the S2 load switch.</p> <p><i>For further details, please see the more detailed description of 'Manual operation' elsewhere in this manual.</i></p>	
<p>Menu navigation</p> <p>Used for navigating the instrumentation, event log and configuration screens. For further details, please see the more detailed description of these items elsewhere in this manual.</p>	

6.3 LOAD SHEDDING CONTROL

This feature may be enabled by the system designer to ensure the loading on S2 is kept to a nominal amount. Conversely as the load increases towards the maximum rating of the set, non-essential loads can be shed to prevent overload of S2.

6.2.2 LOAD SHEDDING CONTROL

The *Load Shedding Control* feature (if enabled) allows for a maximum of five load shedding steps. When S2 is about to take load, the configured number of *Load Shedding Control Outputs at Startup* will energise. This configurable setting allows (for instance) certain loads to be removed from S2 prior to the set's load switch being closed. This can be used to ensure the initial loading of the set is kept to a minimum, below the *Load Acceptance* specification of S2.

S2 is then placed on load. The *Load Shedding Control* scheme begins. When the load reaches the *Load Shedding Trip* level the *Trip Delay* timer will start. If S2 loading is still high when the timer expires, the first *Load shedding Control* output will energise. When the load has been above the trip level for the duration of the timer the 'next' *Load shedding Control* output will energise and so on until all *Load Shedding Control outputs are energised*.


If at any time the load falls back below the *Load Shedding Return* level, the *Return Time* will start. If the load remains below the return level when the timer has expired the 'highest' *Load Shedding Control* output that has been energised will be de-energised. This process will continue until all outputs have been de-energised.


When the set enters a stopping sequence for any reason the *Load Shedding control* outputs will de-energise at the same time as the S2 load switch is signalled to open.

 **NOTE:- Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.**

6.4 START INHIBIT/RESET


▲ NOTE: If a digital input configured to *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.



State Inhibit mode is activated by pressing the  button.

In **START INHIBIT**  mode, the module will remove S2 from load (if necessary) and remove the start signal given to the generator controller (if S2 is configured as a generator and it is running).

If S2 is configured as a generator and it does not stop after the cooling down time, the *FAIL TO STOP* alarm is activated (subject to if the *FAIL TO STOP* timer is enabled and its duration). To detect the generator (S2) is at rest the following must occur:


- S2 Frequency must be zero.
- S2 Voltage must be zero.


Any latched alarms that have been cleared will be reset when **START INHIBIT**  mode is entered.

S2 will not be placed on load (or started if configured as a generator) when in **START INHIBIT**  mode. If remote start signals are given, the input is ignored until **AUTO**  mode is entered.

6.5 MANUAL MODE


▲NOTE: If a digital input configured to *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.

Manual mode is activated by pressing the  button.

In **MANUAL**  mode, the module activates an output to give a start signal to an external generator controller (if S2 is configured as a generator supply), and if required, change the state of the load switching devices. An LED indicator beside the button confirms this action.


6.5.1 STARTING SEQUENCE

▲NOTE: There is no *start delay* in this mode of operation.


As soon as the **MANUAL**  mode button is pressed, the output to give a start signal to an external generator controller is activated (if S2 is configured as a generator)

If the generator fails to start during the 'S2 Fail Delay' timer, an alarm will appear on the display which shows **Fail to Start**. S2 is seen as available once the supply is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

6.5.2 S2 AVAILABLE

In **MANUAL**  mode, the load is not transferred to S2 unless a 'loading request' is made and the S2 supply is within limits (if configured as a mains supply) or achieve loading voltage and frequency (if configured as a generator).

A loading request can come from a number of sources.




- Pressing the **CLOSE/OPEN S2**  button
- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load*
- Activation of the inbuilt exercise scheduler if configured for 'on load' runs.

▲NOTE: The load transfer signal remains inactive until S2 is seen as available. This prevents loading to a supply that has failed or is not yet available.

As the load increases and decreases, the module may (depending upon configuration) remove non-essential loads. This is configured as part of the *Load Shedding* control settings in the DSE Configuration Suite Software.

See section entitled *Load Shedding* elsewhere in this document for further details.



Once the load has been transferred to S2, it will not be automatically transferred back to the S1 supply. To manually transfer the load back to the mains either:

- Pressing the **CLOSE/OPEN S1**  button
- Pressing the **AUTO**  button to return to automatic mode.
- Pressing the **START INHIBIT**  button to return to start inhibit mode.

For further details of breaker control, see the section entitled “controls and indications” elsewhere in this manual.


6.5.3 STOPPING SEQUENCE


In manual mode, S2 will continue to run until either:

- Pressing the **START INHIBIT**  button to return to start inhibit mode.
- Pressing the **AUTO**  button to return to automatic mode.

6.6 AUTOMATIC MODE

▲ NOTE: If a digital input configured to *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.

Auto mode is activated by pressing the  button.

In **AUTO**  mode, the module will operate fully automatically, changing between the two supplies in case of failure without user intervention. An LED indicator beside the button confirms this action.

6.6.1 WAITING IN AUTO MODE

If a starting/loading request is made, the starting sequence will begin. Starting/loading requests can be from the following sources:

- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load* or *remote start off load*.
- Activation of the inbuilt exercise scheduler.
- Instruction from external remote telemetry devices using the RS232 or RS485 interface

6.6.2 STARTING SEQUENCE

To allow for 'false' start/load requests such as S1 brownouts, the *start delay* timer begins. There are individual start delay timers for each of the different start/load request types.


Should all start/load requests be removed during the *start delay* timer, the unit will return to a stand-by state.

If a start/load request is still present at the end of the *start delay* timer, an output to give a start signal to an external generator controller is activated (if S2 is configured as a generator).

If the generator fails to start during the 'S2 Fail Delay' timer, an alarm will appear on the display which shows **Fail to Start**. S2 is seen as available once the supply is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

If a start/load request is present but the starting sequence has not begun, an input configured to '*Auto Start Inhibit*' could be active.

6.6.3 S2 AVAILABLE

In **AUTO**  mode, the load is automatically transferred to S2 when it is within limits (if configured as a mains supply) or achieve loading voltage and frequency (if configured as a generator).

If a start/load request is present but S2 will not go on load, an input configured to 'S2 Load Inhibit' could be active.

A loading request can come from a number of sources.

- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load*
- Activation of the inbuilt exercise scheduler if configured for 'on load' runs.

 **NOTE: The load transfer signal remains inactive until S2 is seen as available. This prevents loading to a supply that has failed or is not yet available.**

As the load increases and decreases, the module may (depending upon configuration) remove non-essential loads. This is configured as part of the *Load Shedding* control settings in the DSE Configuration Suite Software.

See section entitled *Load Shedding* elsewhere in this document for further details.

If all start/load requests are removed, the *stopping sequence* will begin.

6.6.4 STOPPING SEQUENCE

The *return delay* timer operates to ensure that the start/load request has been permanently removed and isn't just a short term removal. Should another start request be made during the return delay (or cooling down period when S2 is configured as a generator), the set will return on load.


If there are no starting requests at the end of the *return delay* timer, the load is transferred back from the S2 to the S1 supply and the *cooling* timer is initiated (when S2 is configured as a generator).

The *cooling* timer allows S2 (when configured as a generator) to run off load and cool sufficiently before the start signal to the external generator control unit is removed. This is particularly important where turbo chargers are fitted to the engine.



After the *cooling* timer has expired, the start signal given to the external generator controller is removed..

6.7 MODE SELECTION

NOTE: If a digital input configured to *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.



Pressing the **MODE**  button sets which of the three modes below to leave the controller in.

6.7.1 TEST ON LOAD

Activate by pressing the **MODE**  button repeatedly until '**Test on Load**' is shown on the display, then press the **TICK**  button to confirm the change. An LED indicator beside the button confirms this action.

The **Test on Load** mode will start S2 (if configured as a generator) and transfer the load to S2.

6.7.1.1 STARTING SEQUENCE

As soon as the **MODE**  is selected and confirmed by pressing the **TICK**  button is pressed, the output to give a start signal to an external generator controller is activated (if S2 is configured as a generator)

If the generator fails to start during the 'S2 Fail Delay' timer, an alarm will appear on the display which shows **Fail to Start**. S2 is seen as available once the supply is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

6.7.1.2 S2 AVAILABLE

In **Test on Load** mode, the load is automatically transferred to S2 when it is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

If a start/load request is present but S2 will not go on load, an input configured to 'S2 Load Inhibit' could be active.



NOTE: The load transfer signal remains inactive until S2 is seen as available. This prevents loading to a supply that has failed or is not yet available.

As the load increases and decreases, the module may (depending upon configuration) remove non-essential loads. This is configured as part of the *Load Shedding* control settings in the DSE Configuration Suite Software.



See section entitled *Load Shedding* elsewhere in this document for further details.

6.7.1.3 STOPPING SEQUENCE

In **Test on Load** mode, S2 will continue to run on load until either:



- Pressing the **START INHIBIT**  button to return to start inhibit mode.
- Pressing the **AUTO**  button to return to automatic mode.

6.7.2 TEST OFF LOAD

Activate by pressing the **MODE**  button repeatedly until **Test off Load** is shown on the display, then press the **TICK**  button to confirm the change. An LED indicator beside the button confirms this action.

The **Test off Load** mode will only start S2 (if configured as a generator) and leave it off load.

6.7.2.1 STARTING SEQUENCE

As soon as the **MODE**  is selected and confirmed by pressing the **TICK**  button is pressed, the output to give a start signal to an external generator controller is activated (if S2 is configured as a generator)

If the generator fails to start during the 'S2 Fail Delay' timer, an alarm will appear on the display which shows **Fail to Start**. S2 is seen as available once the supply is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

6.7.2.2 S2 AVAILABLE

In **Test off Load** mode, the load is not transferred to S2 unless a 'loading request' is made and the S2 supply is within limits (if configured as a mains supply) or has achieved loading voltage and frequency (if configured as a generator).

A loading request can come from a number of sources.

- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load*
- Activation of the inbuilt exercise scheduler if configured for 'on load' runs.



 **NOTE: The load transfer signal remains inactive until S2 is seen as available. This prevents loading to a supply that has failed or is not yet available.**

As the load increases and decreases, the module may (depending upon configuration) remove non-essential loads. This is configured as part of the *Load Shedding* control settings in the DSE Configuration Suite Software.



See section entitled *Load Shedding* elsewhere in this document for further details.

6.7.2.3 STOPPING SEQUENCE

In **Test off Load** mode, S2 will continue to run on load until either:

- Pressing the **START INHIBIT**  button to return to start inhibit mode.
- Pressing the **AUTO**  button to return to automatic mode.

6.7.3 PROHIBIT RETURN

Activate by pressing the **MODE**  button repeatedly until '**Prohibit Return**' is shown on the display, then press the **TICK**  button to confirm the change. An LED indicator beside the button confirms this action.

The '**Prohibit Return**' mode will prevent the load being transfer back to the S1 from the S2 supply until the module is instructed to do so.

6.7.3.1 WAITING IN PROHIBIT RETURN

If a starting/loading request is made, the starting sequence will begin. Starting/loading requests can be from the following sources:

- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load* or *remote start off load*.
- Activation of the inbuilt exercise scheduler.
- Instruction from external remote telemetry devices using the RS232 or RS485 interface

6.7.3.2 STARTING SEQUENCE

To allow for 'false' start/load requests such as S1 brownouts, the *start delay* timer begins. There are individual start delay timers for each of the different start/load request types.

Should all start/load requests be removed during the *start delay* timer, the unit will return to a stand-by state.

If a start/load request is still present at the end of the *start delay* timer, an output to give a start signal to an external generator controller is activated (if S2 is configured as a generator).

If the generator fails to start during the 'S2 Fail Delay' timer, an alarm will appear on the display which shows **Fail to Start**. S2 is seen as available once the supply is within limits (if configured as a mains supply) or had achieved loading voltage and frequency (if configured as a generator).

If a start/load request is present but the starting sequence has not begun, an input configured to '*Auto Start Inhibit*' could be active.

6.7.3.3 S2 AVAILABLE

In **Prohibit Return** mode, the load is automatically transferred to S2 when it is within limits (if configured as a mains supply) or has achieved loading voltage and frequency (if configured as a generator).

If a start/load request is present but S2 will not go on load, an input configured to 'S2 Load Inhibit' could be active.

A loading request can come from a number of sources.

- S1 supply out of limits
- Activation of an auxiliary input that has been configured to *remote start on load*
- Activation of the inbuilt exercise scheduler if configured for 'on load' runs.

 **NOTE: The load transfer signal remains inactive until S2 is seen as available. This prevents loading to a supply that has failed or is not yet available.**



As the load increases and decreases, the module may (depending upon configuration) remove non-essential loads. This is configured as part of the *Load Shedding* control settings in the DSE Configuration Suite Software.

See section entitled *Load Shedding* elsewhere in this document for further details.

If all start/load requests are removed, the *stopping sequence* will begin.

6.7.3.4 STOPPING SEQUENCE

In **Return Inhibit** mode, S2 will continue to run on load even if S1 has return until either:


- Pressing the **START INHIBIT**  button to return to start inhibit mode.
- Pressing the **AUTO**  button to return to automatic mode.

7 PROTECTIONS

When an alarm is present, the Audible Alarm will sound and the Common alarm LED if configured will illuminate.

The audible alarm can be silenced by pressing the **ALARM MUTE** ‘🔇’

The LCD display will jump from the ‘Information page’ to display the Alarm Page



The LCD will display multiple alarms E.g. “S1 Failure Warning”, “Fail to Stop Warning” and “Digital Input A Electrical Trip”. These will automatically scroll in the order that they occurred.

In the event of a warning alarm, the LCD will display the appropriate text. If an electrical trip then occurs, the module will again display the appropriate text.

Example:-

Alarm	1/2
Fail to Stop	
Unlatched	
Warning	

Alarm	2/2
Digital Input A	
Unlatched	
Electrical Trip	

7.1 INDICATIONS

Indications are non-critical and often status conditions. They do not appear on the LCD of the module as a text message. However, an output or LED indicator can be configured to draw the operator's attention to the event.

Example

- Input configured for indication.
- The LCD text will not appear on the module display but can be added in the configuration to remind the system designer what the input is used for.
- As the input is configured to *Indication* there is no alarm generated.
- LED Indicator to make LED1 illuminate when Digital Input A is active.
- The Insert Card Text allows the system designer to print an insert card detailing the LED function.
- Sample showing operation of the LED.

Digital Input A

Function: User Configured

Polarity: Close to Activate

Action: Indication

Arming: Always

LCD Display: Battery Charger On

Activation Delay: 0s

LED Indicators

1 Digital Input A Lit Battery Charger On



7.2 WARNINGS

Warnings are non-critical alarm conditions and do not affect the operation of the system, they serve to draw the operators attention to an undesirable condition.



Example

1/2	Alarm
S1 Failure	
Latched	
Warning	

In the event of an alarm the LCD will jump to the alarms page, and scroll through all active warnings and shutdowns.

By default, warning alarms are self-resetting when the fault condition is removed. However some warning alarms are latched and will need to be reset manually.

Display	Reason
Auxiliary Inputs	If an auxiliary input has been configured as a warning the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.
Battery Under Voltage	The DC supply has fallen below the low volts setting level for the duration of the low battery volts timer
Battery Over Voltage	The DC supply has risen above the high volts setting level for the duration of the high battery volts timer
Calibration Lost	The module has lost its calibration settings and must be sent back to DSE to be re-calibrated.
Expansion Inputs	If an expansion input has been configured as a warning the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.
Fail To Start	S2 has not reached the configured limits or loading voltage and frequency before the S2 Fail Delay timer has expired.
Fail To Stop	The module has detected a condition that indicates that S2 is present when it has been instructed to stop.
Loading Voltage Not Reached	Indicates that the S2 voltage is not above the configured <i>loading voltage</i> . S2 will not take load when the alarm is present after the safety timer. <div style="border: 1px solid black; padding: 5px;"> <p>▲ NOTE: Only applicable when S2 is configured as a generator supply.</p> </div>
Loading Frequency Not Reached	Indicates that the S2 frequency is not above the configured <i>loading frequency</i> . S2 will not take load when the alarm is present after the safety timer. <div style="border: 1px solid black; padding: 5px;"> <p>▲ NOTE: Only applicable when S2 is configured as a generator supply.</p> </div>


Display	Reason
PLC Functions	If a PLC Function has been configured as a warning the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.
S1 Failure Latch	The module has detected that S1 has failed for either an under/over voltage/frequency condition. The latched alarm will not clear until the START INHIBIT/RESET  button is pressed.
S1 Failure Unlatched	The module has detected that S1 has failed for either an under/over voltage/frequency condition. The unlatched alarm will automatically clear upon S1 returning to an available state.
S2 Failure Latch	The module has detected that S2 has failed for either an under/over voltage/frequency condition. The latched alarm will not clear until the START INHIBIT/RESET  button is pressed.
S2 Failure Unlatched	The module has detected that S2 has failed for either an under/over voltage/frequency condition. The unlatched alarm will automatically clear upon S2 returning to an available state.

7.3 ELECTRICAL TRIPS

Electrical trips are latching unload and stop S2 (if configured as a generator) but in a controlled manner. On initiation of the electrical trip condition the module will de-energise the **'Close S2 Output'** to remove the load from S2. Once this has occurred the module will start the Cooling timer and allow the generator to cool down and shut off. The alarm must be accepted and cleared, and the fault removed to reset the module.

Example

1/2 Alarm
Digital Input A Latched Electrical Trip

Electrical trips are latching alarms and unload and stop S2 (if configured as a generator). To clear these alarms the **START INHIBIT/RESET**  button is pressed

Display	Reason
Auxiliary Inputs	If an auxiliary input has been configured as an electrical trip, the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.
Expansion Inputs	If an expansion input has been configured as an electrical trip, the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.
PLC Functions	If a PLC Function has been configured as an electrical trip, the appropriate LCD message will be displayed and the COMMON ALARM LED will illuminate.

8 SCHEDULER

The controller contains an inbuilt exercise run scheduler, capable of automatically starting and stopping the set. Up to 16 scheduled start/stop sequences can be configured in banks of 8 to either repeat on a 7-day or 28-day cycle.


Scheduled runs may be on load or off load depending upon module configuration.

Example


Screen capture from DSE Configuration Suite Software showing the configuration of the Exercise Scheduler.

In this example the set will start at 09:00 on the first Monday of each month and run for 5 hours, then start at 13:30 on every Tuesday and run for 30 minutes.






8.1 STOP MODE

- Scheduled runs will not occur when the module is in **START INHIBIT**  mode.

8.2 MANUAL MODE

- Scheduled runs will not occur when the module is in **MANUAL**  mode.
- Activation of a Scheduled Run 'On Load' when the module is operating OFF LOAD in Manual mode will have no effect, the set continues to run OFF LOAD


8.3 AUTO MODE

- Scheduled runs will operate ONLY if the module is in **AUTO**  mode with no Electrical Trip alarm present.
- If the module is in **START INHIBIT**  or **MANUAL**  mode when a scheduled run begins, S2 will not be started (if configured as generator). However, if the module is moved into **AUTO**  mode during a scheduled run, S2 will be called to start.
- Depending upon configuration by the system designer, an external input can be used to inhibit a scheduled run.
- If S2 is OFF LOAD in **AUTO**  mode and a scheduled run configured to 'On Load' begins, S2 is placed ON LOAD for the duration of the Schedule.


9 FRONT PANEL CONFIGURATION

This configuration mode allows the operator limited customising of the way the module operates.



Use the module's navigation buttons to traverse the menu and make value changes to the parameters:





9.1 ACCESSING THE MAIN FRONT PANEL CONFIGURATION EDITOR


Press and hold the **TICK**  button to enter the editor.
If a module security PIN has been set, the PIN number request is then shown :




Press the **TICK**  button, the first '#' changes to '0'. Press  (up or down) to adjust it to the correct value.

Press  (right) when the first digit is correctly entered. The digit you have just entered will now show '#' for security.

Repeat this process for the other digits of the PIN number. You can press  (left) if you need to move back to adjust one of the previous digits.

When the **TICK**  button is pressed after editing the final PIN digit, the PIN is checked for validity. If the number is not correct, you must re-enter the PIN.



If the PIN has been successfully entered (or the module PIN has not been enabled), the editor is displayed :





NOTE: The PIN number is not set by DSE when the module leaves the factory. If the module has a PIN code set, this has been affected by your ATS supplier who should be contacted if you require the code. If the code has been 'lost' or 'forgotten', the module must be returned to the DSE factory to have the module's code removed. A charge will be made for this procedure.
NB - This procedure cannot be performed away from the DSE factory.


9.1.1 EDITING A PARAMETER


Enter the editor as described above.

Press the  (left) or  (right) buttons to cycle to the section you wish to view/change.

Press the  (up or down) buttons to select the parameter you wish to view/change within the currently selected section.

To edit the parameter, press the **TICK**  button to enter edit mode. The parameter begins to flash to indicate that you are editing the value.

Press the  (up or down) buttons to change the parameter to the required value.

Press the **TICK**  button to save the value. The parameter ceases flashing to indicate that it has been saved.

To exit the editor at any time, press and hold the **TICK**  button.

▲NOTE: The editor automatically exits after 5 minutes of inactivity to ensure security.

▲NOTE: The PIN number is automatically reset when the editor is exited (manually or automatically) to ensure security.

▲NOTE: Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.

9.2 ADJUSTABLE PARAMETERS

NOTE: Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.

Section	Parameter As Shown On Display	Values
Display	LCD Contrast	0%
	Language	English
	LCD Page Timer	hh:mm:ss
	Scroll Delay	hh:mm:ss
	Date and Time	dd-mm-yyyy, hh:mm:ss
S2	S2 Option	Generator, Mains
	Immediate S2 Dropout	Inactive, Active
	Under Voltage Trip (Generator Option)	0 V
	Over Voltage Trip (Generator Option)	0 V
	Under Frequency Trip (Generator Option)	0.0 Hz
	Over Frequency Trip (Generator Option)	0.0 Hz
	Under Voltage Trip (Mains Option)	0 V
	Over Voltage Trip (Mains Option)	0 V
	Under Frequency Trip (Mains Option)	0.0 Hz
S1	S1 Option	Generator, Mains
	Immediate S1 Dropout	Inactive, Active
	Under Voltage Trip	0 V
	Over Voltage Trip	0 V
	Under Frequency Trip	0 Hz
Timers	Over Frequency Trip (Mains Option)	0.0 Hz
	S1 Transient Delay	mm:ss
	Start Delay	hh:mm:ss
	Warming Up Time	hh:mm:ss
	S2 Fail Delay	mm:ss
	Elevator Delay	mm:ss
	Non-sync Transfer Time	mm:ss.s
	Check-Sync Transfer time	mm:ss.s
	Return Delay	hh:mm:ss
	Cooling Time	hh:mm:ss
	Fail to Stop Enable	Inactive, Active
	Fail to Stop Delay	mm:ss
	S2 Transient Delay	s.s
Scheduler Bank 1	Scheduler Enable	Inactive, Active
	Bank 1 Run Mode	Off Load, On Load, Do Not Transfer
	Bank 1 Period	Weekly, Monthly
	Bank 1 Event 1 Week	1-4
	Bank 1 Event 1 Day	Monday to Sunday
	Bank 1 Event 1 Start Time	hh:mm
	Bank 1 Event 1 Duration	hh:mm
	Bank 1 Event 2 Week	1-4
	Bank 1 Event 2 Day	Monday to Sunday
	Bank 1 Event 2 Start Time	hh:mm
	Bank 1 Event 2 Duration	hh:mm
	Bank 1 Event 3 Week	1-4
	Bank 1 Event 3 Day	Monday to Sunday
	Bank 1 Event 3 Start Time	hh:mm
	Bank 1 Event 3 Duration	hh:mm
	Bank 1 Event 4 Week	1-4
	Bank 1 Event 4 Day	Monday to Sunday
	Bank 1 Event 4 Start Time	hh:mm
	Bank 1 Event 4 Duration	hh:mm
	Bank 1 Event 5 Week	1-4
	Bank 1 Event 5 Day	Monday to Sunday
	Bank 1 Event 5 Start Time	hh:mm
	Bank 1 Event 5 Duration	hh:mm
	Bank 1 Event 6 Week	1-4
	Bank 1 Event 6 Day	Monday to Sunday
	Bank 1 Event 6 Start Time	hh:mm
	Bank 1 Event 6 Duration	hh:mm
	Bank 1 Event 7 Week	1-4
	Bank 1 Event 7 Day	Monday to Sunday
	Bank 1 Event 7 Start Time	hh:mm
	Bank 1 Event 7 Duration	hh:mm
	Bank 1 Event 8 Week	1-4
	Bank 1 Event 8 Day	Monday to Sunday
Bank 1 Event 8 Start Time	hh:mm	
Bank 1 Event 8 Duration	hh:mm	


 **NOTE: Refer to DSE335 Configuration Suite Manual (DSE part 057-157) for further details on configuring, monitoring and control.**

Section	Parameter As Shown On Display	Values
Scheduler Bank 2	Bank 2 Run Mode	Off Load, On Load, Do Not Transfer
	Bank 2 Period	Weekly, Monthly
	Bank 2 Event 1 Week	1-4
	Bank 2 Event 1 Day	Monday to Sunday
	Bank 2 Event 1 Start Time	hh:mm
	Bank 2 Event 1 Duration	hh:mm
	Bank 2 Event 2 Week	1-4
	Bank 2 Event 2 Day	Monday to Sunday
	Bank 2 Event 2 Start Time	hh:mm
	Bank 2 Event 2 Duration	hh:mm
	Bank 2 Event 3 Week	1-4
	Bank 2 Event 3 Day	Monday to Sunday
	Bank 2 Event 3 Start Time	hh:mm
	Bank 2 Event 3 Duration	hh:mm
	Bank 2 Event 4 Week	1-4
	Bank 2 Event 4 Day	Monday to Sunday
	Bank 2 Event 4 Start Time	hh:mm
	Bank 2 Event 4 Duration	hh:mm
	Bank 2 Event 5 Week	1-4
	Bank 2 Event 5 Day	Monday to Sunday
	Bank 2 Event 5 Start Time	hh:mm
	Bank 2 Event 5 Duration	hh:mm
	Bank 2 Event 6 Week	1-4
	Bank 2 Event 6 Day	Monday to Sunday
	Bank 2 Event 6 Start Time	hh:mm
	Bank 2 Event 6 Duration	hh:mm
	Bank 2 Event 7 Week	1-4
	Bank 2 Event 7 Day	Monday to Sunday
	Bank 2 Event 7 Start Time	hh:mm
	Bank 2 Event 7 Duration	hh:mm
	Bank 2 Event 8 Week	1-4
	Bank 2 Event 8 Day	Monday to Sunday
Bank 2 Event 8 Start Time	hh:mm	
Bank 2 Event 8 Duration	hh:mm	

10 COMMISSIONING


10.1 PRE-COMMISSIONING

Before the system is started, it is recommended that the following checks are made:-

- The unit is adequately cooled and all the wiring to the module is of a standard and rating compatible with the system. Check all mechanical parts are fitted correctly and that all electrical connections (including earths) are sound.
- The unit **DC** supply is fused and connected to the battery and that it is of the correct polarity.
- To check the start cycle operation, take appropriate measures to prevent S2 from starting (if configured as a generator by disconnecting the start output) and press the **MANUAL**  mode button. Check to see if the start signal energises.
- Set the modules internal clock/calendar to ensure correct operation of the scheduler and event logging functions. For details of this procedure see section entitled *Front Panel Configuration – Editing the date and time*.
- If, despite repeated checking of the connections between the controller and the customer's system, satisfactory operation cannot be achieved, then the customer is requested to contact the factory for further advice on:-

11 FAULT FINDING

11.1 STARTING

Symptom	Possible Remedy
Unit is inoperative Read/Write configuration does not operate	Check the battery and wiring to the unit. Check the DC supply. Check the DC fuse.
Unit shuts down	Check DC supply voltage is not above 35 Volts or below 9 Volts Check the operating temperature is not above 70°C. Check the DC fuse.
Fail to Start is activated	Check wiring of the S2 sensing cables. Check the start output is correctly wired into the generator controller.
Continuous starting of S2 when in AUTO  mode.	Check that there is no signal present on the "Remote Start" input. Check configured polarity is correct. Check the S2 supply available and within configured limits
S2 fails to start or go on load on receipt of Remote Start signal.	Check S2 Fail Delay timer has timed out. Check signal is on "Remote Start" input. Confirm correct configuration of input is configured to be used as "Remote Start".

11.2 LOADING

Symptom	Possible Remedy
S2 supply present runs but will not take load	Ensure S2 is available and within configured limits and a load inhibit signal is not present on the module inputs. Check connections to the switching device. Note that S2 will not take load in manual mode unless there is an active remote start on load signal.

11.3 ALARMS

Symptom	Possible Remedy
Electrical Trip fault operates	Check relevant switch and wiring of fault indicated on LCD display. Check configuration of input.
Warning fault operates	Check relevant switch and wiring of fault indicated on LCD display. Check configuration of input.

11.4 COMMUNICATIONS

Symptom	Possible Remedy
RS485 inoperative	<p>Check :</p> <ul style="list-style-type: none"> • Connection cable – Belden 9841 or equivalent • 120Ω termination resistors are correctly fitted • Baud rate of controller and of master device are the same • Slave ID of the controller is the same as configured in the master device
RS232 connection to PC inoperative	<p>Check :</p> <ul style="list-style-type: none"> • RS232 maximum of 15m is not exceeded • Direct to PC connection requires a Crossover (NULL modem) RS232 cable • Baud rate of controller and of master device are the same • Slave ID of the controller is the same as configured in the master device
RS232 connection to GSM modem inoperative	<p>Check :</p> <ul style="list-style-type: none"> • RS232 maximum of 15m is not exceeded • Modem Initialisation strings in the DSE configuration is correct for the connected modem type • Modem is configured to 9600 baud • SIM card is CSD (circuit switched data) compatible • SIM card is not PIN locked • SIM card is correctly inserted • Antenna is correctly installed and is not inside an earthed metal cabinet / control panel • A good signal is available in the locality
RS232 connection to landline modem inoperative	<p>Check :</p> <ul style="list-style-type: none"> • RS232 maximum of 15m is not exceeded • Modem Initialisation strings in the DSE configuration is correct for the connected modem type • Modem is configured to 9600 baud

11.5 INSTRUMENTS

Symptom	Possible Remedy
Inaccurate S1 & S2 measurements on controller display	<p>Check that the CT primary, CT secondary and VT ratio settings are correct for the application.</p> <p>Check that the CTs are wired correctly with regards to the direction of current flow (p1,p2 and s1,s2) and additionally ensure that CTs are connected to the correct phase (errors will occur if CT1 is connected to phase 2).</p> <p>Remember to consider the power factor. I.e (kW = kVA x powerfactor)</p> <p>The controller is true RMS measuring so gives more accurate display when compared with an 'averaging' meter such as an analogue panel meter or some lower specified digital multimeters.</p> <p>Accuracy of the controller is better than 1% of full scale. I.e S1 volts full scale is 333V ph-n so accuracy is $\pm 3.33V$ (1% of 333V).</p>

11.6 MISCELLANEOUS

Symptom	Possible Remedy
Module appears to 'revert' to an earlier configuration	<p>When editing a configuration using the PC software it is vital that the configuration is first 'read' from the controller before editing it. This edited configuration must then be "written" back to the controller for the changes to take effect.</p> <p>When editing a configuration using the fascia editor, be sure to press the TICK '✓' button to save the change before moving to another item or exiting the fascia editor</p>

▲NOTE: The above fault finding is provided as a guide check-list only. As the module can be configured to provide a wide range of different features, always refer to the source of your module configuration if in doubt.

12 MAINTENANCE, SPARES, REPAIR AND SERVICING

The controller is *Fit and Forget*. As such, there are no user serviceable parts within the controller. In the case of malfunction, you should contact your original equipment manufacturer (OEM).








12.1 PURCHASING ADDITIONAL CONNECTOR PLUGS FROM DSE

If you require additional plugs from DSE, please contact our Sales department using the part numbers below.

12.1.1 PACK OF PLUGS


Module type	Plug Pack Part Number
DSE335	100-400-35

12.1.2 INDIVIDUAL PLUGS


Module Terminal Designation	Plug Description	Part No.
1-8 	8 way 5.08mm	007-164
9-17 	9 way 5.08mm	007-167
18-24 	7 way 5.08mm	007-447
25-29 	5 way 7.62mm	007-473
30-37 	8 way 7.62mm	007-454
38-41 S1	4 way 7.62mm	007-171
42-47 	6 way 5.08mm	007-446
48-53 	6 way 7.62mm	007-162
RS485	3 way 5.08mm	007-174

NOTE: Terminals 24 and 27 are fitted to controllers but must not be connected.

12.2 PURCHASING ADDITIONAL FIXING CLIPS FROM DSE

Item	Description	Part No.
	Module fixing clips (packet of 4)	020-294




12.3 PURCHASING ADDITIONAL SEALING GASKET FROM DSE


Item	Description	Part No.
	Module silicon sealing gasket	020-507

12.4 DSENET EXPANSION MODULES

NOTE: A maximum of six (6) expansion modules can be connected to the DSENet®.

NOTE: DSENet® utilises an RS485 connection. Using Belden 9841 (or equivalent) cable allows for the expansion cable to be extended to a maximum of 1.2km. DSE Stock and supply Belden 9841 cable. DSE Part Number 016-030.

Item	Max No. supported	Description	Model order number	DSE Part Numbers		
				Sales literature	Operator manual	Installation Instructions
	2	Model DSE2130 input module provides additional analogue and digital inputs for use with the controller.	2130-001-00	055-060	057-082	053-033
	2	Model DSE2157 expansion relay module provides eight additional voltage free relays for use with the controller	2157-001-00	055-061	057-083	053-034
	2	Model DSE2548 expansion LED module provides additional LED indications, internal sounder and remote lamp test/alarm mute for use with the controller.	2548-001-00	055-062	057-084	053-032



NOTE 1
AS A TERMINATING RESISTOR IS INTERNALLY FITTED TO THE HOST CONTROLLER, THE HOST CONTROLLER MUST BE THE FIRST UNIT ON THE DSEnet

NOTE 2
A 120 OHM TERMINATION RESISTOR MUST BE FITTED TO THE LAST UNIT ON THE DSEnet

13 WARRANTY

DSE provides limited warranty to the equipment purchaser at the point of sale. For full details of any applicable warranty, you are referred to your original equipment supplier (OEM).

14 DISPOSAL

14.1 WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)

Directive 2002/96/EC

If you use electrical and electronic equipment you must store, collect, treat, recycle and dispose of WEEE separately from your other waste.



14.2 ROHS (RESTRICTION OF HAZARDOUS SUBSTANCES)

Directive 2002/95/EC: 2006

To remove specified hazardous substances (Lead, Mercury, Hexavalent Chromium, Cadmium, PBB & PBDE's)

Exemption Note: Category 9. (Monitoring & Control Instruments) as defined in Annex 1B of the WEEE directive will be exempt from the RoHS legislation. This was confirmed in the August 2005 UK's Department of Trade and Industry RoHS REGULATIONS Guide (Para 11).

Despite this exemption, DSE has been carefully removing all non RoHS compliant components from our supply chain and products.

When this is completed, a Lead Free & RoHS compatible manufacturing process will be phased into DSE production.

This process that is almost complete and is being phased through different product groups.

This page is intentionally left blank