



IPRS-1201 IPRS-1220 IPRS-1230

Serial to IP gateway

USB to IP gateway

User manual

Document reference : 9018409-01

The IPRS gateway is designed and manufactured by

ETIC TELECOM
13 Chemin du vieux chêne
38240 MEYLAN
FRANCE

TEL : + 33 4-76-04-20-00

FAX : + 33 4-76-04-20-01

E-mail : hotline@etictelecom.com

web : www.etictelecom.com

OVERVIEW

1	PRODUCTS IDENTIFICATION.....	5
2	PRODUCT OVERVIEW.....	6
3	TECHNICAL DATA.....	7

INSTALLATION

1	PRODUCT DESCRIPTION	9
2	VENTILATION.....	14
3	SUPPLY VOLTAGE	14
4	ETHERNET PORTS.....	14
5	RS232 INTERFACE	14
6	RS485 INTERFACE	15
7	DIGITAL INPUT & OUTPUT CONNECTION.....	16

SETUP

1	SET UP STEPS.....	17
2	OVERVIEW	17
3	FIRST CONFIGURATION.....	18
4	MODIFYING THE CONFIGURATION.....	20
5	REBOOTING THE IPRS GATEWAY AFTER PARAMETERS CHANGES.....	21
6	RECOVERING THE FACTORY LAN IP ADDRESS	22
7	RECOVERING THE FACTORY CONFIGURATION	22
8	RESTRICTING ACCESS TO THE ADMINISTRATION SERVER	22
9	RECOVERING A FREE ACCESS TO THE ADMINISTRATION SERVER	23



... SETUP

10 LAN INTERFACE..... 24

 10.1 IP protocol 24

 10.2 Ethernet ports..... 24

11 SERIAL TO IP GATEWAY 25

 11.1 COM port data rate..... 26

 11.2 Modbus gateway 27

 11.3 RAW TCP gateway 31

 11.4 RAW UDP gateway..... 34

 11.5 "Multicast" gateway..... 36

12 USB TO IP GATEWAY 39

 12.1 Principles 39

 12.2 Configuration..... 40

13 ALARMS 41

 13.1 SNMP 41

 13.2 Digital output alarm 41

 13.3 E-mail alarm..... 41

DIAGNOSTIC AND MAINTENANCE

1 DIAGNOSTIC 43

2 SAVING THE PARAMETERS TO A FILE 44

3 UPDATING THE FIRMWARE..... 45

Appendix 1 : html server overview

Appendix 2 : VPN technology

1 Products identification

	IPRS-	1201	1220	1230
Serial Raw TCP client or server		-	-	-
Serial UDP		-	•	•
Serial UDP multicast		-	•	•
Serial gateway Modbus TCP client or server		-	•	•
Serial gateway Telnet		-	•	•
Serial Unitelway		-	•	•
USB PPP to IP		•	-	-
RJ45 10 / 100 BT		2	2	2
USB host		1	-	-
RS232		-	1	2
RS485		-	1	-
SNMP		•	•	•
Digital input for alarm emails		1	1	1
HTML setup		•	•	•
IO Viewer : optional dynamic data html server		•	•	•

The sign • means the function is provided
 The sign - means the function is not provided

2 Product overview

The IPRS-1220 provides one RS232 port and one RS485 port (2 wires).

The IPRS-1230 provides two RS232 port.

The IPRS-1220 or IPRS-1230 gateway can be


- Raw TCP client or server
- RAW UDP
- RAW UDP multicast
- Telnet server
- Modbus TCP client or server
- Unitelway


The IPRS-1201 provides one USB port. The IPRS-120 gateway is a PPP client over the USB interface.

3 Technical data


General characteristics	
Dimensions	137 x 48 x 116 mm (h, l, p)
Electrical safety	EN 60950- UL 1950
EMC	ESD : EN61000-4-2 : Discharge 6 KV RF field : EN61000-4-3 : 10V/m < 2 GHz Fast transient : EN61000-4-4 Surge voltage : EN61000-4-5 : 4KV line / earth
RoHS	2002/95/CE (RoHS)
Supply voltage	IPRS-1201 & IPRS-1230 : 10 to 60 VDC - 250mA / 24VDC IPRS-1220 : 10 to 30 VDC - 250mA / 24VDC
Operating T°	-20°C / + 60°C Humidity 5 – 95 %


Serial interface	
RS232	1200 – 115200 kb/s parity N / E / O
RS485	2 wires (A& B)
USB	USB host interface (A type connector)
Serial asynchronous to IP gateways	Modbus master and slave Raw TCP client and server Telnet RAW UDP "multicast" unitelway
USB gateway	USB PPP to IP The IPRS is PPP client


1 Product description
IPRS-1220


IPRS-1220		
Interface	Led	Function
LAN	Ethernet 1 to Ethernet 2	Blinking quickly : Data activity Lit : Interface connected, no activity
	RS232	Rx : Bytes received from the RS232 (to the RAS) Tx : Bytes transmitted to the RS232 (from the RAS)
RS485	Rx	Bytes received from the RS485 (to the RAS)
	Tx	Bytes transmitted to the RS485 (from the RAS)
		Green : Operation Red : Alarm

IPRS-1230



IPRS-1230		
Interface	Led	Function
LAN	Ethernet 1 to Ethernet 2	Blinking quickly : Data activity
		Lit : Interface connected, no activity
RS232	Rx	Bytes received from the RS232 (to the RAS)
	Tx	Bytes transmitted to the RS232 (from the RAS)
		Green : Operation Red : Alarm

IPRS-1201


IPRS-1201		
Interface	Led	Function
LAN	Ethernet 1	Blinking quickly : Data activity
	Ethernet 2	Lit : Interface connected, no activity
USB		Data activity
		Green : Operation Red : Alarm

8 pins screw block Supply voltage and input / output		
Pin Nr	Signal	Function
1	Power 1 +	Supply voltage input 1
2	Power 1 -	0 V
3	Power 2 +	Supply voltage input 2
4	Power 2 -	0 V
5	3V3	+ 3 VDC voltage provided by the product
6	In	Input
7	F +	Output + (max 50Vdc - 0,6A)
8	F -	Output -

LAN Ethernet RJ45 connector Ethernet 10/100 BT		
Pin Nr	Signal	Function
1	Tx +	TX polarity +
2	Tx -	TX polarity -
3	Rx +	Reception polarity +
4	N.C	-
5	N.C	-
6	Rx -	Reception polarity -
7	N.C.	-
8	N.C.	-

RS485 2 pins screw block (IPRS-1220)		
Pin Nr	Signal	Function
1	A	RS485 polarity A
2	B	RS485 polarity B

RS232 RJ45 connector (To connect to a DCE to the RS232 port) (IPRS-1220 or IPRS-1230)			
Pin Nr	Circuit		Function
1	DTR - 108	OUT	Data terminal ready
2	TD - 103	OUT	Data Emission
3	RD - 104	IN	Data Reception
4	DSR - 107	IN	Data set ready
5	SG - 102	-	Ground
6	Not used	OUT	-
7	CTS - 106	IN	Clear to send
8	RTS - 105	OUT	Request to send

RS232 : RJ45 connector (To connect a DTE to the RS232 port) (IPRS-1220 or IPRS-1230)			
Pin	Circuit	Direction	Function
1	CD - 109	OUT	Carrier detect
2	RD - 104	OUT	Data Reception
3	TD - 103	IN	Data Emission
4	DTR - 108	IN	Data terminal ready
5	SG - 102	-	Ground
6	DSR - 107	OUT	Data set ready
7	RTS - 105	IN	Request to send
8	CTS - 106	OUT	Clear to send

DIP switches		
SW 1	SW 2	Management
OFF	OFF	The current IP@ of the product is the stored IP @
ON	OFF	The active IP@ of the product is the factory IP@ : 192.168.0.128 No login and password are required to access to the html server.
OFF	ON	The active IP@ is provided by the BOOTP or DHCP server.
ON	ON	Reserved

Push-button : It enables to restore the factory profile.
 To restore the factory profile, switch the power on while pressing the push-button until the RUN light turns green.

Attention : Once the factory profile has been restored, the stored configuration is lost.

2 Ventilation

To avoid overheating when the ambient temperature is high, leave a 1 cm (0.5 inch) space on each side of the product.

3 Supply voltage

Product	Min Supply voltage	Max supply voltage	Consumption at 24 VDC
	VDC	VDC	mA
IPRS-1220	10	30	250
IPRS-1230	10	30	250
IPRS-1201	10	60	250

4 Ethernet ports

The IPRS features auto-sensing 10/100 Mbps MDI/MDI-X LAN ports.

5 RS232 interface

The RS232 data rate can be tuned from 1200 to 115200 b/s with parity (even / odd) or no parity.

The data terminal must be less than 10 meters far from the modem.

Cables can be provided to connect the product to DTE and DCE as follows :


RS232 cables (L=1m)		
Code	User connector	Cable function
CAB592	SubD 9 male	To connect a DCE to the IPRS
CAB593	SubD 9 female	To connect a DTE to the IPRS
CAB609	wires	To connect a device providing a specific connector

6 RS485 interface

The RS485 serial interface is provided on the front panel 2 pins screw-block.

Polarisation resistors

1 Kohm bus polarisation resistors are included inside the product.



RS485 line matching


For a several meters long connection over the RS485 local interface, it is not necessary to adapt the RS485 line.

For a longer distance, matching and polarisation resistors must be added.

7 Digital input & output connection

Alarm output

1 relay output is provided to indicate an alarm.
The alarm condition can be selected using the html server.



The electrical characteristics of the output are :
Opto-isolated output
Maximum voltage : 48VDC
Maximum current : 500 mA

Inputs

The product features two digital inputs ; they are not isolated.
if one input is opened, an SNMP trap will be sent to the SNMP server if that function has been enabled.

1 Set up steps

To configure the gateway, we advise to proceed as follows :

- [Connecting a PC to the IPRS serial gateway](#)
- [Setting up the LAN interface](#)
- Setting up the [serial gateway](#) or the [USB gateway](#)

2 Overview

Administration server address :

The administration html server is located at the LAN IP address of the serial gateway (The default address is 192.168.0.128).

First setup :

For the first configuration, we advise to connect the PC directly to the LAN interface of the IPRS serial gateway.

Setup modifications :

Modifications can be carried out from the LAN interface, or from the Internet if a firewall rule authorises to reach the administration server (not advised), or from the Internet or using a remote user connection or a VPN.

Restoring the factory IP address :

The factory IP address of the serial gateway on the LAN interface can be restored by setting the DIP switches SW01 ON and SW02 OFF.

In that position of the DIP switches, the stored configuration is not deleted.

Setting the DIP switches in that position gives also a free access to the administration server from the LAN interface.

During operations, the DIP switches must not be left in that position.

Network IP address :

Later in the text, we often speak of "network address".

We mean the lowest value of the addresses of the network.

For instance, if the netmask of a network is 255.255.255.0, the network address of that network is X.Y.Z.0.

Copy and paste :

Parameters must be entered with the keyboard; they cannot be pasted.

However, it can be useful to paste a string when it is long to avoid errors.

In that case, paste the string, delete the last character of the pasted string, and enter it again with the keyboard.

Saving and restoring the parameters file (see the maintenance chapter)

A parameters file can only be downloaded to a product having the same firmware version. It is why, we advise to assign a name to a parameter file including the product name and the software version like for instance "myfile_IPRS1220_V241.bin".

3 First configuration

Step 1 : Check the DIP switches

Coming from factory,

the DIP switches SW1 and SW2 are set OFF to select the stored IP address;
and the stored IP address is the factory IP address 192.168.0.128.

Step 2 : Create or modify the PC IP connection.


Assign to the PC an IP @ in accordance with the IPRS IP address.
For the first configuration, assign or instance 192.168.0.127 to the PC.

Step 3 : Connect the PC directly to the LAN interface of the IPRS serial gateway using any Ethernet cable (straight or cross wired).

Step 4 : Launch the navigator

Enter the LAN IP @ of the serial gateway 192.168.0.128.

The Home page of the administration server is displayed



4 Modifying the configuration

- **If the IP @ of the IPRS is assigned by a DHCP server**

Step 1 : Ensure the DIP switch SW1 is OFF and SW2 ON to select DHCP client operation.

Step 2 : Launch ETIC FINDER to detect the IPRS address over the LAN interface.

Click the product once detected.

The Home page of the administration server is displayed.

Remark :

If the home page cannot be displayed, refer [below](#).

- **If the IP @ of the IPRS gateway is fixed**

Step 1 : Ensure the DIP switch SW1 and SW2 are OFF to select the stored IP @.

Step 2 : Launch the html browser and enter the IP address assigned to the serial gateway.

Or, launch the ETICFINDER utility to detect the IPRS GATEWAY address.

Remark :

If the home page cannot be displayed, refer [below](#).

5 Rebooting the IPRS gateway after parameters changes

- After the parameters of any page have been completed, click the « Save » button at the bottom of the page.
- After some parameters changes, the IPRS GATEWAY must restart. When the configuration has been completely carried out, click the « **Reboot** » red button in the green bar, when displayed.
- Once the product has restarted, check the « **Reboot** » button has disappeared from the green bar.

To save the configuration file to a hard disk :

- Select the “maintenance” menu and then the “Save / restore” menu.
- Click the “Save current configuration to disk” button.

6 Recovering the factory LAN IP address

When launching the html browser, the homepage of the html server may not be displayed; the cause may be the IP address you entered was wrong.

if the IP address you enter is wrong, you can recover the factory IP address by setting SW01 ON and SW2 OFF.

The factory IP address 192.168.0.128 will be restored as long as the SW01 and SW02 micro switch will be left in that position.

Remark :

The SW01 and SW02 must not be left in that position during operations.

7 Recovering the factory configuration

If firewall rules have been created finally preventing from reaching any IP address on the LAN interface including the serial gateway itself, it may be necessary to restore the factory configuration of the serial gateway.

To restore the IPRS gateway factory configuration,

- Switch OFF the power supply of IPRS gateway.
- Press the push button on the top part of the IPRS gateway and switch ON the power supply.
- Keep the push button pressed until the operation led turns red.

Remark : The stored configuration will be lost; the factory IP address 192.168.0.128 will be restored.

8 Restricting access to the administration server

The access to the administration server can be protected by a login and password.

To protect access to the administration server,

- Select the “Setup” menu, the “Security” menu and then the “Administration menu”.

Remark : For more simplicity, we advise to chose the login and the password of one of the remote users stored in the user list.

9 Recovering a free access to the administration server

If the Login & or password entered to reach the administration server have been rejected, it is possible to recover a free access to the administration server from the LAN only, by setting SW01 ON and SW2 OFF.

Remark :

The factory IP address 192.168.0.128 will also automatically be restored as long as SW01 will remain ON and SW2 OFF.

During normal operations SW01 and SW02 must not be left in that position.

10 LAN interface

The product provides 2 switched Ethernet interfaces called LAN interface.

An IP address must be assigned to that interface and the Ethernet ports must be setup.

10.1 IP protocol

- Click the « **Configuration** » menu and then « **LAN interface** » and then “**IP protocol**”.

“IP address” parameter :

Enter the IP address assigned to the serial gateway over the LAN interface.

That IP address will have to be entered to display the administration server.

“Netmask” parameter :

Enter the IP netmask.

“Default gateway” parameter :

Enter the IP address of the default gateway over the LAN network.

10.2 Ethernet ports

- Click the « **Configuration** » menu and then « **LAN interface** » and then “**Ethernet ports**”.

“Hub mode” checkbox :

Select that checkbox if you need to receive the whole Ethernet traffic on both Ethernet ports.

That function can be useful for test trouble-shooting purposes, for instance.

“LAN port 1” and “LAN port 2” parameters :

Select the data speed 10 or 100 Mb/s, and the half or full duplex mode. Or select the “auto” mode.

11 Serial to IP gateway

That function is available in IPRS-1220 or IPRS-1230

The IPRS-1220 or IPRS-1230 feature two serial asynchronous ports RS232 or RS485 (see the [product identification table](#)).

A particular serial gateway can be assigned to each port .

If the same type of gateway is assigned to both serial ports, the UDP or TCP port numbers must be different.

The gateways listed below are provided :

Modbus client or server (i.e. master or slave) :

To connect several serial modbus slaves to several IP modbus clients.
Or to connect a serial modbus master to an IP modbus server.

RAW TCP server or client :

To connect 2 serial devices through an IP network.

Telnet :

To connect a Telnet terminal to the RAS.

RAW UDP :

To exchange serial data between several serial and IP devices, through an IP network, using a table of IP addresses.

RAW multicast :

To exchange serial data between several serial and IP devices, through an IP network, using a multicast IP address.

Unitelway slave :

To connect a serial unitelway master to an IP network.

11.1 COM port data rate

A “COM port parameter ” button is displayed in each gateway menu.

Once a gateway has been setup, click the “COM port parameter” button to setup the COM port :

- The serial port data rate :
1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200

- The byte frame :
7 or 8 bits

- The byte parity :
None, even, odd

- The number of stop bits :
1 or 2


11.2 Modbus gateway

The MODBUS gateway can be assigned to the serial port 1 or to the serial port 2 or to both.

if it is assigned to both serial ports, the UDP port numbers must be different.

11.2.1 Modbus server gateway

This gateway allows to connect asynchronous modbus slaves to the serial interface of the IPRS.



- Select the modbus menu and then modbus server and enable the modbus server gateway and set the parameters as follows :

“Port selection” parameter :

Select the serial port COM 1 or COM2.

If the modbus server gateway is assigned to one serial COM port, it cannot be assigned to the other one.

« ASCII / RTU protocol » parameter:

Select the right option

“Proxi” parameter:

Enable the proxi option if you wish to avoid to frequent requests on the RS232-RS485 interface.

“Cache refreshment period” parameter:

Select the period at which the gateway will send request to the slaves PLC.

“Timeout waiting for the answer” parameter:

Set up the timeout the gateway has to wait for the answer of the modbus slave answer.

“Local retry” parameter :

Set up the number of times the gateway will repeat a request before declaring a failure.

“Inter-character gap” parameter :

Set up the maximum delay the gateway will have to wait between a received character of a modbus answer frame and the following character of the same frame.

“Modbus slave address” parameter:

Choose “specified by the modbus TCP client” , if the address of the slave PLC must be decoded by the gateway from the modbus TCP frame coming from the client.

Otherwise, specify the modbus address of the slave PLC; in that case only one slave can be connected to the RS232 serial interface.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.


“TCP port number” parameter :

Set the port number the gateway has to use.

If the Raw TCP client gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.

11.2.2 Modbus client gateway

This gateway allows to connect a serial modbus master to the serial interface of the IPRS.



- Select the modbus menu and then “modbus client” menu; enable the “modbus client” gateway and set up the parameters as follows :

“Port selection” parameter :

Select the serial port COM 1 or COM2.

If the modbus server gateway is assigned to one serial COM port, it cannot be assigned to the other one.

« ASCII / RTU protocol » parameter :

Select the right option

“Inter-character gap” parameter :

Set up the maximum delay the gateway will have to wait between a received character of a modbus answer frame and the following character of the same frame.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameter :

Set the TCP port number the gateway has to use.

“IP address” parameter :

The modbus client gateway allows to transmit modbus requests from the serial modbus master device to any modbus slave device, more precisely called “ modbus server”, located on the IP network.

To assign an IP address to each modbus slave device with which the serial master device needs to communicate, click the “add a link” button; Assign an IP address in front of each modbus slave address with which the serial master device will have to communicate.

11.3 RAW TCP gateway


The RAW TCP gateway can be assigned to the serial port 1 or to the serial port 2 or to both.

if it is assigned to both serial ports, the TCP port numbers must be different.

11.3.1 Raw client gateway

The RAW client gateway can be used if a serial “master” device has to send requests to one slave device (also called server) located on the IP network.

The server can be either an ETIC gateway or a PC including a software TCP server.



- Select the “transparent” and then the “raw client COM1” or the “raw client COM2” menu .
- Enable the raw client gateway; and set up the parameters as follows :

“RS232/485 input buffer size” parameter :

Set up the maximum length of an asynchronous string the gateway will store before transmitting it to the IP network.

“Timeout of RS232/485 end of frame” parameter :

Set up the delay the gateway will wait before declaring complete a string received from the asynchronous device.

Once declared complete, the gateway will transmit the string to the IP network.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameter :


Set the port number the gateway has to use.
If the Raw TCP client gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.

“Raw server IP address” parameter :

The raw client gateway is able to communicate with a raw server gateway.
Assign an IP address to define the destination gateway.

11.3.2 Raw server gateway

That gateway can be used if a serial slave device has to answer requests coming from devices located on the IP network and acting like a master (also called TCP client).



- Select the “transparent” and then the “raw server COM1” or the “raw server COM2” menu.
- Enable the raw server gateway and set up the parameters as follows :

“RS232/485 input buffer size” parameter :

Set up the maximum length of an asynchronous string the gateway will store before transmitting it to the IP network.

“Timeout of RS232/485 end of frame” parameter :

Set up the delay the gateway will wait before declaring complete a string received from the asynchronous device.
Once declared complete, the gateway will transmit the string to the IP network.

“TCP inactivity Timeout” parameter :

Set up the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameters :

Set up the port number the gateway has to use.
If the Raw TCP server gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.

11.4 RAW UDP gateway

11.4.1 Overview

The RAW UDP gateway can be assigned to the serial port 1 or to the serial port 2 or to both.

if it is assigned to both serial ports, the UDP port numbers must be different.

The RAW UDP gateway enables you to connect together a group of serial or IP devices through an IP network.


The group can include IP devices if they have the software pieces able to receive or transmit serial data inside UDP.

Serial data transmitted by each device is transmitted to all other serial devices through the IP network.

A table of IP destination gateways is stored in each IPRS gateway belonging to the group.

The serial data is encapsulated in the UDP protocol.

The UDP frame is sent to each destination IP address stored in the table.



11.4.2 Configuration

- Select the “gateway” menu and then the “Transparent” menu and then click “RAW UDP COM 1” or the “RAW UDP COM 2” menu.
- Select the “Activate” check box.

« Serial input buffer size” parameter (value 1 to 1024) :

Sets the maximum size of an UDP frame.

“End of frame time-out” parameter (value 10 ms to 5 sec) :

Sets the delay the gateway will wait before sending the UDP frame towards the IP network when no characters are received from the serial interface.

«UDP port number» parameter :

Sets the UDP port number.

If the Raw UDP gateway is assigned to both serial COM ports, the UDP port numbers must be different on each port.

“IP addresses of the destination devices » table :

This table stores the IP addresses of the gateways to which the serial data, encapsulated inside UDP, have to be sent.

A different UDP port number can be entered for each destination IP address.

11.5 “Multicast” gateway


11.5.1 Principle

The MULTICAST gateway can be assigned to the serial port 1 or to the serial port 2 or to both.


if it is assigned to both serial ports, the UDP port numbers must be different.

The multicast gateway must be used when

- a serial master device has to send requests to multiple slave devices; that devices can be IP or serial devices.



- Or when an IP master device (client) has to send requests to multiple slave devices; that devices can be IP or serial devices.



The *Internet Assigned Numbers Authority (IANA)* controls the assignment of IP multicast addresses.

The range of addresses from 224.0.1.0 through 238.255.255.255 are called “globally scoped addresses”. They can be used to multicast data between organizations and across the Internet.

The range of addresses from 239.0.0.0 through 239.255.255.255 contains limited scope addresses or administratively scoped addresses. These are defined by RFC 2365 to be constrained to a local group or organization. Routers are typically configured with filters to prevent multicast traffic in this address range from flowing outside an autonomous system (AS) or any user-defined domain. Within an autonomous system or domain, the limited scope address range can be further subdivided so those local multicast boundaries can be defined. This also allows for address reuse among these smaller domains.

Note This address range is only for the group address or destination address of IP multicast traffic. The source address for multicast datagrams is always the unicast source address.

11.5.2 Configuration

- Select the “transparent” and then the “multicast COM1” or the “multicast COM2” menu.
- Enable the multicast gateway and set up the parameters as follows :

“RS232/485 input buffer size” parameter :

Set up the maximum length of an asynchronous string the gateway will store before transmitting it to the IP network.

“Timeout of RS232/485 end of frame” parameter :

Set up the delay the gateway will wait before declaring complete a string received from the asynchronous device.

Once declared complete, the gateway will transmit the string to the IP network.

“UDP port” parameter :

Set the port number the gateway has to use.

Multicast group IP address :

Enter the multicast IP address assigned to the group with respect to the rules of the IANA authority.

12 USB to IP gateway

That function is available only on the IPRS-1201


12.1 Principles

The IPRS-1201 provides a USB to IP gateway.

It is able to forward IP traffic from devices connected to the Ethernet network to a USB device.

On the USB interface, the IPRS-1201 behaves like a USB host and a PPP client.

The USB device connected to the IPRS-1201 USB interface must behave like a PPP server.



Destination IP address; main case

When a device, connected to the Ethernet network, needs to transmit data to the USB device, the destination address of the IP frames which need to be transmitted to the USB device must be an additional IP address assigned to the USB gateway IPRS-1201 (see the configuration below).

Destination IP address; Modbus case

If no specific IP address is assigned to the USB gateway (see below), the IPRS-1201 forwards only modbus TCP traffic to the USB interface.

The destination IP address of the IP frames must be the LAN IP address of the IPRS gateway.

12.2 Configuration

Select the “Setup” menu and then the “USB” menu.

“Activate” checkbox :

Select the “Activate” checkbox.

“Use a specific IP address” checkbox :

If modbus TCP traffic only has to be forwarded, that checkbox must not be selected.

If other kinds of traffic have to be forwarded, that checkbox has to be selected.

“Specific IP address” parameter :

If modbus TCP traffic only has to be forwarded to the USB interface, no IP address has to be entered.

If other kinds of traffic have to be forwarded to the USB interface, enter a specific IP address.

That address is the specific IP address of the USB gateway. It will be used as the destination IP address of the IP frames which must be forwarded to the USB interface.

“Accept WAN traffic” checkbox:

It is necessary to select that checkbox if the PC is connected to the network connected to the WAN interface.

It is not necessary to select that checkbox if the remote PC is connected to the RAS through a VPN.

13 Alarms

13.1 SNMP

The IPRS gateway is able to send snmp traps when alarms occur.

Activation checkbox :

If that option is selected, the serial gateway will send an SNMP trap if an alarm is detected.

SNMP network management IP address :

Enter the IP address of the management platform

SysName & SysLocation :

That fields allow to identify the source device.

Example :

Sysname : etic

Syslocation : France

Product start-up checkbox :

If that option is selected, the serial gateway will send an SNMP trap each time it will connect to the Internet

13.2 Digital output alarm

If an alarm occurs, the serial gateway will open the digital output..

The causes which make the output to open can be either the ADSL disconnection, power input 1 failure, power input 2 failure.

13.3 E-mail alarm

When the digital input is closed or opened, an email can be transmitted to one of the users of the users list.

To set that function select the "Alarm" menu and click "email".

Enable the alarm email checkbox:

Select this option if you want an email to be sent to a user when the digital input 1 is set ON or OFF.

Alarm launched on event :

If the option OPEN is selected, the alarm will be sent each time the digital input will be opened.

If the option CLOSED is selected, the alarm will be sent each time the digital input will be opened.

If the option BOTH is selected, the alarm will be sent each time the digital input will be opened or closed.

Hold time parameter :

Select the time the input has to stay in its alarm state to be taken into account.

Alarm destination parameter :

Select the user to whom the email must be sent.

Text to send :

Enter the email text.

1 Diagnostic

The html server provides extended diagnostic functions.

Select the Diagnostic menu and then the appropriate sub-menu.

- **Log sub-menu:**

The log displays the last 300 dated events :

ADSL, VPN and users connections and disconnections,
power on,
Serial gateway events.

- **Network status sub-menu and then status sub-menu :**

That screen displays the current status of the LAN interfaces and of the Internet connection :

- **LAN interfaces :**

That part of the page shows the data of the LAN interface :

MAC address,
Ethernet mode (10 /100, half or full),
IP address.

- **Serial gateway :**

That page displays the current status of the serial gateways :

Type of the gateway (Modbus, RAW, Telnet ...),
serial port set-up (data rate etc...),
number of characters received or sent,
Number of TCP frames or UDP datagrams received or sent,
Number of TCP connections enabled.

The View link displays a window which shows the hexadecimal received and transmitted traffic over each serial COM port.

- **Ping :**

That screen enables to send a ping frame to an IP address.

- **IO control**

That screen displays the status of the digital input and output and allows to set ON or OFF the alarm digital output.

2 Saving the parameters to a file

Once a product has been configured, the parameters can be stored and restored when necessary.

To save the parameters,

- Select the “System” menu and then “Save restore”,
- Click the “Save” button
- Select the location to store the file and give a name to the file.

The file suffix is “.bin”.

To restore the parameters,

- Select the “System” menu and then “Save restore”,
- Click the “browse” button and select the parameters file,
- Click the “Load” button and confirm to restart the product.

Attention : A parameters file can only be restored towards a product having the same firmware version.

3 Updating the firmware

Step 1 : Before starting, you need,

a PC with a Web browser and an Ethernet cable;
the FTP server software which can be downloaded from the « firmware page » of the ETIC « download area » web server.

Step 2 : Download the release of the firmware from our download area to your PC

Step 3 : Prepare the PC

Check the IP address of the PC is compatible with the one of the IPRS serial gateway.

Connect the IPRS serial gateway to the PC.

Launch the TFTP server (tftp32.exe) software and select the new release (L026xxx/img) by using the "Browser" button.

Click on "Show dir" to check the files of the directory : rfsmini.tgz, rootfs.bin, u-boot.bin and ulmage.

Step 4 : Update the firmware

Launch the web browser

Enter the IP address of the ETIC product ; the home page of the ETIC configuration server is displayed.

Select the "System" menu and then "firmware Update". In the field "IP address of the TFTP server", enter the IP address of your PC.

Note : The IP address of the PC is written in the field "Server Interface" in the TFTP server windows.

Click "Save" and then "Update".

The first file should begin to be downloaded from the PC to the serial gateway.

During the operation, the led blinks

When the download is finished, the product automatically reboots.

To be sure the new release has been installed, go to "About" in the administration web page of the IP product.

Step 5 : Restore the default configuration

- Select the "Maintenance" menu and then the "Save / restore" menu.
- Click the "Restore default configuration" button.

1/ Setup menu

LAN interface	To enter the IP @ of the serial gateway on the LAN interface. To enter the IP @ assigned to the remote users To set up the Ethernet interfaces
Security	To set the firewall rules (User filter and main filter) To add a certificate To restrict access to the administration server
Alarm	To set up alarm SNMP traps To set up alarm emails
Serial gateway (1)	To set up the modbus gateway (client / server) To set up the RAW TCP gateway To set up the RAW UDP gateway To set up the RAW UDP multicast gateway To set up the TELNET gateway
USB gateway (2)	To set up the USB gateway
System	To set up SNMP parameters To update time and date

2/ Diagnostic menu

Log	To display the events (VPN connections, user connections..)
Serial gateway	To display the status of each gateway (COM1 and COM2)
Tools	To send Pings from the serial gateway
Hardware	To display the input status To control the output To display the DIP switches status
Environment	To display the internal T° and the supply voltage
Advanced	To store the internal report to a disk for diagnostic purposes

(1) IPRS-1220 or IPRS-1230

(2) IPRS-1201



3/ Maintenance menu

- Firmware update To update the firmware
- Save / restore To save or restore a configuration file
 .To restore the factory configuration
- Reboot To restart the gateway

4/ About menu

- To display the certificate "product key"
- To display the firmware version



ETIC TELECOM

13, Chemin du Vieux Chêne

38240 Meylan - France

Tel : 33 4 76 04 20 00

Fax : 33 4 76 04 20 01

E-mail : contact@etictelecom.com

Web : www.etictelecom.com