# ComproPVR 2 User's Guide

Compro Technology, Inc. www.comprousa.com Copyright © 2001-2006. Compro Technology, Inc. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Compro Technology, Inc.

Compro, VideoMate, Poladyne, Play with Power, and the Compro logo are trademarks of Compro Technology, Inc. Other names and marks are trademarks of their respective owners.

Compro makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability, quality, or fitness for any particular purpose. The information in this document is subject to change without notice. COMPRO reserves the right to make revisions to this publication without obligation to notify any person or entity of any such changes.

Compro Technology, Inc. Tel. +886 2 2918 0169, Fax +886 2 2915 2389 3/F, No.12, Alley 6, Lane 45, Pao Shin Road Hsintein City, Taipei, Taiwan www.comprousa.com

# **Table of Contents**

1	Introduction Key Features Installation Updates Remove the Software	<b>1</b> 2 4 4 4 4 4
2	Remote Control	5
	Definitions and Usage	5
	Remote Control Key Definition and Use	6
3	ComproPVR User Interface	7
	Control Panel	7
	Configuration	9
	Channel Options	9
	Video/Audio Options	14
	Recording Options	17
	Timeshifting Options	21
	User Interface	23
	System Devices Options	
4	Using ComproPVR	29
	Watching	29
	Recording	35
	Scheduled Recording	
	PIP or POP for Playback	43
	Video on Desktop	44
	Timeshifting	45
	Still Image Capture	47
	Playback	
	Closed Captioning (USA only)	
	Teletext (PAL TV systems only)	
5	Troubleshooting	
-	OS requirement	
	Driver Installation	
	Video OK / No Audio	
	No audio on the recorded file	
	Recorded file cannot be played	
	Recorded file lags while playing back	
		i

Why can't I choose MPEG-4 format for recording	g?50
Why does the remote control fail?	51
Why does ComproPVR start by itself?	51
Contacting Compro Technical Support	52

# **1** Introduction

ComproPVR is a complete digital entertainment solution for your PC. Watch and record TV programs on your PC, in full-screen mode or in a window. Timeshifting lets you watch TV, pause live TV, or review your favorite scenes without missing a minute of the program. Integrated deinterlacing technology assures the highest picture quality. All this, with the industry's first universal remote control.

ComproPVR can convert analog video sources, such as TV programs, home video tapes, to MPEG-1 / MPEG-2 / MPEG-4 formats for editing and recording to a CD or DVD. Easy-to-use video quality presets simplify the recording process. Everyone can enjoy this convenience and powerful personal video recorder -- ComproPVR.



## **Key Features**

- Watch and record TV programs.
- Supports all TV channels. View all available TV programming.
- Never miss a second with Timeshifting.
- Advanced PIP/POP feature
- Video desktop to watch TV and playback video file in the same time
- Powerful and easy to use schedule recording functioning.
- Capture video from analog video sources and encode them to digital MPEG-1, MPEG-2 or MPEG-4 formats.
- 12 and 16 channels surfing.
- 4:3, 16:9, full screen and customized ratio screens available.
- Convenient Snapshot feature, series or single shot supports.
- Zoom a zone of video image.
- Completely customized On-Screen-Display (OSD) function. Your choices of size, color, and position.
- My favorite channels. Sorting and rearrangement channel orders.
- Video smooth, noise reduction, and scalar technology.
- Mono/Stereo/MTS or Nicam TV stereo support.
- Support Closed Caption and Teletext (where available).
- Electronic program guide support, for example, TitanTV EPG in USA.
- Always on top, hiding window frame and video on desktop.

- Brightness, hue, contrast, saturation, and sharpness options for adjustment. It's also available for each channel.
- Auto splitting of recording files.
- Support for plug-in CODECs.
- Auto tune for best picture quality frequencies.
- Parental control to lock out selected channels.

#### Note

ComproPVR cannot duplicate VHS tapes and DVDs protected by Macrovision<sup>™</sup> technology.

## Installation

Usually, ComproPVR is automatically installed upon inserting the installation CD into your CD drive. Follow the instructions of the software installer.

You can also manually install it by inserting the installation CD. Open Explorer, double-click on the "setup.exe" in the folder named ComproPVR. ComproPVR will be installed right away.

## **Updates**

User satisfaction is the first priority for Compro Technology. Your opinion is crucial in improving our products. Therefore, Compro Technology is continuously improving our products. You can download the latest version of ComproPVR from our website at

http://www.comprousa.com/

After downloading the patch files of ComproPVR, just double-click the update file. It will automatically start the installation program. Restart the computer when prompted.

## **Remove the Software**

You can remove ComproPVR through "Add/Remove Programs" in Control Panel. Find the ComproPVR entry in and click on the "Remove" button. ComproPVR will be removed from your computer.

# 2 Remote Control

## **Definitions and Usage**

Remote control keypad lets you control the ComproPVR application with a familiar, user-friendly interface.

The next two pages describe how to use the remote control to operate ComproPVR.

Note

Not all products support remote function. Please check the description on the product box.

There are different kinds of remote controls. The following illustrate one of the kinds only. Please refer the product installation guide for more information.

The Compro remote control cannot be reprogrammed to control other appliances such as your VCR or satellite decoder box.

## **Remote Control Key Definition and Use**

Please refer to the buttons and their corresponding function listed on the opposite page.

	lcon	ComproPVR 2	ComproDVD 2
	ZOOM	Zoom In/Out	
	DVD	Start/Stop ComproD	VD 2
	TV	Start/Stop ComproP	VR 2
	0-9	Number keys	Number keys
	CHAN	Switch channels	Not used
ZOOM MUTE DVD TV	VOL	Volume	Volume
	REC	Record	Snapshot
4 5 6 <del>-</del>	TV/VIDEO	TV/ S-Video/ Composite	Add to bookmark
	Backward	Replay	Rewind
7 8 9 + VOL	Play/Pause	Pause or enable timeshifting	Play/Pause during playback
REC 0 VIDEO -	Stop	Stop	Stop
	Forward	Advance	Forward
TIMESHIFT LIVE	CC	Closed caption	Select language
CC RECALL SURF MTS	RECALL	Previous channel	Not used
SUBTITLE         MENU         ANGLE         LANGUAGE           SNAP         SLEEP         A         B	SURF	Channel surf	Choose DVD angle
	MTS	Mono/Stereo/SAP	Select language
	Snapshot	Snapshot	Not used
	SLEEP	Sleep function	AB repeat

Α, Β

Not used

Not Used

# **3 ComproPVR User Interface**

## **Control Panel**

The ComproPVR control panel resembles the controls on a VCR. Keep in mind that not all options are available at all times, and may be grayed out or inaccessible depending on your hardware setup and TV services available. The following describe the ComproPVR control panel functions, and tips for using ComproPVR. The following figure gives you the function of the button with (Hot Key.)



lcon	HotKey	Description
	A	Enable/Disable Always-on-Top function for TV window.(Oregon circle on the upper-right corner of the TV window)
n/a	L	Sleep function

Note: Language select is only available while the program supports it.

## Watching

After installation, just press the PVR/TV button on the remote or double click the ComproPVR icon on the desktop you will be able to watch TV.

The first time you start ComproPVR, Autoscan will automatically scan for available TV channels. When **Autoscan** is finished, detected channels are automatically enabled and marked with the green check mark

## Configuration

Click on the **Options Solution** button to open the Options

dialog box.

## **Channel Options**

⊙ Cable ○ Digital TV	<b>○</b> A Digi	<b>Antenna</b> ital TV Se	ttings	Autoscan	Password while Autoscan
Channel	Mem+	Lock		Description	Custom
011	<b>v</b>		ABC		
012	Ĵ,		CBS		
013	<b>`</b>		ESPN		
014					
015					
016	<ul> <li>Image: A second s</li></ul>		NBC		
017	V		Shopp	ing	
018	<ul> <li>Image: A second s</li></ul>		KBOR		
019	<ul> <li>Image: A second s</li></ul>				
020	<ul> <li>Image: A second s</li></ul>				
021	<ul> <li>Image: A second s</li></ul>				
022	<ul> <li>Image: A second s</li></ul>				
023	<ul> <li>Image: A second s</li></ul>				
024	<ul> <li>Image: A second s</li></ul>				
025	<ul> <li>Image: A second s</li></ul>				
026	<ul> <li>Image: A second s</li></ul>				Ľ.
Use My Favorites as Channel List           Fine Tune					

Follow these steps to customize and configure your channel list.

#### Video Source

First, select your video source, Cable or Antenna.

#### Autoscan

The first time you start ComproPVR, Autoscan will automatically scan for available TV channels for both Cable signal and Antenna signals. You can rescan the channels at any time by pressing the **Autoscan** button.

- ComproPVR will automatically scan all available channels for content. The number of scanned channels varies according to whether you use antenna or cable TV input and your country settings.
- 2. You can interrupt the scanning process by pressing the **Stop** button.

After you are finished scanning for available channels, you may select **OK** to return to the display window, or customize the channel list according to your preferences, as described below.

### **Channel Naming**

You can customize the channel names by following these steps.

- Step1. Double-click on the **Description field** of the channel you wish to rename.
- Step2. Type a new name in the text box.

- Step3. Repeat steps 1 through 2 for any other channels you wish to rename.
- Step4. Click **OK** to confirm your modifications.

#### Note

If you enable the checkbox of "Clear Description field while Autoscan," then the text in the field will be erased while Autoscan. The default is disabled.

#### Set Mem+

During the **Autoscan** process, ComproPVR automatically detects and enables channels with valid signal. By default, every available channel will be enabled and marked with the green *✓* icon. However, you can shorten the list of enabled channels to reduce channel-browsing time. Customize your list by enabling or disabling channels from the channel list by clicking on the green *✓* icon.

Disabled channels will not shown when you use the channel Up and Down or channel surfing functions.

#### Set Lock (Parental Control)

By default, ComproPVR lets you access all available channels. A Parental Control feature allows you to restrict the viewing of certain channels altogether or during limited times.

You can lock a channel by clicking in the column labeled **Lock** next to the channel number you wish to restrict. You will then see a red check mark  $\checkmark$  in the box next to the channel. You can unlock it by clicking the check mark.

To use this feature, you should first set a password and follow these steps:

Step1. Start ComproPVR and click on the **Options** button and select the **Channels** tab.

- Step2. Click on the **Password** button and enter the new password in the fields labeled **Password** and **Confirm**.
- Step3. If you previously set a password, you must also enter the old password in the appropriate field.
- Step4. Click on the **OK** button.

#### **Change Password**

Click on the **Password** button. Enter the old password in the field labeled **Old Password**. Then enter the new password in the field labeled **Password** and **Confirm**.

#### **Custom Channels**

ComproPVR can let you set video properties (brightness, contrast, etc) for each channel. Just press the button on the custom column in Channel tab in Settings of ComproPVR. The dialog box will pop up as follow.

Channel Property		
Video Properties		
Brightness		0
Hue		0
Contrast		0
Saturation		0
Sharpness		0
Format SECAM_D	Default OK C	ancel

#### Note

These settings are increasing or decreasing the value of video properties in Video/Audio tab in the next section.

#### **My Favorite Channels List**

ComproPVR includes a channels sorting and re-ordering feature. Check the "Use My Favorites as My Channel Lists" checkbox. You can see the window below.

Available Channels       My Favorite Channels         Ch       Description       Image: Channels         003       Image: Channels       Image: Channels         004       Image: Channels       Image: Channels         005       Image: Channels       Image: Channels         006       Image: Channels       Image: Channels         006       Image: Channels       Image: Channels         007       Image: Channels       Image: Channels         006       Image: Channels       Image: Channels         007       Image: Channels       Image: Channels         006       Image: Channels       Image: Channels         007       Image: Channels       Image: Channels         008       Image: Channels       Image: Channels         009       Image: Channels       Image: Channels         011       ABC       Image: Channels         012       CBS       Image: Channels         013       Image: Channels       Image: Channels         014       Image: Channels       Image: Channels         025       Image: Channels       Image: Channels         026       Image: Channels       Image: Channels         012       Image: Channels       Image	Arrange List	$\mathbf{X}$
Ch       Description         003       Image: Ch       Description         004       Image: Ch       Description         005       Image: Ch       Description         006       Image: Ch       Description         006       Image: Ch       Description         007       Image: Ch       Description         008       Image: Ch       Description         009       Image: Ch       Difference         010       Image: Ch       Difference         010       Image: Ch       Image: Ch         010       Image: Ch       Image: Ch         011       ABC       Image: Ch         016       NBC       Image: Ch         017       Shopping       Image: Ch         018       KBOR       Image: Ch         019       Image: Ch       Image: Ch         021       Image: Ch       Image: Ch         022       Image: Ch       Image: Ch         023       Image: Ch       Image: Ch         024       Image: Ch       Image: Ch         025       Image: Ch       Image: Ch         026       Image: Ch       Image: Ch	Available Channels	My Favorite Channels
027 028 029 030	Ch       Description         003       004         005       005         006       1         007       1         008       1         009       10         010       19         020       1         021       1         022       1         023       1         024       1         025       1         026       1         027       1         028       1         029       1         030       1	Ch Description 011 ABC 013 ESPN 016 NBC 017 Shopping 018 KBOR 012 CBS 012 CBS

Select the channel you wish to add to my favorite and press the proper arrow button. You may double-click on the channel to move it as well. In addition, adjusting the channel order by using the proper arrow button.

## **Fine Tuning**

ComproPVR includes a fine-tuning feature. Select the channel you wish to fine tune and press the button labeled, "Fine Tune." You may then adjust the slider and then press the button labeled, "Exit."

Fine-tuning is normally unnecessary.

## Video/Audio Options

Options 🔀		
Channel Video/Audio Recording Timeshifting User Interface System Devices		
Source     Preview Video Size       TV     720x480		
Country/Region Format USA  NTSC_M		
Brightness     0       Hue     0       Contrast     57       Saturation     127       Sharpness     1		
Mono/Stereo/SAP          Stereo       Image: Sleep Mode         SLEEP OFF       Image: Sleep Computer on		
OK Cancel Apply		

#### Source

Select the video source from among TV, S-Video, or

Composite. Also you can click the button on the control panel to switch video sources.

#### **Preview Video Size**

ComproPVR supports the resolution from 160\*120 to 720\*480 for NTSC and from 160\*120 to 720\*576 for PAL. You can choose the resolution here.

Note

This influences the snapshot resolution.

#### **Country/Region**

Use the pull-down menu to select the country you are in. This allows ComproPVR to use the correct set of frequencies for TV tuning.

#### Video Format

Select the proper video format for your area from the drop-down menu. The options available depend on the standards supported by the TV tuner in your system.

The NTSC standard is used in United States, Canada, Japan, Taiwan and parts of Central and South America. It specifies 525 lines of display at 30 frames per second.

The PAL standard is used in most of Europe, Australia, China and parts of Central and South America, and specifies 625 lines at 25 frames per second.

Additionally, each TV system uses slightly different frequencies. Therefore, it is important to choose the correct settings.

#### **Video Properties Sliders**

Use the sliders in this area to adjust:

- Brightness: Adjusts the amount of white in the image.
- Hue: Adjusts whether the image looks red, green, blue, yellow, orange, etc.

- Contrast: Adjusts the gradation of tone between the image highlights, mid-tones, and shadows.
- Saturation: Adjusts the color intensity of the image.
- Sharpness: Adjusts the sharpness of the image.

Press the **Default** button to reset the sliders to their original positions.

Note

Pressing the **Default** button for Video Properties sometimes fixes the situation where you have audio but a blank (black) or off-color video.

#### Audio Mode

You can select Mono, Stereo or SAP in this dialog box.

#### Note

Stereo and SAP sound may not be available in your area or for all programs in your area.

#### **Sleep Mode**

You can enable sleep mode and set the time delay before ComproPVR automatically shuts itself off.

If the check box "Close application and keep computer on" is checked, then it will close ComproPVR instead of shutting down the computer.

## **Recording Options**

Options	$\overline{\mathbf{X}}$
Channel Video/Audio Recording Timesh	ifting User Interface System Devices
DiskTypeAvailable SC:HDD14.51 GBD:CDROM-E:HDD16.62 GB	Total Volume 19.53 GB
Path	
Quality Advanced Settings CODEC Use Custom Encoder Select Encoder	Format : NTSC MPEG - II Dimension : 720 * 480 Video Bitrate : 6400 kbps Audio Bitrate : 224 kbps Audio Frequency : 48 KHz Available Time : 321 minutes
Performance Exceptional	Hardware Scaling
File Split Size:	Skip 30 🔿 seconds
Recording Volume	50
	OK Cancel Apply

#### Path (Recorded Programs Folder)

Click on the \_\_\_\_\_ button to set the folder where recorded

programs are stored. Check that you have ample disk space to store recorded programs.

#### Quality

Here you can select the video and audio quality settings of recorded programs. ComproPVR includes useful quality presets, from VCD to DVD-quality. However, Custom settings may not be compatible with standard formats. Use it with caution

You can also use **custom** settings by following these steps.

### **Advanced Settings**

Here you can select the details of video and audio quality settings of recorded programs.

Advanced Settings	$\mathbf{X}$	
Format MPEG - II		
Dimension	Frame Rate (Video Format)	
720 * 480 💉	29.97 (NTSC) 🛛 🔽	
Video Bitrate 6400 💮 kbps	🗌 Variable Bit Rates	
Audio Bitrate	Audio Frequency	
224 💽 kbps	48 💽 KHz	
Lock current channel while recording     OK Cancel		

**Format:** Choose between MPEG-1 or MPEG-2 video encoding formats. For example, select MPEG-1 if you want VCD format or select MPEG-2 if you want DVD format.

**Dimension:** Select the recording resolution you like.

**Video Bit Rate:** Video bit rate is expressed in kilobits per second. The higher the bit rate, the more processing power and disk space are required to record and playback video programs.

**Audio Bit Rate:** Choose the audio bit rate you like here. Audio bit rate is expressed in kilobits per second.

**Frame Rate:** NTSC system uses 29.97 FPS (Frame Per Second) while PAL system uses 25 FPS.

**Variable Bit Rates:** Checking this box will use variable bit rates to record. Usually, this will have better video quality. However, CPU loading is higher as well.

**Audio Frequencies:** Standard DVD audio frequencies are 48 KHz while other formats use 44.1 KHz.

**Lock current channel while recording:** Checking this box will disable the channel switching. Un-checking this box can change channel while recording.

#### Note

Switching channel while recording doesn't mean you can record two channels simultaneously. Instead, it is to record another channel after the switch.

#### CODEC

CODECs encode to and decode from video files, usually with a compression scheme, examples include, MPEG-4 and DiVX CODECs. In addition to the CODEC supplied by Compro, ComproPVR can use third-party CODECs that are already installed on your system. Select "Use Customer Encoder" in other to use third-party CODECs.

#### Note

If you would like to record video in MPEG-4 format, you must supply your own MPEG-4 CODEC. You can download MPEG-4 CODEC from the following web sites.

http://www.divx.com/

http://www.microsoft.com/windows/windowsmedia/forma t/codecdownload.aspx

After installing the CODEC software, you will see the MPEG-4 format appear in the field of recording quality.

Compro does not guarantee compatibility or performance with third-party CODECs.

### Performance

You can choose the encoder performance here. The better you choose, the picture quality will be better. However, more processing power is required to record. If CPU usage reaches 100%, the video will become jumpy. Reduce the performance or choosing lower quality like VCD will help.

## File Split Size

Checking this box will enable the automatic splitting of the recording file to the size you want. This is useful burning recording files to CD.

## Skip

Set the amount of programming skipped, in seconds, when you press the **Replay** and **Advance** buttons during video playback.

## **Recording Volume**

You can adjust recording audio volume here. Moving the bar to the right will increase recording audio volume.

### **Timeshifting Options**

Options	×
Channel Video/Audio Recording Timesh	fting User Interface System Devices
Buffered Time Buffered Time	e: 10 minutes
Path	
Citality	
Format MPEG - II	Format : MPEG - II Dimension : 640 * 480 Video Bitrate : 4000 kbps Audio Bitrate : 224 kbps Available Time : 500 minutes
640 * 480 Video Bitrate 4000 kbps	
Audio Bitrate	<
Skip 30 💌 seconds	
[	OK Cancel Apply

#### **Buffered Time**

Set the amount of programming that is stored, or "buffered" during Timeshifting. It also shows the total recording time available.

**Do not** set the Buffered Time to consume all free disk space.

#### Path (Buffer file storage location)

Choose the folder where the Timeshifting buffer file is stored. Choose a folder in a disk partition with ample free disk space. See the video format table for estimates of the amount of disk space needed.

#### Quality

Choose the recording quality used during Timeshifting. Higher quality levels consume more disk space.

The appropriate quality setting depends on many factors, including the speed of your PC, the amount of free disk space, and the quality of source material. For example, when recording broadcast television for later viewing, a medium quality level is usually sufficient. If you plan to archive or edit the video, a higher video quality may be more appropriate.

#### Skip

Set the amount of programming time skipped when you press the Advance and Replay buttons during Timeshifting.

#### **User Interface**

Options	X
Channel Video/Audio Recording 1	Timeshifting User Interface System Devices
⊂ Snapshot	
Path	
E:\Documents and Settings\mce\	My Documents\My Pictures\
File Type	JPEG Compression Quality
JPEG File 💌	80
Channel Surfing	OSD
Channel Number	✓ Enabled
12	Color 🔤
Display Ratio	
Aspect Ratio	Size
4:3	Paritian -
Monitor Ratio	Position X
Windows Default 🛛 🖌	
Video Trimming	
	Chn. Number V Description
Language	Default
	Porduit
	OK Cancel Apply

### Path (Snapshot file storage location)

Choose the folder where the snapshot pictures are stored. Choose a folder in a disk partition with ample free disk space. See the video format table for estimates of the amount of disk space needed.

#### File Type (Snapshot file type)

Choose the snapshot file type. There are BMP and JPEG format available.

If you choose JPEG format, you can also adjust the JPEG Compression Quality on the bar of right side.

#### **Channel Surfing**

Choose the number of channel surfing. There are 12 and 16 options available.

#### **Aspect Ratio**

Select the display screen aspect ratio, the ratio of screen width to screen height. The default ratio is 4:3. You may also choose the 16:9 wide-screen or custom ratios.

If you select a standard ratio, i.e., 4:3 or 16:9, the screen will retain this ratio when you resize it. If you select a **Custom**, ratio, you can modify the ratio by clicking and dragging the lower-right corner of the ComproPVR display window.

#### **Monitor Ratio**

Select your monitor's ratio of screen width to screen height. The default ratio is 4:3. If your monitor's ratio is not 4:3, you still can have a full screen of 4:3 ratio by choosing the correct ratio of monitor here. This is very convenience for your viewing.

### Video Trim

When you see the static strip on the top or bottom of screen, you can crop those lines by adjusting the bar.

The static strip is called the "green line." You won't see this line on normal televisions because they do not show you the entire picture. Standard TV sets trim the edges of the TV picture. ComproPVR, on the other hand, can show you the entire picture, including the "green line."

### **OSD (On-Screen Display)**

When you select the checkbox next to **enable OSD**, channel information such as channel numbers, channel names, and audio quality will be displayed as you switch channels. When this box is unchecked no information will be displayed.

Also you can customize your own text color, position, and size.

### Default

If you press the default button, all User Interface tab parameters will be set to the application program default value.

#### Language

You are welcome to select the language you like for the user interface of ComproPVR here.

### **System Devices Options**

Channel Video/Audio Recording Timeshifting User Interface System Devices         Video       VideoMate X series Video Capture         Audio       Realtek AC97 Audio         TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audid         • TV Mixer: Volume Control         • Record Mixer: Line In         • PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2500)         OS Windows XP Service Pack 2 (build 2500)	Options				
Devices       Video       VideoMate X series Video Capture         Audio       Realtek AC97 Audio         TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device:       VideoMate X series Video Capture         Audio Device:       Realtek AC97 Audio         Video Device:       Realtek AC97 Audio         Yideo Device:       VideoMate X series Video Capture         Audio Device:       Realtek AC97 Audio         • TV Mixer:       Volume Control         • Record Mixer:       Line In         • PCI Audio Disabled       Image: Control         • Second Mixer:       Line In         • PCI Audio Disabled       Image: Control         0S:       Windows XP Service Pack 2 (build 2600)         0S: Default Country:       Unite States         DirectX version:       DirectX 9.0 or better installed         VGA:       RADEON X600 Series         VideoMate       TY: 2, 3, 2, 4         VideoMate       Ty: 2, 3, 2, 4         VideoMate       Ty: 2, 1, 23         VideoMate       Ty: 2, 2, 2, 4         VideoMate       Ty: 2, 2, 0, 4, 9         Analog TV Settings:       Image: Control Ty Settings	Channel Video/Audi	o Recording Ti	meshifting User Interface	System Devices	
Video       VideoMate X series Video Capture         Audio       Realtek AC97 Audio         TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audio         • TV Mixer: Volume Control         • Record Mixer: Line In         • PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2600)         OS Default Country: United States         DirectX version: DirectX 9.0 or better installed         VGA: RADEON X600 Series         VideoMate TV: 2, 3, 2, 4         VideoMate TV: Hybrid: 1, 3, 1, 23         VideoMate X-Series: 4.2.3.2 built by: WinDDK         VideoMate U3: 5.1.2600.1106 built by: WinDDK         ComproPVR Version: 2, 0, 4, 9         Analog TV Settings:	- Devices				
Audio       Realtek AC97 Audio         TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audid         • TV Mixer: Volume Control         • Record Mixer: Line In         • PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2600)         OS Default Country: United States         DirectX version: DirectX 9.0 or better installed         VGA: RADEON X600 Series         VideoMate TV 12, 3, 2, 4         VideoMate TV Hybrid: 1, 3, 1, 23         VideoMate TV Hybrid: 1, 3, 1, 23         VideoMate U3: 5.1.2600.1106 built by: WinDDK         ComproPVR Version: 2, 0, 4, 9         Analog TV Settings:	Video	Videolv	late X series Video Capture	*	
TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audiol         . TV Mixer: Volume Control         . Becord Mixer: Line In         . PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2600)         OS Default Country: United States         DirectX version: DirectX 9.0 or better installed         VGA: RADEON X600 Series         VideoMate TV: 2, 3, 2, 4         VideoMate TV Hybrid: 1, 3, 1, 23         VideoMate U3: 5.1.2600.1106 built by: WinDDK         VideoMate U3: 5.1.2600.1106 built by: WinDDK         ComproPVR Version: 2, 0, 4, 9         Analog TV Settings:	Audio	Realte	k AC97 Audio	~	
TV Live Mixer       Volume Control         Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audio]         • TV Mixer: Volume Control         • Record Mixer: Line In         • PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2600)         OS Default Country: United States         DirectX version: DirectX 9.0 or better installed         VGA: RADEON X600 Series         VideoMate TV Hybrid: 1, 3, 1, 23         VideoMate X-Series: 4.2.3.2 built by: WinDDK         VideoMate U3: 5.1.2600.1106 built by: WinDDK         ComproPVR Version: 2, 0, 4, 9         Analog TV Settings:					
Recording Mixer       Line In         Video Device: VideoMate X series Video Capture         Audio Device: Realtek AC97 Audiol         . TV Mixer: Volume Control         . Record Mixer: Line In         . PCI Audio Disabled         OS: Windows XP Service Pack 2 (build 2600)         OS Default Country: United States         DirectX version: DirectX 9.0 or better installed         VGA: RADEON X600 Series         VideoMate TV: 2, 3, 2, 4         VideoMate TV Hybrid: 1, 3, 1, 23         VideoMate TV: Series: 4.2.3.2 built by: WinDDK         VideoMate U3: 5.1.2600.1106 built by: WinDDK         ComproPVR Version: 2, 0, 4, 9         Analog TV Settings:	TV Live	Mixer	Volume Control	~	
Video Device: VideoMate X series Video Capture Audio Device: Realtek AC97 Audio . TV Mixer: Volume Control . Record Mixer: Line In . PCI Audio Disabled OS: Windows XP Service Pack 2 (build 2600) OS Default Country: United States DirectX version: DirectX 9.0 or better installed VGA: RADEON X600 Series VideoMate TV: 2, 3, 2, 4 VideoMate TV Hybrid: 1, 3, 1, 23 VideoMate TV Hybrid: 1, 3, 1, 23 VideoMate V-Series: 4.2.3.2 built by: WinDDK VideoMate U3: 5.1.2600.1106 built by: WinDDK ComproPVR Version: 2, 0, 4, 9 Analog TV Settings:	Recording	g Mixer	Line In	~	

#### **Video Device**

Please refer the product manual for more information about it. If you don't see the device name here, then you didn't install the device driver properly. Please refer the trouble shooting section in the product manual.

#### **Audio Device**

ComproPVR automatically detects the audio input devices available in your system. Here, you must select the appropriate audio input devices for your system.

#### Note:

You must select the proper Video and Audio devices for correct operation.

If you do not see the appropriate Video and Audio devices, the drivers are not properly installed. Please reinstall these drivers and see product manual for more information.

#### **TV LIVE Mixer**

You can choose the audio source for watching live TV programs. The default is set to main volume.

#### **Recording Mixer**

Please refer the product manual for more information about it.

#### Support

Before contacting Compro for technical support, please check our FAQs (Frequently Asked Questions) on our website. Click on the **FAQ** button will lead to http://www.comprousa.com.

You can download the latest update from our website. Many issues may be solved on the newer version.

If you click on the **E-mail Info** button, ComproPVR will attempt to e-mail this information to the Compro Technical Support team. (support@comprousa.com).

When you contact the Compro Support team about a problem, please write enough details to help us determine the problem. Please also provide the product serial number (19 digits numbers) on the PCI TV tuner card. You can submit your problem in the support form provide by our website.

http://comprousa.com/ support/form.htm

#### Notes

Check the troubleshooting chapter of in this manual for more information before you submit an email for support.

When contacting us, providing the product serial number is important to helping us evaluate the problem. It tells us exactly which product you have.

In order to solve the problem quickly, submitting the details about your problem is crucial to understanding the problem.

# 4 Using ComproPVR

## Watching

After installation, just press the ComproPVR button on the remote or mouse click ComproPVR icon on the desk you will be able to watch TV. Same as operate a normal TV set. Watch TV programs on your PC, in full-screen mode or in a window. Channel up and down. Close ComproPVR and even shutdown the computer with full function remote control keypad.

### **Channel Browsing**

When watching TV, you can browse channels with the

Channel Down 💟 and Channel Up 🚺 buttons to

scroll up and down through the available, enabled channels.

The keyboard shortcuts **Page Up** and **Page Dn**, and the Compro remote control can also be used.

Jump directly to the desired channel by using the number pad on your keyboard or remote control.

The **Last Channel** (recall) button jumps back to the previously selected TV channel.

If the On-Screen Display function is enabled on the Display Options page, channel information will appear briefly in the corner of the display window as you switch channels.

### **Channel Surfing**

While watching TV, the channel surfing feature displays a 4x4 grid of channel images to give you an overview of available programming.

To start the channel surfing feature, press the Channel

**Surfing** button on the ComproPVR control panel. Thumbnail images will begin to appear in the display window. With your mouse, click on the program you wish to watch and you will exit surf mode. You can also return to normal mode by clicking on the **Channel Surfing** button again.



There are 12 and 16 options available for the number of channel surfing. The setting is available on the User Interface tab in the Options of ComproPVR.

#### **Right-Click Mouse Menu**

If using mouse to right-click on the TV screen, you can see the menu below. There are many useful options for your convenience.

Channel Down Channel Up Channel Return	
Channel List 🔹 🕨	CH 002 NBC
Audio 🕨	CH 003 CBS
Diav	CH 004 FOX
	CH 005 CNN
Record	CH 006 ABC
Timeshift	CH 007 ESPN1
Channel Surfing	CH 008 ESPN2
Options	CH 009 Sports
Maximiza	CH 010 HBO
Hida Window Erama	CH 011 Cinema
	CH 012 Good News
Always on Top	CH 013 Shopping
About	
Exit	

## Zooming image

If you like to see more detail on the part of video image, you can press the mouse right button to drag a zone of the screen. You will see the zooming image.

Also you can press the mouse right button and move on the screen to shift the zone area of the image.

Just click the mouse left button to resume the normal mode.

## **Custom channels**

ComproPVR can also set video properties (brightness, contrast, etc) for each channel. Just press the button on the custom column in Channel tab in Settings of

ComproPVR. The dialog box will pop up as follow.

Channel	Mem+	Lock	E	escription	Custom	^
011	<ul> <li>Image: A second s</li></ul>		ABC		( )	
012	×		CBS			
013	×		ESPN			-
Channel 1	Property				×	
_ Video ∶	Properties —					
	Brightness	_		0	— O	L
	Hue	_		0	— O	L
	Contrast	_		-0	— O	L
	Saturation	_		0	— O	L
	Sharpness	_		-0	— O	L
Format						L
SECAM	[_D		Default	OK	Cancel	

ComproPVR can let you re-order channel number if necessary. After Autoscan channels, channel number is as same as default channel number. What if your local TV station uses different channel number, you can click mouse on the column of the channel to drag up or down to the channel order you like.

Options							
Channel Video/	Audio Reco	rdina Tin	neshiftina	User Interface	System Devices		
				// = · · · · · · · · · //	-,		
📀 Cable	🔵 Ante	nna		Autoscan	Password		
O Digital TV	O Digital TV Digital TV Settings Clear Description field while Autoscan						
CH Num	Default CH	Mem+	Lock	CH Name	Custom	^	
002	011	<ul> <li>Image: A second s</li></ul>					
003	006	<ul> <li>Image: A second s</li></ul>					
004	012	<ul> <li>Image: A second s</li></ul>					
005	007	<ul> <li>Image: A set of the set of the</li></ul>					
006	009	<ul> <li>Image: A second s</li></ul>					
007	010	<ul> <li>Image: A second s</li></ul>					
008	002	<ul> <li></li> </ul>					
009	003	<ul> <li>Image: A second s</li></ul>					
010	013	<ul> <li>V</li> </ul>					
011	005	- V					
012	004	- V					
013	014						
014	015						
015	008	~					
016	016	- U					
017	017	- Ŭ				<b>v</b>	
click mouse on the channel to drag the order you like Use My Favorites as Channel List Fine Tune							
				OK Ca	ncel Ar	oply	

Note

The Difference between "Custom Channels" and "My Favorite Channels List" are:

Using "My Favorite Channels List" will only shows the channels you have selected and rotate with up and down in the order you have set.

"Using "Custom Channels" you will be able to assign a new channel number to a frequency and therefore will be able to press the number to select the channel. Combine both function as you need it can be very convenient.

This manual only provides basic information for the ComproPVR 2. For more information on using applications, please see the User's Guides in the programs, on the CDs, or at our website for the latest manuals.

## Recording

ComproPVR is a digital video recorder. ComproPVR can record full-motion video and audio from your video source and save it to your hard disk. ComproPVR supports MPEG-1, MPEG-2, MPEG-4 encoding, which saves disk space while providing high video quality.

To instantly start recording:

- 1. Press the **Record** button . ComproPVR starts recording the video source currently showing in the display window. It will save it to a file on your disk. While recording, you can press the button to setup recording time for 30, 60, 90, and 120 minutes for more convenience if you need to leave to other place.
- 2. Press the **Stop** button **See** to stop recording.
- 3. When you stop recording, ComproPVR prompts you to name the file containing the recorded video. Enter the name and press **OK**.

To playback the recorded file, press the **Play** button and select the file you wish to view.

### Disk usage

The actual disk space used primarily depends on the quality settings for recording. A higher quality setting, e.g., DVD-quality, requires significantly more disk space than a lower quality setting, such as VCD-quality. The appropriate quality depends on the quality of the source material, e.g., DV camera versus broadcast TV, and your intended use of the recorded programming.

Format	Screen Size	Video Bit Rate (Mbps)	Audio Bit Rate (Kbps)	Typical Disk Usage
NTSC DVD	720*480	6.4	224	3 GB/hr
NTSC 1/2-DVD	352*480	3.6	224	1.7 GB/hr
NTSC 1/4-DVD	352*240	1.8	224	1 GB/hr
NTSC VCD	352*240	1.1	224	600 MB/hr
NTSC SVCD	480*480	2.2	224	1 GB/hr
NTSC PC MPEG-2	720*480	6.4	224	3 GB/hr
NTSC 1/4-PC MPEG-2	720*480	1.8	224	1 GB/hr
PAL DVD	720*579	6.4	224	3 GB/hr
PAL 1/4-DVD	352*288	1.8	224	1 GB/hr
PAL VCD	352*288	1.1	224	600 MB/hr
PAL SVCD	480*576	2.2	224	1 GB/hr
PAL PC MPEG-2	720*288	4.0	224	2 GB/hr
PAL 1/4-PC MPEG-2	352*288	1.8	224	1 GB/hr

#### Video File Formats Table

#### Note

You can adjust recording quality settings, and thus disk usage, in the **Recording Options** menu.

Not all formats are available for all products.

## **Scheduled Recording**

ComproPVR can be scheduled to record a TV program later or remind you of an upcoming program. The schedule can be set for a one-time or a recurring session. You can repeatedly record any regularly scheduled programming. Relax. Never miss your favorite shows.

Press the icon to open the **Schedule Recording** dialog box.

Scheduled Progra	m Lists				×	
Event Name	Schedul	Source	Start Date	Duration	Status	
TV_CH017_2005	Recording	TV:CH017	2005/08/23 12:00	30 mins	Standby	
TV_CH017_2005	Recording	TV:CH017	2005/08/24 15:00	1410 mins	Standby	
<		1111				
Event Information         Event Name: TV_CH017_20050823_1500         Scheduled Mode: Record         Scheduled Mode: Record         Video Source: Cable TV         Channel: 17         Quality: PAL DVD         Format: MPEG - II         Dimension: 720 * 576         Video Bitrate: 6400 kbps         Audio Bitrate: 224 kbps						
Create	odify	Delete	Delete Completed		ОК	

#### **Scheduled Program Lists**

Create: Create a new scheduled recording event.

Modify: Modify an existing recording event.

**Delete:** Delete an existing recording event.

**Event Information:** Shows details about your recording schedule.

#### **Scheduled Recording Settings**

You can see the following after clicking **Create**.

Scheduled Recording	g Settings			
Event Name TV_CH017_20050823_ Folder: E:\Documents and Sett	1500 ings\mce\My Docum	Format	Quality Settings PAL DVD Use Custom Enco Available Time : 321	ider minutes
<ul> <li>Enable automatic pow</li> <li>Enable automatic log</li> <li>After recording:         <ul> <li>Shut down the sy</li> <li>System stand by</li> <li>Keep system pow</li> </ul> </li> <li>Recording Settings</li> <li>Scheduled Mode         <ul> <li>Record</li> <li>Reminder</li> <li>Turn On Compute</li> </ul> </li> </ul>	wer up function on «stem ver on		Date/Time Settings - Once Repeat Sunday Monday Tuesday Wednesday Wednesday Friday Saturday	Start Date         8/23/2005         Start Time         15:00         24-hour format         Duration         23:30         End Time         2005/08/24 14:30
Video Source: Channel: Audio Mode:	Cable TV CH 017 Shopping Stereo recording	* •	Weekday	Daily Clear

**Event Name:** Type the event name. The saved recording file will also use this name.

If you leave this field blank, ComproPVR will automatically create the **Event Name** and file name. The **Format** button lets you select the file name format.

Event Name Format 🛛 🔀
Example:
TV_CH030_HBO_20050823_110
Channel
Description
🗹 Start Date
🗹 Start Time
OK Cancel

**Channel Number:** Check this box to add channel numbers to the names of the recording files.

**Start Date:** Check this box to add the start date to the names of the recording files.

**Start Time:** Check this box to add the start time to the names of the recording files.

### **Power Up Scheduling feature**

#### Note

Your VideoMate U880/U900 USB 2.0 box only supports S3 (Standby) or S4 (Hibernation) mode Power Up Scheduled Recording

**Enable automatic power function:** Check this box if you wish to use Power Up Scheduling function, i.e., wake up the computer from Shutdown or Stand by states for scheduled recording.

This option is available only if your hardware supports Power Up Scheduling.

Power Up will start your computer 5 minutes in advance of the scheduled time. If you set schedule to 4 o'clock,

Power up will wake up your computer at 3:55. Therefore, you need to shut down the computer before 3:54 in order to let Power Up start the computer.

There are three possible actions after recording is complete:

- Shut down the system: After recording, shut down the system.
- System stand by: After recording, put computer in stand by mode.
- Keep system power on: After recording, does not shutdown system.

**Enable automatic logon:** When using Power Up Scheduling, ComproPVR will start Windows. If Windows requires you to enter a username and password during start up, you should check this box and enter the required information.

This option will be grayed out if your hardware doesn't support Power Up Scheduling.

If "Enable automatic logon" is checked, you will see a popup window.

Logon	×
User	
test	
Password	
•••••	
Domain	
OK Cancel	]

There are three fields in the Automatic Logon window.

 User: ComproPVR will detect your current user name automatically. Unless you wish to logon by a different user, there is no need to change it.

- **Password:** Type in your password.
- Domain: ComproPVR will automatically detect your Windows Domain name, if any. In most home PCs, this field will be blank and need not be changed. (See Note below). Do not modify this field unless you need to logon to a different Windows Domain during the Power Up process.

Press the OK button to proceed.

#### Notes

Enabling the automatic logon function is only necessary when you need to type user name and password to logon to Windows.

The Windows Domain name is not the Internet domain name that you may be familiar with, e.g., Yahoo.com. Windows Domains usually only exist in business networks. For most users, this field should be left blank.

Your password will be stored on your computer. There is a chance that your password could be discovered by another user

The ComproPVR does not use the logon information for any other purpose.

#### **Recording Settings**

**Schedule mode:** There are two ways to set the schedule.

- Recording: At the set time, ComproPVR starts recording the program.
- **Reminder:** At the set time, ComproPVR starts showing the program without recording it.

**Video Source:** Select video source from CATV or Antenna.

Channel: Select the channel you want to record.

**Audio mode:** Select the audio source you want to record.

**Mute speakers while recording:** Check this box to mute speakers while recording. This feature is useful if the program is to be recorded while you are asleep.

#### **Quality Settings**

**Quality settings:** Select the video quality at which you wish to record. Refer to the Video File Formats Table (page 30) to better understand the relationship between video quality and disk usage.

#### **Date/Time Settings**

Once: Select this to record this program once.

**Repeat:** Select this to record this program repeatedly. You can select any kind of combination in a week to record the programs repeatedly. You can press **Weekday** or **Daily** button to select multiple days. Press **Clear** to uncheck the boxes.

**Date/Start Date:** Select the date you want to record the program or the start date for repeat scheduling.

**Start time:** Select the starting time for recording.

Duration: Amount of programming to be recorded.

**OK:** Click it to add this schedule.

#### Notes

The ComproPVR scheduler program must be running (orange circle visible in the system tray).

#### Play

Pressing the Play button can open up a menu with a list of files which you have recorded with ComproPVR.

You may play, rename and delete with this list. You may also change the folder to select other files.

## **PIP or POP for Playback**

ComproPVR features PIP or POP for playback window. You will see a window popping up after choosing a file for playback as following.



Main window has all features while slave window has limited functions only. Double-click on the slave window can switch the TV program to the main window.

The buttons on the upper-left corner of slave window

respectively.

#### Note

PIP or POP can't let you watch two different channels at the same time due to one tuner can only tune to one frequency.

Running additional windows consumes more CPU usage. If CPU usage reaches 100%, then video lag will occur. Please close the slave windows for this case.

Slave window has no full screen mode. Please double-click on slave window to switch program with main window in order to do so.

It is available to hear audio on multiple programs at the same time. You can mute or un-mute the sound of slave window at any time. However, main window audio can't be muted separately from slave window.

## Video on Desktop

While watching TV, you may right-click on the TV screen and select video on desktop or press the hotkey (F7) to activate Video on Desktop mode. This mode makes the video source as your desktop screen. It is similar with full screen but the desktop icons and taskbar will remain on top. The following picture shows the TV on the desktop.



## Timeshifting

Timeshifting lets you pause, replay, or skip commercials during live TV, without interrupting an ongoing recording session. Timeshifting gives you absolute control over how you watch television, like never before. For example, you watch your favorite sporting event, pause the live action and help yourself to an ice-cold beverage from the fridge.

Press the **Timeshifting** button and the Time

Monitoring bar will appear. (See below.)

-----

The Time Monitoring bar informs you of how much of the timeshifting buffer is in use You can also use your mouse to drag the Time Control Shuttle to jump to a specific time in the program.

You may also press the **Advance** (for commercial skip) and **Replay** (for instant replay) buttons on the control panel or remote control to navigate through the program.

Timeshifting temporary saves the video to your hard disk for a specified period of time.

When you return to your seat, you can resume viewing the program from the point when you left.

Note

Timeshifting can use significant disk space and cannot automatically skip commercials.

#### **Additional Discussion**

In timeshifting, you are recording to and playing back from the same video file or buffer. You can playback from various locations in that buffer.

Similar to video playback, you can pause, fast-forward, and rewind. A major difference, however, is that ComproPVR is simultaneously recording live television. This means you will see greater CPU utilization during timeshifting because you are simultaneously recording and playing recorded videos. At full DVD quality, timeshifting can require up to a 1.7 GHz CPU.

Timeshifting and Playback modes also differ in that Timeshifting lets you pause and replay live TV while Playback only allows you to replay a previously recorded program.

## **Still Image Capture**

Click on the capture icon on the control panel or



hit the "Space Bar" of the keyboard shortcut to capture an image of the display window. You can see the screen capture dialog as below.



Click on the **Shoot** to take another shot. Serial Shoot will shoot 6 straight shots at once. This is useful for action scenes.

There are BMP and JPEG format available for snapshot file type. Check "Save as JPG" box will save the shapshot as JPEG file type.

More settings are available on the User Interface tab in the Options of ComproPVR.

Make sure **Save** your shots before close this dialog or the files will not be saved.

The screen capture image size is fixed at 640 x 480.

#### Playback

ComproPVR can play recorded video files.

Press the **Play** button to open the **Play** dialog box. Highlight the file name in the program list, double-click or press **Play** to start playback.

During playback, the display area of the control panel provides information about currently playing program and provides playback control functions.

To delete a recorded program, open the Play dialog box, highlight the file name on the program list, and press the **Delete** button.

## **Closed Captioning (USA only)**

The closed captioning feature is used to display overlaid text captions. This feature is only available with programming that provides Closed Captioning.

Press the **Closed Caption** button to enable or disable closed captioning. If supported, the overlaid text captions will be displayed.

### **Teletext (PAL TV systems only)**

ComproPVR includes Teletext display capabilities. Press

the Subutton to activate Teletext functions. Availability of specific Teletext features depends on your local TV broadcasters.

# 5 Troubleshooting

#### **OS requirement**

ComproPVR 2 has to work on Windows XP / Windows 2000 or above OS. It's recommended to www.WindowsUpdate.com website for the Service Pack update of Microsoft.

#### **Driver Installation**

The most common cause of problems with ComproPVR is incorrect **installation** of TV Tuner product drivers. If you have problems watching, recording, or timeshifting live TV, please refer the product installation FAQ to check the status of TV Tuner product drivers with Device Manager.

#### Video OK / No Audio

If you can **view** the TV picture but get no audio, you should check the following:

Check the **Windows** Volume Control dialog for muted sound or volume levels that are too low. (Double-click on the speaker icon in the system tray to see the Volume Control dialog.)

If you are using an **external** audio patch cable, verify that it is connected between the Audio-Out of TV tuner card and Line-In of your sound card and that you selected the audio source to be "Line-In." If using the **internal** audio patch cable, check that it is connected between the internal Audio-Out of the TV tuner card and AUX-IN of your sound card and that you selected the audio source to "AUX." Please refer to your hardware installation guides for more information.

#### No audio on the recorded file

This may be a result of choosing the wrong record audio source in the System Device in ComproPVR Settings.

Check the **ComproPVR** in the Record tab of Settings dialog for recording volume levels that is not too low.

Please refer to your hardware installation guides for more information.

#### Recorded file cannot be played

The main reason for this problem usually is the result of installing other CODEC software like Nimo. This kind of software forces applications to use their CODEC for play back. Therefore, the recorded file cannot be played since a different CODEC is being used for playback. Please uninstall the CODEC software and reinstalling DirectX usually solves the problem. For more information, please check our FAQ on the www.comprousa.com

#### Recorded file lags while playing back

Video recording uses significant CPU resources. If CPU usage hits 100% while recording, the quality of your recordings may suffer. If this happens, close other applications while recording or use a lower recording resolution, such as VCD or SVCD formats.

#### Why can't I choose MPEG-4 format for recording?

If you would like to record video in MPEG-4 format, you must supply your own MPEG-4 CODEC. Furthermore, the CODEC must be installed before using ComproPVR.

In general, you can download MPEG-4 CODEC from the following web sites.

http://www.divx.com/

After you install the CODEC software, you will see the MPEG-4 format appear in the field of recording quality.

#### Why does the remote control fail?

Not all products support remote function. Please check the description on the product box.

The remote control sensor, which is plugged into the TV card, may be loose. Please unplug it and plug it again. You should also check the batteries of the remote control. Do not use rechargeable batteries.

Verify that the Milling IR icon (ComproRemote) is in the system tray on the lower-right corner of the screen. If you don't have ComproRemote on the system tray, start the following program:

#### C:\Program Files\Common Files\VideoMate\ComproRemote.exe

Then you should see the icon on the system tray. The IR icon should turn bright when you press buttons on the remote. If you see no response, your IR drivers may not be not properly installed. Please remove ComproPVR using "Add/Remove programs" in the Control Panel and reinstall it.

If you have switched the blue jumper to another pins set, you have to switch the red jumper to 2-3 (right) in order to use remote function.

#### Why does ComproPVR start by itself?

Some device emits the IR signal around. Please check if there is any microwave or light could do that. And make sure as few cable as possible crossing the IR receiver. Also do not use rechargeable batteries for remote keypad. And make sure there is no button getting stocked.

#### **Contacting Compro Technical Support**

Before you submit an email for support, please check support FAQs on our web site. http://www.comprousa.com

You can download the latest update from our website. Many issues should be solved on the newer version.

When contacting Compro for technical support, please use the Compro support request form and provide as much of the requested information as possible. Please write the details in order to determine the problem. And also provide the product serial number (19 digits numbers) on the PCI card. Please use the form from http://comprousa.com/support/form.htm

or directly email to support@comprousa.com.

#### Note

Make sure you include the information of hitting the button of "E-mail Info" in the System Device in Settings of ComproPVR in order to determine the problem.

In order to solve the problem quickly, it is very important to provide as much detail regarding the problem as possible.