

VIP 10

User Guide



Copyright

This user guide is the intellectual property of VCS and is protected by copyright. All rights reserved. No part of this document may be reproduced or transmitted for any purpose, by whatever means, electronic or mechanical, without the express written permission of VCS.

Release: February 2005 (Firmware Version 2.1)

© 2005, VCS Video Communication Systems AG

Note

This user guide has been compiled with great care and the information it contains has been thoroughly verified. The text was complete and correct at the time of printing. Due to further product development, the contents of the user guide may change without prior notice. VCS accepts no liability for damages resulting directly or indirectly from errors, omissions or discrepancies between the user guide and the product described.

Trademarks

All hardware and software product names used in this document are likely to be registered trade marks and must be treated accordingly.

Contents

Chapter 1 Preface	
About this user guide	7
Conventions	7
Intended use	8
EU guidelines	8
Rating plate	8
Chapter 2 Safety Information	
Electrical shock hazard	9
Installation and operation	10
Maintenance and repair	10
Chapter 3 Product Description	
Supplied components	11
System requirements for setup	11
Configuration requirements	11
Operational requirements	12
Overview of functions	13
VIP 10 connections	16
Chapter 4 Installation	
Installing the unit	17
Connections	18
Switching on/off	20
Setup using terminal software	21
Chapter 5 Configuration using a Web Browser	
Establishing the connection	25
Choosing the configuration mode	28
Configuration with the Wizard	29
Configuration in Expert Mode	32
Chapter 6 Configuring the Sender	
Basics	35
Unit identification	35
Password	36

- Language 37
- Date and time 37
- Time server 38
- Camera name 39
- Display stamping 39
- Picture settings 40
- MPEG-4 encoder 41
- Audio stream 44
- Video input 45
- JPEG posting 46
- Alarm sources 47
- Alarm connections 49
- Motion detector 50
- Relay 54
- COM1 56
- Network 57
- Multicasting 60
- Version information 62
- Livepage configuration 63
- Firmware and configuration upload 66
- Function test 68

Chapter 7 Configuring the Receiver

- Basics 69
- Unit identification 69
- Password 70
- Language 71
- Date and time 71
- Time server 72
- MPEG decoder 73
- Audio stream 74
- Alarm sources 75
- Alarm connections 76
- Relay 77
- COM1 79
- Network 80
- Version information 83
- Firmware and configuration upload 83
- Function test 86

Chapter 8	Sender Operation	
	Operation with Microsoft Internet Explorer	87
	The Livepage	88
	Saving snapshots	93
	Recording video sequences	94
Chapter 9	Receiver Operation	
	Operation with Microsoft Internet Explorer	95
	The Decoder connection page	96
	Connection between the receiver and sender	97
Chapter10	Hardware Connections	
	Hardware connections between VCS units	99
	Establishing the connection	99
	Closing the connection	101
Chapter11	Operation with Decoder Software	
	Operation with VIDOS	103
Chapter12	Maintenance and Upgrades	
	Testing the network connection	105
	Device reset	105
	Repairs	106
	Transfer and disposal	106
Chapter13	Appendix	
	Troubleshooting	107
	LEDs	109
	RS232/485 interface	110
	Connection jacks	111
	Glossary	112
	VIP 10 Specifications	114
Chapter14	Index	

Preface

About this user guide

This user guide is intended for persons responsible for the installation and operation of the VIP 10 network video server. International, national and any regional regulations regarding electrical systems must be adhered to at all times. Adequate knowledge of network technology is a precondition. The user manual describes the installation and operation of the unit.

Conventions

Symbols and notation

The following symbols and notation highlight important situations and information.



Warning!

This symbol indicates that failure to follow the safety instructions described may endanger persons and cause damage to the unit or other equipment. It is associated with immediate, direct hazards.



Note

This symbol indicates tips and information for easier, more convenient use of the unit.

Intended use

The VIP 10 network video server transmits video, audio and control signals over data networks (such as Ethernet LANs and the Internet). It is designed for use in CCTV systems. By incorporating external alarm devices, various functions can be triggered automatically. Other applications are not authorized.

For questions regarding the use of the unit that are not answered in this user guide, please contact your local dealer or:

VCS Video Communication Systems AG

Forchheimer Strasse 4
90425 Nuremberg, Germany
Phone: +49 (0)911 9 34 56-0
Fax: +49 (0)911 9 34 56-66

info@vcs.com

EU guidelines

The VIP 10 network video server complies with the specifications of EU Directives 89/336 (Electromagnetic Compatibility) and 73/23, amended by 93/68 (Low Voltage Directive).

Rating plate

For exact identification of the unit, the model and serial number are inscribed on the rating plate on the bottom of the housing. Please note this information before starting installation, so that you have it ready if you need to ask for assistance or order spare parts.

Safety Information

Electrical shock hazard

- Never attempt to connect the unit to any power network other than the type for which it was intended.
 - Use only the power supply provided.
 - Never open the casing!
 - If a fault occurs, disconnect the power supply unit from the mains supply and from all other devices.
 - Install the unit and power supply only in dry, weather-protected areas.
 - If safe operation of the unit cannot be guaranteed, remove it from service and secure it to prevent unauthorized start-up. Safe operation can no longer be guaranteed, for example,
 - if there is visible damage to the unit or power cables,
 - if the unit no longer works properly,
 - if the unit has been exposed to rain or moisture,
 - if foreign matter has infiltrated the unit,
 - after long storage under adverse conditions or
 - after exposure to higher than normal stress during transport.
- In such cases, have the unit checked by VCS.

Installation and operation

- Relevant electrical codes and guidelines must be complied with at all times during installation.
- Adequate knowledge of network technology is necessary for the installation.
- Before installing or operating the unit, make sure you have read and understood the documentation for the other equipment connected to the system, such as cameras. There you will find important safety instructions and information about authorised use.
- Perform only the installation tasks and operating steps described in this manual. Additional actions may lead to personal injuries, property damage or damage to the equipment.

Maintenance and repair

- Never open the casing of the VIP. The unit does not contain parts that you can repair or replace.
- Never open the housing of the power supply unit. The power supply unit does not contain parts that you can repair or replace.
- Ensure that all maintenance or repair work is performed exclusively by qualified personnel.

Product Description

Supplied components

- Network video server VIP 10 including plug-in mains adapter
- RS232 null modem cable
- The quick start guide “First Steps” in English and German
- VCS product CD with the following content:
 - The quick start guide “First Steps” in English and German
 - User guide in English and German
 - MPEG-ActiveX control from VCS
 - MPEG-Viewer
 - DirectX control
 - Microsoft Internet Explorer
 - Microsoft Virtual Machine
 - Adobe Acrobat Reader

System requirements for setup

- Computer with Microsoft Windows 98/2000/XP operating system and
 - network access and Microsoft Internet Explorer (version 5.5 or higher)or
 - a free serial port and terminal software

Configuration requirements

- Computer with Microsoft Windows 98/2000/XP operating system and network access and
 - Microsoft Internet Explorer (version 5.5 or later)or
 - decoder software, such as VIDOS from VCS

 **Note**

Make sure the graphic card is set to 16 or 32 bit color depth and Microsoft's Virtual Machine is installed and active on your computer.

Operational requirements

- Computer with Microsoft Windows 98/2000/XP operating system and network access and
 - Microsoft Internet Explorer (version 5.5 or later)
- or
- decoder software, such as VIDOS from VCS

or

- Hardware receiver from VCS (e.g. VIP 10 E) and video monitor

 **Note**

Make sure the graphic card for receiving on the computer monitor is set to 16 or 32 bit color depth and Microsoft's Virtual Machine is installed and active on the computer.

Overview of functions

Network video server

The VIP 10 is an ultra-compact network video server. Its primary function is to encode and decode video, audio and control data for transmission over an IP network. The VIP 10 is particularly well suited to adapting analog cameras for IP communication and for remote access to digital video recorders and multiplexers.

About the size and shape of a cigarette packet, it can be integrated into small enclosures without difficulty. The use of existing networks means that integration with CCTV systems or local networks is quick and easy.

Two units, a VIP as the sender and another VIP as the receiver, can form a stand-alone system for data transfer without a PC. Video images from one sender can be received simultaneously on a number of receivers.

Receiver

VIP or VideoJet units from VCS can be used as receivers. Computers with decoding software such as VIDOS from VCS or Microsoft Internet Explorer can also be used as receivers.

Video encoding

The VIP 10 works with the MPEG-4 video compression standard. MPEG-4 enables data transfer at narrow bandwidth – via Internet for example.

Dual streaming

Dual streaming allows the incoming data stream to be encoded simultaneously according to two different, individually customizable profiles. This creates two data streams that can serve different purposes, for example one for local recording and one optimized for transmission via the LAN.

Multicast

In suitably configured networks, the multicast function enables simultaneous, real time video transmission to multiple receivers. The prerequisite for this is that the UDP and IGMP protocols be implemented on the network.

Remote control

The VIP can remotely control external devices, such as pan and tilt heads or motorized zoom lenses, by transmitting control data via its bidirectional serial interface. This interface can also be used to transmit transparent data.

Configuration

The VIP can be configured using a browser on the local network (Intranet) or via Internet.

Firmware updates and fast loading of device configurations are possible in the same way.

Recording and playback

You can save the video images provided by the unit as a file on the hard drive of your computer. The video sequences are stored in MPEG format and can be replayed with the VCS MPEG-Viewer included with the package.

Snapshots

Individual video frames (snapshots) can be called up as JPEG images by the VIP, stored on the hard drive or displayed in a separate browser window.

Backup


Backups of video sequences can be made to the hard drive with a simple mouse click on an icon on the Livepage .

Summary

The main functions of the VIP 10 are:

- Video, audio and data transmission over IP data networks
- Simultaneous dual streaming with two independently defined profiles
- Multicast function for simultaneous picture transmission to multiple receivers
- Analog BNC composite video input FBAS (PAL/NTSC) (sender)
- Analog BNC composite video output FBAS (PAL/NTSC) (receiver)
- A bidirectional audio input/output (mono)
- Video and audio encoding using the MPEG-4/G.711 international standards
- Integrated Ethernet interface (10/100 Base-T)
- A transparent bidirectional data channel using a serial interface, type RS232/485
- Remote control of all built-in functions via TCP/IP
- Password protection to prevent unauthorized connection or configuration changes
- Alarm inputs for external sensors (such as a door contact)
- Relay output for switching external devices (such as lights or audible alarms)
- Event-driven, automatic connection (for example when switching on and when alarms are activated)
- Fast, convenient configuration using a Web browser
- Firmware update using flash memory
- Convenient upload of configuration data

VIP 10 connections



- 1 BNC jack: **Video In** (transmitter) or **Video Out** (receiver), for connecting a video source or an analog video monitor
- 2 RJ45 jack for **RS232/485** for transmitting control data and configuration with terminal software
- 3 **USB** interface for future expansion of the recording function
- 4 Reset button for restoring the default settings
- 5 Terminal block (audio, alarms, relay and power supply)
- 6 Operating status LED
yellow, lights up when the device is ready for operation
- 7 Network connection LED
green, lights up when the device is connected to the network
- 8 Data transfer LED
blinks orange when data is transmitted over the network
- 9 RJ45 jack for **Ethernet** for connecting to the network

Installation

Installing the unit

With its ultra-compact dimensions, the VIP is particularly well suited for installation in cabinets.



Warning!

The unit is intended for use indoors or in a protective enclosure. Select a suitable location for installation where the equipment is not subject to extreme temperatures or humidity. The ambient temperature must lie between 0 and +50 °C. The relative humidity should not exceed 80%.

The unit generates heat during operation. Ensure that there is adequate ventilation and also that there is enough clearance between the unit and heat-sensitive objects or equipment.

Make sure the following conditions for installation are complied with:

- Do not mount the unit close to heaters or other heat sources. Avoid locations subject to direct sunlight.
- Allow sufficient space for running cables.
- Ensure that the unit has adequate ventilation.
- Use only the cables supplied for connections or appropriate cables, which are also shielded against electromagnetic interference.
- Position and run all cables so that they are protected from damage, and provide strain relief where needed.

Connections

Camera/monitor

Depending on the device used, you can connect a video source (sender) or a monitor (receiver). All cameras and video sources that generate a standard PAL or NTSC signal and all monitors compatible with PAL or NTSC standards can be used for this purpose.

- Connect the camera or another video source using a video cable (75 Ohms, BNC plug) to the **Video In** BNC jack of the sender.

or

- Connect the video monitor using a video cable (75 Ohms, BNC plug) to the **Video Out** BNC jack of the receiver.

Data interface

The bidirectional data interface is used to control equipment connected to the VIP unit, such as a dome camera with a motorized lens.

The **RS232/485** connection supports RS232, RS422 and RS485 communication standards.

The serial interface is a Sub-D socket. For information on the pin assignment see page 110.

The selection of controllable devices is growing constantly. The manufacturers of this equipment can provide specific information on installation and control.



Warning!

Make use of the device documentation when installing and operating a device that you want to control using the system. It contains important safety instructions and information about authorized use.



Note

A video connection is necessary to transmit transparent data.

Network

You can connect the VIP to a 10/100 Base-T network. Use a standard UTP Category 5 cable with RJ45 connectors for this.

- Connect the unit to the network using the **Ethernet** jack.

Alarm inputs

The VIP has two alarm inputs on the orange terminal block. The alarm inputs are used to transfer signals from external alarm devices, such as door contacts or sensors. Given the appropriate configuration, an alarm device can, for example, trigger automatic connection between the VIP and a remote location. A voltage free normally open contact or switch can be used as an actuator.

Note

It is preferable to use an actuator with a bounce-free contact system.

- Connect the leads to the appropriate terminals on the orange terminal block and check that the connection is secure (for pin assignment see page 111).

Relay output

The VIP has a relay output for switching external devices, such as lights or audible alarms. This relay output can be activated manually if there is an active connection with the VIP. Moreover, the output can be configured to activate audible alarms or other devices as a response to an alarm signal. The relay output is also located on the orange terminal block.



Warning!

The maximum rating of the relay contact is 30 V and 1 A.

- Connect the leads to the appropriate terminals on the orange terminal block and check that the connection is secure (for pin assignment see page 111).

Microphone/loudspeaker

The connection for the microphone/loudspeaker is also on the orange terminal block.

The bidirectional audio signals are transmitted simultaneously with the video signals. This can be used for example to operate a loudspeaker or door intercom at the target location.

- Connect a line level audio source to the appropriate terminals on the orange terminal block of the sender and check that the connection is secure.
- Connect a loudspeaker to the appropriate terminals on the orange terminal block of the receiver and check that the connection is secure (for pin assignment see page 111).

Switching on/off

Power connection

A plug-in mains adapter is included with the VIP package. The VIP does not have a mains switch. The unit is ready for operation as soon as it is connected to the mains supply.



Warning!

Use only the plug-in mains adapter provided for operation of the VIP. Where necessary, take appropriate measures to ensure that the mains supply is protected against voltage surges, spikes or brownouts.



Warning!

Do not connect the VIP to the power source until all the other connections have been made.

- Connect the cable of the mains adapter to the orange terminal block of the VIP.
- Plug the mains adapter into a fused power socket. The unit is ready for operation as soon as the "operating status" LED stops blinking red during start-up and becomes yellow.

If the network connection is in order, the green "network connection" LED is also lit. The blinking orange "data transmission" LED indicates data traffic on the network.

Setup using terminal software

Data terminal

You can connect a data terminal to the VIP for setup and local control. The data terminal consists of a computer with terminal software. Use the serial null-modem cable included in the package supplied to make the connection.

For example, HyperTerminal, a communications utility included with Microsoft Windows, can be used as the terminal program.

Note

Information on installing and using HyperTerminal can be found in the user guides or online help for Microsoft Windows.

- Before working with the terminal program, disconnect the VIP from the data network.
- Connect the **RS232/485** Sub-D connector of the VIP to an available serial port on the computer.

Configuring the terminal

To establish communication between the terminal program and the VIP, the transmission parameters must be correctly defined. Set the following values in the terminal program:

- 19,200 Bit/s
- 8 data bits
- No parity check
- 1 stop bit
- No protocol

Command entry

After the connection has been established, you must log on to the VIP. You can then access the main menu. You can call up additional submenus and functions using the on-screen commands.

- If necessary, turn off the local echo so that entered values are not repeated on the screen display.

- Enter only one command at a time.
- After entering a value (such as an IP address), re-check the entry before pressing the Enter key to send the data to the VIP.

Assigning an IP address

To operate the VIP on your network, you must assign it an IP address that is recognized by the network.

The following default address has been pre-set at the factory:

Sender: 192.168.0.1

Receiver: 192.168.0.2

- Start up a terminal program such as HyperTerminal.
- Enter `service` as user name and password. The main menu will be displayed.
- Enter `i` to open the **IP** menu.

```

VIP 10 - HyperTerminal
Datei Bearbeiten Ansicht Anrufen Übertragung ?
***** IP *****
(*) Device needs to be reset to change setting
-----
i (*)local IP          192.168.0.1
s (*)local subnet mask 255.255.255.0
g (*)local gateway    0.0.0.0
r remote IP           0.0.0.0
  Mac Address         00-07-5f-50-1a-8e
a Auto Connect        Off
m Set HD/FD 10/100 auto mode
p Ping remote IP      0.0.0.0
l RIP Packet Loss Stats
x Leave this Menu
? This Menu
*****

```

- Enter `i` once more. The current IP address will be displayed, and you will be requested to enter a new IP address.
- Enter the desired IP address and press [ENTER]. The new IP address will be displayed.
- If necessary, enter `s` and a new subnet mask.

 Note

The new IP address, subnet mask and gateway address become effective only following a restart.

Restart

- Enter `#reset` and press [ENTER]
- or
- Interrupt the power supply of the VIP for a moment.

Additional parameters

Using the terminal program, you can check other basic parameters and modify them where necessary. Use the on-screen commands displayed in the various submenus for this purpose.

Configuration using a Web Browser

Establishing the connection

The integrated HTTP server allows the unit to be configured over the network using a Web browser. This option offers considerably more possibilities and is more convenient than configuration using terminal software. It also allows live video images to be displayed.

Note

Make sure the graphic card is set to 16 or 32 bit color depth and the Microsoft Virtual Machine is installed and active on your computer. If necessary, the required software and controls can be installed from the CD provided (see page 11).

Instructions for using the Web browser can be found in its online help.

System requirements

- Microsoft Internet Explorer (version 5.5 or higher)
- Monitor resolution 1024 × 768 pixels
- Network access (intranet or Internet)

MPEG-ActiveX installation

In order to display live video images, an appropriate MPEG-ActiveX must be installed on the computer, such as that used for playing DVD movies. If necessary, the required software and controls can be installed from the CD provided (see page 11).

- Insert the CD into the CD-ROM drive of the computer. The CD should start automatically. If the CD does not start automatically, open the root directory of the CD in Windows Explorer and double click **MPEGAx.exe**.
- Follow the instructions on the screen.

Establishing the connection

The VIP must be assigned a valid IP address for your network, before it can be operated in your network environment.


The following default address has been pre-set at the factory:

Sender: 192.168.0.1

Receiver: 192.168.0.2

- Start the Web browser.
- Enter the IP address of the VIP as the URL. The VIP home page will be shown in the browser.

If the unit is a sender, the home page will be the Livepage (which shows the live video image).



The **Decoder connection** page will be displayed as the home page for a receiver. It shows a snapshot from the video source for the sender currently connected, and the unit searches the network automatically for available senders.



Note

If the connection cannot be established, the unit selected may already be in communication with another remote station. Depending upon the network configuration and the individual units, a sender can serve up to five receivers simultaneously.

VIP password protection

If the VIP is password-protected against unauthorized access, a dialog box requesting the password will appear first.

Note

Configuration work can only be performed on a password-protected VIP unit if the user logs on under the **service** user name.

- Enter the user name and password in the appropriate fields.
- Click **OK**. If the password is correct, the VIP home page will open.

Choosing the configuration mode

There are two options to configure the VIP or to check the current setup:

- the Wizard and
- Expert Mode.

All settings are stored in the VIP memory, and they are preserved even if the power is interrupted.

Use of the Wizard is recommended for initial setup. It takes you step by step through the necessary settings. It prevents critical settings for correct operation being overlooked. Moreover, each step offers brief instructions that help with installation.

Expert Mode is recommended only for experienced users or system administrators. All unit parameters can be accessed in this mode. Operations that affect the basic functionality of the unit (such as firmware updates) can only be performed in Expert Mode.

Note

Depending on whether the unit is a sender or a receiver, different home pages will be displayed. (For the sender, see page 26. For the receiver, see page 27).

- Click the **Settings** link in the top part of the VIP sender Livepage. A new page will open, and the desired configuration mode can be selected using the links at the top of the window.

Configuration with the Wizard

The Wizard is used for step-by-step configuration of the VIP. It will lead you through a series of screens where you can input the necessary settings. The settings only become effective after the last screen of the Wizard has been completed. When working with the Wizard, you can switch to another window at any time.

The last screen of the Installation Wizard offers the option of launching the Application Wizard. The Application Wizard helps you to configure the Livepage. It is used in a manner similar to the Installation Wizard.


Starting the Wizard

The Wizard can be launched from the configuration pages.

- Just click the link **Wizard** in the top part of the window. A new page will appear.
- Click the button with the wizard icon in the Installation wizard field. The first screen for the Installation Wizard will appear.
- Click **Start** to launch the Wizard. The next screen for the Wizard will appear.

General procedure

The screens for the Installation Wizard will be shown in sequence, allowing you to work quickly and easily. The upper part of the window always contains information about the settings options. The current settings are shown in the lower part of the window. You can change settings by entering the desired value in a text field or choosing it from a list. The navigation buttons for the Installation Wizard are at the bottom of the window. You can switch between pages of the Wizard at any time.



Note

Your screen display may differ slightly from the illustration, depending on whether you are working with a sender or a receiver. However, the configuration procedure with the Installation Wizard is the same for all units.

- Always read the information in the upper part of the window first.
- Click in the text fields to enter values or use the other controls available, such as buttons, check boxes or list fields.
- Click **Next >>** to go to the next step.
- Click **<< Back** to look at the previous step again.
- Click **Cancel** to interrupt the process and close the Installation Wizard.

Finishing the configuration

After you have specified all the settings you want, they must be transmitted to the VIP unit and saved. Click **Finish** in the last screen of the Installation Wizard to complete this process.



Warning!

All settings changes will become effective only after you have ended the configuration by clicking **Finish** in the last screen.

- Go to the last screen of the Installation Wizard if necessary.
- Click **Finish** to finalize the configuration. All settings will be transmitted to the VIP and become effective forthwith.

Configuration in Expert Mode


Expert Mode allows all parameters of the VIP to be configured. You can view the current settings by opening one of the configuration pages. The settings can be changed by entering new values or by selecting a predefined value in a list field.

The basic use of the configuration pages is described below. Separate descriptions of the individual configuration pages and customizable parameters for senders and receivers can be found in Chapter 6 and Chapter 7 of this user guide.

Navigation

You can switch to Expert Mode from the configuration pages.

- Click the **Expert Mode** link. The initial page will be opened.
- Click one of the links on the left edge of the window. The corresponding page will be opened.



Note

Your screen display may differ from the illustration, depending on whether you are working with a sender or a receiver. However, navigation on the configuration pages is the same for all units.

Making changes

Each configuration page shows the current settings. You can change the settings by entering new values or by selecting from predefined lists.

- Click **Set** after each change to save it.



Warning!

Save each change with the associated **Set** button. When **Set** is clicked, only the changes in the relevant field are saved. Changes in any other fields are ignored.

Configuring the Sender

Basics

The VIP offers various configuration options. Configuration in Expert Mode with a Web browser is described below. Basic information about configuration with a Web browser and other configuration options are described in Chapter 5 of this user guide.

Unit identification

The screenshot shows a web interface with a blue header bar containing the text 'page', 'Wizard', and 'Expert Mode'. Below the header, the title 'Unit identification' is displayed. The main content area is enclosed in a blue border and contains two text input fields: 'Unit name:' and 'Unit ID:'. To the right of the 'Unit ID:' field is a grey button labeled 'Set'. Below the form area, there is a blue link that reads 'Help on this page?'.

The unit can be assigned a name and an ID to facilitate identification. Both make the task of managing video surveillance systems with VIDOS from VCS or other tools much simpler.

Unit name:

Enter a name for the unit here.

Unit ID:

Each VIP should be assigned a unique identifier that can be entered here as an additional means of identification.

Password

page Wizard Expert mode

Password

User name:

Password: No 'user'-password set!

Confirm password:

[Help on this page?](#)

A VIP unit is generally protected by password to prevent unauthorized access. You can limit the scale of access by choosing between different authorization levels.

Note

Correct password protection is only granted when all higher levels of authorization are also protected by password. If a **live** password is assigned, for example, also a **service** and a **user** password must be assigned. Therefore assign passwords always beginning with the highest authorization level.

User name:

The sender operates with three user names: **service**, **user** and **live** which refer to different authorization levels.

The user name **service** refers to the highest authorization level. Logged in under **service**, you can use all the functions offered by the VIP and change all settings.

The user name **user** refers to the medium authorization level. Logged in under **user**, you can operate the device and other devices, such as a camera, but no changes can be made to the configuration.

The user name **live** refers to the lowest authorization level. Logged in under **live**, you can only view the live video image and switch between the various live image feeds.

Password:

You can define and change a unique password for each user name if you are logged on under **service** or if the unit is not protected by a password.

Enter a password for the chosen user name here.

Confirm password:

Re-enter the new password to prevent typing mistakes.

Note

The new password becomes effective only after you have clicked **Set**. Therefore click **Set** immediately after having entered and confirmed the password even if you want to assign a password to another user name, too.

Language



Website language:


[Help on this page?](#)

If more convenient, a different operating interface language can be chosen.

Website language:

Select the language from the dropdown field.

Date and time



Date format:

Unit date: , . .

Unit time: : :

[Help on this page?](#)

If a number of VIP units are part of a system, it is important that the internal clocks of these separate units be synchronized. Only if all units operate with the same time it is possible, for example, to correctly identify and evaluate recordings that have been made simultaneously.

Date format:


Choose the desired date format here
(Europe: DD.MM.YYYY; USA: MM.DD.YYYY; Japan: YYYY/MM/DD).

Unit date:

Enter the current date here. Since the system time is controlled by the internal clock, it is not necessary to enter the day of week. This is added automatically.

Unit time:

Enter the current time here or click the **Synchr. PC** button to copy the system time of your computer to the VIP.

Time server

The screenshot shows a configuration window titled "Time server" within a wizard interface. The window has a blue header bar with "page", "Wizard", and "Expert Mode" tabs. The main content area is white and contains three fields: "Time zone:" with a dropdown menu showing "(UTC +1:00) Western & Central Europe", "Time settings:" with a checkbox labeled "Use daylight saving time" which is currently unchecked, and "Time server IP address:" with a text input field containing "0.0.0.0". A "Set" button is located to the right of the IP address field. Below the form, there is a blue link that says "Help on this page?".

Using the Time Server Protocol the VIP can receive a time signal from a time server and use it to set its internal clock. The device calls up the time signal automatically every two hours.

Time zone:

Select the time zone that applies to your system.

Time settings:

Select this during daylight savings time if the time change is to be taken into account. Deselect it when standard time has resumed.

Time server IP address:

Enter the IP address of the chosen time server here.

Camera name

page Wizard Expert Mode

Camera name

Camera:

[Help on this page?](#)

The camera name simplifies identification of the remote camera location, for example in the event of an alarm call. It will be shown in the video image if this facility has been configured (see page 39). Moreover, the camera name is used by VIDOS, VCS software for managing video surveillance systems, and makes it easier to identify the camera.

Camera:

Enter a unique, unambiguous name for the camera in this field.

Display stamping

page Wizard Expert Mode

Display stamping

Camera name stamping:

Time stamping:

Alarm mode stamping:

Displayed alarm message: (max. 31 characters)

Video watermarking:

[Help on this page?](#)

Various overlays or stamps in the video image provide important supplemental information. These overlays can be enabled individually and arranged on the image in a clear manner.

Camera name stamping:

This field sets the position of the camera name overlay. It can be shown at the **Top** or the **Bottom** or you can define a position yourself via the Hyperterminal and activate it choosing the option **Custom**. Or it can be set to **Off** if no overlay for this information is to be shown.

Time stamping:

This field sets the position of the time and date overlay. It can be shown at the **Top** or the **Bottom** or you can define a position yourself via the Hyperterminal and activate it choosing the option **Custom**. Or it can be set to **Off** if no overlay for this information is to be shown.

Alarm mode stamping:

Choose **On** if a text message should be overlaid in the event of an alarm.

Displayed alarm message:

Enter the message to be displayed for an alarm. The field can contain up to 31 characters.

Video watermarking:

Choose **On** if the video images transmitted are to be "watermarked". After activation, all images will be marked with a green **W**. A red **W** indicates that the sequence (live or saved) has been manipulated.

Picture settings

Livepage
Wizard
Expert mode

Picture settings

Contrast (0...255): Low High


Saturation (0...255): Low High

Brightness (0...255): Low High

128

128

128



[Help on this page?](#)

You can set up the video picture to meet your own particular requirements. To enable you to control the current video picture it is shown in a small window beside the sliders. The changes are effective immediately.

- If necessary click the **Default** button to return the configuration back to the standard settings.

Contrast (0...255):

You can adjust the contrast of the video picture to suit the working environment.

Saturation (0...255):

You can use this function to set the color saturation and achieve the most realistic color reproduction on the monitor.

Brightness (0...255):

You can use this function to adjust the brightness of the video picture to suit the working environment.

MPEG-4 encoder

The screenshot displays the configuration interface for the MPEG-4 encoder. At the top, there are navigation tabs for 'Livepage', 'Wizard', and 'Expert Mode'. The main content area is titled 'MPEG-4 encoder' and contains two primary sections:

- MPEG-4 encoder:** This section includes a dropdown menu for 'Active profile:' currently set to 'High quality (CIF)', a 'Set' button, and a selection between 'MPEG-4 Stream 1' and 'MPEG-4 Stream 2'.
- Profile configuration:** This section allows for detailed settings for 'Profile 1'. It includes:
 - Profile name: High quality (CIF)
 - Data rate: 3000 kBit/s
 - Video quality: Auto (with a slider ranging from High to Low)
 - I-frame distance: 0
 - Encoding interval: 1
 - Video resolution: CIF
 - Field mode: Progressive
 - Reset of profile: Default (with a 'Set' button)

To the right of the configuration panels is a photograph showing a woman in a pink shirt and a hat using an ATM labeled 'Geldautomat'.

The VIP sender has two MPEG-4 encoders that can be configured separately. The benefit of this so-called "dual streaming" is that you can transmit and record simultaneously with different compression settings. The parameters for each can

be configured to suit the environment used (network architecture, bandwidth, data structures, etc.).

There are several pre-programmed profiles available for both MPEG-4 streams. These are optimized for different application scenarios. Individual settings in a profile and its name can be changed.



Warning!

The profiles are rather complex. They include a number of parameters that interact with one another. Therefore it is generally best to use the profiles as provided. The profiles should only be changed after you have familiarized yourself with all the configuration options.

MPEG-4 encoder

You can switch between the profiles of the two MPEG-4 streams by clicking the associated tabs. The choice of the MPEG-4 Livepage stream is set on the **Livepage configuration** page (see page 63).

Active profile:

Profiles can be selected here for each of the two streams.

Eight pre-programmed profiles are available optimized for different transmission modes:

■ **Low bandwidth (CIF)**

for connections with low bandwidth, resolution 352 × 288 pixels

■ **Low delay (1/2 D1)**

for connections with low delay, resolution 352 × 576/480 pixels (parameter displayed for **Video resolution**: Custom)

■ **High resolution (D1/4CIF)**

for connections with high resolution, resolution 704 × 576/480 pixels

■ **DSL**

for DSL connections with 500 kBit/s

■ **ISDN (2B)**

for ISDN connections via two B channels

■ **ISDN (1B)**

for ISDN connections via one B channel

Modem

for analog modem connections at 20 kBit/s

GSM

for 9600 baud GSM connections

**Warning!**

When assigning the profiles take into account that in case of alarm connections and auto-connect always Stream 1 is transmitted.

Profile configuration

You can switch between the profiles by clicking the associated tabs.

**Note**

The parameters as a group constitute a profile and are dependent on one another. If you enter a setting outside the allowed range for the parameter, the nearest valid value will be substituted when the settings are saved.

Profile name:

Enter a name for the current profile. The name will be displayed automatically in the dropdown list of the field **Active profile**.

Data rate:

The data rate for the speed of transmission over the network is shown for each profile. You can change the data rate.

Video quality:

Here you can adjust video quality as a function of the level of movement within the frame. The **Auto** option automatically adjusts to the optimum relationship between movement and image definition (focus). **Manual** allows you to set a value between 1 and 31 on a slide bar. The value **1** gives the highest quality with the lowest frame refresh rate. The value **31** results in a high refresh rate and low image quality.

I-frame distance:

This parameter determines the number of frames between two I-frames

Encoding interval:

This setting determines the frame encoding interval. The value **1** means each image is encoded. The value **2** means that only every other image is encoded, etc. The lower the available transmission bandwidth, the higher this value should be set in order to maintain high-quality images despite the bandwidth.

Video resolution:

Select the desired resolution for the MPEG-4 video image. The following options are available:

- **QCIF** 176 × 144 pixels
- **CIF** 352 × 288 pixels
- **2CIF** 704 × 288 pixels
- **D1/4CIF** 704 × 576/480 pixels
- **Custom** 352 × 576/480 pixels, adjustable (default setting is 1/2 D1)

Field mode:

This parameter determines the video signals being **Interlaced** or **Progressive**.

Reset of profile:

Click the **Default** button to reset the profile to its factory presets.

Audio stream



The screenshot shows a configuration page for 'Audio stream'. At the top, there are three tabs: 'page', 'Wizard', and 'Expert Mode'. The 'Expert Mode' tab is selected. Below the tabs, the title 'Audio stream' is displayed. The main content area contains a label 'Enable audio:' followed by a dropdown menu currently set to 'Off'. To the right of the dropdown is a 'Set' button.

[Help on this page?](#)

In addition to video data, the unit can also send and receive audio signals. The transmission of audio takes place at the same time as that of the video data in a separate data stream. Thus it increases the data traffic. The audio data is coded according to G.711 compression standard and requires an additional bandwidth of about 80 kBit/s per direction.

**Warning!**

G.711 audio data is only saved with central recording, using VIDOS-NVR for example.

Enable audio:

To transmit a separate G.711 audio stream choose **On**.

Video input

The screenshot shows a configuration wizard with three tabs: "page", "Wizard", and "Expert Mode". The "Wizard" tab is active. Below the tabs, the title "Video input" is displayed. A form field contains the text "75 Ohm termination:" followed by a dropdown menu currently set to "On" and a "Set" button. Below the form, there is a blue link that says "Help on this page?"

The 75 Ohm termination of the VIP can be set here. If the video signal is to be looped through, the termination must be set off. The default setting for the video input termination is **On**.

75 Ohm termination:

To loop the video signal through choose **Off**.

JPEG posting

The screenshot shows a configuration window titled "JPEG posting" with three tabs: "page", "Wizard", and "Expert Mode". The "Wizard" tab is active. The window contains several configuration fields:

- JPEG format:** A dropdown menu with "M (352x288)" selected.
- File name:** A dropdown menu with "Overwrite" selected.
- JPEG posting interval:** A text box containing "0" followed by "sec (0 = Off)".
- FTP server IP address:** A text box containing "0.0.0.0".
- FTP login name:** An empty text box.
- FTP password:** An empty text box.
- Path on FTP server:** An empty text box.

A "Set" button is located at the bottom right of the configuration area. Below the form, there is a link that says "Help on this page?".

[Help on this page?](#)

You can store video images in JPEG format at certain intervals on an FTP server. These images can be called up again later, thus enabling for example alarm events to be reconstructed.

JPEG format:

Here you can choose the format of the JPEG pictures:

- **S** 176 × 144 pixel (QCIF)
- **M** 352 × 288 pixel (CIF)
- **XL** 704 × 576 pixel (4CIF)

File name:

You can set what file names are to be generated for the transmitted snapshots.

- **Overwrite:** The same file name is always used. The existing file is continuously over-written with current data.
- **Increment:** A number from 000 to 255 is attached to the filename. This automatically increases by 1 every time a new file is created. When 255 is reached the numbers begin again at 000.
- **Date/time suffix:** A date and time code are automatically incorporated into the file name. When choosing this setting take care that the device's date and time are set correctly. Example: the file snap011204_114530.jpg was saved on December 1st, 2004, at 11.45 and 30 seconds.

JPEG posting interval:

Enter the time interval here at which the single images are to be sent to an FTP server. Enter zero, if no single images are to be sent.

FTP server IP address:

Enter here the IP address of the FTP server on which the JPEG-images are to be stored.

FTP login name:

Enter your login name for the FTP server here.

FTP password:

Enter the password for the access to the FTP server here.

Path on FTP server:

Enter the exact path here under which the images are to be stored on the FTP server.

Alarm sources

page Wizard Expert Mode

Alarm sources

Video loss alarm:	<input type="text" value="Off"/>
Contrast alarm:	<input type="text" value="Off"/>
Motion alarm:	<input type="text" value="Off"/>
Alarm input 1:	<input type="text" value="Off"/> <input type="text" value="Active high"/> Name: <input type="text" value="Input 1"/>
Alarm input 2:	<input type="text" value="Off"/> <input type="text" value="Active high"/> Name: <input type="text" value="Input 2"/>
1. SNMP host address:	<input type="text" value="0.0.0.0"/>
2. SNMP host address:	<input type="text" value="0.0.0.0"/>

[Help on this page?](#)

You can configure the possible alarm triggers for the VIP (e.g. the alarm inputs).

Video loss alarm:

Select **On** if the unit is to activate an alarm whenever the video signal is interrupted.

Contrast alarm:

The VIP can trigger an alarm if the camera image shows too little contrast, possibly indicating that the lens has been sprayed with paint or covered in some way. Select **On** to enable this function.

Motion alarm:

Select **On** if the unit is to respond to a motion alarm.

Motion detection is configured on a separate page (see page 50).

Alarm input 1 ... Alarm input 2:

Select the option **On** in order to activate the alarm via the corresponding external alarm sensor. Otherwise, select **Off**.

You can choose whether the alarm is triggered by an **Active high** (contact open) or **Active low** (contact closed) input state.

Name:

You can enter a name for each alarm input, which is then displayed next to the icon for the alarm input on the video live page during the respective configuration (see page 63).

1./2. SNMP host address:

Enter the IP addresses of up to two chosen receivers here if the alarm message is to be sent via SNMP-traps.

Alarm connections

page Wizard Expert Mode

Alarm connections

Connect on alarm: Off

Number of destination IP address: 1

Destination IP address: 0.0.0.0

Destination password:

Auto-connect: Off

Set

[Help on this page?](#)

You can select a number of options for the response of the VIP to an alarm. In case of an alarm, the VIP can establish a connection to a predefined IP address (VCS hardware receiver or PC with receiver software) automatically. You can enter up to 10 IP addresses which will be selected in sequence by the unit until a connection is established.

Note

Sender and receiver must share the same subnet for connection set-up (see page 58).

When assigning the profiles take into account that in case of alarm connections and auto-connect always Stream 1 is transmitted (see page 42).

Connect on alarm:

Select **On**, to establish a connection automatically to a specified IP address in the event of an alarm.

With the setting **Follows input 1**, the VIP holds the automatically set up connection to a remote location as long as an alarm signal is present at the alarm input 1.

Number of destination address:

Here you assign the numbering for the IP addresses to be contacted in the event of an alarm. The unit contacts the remote locations one after the other in the numbered sequence until a connection has been established.

Destination IP address:

For each number, enter the corresponding IP address of the desired remote unit.


Destination password:

Enter the password, if the remote unit is protected by a password.

Auto-connect:

Select **On** if an active connection should be reestablished automatically to one of the previously specified IP addresses after each restart, e.g. after a connection breakdown or network dropout.

Motion detector



[Help on this page?](#)

The VIP has an integrated video sensor which can detect changes in the signal. Such changes are due primarily to movements in the camera's field of view.

The sensitivity of the video sensor can be adjusted, so an alarm is generated only if specified values are exceeded.

 **Note**

The video sensor monitors Stream 1. For exact motion detection it is recommended to choose CIF as video resolution for Stream 1 (see page 41).

In order for the sensor to function, the following conditions must be met:

- The motion detector must be enabled.
- At least one sensor field must be activated.
- The individual parameters must be set for the operating environment and the desired responses configured accordingly.
- The sensitivity must be set to a value greater than zero.

**Warning!**

Reflections of light (off glass surfaces, etc.), switching lights on or off or changes in the light level caused by cloud movement on a sunny day can trigger unintended responses from the video sensor and generate false alarms. Run a series of tests under day and night conditions to ensure that the sensor works as intended.

For indoor surveillance, ensure constant lighting of the areas during the day and at night.

Uniform surfaces without contrast can trigger false alarms even with constant lighting.

 **Note**

Clicking the **Defaults** button will reset the video sensor to its factory configuration.

Motion detector

Select **On** to activate the video sensor.

Select sensor fields

The areas of the image to be monitored by the video sensor can be selected. The video image is subdivided into 396 square sensor fields. Each of these fields can be activated or deactivated individually. If it is necessary to exclude particular regions of the camera's field of view from monitoring due to continuous movement (by a tree in the wind, etc.), the relevant fields can be deactivated.

- Click **Select area** to configure the sensor fields. A new window will open.
- If necessary, click **Clear all** first to clear the current selection (fields marked red).
- Left-click the fields to be activated. Activated fields are marked red.
- Click **Select all** to select the entire video frame for monitoring.
- Right-click any fields you wish to deactivate. "Inactive" fields are marked white.
- Click **Set** to save the configuration.
- Click the close button (**X**) in the window title bar to close the window without saving the changes.

Local sensitivity

The basic sensitivity of the video sensor can be adjusted for the environmental conditions to which the camera is subject.

The sensor reacts to variations in the brightness of the video image. The darker the observation area, the higher the value that must be selected.

- Adjust the sensitivity by dragging the scroll thumb to the desired setting.

Average (n frames)

You can define the number of frames for which a movement is monitored before generating an alarm. This helps prevent false alarms from events such as a bird flying across the surveillance area.

- Select the value by dragging the scroll thumb to the desired position.

Object min size (n*n blocks)

You can specify the number of sensor fields that a moving object must cover to generate an alarm. This is to prevent objects that are too small from triggering an alarm.

A minimum value of 2 (2 × 2 sensor fields) is recommended.

- Select the value by dragging the scroll thumb to the desired position.

Motion indicator

To prevent false alarms, a threshold can be applied to the motion signal. This allows effects such as the background noise from the camera itself to be filtered out.

The blue line in the illustration represents the alarm threshold. Any value above this level will trigger an alarm. The parts of the motion signal line which will cause an alarm are shown in red. The alarm threshold can be set higher or lower to suit your needs.

- Observe the amplitude of the displayed movement signal over a longer period of time under all the lighting conditions that may be encountered.
- Move the pointer over the blue line.
- Press the left mouse button in and drag the line to the desired level.

Motion tracking

In some situations you may want an alarm triggered only if movement takes place in a particular direction. In such cases, enable motion detection and select the direction of movement required to trigger an alarm.

- Select **On** to enable the motion tracking feature of the video sensor.

Tracker

The **Tracker** field shows an arrow indicating the current motion vector in the video image. The checkboxes at the corners of the field are used to select the directions to monitor. For example, if all movements toward the left and up are to trigger an alarm, mark the top left corner. If all movement to the left is to trigger an alarm, mark the upper left and the lower left checkboxes.

- Observe the movement in the video image indicated by the arrow over a longer period of time at all the relevant light levels.
- Mark the checkboxes to activate the corresponding directional components for monitoring.

Relay

page Wizard Expert Mode

Relay

Idle state:

Operating mode:

Relay follows:

Relay name:

Relay operation

Trigger relay:

[Help on this page?](#)

You can configure the switching behavior of the relay output. Relay action can be specified either as open switch (normally closed contact) or closed switch (normally open contact).

It is also possible to specify whether the output signal should be bistable or monostable. With bistable operation, the relay remains in the activated state. With monostable operation, the delay time can be selected after which the relay reverts to its idle state.

You can choose various events that activate the output automatically. Thus, for example, it is possible to switch on a spotlight in response to a motion alarm and switch it off again when the alarm situation is no longer active.

Idle state:

Select **Open** if the relay is to operate as a normally open contact or **Closed** if it is to operate as a normally closed contact.

Operating mode:

Select an operating mode for the relay.

If, for example, a light switched on by an alarm is to remain lit when the alarm has ended, select **Bistable**. If an audible signal activated by an alarm is to sound for a period of ten seconds for example, select **10 sec**.

Relay follows:

Select a particular event to trigger the relay. The following events can activate the relay:

■ Off

No relay triggering by events

■ Connection

Triggering caused whenever a connection is established

■ Video alarm

Triggering caused by loss of the video signal

■ Motion alarm

Triggering caused by the motion alarm

■ Local input 1

Triggering caused by the alarm input 1

■ Remote input 1

Triggering caused by a relay contact at the target location (only when a connection is established)

■ Contrast alarm

Triggering caused by a lack of contrast in the picture

Relay name:

A name can be assigned to the relay in this field. The name will be shown on the button under **Trigger relay**. The Livepage can also be configured to display the name next to the relay icon.

Trigger relay:

Click the button to switch the relay manually (for example for test purposes or to operate a door opener).

COM1

page	Wizard	Expert Mode
COM1		
Serial port function:	<input type="text" value="Terminal"/>	<input type="button" value="Set"/>
Camera ID:	<input type="text" value="0"/>	<input type="button" value="Set"/>
Interface settings		
Baud rate:	<input type="text" value="19200"/> Bit/s	<input type="button" value="Set"/>
Data bits:	<input type="text" value="8"/>	
Stop bits:	<input type="text" value="1"/>	
Parity check:	<input type="text" value="None"/>	
Interface mode:	<input type="text" value="RS232"/>	
Half-duplex mode:	<input type="text" value="Off"/>	<input type="button" value="Set"/>
Help on this page?		

The **RS232/485** serial interface port can be configured to meet your requirements.

Serial port function:

Select a controllable device from the list. If you want to use the serial interface to transmit transparent data, select **Transparent**. To operate the VIP with a terminal, choose **Terminal**.

Note

After selecting a unit, the remaining parameters in the window are set automatically and should not be altered.

Camera ID:

If necessary, adjust the ID for the peripheral device that is to be controlled (e.g. dome camera or PTZ).

Baud rate:

Select the value for the data communication rate in Bit/s.

Data bits:

The number of data bits per character cannot be changed.

Stop bits:

Select the number of stop bits per character.

Parity check:

Select the type of parity check.

Interface mode:

Select the desired protocol for the serial interface.

Half-duplex mode:

Choose the setting appropriate for your application.

Network

page	Wizard	Expert Mode
Network		
Unit IP address:	<input type="text" value="10.0.32.22"/>	Reboot after 'Set' necessary!
Subnet mask:	<input type="text" value="255.0.0.0"/>	Reboot after 'Set' necessary!
Gateway IP address:	<input type="text" value="0.0.0.0"/>	Reboot after 'Set' necessary!
Video/audio transmission:	<input type="text" value="UDP"/>	
Ethernet link type:	<input type="text" value="Auto"/>	
Dynamic DNS server IP address:	<input type="text" value="0.0.0.0"/>	
Dynamic DNS contact interval:	<input type="text" value="0"/> (30...86,400 sec)	<input type="button" value="Set"/>

[Help on this page?](#)

The settings on this page are used to integrate the unit into an existing network.

**Warning!**

Changes to the IP address, subnet mask or gateway address are sent to the unit when the **Set** button is clicked. However, they only take effect after the unit is restarted!

- Click **Set** after entering a new IP address.
- Enter the old IP address in the address field of the Web browser and append `/reset` to it (e.g. `192.168.0.1/reset`). The VIP will be restarted after which it can only be accessed at the new IP address.

Unit IP address:

Enter the desired IP address for the VIP in this field. The IP address must be valid for the network.

Subnet mask:

Enter the subnet mask corresponding to the inserted IP address here.

Gateway IP address:

Enter the IP address of the gateway here if the unit is to establish a connection to a unit that is in another subnet. Otherwise, this field can remain empty (0.0.0.0).

Video/audio transmission:

If the device is used in front of a firewall, **TCP (HTTP port)** should be selected as the transmission protocol. For use in a local network, choose **UDP**.

**Warning!**

Multicast operation is possible only with the UDP protocol. The TCP protocol does not support multicast connections.

**Note**

In UDP mode the MTU is 1514 bytes.

Ethernet link type:

If the VIP is connected to the network via a switch, both devices must be set for the same type of network connection. If necessary, ask your network administrator about the switch setting.

The value can be set to 10 or 100 MBit/s and full or half-duplex mode (**FD** or **HD**) or to **Auto** for an autosensing network connection.

**Warning!**

Errors such as picture interference can occur if the network is not suitable for transmission of the maximum data rate generated by the VIP.

Dynamic DNS server IP address:

When operating a unit over the Internet, an address pool with dynamic addresses is used for greater efficiency. This means that the unit is assigned an IP address each time a connection is made and this address varies. In this case, access is easier if the unit is listed on a DNS server. It will contact the server at regular intervals and register its unit name and IP address. To connect to the VIP via the Internet, it is enough to enter the unit name and the URL of the DNS server. The server returns the current Internet IP address for the connection.

You can use the DNS server of VCS **videotec.info** as DNS server. The associated IP address is 195.145.107.78. The VIP contacts this server automatically if the desired refresh interval is entered for the next parameter. If the unit name is **MyVIP** for example, the URL **MyVIP.videotec.info** can be entered in the browser to make a connection.

Dynamic DNS contact interval:

Enter the desired update interval in seconds.

Multicasting

ivepage	Wizard	Expert Mode
Multicasting		
Multicast streaming:	<input type="text" value="Off"/>	
Multicast address MPEG-4 encoder 1:	<input type="text" value="0.0.0.0"/>	Port: <input type="text" value="60000"/>
Multicast address MPEG-4 encoder 2:	<input type="text" value="0.0.0.0"/>	Port: <input type="text" value="60100"/>
Multicast audio port (G.711):	<input type="text" value="65000"/>	
Multicast packet TTL:	<input type="text" value="16"/>	<input type="button" value="Set"/>

[Help on this page?](#)

In addition to a 1:1 connection between an encoder and a single receiver (unicast), the VIP can enable multiple receivers to receive the video signal from an encoder simultaneously. This is achieved either by duplicating the data stream in the unit with subsequent distribution to multiple receivers (multi-unicast) or by distribution of a single data stream over the network to a number of receivers in a defined group (multicast). A dedicated multicast address and port can be specified for each of the three encoders.

Note

The prerequisite for multicast operation is a multicast-capable network using the UDP and IGMP protocols. Other group membership protocols are not supported. The TCP protocol does not support multicast connections.

When the multicast address is set to 0.0.0.0, the respective encoder operates in multi-unicast mode (copies the data streams on the unit).

If a valid multicast address is entered the respective encoder operates in the multicast mode (duplication of the data stream on the network).

Note

Duplication of the data on the unit for multi-unicast connections requires considerable processor power and, under certain circumstances, leads to limitations in the picture quality.

Multicast streaming

Select the option **MPEG-4** to enable multicast streaming. **Off** disables multicast streaming.

Multicast address MPEG-4 encoder 1 (2):

A special IP address (class D address) must be configured for multicast operation in a multicast-enabled network.

The network must support group IP addresses and the Internet Group Management Protocol (IGMP). The address range is from 224.0.1.0 to 238.255.255.255.

The multicast address can be the same for multiple encoders. Then however it is necessary to use a different port in each case so that multiple data streams are not sent simultaneously over the same port and multicast address.

Enter the multicast address for the particular encoder here if multicast is to be used.

Port:

In the case of simultaneous data streams from more than one encoder with the same multicast address the data streams must be assigned to different ports.

Enter the port address for the particular encoder here.

Multicast audio port (G.711):

If audio is to be transmitted in multicast mode, too, the audio data must be assigned to another port as it is a separate data stream.

Enter the port address for the audio stream here.

 **Note**

A separate audio stream is only transmitted if the corresponding function on the **Audio stream** page is enabled (see page 45).

Multicast packet TTL:

This value determines the "life span" of multicast packets on the network. If multicast is operated via a router, the value must be greater than 1 to ensure that the packets are passed on.

Version information

page	Wizard	Expert Mode
Version information		
Hardware version:	<input type="text" value="301DC041"/>	
Firmware version:	<input type="text" value="25000210"/>	

[Help on this page?](#)

The hardware and firmware version numbers are for information only and cannot be altered. Keep a record of these numbers in case technical assistance is required.

Hardware version:

The hardware version number of the VIP is displayed.

Firmware version:

The firmware version number of the VIP is displayed.

Livepage configuration

Livepage configuration

Background URL: Search

Logo URL: Search

Show MPEG-4 live video from: MPEG-4 Encoder 1
 MPEG-4 Encoder 2

Show alarm inputs:

Show relay output:

Show event log:

Show system log:

Panorama (Sony camera only): Sony camera not selected!

Save event log:

Save system log:

Path for event log: Search

Path for system log: Search

Path for JPEG and MPEG files: Search Set

[Help on this page?](#)

In this dialog, the appearance of the Livepage can be set up to suit your requirements. Options are provided here to display various information and operating elements in addition to the video image.

Moreover, individual background graphics can be used for the main window and for the upper area of the window (banner).

Note

Either GIF or JPEG images can be used. The file paths must correspond to the access mode (local paths such as `C:\Images\Logo.gif` for local files and URLs such as `http://www.vcs.com/images/logo.gif` for files on the Internet).

Please note for access via Internet/intranet that there must be a connection in order to display the image. The image files are not stored on the VIP.

- Mark the checkboxes for the information to be displayed on the Livepage. The selected elements are marked.

- Check the display of the desired information on the Livepage.

Background URL:

Enter the path to a suitable background graphic in this field. The image can be stored on a local computer, a local network or at an Internet address.

- Click **Search** if necessary to find a suitable image on the local network.

Logo URL:

Enter here the path for a suitable image for the upper part of the window (banner). The image can be stored on a local computer, a local network or at an Internet address.

- Click **Search** if necessary to find a suitable image on the local network.

 **Note**

To restore the original graphics, just delete the entries in the fields **Background URL** and **Logo URL**.

Show MPEG-4 live video from:

Select a stream for the MPEG-4 video image on the Livepage. **MPEG-4 Encoder 1** is equivalent to Stream 1.

Show alarm inputs:

Alarm inputs are displayed next to the video image as icons along with their assigned names. If an alarm is active the corresponding icon changes color.

Show relay output:

The relay output is displayed next to the video image as icon along with its assigned name. If the relay is active the corresponding icon changes color.

Show event log:

The event log will be displayed with date and time in a field under the video image.

Show system log:

The system log will be displayed with date and time in a field under the video image and provide information about connections, etc.

Panorama (Sony camera only):

Selecting this option enables the display of a panoramic image. The panoramic image is shown in the upper part of the browser window. It consists of five single images that can be updated any time (see page 92).

**Note**

The panoramic image facility is only available with Sony EVI-D100 or EVI-D30/31 cameras.

Save event log:

Select this option to save the event log in a text file on the local computer.

These logs can be viewed, edited and printed with any software that can work with text files (such as Microsoft Word or Excel).

Save system log:

Select this option to save the system log to a text file on the local computer.

These logs can be viewed, edited and printed with any software that can work with text files (such as Microsoft Word or Excel).

Path for event log:

Enter full path for the event log file.

- If necessary, click **Search** to find a suitable folder.

Path for system log:

Enter full path for the system log file.

- If necessary, click **Search** to find a suitable folder.

Path for JPEG and MPEG files:

Enter the full path for saving snapshots and video sequences to be saved from the Livepage.

- If necessary, click **Search** to find a suitable folder.

Firmware and configuration upload

Livepage
Wizard
Expert Mode

Firmware and configuration upload

Firmware update:	<input type="text"/>	<input type="button" value="Durchsuchen..."/>	<input type="button" value="Upload"/>
Upload progress:	<input type="text" value="0%"/>		
Configuration download:			<input type="button" value="Download"/>
Configuration upload:	<input type="text"/>	<input type="button" value="Durchsuchen..."/>	<input type="button" value="Upload"/>

[Help on this page?](#)

Firmware update:

The VIP is designed in such a way that its functions and parameters can be updated with firmware. To accomplish this, the current firmware is loaded on the unit via the selected network. It will be installed automatically after the connection is closed.

Thus a VIP unit can be serviced and updated remotely without requiring a technician to make changes on-site.

The current firmware can be obtained from VCS Customer Service or downloaded from the Internet at our Web site (www.vcs.com).



Warning!

Before starting the firmware upload, be sure that you have selected the correct file! Uploading the wrong files can result in the unit no longer being addressable, requiring it to be replaced.

Do not interrupt the firmware installation for any reason! Interruption will damage the flash EPROMs. This can also result in the unit no longer being addressable, requiring it to be replaced.

- First, save the update file to the hard disk.

- Enter the full path for the update file in the field or click **Durchsuchen...** to locate and select the file.
- Click **Upload** to begin transmission to the unit. Transmission progress can be monitored from the progress bar.

After the upload is completed, the new firmware will be decompressed and used to reprogram the flash EPROM. The time necessary is indicated by the message **going to reset Reconnecting in ... seconds**.

After the upload is completed successfully, the unit will restart automatically.

If the operating status LED is red, the upload has failed and must be done again. This requires that you work from a special page:

- Enter the IP address of the unit in the browser and append `/main.htm` (for example `192.168.0.12/main.htm`).
- Repeat the upload.

Configuration download:

The VIP configuration data can be saved on a computer and the saved data loaded on a unit from the computer.

- Click **Download**. A dialog will appear.
- Follow the instructions to save the current settings.

Configuration upload:

- Enter the full path of the file to upload or click **Durchsuchen...** to select the desired file.
- Make sure that the file to be loaded originates from the same type of device as the unit you want to reconfigure.
- Click **Upload** to begin transmitting the file to the unit. Transmission progress can be monitored from the progress bar.

After the upload is completed, the new configuration will be activated. The time necessary is indicated by the message **going to reset Reconnecting in ... seconds**.

After the upload is completed successfully, the unit will restart automatically.

Function test

The VIP offers a number of configuration options. Therefore you should check that it works properly after installation and configuration.

This is the only way to ensure that the VIP will function as intended in an alarm situation.

Check for the following functions (among other things):

- Can the VIP be dialed remotely?
- Does the VIP transmit all the data required?
- Does the VIP respond as configured to alarm events?
- Is it possible to control peripheral devices if necessary?

Configuring the Receiver

Basics

The VIP offers various configuration options. Configuration in Expert Mode with a Web browser is described below. Basic information about configuration with a Web browser and other configuration options are described in Chapter 5 of this user guide.

Unit identification

The screenshot shows a web interface with a dark blue header containing three tabs: 'connection', 'Wizard', and 'Expert Mode'. Below the header, the title 'Unit identification' is displayed. The main content area is enclosed in a blue border and contains two input fields: 'Unit name:' and 'Unit ID:'. To the right of the 'Unit ID:' field is a grey button labeled 'Set'. Below the input fields, there is a blue link that reads 'Help on this page?'.

The unit can be assigned a name and an ID to facilitate identification. Both make the task of managing video surveillance systems with VIDOS von VCS or other tools much simpler.

Unit name:

Enter a name for the unit here.

Unit ID:

Each VIP should be assigned a unique identifier that can be entered here as an additional means of identification.

Password

connection	Wizard	Expert Mode
Password		
User name:	<input type="text" value="user"/>	
Password:	<input type="password"/>	No 'user'-password set!
Confirm password:	<input type="password"/>	<input type="button" value="Set"/>

[Help on this page?](#)

A VIP unit is generally protected by password to prevent unauthorized access. You can limit the scale of access by choosing between different authorization levels.

Note

Correct password protection is only granted when all higher levels of authorization are also protected by password. If a **user** password is assigned a **service** password must be assigned, too. Therefore assign passwords always beginning with the highest authorization level.

User name:

The receiver operates with two user names: **service** and **user** which refer to different authorization levels.

The user name **service** refers to the highest authorization level. Logged in under **service**, you can use all functions of the VIP and change all settings.

The user name **user** refers to the medium authorization level. Logged in under **user**, you can connect the unit to a sender on the network and close the connection, but no changes can be made to the configuration.

Password:

You can define and change a unique password for each user name if you are logged on as **service** or if the unit is not protected by a password.

Enter a password for the chosen user name here.


Confirm password:

Re-enter the new password to prevent typing mistakes.

Note

The new password becomes effective only after you have clicked **Set**. Therefore click **Set** immediately after having entered and confirmed the password even if you want to assign a password to another user name, too.

Language



connection Wizard Expert Mode

Language

Website language: English Set


[Help on this page?](#)

If more convenient, a different operating interface language can be chosen.

Website language:

Select the required language from the dropdown field.

Date and time



connection Wizard Expert Mode

Date and time

Date format: Europe Set

Unit date: Saturday 21 08 2004

Unit time: 17 36 50 Synchr. PC Set

[Help on this page?](#)

If a number of VIP units are part of a system, it is important that the internal clocks of these separate units be synchronized. Only if all units operate with the same time it is possible, for example, to correctly identify and evaluate recordings that have been made simultaneously.

Date format:

Choose the desired date format here


(Europe: DD.MM.YYYY; USA: MM.DD.YYYY; Japan: YYYY/MM/DD).

Unit date:

Enter the current date here. Since the system time is controlled by the internal clock, it is not necessary to enter the day of week. This is added automatically.

Unit time:

Enter the current time here or click the **Synchr. PC** button to copy the system time of your computer to the VIP.

Time server

The screenshot shows a software window titled "Time server" with a blue header bar containing "connection", "Wizard", and "Expert Mode". The window has a white background and a blue border. It contains three main sections: "Time zone:" with a dropdown menu showing "(UTC +1:00) Western & Central Europe"; "Time settings:" with a checkbox labeled "Use daylight saving time" which is currently unchecked; and "Time server IP address:" with a text input field containing "0.0.0.0" and a "Set" button to its right. Below the window, there is a blue link that says "Help on this page?".

[Help on this page?](#)

Using the Time Server Protocol the VIP can receive a time signal from a time server and use it to set its internal clock. The device calls up the time signal automatically every two hours.

Time zone:

Select the time zone that applies to your system.

Time settings:

Select this during daylight savings time if the time change is to be taken into account. Deselect it when standard time has resumed.

Time server IP address:

Enter the IP address of the chosen time server here.

MPEG decoder

connection	Wizard	Expert Mode
MPEG decoder		
Monitor name:	<input type="text"/>	
Video output standard:	<input type="text" value="PAL"/>	<input type="button" value="Set"/>
Monitor display		
Display transmission disturbance:	<input type="text" value="Off"/>	
Disturbance sensitivity level:	<input type="text" value="0"/>	
Notification text:	<input type="text" value="Freeze"/> (max. 31 characters)	<input type="button" value="Set"/>

[Help on this page?](#)

The monitor can be assigned a name to facilitate identification. The video output standard for the connected monitor can also be selected here.

The VIP can monitor the incoming data stream for integrity and can display a notification text on the monitor when it has detected disturbances in the transmission.

Monitor name:

Enter the desired monitor name here. The monitor name is used for easier identification of the monitor in large systems, e.g. it is displayed in VIDOS, the VCS software for managing video surveillance systems.

Enter a unique, unambiguous name.

Video output standard:

Select the video standard for the monitor output.



Warning!

Be sure to choose the correct video standard to avoid damaging the monitor.

Display transmission disturbance:

Choose **On** to display a text on the monitor in case of transmission disturbances.

Disturbance sensitivity level:

Here you can define at what level the text display is triggered. The lower the value the higher the sensitivity level of the VIP.

Notification text:

Enter the text that is to be displayed on the monitor. It can contain up to 31 characters.

Audio stream

connection Wizard Expert Mode

Audio stream

Enable audio: Off

[Help on this page?](#)

In addition to video data, the unit can also send and receive audio signals. The transmission of audio takes place at the same time as that of the video data in a separate data stream. Thus it increases the data traffic. The audio data is coded according to G.711 compression standard and requires an additional bandwidth of about 80 kBit/s per direction.

Note

Sending of audio signals via the receiver is only possible if the audio function of the sender is enabled (see page 74) and the checkbox **Include audio** on the **Decoder connection** page is activated (see page 97).

Enable audio:

To transmit a separate G.711 audio stream choose **On**.

Alarm sources

connection Wizard Expert Mode

Alarm sources

Alarm input 1: Name:

Alarm input 2: Name:

1. SNMP host address:

2. SNMP host address:

[Help on this page?](#)

Both VIP decoder alarm inputs can be configured individually.

Alarm input 1 ... Alarm input 2:

Select the option **On** in order to activate the alarm via the corresponding external alarm sensor. Otherwise, select **Off**.

You can choose whether the alarm is triggered by an **Active high** (contact open) or **Active low** (contact closed) input state.

Name:

You can enter a name for each alarm input.

1./2. SNMP host address:

Enter the IP addresses of up to two chosen receivers here if the alarm message is to be sent via SNMP-traps.

Alarm connections

connection	Wizard	Expert Mode
Alarm connections		
Connect on alarm:	<input type="text" value="Off"/>	<input type="button" value="Set"/>
Number of destination IP address:	<input type="text" value="1"/>	
Destination IP address:	<input type="text" value="0.0.0.0"/>	
Destination password:	<input type="text"/>	
Remote encoder line:	<input type="text" value="1"/>	
Auto-connect:	<input type="text" value="Off"/>	

[Help on this page?](#)

You can select a number of options for the response of the VIP to an alarm. In case of an alarm, the VIP can establish a connection to a predefined IP address, e.g. a VIP sender, automatically. You can enter up to 10 IP addresses which will be selected in sequence by the unit until a connection is established.

Note

Sender and receiver must share the same subnet for connection set-up (see page 81).

If the VIP connects to a "dual streaming" encoder Stream 1 will be transmitted.

Connect on alarm:

Select **On**, to establish a connection automatically to a specified IP address in the event of an alarm.

With the setting **Follows input**, the VIP holds the automatically set up connection to a remote location as long as an alarm signal is present at its alarm input 1. You can use this setting to establish a connection between two VIP units via a connected on-off switch. In this case you don't need a computer to set up the connection.

Number of destination IP address:

Here you assign the numbering for the IP addresses to be contacted in the event of an alarm. The unit contacts the remote locations one after the other in the numbered sequence until a connection has been established.

Destination IP address:

For each number, enter the corresponding IP address of the desired remote unit.

Destination password:

Enter the password, if the remote unit is protected by a password.

Remote encoder line:

If the remote unit is a multi-channel device enter here the number of the video input which is to be the data source.

Auto-connect:

Select **On** if an active connection should be reestablished automatically to one of the previously specified IP addresses after each restart, e.g. after a connection breakdown or network dropout.

Relay

connection	Wizard	Expert Mode
Relay		
Idle state:	<input type="text" value="Open"/>	<input type="button" value="Set"/>
Operating mode:	<input type="text" value="Bistable"/>	
Relay follows:	<input type="text" value="Off"/>	
Relay name:	<input type="text" value="Relay"/>	<input type="button" value="Set"/>
Relay operation		
Trigger relay:	<input type="button" value="Relay"/>	
Help on this page?		

You can configure the switching behavior of the relay output. Relay action can be specified either as open switch (normally closed contact) or closed switch (normally open contact).

It is also possible to specify whether the output signal should be bistable or monostable. With bistable operation, the relay remains in the activated state. With monostable operation, the delay time can be selected after which the relay reverts to its idle state.

You can choose various events that activate the output automatically. Thus, for example, it is possible to switch on a spotlight in response to a motion alarm and switch it off again when the alarm situation is no longer active.

Idle state:

Select **Open** if the relay is to operate as a normally open contact or **Closed** if it is to operate as a normally closed contact.

Operating mode:

Select an operating mode for the relay.

If, for example, a light switched on by an alarm is to remain lit when the alarm has ended, select **Bistable**. If an audible signal activated by an alarm is to sound for a period of ten seconds for example, select **10 sec**.

Relay follows:

Select a particular event to trigger the relay. The following events can activate the relay:

■ Off

No relay triggering by events

■ Connection

Triggering caused whenever a connection is established

■ Local input 1

Triggering caused by the alarm input 1

■ Remote input 1

Triggering caused by a relay contact at a remote location (only when a connection is established)

Relay name:

A name can be assigned to the relay in this field. The name will be shown on the button under **Trigger relay**.

Trigger relay:

Click the button to switch the relay manually (for example for test purposes or to operate a door opener).

COM1

connection	Wizard	Expert Mode
COM1		
Serial port function:	<input type="text" value="Terminal"/>	
Camera ID:	<input type="text" value="0"/>	<input type="button" value="Set"/>
Interface settings		
Baud rate:	<input type="text" value="19200"/> Bit/s	
Data bits:	<input type="text" value="8"/>	
Stop bits:	<input type="text" value="1"/>	
Parity check:	<input type="text" value="None"/>	
Interface mode:	<input type="text" value="RS232"/>	
Half-duplex mode:	<input type="text" value="Off"/>	<input type="button" value="Set"/>

[Help on this page?](#)

The **RS232/485** serial interface port can be configured to meet your requirements.

Serial port function:

If you want to use the serial interface to transmit transparent data, select **Transparent**. To operate the VIP with a terminal, choose **Terminal**.

Note

After selecting an interface function, the remaining parameters in the window are set automatically and should not be altered.

Camera ID:

If necessary, adjust the ID for the peripheral device that is to be controlled (e.g. dome camera or PTZ).

Baud rate:

Select the value for the data communication rate in Bit/s.

Data bits:

The number of data bits per character cannot be changed.

Stop bits:

Select the number of stop bits per character.

Parity check:

Select the type of parity check.

Interface mode:

Select the desired protocol for the serial interface.

Half-duplex mode:

Choose the setting appropriate for your application.

Network

connection	Wizard	Expert Mode
Network		
Unit IP address:	<input type="text" value="10.0.32.23"/>	Reboot after 'Set' necessary!
Subnet mask:	<input type="text" value="255.0.0.0"/>	Reboot after 'Set' necessary!
Gateway IP address:	<input type="text" value="0.0.0.0"/>	Reboot after 'Set' necessary!
Video/audio transmission:	<input type="text" value="UDP"/>	
Ethernet link type:	<input type="text" value="Auto"/>	
Dynamic DNS server IP address:	<input type="text" value="0.0.0.0"/>	
Dynamic DNS contact interval:	<input type="text" value="0"/>	(30...86,400 sec) <input type="button" value="Set"/>

[Help on this page?](#)

The settings on this page are used to integrate the unit into an existing network.

**Warning!**

Changes to the IP address, subnet mask or gateway address are sent to the unit when the **Set** button is clicked. However, they only take effect after the unit is restarted!

- Click **Set** after entering a new IP address.
- Enter the old IP address in the address field of the Web browser and append `/reset` to it (e.g. `192.168.0.1/reset`). The VIP will be restarted after which it can only be accessed at the new IP address.

Unit IP address:

Enter the desired IP address for the VIP in this field. The IP address must be valid for the network.

Subnet mask:

Enter the subnet mask corresponding to the inserted IP address here.

Gateway IP address:

Enter the IP address of the gateway here if the unit is to establish a connection to a unit that is in another subnet. Otherwise, this field can remain empty (0.0.0.0).

Video/audio transmission:

If the device is used in front of a firewall, **TCP (HTTP port)** should be selected as the transmission protocol. For use in a local network, choose **UDP**.

**Warning!**

Multicast operation is possible only with the UDP protocol. The TCP protocol does not support multicast connections.

**Note**

In UDP mode the MTU is 1514 bytes.

Ethernet link type:

If the VIP is connected to the network via a switch, both devices must be set for the same type of network connection. If necessary, ask your network administrator about the switch setting.

The value can be set to 10 or 100 MBit/s and full or half-duplex mode (**FD** or **HD**) or to **Auto** for an autosensing network connection.

**Warning!**

Errors such as picture interference can occur if the network is not suitable for transmission of the maximum data rate generated by the VIP.

Dynamic DNS server IP address:

When operating a unit over the Internet, an address pool with dynamic addresses is used for greater efficiency. This means that the unit is assigned an IP address each time a connection is made and this address varies. In this case, access is easier if the unit is listed on a DNS server. It will contact the server at regular intervals and register its unit name and IP address. To connect to the VIP via the Internet, it is enough to enter the unit name and the URL of the DNS server. The server returns the current Internet IP address for the connection.

You can use the DNS server of VCS **videotec.info** as DNS server. The associated IP address is 195.145.107.78. The VIP contacts this server automatically if the desired refresh interval is entered for the next parameter. If the unit name is **MyVIP** for example, the URL **MyVIP.videotec.info** can be entered in the browser to make a connection.

Dynamic DNS contact interval:

Enter the desired update interval in seconds.

Version information

connection	Wizard	Expert Mode
Version information		
Hardware version:	<input type="text" value="311AF341"/>	
Firmware version:	<input type="text" value="25000210"/>	
Help on this page?		

The hardware and firmware version numbers are for information only and cannot be altered. Keep a record of these numbers in case technical assistance is required.

Hardware version:

The hardware version number of the VIP is displayed.

Firmware version:

The firmware version number of the VIP is displayed.

Firmware and configuration upload

er connection	Wizard	Expert Mode
Firmware and configuration upload		
Firmware update:	<input type="text"/>	<input type="button" value="Durchsuchen..."/> <input type="button" value="Upload"/>
Upload progress:	<input type="text" value="0%"/>	
Configuration download:		<input type="button" value="Download"/>
Configuration upload:	<input type="text"/>	<input type="button" value="Durchsuchen..."/> <input type="button" value="Upload"/>
help on this page?		

Firmware update:

The VIP is designed in such a way that its functions and parameters can be updated with firmware. To accomplish this, the current firmware is loaded on the unit via the selected network. It will be installed automatically after the connection is closed.

Thus a VIP unit can be serviced and updated remotely without requiring a technician to make changes on-site.

The current firmware can be obtained from VCS Customer Service or downloaded from the Internet at our Web site (www.vcs.com).

**Warning!**

Before starting the firmware upload, be sure that you have selected the correct file! Uploading the wrong files can result in the unit no longer being addressable, requiring it to be replaced.

Do not interrupt the firmware installation for any reason! Interruption will damage the flash EPROMs. This can also result in the unit no longer being addressable, requiring it to be replaced.

- First, save the update file to the hard disk.
- Enter the full path for the update file in the field or click **Durchsuchen...** to locate and select the file.
- Click **Upload** to begin transmission to the unit. Transmission progress can be monitored from the progress bar.

After the upload is completed, the new firmware will be decompressed and used to reprogram the flash EPROM. The time necessary is indicated by the message **going to reset Reconnecting in ... seconds**.

After the upload is completed successfully, the unit will restart automatically.

If the „operating status“ LED is red, the upload has failed and must be done again. This requires that you work from a special page:

- Enter the IP address of the unit in the browser and append `/main.htm` (for example `192.168.0.12/main.htm`).
- Repeat the upload.

Configuration download:

The VIP configuration data can be saved on a computer and the saved data loaded on a unit from the computer.

- Click **Download**. A dialog will appear.
- Follow the instructions to save the current settings.

Configuration upload:

- Enter the full path of the file to upload or click **Durchsuchen...** to select the desired file.
- Make sure that the file to be loaded originates from the same type of device as the unit you want to reconfigure.
- Click **Upload** to begin transmitting the file to the unit. Transmission progress can be monitored from the progress bar.

After the upload is completed, the new configuration will be activated. The time necessary is indicated by the message **going to reset Reconnecting in ... seconds**.

After the upload is completed successfully, the unit will restart automatically.

Function test

The VIP offers a number of configuration options. Therefore you should check that it works properly after installation and configuration.

This is the only way to ensure that the VIP will function as intended in an alarm situation.

Check for the following functions (among other things):

- Can the VIP be dialed remotely?
- Does the VIP transmit all the data required?
- Does the VIP respond as configured to alarm events?
- Is it possible to control peripheral devices if necessary?

Sender Operation

Operation with Microsoft Internet Explorer

A computer with Microsoft Internet Explorer (version 5.5 or later) can be used to receive live images from the VIP, control cameras or other peripherals and replay sequences stored on the local hard drive.

 **Note**

Make sure the graphic card is set to 16 or 32 bit color depth and the Microsoft Virtual Machine is installed and active on your computer. If necessary, the required software and controls can be installed from the CD provided (see the list of components supplied, page 11).

Instructions for using the Web browser will be found in its online help.

System requirements

- Microsoft Internet Explorer (version 5.5 or higher)
- Monitor resolution 1024 × 768 pixels
- Network access (intranet or Internet)

MPEG-ActiveX installation

 **Note**

In order to display the live video images, an appropriate MPEG-ActiveX must be installed on the computer, such as that used for playing DVD movies. If necessary, the required software and controls can be installed from the CD provided (see the list of components supplied, page 11).


- Insert the CD into the CD-ROM drive of the computer. The CD will start automatically. If the CD does not start automatically, open the root directory of the CD in Windows Explorer and double click **MPEGAx.exe**.
- Follow the instructions on the screen.

Establishing the connection

The VIP must be provided with a valid IP address to operate on your network.

The following default address has been pre-set at the factory: **192.168.0.1**

- Start the Web browser.
- Enter the IP address of the VIP as the URL. The connection will be established, and after a short time the Livepage with the video image will appear.



The Livepage

After the connection is established, the Livepage will be displayed first. It shows the live video image in the middle of the browser window. Depending upon configuration, various text overlays may be visible on the image (see page 39).

Other information may also be shown next to the video image on the Livepage. The display depends on the settings on the configuration page **Livepage configuration** (see page 63).

 **Note**

If the connection cannot be established, this may be because the unit selected is already busy with another remote station. Depending upon the network configuration and the individual units, a transmitter can serve up to five receivers at the same time.

VIP password protection

If the VIP is password-protected against unauthorized access, a password dialog will appear first.

 **Note**

Configuration work can only be performed on a password-protected VIP unit if the **service** user is logged on.

- Enter the user name and the associated password in the appropriate fields.
- Click **OK**. If the password is entered correctly, the Livepage with the video image will be shown.

Image quality

The VIP 10 displays either a live video sequence in MPEG-4 format or individual live video frames in JPEG format.

- Click on the **MPEG-4** link in the navigation bar at the top of the browser display to display or decode the video sequences in the corresponding image format.

or

- Click on the **M-JPEG** link in the navigation bar at the top of the browser display to display or decode the individual frames in the corresponding image format.
- Click one of the links (**Small** or **Large**) above the live video image to view the image in the respective resolution.

Alarm inputs

In the event of an alarm, a red alarm symbol for the triggering alarm input is displayed next to the video image. The display of alarms and other details depends on the configuration of the unit (see page 47).

Relay output

Depending upon configuration, a device such as a floodlight or a door opener can be activated by the relay of the VIP unit. The display of the relay and other details depends on the configuration of the unit (see page 54).

- Click the relay symbol next to the video image to activate the relay output. The symbol will turn red when the relay is activated.

Event messages

The **Event log** field is where events such as switching a relay or alarm status messages are listed. These messages can be saved automatically in a log file (see page 65).

System messages

The **System log** field contains information about the operating status of the VIP and the connection. These messages can be saved automatically in a log file (see page 65).

Audio function

Depending upon configuration (see page 44) audio data can be send and received by the VIP. All users that are connected via Web browser receive the audio data sent by the VIP.

Only the user who has set up the first browser connection can send audio data to the unit.

- Klick on the Livepage anywhere outside the video picture to take the focus off the ActiveX.
- Keep the key **F12** pressed to send audio data to the VIP. In the browser status bar the message **Send Audio ON** is shown.
- Release the key **F12** if you want to stop sending audio data to the VIP. In the browser status bar the message **Send Audio OFF** is shown.

Note

When the browser connection over which audio data can be sent to the unit is cut off this function is taken over by the connection that is set up next.

Control functions

Control options for peripheral devices (such as a pan and tilt head or a dome camera) depend on the type of device installed and the configuration of the VIP.


If a controllable device is connected to the VIP and configured, the controls for the peripheral are displayed next to the video image, here e.g. for a Sony EVI-D30/31.



- To control a peripheral device click the associated operating elements.
- Move the pointer over the video image. Further options for peripheral device control will be displayed using the pointer.

Panorama view

If you are working with a Sony EVI-D100 or EVI-D30/31 camera, you can also display a panoramic image. The panoramic image is shown in the upper part of the Livepage. It consists of five single images that can be updated any time.



- Right-click on the panoramic image to open the context menu.
- Select **Start scan** to update the individual images. **Stop scan** cancels the update.

 **Note**

The panorama image is displayed only if **Show panorama view** is selected on the configuration page **Livepage configuration** (see page 63).

Saving snapshots

Individual images from the current video sequence on the Livepage can be saved on the computer hard drive in JPEG format.

- Click the **Snapshot** icon. The image will be saved. The storage location depends on the configuration of the VIP (see page 66).



Image resolution

Snapshots can be called up and displayed at different resolutions by entering URL parameters in the address field of the Web browser. Just append the corresponding parameter to the `snap.jpg` command:

■ `snap.jpg?JpegSize=S` for 176 × 144 pixels (QCIF)

■ `snap.jpg?JpegSize=M` for 352 × 288 pixels (CIF)

■ `snap.jpg?JpegSize=XL` for 704 × 576 pixels (4CIF)

Without the extra parameter, the default image size is 352 × 288 (CIF) pixels.

- Type the IP address of the VIP, followed by `/snap.jpg` into the Internet address field as URL (e.g. `http://192.168.0.12/snap.jpg`).
- Press the Return key or Enter key. A single frame image will be displayed in a new window.
- Right-click the image and select **Save Picture As...** from the context menu.
- Save the snapshot in the desired format, giving it a new name.

Recording video sequences

Segments from the current video sequence on the Livepage can be saved on the computer hard drive in MPEG format.

Click the **MPEG-sequence** icon. Saving begins immediately. The storage location depends on the configuration of the VIP (see page 66). A recording in progress is indicated by the blinking of the red dot on the icon.



- Click the **MPEG-sequence** icon again. Saving will be terminated.

Image resolution

The sequences will be recorded at the resolution specified in the encoder settings (see page 41). Select the stream for Livepage video display on the configuration page **Livepage configuration** (see page 64).

MPEG-Viewer installation

You can display recorded video sequences with the VCS MPEG-Viewer which you find on the accompanying software CD (see page 11).

- Insert the CD into the CD-ROM drive of the computer. The CD will start automatically. If the CD does not start automatically, open the root directory of the CD in Windows Explorer.
- Open the directory entitled **MPEG-Viewer** and copy the **MPEGViewer.exe** file to your hard drive.
- You can start the MPEG-Viewer by double-clicking the file **MPEGViewer.exe**.

Receiver Operation

Operation with Microsoft Internet Explorer

A computer with Microsoft Internet Explorer (version 5.5 or later) can be used to set up a connection to a VCS sender and to display the live images received on a monitor.

 **Note**

Make sure the graphic card is set to 16 or 32 bit color depth and the Microsoft Virtual Machine is installed and active on your computer. If necessary, the required software and controls can be installed from the CD provided (see the list of components supplied, page 11).

Instructions for using the Web browser will be found in its online help.

System requirements

- Microsoft Internet Explorer (version 5.5 or higher)
- Monitor resolution 1024 × 768 pixels
- Network access (intranet or Internet)

MPEG-ActiveX installation

 **Note**

In order to display the live video images, an appropriate MPEG-ActiveX must be installed on the computer, such as that used for playing DVD movies. If necessary, the required software and controls can be installed from the CD provided (see the list of components supplied, page 11).


- Insert the CD into the CD-ROM drive of the computer. The CD will start automatically. If the CD does not start automatically, open the root directory of the CD in Windows Explorer and double click **MPEGAx.exe**.
- Follow the instructions on the screen.

Establishing the connection

The VIP must be provided with a valid IP address to operate on your network.

The following default address has been pre-set at the factory: **192.168.0.2**

- Start the Web browser.
- Enter the IP address of the VIP as the URL. The connection will be established, and after a short time the **Decoder connection** page will appear.



The Decoder connection page

After the connection has been established, the **Decoder connection** page will be displayed and the unit automatically scans the network for available senders.

Preview

In this area you can select one of the video sources found in the network. A snapshot of the video image from the selected video source is displayed. In addition to the unit name the snapshot provides other means of identifying the sender.

Monitor

As soon as a connection with a sender is established, you will see a snapshot of the video image from the connected sender here.

Connection between the receiver and sender

During startup the VIP automatically scans the network for available senders. As soon as a sender is found on the network, the VIP automatically displays a snapshot of this sender. All the senders found are listed in a dropdown list labeled **Video sources**.

Establishing a connection

- Choose a sender from the list of **Video sources**. A JPEG snapshot from the video source selected will appear on the start page under **Preview**.
- Mark the checkbox **Include audio** if you want to transmit audio, too. Make sure for correct audio transmission configuration for both, sender and receiver.
- Mark the checkbox **Include data** if you want to transmit transparent data, too. Make sure for correct data transmission configuration for both, sender and receiver.

Note

The checkboxes must be marked prior to connection set-up in order to include audio and data transmission.

- Click the corresponding checkbox again to deactivate audio or data transmission respectively.
- Click the button **Connect MPEG-4** to connect the video images to the connected monitor. Under **Monitor** a snapshot from the connected source is displayed.
- If the sender is a multi-channel unit, e.g. a VideoJet 8000 from VCS, you can choose the **Video input** to be displayed.

Terminating a connection

- Click the close button (**X**) in the 'Monitor'-window title bar to stop the video display on the monitor.

Hardware Connections

Hardware connections between VCS units

A VIP sender, connected to a camera, and a VIP receiver, connected to a monitor, can be linked together or to other VCS units easily via an Ethernet network. This makes it possible to establish connections over large distances with little effort for installation or cabling.

Installation

The VCS units are designed to connect with one another automatically when correspondingly configured. The only requirement is that they are both part of a closed network. Proceed as follows to install the units:

- Connect the units to the closed network using Ethernet cables.
- Connect them to the mains supply.

Note

Make sure the units are correctly configured for the network environment and that the correct IP address of the remote unit that is to be connected in case of alarm is set on the configuration page **Alarm connections** (see page 50 for the sender and page 77 for the receiver).

Establishing the connection

There are three options for establishing a connection between a VCS sender and a VCS receiver in a closed network:

- when an alarm signal is given,
- using a terminal program or
- using a Web browser

Connection when an alarm signal is given

Sender and receiver can be configured to connect automatically with each other when an alarm is triggered (see page 49 for sender and page 77 for receiver). After a short time, the live video image from the sender will be shown on the connected monitor.

This option can also be used to connect two VCS units via an on-off switch at the receiver. In this case, a computer is not needed to establish the connection (see page 76).

Connection using a terminal program

This operating mode has various prerequisites. Refer to the section **Setup using terminal software** (see page 21).

- Start the terminal program. Enter the command `i` to call up the **IP** menu.
- Enter the command `r` in the **IP** menu to change the remote IP address, then enter the IP address of the device to connect to.
- Enter the command `a` in the **IP** menu to activate **automatic connection set up**.

Connection using a Web browser

This operating mode has various prerequisites. Refer to the section **Establishing the connection** (see page 25).

- Use the Web browser to connect to the VIP receiver. Its home page will be displayed.
- Establish the desired connection to the monitor (see page 97).

Closing the connection

The connection may be closed using a terminal program or Web browser.

Closing the connection using a terminal program

- Start the terminal program (see page 21); enter the command `i` to call up the **IP** menu.
- Enter the command `a` in the **IP** menu to deactivate automatic connection.

Closing the connection using a Web browser

- Use the Web browser to connect to the VIP receiver. Its home page will be displayed.
- Click the icon with the red **x** to stop the video display on the monitor.

Operation with VIDOS

VIP video servers and VIDOS software can be combined to form a high-performance system solution.

VIDOS is software for the operation, control and administration of CCTV installations (e.g. surveillance systems) at remote locations. It runs under Microsoft Windows operating systems. Its main function is decoding video, audio and control data from a remote sender.

There are many options available for operation and configuration when using VIP devices in combination with VIDOS. Refer to the software documentation for more details.

Testing the network connection

The `ping` command can be used to check the connection between two IP addresses. This allows you to test whether a unit is active in the network.

- Open the DOS command prompt.
- Type `ping` followed by the IP address of the unit.

If the unit is found, the response appears as `Reply from ...`, followed by the number of bytes sent and the transmission time in milliseconds. Any other response indicates that the unit cannot be accessed via the network. Possible causes:

- The unit is not properly connected to the network. Check the cable connections in this case.
- The unit is not correctly integrated into the network. Check the IP address, subnet mask and, if necessary, the gateway IP.

Device reset

The reset button can be used to reset the unit to its original factory settings. Any changes in the settings will be overwritten by the factory defaults. This may be necessary, for example, if the unit has invalid settings that prevent it from functioning as desired.



Warning!

All configured settings will be discarded during a reset. If necessary, back up the current settings using the **Download** button on the configuration page entitled **Firmware and configuration upload** (see page 66 for sender and page 83 for receiver).

Before starting the firmware update, be sure that you have selected the correct upload file! Uploading the wrong files can result in the unit no longer being addressable, requiring it to be replaced. Do not interrupt the firmware installation for any reason! Interruption will damage the Flash EPROM. This

can likewise result in the unit no longer being addressable, requiring it to be replaced.

Note

After a reset, the unit can only be addressed via the factory default IP address. The IP address can be changed as described in the chapter entitled **Installation** (see page 22).

- If necessary, back up the current settings using the **Download** button on the configuration page entitled **Firmware and configuration upload** (see page 66 for sender and page 83 for receiver).
- Use a pointed object to press the reset button which is found below the USB interface (see page 16) until the „operating status“ LED blinks red. All settings will revert to their defaults.
- Change the IP address of the unit as necessary.
- Configure the unit to meet your requirements.

Repairs



Warning!

Never open the casing of the VIP device. The unit does not contain parts that you can repair or replace.

Ensure that maintenance or repair work is performed only by qualified personnel, or contact your VCS dealer service center.

Transfer and disposal

The VIP should only be passed on together with this manual.

The unit and its power supply contain environmentally hazardous materials that must be disposed of according to law.

Defective or superfluous units and parts should be disposed of professionally or taken to your local collection point for hazardous materials.

Appendix

Troubleshooting

If you cannot correct a malfunction, please contact your supplier, system integrator or VCS customer service (support@vcs.com).

The version numbers of the internal processors can be viewed on a special page. Please note this information before contacting Customer Service.

- In the address field of the browser, append `/version.htm` to the IP address of the unit (e.g. `192.168.0.12/version.htm`) and press Enter.
- Write down the information or print out the page.

The following table is intended to help you identify the causes of malfunctions and correct them where possible.

Problem	Possible Causes	Solution
No connection between the unit and terminal program.	Faulty cable connections.	Check all cables, plugs, contacts and connections.
	The computer's serial interface is not connected.	Check the other serial interfaces.
	Interface parameters do not match.	Select a different COM port if necessary and make sure that the computer's interface parameters match those of the unit. You can also try the following standard parameters: 19,200 baud, 8 data bits, no parity, 1 stop bit. After that, switch off the power to the unit and switch it on again after a couple of seconds.
No image transmission from the target location.	Defective camera.	Connect a local monitor and check the camera function.
	Faulty cable connections.	Check all cables, plugs, contacts and connections.

Problem	Possible Causes	Solution
No connection established, no image transmission.	The unit's configuration.	Check all settings.
	Faulty installation.	Check all cables, plugs, contacts and connections.
	Wrong IP address.	Check the IP addresses (terminal program).
	Faulty data transmission within the LAN.	Check data transmission with the ping command.
	The maximum number of connections possible to other devices has already been reached.	Wait until there is a free connection and contact the sender again.
No image transmission to analog monitor	Transmission data rate too high for receiver	Reduce transmission data rate at the sender.
No audio transmission from the target location.	Hardware failure.	Check that all audio devices connected function correctly.
	Faulty cable connections.	Check all cables, plugs, contacts and connections.
	Faulty configuration.	Check the audio settings (volume and coding mode).
	Audio/voice communication is busy with another receiver.	Wait until a connection is available and contact the sender again.
The unit does not report an alarm.	No alarm source is chosen.	Select alarm input on the Alarm sources configuration page.
	No alarm action selected.	Define the desired alarm actions on the Alarm connections configuration page. If necessary, change the IP address.
Control of cameras or other devices is not possible.	The cable connection between the serial interface and the connected device is incorrect.	Check all cable connections and ensure all plugs are properly plugged in.
	The interface parameters conflict with those of the other device connected.	Make sure the settings of all devices involved are compatible.
The unit is no longer operational after a firmware upload.	Incorrect update file.	Connect the unit via Web browser typing its IP address followed by /main.htm and repeat the upload.

LEDs

The VIP video server is equipped with several LEDs that show the operating status and can give indications of possible malfunctions:

Operating status LED

Not lit:	Device is switched off.
Lit yellow:	Device is switched on.
Lit red (briefly):	Device is starting up.
Lit red (continuously):	Device is out of order, upload failed.

Network connection LED

Lit green:	Connected to the network.
Not lit:	Not connected to the network.


Data transfer LED

Blinking orange:	Data transfer via the network.
Not lit:	No data transfer.

RS232/485 interface

Options for using the serial interface include transparent data transfer, control of connected devices or operation of the unit with a terminal program. Depending on the setting, the interface works with the RS232 or RS422/485 protocol. The protocol used depends on the current configuration (see page 56).

The pin assignments depend on the protocol used.



Pin	RS232 Protocol	RS422/485 Protocol
1	–	–
2	RxD (receive data)	RxD+ (receive data plus)
3	TxD (transmit data)	TxD- (transmit data minus)
4	–	–
5	GND (ground)	GND (ground)
6	–	–
7	RTS (ready to send)	TxD+ (transmit data plus)
8	CTS (clear to send)	RxD- (receive data minus)
9	–	–

Note

For RS422/RS485 pin assignment is also possible for 2-wire connection.

- Connect the TxD+ with the RxD+. TxD+ then is equivalent to DATA+.
- Connect the TxD- with the RxD-. TxD- then is equivalent to DATA-.

Connection jacks

The connection jacks are used to connect to the mains supply. As standard, the connection to the power supply unit is made here. They also allow the connection of alarm switches, relays, an audio source and a loudspeaker.

Terminal allocation

Terminal	Function
Li	audio input (line level)
Lo	audio output (line level)
IN1	Alarm 1 input
R	alarm output
+	power supply, 9 to 24 V
GND	electrical ground
GND	electrical ground
IN2	Alarm 2 input
R	alarm output
-	power supply

Each alarm input (IN1 resp. IN2) is to be connected with the electrical ground (GND) using a trigger contact.

Glossary

A few brief explanations of the most important terms and abbreviations used in the field of communications technology can be found below.

10/100 Base-T	IEEE 802.3 specification for 10 or 100 MBit/s Ethernet
ARP	Address Resolution Protocol: a protocol for mapping MAC and IP addresses
Baud	Measure for the speed of the data transfer rate
Bit/s	Bits per second, the actual data rate
CIF	Common Intermediate Format, video format with 352 × 288 pixels
DNS	Domain Name Service
FTP	File Transfer Protocol
Full duplex	Simultaneous data transmission in both directions (sending and receiving)
G.711	Standard ITU-T audio coding algorithms
GOP	Group of pictures
HTTP	Hypertext Transfer Protocol
ICMP	Internet Control Message Protocol
ID	Identification: a machine-readable character sequence
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Management Protocol
Internet Protocol	The main protocol used on the Internet. Together with the Transfer Control Protocol (TCP), it constitutes "TCP/IP"
IP	See "Internet Protocol"
IP address	A 4-byte number uniquely defining each device on the Internet. It is usually written in dotted decimal notation with periods separating the bytes, for example "209.130.2.193".
ISDN	Integrated Services Digital Network
JPEG	An encoding process for still images (Joint Photographic Experts Group)
kBit/s	Kilobits per second, the actual data rate
LAN	See Local area network
Local area network	A communications network serving users within a limited geographical area, such as a building or a university campus. It is controlled by a network operating system and uses a transfer protocol.
M-JPEG	Motion-JPEG; the video sequence is generated stringing together JPEG-images

MAC	Media Access Control
MPEG-4	Video compression standard designed for transmission of audiovisual data at very low transfer rates (for example via the Internet).
MTU	Maximum Transmission Unit resp. Maximum Transfer Unit
Netmask	A mask that explains which part of an IP address is the network address and which part comprises the host address. It is usually written in dotted decimal notation, for example "255.255.255.192".
Parameter	Values used for configuration
QCIF	Quarter CIF, a video format with 176 × 144 pixels
RS232/RS422/RS485	Data transfer standards
RTP	Realtime Transport Protocol; transport protocol for video and audio in real time
SNMP	Simple Network Management Protocol
Subnet mask	See netmask
TCP	Transfer Control Protocol
Telnet	Connection protocol for a user to connect to a remote computer (host) in the Internet
Time Server Protocol	A protocol to synchronize computers in the Internet
TTT	Time To Live
UDP	User Datagram Protocol
URL	Uniform Resource Locator
UTP	Unshielded Twisted Pair
WAN	See wide area network
Wide area network	A long distance link used to extend or connect remotely located local area networks

VIP 10 Specifications

Operating voltage	12 ... 24 V DC, power supply included
Power consumption	approx. 10 W
Network interface	Ethernet 10/100 Base-T, auto-sensing, half/full-duplex, RJ45
Video data rate	9.6 kBit/s ... 4 MBit/s (MPEG-4)
Audio data rate	80 kBit/s (MPEG-4) per direction
Audio sampling rate	8 kHz (MPEG-4)
Video standards	PAL, NTSC
Image resolution (PAL/NTSC)	704 × 576/480 pixels (D1/4CIF) 704 × 288 pixels (2CIF) 352 × 576/480 pixels (1/2 D1, adjustable) 352 × 288 pixels (CIF) 176 × 144 pixels (QCIF)
Video coding protocols	MPEG-4; M-JPEG
Audio coding protocol	G.711; 300 Hz to 3.4 kHz
Network protocols	RTP, Telnet, UDP, TCP, IP, HTTP, IGMP, ICMP, ARP, SNMP
Video input	1 × BNC jack 0.7 ... 1.2 V _{pp} , 75 Ohm switchable, PAL/NTSC
Video output	1 × BNC jack 1.0 V _{pp} , 75 Ohm, PAL/NTSC
Audio input	1 × push-in terminal 1.0 V _{pp} , 50 kOhm, mono
Audio output	1 × push-in terminal 1.0 V _{pp} , 60 mW, min. 8 Ohm, mono
Data interfaces	1 × RS232/RS422/RS485, bidirectional, 9-pin Sub-D 1 × USB 1.1
Alarm input	2 × push-in terminal, max. activation resistance 10 Ohm
Relay output	1 × push-in terminal, 30 V _{pp} , 1 A
Indicators	3 LEDs (operating status, network connection, data transfer)

Operating conditions	Temperature 0 ... +50°C, relative humidity 20 ... 80%, non-precipitating
Approvals & certifications	CE; IEC 60950; UL 1950; AS/NZS 3548; EN 55103-1, -2; EN 55130-4; EN 55022; EN 55024; EN 61000-3-2; EN 61000-3-3; FCC 47 CFR Ch. 1, Part 15
Dimensions (w × h × d)	85 × 26 × 110 mm (sender) 85 × 26 × 107 mm (receiver)
Weight (without power supply)	approx. 300 g (sender) approx. 200 g (receiver)

Index

A

Active profile 42
Actuator 19
Alarm 76
Alarm input 19
Alarm inputs 89
Alarm IP address 50
Application Wizard 29
Audio connection 19
Audio signals 44, 74
Auto-connect 50, 77

B

Banner 63, 64
Brightness 41
Browser window 88

C

Camera ID 56, 79
Camera name 39
Cameras 18
Changes 33
Color depth 25, 87, 95
Color saturation 41
Communication speed 80
Configuration 67, 84
Connection 27, 89
Contrast 41
Contrast alarm 48

Control 56

Conventions 7

D

Data interface 18
Data rate 43
Data terminal 21
Date format 37, 71
Daylight savings time 38, 72
Defaults 44
Display stamping 39
DNS server 59, 82
Dome camera 18
Dual streaming 13, 41

E

Echo 21
Electromagnetic compatibility 8
Encoding interval 44
EPROM 66, 84, 105
Event messages 90
Expert Mode 28

F

False alarms 51, 53
Firewall 58, 81
FTP server 46, 47
Function test 68, 86

G

Gateway 58, 81

I

Identification 8

IGMP 61

Image resolution 93, 94

Installation 10

Installation location 17

Installation requirements 17

Installation Wizard 29

Interlaced video signal 44

Internal clock 38, 72

IP address 22, 58, 81

J

JPEG format 46

JPEG posting 46

JPEG posting interval 47

L

Language 37, 71

Live video images 25, 89

Live video sequence 89

Livepage 63

Loudspeaker 20

Low Voltage Directive 8

M

Main functions 15

Mains switch 20

Maintenance 10

Monitor 18

Monitor name 73

Monitor resolution 87, 95

Motion alarm 48

MPEG-ActiveX 25, 87, 95

MPEG-sequence 94

MTU 58, 81

Multicast 60

Multicast connection 58, 60, 81

Multicast function 13

Multi-unicast 60

N

Name 35, 69

Navigation 32

Network 19, 57, 80

Network connection 20

Normally open contact 19

O

Operation 9

P

Parameters 23

Password 50, 77, 89

Password protection 36, 70

Peripheral device control 91

Picture quality 60

Power supply 9

Profile configuration 43

Profile name 43

Profiles 42

Protocol 57, 80

R

Receiver 13

Regulations 7
Relay 54, 77, 90
Relay output 19, 54, 77, 90
Remote control 14
Repair 10
Restart 23
Router 61

S

Safety 9
Save picture 93
Setup 11
SNMP 48, 75
Specifications 114
Subnet mask 81
Symbols 7
Synchronous 37, 71
System messages 90

T

TCP 58, 81
Test 68, 86
Time 38, 72
Time server 38, 72
Time Server Protocol 38, 72
Time signal 38, 72
Time zone 38, 72
Transmission disturbances 73
Transmission parameters 21
Transmission rate 56
Trigger relay 55, 79
TTL 61

U

UDP 58, 81
Unicast 60
Unit name 35, 69
Update 66, 83
Upload file 66, 84, 105
URL 26, 88, 96
User name 36, 70, 89

V

Version 62, 83
Video loss alarm 48
Video output standard 73
Video quality 43
Video resolution 44
Video sensor 50
Video sequence 94

W

Watermarking 40
Wizard 28, 29



VCS Video Communication Systems AG
Forchheimer Str. 4
90425 Nuremberg, Germany

Phone: +49 911 93456-0
Fax: +49 911 93456-66
E-mail: info@vcs.com
<http://www.vcs.com>

ID No.: 2010/0205/e/1