

Uniden | A World Without Wires[®]

**UNIDEN
CORDLESS
PHONES**



DCX750

OWNER'S MANUAL

Welcome

Congratulations on your purchase of the Uniden DCX750 accessory handset and charger. You can place this fully featured cordless handset anywhere your home has AC power.

Note: Illustrations in this manual are used for explanation purposes. Some illustrations may differ from the actual unit.

Accessibility

Uniden provides a customer service hotline for accessibility questions. If you have a disability and need customer service assistance or if you have any questions about how Uniden's products can accommodate persons with disabilities, please call the accessibility voice/TTY line: 1-800-874-9314.

A representative is available to talk to you M-F, 8:00 am to 5:00 pm, CST. After hours, you can leave us a message, and we will call you back. Information is also available on our website, www.uniden.com, under the "Accessibility" link.

Important!

The DCX750 accessory handset will not operate until it is registered to a Uniden main base. This manual describes how to set up your new handset; for more detailed instructions on operating your new handset, please refer to the manual supplied with your base.

Terminology Used in this Manual

Base	The main part of the phone that connects to your phone line and lets you make and receive calls.
Charger	A cradle that charges an accessory handset. It connects to power but not to a phone line.
Accessory Handset	A handset that works with an expandable phone base. Accessory handsets must be registered to a base.
Standby	The handset is not in use. If it is off the cradle, no line has been activated. No dial tone is present.
Station	Any handset or the base.
Talk	A telephone line has been activated on the handset or the base, enabling a dial tone.

Uniden® is a registered trademark of Uniden America Corporation.

Compatible Bases

This handset is compatible with Uniden's 2.4 GHz Digital Expandable phone system: the DCT756/DCT758 series, the DCT746/DCT748 series, the DMX776/778 series, and the DCT646/DCT648 series. Visit www.uniden.com for the most up-to-date list of compatible bases.

Installing the Accessory Handset

Checking the Package Contents


Make sure your package contains the following items. If any items are missing or damaged, contact our Customer Service Hotline. See back cover page for contact information.

- Cordless Handset
- Charging Cradle
- AC Adapter, model # AD-0005
Input: 120V AC 60 Hz
Output: 9V DC 210 mA
- Rechargeable NiMH Battery Pack, model # BT-1004
Capacity: 500 mAh, 3.6V
- Beltclip
- Printed Material

Installing the Battery

Follow the steps below to install the rechargeable battery pack.


1. Using the finger indentation, press in on the battery case cover and slide it down to remove it.
2. Plug the battery connector into the battery compartment jack. Be sure to match the red and black wires to the label near the jack.
3. Gently pull on the battery wires. If the battery connector comes loose, try connecting it again.
4. Replace the battery case cover and slide it up until it clicks into place.



Note: Use only the Uniden BT-1004 rechargeable battery pack supplied with your cordless telephone.


Installing the Belt Clip

Line up the tabs with the holes on each side of the handset. Press the belt clip down until both tabs click into place. To remove the belt clip, pull both sides of the clip to release the tabs from the holes.



Installing the Optional Headset

Your phone may be used with an optional headset. To use a headset, insert the headset plug into the headset jack. Headsets may be purchased by calling the Uniden Parts Department. See back cover page for contact information.




Charging the Accessory Handset

The handset is powered by a rechargeable battery pack that automatically recharges when the handset is placed in the charger.

1. Connect the AC adapter to the **DC IN 9V** jack and to a 120V AC outlet that is not controlled by a wall switch.

Caution: Use only the Uniden AD-0005 adapter.



2. Set the charger on a desk or tabletop, and place the handset in the charger with the keypad facing forward.
3. Make sure that the **charge** LED illuminates. If the LED does not illuminate, check to see that the AC adapter is plugged in and the handset makes good contact with the charging contacts on the charging cradle.
4. Charge the handset battery pack for at least 15-20 hours before using your new handset for the first time.

Registering the Handset

You must register the handset to the base before you can use it. Only one handset can be registered at a time. (If an accessory handset has ever been registered to a base, you must reset the handset before you can register it to a new base.)


Note: The model number for your telephone base is located on the bottom of main base unit.

For DCT75 Series Bases (DCT756, DCT756S, DCT758, DCT758S)

To register to a DCT75 series base, place the accessory handset in the base. While the handset is registering, **HANDSET REGISTERING** appears in the LCD. When **REGISTRATION COMPLETE** is displayed, the handset has been registered to the base. If **REGISTRATION FAILED** appears, remove the handset from the base and try again.

For Other Base Models

1. Select your base model from the list and follow the directions:



MODEL	DIRECTIONS:
DCT646 DCT746	Disconnect the base AC adapter. Press and hold [find handset] while you reconnect the adapter.
DCT646S DCT648S	Disconnect the base AC adapter. Press and hold [intercom] while you reconnect the adapter.
DCT648	Disconnect the base AC adapter. Press and hold [intercom/find handset] while you reconnect the adapter.
DCT748	Disconnect the base AC adapter. Press and hold [find hs/▶▶] and [◀◀] while you reconnect the adapter.
DCT748S	Press the MENU soft key. Scroll down to HS REGISTRATION and press the OK soft key.
DMX776 DMX778	Press and hold the registration button on the bottom of the base until the base LEDs start blinking.

2. On the handset, press and hold **[#/→]** until you hear a beep and see **HANDSET REGISTERING** in the display.
3. When **REGISTRATION COMPLETE** is displayed, the handset has been registered to the base. If **REGISTRATION FAILED** appears, please try these steps again.

Resetting the Handset

If you want to register the handset to a different base or replace a handset with another one, you must first clear the registration information from the base and the handset.

1. Press and hold **[j]** and **[#/>]** for at least 5 seconds, until the **SYSTEM RESET** menu appears.

Which Handset?	
▶ Handset	#1
Handset	#2

2. Select the **DEREGISTER HS** submenu by pressing **[select/☑]**. **WHICH HANDSET?** appears in the display.
3. Use **[△]** or **[▽]** to select the handset ID to be de-registered from the list, and then press **[select/☑]**. **DEREGISTER HS** appears.
4. Press **[△]** to move the cursor to **YES**, and then press **[select/☑]**. You will hear a confirmation tone.


Resetting the Handset Without the Base

If the original base this handset was registered to is not available for some reason (for example, it is lost or somehow incapacitated), you can still reset the handset and use it with another base.

1. Press and hold **[j]** and **[#/>]** for more than 5 seconds.
2. Press **[▽]** to move the cursor to **REPLACING BASE** and then press **[select/☑]**. **REPLACE BASE** appears.
3. Press **[△]** to move the cursor to **YES**, and then press **[select/☑]**. You hear a confirmation tone, and the handset deletes its own link to the base without trying to contact the base.
4. Register the handset to the new base.

Using the Interface








Parts of the Handset



- | | | |
|-------------------------------------|---------------------|-----------------------|
| 1. Antenna | 9. [menu/clear] | 16. [△] (up) |
| 2. Headset jack cover | 10. [redial/pause] | 17. [⏏] (end call) |
| 3. Beltclip hole | 11. [⏏/flash] | 18. [ID] (Caller ID) |
| 4. Speaker phone speaker and ringer | 12. [☎] (phonebook) | 19. [▽] (down) |
| 5. Battery compartment | 13. [*/tone/<] | 20. [#>] (pound) |
| 6. New message LED | 14. [xfer/intercom] | 21. [🔊] (speaker) |
| 7. Earpiece | 15. [select/✉] | 22. Microphone |
| 8. LCD display | (select/messages) | 23. Charging contacts |


Reading the Display

The handset display uses icons to tell you the status of your phone. The table below lists the icons and what they mean.

ICON	STATUS	DESCRIPTION
	Standby/ Talk	The battery icon indicates the handset battery status: full, medium, low, and empty.
	Standby	The ringer off icon indicates that the ringer is turned off.
	Talk	The mute icon appears when you mute the handset.
	Talk	The call record icon appears while recording a conversation.
	Talk	The boost icon appears when the Clarity Boost feature is activated.
	Talk	The speaker icon appears when the handset speaker phone is in use.
	Talk	The privacy icon appears when Privacy Mode is turned on.


The Standby Screen

When the phone is in standby, the display shows the following:



Using the Four-way Function Key

Your handset has a four-way function key that allows you to move the cursor or pointer on the display and access the most commonly used features at the touch of a button. Press the left side of the key to open the phonebook. Press the right side to open the Caller ID list.



To use this four-way key, place your thumb over the key on the handset and move to the four positions to get the feel of how it moves and operates.

Using the Handset Menus

To open the menu, press **[menu/clear]**. Select the option you want by pressing the four-way function key. This will move the cursor; the option currently selected has a triangle beside it. Activate the selected option by pressing **[select/☑]**. To exit the menu and return to standby, press **[⏏]**.

If you do not press a key within 30 seconds, the phone will time out and exit the menu. When setting the date and time, the time-out period is extended to two minutes.

Making and Receiving Calls

	With the earpiece	With the speaker phone
Make a call	1.Remove the handset from the charger. 2.Dial the number. 3.Press [⏏/flash] .	1.Remove the handset from the charger. 2.Dial the number. 3.Press [🔊] .
Answer a call	1.Pick up the handset.* 2.Press [⏏/flash]**	1.Pick up the handset.* 2.Press [🔊] .
Hang up	Press [⏏] or return the handset to the cradle.	Press [⏏] or return the handset to the cradle.

* If AutoTalk is on, the phone answers when you remove the handset from the charging cradle.

** If Any Key Answer is on, you can press any key in the twelve-key pad.

Using Caller ID and Call Waiting

If you subscribe to Caller ID, you can store up to 100 Caller ID records. Your phone shares memory between your phonebook and Caller ID entries. If you have 100 phonebook entries, Caller ID records won't be saved (but will display when the call comes in).

Press **[📞ID]** to open the Caller ID record list. The first thing you will see is the summary screen. From the summary screen, you have the following options:

Scroll through the records	To scroll through the records from A to Z, press [▽]. To scroll through the records from Z to A press [△].
Jump to records that start with a certain letter	Press the number key corresponding to the letter you want to jump to.
Store a record in the phonebook	Find the record you want to store and press [select/✉].
Dial a record	Find the entry you want to dial and press [(/flash) or [⏏].
Delete a record	Find the entry you want to dial and press [menu/clear].
Delete all records	Press [menu/clear].
Exit the Caller ID list	Press [⏏] or press [(ID) again if you are on a call.

Using Call Waiting

If you subscribe to call waiting, a tone sounds if a call comes in when you are on the phone. If you subscribe to Caller ID on call waiting, the Caller ID information of the waiting call appears on the display. Press [(/flash) on the handset to accept the waiting call. After a short pause, you will hear the new caller. To return to the original caller, press [(/flash) on the handset again.

Redialing a Number

To redial one of the last 3 numbers dialed on this handset, press [redial/pause] when the phone is in standby. This opens the redial list. Use [△] and [▽] to find the number you want to dial, and press [(/flash) or [⏏]. (You can also press [(/flash) or [⏏], and then [redial/pause] to redial the last number dialed.)

Using the Phonebook

You can store up to 100 names and numbers in the phonebook. Your handset shares memory between your phonebook and Caller ID entries. When all the phonebook entries are full, you will hear a beep and MEMORY FULL appears. You cannot store any additional names and numbers unless you delete some of the existing ones.

Press [⏏] to enter the phonebook. Once in the phonebook, you have the following options:

Scroll through the entries	To scroll through the phonebook from A to Z, press [▽]. To scroll through the phonebook from Z to A press [△].
Jump to entries that start with a certain letter	Press the number key corresponding to the letter you want to jump to.
Store a new entry	Move the cursor to STORE NEW, then press [select/✉].
Copy entries to another handset	<ol style="list-style-type: none"> 1. Move the cursor to COPY and press [select/✉]. 2. Select the handset you want to copy the entries to and press [select/✉]. 3. Select ONE MEMORY or ALL MEMORY and press [select/✉]. 4. If you choose ONE MEMORY, find the entry you want to copy and press [select/✉].
Dial an entry	<ol style="list-style-type: none"> 1. Move the cursor to DIAL/EDIT and press [select/✉]. 2. Find the entry you want to dial. 3. Press [⏏/flash] or [⏏].
Delete an entry	<ol style="list-style-type: none"> 1. Move the cursor to DIAL/EDIT and press [select/✉]. 2. Find the entry you want to delete. 3. Press [menu/clear].
Delete all entries	Move the cursor to DELETE ALL and press [select/✉].
Close the phonebook	Press [⏏] or press [⏏] again if you are on a call.

Adjusting the Volume

Ringer Volume	Choose from three ringer volume settings (off, low, and high). With the phone in standby, use [△] and [▽] to adjust the ringer volume.
Earpiece Volume	Choose from six volume levels for the earpiece. While on a call, press [△] to make the earpiece volume louder or [▽] to make it softer.
Speaker Volume	Choose from six volume levels for the handset speakerphone. While on a call, press [△] to make the speaker volume louder or [▽] to make it softer.


Hold, Conference, Transfer, and Intercom

Put a call on hold	Press [xfer/intercom] . If you leave a caller on hold for more than five minutes, the call will be disconnected. To return to the party on hold, press [/flash] or [] .
Join an in-progress call	To join a call already in progress, press [/flash] or [] . You can hang up normally; the other station remains connected to the call.
Transfer a call	Press [xfer/intercom] ; the call is placed on hold. Use [△] or [▽] to select the station you want to transfer the call to, and press [select/] . (To page all stations at once, select ALL.) When the other station answers, you can talk to the station; the outside call remains on hold. If the other station accepts the call, you will be disconnected.
Cancel a transfer	To cancel the transfer and return to the call, press [/flash] or [] .
Accept a transferred call	To answer the transfer page and speak to the transferring station, press [/flash] or [xfer/intercom] . To accept the call and speak to the caller, press [/flash] again.
Make an intercom page	With the phone in standby, press [xfer/intercom] . Use [△] or [▽] to select the station you want to talk with, then press [select/] . (If you select ALL, all other stations will be paged.)
Cancel a page	To cancel the intercom page, press [] .
Answer an intercom page	Press [/flash] or [xfer/intercom] . If AutoTalk is on, the handset automatically answers the page when you remove it from the cradle.

Muting the Ringer (One Call Only)

While the handset is ringing, press **[]** to mute the ringer for this call. The phone will ring again on the next call. (The handset must be off the cradle to mute the ringer.)

Muting the Microphone

To mute the microphone so the caller can't hear you, press **[menu/clear]**. Move the cursor to select MUTE and then press **[select/☑]**. MUTE ON and  appear in the display. Repeat the procedure to cancel muting.

Privacy Mode

To prevent other stations from interrupting a call, press **[menu/clear]**. Move the cursor to select PRIVACY MODE and then press **[select/☑]**. PRIVACY MODE ON and P appear in the display. Repeat the procedure to turn off privacy mode.

Adjusting the Audio Tone

If you aren't satisfied with your phone's audio quality, you can adjust the Audio Tone of the earpiece. While on a call, press **[select/☑]** to cycle through the three audio tone options: low, natural and high. (The default setting, Natural Tone, is recommended for hearing aid users.) When the desired option appears on the display, stop. After two seconds, the displayed audio tone is set, and the display returns to normal.

Using the Clarity Boost Feature

If you encounter interference while you are on a call, you can manually improve the sound by turning on the clarity boost feature. Press **[menu/clear]**, move the cursor to select CLARITY BOOST, and then press **[select/☑]**. BOOST ON and B appear in the display.

Use the same procedure to turn off clarity boost feature, BOOST OFF appears.

Accessing Your Answering Machine

If your base has an answering machine, you can use your handset to get your messages and change your answering machine setup. To access the answering machine, press **[select/☑]**. The answering machine announces the number of new and old messages and then wait for your next command. You have the following options:

Play messages	Press [> /2]. The system plays the message then announces the time and date the message was received.
Repeat a message	Press [<< /1] to go to the start of the current message. Press [<< /1] repeatedly to go back to a previous message.
Skip a message	Press [>> /3] to go to the beginning of the next message.
Delete a message	While a message is playing, press [⊗ /4]. The message is permanently deleted.
End message review	Press [□ /5] to stop the message playback.
Record a memo	Press [7] to start recording. Press [□ /5] or [7] to stop.
Turn the answering machine on or off	Press [6] to turn the answering machine on. Press [9] to turn it off.
Record a greeting	Press [8] to start recording. Press [□ /5] or [8] to stop.
Listen to Help	Press [0] to hear the Help prompts.
Exit and hang up	Press [⏏] to exit the system and return to standby.

Screening Calls

If your base has an answering machine, you can listen to callers as they leave a message. Press [**select/☑**] when the system is answering to listen to the caller without answering the phone.

Accessing Voicemail

If you subscribe to a voice mail service, you can program your handset to automatically dial the access number.

1. Press [**menu/clear**].
2. Move the cursor to HANDSET SETUP and press [**select/☑**].
3. Move the cursor to EDIT VOICE MAIL and press [**select/☑**].

4. Enter your access number (up to 20 digits). If you need the phone to wait before sending the next digits, press **[redial/pause]** to insert a two-second pause. For a longer pause, press **[redial/pause]** multiple times. Each pause counts as one digit.
5. Press **[select/☑]** when you are finished.

Once you program your access number, press **[select/☑]** to dial your voice mail service.

Maintenance

Battery Life

With average use, your battery talk time will be approximately 7 hours and standby time will be approximately 10 days. For optimum performance, be sure to return the handset to the cradle after each call. If the handset is left off of the charging cradle, the actual talk time duration will be reduced respective to the amount of time the handset is off the cradle.

Note:

Do not place the power cord where it creates a trip hazard or where it could become chafed and create a fire or electrical hazard.

Low Battery Alert

When the battery pack is very low, the display shows LOW BATTERY and the empty battery icon. If the phone is in standby, none of the keys will operate. If you are on a call, complete your conversation as quickly as possible, and return the handset to the charging cradle.

Battery Replacement and Handling

With normal usage, your battery should last about one year. If the talk time becomes short even after the battery is recharged, please replace the battery. You can purchase a replacement battery by calling Uniden's Parts department. See the back cover page for contact information.

Warning

To avoid the risk of personal injury or property damage from fire or electrical shock, use only the BT-1004 battery pack.


Caution:

- This equipment contains a rechargeable Nickel-Metal-Hydrate battery.
- Do not remove the batteries to charge them.
- Never throw the battery in a fire or disassemble or heat it.
- Do not remove or damage the battery casing.
- Nickel is a chemical known to state of California to cause cancer.
- Do not short-circuit the battery.
- Do not charge the battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charger may damage the battery or cause the battery to explode.
- Rechargeable batteries must be recycled or disposed of properly.

Clean the Battery Contacts

To maintain a good charge, clean the charging contacts on the handset once a month. Dampen a cloth with plain water. Gently rub the damp cloth over the charging contacts until all visible dirt is removed. Dry the contacts thoroughly before returning the handset to the charging cradle.

Caution: Do not use any chemical products (benzene, alcohol, paint thinner, etc.), or you may discolor the surface and damage the finish.



The FCC Wants You To Know

Changes or modifications to this product not expressly approved by Uniden, or operation of this product in any way other than as detailed by the owner's manual, could void your authority to operate this product.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this phone.

To insure the safety of users, the FCC has established criteria for the amount of radio frequency energy various products may produce depending on their intended usage. This product has been tested and found to comply with the FCC's exposure criteria. For body worn operation, the FCC RF exposure guidelines were also met when used with the Uniden accessories supplied or designed for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines and should be avoided.

I.C. Notice

Terminal Equipment

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is marked on the equipment itself. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

Radio Equipment

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. "Privacy of communications may not be ensured when using this telephone".

One Year Limited Warranty

Important: Evidence of original purchase is required for warranty service.

WARRANTOR: UNIDEN AMERICA CORPORATION ("Uniden") **ELEMENTS OF WARRANTY:** Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below.

WARRANTY DURATION: This warranty to the original user shall terminate and be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner's manual for this product.

STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. **THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void outside the United States of America and Canada. **PROCEDURE FOR OBTAINING**

PERFORMANCE OF WARRANTY: If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). Disconnect the battery from the Product and separately secure the battery in its own separate packaging within the shipping carton. The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor at:

Uniden America Service
4700 Amon Carter Blvd.
Fort Worth, TX 76155

At Uniden, we'll take care of you!

Thank you for purchasing a Uniden product. If you have any questions or problems, please do not return this product to the place of purchase.

Having trouble?	Our customer care specialists are here to help you! Visit our website at www.uniden.com or call our Customer Service Hotline at 1-800-297-1023, Monday through Friday, 7 AM to 7 PM or Saturday/Sunday, 9 AM to 5 PM, CST. The Customer Service Hotline is closed on holidays.
Need a part?	To order headsets, additional handsets, replacement batteries, or other accessories, visit our website at www.uniden.com or call 1-800-554-3988, Monday through Friday, 8 AM to 5 PM, CST.
Help for our customers with special needs	If you need special assistance due to a disability or have questions on the accessibility features of this product, please call 1-800-874-9314 (voice or TTY).

May be covered under one or more of the following U.S. patents:

4,797,916	5,426,690	5,434,905	5,491,745	5,493,605
5,533,010	5,574,727	5,581,598	5,650,790	5,660,269
5,661,780	5,663,981	5,671,248	5,696,471	5,717,312
5,732,355	5,754,407	5,758,289	5,768,345	5,893,034
5,787,356	5,794,152	5,801,466	5,825,161	5,864,619
5,912,968	5,915,227	5,929,598	5,930,720	6,253,088
5,987,330	6,044,281	6,070,082	6,125,277	6,253,088
6,314,278	6,418,209	6,618,015	6,671,315	6,714,630
6,782,098	6,788,920	6,788,953	6,839,550	6,889,184
6,901,271	6,907,094	6,914,940	6,953,118	7,023,176

Other patents pending.

**VISIT
WWW.UNIDEN.COM
TO REGISTER YOUR
PRODUCT**

© 2006 Uniden America Corporation, Fort Worth, Texas. Contains additional foreign articles. Printed in China.