



Visual Status Display

ENCORE/PRELUDE CONTROL SYSTEMS

Instruction Manual
Software Version 2.0



Affiliate with the N.V. KEMA in The Netherlands



CERTIFICATE

Certificate Number: 510040.001

The Quality System of:

Thomson Inc, and its worldwide Grass Valley division affiliates DBA GRASS VALLEY

Headquarters
400 Providence Mine Rd
Nevada City, CA 95959
United States

15655 SW Greystone Ct.
Beaverton, OR 97006
United States

10 Presidential Way
Suite 300
Woburn, MA 01801
United States

Kapittelweg 10
4827 HG Breda
The Netherlands

7140 Baymeadows Way
Ste 101
Jacksonville, FL 32256
United States

2300 So. Decker Lake Blvd.
Salt Lake City, UT 84119
United States

Rue du Clos Courtel
CS 31719
35517 Cesson-Sevigné Cedex
France

1 rue de l'Hautil
Z.I. des Boutries BP 150
78702 Conflans-Sainte
Honorine Cedex
France

Technopole Brest-Iroise
Site de la Pointe du Diable
CS 73808
29238 Brest Cedex 3
France

40 Rue de Bray
2 Rue des Landelles
35510 Cesson Sevigné
France

Spinnereistrasse 5
CH-5300 Turgi
Switzerland

Brunnenweg 9
D-64331 Weiterstadt
Germany

Carl-Benz-Strasse 6-8
67105 Schifferstadt
Germany

Including its implementation, meets the requirements of the standard:

ISO 9001:2008

Scope:

The design, manufacture and support of video and audio hardware and software products and related systems.

This Certificate is valid until: June 14, 2012
This Certificate is valid as of: June 14, 2009
Certified for the first time: June 14, 2000

H. Pierre Sallé
President
KEMA-Registered Quality

The method of operation for quality certification is defined in the KEMA General Terms And Conditions For Quality And Environmental Management Systems Certifications. Integral publication of this certificate is allowed.

KEMA-Registered Quality, Inc.
4377 County Line Road
Chalfont, PA 18914
Ph: (215)997-4519
Fax: (215)997-3809

Accredited By:
ANAB

Experience you can trust.



Visual Status Display

ENCORE/PRELUDE CONTROL SYSTEMS

Instruction Manual
Software Version 2.0

Contacting Grass Valley

International Support Centers	France 24 x 7	+800 8080 2020 or +33 1 48 25 20 20	United States/Canada 24 x 7	+1 800 547 8949 or +1 530 478 4148
Local Support Centers (available during normal business hours)	Asia	Hong Kong, Taiwan, Korea, Macau: +852 2531 3058 Indian Subcontinent: +91 22 24933476 Southeast Asia/Malaysia: +603 7805 3884 Southeast Asia/Singapore: +65 6379 1313 China: +861 0660 159 450 Japan: +81 3 5484 6868		
		Australia and New Zealand: +61 1300 721 495	Central/South America: +55 11 5509 3443	
		Middle East: +971 4 299 64 40 Near East and Africa: +800 8080 2020 or +33 1 48 25 20 20		
	Europe	Belarus, Russia, Tadzikistan, Ukraine, Uzbekistan: +7 095 2580924 225 Switzerland: +41 1 487 80 02 S. Europe/Italy-Roma: +39 06 87 20 35 28 -Milan: +39 02 48 41 46 58 S. Europe/Spain: +34 91 512 03 50 Benelux/Belgium: +32 (0) 2 334 90 30 Benelux/Netherlands: +31 (0) 35 62 38 42 1 N. Europe: +45 45 96 88 70 Germany, Austria, Eastern Europe: +49 6150 104 444 UK, Ireland, Israel: +44 118 923 0499		

Copyright © Grass Valley, Inc. All rights reserved.
This product may be covered by one or more U.S. and foreign patents.

Grass Valley Web Site

The www.grassvalley.com web site offers the following:

Online User Documentation — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

FAQ Database — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

Software Downloads — Download software updates, drivers, and patches.




END-OF-LIFE PRODUCT RECYCLING NOTICE

Grass Valley's innovation and excellence in product design also extends to the programs we've established to manage the recycling of our products. Grass Valley has developed a comprehensive end-of-life product take back program for recycle or disposal of end-of-life products. Our program meets the requirements of the European Union's WEEE Directive, the United States Environmental Protection Agency, and U.S. state and local agencies.

Grass Valley's end-of-life product take back program assures proper disposal by use of Best Available Technology. This program accepts any Grass Valley branded equipment. Upon request, a Certificate of Recycling or a Certificate of Destruction, depending on the ultimate disposition of the product, can be sent to the requester.

Grass Valley will be responsible for all costs associated with recycling and disposal, including freight. However, you are responsible for the removal of the equipment from your facility and packing the equipment to make it ready for pickup.



For further information on the Grass Valley product take back system please contact Grass Valley at + 800 80 80 20 20 or +33 1 48 25 20 20 from most other countries. In the U.S. and Canada please call 800-547-8949 or 530-478-4148, and ask to be connected to the EH&S Department. Additional information concerning the program can be found at: www.thomsongrassvalley.com/environment



Contents

Section 1 — VSD Introduction	7
Overview	7
VSD Features	8
Views	9
Current VSD Limitations	9
Section 2 — VSD Installation	11
Distribution	11
Requirements	11
Installing Using the VSD Installer	11
Installing with Encore/Prelude Software Installer	13
Uninstall	14
Section 3 — Encore VSD Configuration	15
Overview	15
Register VSD PC With Encore	16
Set VSD Related Parameters and Flags	21
Section 4 — Prelude VSD Configuration	23
Overview	23
Prelude NP Client/Server Configuration Procedure	23
Section 5 — VSD Operation	25
Connecting VSD to the Routing System	25
VSD License Key Registration	25
Toolbar Controls	27
Dropdown Menus	27
View	27
Edit	27
Actions	27
Settings	28
Show	28
Tools	29
Event Stacker	29
Help	29
Standard Icon Toolbar	29
Preferences Bar	30
Events Log	30
Bottom Status Bar	30
VSD Views	31
Views Supported by Encore and Prelude	31
New Views	31

Level Selection.	32
Column Widths.	33
Names and Aliases	33
Arranging and Sorting View Elements	33
Reloading System Views	34
Destination View	35
Source View.	36
Active Salvo View (Encore Only).	37
Tally Salvo View (Encore Only).	38
Tie Line View (Encore Only)	39
Rooms View (Encore Only).	40
Assignment View (Encore Only)	41
Monitor View	42
Event Stacker.	43
Customizing VSD Views.	45
Application Preferences.	45
View Preferences.	46
Color Settings.	47
Font Settings	47
Visual Status Display Instruction Manual	47
Index	49

VSD Introduction

Overview

The Visual Status Display (VSD) application shows the current status of the Source-to-Destination connections of an Encore or Prelude routing system. VSD information is updated automatically. For example, when a Destination's routing changes, if that Destination is currently displayed its status will be updated within five seconds. In addition, on Encore systems the VSD screen can automatically update if an Encore router configuration is modified (for example, changes in the names of existing Sources or Destinations). On Prelude systems VSD automatically updates Source and Destination names whenever the application connects.

The VSD application runs on Windows operating systems. The PC running VSD needs to be connected to the router network. With Encore systems, VSD acts as an RCL client, so the PC running VSD needs to be registered with the Encore system and have access to the Sharer to be operational. On Prelude systems VSD acts as a client for an NP Server configured on a Prelude control panel.

VSD supports fail-over redundancy. On Encore systems redundancy uses a mirrored Panel Server. If the Master Panel Server fails, VSD establishes a connection with its Mirrored Panel Server. On Prelude systems redundancy is accomplished using NP Servers configured on two control panels.

VSD is an option that is registered by entering a license key, obtained from Grass Valley Customer Service. The license key is valid for only a specific PC, and only one VSD instance can run on that PC at a time. An unregistered VSD operates in trial mode, which limits the maximum number of elements supported per View to five. Two types of VSD license are available, a basic licence that excludes the Event Stacker, and a full license that includes Event Stacker.

VSD Features

The VSD application has the following capabilities:

- Eight different system views (see [Views](#) below).
- Event Stacker, which allows programming and executing time-scheduled tasks (Takes, Protects, Unprotects, Salvos, Assignments, Deassignments, and Monitor Takes). Encore systems only, and requires a full license.
- Display of names, or alias names, or both.
- Sorting by names.
- New Destination, Source and Tie Line names can be inserted anywhere in already created view screens.
- Cut, Copy and Paste operations are supported where appropriate.
- Multiple columns of Destinations can be displayed (useful in systems with many Destinations and few Levels).
- An optional Comments column is available for each view type.
- Chop feature status reporting is supported.
- Display font type and size can be configured.
- The VSD can retain its last connection state.
- Fail-over redundancy.
- An Events Log is available, to observe the connected Panel Server's operations.
- Dynamic Audio Attribute feature status reporting is supported (Encore systems only).

Views

Large routing systems can have many Destinations and complex paths, making it impossible to see the status of the entire system on a single screen. VSD permits grouping subsets of the system into Views. Different Views can be created to quickly display the current status of various portions of the system. The types of Views available include:

- Destination View (Encore and Prelude systems)
- Source View (Encore and Prelude systems)
- Active Salvo View (Encore systems only)
- Tally Salvo View (Encore systems only)
- Tie-Line View (Encore systems only)
- Rooms View (Encore systems only)
- Assignment View (Encore systems only)
- Destination Monitor View (Encore systems only)

The VSD limits its view capability automatically based on the type of control system it is connected to.

Current VSD Limitations

- The Event Stacker does not support scheduling a re-occurrence event.
- The Event Stacker does not tally the result of RCL Server events.
- On Prelude systems, if more than one VSD application is connected, any deleted, modified or newly created Views will not be shared by the running VSC applications. To synchronize this information a VSD application must be closed and restarted. On Encore systems, Views are dynamically shared with other connected VSD applications.
- Prelude systems require the use of at least one hardware control panel (not Soft Panels) to act as an NP server for VSD operations.
- Cut, Copy, Paste operations are not available in all Views.

VSD Installation

Distribution

The VSD application is included on the Encore and Compact Router Control System software CDs, and is available for download from the Grass Valley Support web site.

Requirements


VSD runs on a customer supplied PC running Windows 2000, Windows XP, or Windows 7. The PC you use must be a node on the router network, so it will need to be configured with appropriate IP addresses.

Installing Using the VSD Installer

1. If you have not already done so, configure the PC with IP addresses appropriate for your Encore or Prelude network.
2. Physically connect the PC's Ethernet port to the router network.
3. Acquire the VSD software. It can be downloaded from the web onto any convenient media (hard disk, thumb drive, or burned to CD).
4. Quit any applications running on the PC. You may want to reboot the computer to ensure all processes (including Port Mapper) have quit.
5. Access the **VSD** directory and run **Setup.exe**.


- The VSD install program will launch and a Use with Encore window appears (Figure 1).

Figure 1. Use With Encore Window



- Select **Yes** if you plan to use VSD with an Encore system. Later you will be asked for the IP address of the Sharer network.
 - Select **No** if you will be using VSD only with a Prelude system.
- A Welcome to VSD window then appears. Click **Next**, accept the license agreement, and follow the on-screen instructions (Figure 2). Default settings are recommended.


Figure 2. VSD Installation Screens



Installing with Encore/Prelude Software Installer


A check box for VSD is available during an Encore or Prelude control system software installation process. You can choose to install VSD on the PC along with the control system software if you wish, or you can select only that checkbox to install just VSD (Figure 3 and Figure 4).

Figure 3. Encore Installer Checkboxes



Note The VSD can be installed along with the Encore software. Installation at a later time with applications open may result in a **Cannot update Port Mapper** error message. If this occurs, use Task Manager to halt only the Port Mapper.exe application, and then install VSD.

Figure 4. Prelude Installer Checkboxes



When selected, the VSD installer (as described earlier) will launch.

Uninstall

The **UnWise.exe** file, installed by default into the Program Files/Grass Valley Group/VSD, folder can be used to uninstall the VSD application from the PC. User data, including licensing, is not deleted by this uninstall process and becomes available if the VSD program is re-installed.

Encore VSD Configuration

Overview

The Encore system will not recognize the VSD until the IP address of the PC running the VSD application is registered.

Note If the PC has already been registered with the Encore system you will not need to do this registration procedure.


The following procedure assumes an Encore OUI has already been installed onto the PC and the necessary applications have been configured. If this is not the case, refer to the *Encore Release Notes* and/or *Encore Configuration Manual* for specific instructions.

Register VSD PC With Encore

You will need Encore System Administrator privileges to do this registration procedure.


1. Launch the Encore OUI and login as System Administrator. Default is user SYS with no password. When logged in a screen similar to [Figure 5](#) will be displayed.

Figure 5.




2. Click on a blank button on the lower application bar and select a **Control Panel Server** from the pop up menu. The Control Panel Server application screen will be displayed (Figure 6).

Figure 6.



3. Click on the **RCL Servers** button on the lower right to display the next screen (Figure 7).


Figure 7.



4. In the right Ethernet pane, click on a number to select an item to configure. An arrow will be displayed next to the number.
5. Click on the first field and enter a name for the PC you wish to register.

- Click on the second IP field and enter the IP address of the PC you will run VSD on (Figure 8).


Figure 8.



- The new setting will be saved automatically, with no need to Modify or Save the change.

8. If you need to connect multiple clients at the same time from the same PC, (for example, both VSD and Salvo Editor) click **Flags and Parameters** and click the **Multiple Conn** flag so it is green (Figure 9). If this flag is not enabled, when the other client connects the existing client will be dropped.

Figure 9.



Note VSD requires a Protocol Type of either the default **Auto Select** (recommended) or **RCL Protocol**.

9. Click **Main** and disconnect the Panel Server application.

The VSD application will now be recognized by the Encore system when it is launched and connected to the Encore Panel Server. Initially it will operate in Trial mode (limited to 5 items per View). License registration enables the VSD application

Set VSD Related Parameters and Flags

To obtain statuses for all Encore system entities, ensure none are excluded.

- Make sure the Src Category Set is **AllSrcs**. VSD reports statuses of excluded Sources as **<Undef>**.
- Make sure the Salvo Exclusion Set is **AllSvos**. VSD will not be able to select excluded Salvos for status reporting.

If changes are made to the RCL Server Flags and Parameters for a connected VSD, you will need to disconnect and reconnect that VSD instance to activate the changes.

Prelude VSD Configuration

Overview

On a Prelude system the VSD application operates as a client to an NP server configured on a Prelude control panel. Once configured, VSD connects over the network to the control panel to receive Prelude system status information.

The VSD client/server configuration process for Prelude involves several steps.

- A VSD client configuration, which includes the IP address of the PC running VSD, is created and saved on the Prelude system.
- The client configuration is assigned to an NP server of a Prelude control panel configuration, saved, and sent to that panel.
- The VSD application connects using the IP address of the Prelude control panel with the configured server, and so gains access to Prelude system information.


Note The VSD NP server must be configured on a hardware control panel. Soft Panels do not support client connections, even if a configuration containing an NP server is sent to the Soft Panel.

Refer to the separate *Prelude Instruction Manual* for more detailed information.

Prelude NP Client/Server Configuration Procedure


1. In Prelude, open a configuration file for the control panel you wish to use as the VSD server. Click on the **NP Server Configuration** button to open a configuration window. Right click on a **Client Name** field in one of the columns and select **New** to create a new client configuration ([Figure 10](#)).

Figure 10. NP Server Configuration Window



2. In the NP Client Configuration window that opens, enter a name for the VSD client, the IP address of the PC that will be running VSD, and then **Save** the client configuration file (Figure 11).

Figure 11. NP Client Configuration Window



3. The NP Server Configuration window will now show that client configuration assigned to that panel server. **Save** the server configuration for that panel.
4. Click **Send Panel Config to Control Panel**, select the control panel you wish to use as the server, and click **Send**.

The PC running VSD will now be able to connect to that Prelude control panel using the panel's IP address and gain access to the Prelude system.

VSD Operation


Connecting VSD to the Routing System



When the routing system has been configured to support VSD, you will be able to connect VSD to the system.

If the VSD program launches into a disconnected state, clicking on the Connect button opens a window allowing entry of the IP address of the Encore SCB or Prelude control panel you wish to connect to (Figure 12).

Figure 12. VSD Connect Window



If the program is unable to connect to the primary server, it will attempt to connect to the backup server (if one was specified). If this second connection attempt also fails, an error message will be displayed and the VSD application will not be operational.

On successful connection a Level Selection window appears (Figure 19 on page 32), allowing you to select the Levels to be displayed on the screen.

VSD License Key Registration

The VSD will operate in Trial Mode until a valid license key is entered. Trial Mode is fully functional, but limits to five the maximum number of elements in each View.

Two levels of licensing exist. Both versions remove the five element maximum, but the Full license is required to activate the Event Stacker feature.

Each license key is valid for an individual PC, and is generated based on the Device ID of that specific PC. You will need to determine the Device ID of your PC and provide that exact number to Grass Valley Sales. They will then generate the key and send it to you. Entering this key into the VSD will activate full functionality on that PC.

The complete procedure to register your VSD involves the following steps:


1. Click on the VSD desktop icon. If not licensed the following prompt message appears (Figure 13).

Figure 13.



2. Click **OK**. A blank VSD screen will be displayed. Click on **Help/Enter License Key** and note the Device ID displayed (Figure 14).

Figure 14.



3. Contact Grass Valley Sales by email or phone (refer to the back of the title page of this manual for the current contact methods) and provide the exact Device ID number. After your purchase has been confirmed, a License Key will be generated and sent to you.
4. Enter the license key text exactly (including dashes) in the field displayed and click **Submit**. If the key is entered correctly and matches the Device ID it will be accepted and the following valid key message will be displayed (Figure 15).

Figure 15.



5. Click **OK**. Your copy of VSD is now fully operational (allows unlimited elements your Views). If no license key is entered or the license key is invalid, the VSD application will operate in trial mode.

Toolbar Controls

Dropdown Menus

The dropdown menu items follow Windows OS conventions, with some additional application specific functions.

View

New - Presents a sub-menu listing types of Views that can be created. Selecting a View type creates a new **Noname** View of that type.

Open - Presents a sub-menu listing types of Views. Selecting a View type opens a window of those existing Views. Selecting a View loads it into the spreadsheet.

Save - Saves the currently loaded active View with its current name.

Save As... - Opens a window that allows saving the active View under the same or a new name.

Close - Closes the active View.

Close All - Closes all currently loaded Views.

Exit - Exits the VSD application.

Edit

Cut, Copy, Paste - Standard clipboard style editing controls.

Levels - Opens a window allowing selection of the Levels to be displayed in the active View.

Actions

Connect - Opens a window allowing entry of the IP address of the server VSD will connect to.

Disconnect - Disconnects VSD from the server.

Reload System Views from Sharer - Loads Views from the Encore Sharer (Encore systems only).

Delete - Opens a window allowing the selection of existing Views to be deleted.

Note On Encore systems, use this control to delete Views. The Encore OUI Filer should not be used for this purpose, unless you also use the Encore System Manager OUI to delete the Views from the dustbin. Views in the dustbin prevent new Views with the same name from being saved to the Sharer. See the separate *Encore Configuration Manual* for more information.

Settings

Preferences - Provides access to the **Application Preferences** screen, for changing application features, and the **View Preferences** window allowing changes to VSD spreadsheet colors and other settings.

Font Settings - Opens a window allowing the selection of the font, font style, and size to be used in the VSD spreadsheet.

Show

Toolbars

Standard - Shows or hides the standard icon controls at the top of the screen.

View Preferences - Shows or hides the preferences bar at the top of the screen.

Status Bar - Shows or hides the bottom status bar.

Full Screen - Enlarges the active window by hiding the toolbars.

Show Area Aliases - Appends the Area Alias names in front of Source and Destination names (Encore systems only).

Auto-Fit Columns - Controls whether columns will automatically resize to fit the contained text.

Show Names - Displays Destinations and Sources by name (the default setting).

Show Alias - Displays Destinations and Sources by alias, adding extra columns if **Show Names** is also selected.

Note If both **Show Names** and **Show Alias** are turned off, names will be displayed.

Destination Columns - In Destination View, allows display of up to eight columns of Destinations.

Events Log - Enables a resizable sub-window at the bottom of the screen that reports router activity (Takes, Protects, etc.).

- Connect to Server
- Disconnect from Server
- Open Preferences Window
- Font Settings
- Zoom Spreadsheet Display Size
- Open Event Stacker

Preferences Bar

When View Preferences is selected, controls are available for Show Alias, Show Names, and Destination Columns (Figure 16).

Events Log

When **Events Log** is selected, a resizable window is available to view router activity (Figure).

Figure 17. VSD Events Log and Status Bar

Date & Time	EventType	Description
22Apr2010 14:52:40.08	Take	TechPub:ASrc10 has been taken on to RtSW:RD_1 on Primary; levels by KenS
22Apr2010 14:53:40.09	Take	TechPub:ASrc11 has been taken on to RtSW:RD_2 on Primary; levels by KenS
22Apr2010 16:15:44.07	Take	RtSW:RS_11 has been taken on to RtSW:RD_3 on Primary; levels by KenS
22Apr2010 16:16:44.07	Take	RtSW:RS_12 has been taken on to RtSW:RD_4 on Primary; levels by KenS

Ready Connected to Encore V1.8.0a6 Server - '10.16.22.127' Sharer is pr

A text file of the log activity is saved locally during VSD operation, in the Event Log folder inside the VSD application folder. Each file is named with date, in day month year format (i.e. 02-06-2010.txt).

Clicking **View, Open, Event Log** opens a window allowing you to select a log file to open into a Notepad window.

Bottom Status Bar

A status bar (if selected in the Show dropdown) is located at the bottom of the VSD screen (Figure).

The statuses reported, from left to right, are:

- Current activity status of the VSD application, including any error messages.

Note Error messages are displayed as they are received, and may not be cleared by subsequent successfully performed events.

- Server connection status, including IP address of the connected server.
- Sharer availability status (Encore systems only).

VSD Views

Views are status displays of subsets of Encore system crosspoints. Different Views can be created and saved for reuse. VSD Views can be stored as System Views in the Sharer (on Encore systems) as well as on the local PC on which the VSD is running. Tally Salvo Views for system salvo individual elements are read only and cannot be saved.

Each type of View (Destination View, Source View, etc.) is identified at the top of the screen, followed by the name of the currently selected View. Color coded tabs with the name of the View are also displayed at the bottom of the screen, allowing quick access to any loaded View. The default View is titled **NoName1**. Subsequent newly created Views initially have that name with the trailing number.


Views Supported by Encore and Prelude

Encore control systems support all VSD Views and the Event Stacker. Prelude systems support only Destination and Source Views, and do not support the Event Stacker.

New Views

New Views will appear as a blank spreadsheet. You select which items (destinations, sources, tielines, etc.) you wish to see status for by double clicking on an item's column. A window will appear listing the available items. Clicking on one or a series of items will load them into the View. You can restrict the list to show items in an individual Area with the **Select an Area** dropdown list ([Figure 18](#)).


Figure 18. Adding Destinations



Level Selection

You can select which levels will be displayed on the screen, with the **Edit / Levels** dropdown menu. A list of the available Levels is displayed (Figure 19).

Figure 19. Level Selection Window



When the **Applicable** box is checked (the default setting), each View will open with only the defined Levels.


Column Widths

The width of the columns on the screen can be adjusted by dragging the cursor on the margin at the top of each column. Column widths can also be automatically adjusted to the size of the text with the **Show / AutoFit Columns** setting.

Names and Aliases

Items can be listed by name, by alias, or both, using the checkboxes in the View Preferences toolbar that can appear above the spreadsheet (Figure 20). If neither box is checked, names will be used (the default). The selection applies to all Views except Tally Salvo View. Alias name display is not supported by Prelude systems.


Figure 20. Alias and Names Selected



Arranging and Sorting View Elements


One or more items can be added to or removed from any location on the list, which will ripple the lower items. This allows you to group items together on the list regardless of the item's name or alias (Figure 21). Saving a view saves the current item list order.

Figure 21. Non-Contiguous Item Listing



Clicking a left column heading (Destination, Source, etc.) sorts the list into alphanumeric order. Clicking the heading again reverses the sort order. (Figure 22)

Figure 22. Items Listed in Descending and Ascending Order



Reloading System Views

On Encore systems, System Views on the Sharer can be reloaded from the Sharer to the VSD with the **Actions / Reload System Views from Sharer** control. A progress bar will be displayed as the Views are downloaded to the VSD.

On Prelude systems this control is not operational. Prelude System Views are stored locally on the PC running VSD.

Destination View

Destination View shows the status of a group of Destinations, reporting the Source(s) currently routed to each level, and also shows the protect status of each Destination in the third column of the View ([Figure 23](#)).

Figure 23. VSD Destination View

The screenshot shows a window titled "VSD-DestinationView- Dest5" with a menu bar (View, Edit, Actions, Settings, Show, Tools, Event Stacker, Help) and a toolbar. Below the toolbar are checkboxes for "Show Alias" and "Show Names", and a "Destination Columns" dropdown set to "1". The main area contains a table with the following data:

Row	Destination	Alias	Protect	Primary	Alias	AES	Alias
1	RD_1	RTRD_1		RS_1	RTRSW1	RS_1	RTRSW1
2	RD_2	RTRD_2		RS_2	RTRSW2	RS_2	RTRSW2
3	RD_3	RTRD_3	XY891	RS_3	RTRSW3	RS_3	RTRSW3
4	RD_4	RTRD_4		RS_10	RTRSW10		
5	RD_5	RTRD_5		RS_5	RTRSW5	RS_5	RTRSW5
6	RD_15	RTRD_15		RS_15	RTRSW15	RS_15	RTRSW15
7	RD_25	RTRD_25		RS_25	RTRSW25	RS_25	RTRSW25

At the bottom of the window, there is a "Dest5" tab and a status bar showing "Ready" and "Connected to Encore V1.8.0a8 Ser".


If the state of a destination that is displayed changes, it is highlighted for five seconds, by default. This duration can be changed by with VSD Preferences (see [Enter Highlight Duration - Sets how long items are highlighted when their status changes.](#) on page 45).

Active Salvo View (Encore Only)

Salvo related Views (Active Salvo and Tally Salvo) are unavailable unless **Load Salvos on Connect to Encore** is checked in the Preferences window (see [page 45](#)).

Active Salvo View reports the status of one or more salvos. A green background indicates all the cross points in a salvo's definition match the current state of the matrix. A red background indicates at least one source is not connected to its defined destination ([Figure 25](#)).

Figure 25. VSD Active Salvo View



Right clicking on a red colored cell reports the actual Source for that Destination Level.


Double clicking on a salvo cell opens a Tally Salvo View for that salvo (see [Figure 26 on page 38](#)).

Tally Salvo View (Encore Only)

Tally Salvo View shows the status of all the destinations of a given salvo. Destinations connected to Sources that do not match their salvo definition are highlighted in red (Figure 26). Moving the cursor to a red cell displays the currently connected Source for that Destination.

A Tally Salvo View is opened by double clicking on a Salvo in Active Salvo View, or using the **View / Open / Tally Salvo View** dropdown menu selection and selecting a Salvo.


Figure 26. VSD Tally Salvo View



Tie Line View (Encore Only)

Tie Line View reports status information for tie lines. Status includes the usage of the Tie line, the type of tie line (reserved, floating, etc.), the name of the room to which it is assigned (if any), its ultimate source, and its ultimate destination (Figure 27).

Figure 27. VSD Tie Line View



The screenshot shows the VSD-TieLineView-KenTL application window. The window title is "VSD-TieLineView- KenTL". The menu bar includes View, Edit, Actions, Settings, Show, Tools, Event Stacker, and Help. The toolbar contains various icons for file operations and viewing. Below the toolbar, there are checkboxes for "Show Alias" and "Show Names", and a "Destination Columns" dropdown set to "1". The main area is a table with the following columns: R..., Tie Line, Type, Assigned To, Fixed/Reserved, Ultimate Source, and Ultimate Destination. The table contains 10 rows of data.


R...	Tie Line	Type	Assigned To	Fixed/Reserved	Ultimate Source	Ultimate Destination
1	Mfg_T106	Floating				
2	Mfg_T107	Floating				
3	Mod_T1	Fixed		CrPDR4-1		
4	Mod_T2	Fixed		CrPDR4-2	CrPDR4-2	MoRHT7;
5	Mod_T3	Fixed		CrSDSAT1	CrSDSAT1	MoRHT8;ModB5-3;ModB4-1;
6	Mod_T4	Fixed		CrSDSAT2	CrSDSAT2	MoRHT12;ModB5-4;
7	Mod_T5	Fixed		CrPDR5-1		
8	Mod_T6	Fixed		CrPDR5-2		
9	Mod_T7	Fixed		CrNTEST4	CrPDR5-3	Dst38;ModB9-4;
10	Mod_T8	Fixed		CrPTEST4		

At the bottom left of the window, there is a red "KenTL" button.

Assignment View (Encore Only)

Assignments are another specialized capability not commonly used. An assignment is the same as reserving an item, but assignments can be used by an automation client. Two types of resources can be assigned: Tie Lines and Machine Control. Assignment View shows the source assignments made in the system on a destination by destination basis.

Figure 29. VSD Assignment View




Assignment View also supports assignment and de-assignment operations. This is the only View in which the VSD can effect control of the system. All other Views can only report statuses.

Event Stacker

The Event Stacker (available with Encore v1.8.0 software) can be used to schedule actions to be performed at future times. Actions include Takes, Protects, Unprotects, Salvos, Assignments, Deassignments, and Monitor Takes. A full license is required, and this feature is only available for Encore control systems.


To open the Event Stacker window, click on **Tools** and select the **Event Stacker** dropdown item (Figure 31).

Figure 31. Event Stacker Dropdown Selection



The initial Event Stacker window has an **Actions** dropdown control, used to select the type of event. Once the event type is selected, additional dropdown controls become available to select the required data for that event (Area, Destination, Source, Date, Time, etc.). When all the information has been selected click the **Stack** button to enter that event into the list. An example with Take events is shown in Figure 32. The **Reset** button can be used to clear all the dropdown data.

Figure 32. VSD Event Stacker, Take Events



Item colors indicate the following:


- Orange when the event is active (queued for action),
- Green when the event has completed, and
- Blue if the event has been cancelled.

Note Item colors represent the status of the sending the event, and does not indicate whether the action of that event was actually successful. For example, a Take sent to a Protected Destination will be reported as Completed, even though the Source for that Protected Destination did not change.

These colors are fixed, and are not affected by changes made to the VSD View preferences.

Clicking on the **Event Stacker** menu, or right clicking on one or more items on the list, opens a dropdown menu with **Event** and **View** options (Figure 33).

Figure 33. Event and View Dropdown Menus



The **Event** dropdown options apply to the currently selected event.

Cancel - Deactivates an active event, leaving it in the list. This command does not affect completed events.

Modify - Opens an active event for editing. This command does not affect completed events.

Delete - Removes the event from the list. This command can be applied to all events.

The **View** dropdown options control what types of events are shown on the list (Figure 33). The **By Category** submenu permits selecting to display just **Take**, **Protect**, or **Assignment** events.

Note Error messages on the left side of the lower Status Bar are displayed as they are received, and may not be cleared by subsequent successfully performed events. An error being reported may have been caused by any preceding event, not just the one last sent.


Customizing VSD Views

Selecting **Settings / Preferences** opens a window that allows you to customize VSD preferences.

Application Preferences

Selecting **Application Preferences** opens a window allowing adjustments to VSD application behaviors (Figure 34).

Figure 34. VSD Application Preferences Window



Enter Highlight Duration - Sets how long items are highlighted when their status changes.

Open Recently Used Views On Startup - Determines whether and how many Views are opened when VSD starts up. The maximum is 10 Views.

Retain Connection State - When On, the VSD application will reconnect when the application is launched.

Load Views From Sharer On Connect - On Encore systems, check this box to have VSD load saved Views when the application connects to the Encore Panel Server (Figure 35). This control does not apply to Prelude systems.


Load Salvos on Connect - For Encore systems, check this box to load Salvos when the VSD connects to the Panel Server. This control also activates Active Salvo and Tally Salvo Views, which are grayed out otherwise. This control does not apply to Prelude systems.

Automatic Reload of Router Config - For Encore systems, when checked changes to router configurations (for example, modifying the names of sources or destinations) will be automatically loaded into VSD, allowing dynamic updates of this information. This control does not apply to Prelude systems.

View Preferences

Selecting **View Preferences** opens a window allowing adjustments to the display colors and other settings used by VSD ([Figure 35](#)).

Figure 35. VSD View Preferences Window



Options you can select include:

Show Chop Status - Colors the cells of Chopping destinations.

Include Comments Column - Adds a column for typed in comments.

Autofit Columns - widens and narrows columns to fit the text. This can also be set using the Show dropdown menu.

Show Alias - This can also be set using the Show dropdown menu or the View Preferences toolbar.


Show Names - This can also be set using the Show dropdown menu or the View Preferences toolbar.

Destination Columns - This can also be set using the Show dropdown menu or the View Preferences toolbar.

Color Settings

Clicking on a colored box opens a color definition window, permitting the selection of a different color for that VSD display element (Figure 36).


Figure 36. VSD Color Definition Window



Font Settings

Selecting Font Settings opens a window allowing you to change the font type and size used by VSD (Figure 37).

Figure 37. VSD Font Window



Visual Status Display Instruction Manual

This instruction manual in .pdf format is accessible in the Help menu. Adobe Acrobat Reader must be installed to view this file. The free Acrobat Reader application is available for download from www.adobe.com.

Index

A

- About VSD button [29](#)
- Actions dropdown control [43](#)
- Actions menu controls [27](#)
- activating RCL Server changes [21](#)
- Active Salvo View [37](#)
- activity status [30](#)
- Aliases [33](#)
- AllSrcs
 - Src Category Set [21](#)
- AllSvoss
 - Salvo Exclusion Set [21](#)
- Applicable checkbox [32](#)
- Application Preferences [45](#)
- arranging view elements
 - view elements
 - arranging [33](#)
- assignment operation [41](#)
- Assignment View [41](#)
- Auto Select protocol [20](#)
- AutoFit Columns [33](#)
- Autofit Columns [46](#)
- Auto-Fit Columns button [28](#)
- Automatic Reload of Router Config [45](#)

C

- Cannot update Port Mapper error [13](#)
- color settings [47](#)
- column
 - AutoFit [33](#)
- column width [33](#)
- configuration
 - NP Client [23](#)
 - NP Server [23](#)
 - Prelude overview [23](#)
- Connect menu [27](#)
- connecting to routing system [25](#)
- customizing VSD View [45](#)

D

- de-assignment operation [41](#)
- default View name [31](#)
- Delete menu [28](#)
- Destination Columns [46](#)
- Destination Columns button [28](#)
- Destination View [35](#)
- device ID [26](#)
- Disconnect button [27](#)
- documentation online [4](#)
- dropdown menu items [27](#)

E

- Edit menu controls [27](#)
- Encore
 - deleting Views [28](#)
 - Views supported [31](#)
- Encore OUI [15](#)
- Encore Visual Status Display
 - overview [7](#)
- Enter Highlight Duration [45](#)
- Enter License Key button [29](#)
- Event Stacler
 - Event dropdown [44](#)
- Event Stacker
 - Actions [43](#)
 - By Category submenu [44](#)
 - Event [29](#)
 - general description [43](#)
 - item colors [44](#)
 - Reset button [43](#)
 - View [29](#)
 - View dropdown [44](#)
- Event Stacker button [29](#)
- Events Log [30](#)
 - naming [30](#)
- Events Log button [28](#)

F

FAQ database [4](#)
features of VSD [7](#)
Font Settings button [28](#)
Font Settings window [47](#)
frequently asked questions [4](#)
Full Screen button [28](#)

G

Grass Valley web site [4](#)

H

Help menu controls [29](#)

I

Include Comments Column [46](#)
installation
 with Encore/Prelude installer [13](#)
 with VSD installer [11](#)
installation of VSD [11](#)
Instruction Manual [47](#)

L

Level selection [32](#)
 Applicable box [32](#)
Levels menu [27](#)
license key [7](#)
 basic [7](#)
 full [7, 25](#)
 registration [25](#)
license key registration
 Trial Mode [25](#)
limitations of VSD [9](#)
Load Salvos on Connect [37, 45](#)
Load Views From Sharer [45](#)

M

Monitor View [42](#)
Multiple Conn flag [20](#)

N

Names [33](#)
new View [31](#)
NoName1 default name [31](#)
NP Client Configuration window [24](#)
NP Client/Server configuration [23](#)
NP Server Configuration Window [24](#)

O

online documentation [4](#)
Open recently used views on Startup [45](#)
overview
 VSD [7](#)

P

Panel Server redundancy [7](#)
PC
 requirements [11](#)
Preferences Bar [30](#)
Preferences button [28](#)
Prelude
 configuration overview [23](#)
 Views supported [31](#)

R

RCL protocol. [20](#)
RCL Server
 activating changes [21](#)
redundancy
 Panel Server [7](#)
registration [7](#)
 license key [25](#)
 VSD PC [16](#)
Reload System Views from Sharer [27](#)
reloading System views [34](#)
Retain Connection State [45](#)
Rooms View [40](#)
routing system connection [25](#)

S

- Salvo Exclusion Set
 - AllSvos [21](#)
- selecting Levels [32](#)
- server connection status [31](#)
- Settings menu controls [28](#)
- Sharer availability status [31](#)
- Show Alias [46](#)
- Show Alias button [28](#)
- Show Area Aliases button [28](#)
- Show Chop Status [46](#)
- Show menu controls [28](#)
- Show Names [46](#)
- Show Names button [28](#)
- software download from web [4](#)
- sorting view elements
 - view elements
 - sorting [33](#)
- Source Category Set
 - AllSrces [21](#)
- Source View [36](#)
- Stack button [43](#)
- Standard toolbar [28](#)
- Status Bar [30](#)
- Status Bar button [28](#)
- system requirements of VSD [11](#)
- system View
 - reloading from Sharer [34](#)

T

- Tally Salvo View [38](#)
- Tie Line View [39](#)
- Tool Bar controls [27](#)
- Tool Bar icons
 - descriptions [29](#)
- Toolbar icons [29](#)
- Tools menu controls [29](#)
- Trial Mode [25](#)

U

- uninstall VSD [14](#)

V

- View
 - Active Salvo [37](#)
 - Assignments [41](#)
 - deleting on Encore [28](#)
 - Destination [35](#)
 - general description [9](#)
 - Monitor [42](#)
 - new [31](#)
 - Rooms [40](#)
 - Source [36](#)
 - Tally Salvo [38](#)
 - Tie Line [39](#)
 - types [9](#)
- View menu controls [27](#)
- View Preferences toolbar [28](#)
- View Preferences window [46](#)
- Views
 - supported by Encore [31](#)
 - supported by Prelude [31](#)
- Views overview [31](#)
- Visual Status Display
 - features [7](#)
 - overview [7](#)
- VSD
 - distribution [11](#)
 - features [7](#)
 - installation [11](#)
 - on software CDs [11](#)
 - overview [7](#)
 - registration [7](#)
 - uninstall [14](#)
- VSD features [8](#)
- VSD limitations [9](#)
- VSD PC
 - registration [16](#)
- VSD system requirements [11](#)
- VSD View
 - customizing [45](#)

W

- web site documentation [4](#)
- web site FAQ database [4](#)
- web site Grass Valley [4](#)
- web site software download [4](#)

Index

width of column [33](#)

Windows OS [7](#)