

Sears KS-1000

AKS Ricoh XR-1

Posted 3-7-'04

This camera manual library is for reference and historical purposes, all rights reserved.

This page is copyright© by mike@butkus.org, M. Butkus, NJ.

This page may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

This is the full text and images from the manual. This may take 3 full minutes for all images to appear. If they do not all appear. Try clicking the browser "refresh" or "reload button" or right click on the image, choose "view image" then go back.

It should now appear.

To print, try printing only 3 or 4 pages at a time.

If you find this manual useful, how about a donation of \$3 to:

M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701

and send your e-mail address so I can thank you.

**Most other places would charge you \$7.50 for a electronic copy
or \$18.00 for a hard to read Xerox copy.**

This will allow me to continue to buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

If you use Pay Pal, use the link below. Use the above address for a check, M.O. or cash.



[Back to main camera manual page](#)



CONTENTS

Description of parts	2
Specifications	4
How to use your camera	6
1. Inserting and checking the batteries	8
2. Loading the film	10
3. Setting the film speed	13
4. Selecting the shutter speed	14
5. Meter/shutter "on-off" control	16


6. Setting the aperture.....	17
7. The correct exposure	18
8. Viewing and focusing.....	22
9. Depth of field	23
10. Infrared photography.....	25
11. Holding the camera	26
12. Changing lenses.....	27
13. Using self-timer.....	29
14. Using auto winder	30
15. Unloading film	30
16. Multiple exposures.....	31
17. Flash photography	32
18. Trouble shooting your camera	35
19. Proper care of your camera	37

CONGRATULATIONS


You have just purchased a fine camera that will give you many years of picture-taking pleasure. The KS 1000 is a 35 mm SLR camera which assures you of superb optics, outstanding mechanical performance and reliability which will justify your choice for years to come.

Before using your KS 1000


Please read this instruction booklet carefully and familiarize yourself with the equipment and its features thoroughly. Your pleasure in using your KS 1000 will be greater if you know your camera properly. DESCRIPTION OF PARTS



1. Film Rewind Knob/Back Cover Lock Release
2. Film Rewind Crank
3. Film Speed Dial (ASA/DIN)
4. Film Speed Lock Button
5. Flash Ready Signal Contact
6. Hot Shoe/Flash Contact
7. Shutter Speed Index Line
8. Shutter Speed Dial
9. Cable Release Socket
10. Shutter Release Button
11. Meter/Shutter "ON-OFF" Index Mark
12. Film Advance Lever
13. Battery Check Ring
14. Exposure Counter
15. Neck Strap Eyelet
16. Self-timer Lever
17. Depth of Field Preview Button
18. Lens Release Lever
19. Lens Locator Node
20. Lens Release Button
21. Lens Release Lock
22. Lens Release Lock Release
23. Lens Release Lock Release
24. Lens Release Lock Release



- 20. Focusing Ring
- 21. Distance Scale
- 22. Depth of Field Scale
- 23. F-Stop Ring
- 24. Aperture Relay Port
- 25. Sprocket Teeth
- 26. Multi-exposure Button
- 27. Multi-exposure Lock Lever
- 28. Viewfinder Eyepiece
- 29. Flash LED
- 30. Film Rail
- 31. "X" Flash Terminal
- 32. Film Rewind Shaft
- 33. Film Chamber
- 34. Battery Compartment Cover
- 35. Tripod Socket
- 36. Winder Contacts



- 37. Shutter Release Connection
- 38. Film Rewind Release Button
- 39. Film Take-up Spool
- 40. Winder Coupler
- 41. Positioning Hole
- 42. Back Cover
- 43. Film Pressure Plate (In the Viewfinder)
- 44. Microprism-image Band
- 45. Split-image Spot
- 46. Exposure Meter Needle
- 47. Shutter Speed Indicator
- 48. Battery Power Check Mark "C"
- 49. Aperture Readout Window

SPECIFICATIONS: Sears KS 1000

- CAMERA TYPE**..... 35 mm SLR with metal focal plane shutter.
- FILM FORMAT** 24 x 36 mm
- FILM SIZE AND CAPACITY**..... 35 mm perforated film in 12, 20, 24 or 36 exposures.
- STANDARD LENS** 50 mm Auto Sears MC f/1.7 (Multi-coated), 5 groups, 6 elements Filter size: 52 mm screw-in type
- LENS MOUNT** "K" type bayonet with 65° rotating angle
- SHUTTER**..... Vertically moving Copal FC-523 metal focal plane shutter with speeds from 1 to 1/1000 sec. plus **B**.
- VIEWFINDER**..... Fixed eye-level pentaprism, F-stop, shutter speeds, "B" (bulb), exposure meter needle (also acts as battery checker), shutter speed indicator and battery check mark visible. Viewing magnification 0.88X. Field of view covers 93% of actual picture area.
- FOCUSING** Diagonal split-image spot in microprism band surrounded by Fresnel field.
- EXPOSURE METER** Three CdS photocells TTL full open metering for center-weighted average light reading coupled to shutter speeds, film speeds and f-stops.
- EXPOSURE COUPLING RANGE**..... EV3.5 to 18 (ASA 100 film with 50 mm f/1.7 lens)
- FILM SPEED RANGE** ASA 12 to 3200 (DIN 12 to 36)
- EXPOSURE METER POWER SUPPLY** Two 1.5V silver-oxide batteries, Mallory MS76, Eveready S76 or equivalent).
- FLASH SYNCHRONIZATION** X Synchronization for electronic flash unit at "B" and 1 sec. to 1/125 sec.
- FLASH TERMINAL**..... "X" flash terminal. "X" contact (with electric shock prevention mechanism) on hot shoe for cordless electronic flash unit.

FILM LOADING Multi-slit easy loading.

FILM WIND..... Single stroke film advance lever with 135° winding angle (40° play).

FILM REWIND..... Engage film rewind by pressing film rewind button on base of camera.

EXPOSURE COUNTER..... Additive, automatic resetting.

OTHER FEATURES Self-timer, Hot shoe, Depth of field preview button, Shutter release lock (with film advance lever) Meter on/off switch (with film advance lever) Battery check ring (around shutter release button) Multi-exposure button, ASA/DIN dial lock Cable release socket Tripod socket

DIMENSIONS (Body only) Width:139.9 mm (5.51 inch), Height:91.3 mm (3.59 inch)
Thickness: 48.0 mm (1.89 inch)

WEIGHT (Body only) 550 g (19.59 oz)

HOW TO USE YOUR CAMERA

1. Insert an Eveready S-76 battery (or equivalent).

2. Load the film.

Pull up the rewind knob to open the film compartment door, drop in the film cartridge and push down the knob, turning it until it drops into place. Insert the end of the film leader into the film take-up spool, making sure the perforations along the film edge are hooked onto the teeth of the sprocket. Close the film compartment door and advance the film and press the shutter button repeatedly until the number "1" appears in the exposure counter window.

3. Set the film speed. Depress film speed lock button and rotate the outer ring of film speed dial until the ASA/DIN number of the film you are using is exactly opposite the index line on outer ring of film speed dial and click stops.

4. Set the shutter speed.

When outdoors in bright or hazy sunlight, 1/125 second is generally suitable for most photographs. When indoors in a well lit room, 1/60 second should be sufficient to capture your subject, depending upon the film you are using.

5. Set the aperture.

Rotate f-stop ring until desired f-stop is opposite the aperture index line. F-stop selected determines amount of light entering the lens.

6. Focus on your subject.

Rotate the focusing ring until the split image in the slit image spot forms a single image or until the image in the microprism-image band appears sharp.

7. Turn on the exposure meter.

By pulling the film advance lever away from the camera body approximately 1/2 inch.

8. Set the exposure.

Align the exposure meter needle with shutter speed indicator in the viewfinder by turning the aperture ring or the shutter speed dial.

9. Compose your picture and press the shutter release button.

1. INSERTING AND CHECKING THE BATTERIES



Remove battery compartment cover by unscrewing it counterclockwise with a coin. Place two batteries into the compartment with the plus Q+ side down, as illustrated in the battery holder of battery compartment cover. Make sure that the batteries are correctly placed. If incorrectly placed, the exposure meter needle in the viewfinder will not move at all. Replace battery compartment cover by screwing it clockwise until it stops, but do not force.

Tips for Better Results:

- Before loading, wipe off the surfaces of the batteries with a clean and dry cloth to ensure they are free of fingerprints or stains.
- When your camera is not used for a long period, remove the batteries and keep them in a cool, dry place.

- Replace the batteries about once a year.
- Do not dispose of batteries in fire-they may explode.



Check the power of the batteries after loading them. Turn the battery check ring clockwise until it stops.



If exposure meter needle in the viewfinder swings to battery power check mark "C", the batteries have sufficient power. If the needle doesn't move or stays below check mark "C" the batteries must be replaced. For replacement use Mallory MS76, Eveready S76 or equivalent.


2. LOADING THE FILM




Pull up film rewind knob until back cover snaps open. Then, pull it out all the way to allow for insertion of the film cartridge. Swing open back cover and place a film cartridge into film chamber.

Push down film rewind knob to its original position by turning film rewind crank clockwise or counterclockwise so that film rewind shaft engages film cartridge and locks it in place.

Insert the film leader into one of the slots in the film take-up spool. To bring the slot into a convenient position, rotate film take-up spool in the direction of arrow with your finger.





Rotate film take-up spool by advancing film advance lever to take up any slack in the film. Be sure film tip is firmly hooked onto film take-up spool and that the holes on both sides of the film are caught by the teeth on the film transport sprockets.

NOTE: The film must pass under the take-up spool when advanced.

Close and press back cover firmly until it snaps shut. Advance film advance lever two or three times, after depressing shutter release button each time, until the number "1" is opposite the index line in exposure counter. As you advance film advance lever, film rewind knob will simultaneously rotate counterclockwise indicating that the film is properly advanced. Your camera is now loaded and ready to go.

Tips for Better Results:

* Always load your camera in the shade or in a poorly-lit place. Never in direct sunlight or other bright light.

3. SETTING THE FILM SPEED



Each type of film, color or black and white, has its own sensitivity to light. This sensitivity is assigned by a numerical value described as a ASA rating (U.S.A. Standard) or a DIN rating (Europe and most other countries). In most cases, both ASA and DIN ratings are imprinted on the film package, as well as the data sheet packed with the film and the film cartridge itself. The higher the film speed rating, the more sensitive the film is to light; that is, less light is required for a proper exposure. The film speed, therefore, is an important element in insuring that the through-the-lens metering system of your camera determines the correct shutter speed and f-stop combinations for a given lighting situation.

Depress film speed lock button and rotate the outer ring of film speed dial until the ASA (or DIN) number of your film is exactly opposite the index line on the outer ring of film speed dial and click stops. For example, if the film is ASA 100, make the correct setting at "100". Take your finger off film speed lock button to lock the film speed setting in the camera. Below is a table of the available ASA/DIN ratings with the numbers represented by the dots shown above them.

Tips for Better Results:

* Each time a film with a new film speed rating is loaded in your camera, the film speed must be set to assure accurately exposed photographs.

4. SELECTING THE SHUTTER SPEED

The shutter controls the length of time the light is allowed to strike the film. The speed at which the shutter opens and closes measured in fractions of a second that correspond to the numbers on shutter speed dial. For example, "1000" is 1/1000 sec., "125" 1/125 sec., "4" is 1/4 sec., "1" is one full second and so on.

Simply turn shutter speed dial until the desired shutter speed is opposite shutter speed index line.

Generally speaking, when shooting outdoors in bright or hazy sunlight, "125" (1/125 sec.) is suitable for most pictures. When taking your subjects in motion "250" (1/250 sec.) to "1000" (1/1000 sec.) should be used ... faster speeds will "freeze" extremely fast moving subjects (sports, racing cars, etc.) When indoors in a well-lit room, "60" (1/60 sec.) should be sufficient to take your subject, depending upon the film you are using. When in poorly-lit places, or to achieve the maximum depth of field, "30" (1/30 sec.) to "1" (1 sec.) should be used. When set at "B", the shutter will remain open as long as shutter release button is depressed (preferably by a cable release). The "B" setting is used for long night exposures using street lights or electric signs as a light source, or under poor lighting conditions when flash cannot be used.

Tips for Better Results:

- When using slow speeds (below 1/30 sec.) and "B" setting, use a tripod and cable release to minimize camera movement and prevent blurred pictures. Be especially careful to minimize camera movement when using a telephoto lens.
- Do not set shutter speed dial between marked speeds, but only at a click stop in accordance with indicated speeds.
- Shutter speed dial does not revolve between "1000" and "B".

5. METER/SHUTTER "ON-OFF" CONTROL



Film advance lever controls exposure meter "ON-OFF" and shutter(release "LOCK-UNLOCK" to protect your camera from unnecessary depletion of the batteries and accidental shutter release when not taking pictures. pre-advance with two click positions in 20° and 40° angle and 135° advance angle assures faster winding and permit continuous operation for sequence photography. Choose your suitable angle of 20° or 40° pre-advance position. When film advance lever is moved to "ON" position, the electric circuit is switched on and shutter release button is unlocked.

Whenever picture-taking is completed, be sure to move film advance lever to "OFF" position. The electric circuit is switched off and shutter release button is locked.

6. SETTING THE APERTURE



The lens opening determines the amount of light entering the lens and exposing the film. The smaller the f-stop (f/2.0, f/2.8, etc.) the wider the lens opening and the greater the amount of light entering the lens. The larger the f-stop (f/16, f/11, etc.) the smaller the lens opening and the smaller the amount of light entering the lens. As the lens opening is moved from f/16 to f/11, the amount of light entering the lens is doubled. As the lens opening is moved from f/2.0 to f/2.8 the amount of entering light is cut in half. Rotate f-stop ring until the desired f-stop is opposite the aperture index line. Click stops are provided to prevent accidental movement from the setting made. If necessary, you may set f-stop ring between two f-stops.

7. THE CORRECT EXPOSURE

Your KS 1000 has a built-in through-the-lens full aperture CdS exposure meter which measures the light coming through the lens and enables you to set the proper exposure for a given lighting condition. The correct exposure is obtained by setting the shutter speed and f-stop (aperture) in the correct combination for the film, subject and lighting conditions.

Set the desired shutter speed opposite shutter speed index line by rotating shutter speed dial (Read "SELECTING THE SHUTTER SPEED"). Shutter speed indicator in the viewfinder indicates the shutter speed you just set.

As a general rule, the camera should not be hand held at shutter speeds slower than 1/60 second. This becomes particularly important when using lenses of longer than normal focal length, where it may be necessary to use even faster speeds to eliminate camera movement. At speeds slower than 1/60, a tripod is a must for the sharpest photographs.

IMPORTANT: When attaching the camera to a tripod that has a long attachment screw, adjust the screw to less than 1/4 inch to prevent damage to the interior of the camera body.

12. CHANGING LENSES - This is a standard K-mount lens



To mount the lens on the camera:


Mount the lens by lining up the red dot on the lens mount with the matching dot on the camera mount. Grasp the lens firmly around the lens barrel and turn it clockwise until it clicks into place.

To remove the lens from the camera:

Grasp the lens firmly around the lens barrel in one hand. With the other hand, hold the camera body and press lens release lever and turn the lens counterclockwise until it stops. The lens now can be removed.

NOTE: A wide range of Sears interchangeable lenses including extremely wide angle lenses, telephoto lenses and zoom lenses are available to enable you to expand the pleasure of your picture-taking. Since the camera is designed to accept any lens with the "K" type bayonet mount, your KS 1000 affords you the opportunity to select any interchangeable lens or accessory of the "K" type bayonet mount available on the market.

13. USING SELF-TIMER




Your KS 1000 has a built-in self-timer which delays the shutter release a maximum of 10 seconds. This enables you to include yourself in your own pictures and is also of benefit in taking close-ups or photomicrographs where camera movement must be avoided.

First, advance film advance lever. Then move self-timer lever counterclockwise. According to the degree you have moved it, you can adjust the operating time. For the maximum delay, move it until it stops. Press shutter release button to start the self-timer moving.

14. USING AUTO WINDER

The Sears KS Autowinder can be used with the KS-1000 and KS Auto cameras. By operating the shutter release button on the winder, it can be used for rapid sequence photography at approximate 2 frames per second (at shutter speed 1/125 sec.). By first setting the selection switch you may choose frame-by-frame shots or rapid sequence shots according to your needs. You can for instance capture the rapid movement in sports, or the fleeting facial expressions that make your picture-taking a more enjoyable experience

15. UNLOADING FILM



After the last picture on the roll of film has been taken, rewind the film and unload your camera as follows:

Press film rewind release button.

Lift up film rewind crank and turn it clockwise until film rewind release button stops revolving and you feel the film tension released. This indicates that the film has been completely rewound into the cartridge.

Open back cover by pulling up film rewind knob.

Remove the film cartridge and have the film processed as soon as possible.

Tips for Better Result:

- Always unload your camera in the shade or in a poorly-lit place, never in direct sunlight or other bright light.
- When you reach the end of the roll of film, film advance lever will tighten and refuse to advance. If this happens, do not advance film advance lever by force for "just one more shot", otherwise the film will be torn out of the cartridge.
- Film rewind release button will remain in place once it is pressed, and return automatically to its original position when film advance lever is advanced.

16. MULTIPLE EXPOSURES



Your KS 1000 has a multi-exposure device which allows you to make double exposures for special effect and lots of creative fun.

Make the first picture in the normal way. Release the lock by sliding the multi-exposure Lock Lever to the left until the red dot appears.

For the second exposure, advance film advance lever while pressing multi-exposure button firmly with the other hand. This will set the shutter for the second exposure without advancing the film and exposure counter.



When multi-exposure shots are not required, be sure to lock the multi-exposure Button by sliding the Multi-exposure Lock Lever towards the right until the red dot disappears.



Tips for Better Results:

- Good results in multi-exposure depend on careful shutter speed and lens opening setting. This means, in order to prevent overexposure of the final picture, we suggest that the first picture should be underexposed by adjusting either shutter speed or lens opening.



- If you want, repeat the same action for the third exposure or more.
- Whenever advancing the film advance lever for second exposure, make sure that the multi-exposure button is pressed firmly with the other hand and watch to see that exposure counter is not advanced, indicating that multi-exposure picture is ready to be taken.

17. FLASH PHOTOGRAPHY

You can use a flash at night or in a dimly lit room as well as for supplementary lighting in outdoor photography. The camera and electronic flash will be fully synchronized with the shutter speed at "B" and 1 sec. to 1/125 sec.

Cordless electronic flash unit:

If you are using an electronic flash unit with a built-in hot shoe contact, it can be attached directly to hot shoe on top of the camera pentaprism.

Exposure for flash photography:

The exposure is determined by the guide number of the flash bulb or electronic flash unit. The guide number represents a relationship between the light output of the flash and the speed of the film. Guide numbers for flash bulbs can be found on the package and guide numbers for electronic flash units are found in the technical specifications. Using the guide number, you can determine the correct f-stop for a given flash situation using the following formula:

$$\text{F-stop} = \text{Guide number} / \text{Flash-to-subject distance}$$

For example, if your flash unit has a guide number of 16 (m) or 52.8 (ft.) for the type of film you are using, and your subject is 2 meters (6.6 ft.) from the flash unit as indicated on distance scale after focusing, divide 16 (52.8) by 2 (6.6). The answer is 8; therefore, set f-stop ring at 8 (f/8).

Tips for Better Results:

- If you are using an auto electronic flash unit with power ratio control, follow the instruction sheets packed with flash unit.
- Most electronic flash units have a built-in dial or exposure table which enables you to quickly compute f-stops based on flash-to-subject distances.
- The Sears 8025 Auto Flash is available exclusively for use with the Sears KS Auto camera for automatic flash photography.

18. TROUBLE SHOOTING YOUR CAMERA

The proper operation of a precision instrument like the Sears KS 1000 camera requires strict attention to the correct manipulation of controls. In many cases, the camera may appear to malfunction simply because some small detail was overlooked, or the operations were not in the proper sequence. Before you decide the camera is broken, there are some things you can look for.

Problem: EXPOSURE METER NEEDLE WILL NOT MOVE TO TAKE READING.

Possible cause: Improper shutter speed/aperture combination for film and light conditions. Try changing the shutter speed/aperture combination until needle reacts. Or check to see that the correct type of battery is being used and has been inserted correctly.

Problem: FILM COMPLETELY BLANK WHEN PROCESSED, INDICATED NO EXPOSURE HAS BEEN MADE.

Possible cause: Improper loading. Review section on film loading and be sure you are loading the camera correctly with the film being securely attached to the take-up spool and winding in the CORRECT DIRECTION, that is UNDER the take-up spool. Film may not have gone through camera at all.

Problem: SELF TIMER DOES NOT OPERATE SHUTTER.

Possible cause: Timer not rotated at least 90 degrees.

Problem: LENS VERY HARD TO REMOVE FROM CAMERA. STOP IMMEDIATELY!

Possible cause: Pressure on film advance lever causing automatic diaphragm actuating plate to press against pin on back of lens.
THIS CAN CAUSE SERIOUS DAMAGE TO YOUR LENS. DO NOT FORCE THE LENS! Check to be sure the film advance lever is retracted.

Problem: FLASH PICTURES BLANK OR PARTIALLY EXPOSED.

Possible cause: Improper shutter speed for the type of flash used, or improper cord receptacle used for the type of bulb or shutter speed. Check Flash Synchronization Table carefully.

Problem: SHUTTER *WILL* NOT RELEASE.

Possible cause: Film advance lever not advanced far enough. A full stroke is necessary to cock the shutter. However, a ratchet incorporated within the film advance mechanism will allow you to accomplish a full wind in a series of short strokes.

If the problems above cannot be solved in the manners suggested, do not attempt to repair the camera yourself. Take it to the nearest service center. A minor problem could be aggravated by tampering.

19. PROPER CARE OF YOUR CAMERA

- Always carry your camera with its carrying case and neck strap.
- Use the lens cap to protect the lens when not taking pictures.
- Protect your camera from dust, dirt, water, rain, dampness, salt air and rough handling.
- Never expose your camera to excessively high or low temperatures for an extended period of time. In extremely hot climates, do not leave your camera inside closed automobiles during the daytime or in direct sunlight. In extremely cold climates, expose your camera to the outer air only when in use... when using, expose your camera gradually to the outer air to prevent the lens from clouding. If exposed to an extremely cold climate, the exposure meter batteries may fail to operate properly. Keep your camera inside your clothing until taking a picture.
- Never touch the surfaces of the lens, metal focal plane shutter curtain, reflex mirror, etc. with your fingers.
- To clean the lens, gently wipe it in a circular motion with a lens cleaning paper or a soft, clean and lintless cloth.
- Do not wipe the camera body with chemicals, such as benzine, thinner, etc. Use only soft cloth or cotton swab sprinkled LIGHTLY with alcohol on the camera body. Do not use them on the lens because it can affect coating.
- When your camera is not in use for an extended period of time, put the lens cap on, remove the batteries, place your camera in its carrying case together with silica gel or other desiccant and store it in a dry and cool place, Never store your camera in places where the temperatures are excessively high or low.
- Do not attempt to disassemble or repair your camera yourself. If service is necessary, get in touch with your dealer.