

11

CoPILOT[®] TRUCK

Laptop




GPS Navigation For Professional Drivers



Welcome

**Thank you for choosing CoPilot Truck 11.
This guide will tell you everything you need to know
about using CoPilot Truck 11.**


This PDF is interactive to make it easier for you to navigate through it to find the information you are looking for. Here are some tips for using it:

- Click on the titles in the contents page to be taken straight to the section of your choice.
- Click  at the bottom of each page to go back to the contents page.
- Click on **red text** and **page numbers** to be taken to the page referenced.

You can also use the Pages tab in Adobe Acrobat Reader to help you navigate the document.

Safety Note:

CoPilot Truck is designed to calculate the most efficient and truck-specific routes for you. However, some of the information in the database may change from time to time. **You must stay alert and pay attention to road signs at all times.**



Contents

01 Getting Started

Checklist.....	5
Installing CoPilot Truck 11	6
Activating CoPilot	6
Select Language and Voice	7
Select a Distance Measurement	8
Tips and Tricks	8
GPS Setup	9
Setting Up a Built-In or USB GPS Receiver.....	9
Setting Up a Bluetooth GPS Receiver	10

02 Using CoPilot Truck

Selecting a Destination	11
Pick a Stop From the Map.....	11
Nearby Points of Interest.....	12
Adjusting the POI Settings.....	12
Advanced POI Search	13
To Choose a Recent Destination	14
To Choose a Contact's Address As a Destination.....	14
To Choose an Intersection For Your destination	14
Selecting a Destination Using Lat and Long.....	15
Choosing a Saved Trip	15
Saving Your Current Location.....	15
Other Ways to Select a Destination	15
Entering Multiple Destinations	16
Trip Options.....	16
Change the Stop Order	16
Optimize Stops	16
Setting Waypoints.....	17
Saving Destinations as Favorites.....	17

Preview Your Route.....	17
Saving a Planned Trip	18
Loading a Saved Trip	18
Deleting a Planned Trip	18
Generating a State Mileage Report	18
Route Settings.....	19
Saving a Routing Profile	19
Loading a Routing Profile	19
Road Preferences.....	19

03 Driving With CoPilot Truck

Begin Driving.....	20
Trip Editing.....	20
Traffic Service	20
Guidance	20
Driving Views	21
On-screen Information	21
Setting Display Mode	22
Driver Safety	22
3D.....	22
2D Where Am I?	22
2D Next Turn	23
2D Destination	23
Itinerary	23
Night Mode	23

04 Personalize

Saving a Destination as Home	24
Saving a Destination as Work	24



Contents

Changing Your Work or Home	24
Save Your Favorite Destinations	25
Edit or Delete Favorites	25
Night Map	26
Customizing the Guidance Screen	26
Personalizing the Voice Instructions	27
Setting Map Styles.....	27
Applying Themes.....	27
Customizing Routing Options.....	27
05 Advanced	
Detours.....	28
Ending a Detour	28
Recalculate the Whole Trip	28
CoPilot Truck Traffic Service	29
Setting Up CoPilot Truck Traffic	29
Avoiding Traffic.....	29
Additional Traffic Settings	30
Searching for Traffic Incidents	30
Using the Traffic Incidents List	30
Setting Map Preferences.....	31
Setting Map Styles.....	31
Checking the GPS Status	32
Track Playback.....	32
Adjusting the Volume	32
Adjusting the Guidance Settings	33
Adjusting Your Safety View	33
Setting the Language and Speech	33
Playing a Demo	34
Keyboard	34
About CoPilot	34

Licensing	35
Transferring Your CoPilot Truck License	35
CoPilot Live FleetCenter	36

06 PC*MILER Route Types

PC*MILER Route Type Descriptions.....	37
PC*MILER Hazmat Route Types & Road Categories	40

07 Support

CoPilot Customer Support Helpline.....	42
Online Help	42

08 EULA



Getting started

Checklist

First check the contents of your box with the list below.



CoPilot Truck DVD
Software & Street-level Maps



Documentation



USB GPS Receiver*



Bluetooth GPS Receiver**



Car Charger**

* Optional accessory. Only included in certain CoPilot Truck navigation kits that include a USB GPS receiver.

** Optional accessory. Only included in certain CoPilot Truck navigation kits that include a Bluetooth GPS receiver.



Getting started

Installing CoPilot Truck 11

Note: If you are updating from an older version of CoPilot, you may want to uninstall the previous version first. This is not required.

- 1 Turn on your laptop and insert the supplied CoPilot Truck DVD into your DVD drive. The install will start automatically within a few seconds.
- Note:** Alternatively, you can select **Start > My Computer > DVD Drive**.
- 2 Choose a language (for example: “English (United States)”) and click **OK**.
- 3 Follow the Installation Wizard instructions and select **Next**.
- 4 Enter your product key in the boxes provided. Your product key can be found on the back of the Quick Start Guide.
- 5 Follow the instructions, click **Next** to go from one screen to the next in the Installation Wizard.

CoPilot Truck 11 will now be installed. This may take a few minutes, please be patient.


Activating CoPilot Truck

After CoPilot Truck is installed, a shortcut will be available on your desktop.

The first time you open CoPilot Truck, you will be prompted to activate the license.

Press **Next** to activate now or **Cancel** if you prefer to activate the license later. If you press Cancel you will still be able to use your CoPilot Truck software under an evaluation license for 3 days.

You can activate CoPilot Truck automatically using your laptop’s internet connection. Or, you can activate your license on the CoPilot Truck activation website at <http://activate.alk.com>.



Automatic Activation

For automatic activation (recommended):



- 1 Select **Internet** and then select **Next**.
- 2 Enter your email address when requested and select **Next**.



Getting started

Manual Activation Through the CoPilot Activation Website

- 1 Select **No Internet** from the Activate CoPilot screen. Press **Next**.
- 2 The next screen will show your product key and license number.
- 3 Now, visit the CoPilot activation website at <http://activate.alk.com> and enter your product key, license number and email address as requested. Press **Submit**. Your activation code will be displayed on-screen and will be sent to you by email.
- 4 On your laptop, press **Next** to continue to the next screen. Enter your activation code and press **Next**.





After activation

When activation is completed you will see the message **Activation successful**.

- Press **Next** to continue using CoPilot.

Select Language and Voice

in the Language and Speech screen you can choose which language you would like CoPilot Truck to use for on-screen text and voice guidance.

- Use the  and  arrows to choose your preferred options.
- Click **Test** to hear a sample of the voice you have chosen.



When you are happy with your selections click **Next**.

Note: You can change these settings at any time, **Menu > Settings >  > Language & Speech**.




Getting started

Select a Distance Measurement

Choose between Miles and Kilometers for the distance units used in maps and instructions.

Note: You can change these settings at any time, **Menu > Settings > Map.**

Note: When you have selected your distance setting, you will be presented with a legal notice. Please read this carefully, and then click **Accept.**




Tips and Tricks

CoPilot Truck has loads of great features, to help you get to know and understand them we have included **Tips and Tricks** at start up.

To turn off the Tips and Tricks uncheck the '**Show Tips and Tricks**' box. To see more use and . To close the window click on the cross ().

To view Tips and Tricks at any time:

- **Menu > > Tips & Tutorials > Tips & Tricks.**



Getting started

GPS Setup

Your laptop may have a built-in GPS receiver. If it does not, you will need to set up a connection to a Bluetooth or a USB GPS receiver.




Configuring GPS

Whether you have a built-in or a USB GPS receiver, you will need to set up your GPS receiver in CoPilot before you can begin navigating.

- Click **Menu > Settings > GPS > Setup GPS**.

On the Setup GPS Receiver screen choose between:

- **Built-In** to use the GPS receiver built into your laptop.
- **Bluetooth** to set up a connection between your laptop and the Bluetooth GPS receiver.
- **USB** to use a USB GPS receiver connected to your laptop's USB port.



Important: Make sure you set the correct date and time on your laptop to get the best GPS functionality.

Setting Up a Built-in or USB GPS Receiver

If you selected **Built-In** or **USB** you will need to choose between **Automatic** and **Manual**. We recommend Automatic setup.

With Automatic selected, click **Finish**. CoPilot will find and connect to the GPS receiver in your laptop.



To set up Manually, select **Manual**, you will need to select the **COM Port** that the GPS is connected to and the **BAUD** rate for the laptop. Please consult your laptop manufacturer for this information.

When you have entered the information click **Finish** to continue. Once setup has been completed select **Finish** to complete the process.

Note: If you get the message GPS Setup failed, the COM Port and/or BAUD information were incorrect. Please try again.

You are now ready for your first trip with CoPilot!

See [page 10](#) for GPS Signal tips.



Getting started

Setting Up a Bluetooth GPS Receiver



- 1 Switch on your Bluetooth GPS receiver.
- 2 Select **Bluetooth** in the Setup GPS Receiver screen then click **Next**.

CoPilot Truck will begin searching for Bluetooth devices in your immediate vicinity. Once the search is complete, all nearby GPS devices will be displayed.

- 3 Select your GPS receiver from the list. (If you are using the GPS receiver supplied with your CoPilot software it will appear in the list with a name similar to “**BTGPS**”.)
- 4 Click **Next**. To complete the setup, click **Finish**.

You are now ready for your first trip with CoPilot!

Note: If you chose Manual to set up your Bluetooth receiver, you may be prompted to enter a pin code. Use “0183” or “0000” to enter.



Tips: GPS Signal



- The first time you use the GPS receiver it may take a moment to determine your position.
- GPS signal will be limited inside buildings, tunnels or parking lots. To work effectively the GPS receiver needs to have a clear line of sight to the sky.
- If you are using a USB receiver, be sure it is firmly plugged into your laptop and that your computer recognizes the device.



Using CoPilot Truck

Safety Information

Do not attempt to change the settings, or set a destination on CoPilot while you are driving. Ask a passenger to make changes, or pull over safely.

Do not leave your laptop PC or GPS loose in the car while driving. Ensure they are correctly seated in a car mount.



Selecting a Destination

CoPilot uses GPS satellites to calculate your exact position so you don't have to enter your starting point. Simply enter your destination and CoPilot will take you there, providing detailed turn instructions all the way.



- Click **Menu > Destination > Address**.
- Enter the city/town name of your destination.
- Select the correct city or area when it appears in the list below. Scroll down to see more address options matching what you have typed.



- Enter the first three or four letters of the street name. As you enter the street name CoPilot will list potential matches. Select the correct street name when it appears in the list below.
- Enter the house number and select **Finish**, or just select **Finish** to skip this step.

A preview map of your route will then appear. Select **Drive** to begin navigating your route.



Quickly Pick a Stop From the Map

You can also select a destination from the map.

- Select **Menu > Destination >  > Pick on Map**.

A map of the area around your current location will be displayed. Touch and drag the screen to move around the map and click your desired destination when you find it.



Using CoPilot Truck


Nearby Points of Interest

If you are running low on diesel fuel or need to rest at a truck stop, CoPilot Truck has over 6 million pre-loaded Points-of-Interest (POI) to search.

- Select **Menu** > **Nearby POI**.
- From the list, select a category. For example, Truck Services.

After a few moments a list of nearby Truck Services will appear, in order of distance from your current location.


- Make a selection and click **OK**. A preview map of the route to your selected POI will appear.
- Click **Drive** to begin navigating the route.



Tip: POI In the City

You can search for a POI within a city, near your current location or along your route by pressing **Menu** > **Destination** > **Points of Interest**.


You can search for a particular POI within a category by name, see [page 13](#).



Adjusting the POI Settings

You can choose when to have POIs shown on-screen and the distance at which you are notified by adjusting the POI settings.

- Click **Menu** > **Settings** > **POIs**.
- Enable the POIs by checking the box. Disable by unchecking.
- Choose to **Show POIs Always, Never** or **When Stopped** from the picklist.
- In the **Report POIs this far ahead** field, select a distance between 0.2 and 25 miles.
- Select whether to show POIs that are on your route or nearby it. Select **On Route** or **Near Route**.
- Under **Select POIs to be reported**, select specific POI categories to display by checking the boxes.
- Click **OK** to apply the settings and return to the Settings menu.




Using CoPilot Truck

Advanced POI Search

If you want to visit a specific POI without entering the address, you can search the POI database and set it as a destination.



- Select **Menu > Destination > Points of Interest**.
- Choose to select a category or search all. If you check the **Pick Category** box, click the correct category. Click **Next**.
- If you know the name of the place you want to visit, enter it here.
- Select a location option: choose from **Near current location**, **Along my route** or **In a City** to search for a related POI. Press **Next**.
- For **Near current location** and **Along my route**, the POI list will be automatically generated. If you selected **In a City**, enter the name of the city or town nearest the POI you are searching for.



CoPilot will then search the millions of POIs in its database. When complete, a list of the nearest matches will appear on-screen.

- Select the correct POI from the list.
- Press **Details** to view the POI on the map. CoPilot will also display the phone number for the POI if available.
- For CoPilot to create a route from your current location to your selected POI, select **OK**.



Using CoPilot Truck

To Choose a Recent Destination

- Select **Menu > Destination > Recent**.

Recent provides quick and easy access to the last 50 destinations that you entered.

Note: Your recent list will store the last 50 addresses you have entered. When the list is full each new address will replace an older inactive address.

To delete the recent stops list:

- Select **Menu > Destination > Recent > Clear All**.


To Choose a Contact's Address As a Destination

You can select an address from any Contacts that you have stored in your laptop.

To select a contact:

- Click **Menu > Destination > Contact**.


Enter your contact name to automatically recall the address saved in your laptop, or select from the list of contacts.



To Choose an Intersection For Your Destination

- Select **Menu > Destination > [Intersection Icon] > Intersection**.

Enter the City or Town and click next, you will be asked to enter the first road and then the second. CoPilot will calculate your route to the point where they meet.



Using CoPilot Truck

Selecting a Destination Using Lat and Long

If you know the latitude and longitude of your destination you can enter them directly.



- Click **Menu > Destination > [blue arrow icon] > Coordinates**.
- Choose to set the latitude and longitude in Degrees Minutes Seconds, Decimal Degrees or Decimal Minutes.
- Enter a latitude and longitude in the appropriate format depending on which one you selected.



CoPilot will take a few moments to find the point. When it is located a map will appear with the location pinpointed by a red arrow.

- Select **Drive** to begin navigating your route.



Choosing a Saved Trip

If you already have a saved trip that you want to use, you can access it quickly.

- Click **Menu > Destination > Open Saved Trip**. For details on saving a planned trip, see [page 18](#).

Saving Your Current Location

If you are outside and have a GPS fix, you can save your current location.



- Click **Menu > [blue arrow icon] > Save Current Location**.
- Enter a name for the destination and click **Save**.
- The location will be saved in your Favorites list, where it can be accessed as a destination in the future.

Other Ways to Select a Destination



You can save locations as Home and Work for one-click address entry, [see page 24](#). In addition, CoPilot lets you save your Favorite destinations so you can access them quickly, [see page 25](#).



Using CoPilot Truck

Entering Multiple Destinations

CoPilot allows you to plan a trip with multiple destinations.


- Click **Menu > Plan or Edit Trip**.
- Click  to add a destination.
- To delete a stop, select it and click .
- Add the first address; click the **Add Destination** button again to add a second, third, etc. address. See [page 11](#) for address entry details.



Trip Options

In the trip planning window click the **Options** button.

- To see a fuel cost estimate when the trip is calculated, type in the vehicle Miles per Gallon and cost per gallon.
- To have break hours included in the trip ETA, select a time interval and break time.
- When **Optimize Final Destination** is checked, the position of the last stop on the stop list can be changed when the trip is optimized (see below).



Change the Stop Order

When you have entered all your required stops you can change the order they appear in.

- Highlight the address you wish to move.

Click the **Move Up**, **Move Down**, **Move to Start** or **Move to End** button.



The selected stop will move to its new position in the trip list.



Optimize Stops

Optimize

CoPilot has an Optimize function which will automatically rearrange the stops on a trip to create the most efficient route.

If your planned trip has more than three (3) stops, click **Optimize**. CoPilot will take a few seconds to reorder your stops for the most efficient trip.


Note: Your start point and final destination will not be altered. If you want the final destination to be included in the optimization, click **Options** and check **Optimize Final Destination**.



Using CoPilot Truck


Setting Waypoints

CoPilot Truck can route you through a designated point without considering it as a stop. By setting Waypoints you can adjust CoPilot's route to calculate a detour via the waypoint.





- Select **Menu > Plan or Edit Trip**. Enter the addresses or places in the same way detailed in **Selecting a Destination** on page 11.
- Addresses will normally appear on the trip list as stops with a flag icon next to them. Highlight the address you wish to change to a Waypoint.
- Click the **Set as Waypoint** button. 

The address or place will now be listed as a Waypoint, with an arrow icon in front of it to indicate that it is a Waypoint.


Tip: Make a Waypoint a Stop

To change a Waypoint back to a stop, highlight the address then click the **Set as Stop** button. 



Plan Trip	
Destinations	
	Current Location
	52 Berkley Avenue Belle Mead, NJ 08502
	5 Glen Clair Drive Ewing, NJ 08618
	56 Jacobs Creek Road Ewing, NJ 08628
	Washington Crossing Inn Washington Crossing, PA
	5500 Market Street Philadelphia, PA 19139

Saving Destinations As Favorites

You can save addresses listed on the trip list as Favorite destinations so you can access them quickly. 

- Click on the address you wish to save as a favorite.
- Click the **Add to Favorites** button. Now you will be able to enter this address as a destination quickly by selecting **Menu > Destination > Favorites** and selecting it from the Favorites list.

Tip: Do More With Favorites

For more information on Favorites see page 25.

Calculate

Preview Your Route

When all your stops have been entered, press **Calculate**.

Your planned trip will appear on the map. From this window you can run a **State Mileage Report**, do a **Preview** run of the trip, edit the stop list, or change the trip options and re-calculate.



Using CoPilot Truck

Saving a Planned Trip

Before you calculate a trip, you may want to save it for future use.




- In the trip planning window click **Save Trip**.
- Enter a name for the trip you are saving.
- Click **Save** and the trip will be saved.



Loading a Saved Trip


- Click **Menu > Plan or Edit Trip**.

The last trip you planned will automatically load. If you wish to load an older trip, click **Load Trip** and select the trip you wish to load from the list. Click **Open**. Or, select **Menu > Destination > Open Saved Trip**.



Deleting a Planned Trip

- Click **New Trip**.

You will be asked to confirm this selection. Click **Yes** at the prompt. Now you can enter a new trip, or click  to return to the main window.

Generating a State Mileage Report

State Mileage Report

After calculating a route, you can generate a State Mileage Report. Click the **State Mileage Report** button under the mileage and time estimate.

This report shows a state-by-state breakdown of total, toll, free, and ferry mileage on your trip. It will open in the internet browser on your laptop.

State/Country	Total	Toll	Free	Ferry
IN	251.1	0.0	251.1	0.0
NJ	40.1	0.0	40.1	0.0
NY	396.6	311.0	85.7	0.0
OH	533.0	0.0	533.0	0.0
PA	393.4	276.6	116.8	0.0
VT	59.9	0.0	59.9	0.0
WV	12.9	0.0	12.9	0.0
US	1687.2	587.6	1099.6	0.0
TOTAL	1687.2	587.6	1099.6	0.0




Using CoPilot Truck

Route Settings

CoPilot Truck offers a number of standard PC*MILER route types and options. For a full description, see the **PC*MILER Route Types** on pages 37-41.


- Select **Menu > Settings > Routing**. You will need to scroll down to see some of the options.
- **Routing Type:** Select **Practical** or **Shortest**.
- **Toll Roads:** Select whether you want CoPilot to **Use** toll roads, **Never** use them, or to **Avoid If Possible**.
- **Options:** Select **National Network** or **53 Ft. Trailer**.
- Check **Override Restrictions** for Light Vehicle Routing.
- Check **International Borders Open** to allow your route to cross international borders.
- Check **Hazmat Routing** to generate trips for hazardous material routing (see pages 42-43 for more information).
- **Vehicle Restriction:** *(Not currently available)* Click **Edit Vehicle Restriction** and enter the information that pertains to your vehicle. If nothing is entered here, your route will avoid all truck-restricted roads by default. If information is entered, some restricted roads may be used where appropriate.



Saving a Routing Profile

Different combinations of route settings can be saved as routing profiles for use at a later time.

- Click **Save Routing Profile**.
- Enter a name at the prompt and click **OK**.



Loading a Routing Profile


- Click **Load Routing Profile**.
- Select a profile from the list and click **OK** twice to apply the profile and close the Routing window.

Road Preferences

(Available only after a routing profile has been saved.)
Scroll down and click **View/Edit Road Preferences**.

- **For each road type:** Choose whether you want CoPilot to **Strongly Avoid**, **Avoid**, be **Neutral**, **Favor** or **Strongly Favor** when calculating a route.
- **Speed:** Select an appropriate speed for each road.

Note: Changing the default route and road preferences in CoPilot will affect the route calculated and ETA shown.



Driving With CoPilot Truck


Begin Driving

Select **Drive** to begin navigating your route.



Tip: Starting Points

If you are planning a trip in advance and are not at the start point of your journey CoPilot will ask you to select your starting location. You can choose to navigate to the starting point, or to navigate directly to the destination from your current location.



Trip Editing

Once you have pressed **Drive**, you can change the trip entered by selecting: **Menu > Plan or Edit Trip**. See **Entering Multiple Destinations**, page 16. To simply delete a destination you have entered, click **Menu > [Home Icon] > Clear Destination**.

Traffic Service*

CoPilot can automatically display any traffic incidents that affect your route and can recommend an alternate route if required. For more information see page 29.

*CoPilot Truck Traffic is available as an optional service.



Guidance

CoPilot will guide you to your destination with clear on-screen and spoken instructions. Whenever you are approaching your next turn, CoPilot will speak to you to alert you to the upcoming direction change.



Driving With CoPilot Truck

Driving Views

You can choose from six different screen display options. To access, click **Menu > Driving Views**. For more details on each view and how to change views, see **Setting Display Mode** on page 22-23.



In the default mode, your screen will look like the one below.



Tip: Take a Closer Look

Use the and in 2D or 3D driving views to zoom in or out of the map view.

On-Screen Information

By default your current location is displayed at the bottom of the map. You can choose what useful information is displayed at the base of your screen when you are driving, see **Customizing the Guidance Screen** on page 26.



Tip: What Are These?

- Hazmat routing indicator (see page 19)
- Truck routing indicator
- FleetCenter Online indicator (see page 36)
- GPS Status:
 - Green = Best fix
 - Yellow = Fair
 - Red = No fix
- Traffic Service connected (when green)




Driving With CoPilot Truck

Setting Display Mode

You can choose from several different screen display options. To access, click **Menu > Driving Views**.

Or, click the Driving Views Shortcut button to quickly access one of four views:



Driver Safety

While you are driving we recommend you choose Driver Safety, which displays a simple turn instruction arrow with concise next turn instructions in large type. In driver safety mode, a map is only displayed as you approach a turn or are travelling below 10mph.

Tip: Adjusting Your Safety View

You can alter the settings of the driver safety view. See [Adjusting Your Safety View](#) on [page 33](#).

3D

Shows your current position, next turn and surrounding roads using a 3-dimensional perspective.



2D Where Am I?


Displays your current location, next turn and surrounding roads on a 2D map.



Driving With CoPilot Truck


2D Next Turn

Displays your current location and auto zooms into the next turn on a 2D map.



2D Destination

This view shows the route from your current position to your destination.



Itinerary

This view shows each direction and turn in a text list, including distances.



You can use the Itinerary to check your route before you travel.

Alexander Street	0.4
US-1 South (Brunswick Pike)	5.4
US-1 South (Trenton Freeway)	2.9
New York Avenue	0.2
Route 622 North (North Olden Avenue)	1.0
NJ-33 West (Greenwood Avenue)	0.5
Chambers Street (Route 626 South)	0.2
Hamilton Avenue (Route 606 West)	0.0

Night Mode

Displays map with a dark background that reduces glare for easier night-time viewing.



Personalize


Enter and save personal destinations, change the map style and color theme, adjust your routing options, and select the voice that guides you to your destination. With CoPilot Truck 11 you can personalize your laptop to behave exactly the way you want it to.

Saving a Destination As Home

Save your home address so you don't have to enter it every time you wish to be directed home.



- Click **Menu > Destination > Home**.
- Enter your home city/state name, street name and (optionally) house number, then click **Finish**.
- The next time you are entering a destination and select Home, your home address will enter automatically.



Saving a Destination As Work

Save your work address so you don't have to enter it every time you wish to be directed there.



- Click **Menu > Destination > Work**.
- Enter your home city/state name, street name and (optionally) building number, then click **Finish**.
- The next time you are entering a destination and select Work, your work address will enter automatically.

Changing Your Work or Home

The home and work addresses you entered are placed in your Favorites list and can be edited or deleted at any time, see [page 25](#).




Personalize

Save Your Favorite Destinations

You can save other addresses to your Favorites list, so you can access them quickly.

- Click **Menu > Destination > Favorites**.
- Click **Add New** and CoPilot will return to the Destination menu.
- Choose to add the favorite by inputting the address/postcode (click **Address**) or by locating it on a map (**Pick on Map**) or any of the other ways to enter a destination.



When you've successfully added the address or location, it will appear in your Favorites list.



Edit or Delete Favorites

To edit or delete a location in your Favorites list, click **Manage**, select a favorite and choose to **Edit**, **Delete** or **Delete All**.

- **Edit** will open an enter address window so you can change the location.
- **Delete** will erase the currently highlighted location.
- **Delete all** will erase all the locations in your favorites list, including your Home and Work addresses.



Note: You will be asked to confirm you wish to delete an item. If you select **Yes** the address/es will be lost.



Personalize

Night Map

Night Map can be selected in any of the display screen modes. It dims the screen display to reduce glare and eye strain when driving at night.




CoPilot will automatically switch to night mode based on the time and your location, or you can do it manually from the Driving Views menu.

Click **Menu > Driving Views > [Night Map Icon] > Night Map.**


To switch off Night Mode, click **Menu > Driving Views > [Day Map Icon] > Day Map.**

You can also alter the day and night mode settings from the Map Styles window. See **Setting Map Styles** on [page 31](#) for details.



Customizing the Guidance Screen

You can choose what information you want to be displayed below the map when you are driving.

- Click  on the bottom right of the screen.

Choose from:

- Destination
- Current Road
- Next Crossroad
- Next Major Road
- Nearest Town
- Speed
- Altitude & Heading
- Latitude & Longitude.




Personalize

Personalizing the Voice Instructions

You can alter the voice with which the guidance instructions are spoken.

- Click **Menu > Settings > [Settings Icon] > Language and Speech**.
- Select a language from the **Choose a Language** picklist.
- Select a voice from the **Choose a Voice** picklist. Select **Test** to hear a sample of the chosen voice. For text-to-speech directions, select **Samantha**.




Setting Map Styles

- Click **Menu > Settings > [Settings Icon] > Map Styles**.

You can select from a range of industry-standard map presentation styles and color themes using the **Map Style** list. A preview is shown each time you select one. Once you are happy with your selection click **OK**.

Also see **Adjusting Your Safety View** on page 33.



Applying Themes

You can change the color theme of your CoPilot.

Menu > Settings > [Settings Icon] > Themes.


Select a theme using the up and down arrows next to the **Select a Theme** field. Press **Apply Theme** to apply the chosen theme.



Customizing Routing Options

Once a destination has been entered the Route screen will appear, showing you a preview map of the route. Select **Options** to change the route type or routing profile for the trip.

For more details see **Preview Your Route** on page 17, and **Route Settings** on page 19.



Advanced


Detours

You can program CoPilot to make a detour around one or more selected roads on the calculated route, or to calculate a whole new alternate route.





- Select **Menu > Detour**.
- To route around a specific road, select **Avoid Roads**.

An itinerary of your journey will appear. Click on the road you would like to avoid then select **Avoid Road**.




CoPilot will take a few moments to calculate another route around the selected road, then an updated map display of the new route will be generated. The difference in mileage and time that will result if the new route is accepted is displayed below the map.

For example: “< 1 mi / +2 mins” means that the new route is about one mile shorter but is estimated to take approximately two minutes longer to drive.

- Click **Accept**, then press  to close the itinerary window and CoPilot will begin guiding you along the new route.
- If you decide not to use the new route, select **Decline**. CoPilot will then return to your original route. Press  to close the itinerary window.

Tip: Avoiding Multiple Roads

You can specify multiple roads to be avoided. Repeat as many times as required. Press  to return to the driving screen when done.

Note: CoPilot will save all the roads you select to avoid and avoid them in future route calculations. To clear the memory, select **Menu > Detour > Clear Avoided Roads**.



Ending a Detour

If you are on a detour route and would like to return to the original trip, select **Menu > Detour > End Detour**.

Recalculate the Whole Trip

If you are unhappy with the whole route CoPilot has planned for you, click **Menu > Detour > Alternate route**.

CoPilot will compile a different route for you if a reasonable alternative exists. A map of the proposed detour will be displayed. Select **Accept** to agree or **Decline** to return to the previous route.



Advanced



CoPilot Truck Traffic Service*

The optional CoPilot Truck Traffic service provides information about real-time traffic incidents on your route or in a specific location.

Traffic information will be delivered to CoPilot Truck using your mobile internet connection. CoPilot Truck will automatically display any traffic incidents that affect your route and can calculate an alternative route if required.

You can also search for traffic incidents in other locations before you start driving.

The availability of CoPilot Truck Traffic varies by region and retailer. For more information, please visit www.copilotgps.com.

Setting up CoPilot Truck Traffic

Traffic information delivered via Mobile Internet

- Select **Menu > Traffic > Traffic (GPRS) Connect**.
- Once connected, CoPilot Truck will check your route for traffic automatically, downloading traffic information via your mobile Internet connection.

Avoiding traffic

You can program CoPilot to make a detour from the programmed route to avoid traffic.


- Select **Menu > Detour**.
- From the Detour options, select **Avoid All Traffic**.

CoPilot will use GPRS information to find traffic incidents and will automatically plan another route, avoiding traffic congestion.

Along with a map, CoPilot will display the distance the new route will add/subtract from your trip.

- Click **Accept** and CoPilot will begin directing you according to the new route.
- If you decide not to use the new route, select **Decline**. CoPilot will then return to your original route.

* CoPilot Truck Traffic is available as an optional service. You must be connected via the Mobile Internet as described here to receive traffic data.



Advanced

Additional Traffic settings

To adjust the alert settings and define how CoPilot uses GPRS traffic information:

- Select **Menu > Traffic > Settings**.

Options are:

- **Traffic Source:** The CoPilot Truck Traffic Service in North America receives information via a GPRS Wireless connection to the mobile Internet.
- **Internet Connection:** In the U.S., use **Default** to automatically connect with your Internet Provider.
- **Default Incident Action:** Select **Avoid** to set CoPilot to automatically detour around reported incidents, select **Ignore** if you do not want to be automatically detoured.
- **Speak Incidents:** Choose to have CoPilot announce traffic incident alerts as they occur.



Searching for Traffic Incidents

To search for traffic incidents along your current route:

- Select **Menu > Traffic > Traffic on Route**.



To search for traffic incidents in a City:

- Select **Menu > Traffic > Traffic in a City**.

Enter the city/town name of where you would like to check for traffic destination.

To search for all traffic incidents:

- Select **Menu > Traffic > View Traffic Incidents**.

To clear the traffic incidents list:


- Select **Menu > Traffic > Clear Traffic Incidents**.

Description	mi	Map All	Avoid All	Ignore All
Lane closed, on MANHATTAN BRG EB at MANHATTAN BRG	0.2			
Road construction, on HOLLAND TUNEL at OUTBOUND HOLLAND TUNEL	1.7			
Lane closed, on CHARLTON ST at HUDSON ST	1.7			
Lane closed, on HOLLAND TUNEL EB at HOLLAND TUNEL	1.7			
Road construction, on W HOUSTON ST at HUDSON ST	1.8			
Lane closed, on HOLLAND TUNEL WB at HOLLAND TUNEL	2.5			
Slow traffic, on HOLLAND TUNEL at IJOUND HOLLAND TUNEL	3.3			
Two lanes closed, on RT-139 at JERSEY AVE	3.6			
Slow traffic, on New Jersey TPKE EB at 14	8.5			
Slow traffic, on NEW JERSEY TPKE EB at I-78	8.5			
Road construction, on NEW JERSEY TPKE SB at 14	12.3			

Using the Traffic Incidents List

Once CoPilot has found traffic incidents, select one to view detailed information relating to the incident. Choose **Ignore** to continue on your planned route, **Avoid** to calculate a new route that avoids the incident, or **Show Map** to display the incident on a map.

In the Traffic Incidents list you can also select **Map All** to see all listed incidents on the map, **Avoid All** to calculate a new route that avoids all incidents, or **Ignore All** to continue and ignore all incidents.



Advanced

Setting Map Preferences

You can also set up what sort of maps CoPilot uses.

- Click **Menu > Settings > Map**.

The available settings are:

- **Units:** Choose to display Miles or KM on your maps.
- **Map Rotation:** Choose **Heading Up** to always be travelling upwards on the screen, or select **North Up** to hold the map static as you travel along your route.
- **Stylus control:** Select **Box Zoom** or **Drag Map**.
- **General:** Choose whether to display turn restrictions by checking or unchecking the box. Check the box marked '**Display View Shortcuts**' to display a driving view button which allows you to quickly change between driving views.
- Click **OK** to apply the settings and return to the Settings menu.



Setting Map Styles

- Click **Menu > Settings > Map Styles**.

Choose the default setting for the day or night mode from the lists. The options are **Automatic**, **Night** and **Day**.

If you select Automatic, CoPilot will automatically switch to night mode when it starts to get dark, based on the current time and location.

Select Styles: Choose to display **Day** or **Night** map styles.

You can select from a range of industry standard map presentation styles and color themes using the **Map Style** list. A preview is shown each time you select one, once you are happy with your selection click **OK**.



Advanced

Checking the GPS Status

- Click **Menu > Settings > GPS > GPS Status**.

The GPS Status window shows detailed information regarding the GPS fix and signal strength which your laptop uses for guidance. In this window you can see your current latitude and longitude position, the UTC time and date, your speed and your elevation (feet above sea level).



Note:

Your GPS signal will be limited when the receiver is inside buildings, tunnels or garages. To work effectively the GPS receiver needs to have a clear line of sight to the sky.

Track Playback

CoPilot automatically tracks you as you drive and stores each completed trip. You can play back any previously completed trip.

- Click **Menu > Settings > GPS > Track Playback**.
- Select the track to play from the list, click **OK**.

To control the speed of the playback, or to close it, see instructions for playing a demo on [page 34](#).



Adjusting the Volume

- Click **Menu > Settings > Volume**.

Use the + and - symbols to increase or decrease the volume of the spoken instructions. To turn off the 'click' sound which occurs when you touch the screen, uncheck the **Button Sounds** box.




Advanced

Adjusting the Guidance Settings


You can adjust the way CoPilot guides you.

- Click **Menu > Settings > Guidance**.
- Select the distances at which you want CoPilot to speak to you when approaching a turn.
- Select what information you wish to be displayed on the customizable part of the screen, see [page 26](#).
- Check the box to **Display Route Arrow**, or uncheck to remove.



Adjusting Your Safety View


- Click **Menu > Settings > Driver Safety**. From here you can alter the settings of the Safety View in the following ways:
- **Display Map Near Turns:** Decide whether to show a 2D/3D zoomed map on the approach to each turn or always show the Driver Safety screen. Select **Yes** to display the map or **No** not to.



- **When the Turn is Within:** If you selected **Yes** above, choose the distance before the turn at which you would like the map to be displayed. The distance can be set between 0.3 miles and 1 mile.
- **Map Type:** If **Display Map Near Turns** is set to **Yes**, select whether to use a 2D or 3D map when approaching turns.

Setting the Language and Speech

- Click **Menu > Settings > [Map Icon] > Language and Speech**.
- Select a language from the **Choose a Language** picklist.
- Select a voice from the **Choose a Voice** picklist. Select **Test** to hear a sample of the chosen voice. For text-to-speech directions, select **Samantha**.



Advanced






Playing a Demo

CoPilot contains a demonstration trip to a pre-defined destination. To view the demo:

- **Menu** >  > **Play Demo**.

Click the camera on the map to open a panel of buttons that lets you control the demo or a track playback.




- Speed up by clicking **Faster** or slow down by clicking **Slower**.
- Click  to go back to the beginning of the demo or track.
- Click  to go back to the most recent turn.
- Click  to pause.
- Click  to forward to the next upcoming turn.
- Click  to close the demo or track.





Keyboard

- **Menu** > **Settings** >  > **Keyboard**.

This setting affects CoPilot screens that include a keyboard for text entry. Select a keyboard type from the drop-down menu. The options are Alphabetical, QWERTY, AZERTY.



About CoPilot

- To access the version, data number and product key of your CoPilot Truck software, click **Menu** > **Settings** >  >  > **About CoPilot**.




Advanced

Licensing

- Click **Menu** > **Settings** >  > **Licensing**.

The Licensing settings allow you to deactivate license regions.



Transferring Your CoPilot Truck License

If you wish to use your CoPilot Truck application and maps license on a different laptop, select **Deactivate** and follow the on-screen instructions.



Advanced

CoPilot Live FleetCenter



CoPilot Truck may be combined with CoPilot Live FleetCenter for fleet management and real-time tracking. FleetCenter is a web-based extension of our CoPilot Truck GPS navigation solution that provides real-time location tracking for fleet managers and customers, job dispatch, instant messaging and historical reporting.

CoPilot Live FleetCenter provides the following capabilities:

- Lets your dispatcher see your exact location on an Internet map.
- Enables your dispatcher to send you instant messages from the FleetCenter web site when you are on the road.
- Allows your dispatcher to see your destination and estimated time of arrival.
- Lets your dispatcher send you new stops that are automatically added to your CoPilot Truck itinerary.
- Allows drivers to send tracking invites by e-mail directly from CoPilot Truck.
- Includes historical reports, exception reports, and bread crumb trails.



For More Information

For more information and pricing please contact:

888-872-8768

or send an email to:

fleetcenterinfo@alk.com.

Please include your company name, contact name, phone number, email address, product you are interested in and license quantity.



PC*MILER Route Types

PC*MILER Route Type and Option Descriptions

Safety Note:

CoPilot Truck is designed as a tool to get you from Point A to Point B along the most efficient and truck-specific routes. However, some of the information in the database may change from time to time. **You must stay alert and pay attention to road signs at all times.**

PC*MILER Practical Routes

Practical routes represent distances and driving routes that a driver would normally take to minimize time and cost. Practical Routes model the trade-off between taking the most direct path and staying on major, high quality highways. Interstate highways are given a higher priority than toll roads, which, in turn, are given a higher priority than secondary highways, and so on. Routing instructions and mileage can be used when actual travel distances and directions are needed.

PC*MILER Practical routings consider distance, road quality, terrain, urban/rural classifications, truck-restricted roads, and designated principal and secondary through routes.

PC*MILER Practical Route mileage and state-by-state mileage breakdowns can be used to supplement your regular fuel tax reporting documents for many states. Many state audit departments have purchased licenses to incorporate PC*MILER into their audit procedures.

PC*MILER Shortest Routes

PC*MILER Shortest Routes represent distances and driving routes that a vehicle would take to minimize total distance traveled while still following a reasonable route. For instance, Shortest Route mileage and routes will also avoid truck-restricted roads and, in some cases, may favor a beltway rather than traveling directly through a city.

ALK believes, however, that carriers and shippers alike would all be better served by using a mileage tariff based on actual miles traveled (i.e. similar to those generated using the PC*MILER Practical Route option), which would more accurately reflect true transportation costs.

PC*MILER National Network Routes

The National Network is a U.S. government-designated system of highways originally established by the Surface Transportation Assistance Act of 1982 (STAA). This routing option is based on the federally-designated National Network system updated in the April, 1992 Code of Federal Regulations, Part 658, Appendix A. The National Network includes the Interstate System (several minor segments are not included), and many selected U.S. and state highways. Highways continue to be added to the National Network by federal and state governments.

PC*MILER National Network routing represents distances and driving routes which are most reasonable and legal for the larger trucks authorized by the Surface Transportation Assistance Act of 1982. *(continued on next page)*



PC*MILER Route Types

National Network routing stays on the National Network to the maximum extent possible. Given that many areas are not directly served by the National Network, the origin and stop-offs of your route may not be on the National Network. In these cases PC*MILER will take the shortest reasonable path from the origin and stop-offs to the Network. Detailed Route Reports (driving directions) for PC*MILER National Network routes provide a warning wherever the route is forced to use a non-conforming link. These road segments should be checked before traveling.

National Network mileage tends to be higher than Shortest or Practical mileage.

These designated highways permit, at a minimum, 102" wide, single 48 ft. trailers and tandem 28 ft. trailers. The Interstate system and most, but not all, remaining designated routes are open to 80,000 pound vehicles. Certain states, notably Arkansas and Mississippi, have designated certain National Network segments with less than an 80,000 pound capacity.

In addition to the National Network highways, access routes and access policies are components of routing STAA dimensioned trucks. The Federal government has mandated that no state may prohibit travel from the National Network for a minimum of one road mile unless safety restrictions apply. Additionally, no state may deny reasonable access to terminals and facilities for food, fuel, repairs and rest.

Several states maintain more generous access policies and lists of specifically designated access routes to terminals and facilities. (For detailed information about pre-approved access routes, contact the individual states.) Should you

need to travel beyond the National Network and the access roads, you must acquire the proper permit.

Note: These suggested National Network routings are based on official highway maps, the Code of Federal Regulations, and information provided by state governments. It is provided without a warranty of any kind. The user assumes full responsibility for any delay, expense, loss, or damage which may occur as a result of its use.

PC*MILER 53 Foot Trailer Routing

Because every mile equals money, PC*MILER now offers enhanced routing specifically for 53'/102" trailers. The calculations for these routes are based on National Network routing, with the addition of roads that permit 53'/102" trailers.

Detailed Route reports for PC*MILER 53' Trailer routes now provide a warning wherever the route is forced to use a non-conforming link (a red exclamation point also appears in the route window for the generated route).



PC*MILER Route Types

Heavy/Light Vehicle Routing (Override Restrictions)

In addition to the five basic route types, the Heavy and Light Vehicle routing option is also a critical setting. A “heavy vehicle” is one weighing at least 80,000 pounds; a “light vehicle” weighs less than 80,000 pounds.

When **Override Restrictions** is left unchecked, Heavy Vehicle routing will be in effect, so both truck-prohibited and truck-restricted roads will always be avoided. In addition, Heavy Vehicle routing takes nationwide 13’ 6” height restrictions into account.

Checking Override Restrictions activates the Light Vehicle option. With Light Vehicle routing active, truck-prohibited roads will always be avoided, but truck-restricted roads are considered for a route. (Preference is normally given to Interstates, major highways, and major thru-roads where possible.)

Safety Tip: Winter Roads

For winter roads in Manitoba and North West Territories, Canada, road safety information for heavy vehicles using these roads can be found at: http://www.gov.mb.ca/tgs/hwyinfo/winterroads/heavy_traffic.html

Toll Roads

If **Avoid If Possible** is checked, CoPilot will avoid long stretches of toll roads but won’t take long, impractical detours to avoid toll bridges and tunnels. Example: a trip from Boston, MA to Albany, NY avoids the Massachusetts Turnpike, but a trip from Camden, NJ to Philadelphia, PA includes a toll bridge.

International Borders Open

If this option is checked, the calculated trip will ignore international boundaries (Canada and Mexico) when necessary to generate the best route. If this option is not checked, borders will never be crossed. For example, if all your stops are in the United States, the route will stay in the U.S. even though the most practical or shortest route would involve some Canadian mileage.

PC*MILER Hazmat Routing

CoPilot calculates routes for hazardous materials based on over thirty different road categories. Hazmat route options include: **General, Caustic, Explosives, Flammable, Inhalants,** and **Radioactive**. To calculate normal (non-hazmat) PC*MILER routes, select **None**. The table in Appendix B on the next two pages shows how each PC*MILER hazmat route type handles each hazmat road category.



PC*MILER Route Types

PC*MILER Hazardous Material Route Types & Road Categories

CoPilot Truck calculates routes for hazardous materials based on over thirty different road categories. The table below and on the next page shows how each PC*MILER hazmat route type handles each hazmat road category.

favor = routing will prefer these segments

avoid = routing will go around these segments whenever possible

no change = routing will not be altered in any way

discourage = a lesser degree of avoidance, used when a state or road authority allows hazmat only at certain times of day, with prior notification, by permit, or in limited quantities, and for tunnels not otherwise classified

#	Hazmat Routing Category	PC*MILER HazMat Routing Type						Detailed Route Report Restriction Column Text	Map's HazMat Restriction Legend
		General	Caustic	Explosives	Flammable	Inhalants	Radioactive		
0	None	no change	no change	no change	no change	no change	no change		none
1	Alternate	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
2	Preferred	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
3	Designated	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
4	Prohibited	avoid	avoid	avoid	avoid	avoid	avoid	Prohibited	Prohibited
5	Restricted	discourage	discourage	discourage	discourage	discourage	discourage	Restricted	Restricted
6	Unused	-	-	-	-	-	-	-	-
7	Explosive Designated	no change	no change	favor	no change	no change	no change		Desig Expl
8	Inhalant Designated	no change	no change	no change	no change	favor	no change		Desig Inhal
9	Explosive & Inhalant Designated	no change	no change	favor	no change	favor	no change		Desig/Pref/Alt
10	Tunnel	discourage	discourage	discourage	discourage	discourage	discourage	Tunnel	Restricted
11	Tunnel & Alternate	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
12	Tunnel & Preferred	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
13	Tunnel & Designated	favor	favor	favor	favor	favor	favor		Desig/Pref/Alt
14	Tunnel & Prohibited	avoid	avoid	avoid	favor	avoid	avoid	Proh. Tunnel	Prohibited
15	Tunnel & Restricted	discourage	discourage	avoid	avoid	avoid	avoid	Restr. Tunnel	Restricted
16	Unused	-	-	-	-	-	-	-	-
17	Unused	-	-	-	-	-	-	-	-

(continued on next page)



PC*MILER Route Types

(continued from previous page)

18	Caustic, Explosive, Flammable & Radioactive Prohibited	no change	avoid	avoid	avoid	no change	avoid	Many Commodities Prohibited	Some Cmts Prohib.
19	Explosive Restricted	no change	no change	no change	no change	no change	no change	Expl. Restr.	Restricted
20	Unused	-	-	-	-	-	-		none
21	Explosive & Flammable Prohibited	no change	no change	avoid	avoid	no change	no change	Expl. & Flam. Prohibited	Some Cmts Prohib.
22	Radioactive Preferred	no change	no change	no change	no change	no change	favor		Desig Rad
23	Radioactive Designated	no change	no change	no change	no change	no change	favor		Desig Rad
24	Radioactive Prohibited, Explosive Restricted	no change	no change	discourage	no change	no change	avoid	Rad. Prohib. Expl. Restr.	Some Cmts Prohib.
25	Radioactive Prohibited	no change	no change	no change	no change	no change	avoid	Rad. Prohib.	Some Cmts Prohib.
26	Escort Needed	no change	no change	no change	no change	no change	no change	Escort	none
27	Unused	-	-	-	-	-	-		none
28	Explosives, Inhalant & Radioactive Designated	no change	no change	favor	no change	favor	favor		Desig/Pref/Alt
29	Radioactive & Explosive Designated	no change	no change	favor	no change	no change	favor		Desig/Pref/Alt
30	Radioactive & Explosive Prohibited	no change	no change	avoid	no change	no change	avoid	Rad. & Expl. Prohib.	Some Cmts. Prohib.
31	Radioactive & Explosive Restricted	no change	no change	discourage	no change	no change	discourage	Rad. & Expl. Restr.	Restricted

Note: U.S. hazardous material routing restriction/designation information taken from *The National Hazardous Materials Route Registry* provided by the Federal Motor Carrier Safety Administration (FMCSA); and various other state and federal sources. Canadian hazmat data derived from government and municipal sources in each Province and Territory, and includes hazmat restrictions for major Canadian bridges and tunnels.



Support

CoPilot Customer Support Helpline

Call a member of our Customer Support team to receive professional and friendly assistance.

Telephone **888-872-8768 x551**

Our Support team is available Monday to Friday 9:00am to 5:00pm EST.

Online Support

Please email **email cpsupport@alk.com** for answers to your CoPilot support related queries and questions.

Alternatively, visit the support section at **www.alk.com/support** to register and activate your CoPilot.

Our FAQs section provides answers to customers' most frequent requests to help you get started and get the most out of CoPilot today.

Register your CoPilot

You should register your CoPilot navigation solution at **www.alk.com/register**

Registered customers receive information about downloads, map updates and new versions of CoPilot.



EULA

END-USER LICENCE AGREEMENT FOR COPILOT® SOFTWARE

Please read the following agreement (“Licence”) carefully.

Acceptance: Installation or use of the enclosed ALK Technologies, Inc. (“ALK”) software (the “Software”) on your laptop constitutes your acceptance of these terms. If you do not agree to the terms of this Licence, you must immediately delete the Software from your laptop and destroy any copies you made of the Software and of any written materials relating to the Software, and promptly return the Software and, if bought as part of a package, any associated laptops to your retailer for a refund.

Licence: ALK grants you, as an individual, a non-exclusive, non-transferable right and licence to install and use one copy of the Software on a single laptop at a time. If your Software includes CoPilot Central, you may install and use the CoPilot Central portion on a different laptop than the CoPilot portion. Your licence to use the Software is subject to you complying with the terms of this Licence. A licence is required for each installation of the Software, unless the Software is (i) installed temporarily on a computer during the repair or maintenance of the laptop on which the Software is normally installed and (ii) is immediately deleted from such laptop as soon as those repairs or maintenance are complete. You may make one copy of the Software for backup purposes only.

Copyright: United States copyright law and international treaty provisions protect the Software. You agree that no title to the intellectual property in the Software is transferred to you. You further acknowledge that title and ownership rights will remain the exclusive property of ALK, and you will not acquire any rights to the Software except as expressly set out in this licence. You agree that any copies of the Software will contain the same proprietary notices that appear on and in the Software.

Prohibited Use: Unless you have ALK’s prior written permission, you may not (i) use, copy, modify, alter, or transfer the Software or accompanying documentation, except as expressly permitted in this Licence; (ii) translate, disassemble, decompile, or reverse engineer the Software (iii) sublicense or lease the Software or its documentation; or (iv) use the Software in a multi-user or networked environment or on a rental basis or in a time-sharing or computer service business.

Limited Warranty: ALK warrants that the Software will perform substantially in accordance with the accompanying written materials for a period of 30 days from the date of purchase. Any implied warranties relating to the Software are limited to such 30 day period provided that limitation is permitted by applicable law.

End-User Remedies: If the Software does not conform to the “Limited Warranty” above, ALK’s entire liability and your sole and exclusive remedy will be, at ALK’s option, either to (i) correct the error, or (ii) help you work around the error, or (iii) accept a return and issue a refund through your retailer. The Limited Warranty is void if failure of the Software has resulted from your fault, abuse, or misapplication. If we correct an error in the Software for you, then the unexpired portion of the Limited Warranty period as at the date you informed us of the error will apply to the corrected software once you have received the corrected version.

NO OTHER WARRANTIES: EXCEPT AS SET OUT IN THE LIMITED WARRANTY, ALK DOES NOT WARRANT THAT THE SOFTWARE IS ERROR FREE. ALK DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO THE SOFTWARE, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. Some jurisdictions do not allow the exclusion of implied warranties or limits on how long an implied warranty may last, or an exclusion of incidental damages. This means the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights depending on your country.

No Liability for indirect loss: In no event will ALK be liable to you for any loss of profit, wasted time, lost business or for any incidental, or indirect loss of any kind arising out of the performance or use of the Software, even if ALK has been advised of the possibility of such damages.

Termination: Without prejudice to its other rights, ALK may terminate this Licence if you fail to comply with these terms and conditions. In that situation, you must destroy all copies of the Software.

Limitations on Export: You hereby expressly agree not to export or re-export the Software, in whole or in part, in violation of any export laws or regulations of the United States.

DISCLOSURE FOR PRODUCTS CONTAINING CANADIAN POSTAL CODE AND/OR CANADIAN STREET-LEVEL DATA: Based on Computer File(s) licensed from Statistics Canada. © Copyright, HER MAJESTY THE QUEEN IN RIGHT OF CANADA, as represented by the Minister of Industry, Statistics Canada 2003. ALK Technologies, Inc. is an Authorized User of selected Statistics Canada Computer File(s) and Distributor of derived Information Products under Licensing Agreement 6147. No confidential information about an individual, family, household, organisation or business has been obtained from Statistics Canada.



EULA

U.S. Government Restricted Rights: The Software is provided with restricted and limited rights. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in the appropriate subparagraphs of the Commercial Computer – Restricted Rights clause at 48 C.F.R. 52.227-19 or in the appropriate subparagraphs of the Rights in Technical Data and Computer Software clause at 252.227-7013 of the Defence Federal Acquisition Regulations. The Copyright to the Software is held by ALK Technologies, Inc., 1000 Herrontown Road, Princeton, NJ 08540 USA.

Choice of Law: This Licence is governed by the laws of England.

END USER LICENSE FOR SPEECH PLAYBACK

This license applies to the speech playback function included in your Software, if any.

Copyright (c) 2002, Xiph.org Foundation. Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Personal Use Only. You agree to use this Data together with COPILOT for the solely personal, non-commercial purposes for which you were licensed, and not for service bureau, time-sharing or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for your personal use to (i) view it, and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws.

Restrictions. Except where you have been specifically licensed to do so by ALK, and without limiting the preceding paragraph, you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning laptops or any mobile or wireless-connected electronic or computer laptops, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs.

Warning. The Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic data, any of which may lead to incorrect results.

No Warranty. This Data is provided to you "as is," and you agree to use it at your own risk. ALK and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: ALK AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF ALK OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.



EULA

Export Control. You agree not to export from anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations.

Entire Agreement. These terms and conditions constitute the entire agreement between ALK (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing Law. The above terms and conditions shall be governed by the laws of the Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the Netherlands for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.



