

ComproFM2 User's Guide

Compro Technology, Inc.
www.comprousa.com

Copyright © 2001-2004. Compro Technology, Inc. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Compro Technology, Inc.

Compro, VideoMate, Poladyne, Play with Power, and the Compro logo are trademarks of Compro Technology, Inc. Other names and marks are trademarks of their respective owners.

COMPRO makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability, quality, or fitness for any particular purpose. The information in this document is subject to change without notice. COMPRO reserves the right to make revisions to this publication without obligation to notify any person or entity of any such changes.

Compro Technology, Inc.

Tel. +886 2 2918 0169, Fax +886 2 2912 1465

3/F, No.12, Alley 6, Lane 45, Pao Shin Road

Hsintein City, Taipei, Taiwan, R.O.C.

www.comprousa.com

Table of Contents

1 Introduction	1
Key Features.....	2
Installation.....	3
Updates.....	3
Remove software	3
2 Remote Control	4
Definitions and Usage	4
3 ComproFM User Interface	8
Control Panel	8
Configuration.....	11
Station Options	11
Recording Options.....	16
System Devices Options	18
4 Using ComproFM	21
Listening.....	21
Recording.....	21
Playback	22
Browse the Compro Web Site	24
5 Troubleshooting.....	31
Driver Installation.....	31
Error Code: 0x1000006	32
No Audio.....	34
Contacting Compro Technical Support.....	34

1. Introduction

ComproFM lets you enjoy FM radio programs on your PC. Listen to music or other programs while you work or browse the Internet. All this, with the industry's first universal remote control.

You can also record your favorite programs to MP3, WMA, and WAV formats for later playback. You can later download these recordings to your MP3 player (purchased separately) for listening on the go.



Key Features

- Listen to and record live FM programs.
- Powerful and easy to use scheduled recording function.
- Easy-to-use, familiar user interface.
- Deluxe, ergonomic, multi-function IR remote control.
- Capture audio and encode to WAV, WMA or MP3 formats.
- My favorite stations — Sort and rearrange station order.
- Easy to install.
- Stereo and mono support.
- Auto tune for best sound quality frequencies.

Installation

ComproFM is usually automatically installed while you install the VideoMate TV drivers. Follow the instructions of the software installer.

You can also manually install it by inserting the installation CD. Choose “Exit” or “Cancel” when the installation program starts. Open Explorer, double-click on the “setup.exe” in the folder named ComproFM. ComproFM will be installed right away.

Updates

User satisfaction is the first priority for Compro Technology. Your opinion is crucial in improving our products. Therefore, Compro Technology is continuously improving our products. You can download the latest version of ComproFM from our website at

<http://www.comprousa.com/download>

After downloading the patch files of ComproFM, just double-click the update file. It will automatically start the installation program.

Remove software

You can remove ComproFM through “Add/Remove Programs” in Control Panel. Select the ComproFM entry and click on the “Remove” button. ComproFM will be removed from your computer.

2. Remote Control

Definitions and Usage


Remote control keypad lets you control the ComproFM application with a familiar, user-friendly interface.

The next two pages describe how to use the remote control to operate ComproFM.

Note

The Compro remote control cannot be reprogrammed to control other appliances such as your VCR or satellite decoder box.

Remote Control



Remote Control

Key Number	ComproFM Function
0-9	Pre-set stations
10	Mute
11	Minimize/Maximize
12	Start/Stop ComproDVD (if available)
13	Start/Stop ComproFM
14	Start/Stop ComproPVR (if available)
15	Rewind
16	Play/Pause during playback
17	Forward
18	Jump to last station
19	Stop
20	Not used
21	Open on-line help file
22	Open properties setup dialog box
23	Up Arrow
24	Scan Down
25	Down Arrow
26	Scan Up
27	Volume Adjustment
28	Open play list
29	Station Up
30	Station Down
31	Record
32	Not used
33	Not used
34	Enter Frequency
35	Sleep Function

Note

FM function is only available with supported hardware.

3. ComproFM User Interface

Control Panel

The ComproFM control panel resembles the controls on a radio. Keep in mind that not all options are available at all times, and may be grayed out or inaccessible depending on your hardware setup and FM services available. The following pages describe the ComproFM control panel functions and usage tips.



ComproFM User Interface

ICON	Keyboard Shortcut	Description
	Ctrl-A	Always on top
	F1	Online Help System - Open HTML help file
	Z	Minimize ComproFM
	Ctrl-W	Exit ComproFM
	Page Up	Station Up - Jump up to next pre-set station
	Page Down	Station Down - Jump down to next pre-set station
	N	Last station - Jump back to last selected station
	R	Record - Start recording FM audio program to system
	Right Arrow Key	Station searching / Forward when playing audio files
	Left Arrow Key	Station searching / Backward when playing audio files
	Space Bar	Pause - Suspend playback
	O	Stop - Stop current action, e.g., recording, playback, Timeshifting.
	Space Bar	Play - Begin playback of recorded program
	K	Enter frequencies button

ComproFM User Interface


ICON	Keyboard Shortcut	Description
	S	Properties - Open FM radio properties window
	B	Schedule Recording setup.
	+ / -	Volume Control - Increase or decrease sound intensity. Drag your mouse over this icon to change the audio volume.
	Ctrl-S	Stereo/Mono switch
	M	Mute - Press to mute or restore sound
	I	About window - Shows ComproFM radio version and copyright information
	W	Show/Hide number pad
	Number keypad	Select pre-set stations
n/a	L	Sleep function
n/a	E	Open a browser window and go to the Compro web site.

Configuration

Use the ComproFM options menus to control how

ComproFM looks and functions. Click the **Options**  button to open the Options dialog box. The Options dialog box is composed of tabbed pages, each with its own group of feature-specific settings.

Station Options



Follow these steps to setup and customize your station list.

Autoscan

The first time you start ComproFM, Autoscan will automatically search for all available FM stations.

1. The number of scanned stations varies according to the quality of reception and your country settings.
2. You can interrupt the scanning process by pressing the **Stop** button.
3. When **Autoscan** is finished, detected stations are automatically enabled and marked with a check mark.
 Stations, where a valid signal could not be detected, are disabled and marked with a blank.

After you are finished scanning for available stations, you may select **OK** to return to the display window, or customize the station list according to your preferences, as described below.

You can rescan later by pressing the **Autoscan** button.

Naming Stations

You can customize the station names by following these steps.

Step1. Double-click on the **Description field** of the station you wish to rename.

Step2. Type a new name in the text box.

Step3. Repeat steps 1 through 2 for any other stations you wish to rename.

Step4. Click **OK** to confirm your changes.

Set Mem+

During the **Autoscan** process, ComproFM automatically detects and enables stations with valid content. By default, every available station will be enabled and marked with


ComproFM User Interface

the icon. You can shorten the list of enabled stations to reduce station-browsing time disabling stations from the station list by clicking on the icon. You can re-enable stations by clicking on the Mem+ field again.

Disabled stations will not be played when you use the Station Up and Down buttons.

Random Access


Press Random Access button, you will see the popup window to enter the frequency of the radio station you wish to listen to. You can store the station to the station field by pressing **Store** button.



Pre-set Stations

You can assign up to ten of your favorite stations to the number pad keys by following these steps.

- Step1. Click on the **Pre-set No field** of the station you wish to pre-set.
- Step2. Choose the number you wish to use in the number box.
- Step3. Repeat steps 1 through 2 for any other stations you wish to rename.



Click **OK** to confirm your changes.

You can then select your favorite stations by press the number key.

Note:

There are ten numbers you can use, from 0 to 9.

The number box only shows the available numbers. If you wish to reassign a pre-set, choose the number you wish to use in the number box again.

You can select the number again to undo the change?.

Fine Tuning


ComproFM includes a fine-tuning feature. Check the box labeled, "Fine Tune." if you like to do so.

Fine-tuning is normally not necessary.

Sleep mode

You can enable this mode to automatically shutdown the system after 30 minutes, 1 hour, or 2 hours.

Recording Options



Recorded Programs Folder

Click on the  button to set the directory where recorded programs are stored. Check that you have ample disk space to store recorded programs.

Recording Format

Here you can select the audio format of recorded programs. ComproFM includes useful quality pre-sets, from MP3, WMA, and WAV format.

Recording Quality

Choose between 8.000 KHz to 44.100 KHz sampling rate for your audio quality. For example, select 44.100 KHz if you want CD quality.

Note:

You must install Microsoft Windows? Media Encoder 9 in order to record to WMA or MP3 formats.

Microsoft Media Encoder 9 is included in the FM installation CD and will be installed automatically. This CODEC, however, only supports up to 56 Kbps audio bit rate.


Skip

Set the amount of programming time skipped when you press the Advance and Replay buttons during playback. This is useful, for example, for skipping commercial messages.

Recording Volume

Set the volume of recording files. Move the bar to the right to increase the volume.

System Devices Options



Audio Device

Normally, the audio device is set to the name of your sound card.

Note:

You must select the proper Audio devices for correct operation.

If you cannot see the name of your sound card, the sound card drivers are probably not correctly installed. Please see Chapter 5, "Troubleshooting."

Audio Input

Choose the “**AUX-In**” if you are using an internal audio patch cable connected to “**AUX-In**” of your sound card.

If you are using an external audio patch cable, you should connect it to the “**Line-In**” port on your sound card.

Note:

If you cannot see the audio device on the field, the sound card drivers are not properly installed. Please make sure that your sound card works normally and reinstall the sound drivers, if necessary.

Country/Region

Select the country or region you are located.

Note:

Choosing the wrong location may result in incorrect station scanning.

Support

Before contacting Compro for technical support, please check our FAQs (Frequently Asked Questions) on our website.

<http://www.comprousa.com/support>

If you click on the **E-mail Info** button, ComproFM will attempt to e-mail this information to the Compro Technical Support team. (support@comprousa.com).

When you contact the Compro Support team about a problem, please write enough details to help us determine the problem. Please also provide the product serial number (19 digits numbers) on the PCI TV tuner card.

Notes

Please check the troubleshooting chapter of this manual for more information before contacting Compro for support.

In order to solve the problem quickly, submitting the details about your problem is crucial to understanding the problem.

4. Using ComproFM

Listening

ComproFM lets you easily listen to your favorite FM programs. After autoscanning the stations, you are ready to listen.

Station Browsing

When listening to FM, you can browse stations with the

Station Down  and **Station Up**  buttons to scroll up and down through the available, enabled stations. The **Page Up** and **Page Dn** keys on your keyboard can be used instead.

Jump directly to the desired station by typing your keyboard or remote control, the station preset number.

The **Last Station**  (recall) button jumps back to the previously selected FM station.

Note

Some station numbers may not be available. Check the Station Options section for more information on shortening the list of enabled stations.

Recording

ComproFM is also a digital audio recorder. ComproFM can record FM programming and save it to your hard disk. ComproFM supports several encoding methods, letting you choose between high quality and economical use of

disk space.

To instantly start recording:

1. Press the **Record** button . ComproFM starts recording the audio currently showing in the display window. It will save it to a file on your disk.
2. Press the **Stop** button  to stop recording.
3. When you stop recording, ComproFM prompts you to name the file containing the recorded audio. Enter the name and press **OK**.

[Didn't CopmroPVR users complain about being asked the filename AFTER recording was complete? I think it's much more natural and easier to name the file up front. Tell Kevin Su that, if necessary, he can ask for the filename up front and then rename at the end of the recording session.]

To playback the recorded file, press the **Play** button and select the file you wish to view.


Disk usage

The actual disk space used primarily depends on the quality settings for recording. A higher quality setting, e.g., CD-quality, requires significantly more disk space than a lower quality setting, such as MP3-quality.

Playback

ComproFM can playback recorded audio files.

Press the **Play** button to open the **Play** dialog box. Highlight the file name in the program list, double-click or press **Play** to start playback.




During playback, the display area of the control panel provides information about currently playing program and provides playback control functions.

To delete a recorded program, open the Play List dialog box, by pressing ?? <how to open the dialog box?>, highlight the file name on the program list, and press the **Delete** button.

Scheduled Recording

ComproFM can be scheduled to record a FM program later or remind you of an upcoming program. The schedule can be set for a one-time or a recurring session. You can repeatedly record any regularly scheduled programming. Relax. Never miss your favorite shows.

Press the icon  to open the **Schedule Recording** dialog box.



Scheduled Program Lists

Create: Create a new scheduled recording event.

Modify: Modify an existing recording event.

Delete: Delete an existing recording event.

Event Information: Shows details about your recording schedule.

Scheduled Recording Settings

You can see the following after clicking **Create**.

The screenshot shows the 'Scheduled Recording Settings' dialog box with the following configuration:

- Event Name:** FM_CH005_20040414_1700
- Recording quality settings:** Format: WMA File, Quality: CBR,128Kbps, Available Time: 5668mins
- Recording settings:** Scheduled mode: Record, Station: Ch 005: 99.70 MHz, Audio Mode: Stereo, Mute speakers while recording: checked
- After recording:** Keep system power on (selected)
- Date/Time settings:** Frequency: weekly, Start Date: 4/14/2004, Start Time: 17:00, Duration: 00:30, Days: Monday, Wednesday, Friday (checked)

Event Name: Type the event name. The saved recording file will also use this name.

ComproFM will automatically create the **Event Name** and file name. The **Format** button lets you select the file name format.



Channel Number: Check this box to add station numbers to the names of the recording files.

Start Date: Check this box to add the start date to the names of the recording files.

Start Time: Check this box to add the start time to the names of the recording files.

Power Up Scheduling feature

If your hardware supports Compro Power Up Scheduling, ComproFM can wake your PC from the Shutdown (ACPI:S5) state. What about S3 or S4?

Note

In order to enable scheduled recording from the Shutdown state, the Power Up power switch circuit connections must be properly connected.

Power Up Scheduling is only available with VideoMate TV Gold, Gold Plus, and Ultra.

Enable automatic power function: Check this box if you wish to use Power Up Scheduling function, i.e., wake up the computer from Shutdown or Stand by states for scheduled recording.

This option is available only if your hardware <which

hardware? VMTV card and PC?> supports Power Up Scheduling.

Power Up will start your computer 5 minutes in advance of the scheduled time. If you set schedule to 4 o'clock, Power up will wake up your computer at 3:55. Therefore, you need to shut down the computer before 3:54 in order to let Power Up start the computer.


You may select from three possible actions to occur after recording is complete:

- **Shut down the system:** After recording, shut down the system.
- **System stand by:** After recording, put computer in stand by mode.
- **Keep system power on:** After recording, do not shutdown system.

Enable automatic logon: When using Power Up Scheduling, ComproFM will start Windows. If Windows requires you to enter a username and password during start up, you should check this box and enter the required information.

This option will be grayed out if your hardware doesn't support Power Up Scheduling.

If "Enable automatic logon" is checked, you will see a popup window.



There are three fields in the Automatic Logon window.

- **User:** ComproFM will detect your current user name automatically. Unless you wish to logon by a different user, there is no need to change it.
- **Password:** Type in your password.
- **Domain:** ComproFM will automatically detect your Windows Domain name, if any. In most home PCs, this field will be blank and need not be changed. (See Note below). **Do not modify** this field unless you need to logon to a different Windows Domain during the Power Up process.

Press the OK button to proceed.

Notes

Enabling the automatic logon function is only necessary when you need to type user name and password to logon to Windows.

The Windows Domain name is not the Internet domain name that you may be familiar with, e.g., Yahoo.com. Windows Domains usually only exist in business networks. For most users, this field should be left blank.

Your password will be stored on your computer. There is a chance that your password could be discovered by another user

The ComproFM does not use the logon information for any other purpose.

Recording Settings

Schedule mode: There are two ways to set the schedule.

- **Recording:** At the set time, ComproFM starts recording the program.
- **Reminder:** At the set time, ComproFM starts showing the program without recording it.

Station: Select the station you want to record.

Audio mode: Select the audio mode you want to record.

Mute speakers while recording: Check this box to mute speakers while recording. This feature is useful if the program is to be recorded while you are asleep.

Quality Settings

Format: Here you can select the audio format of recorded programs. ComproFM includes useful quality pre-sets, from MP3, WMA, and WAV format.

Choose between 8.000 KHz to 44.100 KHz sampling rate for your audio quality. For example, select 44.100 KHz if you want CD quality <repeated below?>

Quality: Choose between 8.000 KHz to 44.100 KHz sampling rate for your audio quality. For example, select 44.100 KHz if you want CD quality.

Date/Time Settings

Once: Select this to record this program once.

Repeat: Select this to record this program repeatedly. You can select any kind of combination in a week to record the programs repeatedly. You can press **Weekday** or **Daily** button to select multiple days. Press **Clear** to uncheck the boxes.

Date/Start Date: Select the date you want to record the program or the start date for repeat scheduling.

Start time: Select the starting time for recording.

Duration: Amount of programming to be recorded.


OK: Click it to add this schedule.

5. Troubleshooting

Driver Installation

The most common cause of problems with the TV Tuner Card is incorrect installation of the TV capture and TV tuner drivers (also called WDM drivers). If you have problems watching, recording, or timeshifting live TV, please check the status of the WDM drivers with Device Manager.

You should see both "VideoMate TV Capture" and "VideoMate TV Tuner" drivers, in the "Sound, video and game controllers" section of Windows Device Manager.



If these drivers are not there, please uninstall and reinstall the VideoMate TV drivers. Use the Add/Remove Programs Control Panel applet to uninstall the drivers. Reinstalling the drivers should fix this problem.

[I've recently learned that many people are unfamiliar with the Add/Remove Programs Control Panel applet. Please


add a figure of it here, with the Compro drivers entry. These days, most software install the Uninstall item in the Start Menu, so people rarely use the Add/Remove Programs Control Panel Applet. Also add it to the support web site.]

Error Code: 0x1000006

This error code generally indicates a WDM driver installation problem. Please uninstall and reinstall the WDM drivers, as described above.

If the problem persists, the cause could be an IRQ conflict. IRQ conflicts happen when other devices, e.g., network card or sound card, in your computer share the same IRQ with your TV tuner card.

Use Device Manager to detect IRQ conflicts. In Device Manager, choose "View->Resource by type" and click on the "+" besides Interrupt request (IRQ). Please see the figure below.



For best performance, no other device should share an IRQ with the VideoMate TV card.

If another device shares an IRQ with the TV tuner card, remove other PCI cards from your PC and insert TV card on another slot. Then uninstall and reinstall the TV card driver. This usually solves the problem. If the problem persists, try moving the PCI TV Tuner card to another PCI slot.

After you can successfully use ComproFM, install the other PCI devices one at a time. Restart your system and test ComproFM after installing each card.

Note

Note the IRQ numbers of networking, sound, and SCSI cards. They should not share an IRQ with the VideoMate TV tuner card.

No Audio

Check that the sound is not muted or low volume in the Windows Volume Control dialog. (Double-click on the speaker icon in the system tray.)

Verify that the external audio patch cable is connected between the Audio-Out of TV tuner card and Line IN of your sound card if you select the audio source to “Line-In”. Or the inner audio patch cable is connected between the inner Audio-Out of TV tuner card and AUX of your sound card if you select the audio source to “AUX”. You can verify the connection refer to the Hardware Installation.

Also, if you have Norton AntiVirus running, please uncheck the Instant Messenger protection in the Internet in options.

No audio on the recorded file

This may be a result of choosing the wrong record audio source in the System Device in ComproFM Settings.

If you are using an **external** audio patch cable, verify that it is connected between the Audio-Out of TV tuner card and Line-In of your sound card and that you selected the audio source to be “Line-In.” If using the **internal** audio patch cable, check that it is connected between the internal Audio-Out of the TV tuner card and AUX-In of your sound card and that you selected the audio source to “AUX.”

Check the **ComproFM** in the Record tab of Settings dialog for recording volume levels that is not too low.

Poor FM reception

Poor FM reception is usually the result of interference or weak signal. Please try using another FM radio in the

same location to test if the reception is OK. Make sure that you connect the FM antenna tightly and try repositioning the antenna for optimum reception.

Why isn't the MP3 128Kbits format available

ComproFM uses Microsoft Media Encoder 9 to be the encoder. However, Microsoft Media Encoder 9 can only support 56Kbits audio bit rates. Therefore, the 128Kbits audio bit rates of MP3 is not available.

Contacting Compro Technical Support

Before you submit an email for support, you should check our FAQs. Please see <http://www.comprousa.com/support>

When contacting Compro for technical support, please use the Compro support request form and provide as much of the requested information as possible. Please write the details in order to determine the problem. And also provide the product serial number (19 digits numbers) on the PCI card. Please use the form from below.

<http://comprousa.com/support/form.htm>

Notes

Providing the product serial number is crucial to verify the exactly product you own for evaluating the problem.

In order to solve the problem quickly, submit the details about your problem are very important for support. We need the information to understand the problem.
