


HyCNC-4P (4 Axis)

USB Motion Control

Parallel Port Interface

Instruction Manual



Cautions



HyTechWorks provides its products and services “as it is”. HyTechworks accepts no responsibility for performance of any machine or any damage or injury caused by using its products and services.

All computer controlled machine tools are potentially dangerous if they are incorrectly designed or operated. It is your responsibility to insure that you understand the implications of your design and build and the compliance requirements with any legislation and codes of practice applicable to your country. If you have any doubt, please consult qualified experts rather than take risks.

HyTechWorks reserves the right to change its designs without further notice.

Contents

Introduction	1
Minimum System Requirements.....	2
Shape and Connections	3
DB25 Connector.....	3
X/Y/Z/A Stepping Pulses	4
X/Y/Z/A Direction Pulses.....	5
PWM Outputs	5
Relay Control Outputs (Original and B Type)	6
RS485 Port (C Type)	6
Control Inputs	6
USB Connector	7
Working Status LED.....	7
USB Driver Install.....	8
Multiple Connection	17
Mach3 Configurations	20
HyCNC-4P PlugIns.....	20
Relay Output Config (Original/B Type)	23
X/Y/Z/A Axis Config.....	25
Spindle and PWM2 Config.....	28
Homing/Soft Limits.....	32
Slave Axis	37
Auto Tool Setting	39
EStop Configuration.....	47
Mach3 Watchdog Configuration.....	50
RS485 (C Type Only).....	52
Firmware Update.....	53
Normal Operation.....	53
Firmware Recovery	58
Low Level API.....	59

Device Identification and Opening59

Device Basic Information Reading60

Motion Control61

Other Controls62

Introduction

HyCNC-4P is a 4-axis machine tool motion control USB interface, replacing traditional PC parallel port. Its operation features are as the follows:

- ✧ Connect to PC via USB port, suitable for any netbook, notebook, desktop and tablet PC with USB ports.
- ✧ USB kernel mode driver compatible with 32/64 bit Microsoft Windows XP/Vista/7 OS.
- ✧ Compatible with Mach3 PC based CNC software, including version 3.043.066.
- ✧ Simultaneous connection for control axis expansion using API (127 USB device with 508 axis in theory), or control of multiple machines with single PC running Virtual PC or VMWARE.
- ✧ 4 axis linkage operation with 250KHz(-250) / 125KHz(-125) / 60KHz(-60) / 30KHz(-30) maximum stepping pulse frequency for each axis. The polarity of the direction signals can be defined according to requirements.
- ✧ A-axis can be used as a slave axis.
- ✧ 2-stage fast homing on all axis and automatic alignment between the master and slave axis during homing stage.
- ✧ Support professional and low-cost automatic tool setters.
- ✧ Emergency stop (can optionally stop PWM1/PWM2).
- ✧ 2 PWM outputs – PWM1 for spindle speed control and PWM2's duty cycle can be adjusted by a M code.
- ✧ 2 relay control outputs.
- ✧ Small size and easy to use, similar to an usb-parallel port adapter.
- ✧ Online firmware updating.
- ✧ Firmware recovery mode to eliminate the danger of firmware updating.
- ✧ Control signals on DB25 connector are defined as a PC parallel port

with 5V signal level.


- ✧ Working status LED.
- ✧ Motion control using a 32bit single chip microcontroller, greatly reducing real time requirement for PC OS.
- ✧ All control pulses are generated using on-chip hardware, eliminating motor vibration caused by control signal jitters.
- ✧ Reliable design that can work under severe conditions.
- ✧ Software watchdog monitors Mach3's proper running.
- ✧ Providing Windows API to support special control system (i.e. motion control using LabView Windows).
- ✧ RS485 Communication Port (HyCNC-4P-xxxC only).

Minimum System Requirements

- ✧ Pentium 1GHz or similar CPU, i.e. Atom N270.
- ✧ 512MB memory.
- ✧ 32/64 bit Microsoft Windows XP, Windows Vista or Windows7 OS.
- ✧ Mach3 software.

Shape and Connections

HyCNC-4P is assembled in a plastic cover with a DB25 and two fasten screws on one end, and an USB connector and working status LED on another end.




Size:

74mm(L) x 58mm(W) x 24mm (D)

DB25 Connector

The DB25 connector has 17 control signals as the following figure.




X/Y/Z/A Stepping Pulses

X/Y/Z/A Stepping Pulses are 0-5V position pulse with raising edge effective. The minimum pulse width us 1uS(-250)or 2uS(-125) or 4uS(-60) or 8uS(-30). Each output can be used to drive 15mA push and pull.

When connecting to a motor driver with low to high transaction, the following

connection should be used:



When connecting to a motor driver with high to low transaction, the following connection should be used (5V is not isolated from the HyCNC-4P):



X/Y/Z/A Direction Pulses

High level(5V) represents positive direction movement and low level (0V) represents negative direction movement. Each output can be used to drive 15mA push and pull.

The direction of a two-phase stepping motor can be changed by swapping connection of one of the coils. Therefore, the connection to the motor driver can be either one of the above connections.

If the motor direction can't be changed by an external switch, the first connection should be used for the motor moving position direction when the direction input is driven and the second connection should be used for the motor moving position direction when the direction input is not driven.

PWM Outputs

PWM1 and PWM2 have same base frequency (0.017-100000Hz adjustable by software). PWM1's duty cycle is proportional to spindle speed and PWM2's duty cycle can be adjusted by a M code. 0% duty cycle is low level and 100% duty cycle is high level output. Each output can be used to drive 15mA push and pull,

capable to drive an optical coupler like stepping pulse outputs do.

Relay Control Outputs (Original and B Type)

OUT1 and OUT2 can be used to control 2 relays with relay drivers. Each output can be used to drive 15mA push and pull.

OUT1 is mapped to Mach3's digital output port 1 pin 0.

OUT2 is mapped to Mach3's digital output port 1 pin 1.

RS485 Port (C Type)

OUT1 – RS485+

OUT2 – RS485-

Control Inputs

There are X-axis zero, Y-axis zero, Z-axis zero, A-axis zero/tool setter and EStop 5 inputs. Each input is connected to a microcontroller (3.3V supply) pin via a 10K resistor without using voltage converters. The signal switching level is not compatible with 5V circuitry. It is low level when input voltage < 1.15V and high level when input voltage > 2.15V.

X-axis zero is mapped to Mach3 digital input port 1 pin 5.

Y-axis zero is mapped to Mach3 digital input port 1 pin 4.

Z-axis zero is mapped to Mach3 digital input port 1 pin 3.

A-axis zero/tool setter is mapped to Mach3 digital input port 1 pin 7 (B Type is pin 9).

EStop 5 is mapped to Mach3 digital input port 1 pin 12.

USB Connector

The USB connector is used to communicate with a PC. Please use a high quality USB2.0 cable for better resistance of disturbance.

Working Status LED

Flash Rate	Status
1 flash/s	Normal working, without motion instruction.
2 flash/s	Normal working, with motion instructions (including zero motions).
5 flash/s	Firmware update.

USB Driver Install


Attention: USB driver install requires “administrator” privilege.

Double click install.bat under “USB Driver” directory. The install program will choose proper driver depends on the OS.


The following window pops up. Click “Next”.



Then the “Important Notice” window appears. Please read the “Important Notice” carefully. If agree, select “I accept” the click “Next”.



Windows Vista/7 will show the following warning. Click “Install this driver software anyway”.



Then the driver install begins. The following window pops up when finish. Click


“Finish”.




When plug in HyCNC-4P for the first time, the “Found New Hardware Wizard” window pops up. Select “Yes, this time only” the click “Next”.



Select “Install from a list or specific location” then click “Next”.




Select “Don’t search. I will choose the driver to install” then click “Next”.



PC will show suitable drivers. Select “HyCNC-4P USB Interface” then click “Next”.



PC starts installing the driver.




When finish, the following window poops up. Click “Finish”.




For C type hardware, RS485 virtual COM driver is installed for the new hardware. “Found New Hardware Wizard” window pops up. Select “Yes, this time only” the click “Next”.



Select “Install from a list or specific location” then click “Next”.



Select “Don’t search. I will choose the driver to install” then click “Next”.



PC will show suitable drivers. Select “HyCNC RS485I Com Port” then click “Next”.




PC starts installing the driver.



When finish, the following window poops up. Click “Finish”.



RS485 COM port number can be view from the device manager. Open the device manager. Expand “Ports(COM & LPT)”. The “COM3” at the back of “HyCNC RS485 Com Port” is the RS-485 virtual com port number.




Note: the latest USB driver can be downloaded from
http://www.hytechworks.com/Downloads/HyCnc/HyCNC_4P/index_e.html


Multiple Connection

Total 127 USB device can be connected to a PC. They can be all HyCNC-4P if possible. The difference between 2 HyCNC-4P is the USB serial number. The USB serial number can be revealed by the following method.

Plug a HyCNC-4P in to PC. The open Windows' "Devicie Manager" shown below. Expend "HyTechworks Hardware" to show all plugged in interface. Right click the interface, select "Properties".



Then click "Details" page and select "Device Instance Id". The last 8 characters following the VID and PID number is the USB serial number.



Mach3 Configurations

Please refer to proper materials regarding to Mach3 install.

Mach3 software download: <http://www.machsupport.com/downloads.php>


Mach3 document download: <http://www.machsupport.com/documentation.php>

There is no need to install Mach3 parallel port driver, which is not functional under 64 bit Windows. Normal USB-parallel port adapter cables don't work as well. The motion pulses have jitters because Windows' scheduling.

The following descriptions only address configuring HyCNC-4P for Mach3.

HyCNC-4P PlugIns


Open ZIP file contains HyCNC-4P.DLL and drag it to Mach3/PlugIns.




Note: the latest Mach3 plugin can be downloaded from

http://www.hytechworks.com/Downloads/HyCnc/HyCNC_4P/index_e.html


Click Mach3Mill icon on the desktop to start Mach3. The following window appear to allow user select proper motion control hardware. Select “HyCNC_4P” then click OK.




If there is no suitable hardware to run HyCNC-4P, the following error windows appears.




If there are more than one HyCNC-4P connected to the PC, another selection window appears. All available HyCNC-4P are listed in the window by their USB serial number. Select the one intend to use and click OK. If there is only one HyCNC-4P, no more windows will be shown and the only one HyCNC-4P will be used.



The firmware version and the hardware serial number of the HyCNC-P can be read by operating Mach3 main menu "Config"->"Config PlugIns".



Click "CONFIG" behind HyCNC_4P and a new window shows up.



FW is the firmware version and SN is the hardware serial number.

Relay Output Config (Original/B Type)

Operate Mach3 main menu's "Config"->"Ports and Pins". Then click on "Output Signals" page. Click to put green tick on "Enabled" column of the "Output #1" and "Output #2" row. Their "Port #", "Pin Number" and "Active Low" should be set according to physical connection(referring to chapter "Shape and Connections", section "Relay Outputs"), put a green tick on "Active Low" if the output is effective when low. "Output #1" and "Output #2" can be further mapped further to control mist, coolant and spindle motor etc.

Engine Configuration... Ports & Pins

Encoder/MPG's		Spindle Setup		Mill Options	
Port Setup and Axis Selection		Motor Outputs		Output Signals	
Signal	Enabled	Port #	Pin Number	Active Low	
Enable3	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Enable4	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Enable5	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Enable6	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Output #1	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Output #2	<input checked="" type="checkbox"/>	1	1	<input checked="" type="checkbox"/>	
Output #3	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Output #4	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Output #5	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Output #6	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	
Charge Pump	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	

Pins 2 - 9, 1, 14, 16, and 17 are output pins. No other pin

OK Cancel Apply

Coolant control can be used to test "Output #1" and "Output #2". Click on page "Spindle Setup". Set as the following figure for "Relay Control" and "Coolant Mist Control" blocks, in which "Output #1" is used to control mist and "Output #2" is used to control coolant.


Engine Configuration... Ports & Pins

Port Setup and Axis Selection		Motor Outputs		Input Signals		Output Signals	
Encoder/MPG's		Spindle Setup		Mill Options			
Relay Control <input checked="" type="checkbox"/> Disable Spindle Rel Clockwise Output <input type="text" value="1"/> CCW (M4) Output <input type="text" value="1"/> Output Signal #'s		Motor Control <input checked="" type="checkbox"/> Use Spindle Motor Out <input checked="" type="checkbox"/> PWM Control <input type="checkbox"/> Step/Dir Moto PWMBase Freq. <input type="text" value="10"/> Minimum PWM <input type="text" value="0"/> %		Special Functions <input type="checkbox"/> Use Spindle Feedback in Sync M <input type="checkbox"/> Closed Loop Spindle Cont P <input type="text" value="0.25"/> I <input type="text" value="1"/> D <input type="text" value="0.3"/> <input type="checkbox"/> Spindle Speed Averagi			
Flood Mist Control <input type="checkbox"/> Disable Flood/Mist reDelay Mist Output <input type="text" value="1"/> <input type="text" value="0"/> Flood Output <input type="text" value="2"/> <input type="text" value="0"/> Output Signal #'s		General Parameters CW Delay Spin UP <input type="text" value="1"/> Seconds CCW Delay Spin UP <input type="text" value="1"/> Seconds Delay Spind DOWN <input type="text" value="1"/> Seconds CCW Delay Spin DOWN <input type="text" value="1"/> Seconds <input type="checkbox"/> Immediate Relay off before d		Special Options, Usually Off <input type="checkbox"/> HotWire Heat for J <input type="checkbox"/> Laser Mode. fr <input type="checkbox"/> Torch Volts Cont <input type="checkbox"/> Torch Auto Of			
ModBus Spindle - Use Step/Dir as <input type="checkbox"/> Enabled Reg <input type="text" value="64"/> <input type="text" value="64"/> - Max ADC Count <input type="text" value="16380"/>							

确定 取消 应用 (A)


Then click Apply and OK to close the config window. Then switch to page "Diagnostics" of the Mach3's main interface and type "M7 ✓" to switch on mist,

“M8✓” to switch on coolant, “M9✓” to switch both off. Check output change accordingly.



X/Y/Z/A Axis Config


Operate Mach3 main menu’s “Config”->”Ports and Pins”. Click on page “Port Setup and Axis Selection”. Disable using “Port #1” and “Port #2” and keep “Kernal Speed” at 25000Hz. This is only associated with PWM frequency setting and has nothing to do with motion control using HyCNC-4P.



Then click on page “Motor Outputs”. Put green ticks in column “Enabled” on “X Axis”, “Y Axis”, “Z Axis” and “A Axis” row and “Dir LowActive” according to the requirements. The other columns have no effect on HyCNC-4P’s operation. The length unit used by Mach3 can be set by operation the main menu “Config”->“Select Native Units”. The choose “MM’s” or “Inches” as needed.



Finally, the motor operation characteristics need to be set. Operate the main menu “Config”->“Motor Tuning and Setup”.



Click on “X Axis” button on the upper right corner. Then fill in “Step per” (mm/inch) according to the following equation

$$\frac{\text{step motor steps per revolution} \cdot \text{driver microstep setting}}{\text{screw pitch}}$$


For example, the step has 200 steps per revolution. The driver microstep is 20. The screw pitch is 4mm. Then 1000 should be filled in “Set per” box.

“Velocity” is the maximum distance X-axis is allowed to move per minute. It is the maximum speed of G0 code. It also limits the maximum value for F code. The machine mechanical and control system performance limit the “Velocity”, as well as the “Acceleration” value after it.

The pulse width settings are not used by HyCNC-4P. Press “SAVE AXIS SETTINGS” to save X-axis settings. Then do same for “Y Axis”, “Z Axis” and “A Axis”.

The jogging can be used to test axis settings. Press “TAB” key on the keyboard to show jogging window as the following figure. First make sure Mach3 is not in “RESET” state by checking “RESET” button on the lower left corner not flashing

red-green box. If Mach3 is in reset state, click on “RESET” button to release the reset state (a steady green box encapsulate “RESET”). Press “X+” and “X-” in the jogging window to check X movement. Press “Y+” and “Y-” to check Y movement. Press “Z+” and “Z-” to check Z movement and press “A+” and “A-” to check A movement(if fitted).



The jog response speed can be adjusted by “Jog Buffer” length in “HyCNC-4P” plugin’s “CONFIG” setting. The smaller the buffer is set, the faster response speed becomes. However, the larger chance of inconstant motion caused by PC OS’s scheduling timing error.

Spindle and PWM2 Config

Operate the main menu “Config”->”Ports and Pins”. Click on page “Motor

Outputs”. Put a green tick on the “Spindle” row’s “Enabled” column. All other columns are not used by HyCNC-4P.

Encoder/MPG's		Spindle Setup				Mill Options	
Port Setup and Axis Selection		Motor Outputs		Input Signals		Output Signals	
Signal	Enabled	Step Pin#	Dir Pin#	Dir Low...	Step Lo...	Step Port	Dir Port
X Axis		2	6			1	1
Y Axis		3	7			1	1
Z Axis		4	8			1	1
A Axis		5	9			1	1
B Axis		0	0			0	0
C Axis		0	0			0	0
Spindle		0	0			0	0

OK Cancel Apply

Then click on page “Spindle Setup” page. If there is no circuit to control spindle rotating direction. Put a “X” on “Disable Spindle Relay”. If spindle’s rotating direction can be controlled by a H-bridge consisted by 2 relays, 2 relay outputs are needed. If spindle’s rotating direction can be controlled by a H-bridge consisted by 1 relays, 1 relay outputs are needed and the other is set to the undefined output. The PWM1 and PWM2 base frequency is calculated by equation

$$\frac{25000 \times 10}{\text{“PWM base Freq” value}}$$

The PWM1 and PWM2’s duty cycle is controlled by the hardware. Its accuracy is has nothing to do with “Kernel Speed”.

Engine Configuration... Ports & Pins

Port Setup and Axis Selection	Motor Outputs	Input Signals	Output Signals
Encoder/MPG's	Spindle Setup		Mill Options

Relay Control

☒ Disable Spindle Rel

Clockwise Output

CCW (M4) Output

Output Signal #'s

Flood Mist Control

☐ Disable Flood/Mist reDelay

Mist Output

Flood Output

Output Signal #'s

ModBus Spindle - Use Step/Dir as

☐ Enabled Reg -

Max ADC Count

Motor Control

☒ Use Spindle Motor Out

☒ PWM Control

☐ Step/Dir Moto

PWMBase Freq

Minimum PWM %

Special Functions

☐ Use Spindle Feedback in Sync M

☐ Closed Loop Spindle Cont

P I D

☐ Spindle Speed Averagi

General Parameters

CW Delay Spin UP Seconds

CCW Delay Spin UP Seconds

CW Delay Spin DOWN Seconds

CCW Delay Spin DOWN Seconds

☐ Immediate Relay off before d

Special Options, Usually Off

☐ HotWire Heat for J

☐ Laser Mode. fr

☐ Torch Volts Cont

☐ Torch Auto Of

确定

取消

应用 (A)

The ratio between PWM1's duty cycle and spindle speed is set by operating the main menu "Config"->"Pulley Selection". "Min Speed" is for 0% duty cycle and "Max Speed" is for 100% duty cycle. If "Min Speed" is for 100% duty cycle and "Max Speed" is for 0% duty cycle, put "X" on "Reversed".


Pulley Selection

Current Pulley	Min Speed	Max Speed	Ratio
Pulley Number 1	<input type="text" value="0"/>	<input type="text" value="24000"/>	<input type="text" value="1"/>

☐ Reversed

OK

The spindle operation can be tested by select the main menu "Function Cfg's"->"Spindle Calibration". Put a test value in RPM box and click "Spindle On/Off" button to start spindle. When spindle is rotating, the PWM1 duty cycle is shown in "Control Ratio" box. Click click "Spindle On/Off" button to stop spindle and the "Control Ratio" box shows 0.




When PWM2 is not used for Mach3 watchdog status output, PWM2 's duty cycle can be set by using a M code, i.e." M101". Create a new text file called m101.m1s under Mach3/Macros/Mach3Mill directory. Fill the following content by a text editor and save.

```
Declare Sub PWM2_SetDutyCycle Lib "HyCNC_4P"(ByVal duty As Double)
```

```
PWM2_SetDutyCycle(Param1())
```


PWM2_SetDutyCycle is a function declared in HyCNC_4P.DLL. It takes a double input value between 0.0 – 1.0 that controls the PWM2's duty cycle. Such value is provided by P parameter of M101 code (via Param1()). To test this M code, click on page "MDI" of the Mach3's main interface. Type "M101 P0.3✓" on the MDI input box and check 30% duty cycle output on PWM2. This M code can be used in GCode file(*.TAP) as well.



Homing/Soft Limits

The homing process is divided into 2 stages. The first stage is to seek the home switch with speed of G0 speed's predefined percentage (plugin config's "Home Speed%") according to pre-defined direction. When the home switch is triggered, the moving speed is decelerated to 0 and the second stage starts. The second stage is to leave the home switch with the speed of predefined % of the first stage speed towards the opposite direction. The home position is the spot where the home switch changes its state again. HyCNC-4P will set its internal coordinate counter according to the defined home switch offset. Then moving speed is decelerated to 0. The order of the homing is also defined. Operate the main

menu “Operator”-> “Edit Button Script”. The click on flashing “REF ALL HOME” to bring up the homingscript edit window.



DoButton(22), DoButton(23), DoButton(24), DoButton(25), DoButton(26), DoButton(27) are used to execute auto zero on X/Y/Z/A/B/C axis. The above script execute homing on Z axis, then Y axis, then X axis and finally A axis.

DoOEMButton(133), DoOEMButton(134), DoOEMButton(134) are used to reset X/Y/Z encoder. For the machine without encoder, these 3 line of script can be removed. More code can be added to the script to suit a specific machine. For example, a fast move to a predefined coordinate, i.e. (10, 15, 5, 90) is required after homing. The script looks like this.


```
DoButton(24)
DoButton(23)
DoButton(22)
DoButton(25)
While IsMoving()
Sleep(100)
Wend
```

```
code("G0 Z5")  
While IsMoving()  
Sleep(100)  
Wend  
code("G0 X10 Y15 A90")
```

This script execute homing like before. After homing is finished, it first fast moves Z axis to coordinate 5. After Z axis movement is finished, it fast moves to 10 on X axis, 15 on Y axis with 90 on A axis at the same time. After edit the script, save it to the system by operating menu "File" -> "Save". Clicking "REF ALL HOME" can run the saved script. If homing needs to be run from a GCode file, save above script to a mXXX.m1s file (i.e. m299.m1s) under Mach3/Macros/Mach3Mill directory.

More settings are needed to get homing working properly.

Operating the main menu "Config"->"Ports and Pins" and click on page "Input Signals". Put green ticks in "X Home", "Y Home", "Z Home" and "A Home" row's "Enabled" column if homing is required on X/Y/Z/A axis. Their "Port #", "Pin Number" and "Active Low" should be set according to physical connections (referring to chapter "Shape and Connections", section "Control Inputs"). If the inputs are low level effective, put green ticks in "Active Low" columns.



Then operating the main menu “Config”->”Motor Home/SoftLimits”. For the axis equipped with a home switch that requires the homing process, put a green tick in their “Auto Zero” column (attention: A axis home switch input shares the same input as the auto tool setting input(If homing is enabled on A axis, the auto tool setting can’t be enabled). “Home Neg” column defines the location of the homing switch. If the switch is on the negative direction (seeking towards negative direction for the home switch in the first stage), put a green tick in this column. “Speed %” defined the maximum speed of the second stage as the percentage of the first stage. When this setting generates stepping pulses more than 1000Hz, the accuracy is also affected. In this case, the homing accuracy in theory is

$$\frac{\text{distance per step} \cdot \text{pulse frequency}}{1000}$$

“Home Off.” is the machine coordinate of the zero switches. its value is set to HyCNC-4P coordinate when the home switch is triggered again in the second stage.

“Soft Max” and “Soft Min” define the working range of an axis. “Slow Zone” define deceleration distance before each ends. These values should be set

properly according to work range to avoid mechanical collision. For small CNC machine tools using step motors, home switches with soft limits provide an effective and low cost solution for safe machine operation.

Motor Home/SoftLimits

Entries are in setup units.

Axis	Reversed	Soft Max	Soft Min	Slow ...	Home ...	Home Neg	Auto ...	Speed %
X		100.00	-100.00	1.00	1.0000			10
Y		100.00	-100.00	1.00	2.0000			10
Z		100.00	-100.00	1.00	3.0000			10
A		100.00	-100.00	1.00	4.0000			3
B		100.00	-100.00	1.00	0.0000			10
C		100.00	-100.00	1.00	0.0000			10

G28 home location coordinates

X	<input type="text" value="0"/>	A	<input type="text" value="0"/>
Y	<input type="text" value="0"/>	B	<input type="text" value="0"/>
Z	<input type="text" value="0"/>	C	<input type="text" value="0"/>

OK


The first stage speed is defined by “Home Speed%” in plugin’s config. Operate Mach3 main menu “Config” -> “Config Plugins”.

PlugIn Control and Activation

Enabled	PlugIn Name	Config
	Flash-FlashScreen-SWF-PlugIn-A. Fenerty--B.-B...	CONFIG
	HyCNC_4P-V1.0	CONFIG
	JoyStick-JoyStick-PlugIn--Art-Fenerty-Ver-1.0a	CONFIG
	PrinterScope-Port-Scope-1.00.046	CONFIG
	TurnDiags-Turn-Diags-1.00.1	CONFIG
	Video---B. Barker-Ver-1.0	CONFIG

OK


Click “CONFIG” behind HyCNC_4P and a new window shows up.




Set and test "Home Speed%". It is percentage of the speed limits.

Slave Axis

A-axis can be used as a slave axis of X/Y/Z axis by clicking on menu "Config"'s "Slave Axis" item. When A-axis is used as a slave axis, the main axis's pulse per (mm or inch), speed limitation, maximum acceleration and direction signal's polarity are applied to the slave axis. The slave axis' end-stop switches have no effect but the end stop switches of the main axis stop motion on both axis.



When homing is carried out with a slave axis, machine seeks both home switches on the main and slave axis in the first stage. When both switches are triggered, machine decelerates to 0 and the second stage start. The machine also checks both homing switches in the second stage. The alignment error between the main and the slave axis is compensated during the deceleration stage. The alignment offset can be adjusted "Slave Axis Offset" in "HyCNC-4P" plugin's "CONFIG" setting.




Auto Tool Setting

Two commonly used auto tool setting processes are implemented. One for professional tool setter (one with retreatable spring loading surface) and one for low cost tool setter (one with hard non-retreatable surface).


A professional tool setter normally has 2 wires, working like a precision micro switch. It uses magnets to stick on the bench top stably. When the tool presses the surface down to a fix point, the switch changes its status. The switch is usually isolated from the mechanical parts electrically. It can connected to the tool setter input pin without using an optical coupler.




Low cost tool setter can simply be constructed by a piece of PCB board or a block of metal with isolation layer on one of its surface. This kind of tool setter requires conductive tool bits, forming a close circuit when tool bits touch the tool setter surface. An optical coupler is required to interface with tool setter input safely, as shown in the following figure. GND2 is the ground of +24V. It is connected to the machine and tool using the black crocodile clip. 1800 ohm resistor limit the current through the LED to 10-20mA when the tool touches the PCB surface. The closing circuit status optically coupled to the transistor side, grounding the tool setter input.




There is an improved low cost tool setter shown in the figure below. It requires the same connection and optical coupler circuit as the low cost tool setter described above. However, its setting method should be as same as the professional one.



Two tool setting methods are selected by operating Mach3 main menu “Config”
 -> “Config Plugins”.



Click "CONFIG" behind HyCNC_4P and a new window shows up.



Putting "X" before "ATS Stop on Touch" selects auto tool setting using low cost tool setter. Removing "X" before "ATS Stop on Touch" selects auto tool setting using professional tool setter.

Process of using professional tool setter is similar to auto zero. The first stage is to seek tool setter with acceleration to G0 speed according to pre-defined direction. When tool setter is triggered, the moving speed is decelerated to 0 and the second stage starts. The second stage is to leaving the tool setter with acceleration to predefined % of the G0 speed towards the opposite direction. When tool setter changes its status, the difference between Z-axis coordinate and predefined tool setter surface coordinate is used as the tool length offset and save in tool library database. The movement decelerates to 0 then accelerates to G0 speed to the coordinate where tool setting started. This process have overshoot when tool touches tool setter surface at first stage. Therefore, tool setter with retreatable surface is required to avoid tool and/or machine damage.

A low cost tool setter has hard non-retreatable surface isolated from the machine electrically. It doesn't allowed overshoot (or allows every small overshoot), It requires movement to stop immediately when the tool touch tool setter surface. Setting process is to seek tool setter with acceleration to % of G0 speed according to pre-defined direction. When tool touch the tool setter, movement stops within 1/1000s. The difference between Z-axis coordinate and predefined tool setter surface coordinate is used as the tool length offset and save in tool library database. Then machine accelerates to G0 speed to move the coordinate to where tool setting started. Please pay attention, even with control system stops within 1/1000s, the mechanical system may not stop fast enough to avoid tool and/or machine damage. The % of G0 speed should be set small enough to avoid such damage.

The tool setter input shares same input as the A-axis zero switch input. When auto tool setting is used, A-axis auto zero can't be used. Operate the main menu "Config"->"Ports and Pins". Click on page "Input Signals" shown below. The tool setting is enabled by putting a green tick in the "OEM Trig #1" row's "Enable" column. "Port #", "Pin Number" and "Active Low" should be set according to physical connections (referring to chapter "Shape and Connections", section

“Control Inputs”). If the input is low level effective, put a green tick in “Active Low” column. Then click “Apply” and “OK” to save the settings.

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Probe		1	0			0
Index		1	0			0
Limit Ovrd		1	0			0
EStop		1	12			0
THC On		1	0			0
THC Up		1	0			0
THC Down		1	0			0
OEM Trig #1		1	7			0
OEM Trig #2		1	0			0
OEM Trig #3		1	0			0

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be

Automated Setup of Inputs

OK Cancel Apply

The operate the main menu “Config”->”Motor Home/SoftLimits”. The A-axis settings are used for tool setting operation. If the tool setter is located on the negative direction on Z-axis (moving negatively to seek tool setter), put a green tick in column “Home Neg”. “Speed %” defines the % of G0 speed on Z-axis slow movement. When this setting generates stepping pulses more than 1000Hz, the accuracy is also affected. In this case, the homing accuracy in theory is

$$\frac{\text{distance per step} \cdot \text{pulse frequency}}{1000}$$

Motor Home/SoftLimits

Entries are in setup units.

Axis	Reversed	Soft Max	Soft Min	Slow ...	Home ...	Home Neg	Auto ...	Speed %
X	✗	100.00	-100.00	1.00	1.0000	✓	✓	10
Y	✗	100.00	-100.00	1.00	2.0000	✓	✓	10
Z	✗	100.00	-100.00	1.00	3.0000	✓	✓	10
A	✗	100.00	-100.00	1.00	4.0000	✗	✗	3
B	✗	100.00	-100.00	1.00	0.0000	✗	✗	10
C	✗	100.00	-100.00	1.00	0.0000	✗	✗	10

G28 home location coordinates

X A
Y B
Z C

OK

The tool setter surface Z-axis coordinate is defined using “Gauge Block Height” box in main interface’s “Offset” page. Click on the box and type in the height and return, as shown below.

Mach3 CNC Licensed To: Ivan.Todorov@jrc.co.uk

File Config Position Cfg's View Wizards Operator PlugIn Control Help

Program Run (Alt-1) MDI (Alt-2) Tool Path (Alt-4) **Offsets (Alt-5)** Settings (Alt-6) Diagnostics (Alt-7) MB-015 01 017 040 021 080 084 054 043 088 084 087

Gage Block Height: +0.0000 Set Z

Current Work Offset: 1

Active Work Offset: G54

Zero X: +0.0000
Zero Y: +0.0000
Zero Z: -1.0000
Zero 4: +0.0000

Machine Coord's

Please Select Edge Finder Location

Select Click Center If Indicating A Circle Select

HELP - Work Offsets

Edge Finder Dia. +0.0000

Reset

G Codes M Codes

Jog ON OFF Cntrl-J

History Clear Status:

Profile: Mach3Mill

Gage Block Height: +5.0000 Set Tool Offset

HELP - Tool Offsets


Tool Offset On/Off

Tool: 1
Z Offset: 1.000
Diameter: 3.000

Save Offset Tables Here to Make Them Permanent

Save Work Offsets Save Tool Offsets

Finally, script for auto tool setting needs to be updated. Operate the main menu “Operator”->”Edit Button Script”. Then click on flashing “Auto Tool Zero” button, as shown below.



Type the following script in the new window.

Declare Sub AutoToolSetting Lib "HyCNC_4P"(ByVal ctool As Integer)
AutoToolSetting(GetOEMDRO(824))

AutoToolSetting is a function define in HyCNC_4P.DLL. The input parameter is the tool number (the green circle in above figure), provided by GetOEMDRO(824) standard function. Then click menu “file”->”Save”. When auto tool setting is required, click on the tool number box (the green circle in above figure). Type in tool number other 0 followed by return (tool 0 always has 0 offset). Then put tool setter on the machine bench and jog the tool above center of the tool setter. Press “Auto Tool Zero” to start tool setting process. After tool setting is finished, the box indicated by the blue arrow (see above figure) is updated with the measured tool length. Please pay attention, the new tool length won’t be used immediately. To use the new value, either type G43 in MDI or click on page “Offset” of the main interface. There is a button called “Turn Offset on/Off” and a green indicator beside it. If the indicator is on, click “Turn Offset on/Off” twice to use the new tool length offset. If the indicator is off, click “Turn Offset on/Off” once to use the new tool length offset.

The tool setting script can further adapted to the machine. For example, if the tool setter is fixed at a location, i.e. machine coordinate (100, 50) and new tool length is always used after tool setting, the script can be update as the following.

```
Declare Sub AutoToolSetting Lib "HyCNC_4P"(ByVal ctool As Integer)  
code("G53 G0 X100 Y50")  
While IsMoving()  
Sleep(100)  
Wend  
AutoToolSetting(GetOEMDRO(824))  
While IsMoving()  
Sleep(100)  
Wend  
code("G43 ")
```

"G53 G0 X100 Y50" moves quickly to the center of the tool setter. When movement is done, auto tool setting is executed. When setting process is finished, G43 force the new tool length to be used.

If a manual tool change followed by auto tool setting is required from the GCode file, save the following script to a mxxx.m1s file, i.e. m900.m1s, in Mach3/Macros/Mach3Mill directory.

```
Declare Sub AutoToolSetting Lib "HyCNC_4P"(ByVal ctool As Integer)  
code("G53 G0 Z200" )  
While IsMoving()  
Sleep(100)  
Wend  
DoSpinStop()  
code("G53 G0 X500 Y500" )  
MsgBox ("Press OK after tool change.", 0)  
code("G53 G0 X100 Y50")  
While IsMoving()  
Sleep(100)
```

```
Wend  
AutoToolSetting(GetOEMDRO(824))  
While IsMoving()  
Sleep(100)  
Wend  
code("G43 ")  
DoSpinCW();
```

Call M900 in GCode execute following operations: "G53 G0 Z200" moves the current to a safe height suitable for manual tool change. Then spindle is stopped. Then move to tool change located at machine coordinate (500, 500) by "G53 G0 X500 Y500". Then a window with confirm button pops up on the screen, waiting manual tool change to be carried out. After tool changing, click on the confirmation button to continue the program. The machine moves to the tool setter center to start tool setting process. After the setting is finished, the new tool length offset is used and spindle rotates again.

Attention: the safety of the manual tool changing operator is depend on the proper running of the above script by the PC control system. If a safer condition is required (even the malfunction of the PC control system doesn't start spindle to hurt the operator), install safety switches or consult experts or HyTechWorks for a proper solution.

EStop Configuration

Attention: it is suggested to use the EStop provided by the PC control system as the secondary or backup solution and use direct hardware solution as the primary solution to guarantee stopping of the machine under critical conditions. The following configuration of the EStop is all based on using PC and HyCNC-4P interface. It is provided as it is for a reference only.

The EStop is enabled by operating the main menu “Config”->”Ports and Pins”, clicking on page “Input Signals” and putting a green tick on EStop’s “Enabled” column. “Port #”, “Pin Number” and “Active Low” should be set according to physical connections (referring to chapter “Shape and Connections”, section “Control Inputs”). If the input is low level effective, put a green tick in “Active Low” column. Then click “Apply” and “OK” to save the settings.


Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Probe		1	0			0
Index		1	0			0
Limit Ovrd		1	0			0
EStop		1	12			0
THC On		1	0			0
THC Up		1	0			0
THC Down		1	0			0
OEM Trig #1		1	7			0
OEM Trig #2		1	0			0
OEM Trig #3		1	0			0

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be


Automated Setup of Inputs

OK Cancel Apply

When EStop is triggered, the GCode execution is stopped. If 2 PWM outputs also required to stop, put “X” on “PWM1=0 on EStop” and “PWM2=0 on EStop” in “HyCNC-4P Config” window. The “HyCNC-4P Config” window can be shown by operating the main menu “Config”->”Config Plugins”.




Then click on “CONFIG” box behind the “HyCNC-4P” .




When external EStop is triggered, the Mach3 will be locked to stop state even external EStop is released. The red “RESET” button continues having a green-red box flashing. Click on the “RESET” button to release Mach3’s internal stop state. If the external EStop is still engaged when the “RESET” button is clicked, the internal stop can’t be released.

Mach3 Watchdog Configuration

A software watchdog can be enabled to monitor the proper working of the Mach3. Operate the main menu “Config”->”Config PlugIns”.



Then click on “CONFIG” box behind the “HyCNC-4P” .



Tick “Watchdog on PWM2” to enable the watchdog function. When Mach3 works properly, PWM2 output a 50% duty cycle signal. When Mach3 works abnormally, PWM2 output a 0 duty cycle signal. When watchdog is enabled, PWM2 can’t be controlled by a M code. As soon as watchdog is enabled, it can’t be disabled until USB interface’s power is recycled. To disable the watchdog, untick “Watchdog on PWM2”, exit Mach3, recycle the USB interface’s power and restart Mach3.

RS485 (C Type Only)

HyCNC-4P-xxxC has a RS-485 port to communicate with external modules, ie. VFC controller. It is emulated as a serial port on PC windows. The port has the following functions:


1. Automatic TX/RX modes changeover. TX mode has priority. Any sending data put RS-485 in TX mode until data is transmitted and RX mode is recovered.
2. Gavanlic isolation.
3. Virtual COM port emulation.
4. Baud rate 300-115200bps.
5. 1/2 stop bits, odd/even/none polarity bit supported.

Firmware Update

The HyCNC-4P's firmware can be updated online by the final users for function extension and bug fix. The latest firmware can be downloaded from http://www.hytechworks.com/Downloads/HyCnc/HyCNC_4P/index_e.html

Normal Operation

Run HyCncFlash.exe to start firmware updating process. First, select the firmware image file that need to be programmed into the HyCNC-4P interface. All firmware image files have extension of “fbl”. Please use firmware matching to the hardware. Incorrect firmware may cause malfunction and damage.



Firmware update process starts, a window pops up to show the progress.



When firmware update process finishes, the following window pops up. Click “OK”.



When the firmware update process runs the first time on a PC, HyCncFlash.exe can't run properly because the firmware update USB driver has not been installed. The following failure windows will appear. It is normal. Click “OK” to end HyCncFlash.exe.




“New Hardware Wizard” window pops up. Click “Yes, this time only” and “Next”.




Then click on “Install from a list or specific location” and “Next”.



Then click “Don’t search. I will choose the driver to install” and “Next”.



“New Hardware Wizard” will find the suitable driver and list it. Click on “HyCnc USB Bootloader” and “Next”.



The USB driver is then installed to PC.



When the installation is finished, the following window pops up. Click “Finish”.




After install the USB driver, run HyCncFlash.exe again to perform firmware

update.

Firmware Recovery

For any reason that HyCncFlash.exe fails to run properly in normal mode, firmware recovery need to be performed to force re-programming a correct firmware that can recover the normal working condition. First, disconnect HyCNC-4P from the PC's USB. Then connect a 7-10V DC voltage source (i.e. using a 9V battery) between EStop (pin 10) and the ground (pin 18-25), as shown in the following drawing.



Connect HyCNC-4P to PC USB. If the firmware update mode USB driver has not been installed, the driver install process starts automatically (described in the last section). After the driver is installed, run HyCncFlash.exe to normally. After update process starts, the external DC voltage source can be removed. After updating process is finished, the HyCNC-4P should work properly.

Low Level API

Windows programs can use HyCNC-4P to generate motion and other control signals via API functions. API consists of HyCNC_4P.LIB and its header file HyCNC_4P.H. The latest API can be downloaded from

http://www.hytechworks.com/Downloads/HyCnc/HyCNC_4P/index_c.html

The API has following functions.

Device Identification and Opening

<i>BOOL HyCNC_GetDevicePathByGUID(LPGUID DeviceGuid, char *DevicePath, DWORD DeviceIndex)</i>
--

HyCncLib_GetDevicePathByGUID identifies the path of a HyCNC-4P interface by its driver GUID.

DeviceGuid – pointer to the device GUID.

DevicePath – pointer to store the device path string found according to the GUID and device index.

DeviceIndex – index to the number of the device in system list, starting with 0.

If the function succeeds, the return value is true. Otherwise, it returns false.

<i>HANDLE HyCNC_OpenDeviceByPath(char *DevicePath)</i>

HyCncLib_OpenDeviceByPath opens HyCNC-4P interface by its path obtained from calling HyCncLib_GetDevicePathByGUID.

DevicePath – pointer to the device path string.

If the function returns the device handle. If it fails, the handle is INVALID_HANDLE_VALUE.

Device Basic Information Reading

BOOL HyCNC_GetStatus(HANDLE hUsb, LPOVERLAPPED olp, HyCNC_StatusStruct *status)

HyCNC_GetStatus reads essential status from HyCNC-4P interface.

hUsb – the handle of the HyCNC interface.

olp – pointer to OVERLAPPED structure (see FileRead Visual C++ function for overlapped I/O access)

status – status data read from HyCNC interface.

If the function succeeds, the return value is true. Otherwise, it returns false.

The status data have the following fields:

num – number of way point to fill the FIFO buffer in the HyCNC interface.

cx – 32 bit x-axis coordinate count value in motor step.

cy – 32 bit y-axis coordinate count value in motor step.

cz – 32 bit z-axis coordinate count value in motor step.

ca – 32 bit a-axis coordinate count value in motor step.

cb – 32 bit b-axis coordinate count value in motor step.

cc – 32 bit c-axis coordinate count value in motor step.

din – port #1 inputs.

BOOL HyCNC_GetHardwareInfo(HANDLE hUsb, HyCNC_HardwareInfoStruct *info);

HyCNC_GetHardwareInfo reads HyCNC-4P hardware information.

hUsb - the handle of the HyCNC interface.

info - hardware information data.

If the function succeeds, the return value is true. Otherwise, it returns false.

hardware information data have the following fields:

type – hardware type.

axis – number of axis.

option – hardware option.

features – functional features

fwv – firmware version

sn1 – serial number 1

sn2 – serial number 1

sn3 – serial number 1

Motion Control

BOOL HyCNC_SetMovement(HANDLE hUsb, LPOVERLAPPED olp, double *points, unsigned char axis, unsigned short num)

HyCNC-4P generates interpolated stepping pulses with 1ms time base. HyCNC_SetMovement sends the motor 1ms based movement vector data to HyCNC-4P through USB.

hUsb – the handle of the HyCNC interface.

olp – pointer to OVERLAPPED structure (see FileWrite Visual C++ function for overlapped I/O access)

points – pointer to the vector data. The vector data is organized in (x0,[[[y0],z0],a0]), (x1,[[[y1],z1],a1]), (x2,[[[y2],z2],a2])...order.

axis – number of axis in vector.

num – number of vectors in data (no more than num return by HyCNC_GetStatus).

If the function succeeds, the return value is true. Otherwise, it returns false.

BOOL HyCNC_PurgeMovement(HANDLE hUsb)

HyCNC_PurgeMovement clears all pending movement data in HyCNC-4P so that stepping pulse can be stopped immediately.

hUsb – the handle of the HyCNC interface.

If the function succeeds, the return value is true. Otherwise, it returns false.

BOOL HyCNC_SetCoordinate(HANDLE hUsb, int* coordinate, int* mode)

HyCNC_SetCoordinate manipulates coordinate counters in HyCNC-4P.

hUsb – the handle of the HyCNC interface.

coordinate – pointer to 4 element coordinate array that used to modify the coordinate counters.

mode – pointer to 4 element mode array that defines the mode for coordinate counter modifications. 0 – relative mode – the coordinate value is added to current coordinate counter. 1 – absolute mode - the coordinate value is set to current coordinate counter.

If the function succeeds, the return value is true. Otherwise, it returns false.

Other Controls

BOOL HyCNC_SetSwitch(HANDLE hUsb, unsigned int val)

HyCNC_SetSwitch sets relay output on/off.

hUsb – the handle of the HyCNC interface.

val – output level. Bit 0 –OUT1. Bit 1 – OUT2.

If the function succeeds, the return value is true. Otherwise, it returns false.

BOOL HyCNC_SetSpindle0(HANDLE hUsb, unsigned short period, unsigned short prescale)

HyCNC_SetSpindle0 sets base frequency for PWM1 and PWM2.

hUsb – the handle of the HyCNC interface.

$$\text{Freq} = \frac{72000000}{\text{period} \cdot \text{prescale}}$$

BOOL HyCNC_SetSpindle1(HANDLE hUsb, unsigned short duty)

HyCNC_SetSpindle1 sets PWM1's duty cycle.

hUsb – the handle of the HyCNC interface.

$$\text{Duty Cycle} = \frac{\text{duty}}{\text{period}}$$

BOOL HyCNC_SetSpindle2(HANDLE hUsb, unsigned short duty)

HyCNC_SetSpindle2 sets PWM2's duty cycle.

hUsb – the handle of the HyCNC interface.

$$\text{Duty Cycle} = \frac{\text{duty}}{\text{period}}$$

BOOL HyCNC_KickWatchdog(HANDLE hUsb)

This function send a normal working signal to USB interface. The first signals enable the watchdog if it is not enabled. This function needs to be called every 0.1 second. If it is not called in 0.5 second, the watchdog times out.

hUsb – the handle of the HyCNC interface.

BOOL HyCNC_CaptureCoordinate(HANDLE hUsb, int data, int size, unsigned int trigger, unsigned short hw_type)*

This function captures the coordinate readings when home switches' inputs or tool setting input is toggled.

hUsb – the handle of the HyCNC interface.

data – pointer that hold the current coordinate readings. The order of the data is as the follow:

Data[0] – X-coordinate reading when X homing switch input toggled if X capture trigger is set.

Data[1] – Y-coordinate reading when Y homing switch input toggled if Y capture trigger is set.

Data[2] – Z-coordinate reading when Z homing switch input toggled if Z capture trigger is set.

Data[3] – A-coordinate reading when A homing switch input toggled if A capture trigger is set.

Data[4..7] – X/Y/Z/A-coordinate readings when tool setting switch input toggled if tool setting capture trigger is set.

size – number of data to read.

trigger – capture trigger setting. The trigger is reset when the input toggles.

bit 0 – X capture trigger. "1" sets and "0" has no effect.

bit 1 – Y capture trigger. "1" sets and "0" has no effect.

bit 2 – Z capture trigger. “1” sets and “0” has no effect.

bit 3 – A capture trigger. “1” sets and “0” has no effect.

bit 31 – tool setting capture trigger. “1” sets and “0” has no effect.

hw_type – hardware type (see **HyCNC_GetHardwareInfo**). 1 – original type; 2 – B/C type.

The switch input is evaluated every millisecond. The movement should be no more than 1 pulse per millisecond to achieve the best result when the trigger for that moving axis is set.

This function is useful for homing or tool setting. The trigger is set during the homing or tool setting stage, when the switch input changed, the coordinate is captured. Then the coordinates are read back without any trigger setting. The captured coordinate can be subtracted from the current coordinate to achieve “zero” effect.