


User Manual



# EKI-1121L, EKI-1122L, EKI-1124L

1/2/4-port Programmable Serial  
Device Servers

**ADVANTECH**

*eAutomation*

---

## Copyright

The documentation and the software included with this product are copyrighted 2010 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

## Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

## Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

# Declaration of Conformity

## CE

The EKI-1121L/1122L/1124L has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

## Advantech Customer Services

Each and every Advantech product is built to the most exacting specifications to ensure reliable performance in the unusual and demanding conditions typical of industrial environments. Whether your new Advantech equipment is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Advantech has come to be known.

Your satisfaction is our number one concern. Here is a guide to Advantech's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

## Technical Support and Assistance

1. Visit the Advantech web site at <http://support.advantech.com.cn> where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

---

## Safety Instructions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well, or you cannot get it to work according to the user's manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious signs of breakage.
15. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.**
16. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**

The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

**DISCLAIMER:** This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

# Contents

<b>Chapter 1</b>	<b>Introduction.....</b>	<b>1</b>
1.1	Overview .....	2
1.2	Features .....	2
1.3	Specifications .....	2
1.4	Packing List.....	3
<b>Chapter 2</b>	<b>Getting Started.....</b>	<b>5</b>
2.1	Understanding the EKI-1121L/1122L/1124L.....	6
2.2	Hardware.....	6
2.2.1	LED Indicators .....	6
	Table 2.1: EKI-1121L/1122L/1124L LED Indicators .....	6
2.3	Dimensions (Units: mm).....	7
	Figure 2.1 Front View of EKI-1121L .....	7
	Figure 2.2 Side View of EKI-1121L.....	7
	Figure 2.3 Back View of EKI-1121L.....	8
	Figure 2.4 Top View of EKI-1121L.....	8
	Figure 2.5 Front View of EKI-1122L .....	9
	Figure 2.6 Side View of EKI-1122L.....	9
	Figure 2.7 Back View of EKI-1122L.....	10
	Figure 2.8 Top View of EKI-1122L.....	10
	Figure 2.9 Front View of EKI-1124L .....	11
	Figure 2.10 Side View of EKI-1124L.....	11
	Figure 2.11 Back View of EKI-1124L.....	12
	Figure 2.12 Top View of EKI-1124L.....	12
2.4	Connecting Hardware .....	13
2.4.1	Choosing the Location .....	13
	Figure 2.13 Combine the Metal Mounting Kit .....	13
	Figure 2.14 Din-rail Step1 .....	14
	Figure 2.15 Din-rail Step2.....	15
2.4.2	Connecting Power.....	15
	Figure 2.16 Power Connector.....	15
2.4.3	Connecting Serial Device.....	16
	Table 2.2: EKI-1121L/1122L/1124L Serial Port Pin Assignments .	16
2.4.4	Connecting to a Host or the Network.....	16
<b>Chapter 3</b>	<b>Installation and Configuration.....</b>	<b>17</b>
3.1	Connecting the Hardware .....	18
	Figure 3.1 The boot up messages .....	18
3.2	OS Configuration and Usage .....	19
3.2.1	Configure RTC .....	19
	Figure 3.2 Configure RTC.....	19
3.2.2	Configure IP .....	20
	Figure 3.3 Configure Ethernet Interface Using Static IP.....	20
	Figure 3.4 Configure Ethernet Interface Using DHCP .....	21
3.2.3	TELNET Service and Client .....	22
	Figure 3.5 TELNET Service and Client.....	22
3.2.4	FTP Service and Client .....	23
	Figure 3.6 FTP Client in Another Computer .....	23
	Figure 3.7 FTP Command in Another Computer .....	24
	Figure 3.8 FTP Client in EKI-1121/1122/1124.....	25

3.2.5	TFTP Service and Client.....	26
	Figure 3.9 TFTP Server in EKI-1121L/1122L/1124L .....	26
	Figure 3.10TFTP Client in EKI-1121L/1122L/1124L .....	27
3.2.6	NFS Client .....	28
	Figure 3.11NFS Client in EKI-1121L/1122L/1124L .....	28
3.2.7	NTP Client .....	29
	Figure 3.12NTP Client in EKI-1121L/1122L/1124L .....	29
3.2.8	SNMP Service .....	30
	Figure 3.13SNMP Client in EKI-1121L/1122L/1124L .....	30
	Figure 3.14SNMP Message in Manage Computer .....	31
3.2.9	Mail Client .....	32
	Figure 3.15MAIL Client in EKI-1121/1122/1124 .....	32
3.2.10	Web Server .....	33
3.2.11	PPP Client .....	33
3.2.12	PPPoE client.....	34
3.3	Partition of Flash .....	35
<b>Chapter 4</b>	<b>Development Guide .....</b>	<b>37</b>
4.1	Establish Develop Environment .....	38
	4.1.1 Install the Cross Compile Tool Chain .....	38
	4.1.2 Setup the Runtime Environment.....	38
4.2	Put Applications into .....	38
	4.2.1 Check the Flash Memory Space.....	38
	4.2.2 User Space via FTP.....	39
	Figure 4.1 How to Get Applications via FTP.....	39
	4.2.3 Root File-system.....	39
4.3	Device APIs .....	39
	4.3.1 Serial port APIs.....	39
	4.3.2 RTC APIs.....	40
	4.3.3 LED APIs .....	40
<b>Chapter 5</b>	<b>Troubleshooting.....</b>	<b>43</b>
5.1	Troubleshooting .....	44
<b>Appendix A</b>	<b>Restore the Platform Kernel .....</b>	<b>45</b>
A.1	Restore the Platform Kernel.....	46
<b>Appendix B</b>	<b>Erase JFFS2 File System .....</b>	<b>47</b>
B.1	Erase JFFS2 File System .....	48
<b>Appendix C</b>	<b>Command Collection .....</b>	<b>49</b>
C.1	File manager .....	50
C.2	Editor.....	50
C.3	Network.....	51
C.4	Process .....	51
C.5	Others .....	52

# Chapter 1

Introduction

---

## 1.1 Overview

The EKI-1121L/1122L/1124L is a Linux-based RISC-grade embedded platform that offers 2 LAN and 1/2/4 serial ports.

EKI-1121L/1122L/1124L could operate well under 0~60°C. Its compact size and light weight could fit in industrial robust environment. With these advantages, EKI-1121L/1122L/1124L is suitable for communication gateway for converting communication protocol.

EKI-1121L/1122L/1124L is a perfect embedded ready platform that can shorten your development time and offer rich networking interfaces to fulfill your diverse requirements.

## 1.2 Features

- Winbond ARM7 W90N740 80MHz Processor
- 16 MB SDRAM onboard, 8 MB Flash
- 1/2/4 independent RS-232/422/485 serial ports
- Dual 10/100 Mbps Ethernet
- 1 channel LED for user define
- Ready platform for Linux build in flash
- Compact size and light weight
- 0~60°C wide range operation temperature
- DIN-rail and wall mounting
- 10/100 Mbps Base-T standard
- Surge protection for RS-485 line and power supply
- Automatic RS-485 data flow control

## 1.3 Specifications

- Boot-loader: Redboot
- Kernel version: linux-2.6.29.6-rt24
- C Library: uClibc 0.9.26
- OS boot up time <= 9 seconds
- Independent hardware watchdog timer
- Real-time clock with battery
- Ethernet communication compatibility: IEEE 802.3, IEEE802.3u
- Protocols: IPv4, ARP, ICMP, UDP, TCP, HTTP, SNMP v1/v2c, NTP, FTP, TFTP, TELNET, PAP, CHAP, DHCP, PPP, PPPoE, NFS, SMTP
- Interfaces:
  - Network: 2 10/100 BASE-T Ethernet ports
  - Serial: 1/2 independent RS-232/422/485 serial ports
- Serial ports:
  - EKI-1121L: 1 independent RS-232/422/485 serial port
  - EKI-1122L: 2 independent RS-232/422/485 serial ports
  - EKI-1124L: 4 independent RS-232/422/485 serial ports
- Connectors:
  - Network: RJ-45
  - Serial: DB9

Transmission speed: 50 bps to 921 Kbps

Parity bit: Odd, Even, None, Space, Mark

- Data bits: 5, 6, 7, 8
- Stop bits: 1, 1.5, 2
- Flow Control: None, Xon/Xoff, RTS/CTS, DTR/DSR
- Data Signals:
  - RS-232: TxD, RxD, CTS, RTS, DTR, DSR, DCD, RI, GND
  - RS-422: TxD+, TxD-, RxD+, RxD-, GND
  - RS-485: Data+, Data-, GND
- Diagnostic LEDs:
  - Power
  - Programmable Status LED
  - Network: Link, Active
  - Serial: Tx, Rx
- Power Requirements: Dual unregulated 12 to 48 Vdc with surge protection
- Power Consumption:
  - EKI-1121L: 2 W
  - EKI-1122L: 2.5 W
  - EKI-1124L: 4 W
- Enclosure: Metal with solid DIN rail or panel mounting hardware
- Serial protection: 15KV ESD
- Ethernet protection: Built-in 1.5 KV magnetic isolation
- Operation Temperature: 0 ~ 60°C (32 ~ 140°F)
- Storage Temperature: -20 ~ 80°C (-4 ~ 176°F)
- Operating Humidity: 20 ~ 95% (non-condensing)
- Storage Humidity: 0 ~ 95% (non-condensing)

## 1.4 Packing List

- EKI-1121L/1122L/1124L
- CD-ROM for BSP



# Chapter 2

Getting Started

In this chapter, you will be given an overview of the EKI-1121L/1122L/1124L hardware installation procedures. As mentioned in the previous chapter, the EKI-1121L/1122L/1124L comes ready with all network connections, including Ethernet and RS-232/422 /485 port connections.

## 2.1 Understanding the EKI-1121L/1122L/1124L

Networks have become increasingly vital for industrial automation applications. Many control devices today do not have a network port and can only communicate with a dedicated local PC or control panel. Advantech's revolutionary network-enabling technology is now allowing control devices with serial ports to connect to the Ethernet and share networks quickly and cost-effectively. The EKI-1121L/1122L/1124L are network-based, Modbus gateways for integrating new and existing Modbus/RTU and Modbus/ASCII serial devices to newer TCP/IP networked-based devices. Manufacturers, system integrators, and end users can now take advantage of Modbus gateways to create networked applications for remote managing and accessing data for their control devices that wasn't possible before.

## 2.2 Hardware

The following instructions will give the overview of EKI-1121L/1122L/1124L hardware and its installation.

### 2.2.1 LED Indicators

There are LEDs indicating the two sets of power status, system status, dual networks status and serial communication status on the front panel of EKI-1121L, EKI-1122L, and EKI-1124L. Each of them has its own specific meaning, please refer to the below table.

**Table 2.1: EKI-1121L/1122L/1124L LED Indicators**

LED Name	LED Color	LED Description
<b>P1</b>	Green	Power 1 is on.
	Off	Power 1 is off, or power error condition exists.
<b>P2</b>	Green	Power 2 is on.
	Off	Power 2 is off, or power error condition exists.
<b>Status (Default behavior)</b>	Orange	Blinking: System is ready.
	Off	System is not working.
<b>Ethernet</b>	Orange	Blinking: Ethernet port is transmitting or receiving data. Steady on: Ethernet has the good link for 10Mbps or 100Mbps operations.
	Green	On: 100Mbps Ethernet connection. Off: 10Mbps Ethernet connection.
<b>Serial</b>	Orange	Serial port is transmitting data.
	Green	Serial port is receiving data.
	Off	No data is transmitted or received through the serial port.

## 2.3 Dimensions (Units: mm)

EKI-1121L:




Figure 2.1 Front View of EKI-1121L






Figure 2.2 Side View of EKI-1121L



**Figure 2.3 Back View of EKI-1121L**



**Figure 2.4 Top View of EKI-1121L**

EKI-1122L:




Figure 2.5 Front View of EKI-1122L






Figure 2.6 Side View of EKI-1122L



**Figure 2.7 Back View of EKI-1122L**



**Figure 2.8 Top View of EKI-1122L**

EKI-1124L:




Figure 2.9 Front View of EKI-1124L






Figure 2.10 Side View of EKI-1124L



**Figure 2.11 Back View of EKI-1124L**



**Figure 2.12 Top View of EKI-1224L**

## 2.4 Connecting Hardware

This section will explain how to find a proper location for your EKI-1121L/1122L/1124L and how to connect to the network, hook up the power cable and connect to the EKI-1121L/1122L/1124L.

### 2.4.1 Choosing the Location

Due to its versatility and innovative design, the EKI-1122L/1122L/1124L can be:

- Fixed to a panel mount
- Fixed to a DIN-rail

#### 2.4.1.1 Panel/Wall Mounting

The EKI-1121L/1122L/1124L can be attached to a wall using the included metal brackets. Each bracket comes with four screws. You can install the EKI-1121L/1122L/1124L firmly via the components, please see the figure below.



Figure 2.13 Combine the Metal Mounting Kit

### 2.4.1.2 DIN-rail Mounting

The EKI-1121L/1122L/1124L can be mounted on a standard DIN-rail. The DIN-rail kit is screwed on the Modbus data gateway when out of factory. If the DIN-rail kit is not screwed on the EKI-1121L/1122L/1124L, please screw the DIN-rail kit on the Modbus data gateway first.

First, hang the EKI-1121L/1122L/1124L to the DIN-rail with angle of inclination. Please see the figure below.



**Figure 2.14 Din-rail Step1**

Then, let the EKI-1121L/1122L/1124L down straight to slide over the rail smoothly.



Figure 2.15 Din-rail Step2

## 2.4.2 Connecting Power

The EKI-1121L/1122L/1124L supports dual 12 to 48 VDC power inputs and a power-fail relay output. Below figure is the power terminal block pin assignments. Please refer it to connect to the proper power and polarity.





Figure 2.16 Power Connector

You can connect an alarm indicator, buzzer or other signaling equipment through the power-fail relay output. The relay opens if power input V1 or V2 fails. ("Open" means if you connect relay output with an LED, the light will be turned off)

### 2.4.3 Connecting Serial Device

The EKI-1121L/1122L/1124L provides one, two or four standard serial ports DB9 (male) connectors. RS-232/422/485 pin assignments are as below.



**Table 2.2: EKI-1121L/1122L/1124L Serial Port Pin Assignments**

Pin	1	2	3	4	5	6	7	8	9
RS-232	DCD	RX	TX	DTR	GND	DSR	RTS	CTS	RI
RS-422	TX-	-	-	TX+	GND	-	RX+	-	RX-
RS-485	Data-	-	-	Data+	GND	-	-	-	-

### 2.4.4 Connecting to a Host or the Network

The EKI-1121L/1122L/1124L provides two RJ45 connectors with dual independent Ethernet networks and supports 10/100 Mbps transmission speed. The EKI-1121L/1122L/1124L will automatically detect current transmission speed on the network and configure itself accordingly. For normal operation, the EKI-1121L/1122L/1124L can be connected to other hubs or switches through a twisted-pair straight through the Ethernet cable. For configuration or troubleshooting purposes, user may need to connect the EKI-1121L/1122L/1124L directly to the host PC. In this operation mode, user can use a crossover Ethernet cable to connect the EKI-1121L/1122L/1124L to the host PC's Ethernet connector.

# Chapter 3

Installation and  
Configuration





## 3.2.2 Configure IP


After connect to the console and power on the device, you can use following command to enable Ethernet or you can modify the /etc/rc(/var/other1/init.custom) file to bring up Ethernet when booting up by default.

### 3.2.2.1 Using Static IP

User can modify the /etc/rc(/var/other1/init.custom) file like below to make system boot up using static IP. /etc/rc(/var/other1/init.custom) will be executed when system boot up if the file exists.

```
ifconfig eth0 10.0.0.1 broadcast 10.0.0.255 netmask 255.255.255.0
```

And user can configure IP address with command line. For example:



```
root@localhost:~  
File Edit View Terminal Help  
/>  
/>  
/>  
/>  
/>  
/>  
/>  
/> ifconfig eth0 10.0.0.1 broadcast 10.0.0.255 netmask 255.255.255.0  
  
Wait for auto-negotiation complete...Done  
100MB - Full Duplex  
/> ifconfig eth0  
eth0      Link encap:Ethernet  HWaddr 00:D0:C9:22:01:12  
          inet addr:10.0.0.1  Bcast:10.0.0.255  Mask:255.255.255.0  
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1  
          RX packets:489 errors:0 dropped:0 overruns:0 frame:0  
          TX packets:9 errors:4 dropped:0 overruns:0 carrier:0  
          collisions:0 txqueuelen:1000  
          RX bytes:40043 (39.1 KiB)  TX bytes:0 (0.0 B)  
          Interrupt:13  
  
/>  
/>  
/>  
/>
```


Figure 3.3 Configure Ethernet Interface Using Static IP

### 3.2.2.2 Using DHCP

User can modify the `/etc/rc(/var/other1/init.custom)` file like below to make system boot up using DHCP.

```
dhcpcd eth0 &
```

And user can obtain IP address with command line. For example:




```
root@localhost:~  
File Edit View Terminal Help  
For further information check:  
http://www.uclinux.org/  
http://www.advantech.com/eAutomation/  
Execution Finished, Exiting  
Sash command shell (version 1.1.1)  
/> dhcpcd eth0 &  
[290]  
/>  
Wait for auto-negotiation complete...Done  
100MB - Full Duplex  
/> ifconfig eth0  
eth0      Link encap:Ethernet  HWaddr 00:D0:C9:22:01:12  
          inet addr:172.21.73.77  Bcast:172.21.73.255  Mask:255.255.255.0  
          UP BROADCAST NOTRAILERS RUNNING MULTICAST  MTU:1500  Metric:1  
          RX packets:112 errors:0 dropped:0 overruns:0 frame:0  
          TX packets:8 errors:0 dropped:0 overruns:0 carrier:0  
          collisions:0 txqueuelen:1000  
          RX bytes:9367 (9.1 KiB)  TX bytes:0 (0.0 B)  
          Interrupt:13  
/> █
```

Figure 3.4 Configure Ethernet Interface Using DHCP

### 3.2.3 TELNET Service and Client

When boot up the EKI-1121L/1122L/1124L, the telnet service is already started by default. User can telnet to EKI-1121L/1122L/1124L by telnet client in another computer. After you telnet into the EKI-1121L/1122L/1124L, all the other operations is the same as using console. And you can telnet to other computer by telnet client in EKI-1121L/1122L/1124L as well. Use command like this:


A screenshot of a terminal window titled 'root@localhost:~'. The window contains the following text:

```
>/>
>/>
>/>
>/>
>/>
>/>
>/>
>/>
>/>
>/> telnet 172.21.73.101
Trying 172.21.73.101(5888)...
Connected to 172.21.73.101.
Escape character is '^]'.
Fedora release 11 (Leonidas)
Kernel 2.6.30.10-105.2.23.fc11.i686.PAE on an i686 (2)
login: jinxin
Password:
Last login: Wed Jun 23 09:14:04 from axa-sitong.acn.advantech.corp
[jinxin@localhost ~]$ pwd
/home/jinxin
[jinxin@localhost ~]$
[jinxin@localhost ~]$
[jinxin@localhost ~]$
[jinxin@localhost ~]$
[jinxin@localhost ~]$
```

Figure 3.5 TELNET Service and Client

### 3.2.4 FTP Service and Client

When boot up the EKI-1121L/1122L/1124L, the ftp service is already started by default. User can ftp to EKI-1121L/1122L/1124L by ftp client in another computer to get and put files.



```
root@localhost:~  
File Edit View Terminal Help  
[root@localhost ~]#  
[root@localhost ~]# ftp 172.21.73.77  
Connected to 172.21.73.77 (172.21.73.77).  
220 AdvantechNew FTP server (GNU inetutils 1.4.1) ready.  
Name (172.21.73.77:root): ftp  
331 Guest login ok, type your name as password.  
Password:  
230 Guest login ok, access restrictions apply.  
Remote system type is UNIX.  
Using binary mode to transfer files.  
ftp>  
ftp>  
ftp>  
ftp>  
ftp>  
ftp>  
ftp>  
ftp>
```


**Figure 3.6 FTP Client in Another Computer**

'172.21.73.77' is your EKI-1121L/1122L/1124L's IP address. 'Name' can be 'anonymous' or 'ftp' and 'Password' can be any or none.

**Note!** You should use command "adduser ftp" to add a user "ftp" in advance!



Use command to get and put file like this:


A terminal window titled 'root@localhost:~' showing the execution of an FTP client. The user enters 'ftp 172.21.73.77' and connects to the server. They then use 'get eth0' to download a file and 'put EKI' to upload a file. The terminal output shows the progress of these operations, including file sizes and transfer speeds.

```
root@localhost:~# ftp 172.21.73.77
Connected to 172.21.73.77 (172.21.73.77).
220 AdvantechNew FTP server (GNU inetutils 1.4.1) ready.
Name (172.21.73.77:root): ftp
331 Guest login ok, type your name as password.
Password:
230 Guest login ok, access restrictions apply.
Remote system type is UNIX.
Using binary mode to transfer files.
ftp> get eth0
local: eth0 remote: eth0
227 Entering Passive Mode (172,21,73,77,181,37)
150 Opening BINARY mode data connection for 'eth0' (76 bytes).
226 Transfer complete.
76 bytes received in 0.00262 secs (28.96 Kbytes/sec)
ftp> put EKI
local: EKI remote: EKI
227 Entering Passive Mode (172,21,73,77,229,102)
150 Opening BINARY mode data connection for 'EKI'.
226 Transfer complete.
10 bytes sent in 2.4e-05 secs (416.67 Kbytes/sec)
ftp> bye
221 Goodbye.
[root@localhost ~]#
```

**Figure 3.7 FTP Command in Another Computer**

Please look at 'get' and 'put' command line. In 'get' command line, user must use full path of file that will be transmitted from EKI-1121L/1122L/1124L to a local file with the same name. In 'put' command line, user must use full path of file of EKI-1121L/1122L/1124L and the file name must be same as that will be put.

If user wants to connect other computers by ftp client in EKI-1121L/1122L/1124L, use command to put and get file like this:




```
root@localhost:~  
File Edit View Terminal Help  
/home/ftp> ls  
EKI  eth0  
/home/ftp> ftp 172.21.73.101  
Connected to 172.21.73.101.  
220 (vsFTPd 2.1.2)  
Name (172.21.73.101): jinxin  
331 Please specify the password.  
Password:230 Login successful.  
ftp> put EKI  
local: EKI remote: EKI  
200 PORT command successful. Consider using PASV.  
150 Ok to send data.  
226 File receive OK.  
11 bytes sent in 0 secs (11 Kbytes/sec)  
ftp> get eki  
local: eki remote: eki  
200 PORT command successful. Consider using PASV.  
150 Opening BINARY mode data connection for eki (10 bytes).  
WARNING! 1 bare linefeeds received in ASCII mode  
File may not have transferred correctly.  
226 File send OK.  
10 bytes received in 0 secs (10 Kbytes/sec)  
ftp> bye  
221 Goodbye.  
/home/ftp> ls  
EKI  eki  eth0  
/home/ftp>   
CTRL-A Z for help |115200 8N1 | NOR | Minicom 2.3 | VT102 | Offline
```

**Figure 3.8 FTP Client in EKI-1121/1122/1124**

'172.21.73.101' is another computer's IP address.

### 3.2.5 TFTP Service and Client

When boot up the EKI-1121L/1122L/1124L, the tftp service is already started by default. User can tftp to EKI-1121L/1122L/1124L by tftp client in another computer. Use command to get and put file like this:


A terminal window titled 'root@localhost:/home/jjinxin/test' showing a series of commands and their outputs. The user runs 'ls' and sees 'EKI'. Then they start a tftp session with 'tftp 172.21.73.77', use 'put EKI /home/ftp/EKI' to upload a file, 'get /home/ftp/eth0' to download a file, and 'quit' to end the session. Finally, they run 'ls' and see 'EKI eth0', and 'cat eth0' to view the contents of the downloaded file.

```
root@localhost:/home/jjinxin/test
File Edit View Terminal Help
[root@localhost test]#
[root@localhost test]# ls
EKI
[root@localhost test]# tftp 172.21.73.77
tftp> put EKI /home/ftp/EKI
tftp> get /home/ftp/eth0
tftp> quit
[root@localhost test]# ls
EKI  eth0
[root@localhost test]# cat eth0
nameserver 172.21.128.1
nameserver 172.21.128.251
search acn.advantech.corp
[root@localhost test]#
[root@localhost test]#
[root@localhost test]#
[root@localhost test]#
```

Figure 3.9 TFTP Server in EKI-1121L/1122L/1124L

'172.21.73.77' is your EKI-1121L/1122L/1124L's IP address. In 'get' command line, user must use full path of file that will be received from EKI-1121L/1122L/1124L. In 'put' command line, user must use full path of file of EKI-1121L/1122L/1124L and file name must be the same as that will be put.

If user wants to connect another computer by tftp client in EKI-1121L/1122L/1124L, use command to get and put file like this:

A terminal window titled 'root@localhost:~' with a menu bar (File, Edit, View, Terminal, Help). The terminal shows a series of commands and their outputs in a directory '/home/ftp'. The commands include 'ls', 'tftp -p -l eth0 172.21.73.101', 'tftp -g -l EKI 172.21.73.101', and 'cat EKI'. The output shows 'eth0' and 'EKI' files, and the content of 'EKI' is 'hello EKI!'.


```
root@localhost:~  
File Edit View Terminal Help  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp> ls  
eth0  
/home/ftp> tftp -p -l eth0 172.21.73.101  
/home/ftp> tftp -g -l EKI 172.21.73.101  
/home/ftp> ls  
EKI eth0  
/home/ftp> cat EKI  
hello EKI!  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>
```

**Figure 3.10 TFTP Client in EKI-1121L/1122L/1124L**

'172.21.73.101' is another computer's IP address. User can use "tftp -g -r" to send file to another computer and use "tftp -p -l" to get file from another computer.

### 3.2.6 NFS Client

User can mount file system to EKI-1121L/1122L/1124L provided by another computer with NFS service. Use 'mount' command like this:

A terminal window titled 'root@localhost:~' with a menu bar (File, Edit, View, Terminal, Help). The terminal shows a series of commands and their outputs. The user repeatedly enters '/home/ftp>' until they run 'portmap &', which returns '[341]'. Then they run 'mount -n -t nfs 172.21.73.101:/home/jinxin/test /mnt', followed by 'cd /mnt'. Finally, they run 'ls', which outputs 'EKI eth0'. The terminal ends with several more '/mnt>' prompts and a cursor at the end of the last one.

```
root@localhost:~  
File Edit View Terminal Help  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp>  
/home/ftp> portmap &  
[341]  
/home/ftp> mount -n -t nfs 172.21.73.101:/home/jinxin/test /mnt  
/home/ftp> cd /mnt  
/mnt> ls  
EKI eth0  
/mnt>  
/mnt>  
/mnt>  
/mnt>  
/mnt>  
/mnt>  
/mnt>  
/mnt>  
/mnt>
```


**Figure 3.11 NFS Client in EKI-1121L/1122L/1124L**

'172.21.73.101' is another computer's IP address. '/home/jinxin/test' is file system supported by another computer. User can mount it to EKI-1121L/1122L/1124L.





Then user can manage EKI-1121L/1122L/1124L by snmp service in another computer, use 'snmpwalk' command like this:



```

root@localhost:/home/jlxxin/test
File Edit View Terminal Help
[root@localhost test]#
[root@localhost test]# snmpwalk -v 1 172.21.73.77 -c public system
SNMPv2-MIB::sysDescr.0 = STRING: Linux AdvantechNew 2.6.29.6-rt24 #59 PREEMPT RT
Sat Jun 12 09:15:25 CST 2010 armv4tl
SNMPv2-MIB::sysObjectID.0 = OID: NET-SNMP-MIB::netSnpAgentOIDs.255
DISMAN-EVENT-MIB::sysUpTimeInstance = Timeticks: (10208) 0:01:42.08
SNMPv2-MIB::sysContact.0 = STRING: root@acn.advantech.corp
SNMPv2-MIB::sysName.0 = STRING: AdvantechNew
SNMPv2-MIB::sysLocation.0 = STRING: Unknown
SNMPv2-MIB::sysORLastChange.0 = Timeticks: (8) 0:00:00.08
SNMPv2-MIB::sysORID.1 = OID: SNMPv2-MIB::snmpMIB
SNMPv2-MIB::sysORID.2 = OID: SNMP-VIEW-BASED-ACM-MIB::vacmBasicGroup
SNMPv2-MIB::sysORID.3 = OID: SNMP-FRAMEWORK-MIB::snmpFrameworkMIBCompliance
SNMPv2-MIB::sysORID.4 = OID: SNMP-MPD-MIB::snmpMPDCompliance
SNMPv2-MIB::sysORID.5 = OID: SNMP-USER-BASED-SM-MIB::usmMIBCompliance
SNMPv2-MIB::sysORDescr.1 = STRING: The MIB module for SNMPv2 entities
SNMPv2-MIB::sysORDescr.2 = STRING: View-based Access Control Model for SNMP.
SNMPv2-MIB::sysORDescr.3 = STRING: The SNMP Management Architecture MIB.
SNMPv2-MIB::sysORDescr.4 = STRING: The MIB for Message Processing and Dispatchin
g.
SNMPv2-MIB::sysORDescr.5 = STRING: The management information definitions for th
e SNMP User-based Security Model.
SNMPv2-MIB::sysORUpTime.1 = Timeticks: (7) 0:00:00.07
SNMPv2-MIB::sysORUpTime.2 = Timeticks: (8) 0:00:00.08
SNMPv2-MIB::sysORUpTime.3 = Timeticks: (8) 0:00:00.08
SNMPv2-MIB::sysORUpTime.4 = Timeticks: (8) 0:00:00.08
SNMPv2-MIB::sysORUpTime.5 = Timeticks: (8) 0:00:00.08
[root@localhost test]#

```

**Figure 3.14 SNMP Message in Manage Computer**

And user can modify configurable file snmpd.conf to change configuration.



### 3.2.10 Web Server

The `boa` is a small web server. If you want the web server starting by default, user must add `'boa:unknown:/bin/boa -c /www &'` to `/etc/inittab`. To use web server, user can use `vi` to modify `/var/other1/www/boa.conf` which is released from `other1.tar.gz` like this:

```
Port 80
User 0
Group 0
DocumentRoot /www
UserDir public_html
DirectoryIndex index.htm
KeepAliveMax 1000
KeepAliveTimeout 10
DefaultType text/html
AddType application/x-httpd-cgi cgi
ScriptAlias /cgi-bin/ /www/cgi-bin/
AddType image/jpeg jpg
```

Because the default homepage is already located at `/var/other1/www/index.htm` released from `other1.tar.gz`, user can open default page. Type `"http://IP_address"` ('IP\_address' is web server's LAN IP address which is still active.) in the address box of a browser (such as Microsoft Internet Explorer or Mozilla Firefox) from your PC. And user can open default CGI page, type `"http://IP_address/cgi-bin/hello.cgi"` in your browser's address box.

If user wants to make your pages. You can do it like this:

Firstly, save your own homepage to the following directory: `/var/other1/www/`. And then save your CGI page to the following directory: `/var/other1/www/cgi-bin`.

After that, you can browse to `EKI-1121/1122/1124` by web browser in another computer.

### 3.2.11 PPP Client

Before use it, user must open and modify `/var/other1/ppp-on` firstly.

```
#!/bin/sh
DEV=/dev/ttyS3
BAUDRATE=115200
NAME=USERNAME
DIAL_SCRIPT=/var/other1/ppp-on-dialer
pppd lock modem crtscts asyncmap 20A0000 escape FF $DEV $BAUDRATE noipdefault
defaultroute noauth name $NAME connect $DIAL_SCRIPT
```

Please replace `'/dev/ttyS3'` and `'115200'` with correct serial port and baud rate. And replace `'USERNAME'` with login account.

Secondly, user must open and modify `/var/other1/ppp-on-dialer`.

```
#!/bin/sh
TELEPHONE=NUMBER
HANGUP=ATH0
RESET_MODEM=ATZ
INIT_MODEM=ATL1M1V1S11=55S7=75
DIAL=ATDT$TELEPHONE
chat ABORT 'ERROR' ABORT 'BUSY' ABORT 'NO ANSWER' ABORT 'RING\r\n\r\nRING' "
AT 'OK+++\\c-OK' $HANGUP OK $RESET_MODEM OK $INIT_MODEM TIMEOUT 30 OK
$DIAL CONNECT "
```

Please replace 'NUMBER' with the telephone number.

Use the following command to launch the ppp connection.

```
/>/var/other1/ppp-on &
```

After the connection is built, a new Ethernet interface ppp will attach to system.

### 3.2.12 PPPoE client

Before use it, user must open and modify `/var/other1/pppoe-on` firstly.

```
#!/bin/sh
USER=USERNAME
pppd debug lock usepeerdns noipdefault noauth defaultroute local name $USER pty /var/
other1/pppoe-dialer
```

Please replace 'USERNAME' with correct user name.

Secondly, user must open and modify `/var/other1/pppoe-dialer`.

```
#!/bin/sh
ifconfig eth0 up
pppoe -p /var/run/adsl.pid -I eth0 1412
Please replace 'eth0' with correct interface of Ethernet.
Thirdly, user must open and modify /var/other1/pppoe.conf.
ETH=eth0
USER=USERNAME
DEMAND=no
USEPEERDNS=yes
CONNECT_TIMEOUT=60
CONNECT_POLL=6
PING="."
PIDFILE=/var/run/adsl.pid
SYNCHRONOUS=no
CLAMPMSS=1412
LCP_INTERVAL=20
LCP_FAILURE=3
PPPOE_TIMEOUT=80
FIREWALL=NONE
PPPOE_EXTRA=""
```

Please replace 'USERNAME' with correct user name and 'eth0' with correct interface of Ethernet.

Fourthly, user must open and modify /var/other1/www/chap-secrets.

```
"USERNAME" * "PASSWORD" *
```

Please replace 'USERNAME' with correct user name and 'PASSWORD' with correct password.

At last, user must open and modify \var\other1\www\pap-secrets.

```
"USERNAME" * "PASSWORD" *
```

Please replace 'USERNAME' with correct user name and 'PASSWORD' with correct password.

Use the following command to launch the pppoe connection.

```
/>/var/other1/pppoe-on &
```

After the connection is built, a new Ethernet interface ppp will attach to system.

### 3.3 Partition of Flash

As mentioned before, the flash has 4 partitions: The first is used by boot loader; the second is used by uClinux kernel; the third is used by root file system and the forth is reserved for user use. It is about 2.6 MB, identified as /dev/mtdblock3 and mounted at /var/other1.

Redboot	0x 0000 0000 ~ 0x 7F06 0000
kernel.lzo	0x 7F06 0000 ~ 0x 7F26 0000
jffs2fs.img	0x 7F26 0000 ~ 0x 7F7F 0000
FIS directory	0x 7F7F 0000 ~ 0x 7F7F F000
Redboot config	0x 7F7F F000 ~ 0x 7F80 0000



# Chapter 4

Development Guide

---

## 4.1 Establish Develop Environment

### 4.1.1 Install the Cross Compile Tool Chain

Install Linux distribution on your host computer.

Use root account to login system.

Put arm-uclinux-tool-20080121-advantech.tar.bz2 under "/" path. You can find the file at release\toolchain\linux\.

Use "tar jxvf arm-uclinux-tool-20080121-advantech.tar.bz2" to uncompress the tool chain.

The tool chain has been installed into your system.

### 4.1.2 Setup the Runtime Environment

1. Use the account who wants to use this tool chain to login.
2. Append /usr/local/arm-uclinux-tool-20080121/bin to environment variant PATH and export it.
3. Add following line into .bash\_profile. (According to the different shell you use, the configuration file name maybe different.)

```
export PATH=/usr/local/arm-uclinux-tool-20080121/bin:PATH
```

4. Re-login the account.
5. Use 'whereis arm-elf-gcc' or 'which arm-elf-gcc' command to make sure the command points to the correct arm-elf tool chain.
6. Use 'arm-elf-gcc -v' command to make sure you are using the correct version of arm-elf tool chain.
7. Now the development environment is established.


## 4.2 Put Applications into

### 4.2.1 Check the Flash Memory Space

If flash memory is not big enough for your application, you will not be able to download your data to the flash ROM. To calculate the amount of available space of the flash, you can use "df" command.

## 4.2.2 User Space via FTP

Sometimes, user wants to execute applications in file system of EKI-1121L/1122L/1124L. Please use the following commands to get and execute the files.



```

root@localhost:~
File Edit View Terminal Help
/> ftp 172.21.73.101
Connected to 172.21.73.101.
220 (vsFTPD 2.1.2)
Name (172.21.73.101): aaa
331 Please specify the password.
Password:230 Login successful.
ftp> bin
200 Switching to Binary mode.
ftp> get hello
local: hello remote: hello
200 PORT command successful. Consider using PASV.
15000opening BINARY mode data connection for hello (16388 bytes).
226 File send OK.
16388 bytes received in 0 secs (32 Kbytes/sec)
ftp> bye
221 Goodbye.
/> ls
bin      etc      home    mnt     sbin    var
dev      hello   lib     proc    usr     www
/> chmod 755 hello
/> ./hello

hello
/>

```

Figure 4.1 How to Get Applications via FTP

## 4.2.3 Root File-system

we support jffs2 file system in current version.

## 4.3 Device APIs

### 4.3.1 Serial port APIs

Each serial port has an associated device file. To access a serial port, you simply open the corresponding device file.

Peripheral	Device File
Serial Port 1	/dev/ttyAP0
Serial Port 2	/dev/ttyAP1
Serial Port 3	/dev/ttyAP2
Serial Port 4	/dev/ttyAP3

Port configuration is done using the POSIX termios interface. Developing in C, you will first need to include the <termios.h> header file to use the required functions.

Additionally, the serial port line drivers are software configurable for RS-232, RS-422 or RS-485 operation, through the termios interface. You will need to include the adv.h header file or the following defines.

```

#define IRS4220100000
#define IRS4850200000

```

Then, use the following instructions to set the termios structure, followed by the `tcsetattr` function to set the new configuration.

```
switch(gMode) {
    case MODE_RS232:
        PortTermios.c_iflag &= ~IRS422;
        PortTermios.c_iflag &= ~IRS485;
        break;
    case MODE_RS422:
        PortTermios.c_iflag |= IRS422;
        PortTermios.c_iflag &= ~IRS485;
        break;
    case MODE_RS485:
        PortTermios.c_iflag &= ~IRS422;
        PortTermios.c_iflag |= IRS485;
        break;
}

//Set the new serial port interface type
tcsetattr(portHandle, TCSANOW, &PortTermios);
```

For a complete example of serial port configuration, please see the provided `serialecho.c` example.

### 4.3.2 RTC APIs

To access a RTC device, you simply open the corresponding device file.

Peripheral	Device File
Real Time Clock	/dev/rtc

### 4.3.3 LED APIs

To access a LED device, you simply open the corresponding device file.

Peripheral	Device File
LED Indicator	/dev/led

Developing in C, you will first need to include the `<stdio.h>` `<sys/types.h>` `<sys/ioctl.h>` `<unistd.h>` and "ledman.h" header file to use the required functions.

Then, use the following program to set the command, followed by the `ioctl` function to control leds.

```
if(flag)
{
    flag = 0;
    cmd = LEDMAN_CMD_ON;
    /*your action*/
}
```

```
else
{
    flag = 1;
    cmd = LEDMAN_CMD_OFF;
    /*your action*/
}
if( ioctl(devfp, cmd, LEDMAN_HEARTBEAT) < 0
    || ioctl(devfp, cmd, LEDMAN_RESET) < 0 )
{
    /*your action*/
}
```

For a complete example of serial port configuration, please see the provided `lmttest.c` example.



# Chapter 5

Troubleshooting

---

## 5.1 Troubleshooting

1. After restart the EKI-1121L/1122L/1124L, You may encounter following or similar warnings:

```
JFFS2 warning: (270) jffs2_do_read_inode_internal: Truncating ino #30 to 23732 bytes failed because it only had 12288 bytes to start with!
```

In this case, you need "fis load" and "fis write" (but not fis create) the jffs2fs.img again under redboot. For examples:

```
redboot>load -r -v -h 172.21.73.101 -b 0x100000 jffs2fs.img
redboot>fis write -b 0x100000 -f 0x7F260000 -l 0x250000
```

**Note!** Here "-l 0x250000", 0x250000 is just greater than the size of image file jffs2fs.img and aligns at 0x100000



Restart the EKI-1121L/1122L/1124L and it will work.

# Appendix **A**

Restore the Platform  
Kernel

## A.1 Restore the Platform Kernel

Just in case if the kernel or flash is corrupted, follow the below steps to recover the kernel and root file system.

1. Connect the EKI-1121L/1122L/1124L with console.
2. Press Ctrl + C when power on the EKI-1121L/1122L/1124L.
3. You should see the following messages.
4. Start your TFTP server and put the kernel.lzo and jffs2fs.img under the TFTP directory.
5. Assume your TFTP server's IP is 172.21.73.101. Use the following commands.

```
Redboot>fis init -f
Redboot>load -r -v -h 172.21.73.101 -b 0x8000 kernel.lzo
Redboot>fis create -b 0x8000 -l 0x200000 -s 0x200000 -f 0x7F060000 -e 0x8000
kernel.lzo
Redboot>load -r -v -h 172.21.73.101 -b 0x100000 jffs2fs.img
Redboot>fis write -b 0x100000 -f 0x7F260000 -l 0x250000
Redboot>fis create -f 0x7F260000 -l 0x590000 jffs2fs.img
Redboot>fis load -b 0x8000 -l kernel.lzo
Redboot>go -n 0x8000
```

6. After EKI-1121L/1122L/1124L startups, You may encounter following or similar CRC errors:  
jffs2\_get\_inode\_nodes: Node header CRC failed at 0x06add4.  
{df0e,e002,df4edf4e,df4edf4e}  
This is because that part of flash space is not formatted according to the jffs2 format. Generally speaking, this is not a problem. In this case ,you just need restart the EKI-1121L/1122L/1124L.
7. After restart, it should be work. But if you encounter other warnings, please look over Chapter 5 "Troubleshooting".

# Appendix **B**

Erase JFFS2 File  
System

## B.1 Erase JFFS2 File System

1. Sometimes, you may encounter the issue during development. You may see the output message like below.

```
mtddblock_open
ok
jffs2_scan_empty(): Empty block at 0x003142e4 ends at 0x00316000 (with 0x00000000)!
Marking dirty
JFFS2: Erase block at 0x00310000 is not formatted. It will be erased
Cowardly refusing to erase blocks on filesystem with no valid JFFS2 nodes
mtddblock_release
ok
mount: wrong fs type, bad option, bad superblock on /dev/mtddblock3,
       missing codepage or other error
mtddblock_open
ok
mtddblock_release
ok
    In some cases useful info is found in syslog - try
    dmesg | tail or so

pid 14: failed 8192
```

2. Try to use following command to solve this issue.

```
Sash command shell (version 1.1.1)
/> umount /var/other1
/> eraseall /dev/mtd3
MTD_open
MTD_ioctl
Erasing 64 Kibyte @ 0 -- 0 % complete.MTD_ioctl
Erasing 64 Kibyte @ 10000 -- 1 % complete.MTD_ioctl
Erasing 64 Kibyte @ 20000 -- 3 % complete.MTD_ioctl
.....
Erasing 64 Kibyte @ 3c0000 -- 95 % complete.MTD_ioctl
Erasing 64 Kibyte @ 3d0000 -- 96 % complete.MTD_ioctl
Erasing 64 Kibyte @ 3e0000 -- 98 % complete.MTD_ioctl
Erased 4032 Kibyte @ 0 -- 100% complete.
MTD_close
/>reboot
```

3. Restart the device.

# Appendix **C**

Command Collection

---

## C.1 File manager

1. mount: Mount a filesystem. You need this to access NFS and SMB filesystems.
2. umount: Unmount a filesystem.
3. ar: Extract or list files from an ar archive.
4. basename: Strips directory path and suffixes from FILE. If specified, also removes any trailing SUFFIX.
5. cp: Copy files.
6. dd: Copy a file with formatting and conversions.
7. df: Print the filesystem space used and space available.
8. dirname: Strips non-directory suffix from arguments.
9. du: Summarizes disk space used for each file argument and/or directory. Disk space is printed in units of 1024 bytes
10. gunzip: Uncompress files.
11. gzip: Compress files.
12. ln: Create a link between two files.
13. ls: List directory contents.
14. mkdir: Create directory(ies), if they do not already exist.
15. mkfifo: Creates a named pipe.
16. mknod: Create a special file (block, character, or pipe).
17. mv: Move (rename) files.
18. pwd: Print the full filename of the current working directory.
19. rm: Remove (unlink) the file(s). You may use '--' to indicate that all following arguments are non-options.
20. rmdir: Remove the directory(ies), if they are empty.
21. sync: Write all buffered filesystem blocks to disk.

## C.2 Editor

22. cat: Concatenates FILE(s) and prints them to stdout.
23. cmp: Compare files.
24. cut: Prints selected fields from input file to standard out.
25. echo: Prints arguments to stdout.
26. find: Search for files in a directory hierarchy.
27. grep: Search for a pattern in each file or standard input.enable context : Support for the EGREP applet (alias to the grep applet). Alias egrep to grep -e : Support for the EGREP applet (alias to the grep applet)
28. more: More is a filter for viewing a file one screenful at a time.
29. sed: Stream editor.
30. sort: Sorts lines of text in the specified files.
31. tail: Print last 10 lines of each file to standard output. With more than one file, precede each with a header giving the file name. With no file, or when file is -, read standard input.
32. tee: Copy standard input to each file, and also to standard output.
33. test: Checks file types and compares values returning an exit code determined by the value of an expression.
34. top :
35. touch: Update the last-modified date on the given file[s].
36. tr: Translate, squeeze, and/or delete characters from standard input, writing to standard output.
37. vi: Visual file editor.

## C.3 Network

38. `boa`:
39. `dhcpcd`: The DHCP client daemon, used to get an IP address from a DHCP server.
40. `ftp`: An ftp client
41. `ftpd`:
42. `inetd`:
43. `mail`: Client which allows mail to be sent to other hosts that support SMTP
44. `msntp`: Simple Network Time Protocol utility.
45. `portmap`: The portmapper service, needed for NFS under 2.4.
46. `pppd`: Dialup networking daemon.
47. `pptpd`: PPTP VPN daemon.
48. `pptp`: PPTP Client for establishing VPN's.
49. `rp_pppoe`: The Roaring Penguin PPPOE.
50. `telnetd`: Allow remote users to login to the system using telnet.
51. `telnet`: A telnet client application.
52. `tftpd`: A tftp server
53. `chat`: The chat command is used for PPP and other processes that need to talk to modems.
54. `hostname`: Get or set the hostname or DNS domain name.
55. `ifconfig`: Configure a network interface.
56. `iproute`: Equivalent to selecting route support to "ip", above.
57. `netstat`: `netstat` prints information about the Linux networking subsystem.
58. `nslookup`: Queries the nameserver for the IP address of the given host.
59. `ping`: Send ICMP ECHO\_REQUEST packets to network hosts.
60. `route`: Edit the kernel's routing tables.
61. `tftp`: Transfers a file from/to a tftp server using "octet" mode.
  - `put`: Support the TFTP PUT command.
  - `get`: Support the TFTP GET command.
62. `traceroute`: Print the route packets take to a network host.
63. `wget`: Retrieves files via HTTP or FTP.

## C.4 Process

64. `kill`: Send a signal to the specified process(es).
65. `killall`: Send a signal to the specified process(es)
66. `ps`: Report process status. This version of `ps` accepts no options.

---

## C.5 Others

- 67. `cpu`: cpu tool
- 68. `setserial`: User level serial port configuration tool.
- 69. `clear`: Clear screen.
- 70. `date`: Displays the current time or sets the system date.
- 71. `dmesg`: Prints or controls the kernel ring buffer.
- 72. `hwclock`: The `hwclock` utility is used to read and set the hardware clock on a system. This is primarily used to set the current time on shutdown in the hardware clock, so the hardware will keep the correct time when Linux is `_not_` running.
- 73. `mesg`: `Mesg` controls access to your terminal by others. It is typically used to allow or disallow other users to write to your terminal
- 74. `reboot`: Reboot the system.
- 75. `sleep`: Pause for a specified number of seconds.
- 76. `time`:
- 77. `TTY`: Print the file name of the terminal connected to standard input.
- 78. `uname`: Print certain system information.
- 79. `uptime`: Display the time since the last boot.
- 80. `usleep`: Pause for N microseconds.
- 81. `yes`: Repeatedly outputs a line with all specified string(s), or 'y'.



# ADVANTECH

## *eAutomation*

[www.advantech.com.cn](http://www.advantech.com.cn)

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2010