

Crestron **TPMC-4SM**  
RoomView<sup>®</sup> Interface

---

Operations Guide



This document was prepared and written by the Technical Documentation department at:



Crestron Electronics, Inc.

15 Volvo Drive

Rockleigh, NJ 07647

1-888-CRESTRON

# Contents

<b>RoomView® Interface for TPMC-4SM</b>	<b>1</b>
Introduction .....	1
Panel Configuration .....	2
Hard Button Controls.....	9
Main Screen Controls .....	10
Meeting Information Controls .....	11
Day View Controls .....	13
Add Appointment Controls.....	14
Add Appointment .....	14
Edit Subject .....	15
Tools .....	16
About .....	17
UI Configuration .....	18
Room Configuration.....	23
Software License Agreement.....	26



# RoomView<sup>®</sup> Interface for TPMC-4SM

---

## Introduction

The Isys i/O<sup>®</sup> TPMC-4SM Wall Mount Touchpanel Media Center works directly with Crestron<sup>®</sup> RoomView<sup>®</sup> Server Edition room management software to provide a powerful enterprise-wide room scheduling solution. Installed outside the entrance to every meeting room, the TPMC-4SM provides an immediate view of each room's availability, with the ability to look up the calendar for any room on the network and even book the room right on the spot. The dual color buttons give a clear indication of a room's status at a glance, lighting green when the room is available and red when it is in use. The touchpanel's contoured shape assures that even when mounted in a narrow hallway, the buttons remain clearly visible at a distance to either side.

For more information on the TPMC-4SM refer to the latest version of the TPMC-4SM Operations & Installation Guide (Doc. 6845), which is available from the Crestron website ([www.crestron.com/manuals](http://www.crestron.com/manuals)).

---

## Panel Configuration

The TPMC-4SM touchpanel supports a direct connection to Crestron's RoomView software application.

To connect to RoomView, first enter the "Panel Setup Options" screen by touching the screen while booting the touchpanel. Set the desired Ethernet configuration for the panel using the "Ethernet Setup" screens and make note of the panel's IP address.


---

**NOTE:** For details on the setup options for the TPMC-4SM, refer to the "Configuring the Touchpanel" section of the latest version of the TPMC-4SM Operations & Installation Guide (Doc. 6845).

---

On the "Panel Setup Options" screen, the button on the lower right allows selection of either *RoomView* mode and *User Project* mode. The text on the button reflects which mode is currently selected. Touching the button toggles between modes. This must be set to *RoomView* mode in order to make the connection to RoomView. Refer to the following illustration. Touch **Save & Exit** to confirm the settings.

### "Panel Setup Options" Screen




After the panel has updated, the screen will display a "Waiting for RoomView connection..." message, as shown in the following illustration.

### "Waiting for RoomView connection..." Screen




The TPMC-4SM must now be added to the RoomView application and associated with a room. Using a web browser, navigate to your facility's RoomView SE web site. The RoomView login page, shown in the following illustration, will be displayed.

#### *RoomView Login Page*




The image shows the RoomView server edition login page. It features a light blue header with the Crestron logo and the text "RoomView® server edition". Below the header, there are two input fields: "Username:" and "Password:". A "Login" button is positioned below the password field.

**NOTE:** If the application has not yet been configured, the *Username* and *Password* are both "admin".

After login, click on the Setup icon  near the upper right corner of the page to display the RoomView "Setup" page, shown in the following illustration.

#### *RoomView "Setup" Page*



The image shows the RoomView Setup page. The header includes the Crestron logo, "RoomView® server edition", and the date "Wednesday, May 20, 2009". Below the header, there are three buttons: "Add Room", "Add Asset", and "Security Policies". The main content area is divided into several sections: "Rooms & Attributes" (with sub-sections: Add Room, Add Room from Template, Add Room Template, Add Attribute, Add Attribute Email Template; Manage Rooms, Manage Room Custom Properties, Manage Room Templates, Manage Attributes, Combine Attributes), "People & Roles" (with sub-sections: Add Role, Add Person, Manage Roles, Manage People), "Assets & Contracts", "Nodes & Regions", "Security Groups & Policies", and "Actions & Meeting Presets".

Select **Add Room** to display the RoomView “Add Room” page, shown in the following illustration.

**RoomView “Add Room” Page (Top Sections of Page Shown)**

The screenshot shows the RoomView server edition interface. At the top, there is a header with the Crestron logo and 'RoomView server edition' text. The date 'Friday, September 18, 2009' and 'RoomView Admin' are also visible. Below the header, there is a 'Quick Start' link and a 'Add Room' title. The main content area is divided into three sections: 'Room Pre-fill' with a dropdown menu for 'Select room for pre-filling'; 'Room Details' with fields for 'Alias' (with a 'Lookup Room Name' button), 'Room Name' (with a red asterisk), 'Room Description' (a large text area), 'Location', 'Time Zone' (a dropdown menu), 'eControl URL', and 'Web-cam URL'; and 'Scheduling Details' with a 'Calendar Type' dropdown menu. On the right side, there is a section titled 'Associate with a node (optional)' containing a tree view with 'Root' and 'Rooms' nodes.

On the right side of the page, within *Associate with a node (optional)*, select the Rooms node.

In the *Room Details* section of the page, for *Room Name*, enter a name for your room (e.g. Conference Room 100). For *Location*, enter the location (e.g. Building 100).

---

**NOTE:** In order for the Available Rooms feature to work, the *Location* field must be populated. All rooms within the same location should have the same text in the field.

---

In the *Scheduling Details* section of the page, fill in the details based on the type of scheduling system in the environment. First, select the *Calendar Type* from the dropdown list. When *Calendar Type* has been selected, the *Scheduling Details* section of the page will expand and new fields will appear, as shown in the following illustration.



*Scheduling Details*

**Scheduling Details**

Calendar Type: MS Exchange: EWS ▼

Calendar Email Address: \*

Username:

Password:

Domain:

Validate mailbox settings

---

**NOTE:** The following instructions are specific to MS Exchange with EWS. The required fields may be different, depending on the calendar type specified.

---

Enter the *Calendar Email Address*, your *Username* and *Password* and the *Domain* name.


To validate the scheduling configuration has been correctly set, select **Validate mailbox settings**. Near the top of the page, a message will be displayed saying either “The mailbox settings were successfully verified.” or “The mailbox settings could not be verified.”

Upon successfully entering the settings, click **Update** at the bottom of the page. From the next page that appears, click **Close** to return to the Room View “Setup” page.

If the driver for the TPMC-4SM has already been added to the database, you can proceed to page 8 and the instructions for adding an asset.


If it has not yet been added to the database, the driver must be added. On the left side of the “Setup” page, click **Assets & Contracts**. When this section of the page expands, click **Manage Asset Types**, shown in the following illustration.

*Assets & Contracts*



Select the type of asset being managed, in this case *Touchpanel*. Then click **Edit**, as shown in the following illustration.

**RoomView Setup – Asset Types Page**



The RoomView “Edit Asset Type” page will open, as shown in the following illustration.

*RoomView Edit Asset Type Page*

Monday, September 21, 2009  
RoomView Admin

Quick Start ▶

**Edit Asset Type -Touchpanel**

**Asset Type Details**

Name: Touchpanel\*

Life Span Years: 5

Service Interval: 4 Week

Notes:

\* denotes a required field

Update Cancel

**Drivers** [-]

Add Driver

Driver ID	Make	Model	API Type	Direct Connect Properties	
TPMC_4SM	Crestron	TPMC-4SM	Touchpanel	True	Delete Edit Mapping

**Email Rules:** [-]

Add Email Rule

In the *Drivers* section of the page, click **Add Driver**. An “Upload Driver File” window will open, as shown in the following illustration.

*“Upload Driver File” Window*

**Upload Driver File**

File Name:  Browse...

Upload Cancel

Browse to the location of the driver file and click **Upload** to add it to the database.

**NOTE:** The driver is located in the installation directory. The default path is:  
C:\Program Files\Crestron\RoomView70\dbSetup\Drivers.

On the left side of the “Setup” page, click **Assets & Contracts** to expand this section, then click **Add Asset** to open the RoomView “Add Asset” page, shown in the following illustration.

### RoomView “Add Asset” Page

Monday, September 21, 2009  
RoomView Admin

Quick Start ▶

#### Add Asset

##### Asset Details

Name:  \*

Serial Number:

Type:  \*

Economic Lifespan:

Date of Purchase:  \*

Warranty Expiration Date:  \*

Make:

Model:

Connection Type:

IP Address/ Hostname:

Port:

Password:

Use SSL:

Asset Tag:

MAC Address:

##### Associate Asset

Room/Node selection optional.

- Root
- Rooms
  - Conference Room 100
- Un-associated Rooms

##### Maintenance Details

Service Contract:

Service Interval:

Service Contact Information:

Last Service:  \*

\* denotes a required field

Enter a *Name* for the asset. From the *Type* dropdown list, select *Touchpanel*.


In the *Make* field, click on the ellipsis (...) and from the list that appears, select *Crestron*.

In the *Model* field, click on the ellipsis and from the list that appears, select *TPMC-4SM*.

From the *Connection Type* dropdown list, select *Direct Connect*. Then enter the *IP Address/Hostname* for the TPMC-4SM.

In the *Associate Asset* section on the right side of the page, select the room by clicking in its check box.

At the bottom of the page, click **Update**. You should then see a message saying *Asset was successfully added*.

Click **Close**, then exit the “Setup” page by clicking on the Exit Setup icon  near the upper right corner of the page.

## Hard Button Controls

Once RoomView has successfully connected to the touchpanel, the screen should look something like the following illustration.

*Main Screen*



The following table explains the function of the TPMC-4SM’s hard button controls.

**NOTE:** For any button press that results in a page flip away from the main screen, the panel will revert to the main view after a timeout period.

BUTTON	FUNCTION
TODAY	Displays the “Day View” screen and the current workday schedule. The time period shown will be based on the current local time.
DAY ◀	On first press, the panel displays the “Day View” screen. On second press, it will display the previous day schedule. The time period shown will be based on the current local time.
DAY ▶	On first press, the panel displays the “Day View” screen. On second press, it will display the next day schedule. The time period shown will be based on the current local time.
TIME ▲	On first press, the panel displays the “Day View” screen. On second press, it moves the time period up one page. If the first block is already at 12 AM, the period will not shift.
TIME ▼	On first press, the panel displays the “Day View” screen. On second press, it moves the time period down one page. If the last block is already at 11 PM, the period will not shift.
CLOSE	Closes the current dialog and returns to the previous screen.
MORE	Shows more information where applicable.
▲	Moves the user interface selection up where applicable.
▼	Moves the user interface selection down where applicable.
SELECT	Selects the currently selected item where applicable.

## Main Screen Controls

In addition to the hard button controls on the TPMC-4SM, there are four on screen controls on the main screen.

### Main Screen




The following table explains the function of the TPMC-4SM's main screen controls.

BUTTON	FUNCTION
Meeting Info	Displays the "Current Meeting Information" screen. If there is no active meeting, this button will not be available.
Day View	Displays the "Day View" screen and the workday schedule. Other days can be selected from this screen and meetings can be reserved.
Reserve Now	Creates an ad hoc meeting reservation. The actual reservation duration is based on the start time of the next meeting and the maximum reserve now configuration value. If there is a current active meeting, this button will not be available.
Available Rooms	If there are available rooms, displays the "Available Rooms" screen and shows a list of available rooms. During RoomView configuration of this room, the <i>Location</i> field must contain data or this button will not be available.

## Meeting Information Controls

“Current Meeting Information” Screen




The following tables explain the function of the TPMC-4SM’s **CLOSE** and **MORE** hard button controls, when the “Current Meeting Information” screen is displayed.

**NOTE:** The panel will revert to the main view after a timeout period.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
MORE	Displays the next “Current Meeting Information” screen, showing <i>Required Attendees</i> and <i>Optional Attendees</i> .

*“Current Meeting Information” Screen After Pressing MORE*




BUTTON	FUNCTION
CLOSE	Returns to the previous “Current Meeting Information” screen.



## Day View Controls

“Day View” Screen



The following table explains the function of the TPMC-4SM’s “Day View” screen controls.

BUTTON	FUNCTION
TODAY	Displays the current workday schedule. The time period shown will be based on the current local time.
DAY ◀	Displays the previous day schedule. The time period shown will be based on the current local time.
DAY ▶	Displays the next day schedule. The time period shown will be based on the current local time.
TIME ▲	Moves the time period up one page. If the first block is already at 12 AM, the period will not shift.
TIME ▼	Moves the time period down one page. If the last block is already at 11 PM, the period will not shift.
CLOSE	Closes the current dialog and returns to the main screen.
MORE	N/A
▲	Moves the field selection up.
▼	Moves the field selection down.
SELECT	Selects the currently selected field.
Active Meeting Field	Displays the “Selected Meeting Information” screen. This feature is only available if the <input checked="" type="checkbox"/> icon is visible next to the meeting text.
Inactive Meeting Field	Displays the “Add Appointment” screen.

## Add Appointment Controls

When an inactive meeting field (i.e. an open time slot) is selected from the “Day View” screen, the “Add Appointment” screen is displayed.

### Add Appointment

“Add Appointment” Screen



The following table explains the function of the TPMC-4SM’s “Add Appointment” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the “Day View” screen. The meeting will not be added to the room calendar.
Edit	Displays the “Edit Subject” screen.
+	Increases the duration of the meeting in 30 minute increments.
-	Decreases the duration of the meeting in 30 minute increments.
Save	Adds the meeting to the room calendar.

**NOTE:** By design, a meeting duration that will extend into the next calendar day is not permitted.

## Edit Subject

The **Edit** button on the “Add Appointment” screen displays the “Edit Subject” screen.

*“Edit Subject” Screen*




The following table explains the function of the TPMC-4SM’s “Edit Subject” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the “Add Appointment” screen. The subject text will not be updated.
Save	Saves the current text as the subject and returns to the “Add Appointment” screen.

## Tools

A hidden “Tools Main Menu” screen is provided on the TPMC-4SM to display and configure features of the scheduling user interface. To access the “Tools Main Menu” screen, touch and hold the room name on the main screen for five seconds.

*“Tools Main Menu” Screen*



The following table explains the function of the TPMC-4SM’s “Tools Main Menu” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
About	Displays the “About” screen.
UI Configuration	Displays the “UI Configuration” screen.
Room Configuration	Displays the “Room Configuration” screen.

## About

“About” Screen




The following table explains the function of the TPMC-4SM’s “About” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
Return	Returns to the “Tools Main Menu” screen.

On the “About” screen, the *Push Capable* indicator is green if the touchpanel has the capability to dynamically receive meeting events from RoomView. The *Push Registered* indicator is green if the touchpanel has successfully notified RoomView that it is a push capable device. If a touchpanel is not push registered, it must periodically send a request to RoomView for its calendar information.

## UI Configuration

“UI Configuration” Screen



The following table explains the function of the TPMC-4SM’s “UI Configuration” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
Return	Returns to the “Tools Main Menu” screen.
Edit Enable Meeting Information	Displays the configuration screen for the <b>Meeting Info</b> button.
Edit Enable Day View	Displays the configuration screen for the <b>Day View</b> button.
Edit Enable Available Rooms	Displays the configuration screen for the <b>Available Rooms</b> button.
Edit Enable Reserve Now	Displays the configuration screen for the <b>Reserve Now</b> button.

### **Edit Meeting Info**

*“Edit Meeting Info” Screen*



The following table explains the function of the TPMC-4SM’s “Edit Meeting Info” screen controls.

<b>BUTTON</b>	<b>FUNCTION</b>
CLOSE	Returns to the main screen.
Return	Returns to the “UI Configuration” screen.
Enable Show Button	Enables the <b>Meeting Info</b> button.

### Edit Day View

“Edit Day View” Screen



The following table explains the function of the TPMC-4SM’s “Edit Day View” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
Return	Returns to the “UI Configuration” screen.
Enable Show Button	Enables the <b>Day View</b> button.
Enable Get Info	Enables the ability to get meeting information for a selected meeting on the “Day View” screen.
Enable Reserve Meeting	Enables the ability to reserve a meeting on the “Day View” screen.



### **Edit Available Rooms**

*“Edit Available Rooms” Screen*



The following table explains the function of the TPMC-4SM’s “Edit Available Rooms” screen controls.

<b>BUTTON</b>	<b>FUNCTION</b>
CLOSE	Returns to the main screen.
Return	Returns to the “UI Configuration” screen.
Enable Show Button	Enables the <b>Available Rooms</b> button.

### **Edit Reserve Now**

*“Edit Reserve Now” Screen*




The following table explains the function of the TPMC-4SM’s “Edit Reserve Now” screen controls.

<b>BUTTON</b>	<b>FUNCTION</b>
CLOSE	Returns to the main screen.
Return	Returns to the “UI Configuration” screen.
Enable Show Button	Enables the <b>Reserve Now</b> button.
+	Increases the maximum duration of the meeting in 30 minute increments.
-	Decreases the maximum duration of the meeting in 30 minute increments.

## Room Configuration

*“Room Configuration” Screen*



The following table explains the function of the TPMC-4SM’s “Room Configuration” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
Return	Returns to the “Tools Main Menu” screen.
Edit Enable Decline for No Show	Displays the “Edit Decline for No Show” screen.
Edit Privacy Level	Displays the “Edit Privacy Level” screen.

### Edit Decline for No Show

“Edit Decline for No Show” Screen




The following table explains the function of the TPMC-4SM’s “Edit Decline for No Show” screen controls.

BUTTON	FUNCTION
CLOSE	Returns to the main screen.
Return	Returns to the “Room Configuration” screen.
Enable Function	Enables the Decline for No Show function.
+ Applies to Meetings...	Increases the <i>Applies to Meetings...</i> value in 30 minute increments.
- Applies to Meetings...	Decreases the <i>Applies to Meetings...</i> value in 30 minute increments.
+ Decline Meetings After...	Increases the <i>Decline Meetings After...</i> value in 30 minute increments.
- Decline Meetings After	Decreases the <i>Decline Meetings After...</i> value in 30 minute increments.

### **Edit Privacy Level**

*“Edit Privacy Level” Screen*



The following table explains the function of the TPMC-4SM’s “Edit Privacy Level” screen controls.

<b>BUTTON</b>	<b>FUNCTION</b>
CLOSE	Returns to the main screen.
Return	Returns to the “Room Configuration” screen.
Enable Room is Public	Sets the room privacy level to Public.
Enable Room is Semi- Private	Sets the room privacy level to Semi-Private.
Enable Room is Fully-Private	Sets the room privacy level to Fully-Private.

---

## Software License Agreement

This License Agreement (“Agreement”) is a legal contract between you (either an individual or a single business entity) and Crestron Electronics, Inc. (“Crestron”) for software referenced in this guide, which includes computer software and as applicable, associated media, printed materials and “online” or electronic documentation (the “Software”).

BY INSTALLING, COPYING OR OTHERWISE USING THE SOFTWARE, YOU REPRESENT THAT YOU ARE AN AUTHORIZED DEALER OF CRESTRON PRODUCTS OR A CRESTRON AUTHORIZED INDEPENDENT PROGRAMMER AND YOU AGREE TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, DO NOT INSTALL OR USE THE SOFTWARE.

IF YOU HAVE PAID A FEE FOR THIS LICENSE AND DO NOT ACCEPT THE TERMS OF THIS AGREEMENT, CRESTRON WILL REFUND THE FEE TO YOU PROVIDED YOU (1) CLICK THE DO NOT ACCEPT BUTTON, (2) DO NOT INSTALL THE SOFTWARE AND (3) RETURN ALL SOFTWARE, MEDIA AND OTHER DOCUMENTATION AND MATERIALS PROVIDED WITH THE SOFTWARE TO CRESTRON AT: CRESTRON ELECTRONICS, INC., 15 VOLVO DRIVE, ROCKLEIGH, NEW JERSEY 07647, WITHIN 30 DAYS OF PAYMENT.

### LICENSE TERMS

Crestron hereby grants You and You accept a nonexclusive, nontransferable license to use the Software (a) in machine readable object code together with the related explanatory written materials provided by Crestron (b) on a central processing unit (“CPU”) owned or leased or otherwise controlled exclusively by You and (c) only as authorized in this Agreement and the related explanatory files and written materials provided by Crestron.

If this software requires payment for a license, you may make one backup copy of the Software, provided Your backup copy is not installed or used on any CPU. You may not transfer the rights of this Agreement to a backup copy unless the installed copy of the Software is destroyed or otherwise inoperable and You transfer all rights in the Software.

You may not transfer the license granted pursuant to this Agreement or assign this Agreement without the express written consent of Crestron.

If this software requires payment for a license, the total number of CPUs on which all versions of the Software are installed may not exceed one per license fee (1) and no concurrent, server or network use of the Software (including any permitted back-up copies) is permitted, including but not limited to using the Software (a) either directly or through commands, data or instructions from or to another computer (b) for local, campus or wide area network, internet or web hosting services or (c) pursuant to any rental, sharing or “service bureau” arrangement.

The Software is designed as a software development and customization tool. As such Crestron cannot and does not guarantee any results of use of the Software or that the Software will operate error free and You acknowledge that any development that You perform using the Software or Host Application is done entirely at Your own risk.

The Software is licensed and not sold. Crestron retains ownership of the Software and all copies of the Software and reserves all rights not expressly granted in writing.

### OTHER LIMITATIONS

You must be an Authorized Dealer of Crestron products or a Crestron Authorized Independent Programmer to install or use the Software. If Your status as a Crestron Authorized Dealer or Crestron Authorized Independent Programmer is terminated, Your license is also terminated.

You may not rent, lease, lend, sublicense, distribute or otherwise transfer or assign any interest in or to the Software.

You may not reverse engineer, decompile or disassemble the Software.

You agree that the Software will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration Act or any other export laws, restrictions or regulations (“Export Laws”). By downloading or installing the Software You (a) are certifying that You are not a national of Cuba, Iran, Iraq, Libya, North Korea, Sudan, Syria or any country to which the United States embargoes goods (b) are certifying that You are not otherwise prohibited from receiving the Software and (c) You agree to comply with the Export Laws.

If any part of this Agreement is found void and unenforceable, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. This Agreement may only be modified by a writing signed by an authorized officer of Crestron. Updates may be licensed to You by Crestron with additional or different terms. This is the entire agreement between Crestron and You relating to the Software and it supersedes any prior representations, discussions, undertakings, communications or advertising relating to the Software. The failure of either party to enforce any right or take any action in the event of a breach hereunder shall constitute a waiver unless expressly acknowledged and set forth in writing by the party alleged to have provided such waiver.

If You are a business or organization, You agree that upon request from Crestron or its authorized agent, You will within thirty (30) days fully document and certify that use of any and all Software at the time of the request is in conformity with Your valid licenses from Crestron or its authorized agent.

Without prejudice to any other rights, Crestron may terminate this Agreement immediately upon notice if you fail to comply with the terms and conditions of this Agreement. In such event, you must destroy all copies of the Software and all of its component parts.

#### PROPRIETARY RIGHTS

**Copyright.** All title and copyrights in and to the Software (including, without limitation, any images, photographs, animations, video, audio, music, text and “applets” incorporated into the Software), the accompanying media and printed materials and any copies of the Software are owned by Crestron or its suppliers. The Software is protected by copyright laws and international treaty provisions. Therefore, you must treat the Software like any other copyrighted material, subject to the provisions of this Agreement.

**Submissions.** Should you decide to transmit to Crestron’s website by any means or by any media any materials or other information (including, without limitation, ideas, concepts or techniques for new or improved services and products), whether as information, feedback, data, questions, comments, suggestions or the like, you agree such submissions are unrestricted and shall be deemed non-confidential and you automatically grant Crestron and its assigns a non-exclusive, royalty-free, worldwide, perpetual, irrevocable license, with the right to sublicense, to use, copy, transmit, distribute, create derivative works of, display and perform the same.

**Trademarks.** CRESTRON and the Swirl Logo are registered trademarks of Crestron Electronics, Inc. You shall not remove or conceal any trademark or proprietary notice of Crestron from the Software including any back-up copy.

#### GOVERNING LAW

This Agreement shall be governed by the laws of the State of New Jersey, without regard to conflicts of laws principles. Any disputes between the parties to the Agreement shall be brought in the state courts in Bergen County, New Jersey or the federal courts located in the District of New Jersey. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement.

#### CRESTRON LIMITED WARRANTY

CRESTRON warrants that: (a) the Software will perform substantially in accordance with the published specifications for a period of ninety (90) days from the date of receipt and (b) that any hardware accompanying the Software will be subject to its own limited warranty as stated in its accompanying written material. Crestron shall, at its option, repair or replace or refund the license fee for any Software found defective by Crestron if notified by you within the warranty period. The foregoing remedy shall be your exclusive remedy for any claim or loss arising from the Software.

CRESTRON shall not be liable to honor warranty terms if the product has been used in any application other than that for which it was intended or if it as been subjected to misuse, accidental damage, modification or improper installation procedures. Furthermore, this warranty does not cover any product that has had the serial number or license code altered, defaced, improperly obtained or removed.

Notwithstanding any agreement to maintain or correct errors or defects, Crestron shall have no obligation to service or correct any error or defect that is not reproducible by Crestron or is deemed in Crestron’s reasonable discretion to have resulted from (1) accident; unusual stress; neglect; misuse; failure of electric power, operation of the Software with other media not meeting or not maintained in accordance with the manufacturer’s specifications or causes other than ordinary use; (2) improper installation by anyone other than Crestron or its authorized agents of the Software that deviates from any operating procedures established by Crestron in the material and files provided to You by Crestron or its authorized agent; (3) use of the Software on unauthorized hardware or (4) modification of, alteration of or additions to the Software undertaken by persons other than Crestron or Crestron’s authorized agents.

ANY LIABILITY OF CRESTRON FOR A DEFECTIVE COPY OF THE SOFTWARE WILL BE LIMITED EXCLUSIVELY TO REPAIR OR REPLACEMENT OF YOUR COPY OF THE SOFTWARE WITH ANOTHER COPY OR REFUND OF THE INITIAL LICENSE FEE CRESTRON RECEIVED FROM YOU FOR THE DEFECTIVE COPY OF THE PRODUCT. THIS WARRANTY SHALL BE THE SOLE AND EXCLUSIVE REMEDY TO YOU. IN NO EVENT SHALL CRESTRON BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, SPECIAL OR PUNITIVE DAMAGES OF ANY KIND (PROPERTY OR ECONOMIC DAMAGES INCLUSIVE), EVEN IF A CRESTRON REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR OF ANY CLAIM BY ANY THIRD PARTY. CRESTRON MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AS TO TITLE OR INFRINGEMENT OF THIRD-PARTY RIGHTS, MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY OTHER WARRANTIES, NOR AUTHORIZES ANY OTHER PARTY TO OFFER ANY WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY FOR THIS PRODUCT. THIS WARRANTY STATEMENT SUPERSEDES ALL PREVIOUS WARRANTIES.



**Crestron Electronics, Inc.**  
15 Volvo Drive Rockleigh, NJ 07647  
Tel: 888.CRESTRON  
Fax: 201.767.7576  
[www.crestron.com](http://www.crestron.com)

**Operations Guide – DOC. 6846A**  
**(2024511)**  
**11.09**  
Specifications subject to  
change without notice.