



**ACD-1500  
ATMOSPHERIC  
DEGASSER**

Issued 15 Nov 09

**Maintenance & Operation Manual**

**Mineral Processing, Industrial,  
& Environmental Applications**

Derrick Corporation  
590 Duke Road  
Buffalo, New York 14225  
Phone: 716.683.9010  
Fax: 716.683.4991  
[www.derrickcorp.com](http://www.derrickcorp.com)

**Oil & Gas  
Applications**

Derrick Equipment Company  
15630 Export Plaza Drive  
Houston, Texas 77032  
Phone: 281.590.3003  
Toll Free: 1.866.DERRICK  
Fax: 281.442.6948  
[www.derrickequipment.com](http://www.derrickequipment.com)





## UNIT NUMBER IS KEY TO DERRICK SERVICE

All inquiries to Derrick must include the equipment unit number. The stainless steel unit number tag attached to each piece of Derrick equipment is your key to efficient service and support.



### Typical Derrick Unit Number

This unique number gives vital information to Service personnel who use it to identify the correct parts when filling orders, provide accurate responses to service questions, track documentation, and trace the equipment's history or configuration. In short, the **unit number provides the critical information needed to ensure that Derrick customers receive the best possible service.**

The unit number consists of a two-character alphabetic prefix that identifies the equipment type and a series of numeric characters that signify the sequence of the machine's manufacture. For example, unit number MA000001 would be the first screening machine manufactured by Derrick. Alphabetic prefixes currently in use are:

MA - Screening Machine	AD - Desilter and Desander
DG - Degasser	AG - Mud Agitator
CF - Centrifuge	SF - Screen Frame

To ensure that it will remain intact over many years of rigorous service, the heavy-gage tag is riveted to a structural member such as the shaker support structure. It is not to be confused with any other identifier on the machine such as a vibrator motor serial number.

For convenient availability, the unit number is also recorded in the Operation and Maintenance manual shipped with the equipment. When contacting Derrick for any equipment question or need, always have the unit number in your possession. It's the best way to get the most efficient service from our dedicated Service and Engineering personnel.





## ABOUT THIS MANUAL

This document is published in both printed and electronic form. In the electronic manual, all sections and paragraphs listed in the CONTENTS are linked to the corresponding text.

Navigate the electronic manual as follows:

1. To view any desired information, display the CONTENTS page and move the cursor to the desired paragraph or section title.
2. To display the desired information, click on the listing when the pointing finger appears over the text.
3. When finished viewing the text, press Alt + left arrow key to return to the CONTENTS page.
4. If desired to return to the same information, press Alt + right arrow. To locate a different item, repeat steps 1 and 2.

The content of this document is subject to change at any time. Information provided does not cover all details or variations possible with DERRICK equipment, nor does it cover every contingency that may be met in conjunction with installation, operation, maintenance, or troubleshooting of the equipment. Should additional information be required, or should situations arise that are not covered by this manual, bring the matter to the attention of your local DERRICK representative or the Service Department at DERRICK Corporation in Buffalo, New York.

Copyright© 2009 by DERRICK CORPORATION



---

---

## CONTENTS

---

Section	Page
<b>1 - Introduction .....</b>	<b>1-1</b>
Overview .....	1-1
Safety .....	1-2
Equipment Use.....	1-2
Description and Operation.....	1-2
Major Components .....	1-2
Product Support .....	1-5
<b>2 - Safety .....</b>	<b>2-1</b>
Introduction .....	2-1
Warnings .....	2-1
Material Safety Data Sheets (MSDSs) .....	2-3
<b>3 - Installation .....</b>	<b>3-1</b>
General .....	3-1
Safety .....	3-1
Installation Sequence .....	3-1
Storage.....	3-2
Site Preparation and Clearance Requirements.....	3-2
Moving/Positioning the Equipment .....	3-2
Electric Power Connections .....	3-5
Splash Plate Adjustment .....	3-6
Machine Startup .....	3-6
<b>4 - Operating Instructions .....</b>	<b>4-1</b>
General .....	4-1
Operating Safety .....	4-1
Initial Startup .....	4-1
Normal Startup and Operation .....	4-1
Normal Shutdown.....	4-2
Emergency Shutdown .....	4-2

# CONTENTS

---

Section	Page
<b>5 - Maintenance</b> .....	<b>5-1</b>
General .....	5-1
Bearing Lubrication .....	5-1
Troubleshooting .....	5-2
Parts Replacement .....	5-2
Spare Parts .....	5-2
<b>6-7 - Not Used</b>	
<b>8 - Reference Drawings</b> .....	<b>8-1</b>
<b>9 - Installation and Maintenance Log</b> .....	<b>9-1</b>
<b>10 - Supplier Data</b> .....	<b>10-1</b>



---

## SECTION 1 - INTRODUCTION

---

### OVERVIEW

This manual provides installation, operation, and maintenance instructions for the Derrick Atmospheric Centrifugal Degasser (ACD) 1500 (Figure 1-1). The manual is divided into several sections to assist the user in readily accessing the information.

Personnel responsible for transporting, installing, operating, adjusting, or maintaining this equipment should be required to read and understand the information and instructions in this manual. One copy of this manual should be available and accessible at the equipment location.

For maximum safety and performance, no additions and/or changes may be made to the equipment without the explicit written permission of Derrick Corporation. Genuine Derrick repair/replacement parts are required.



**Figure 1-1 Atmospheric Centrifugal Degasser (ACD) 1500**

## **INTRODUCTION**

---

### **SAFETY**

Section 2 of this manual contains relevant safety information relating to both operation and maintenance of this equipment. Be sure this information is read and understood by all personnel.

**DO NOT** operate the equipment if defective or faulty mechanical or electrical components are detected.

### **EQUIPMENT USE**

The degasser and associated components are designed exclusively for releasing entrained gases from slurries. Derrick Corporation does not authorize any other use of this equipment. Intended usage of equipment includes compliance with the operating, maintenance, and safety procedures included in this manual.

### **DESCRIPTION AND OPERATION**

The ACD-1500 degasser (Figure 1-2) is designed to be immersed in a drilling fluid tank. For proper functioning, the fluid level in the mud tank should be higher than the pump bolting flange. The degasser uses impact/turbulence combined with a large surface area of exposure to liberate gas from the mud. Entrained gases are removed from drilling fluid by exposing a thin film of the mud to the atmosphere. Drilling fluid is pumped by the centrifugal pump at the bottom of the degasser up through the pump riser and delivered to the impact plate, which disperses the liquid horizontally against the interior surface of the spray tank. The mud spreads evenly across the horizontal surface of the spray tank, allowing the bubbles to break free from the mud. Degassed mud flows out the discharge outlet and returns to the tank. Mud is continuously circulated from the tank through the degasser and back to the tank. This recirculation process maximizes gas removal.

The removed gas exits the vent at the top of the spray tank. An optional exhaust fan at the top of the spray tank assists in drawing gas away from the vent. The fan's discharge flange may be connected to a pipe to transport the gas farther from the degasser.

The gap between the impact plate and riser opening is adjustable to control the thickness of the dispersed film. The ACD-1500 degasser processes up to 1500 gallons per minute (gpm), depending on the impact plate gap, which is adjustable within a 1" range (1/4" to 1-1/4") in 1/4" increments. Forcing the mud through the small gap between impact plate and pump riser causes it to strike the walls of the spray tank with considerable force, producing turbulence that assists in liberating gas from the mud.

Maximum process throughput is achieved with the largest impact plate gap, while flow is diminished with a smaller gap. Generally, the higher the flow the lower the release of entrained gas. The impact plate gap is adjusted to meet the mud conditions. High gas content may warrant a small gap to maximize removal of entrained gas, while a larger gap may be suitable when gas content is lower and higher flow is desired.

### **MAJOR COMPONENTS**

The degasser (Figure 1-3) consists of a skid-mounted spray tank, electric motor-driven centrifugal pump, impact plate, electrical control panel, vent, and exhaust fan (optional). These components are described in the following paragraphs.

## Centrifugal Pump

Drilling fluid is drawn into the degasser from the bottom of the mud tank by the centrifugal pump. The pump is driven by a shaft rotated by the electric motor at the top of the degasser. The shaft is supported by two bearings that control the shaft movement in both thrust and radial directions. Clamping collars installed on the shaft ensure that minimal thrust is applied to the vertical shaft.

## Impact Plate

Fluid pumped upward through the riser by the centrifugal pump strikes the circular impact plate, which disperses the fluid horizontally into the spray tank. Its slotted mounting holes permit vertical positioning of the impact plate to vary the gap between the top of the riser and the plate. Serrated tabs ensure positive setting of the gap at six locations. After properly positioning the impact plate, tightening the attaching hardware secures the plate to a fitting at the top of the spray tank.

## Spray Tank

Fluid dispersed at high velocity by the impact plate spreads across the interior surfaces of the spray tank. The tank's shape encourages release of entrained gas from the mud.




Figure 1-2 ACD-1500 Degasser Functional Diagram

## INTRODUCTION

---




Figure 1-3 ACD-1500 Degasser Major Components

### Electrical Control Panel

Three-phase AC electric power at 460/480 60 Hz or 380/400 50 Hz 50A is supplied to the drive motor and exhaust fan motor by the electrical control panel. In addition to the START and STOP switches that turn the machine on and off, the control panel contains a DC power supply, control relay, power contactor, starter, and other electrical components. A thermal overload in the starter shuts down the degasser in case of excessive current draw. Upon sensing an overload, power is immediately interrupted to both the degasser drive motor and exhaust fan motor.

### Vent Pipe

Aided by the exhaust fan, liberated gas flows upward through the vent pipe and exits the flange at the top of the vent. Slots around the outside of the vent pipe permit entry of ambient air to mix with the gas and facilitate gas extraction.

## PRODUCT SUPPORT

Derrick offers 24-hour-per-day, 7-day-per-week product support. Product support includes screen replacement / ordering information and repair / replacement parts and service for the entire product line. Refer to the following table for the parts / service center nearest you.

PARTS SALES & SERVICE LOCATIONS	
<b>Colorado - 970.241.2417</b>	
<b>Louisiana</b>	
Broussard - 877.635.3354	
<b>Mississippi</b>	
Laurie - 877.635.3354	
<b>New York - Corporate Headquarters</b>	
Buffalo - 716.683.9010	
<b>Oklahoma</b>	
Oklahoma City - 405.208.4070	
<b>Texas</b>	
Houston (Oilfield Headquarters) - 866.DERRICK (337.7425)	
Bridgeport - 940.210.9975	
Corpus Christi - 361.664.2410	
<b>Texas (Cont'd)</b>	
Longview - 337.298.9411	
Midland - 432.230.3720	
<b>Wyoming - 307.265.0445</b>	
<b>Germany - 011.49.5162.98580</b>	

CONTACT INFORMATION			
Location	Telephone	Facsimile (FAX)	E-Mail / Website
Derrick Corporation 590 Duke Road Buffalo, New York 14225 <b>USA</b>	716.683.9010	716.683.4991	General Service Manager <a href="mailto:toconnor@derrickcorp.com">toconnor@derrickcorp.com</a>
Derrick Equipment Company 15630 Export Plaza Drive Houston, Texas 77032 <b>USA</b>	281.590.3003	281.442.6948	General Manager <a href="mailto:rerice@derrickequipment.com">rerice@derrickequipment.com</a>



---

## SECTION 2 - SAFETY

---

### INTRODUCTION

This section contains a summary of WARNINGS used in this manual and a list of material safety data sheets (MSDSs) applicable to the equipment. The ACD-1500 Degasser has been designed to perform the stated functions safely.

### WARNINGS

All persons responsible for operation and maintenance of this equipment must read and understand all safety information in this manual prior to operating and/or maintaining the equipment. The safety warnings listed below are included in applicable procedures throughout this manual.

#### Sound



**WARNING! TO PROTECT AGAINST HEARING LOSS, HEARING PROTECTION SHOULD BE WORN AT ALL TIMES WHEN WORKING ON OR NEAR DERRICK MACHINES.**

#### Electrical Hazards



**WARNING! TO AVOID SERIOUS PERSONAL INJURY BE SURE EQUIPMENT IS LOCKED OUT, TAGGED OUT, AND DE-ENERGIZED PRIOR TO PERFORMING MAINTENANCE AND/OR ADJUSTMENTS.**



**WARNING! MOTOR MUST BE OPERATED AT THE DESIGNATED SUPPLY VOLTAGE.**



**WARNING! HIGH VOLTAGE MAY BE PRESENT. BE SURE FUSED DISCONNECT SUPPLYING ELECTRICAL POWER TO THIS EQUIPMENT IS OPEN. LOCK-OUT AND TAG-OUT POWER SUPPLY TO PREVENT ACCIDENTAL APPLICATION OF POWER WHILE MAINTENANCE AND/OR ADJUSTMENTS ARE IN PROGRESS.**



**WARNING! ELECTRICAL CONNECTIONS MUST BE MADE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND ALL APPLICABLE LOCAL CODES. FAILURE TO COMPLY MAY RESULT IN AN UNSAFE CONDITION THAT COULD INJURE PERSONNEL OR DAMAGE EQUIPMENT. ENSURE THAT ALL ELECTRICAL AND CONDUIT CONNECTIONS ARE SECURE.**

## **SAFETY**

---

### **Equipment Handling**



**WARNING! TO ENSURE PROPER BALANCE AND ORIENTATION WHEN UNIT IS RAISED AND PREVENT DAMAGE TO COMPONENTS, ATTACH LIFTING SLINGS ONLY TO LABELLED LIFTING POINT. DO NOT ATTEMPT LIFTING BY ATTACHMENT TO ANY OTHER LOCATION.**



**WARNING! BE SURE THAT HANDLING DEVICES HAVE SUFFICIENT LIFTING CAPACITY TO SAFELY HANDLE THE WEIGHT OF THE EQUIPMENT.**

### **Operation**



**WARNING! ALL OPERATING AND MAINTENANCE PERSONNEL MUST READ AND UNDERSTAND ALL SAFETY INFORMATION IN THIS MANUAL BEFORE WORKING WITH THE EQUIPMENT.**

### **Maintenance**



**WARNING! HIGH VOLTAGE MAY BE PRESENT. ALWAYS OPEN FUSED DISCONNECT SUPPLYING ELECTRIC POWER TO THE EQUIPMENT, AND LOCK OUT AND TAG OUT POWER SUPPLY BEFORE PERFORMING ANY MAINTENANCE OF EQUIPMENT.**



## MATERIAL SAFETY DATA SHEETS (MSDSs)

Material Safety Data Sheets (MSDSs) for exterior finish products are included on the following pages to advise personnel of the properties and any possible hazards associated with these materials. Emergency first-aid procedures, special precautions, emergency telephone number, and other relevant data are contained in the MSDSs. These documents were prepared by the product manufacturers, which have sole responsibility for accuracy of the information.

The MSDSs in this section are current as of the publication date of this manual and are supplied only for reference. Checking with the product manufacturer for updates is recommended and is the responsibility of the customer.

In addition to the MSDSs, manufacturer's specifications are listed for the approved bearing greases and anti-seize lubricant for the ACD-1500 Degasser.

To ensure that current information is available, the MSDS for each product should be obtained at the time of purchase. Please note that all lubricants listed are equivalent and approved for bearing and other lubrication requirements.

MATERIAL DESCRIPTION – WHERE USED	MSDS No. / Date
<b>Paints</b>	
Devoe Devthane 359 - Top Coat	<a href="#">359</a> / 05-06-08
Devoe Epoxy Primer - Undercoat	<a href="#">313K</a> / 08-02-04
<b>Lubricants and Sealants*</b>	
Grease, NLGI Grade 2, Lithium Base - Shaft Bearings	Contact Manufacturer
Loctite 76764 Anti-Seize Lubricant - Fasteners	Contact Manufacturer

\* Equivalent product may be substituted for listed items.





# MATERIAL SAFETY DATA SHEET

prepared 05/06/08

ICI Paints North America

15885 Sprague Road Strongsville, Ohio 44136

EMERGENCY TELEPHONE NO. (800) 545-2643

DEVTHANE 359 DERRICK GREEN

359D

## HAZARDS IDENTIFICATION (ANSI Section 3)

**Primary route(s) of exposure :** Inhalation, skin contact, eye contact, ingestion.

### Effects of overexposure :

**Inhalation :** Irritation of respiratory tract. Prolonged inhalation may lead to. Inhalation of spray mist may cause irritation of respiratory tract. Mucous membrane irritation, fatigue, drowsiness, dizziness and/or lightheadedness, headache, uncoordination, nausea, vomiting, abdominal pain, chest pain, coughing, apathy, central nervous system depression, intoxication, anesthetic effect or narcosis, difficulty of breathing, allergic response, tremors, severe lung irritation or damage, pulmonary edema, pneumoconiosis, loss of consciousness, respiratory failure, death. Possible sensitization to respiratory tract.

**Skin contact :** Irritation of skin. Prolonged or repeated contact can cause dermatitis, defatting, severe skin irritation. Possible sensitization to skin.

**Eye contact :** Irritation of eyes. Prolonged or repeated contact can cause conjunctivitis, blurred vision, tearing of eyes, redness of eyes, severe eye irritation, corneal injury.

**Ingestion :** Ingestion may cause lung inflammation and damage due to aspiration of material into lungs, mouth and throat irritation, drowsiness, dizziness and/or lightheadedness, headache, uncoordination, nausea, vomiting, diarrhea, gastro-intestinal disturbances, abdominal pain, visual disturbances, apathy, central nervous system depression, intoxication, anesthetic effect or narcosis, burns of the mouth, throat, stomach, pulmonary edema, loss of consciousness, respiratory failure, death.

**Medical conditions aggravated by exposure :** Eye, skin, respiratory disorders, kidney disorders, liver disorders, nervous system disorders, respiratory disorders.

## FIRST-AID MEASURES (ANSI Section 4)

**Inhalation :** Remove to fresh air. Restore and support continued breathing. Get emergency medical attention. Have trained person give oxygen if necessary. Get medical help for any breathing difficulty. Remove to fresh air if inhalation causes eye watering, headaches, dizziness, or other discomfort.

**Skin contact :** Wash thoroughly with soap and water. If any product remains, gently rub petroleum jelly, vegetable or mineral/baby oil onto skin. Repeated applications may be needed. Remove contaminated clothing. Wash contaminated clothing before re-use. Dispose of contaminated leather items, such as shoes and belts. If irritation occurs, consult a physician.

**Eye contact :** Flush immediately with large amounts of water, especially under lids for at least 15 minutes. If irritation or other effects persist, obtain medical treatment.

**Ingestion :** If swallowed, obtain medical treatment immediately.

## FIRE-FIGHTING MEASURES (ANSI Section 5)

**Fire extinguishing media :** Dry chemical or foam water fog. Carbon dioxide. Closed containers may explode when exposed to extreme heat or fire. Vapors may ignite explosively at ambient temperatures. Vapors are heavier than air and may travel long distances to a source of ignition and flash back. Vapors can form explosive mixtures in air at elevated temperatures. Closed containers may burst if exposed to extreme heat or fire. Dust explosion hazard. May decompose under fire conditions emitting irritant and/or toxic gases.

**Fire fighting procedures :** Water may be used to cool and protect exposed containers. Firefighters should use full protective clothing, eye protection, and self-contained breathing apparatus. Self-contained breathing apparatus recommended.

**Hazardous decomposition or combustion products :** Carbon monoxide, carbon dioxide, oxides of nitrogen, oxides of sulfur, ammonia, hydrogen chloride, toxic gases, barium compounds. Cyanides.

## ACCIDENTAL RELEASE MEASURES (ANSI Section 6)

**Steps to be taken in case material is released or spilled :** Comply with all applicable health and environmental regulations. Eliminate all sources of ignition. Ventilate area. Ventilate area with explosion-proof equipment. Spills may be collected with absorbent materials. Use non-sparking tools. Evacuate all unnecessary personnel. Place collected material in proper container. Complete personal protective equipment must be used during cleanup. Large spills - shut off leak if safe to do so. Dike and contain spill. Pump to storage or salvage vessels. Use absorbent to pick up excess residue. Keep salvageable material and rinse water out of sewers and water courses. Small spills - use absorbent to pick up residue and dispose of properly.

## HANDLING AND STORAGE (ANSI Section 7)

**Handling and storage :** Store below 80f. Store below 100f (38c). Keep away from heat, sparks and open flame. Store in original container. Keep away from direct sunlight, heat and all sources of ignition. Keep container tightly closed in a well-ventilated area.

**Other precautions :** Use only with adequate ventilation. Do not take internally. Keep out of reach of children. Avoid contact with skin and eyes, and breathing of vapors. Wash hands thoroughly after handling, especially before eating or smoking. Keep containers tightly closed and upright when not in use. Empty containers may contain hazardous residues. Ground equipment when transferring to prevent accumulation of static charge.

## EXPOSURE CONTROLS/PERSONAL PROTECTION (ANSI Section 8)

**Respiratory protection :** Respiratory protection is required for use in isocyanate containing environments. Consider type of application and environmental concentrations when selecting respiratory protection. Observe governmental regulations for respirator use. (29 CFR 1910.134(OSHA))(Canadian z94.4) The use of positive pressure supplied air respirator is mandatory when the airborne isocyanate concentrations are not known. Note: isocyanate based materials have been determined to cause allergic sensitization in humans. Avoid inhalation and dermal (skin) contact with the uncured material.

**Ventilation :** Provide dilution ventilation or local exhaust to prevent build-up of vapors. Use explosion-proof equipment. Use non-sparking equipment.

**Personal protective equipment :** Eye wash, safety shower, safety glasses or goggles. Impervious gloves, impervious clothing, face shield, apron, boots.

## STABILITY AND REACTIVITY (ANSI Section 10)

**Under normal conditions :** Stable see section 5 fire fighting measures

**Materials to avoid :** Oxidizers, acids, reducing agents, bases, aldehydes, halogens, amines, alkalis, water, peroxides, nitric acid, alcohols, combustible materials, caustics, mineral acids. Nitrates.

**Conditions to avoid :** Sunlight, elevated temperatures, moisture, contact with oxidizing agent, storage near acids, sparks, open flame, ignition sources.

**Hazardous polymerization :** Will not occur

**TOXICOLOGICAL INFORMATION****(ANSI Section 11)**

**Supplemental health information :** Contains a chemical that is moderately toxic by ingestion. Contains a chemical that is toxic by inhalation. Contains a chemical that may be absorbed through skin. Free diisocyanate may cause allergic reaction in susceptible persons. Notice - reports have associated repeated and prolonged occupational overexposure to solvents with permanent brain and nervous system damage. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful or fatal. Contains iron oxide, repeated or prolonged exposure to iron oxide dust may cause siderosis, a benign pneumoconiosis. Other effects of overexposure may include toxicity to liver, kidney, central nervous system, blood.

**Carcinogenicity :** Contains formaldehyde, a potential cancer hazard. Rats exposed to formaldehyde via inhalation developed cancer of the nasal cavity. Evidence in humans is limited (nasal and nasopharyngeal cancer). Formaldehyde is listed as a carcinogen by OSHA, probable human carcinogen (group 2a) by IARC, and anticipated human carcinogen by NTP. Overexposure can cause eye, skin, and respiratory tract irritation, and skin and respiratory sensitization. In a lifetime inhalation study, exposure to 250 mg/m3 titanium dioxide resulted in the development of lung tumors in rats. These tumors occurred only at dust levels that overwhelmed the animals' lung clearance mechanisms and were different from common human lung tumors in both type and location. The relevance of these findings to humans is unknown but questionable. The international agency for research on cancer (IARC) has classified titanium dioxide as possibly carcinogenic to humans (group 2b) based on inadequate evidence of carcinogenicity in humans and sufficient evidence of carcinogenicity in experimental animals.

**Reproductive effects :** High exposures to xylene in some animal studies, often at maternally toxic levels, have affected embryo/fetal development. The significance of this finding to humans is not known.

**Mutagenicity :** No mutagenic effects are anticipated

**Teratogenicity :** No teratogenic effects are anticipated

**ECOLOGICAL INFORMATION****(ANSI Section 12)**

No ecological testing has been done by ICI paints on this product as a whole.

**DISPOSAL CONSIDERATIONS****(ANSI Section 13)**

**Waste disposal :** Dispose in accordance with all applicable regulations. Avoid discharge to natural waters.

**REGULATORY INFORMATION****(ANSI Section 15)**

As of the date of this MSDS, all of the components in this product are listed (or are otherwise exempt from listing) on the TSCA inventory. This product has been classified in accordance with the hazard criteria of the CPR (controlled products regulations) and the MSDS contains all the information required by the CPR.

**Physical Data****(ANSI Sections 1, 9, and 14)**

Product Code	Description	Wt. / Gal.	VOC gr. / ltr.	% Volatile by Volume	Flash Point	Boiling Range	HMIS	DOT, proper shipping name
359F65DGF	devthane 359h (no organic haps) derrick green	9.02	291.43	34.96	80 f	208-595	*330	UN1263, paint, 3, PGIII
379C0910	devthane 379 hs converter	9.40	112.85	13.00	135 f	293-293	*321	UN1866, resin solution, combustible liquid, PGIII

**Ingredients****Product Codes with % by Weight (ANSI Section 2)**

Chemical Name	Common Name	CAS. No.	359F65DGF	379C0910
4-heptanone, 2,6-dimethyl-	diisobutyl ketone	108-83-8	1-5	
ethane, 1,1',1''-methylidenetrakis(oxy)-tris-acetic acid, butyl ester	ethyl orthoformate	122-51-0	1-5	
c.i. pigment green 7	butyl acetate	123-86-4	5-10	5-10
benzene, dimethyl-	phthalo green pigment	1328-53-6	1-5	
titanium oxide	xylene	1330-20-7	.1-1.0	.1-1.0
2-propenoic acid, 2-methyl-, 2-hydroxyethyl ester, polymer with ethenylbenzene, 2-ethylhexyl 2-propeno and methyl 2-methyl-2-propenoate	titanium dioxide	13463-67-7	1-5	
hexane, 1,6-diisocyanato-, homopolymer	acrylic polymer	26916-05-2	40-50	
formaldehyde	aliphatic polyisocyanate	28182-81-2		90-95
c.i. pigment yellow 42	formaldehyde	50-00-0	LT .01	
acetic acid, 1,1-dimethylethyl ester	yellow iron oxide	51274-00-1	1-5	
butanamide, 2-((2-methoxy-4-nitrophenyl)azo) -n-(2-methoxyphenyl)-3-oxo-	tert-butyl acetate	540-88-5	1-5	
solvent naphtha (petroleum), light aromatic	pigment yellow 74	6358-31-2	1-5	
1-butanol	light aromatic solvent naphtha	64742-95-6		1-5
propanoic acid, 3-ethoxy-, ethyl ester	n-butanol	71-36-3	1-5	
sulfuric acid, barium salt	ethyl 3-ethoxypropionate	763-69-9	5-10	
castor oil	barium sulfate	7727-43-7	1-5	
hexane, 1,6-diisocyanato-	castor oil, raw	8001-79-4	10-20	
acetic acid, c6-8-branched alkyl esters	hexamethylene diisocyanate	822-06-0		.1-1.0
benzene,1,2,4-trimethyl-	oxo-heptyl acetate	90438-79-2	1-5	
anti-settling agent	pseudocumene	95-63-6	.1-1.0	1-5
polyamide	anti-settling agent	Sup. Conf.	1-5	
	rheological additive	Sup. Conf.	1-5	

**Chemical Hazard Data**

(ANSI Sections 2, 8, 11, and 15)

Common Name	CAS. No.	ACGIH-TLV				OSHA-PEL				S.R. Std.	S2	S3	CC	H	M	N	I	O
		8-Hour TWA	STEL	C	S	8-Hour TWA	STEL	C	S									
diisobutyl ketone	108-83-8	25 ppm	not est.	not est.	not est.	50 ppm	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
ethyl orthoformate	122-51-0	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
butyl acetate	123-86-4	150 ppm	200 ppm	not est.	not est.	150 ppm	not est.	not est.	not est.	not est.	n	n	y	n	n	n	n	n
phthalo green pigment	1328-53-6	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
xylene	1330-20-7	100 ppm	150 ppm	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	y	y	y	n	n	n	n
titanium dioxide	13463-67-7	10 mg/m3	not est.	not est.	not est.	10 mg/m3	not est.	not est.	not est.	not est.	n	n	n	n	n	y	y	n
acrylic polymer	26916-05-2	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
aliphatic polyisocyanate	28182-81-2	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
formaldehyde	50-00-0	not est.	not est.	0.3 ppm	not est.	0.75 ppm	2 ppm	not est.	not est.	not est.	y	y	y	y	n	y	y	y
yellow iron oxide	51274-00-1	5 mg/m3	not est.	not est.	not est.	10 mg/m3	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
tert-butyl acetate	540-88-5	200 ppm	not est.	not est.	not est.	200 ppm	not est.	not est.	not est.	not est.	n	n	y	n	n	n	n	n
pigment yellow 74	6358-31-2	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
light aromatic solvent naphtha	64742-95-6	not est.	not est.	not est.	not est.	500x ppm	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
n-butanol	71-36-3	20 ppm	not est.	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	y	y	n	n	n	n	n
ethyl 3-ethoxypropionate	763-69-9	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
barium sulfate	7727-43-7	10 mg/m3	not est.	not est.	not est.	5 mg/m3	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
castor oil, raw	8001-79-4	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
hexamethylene diisocyanate	822-06-0	0.005 ppm	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	y	y	y	n	n	n	n
oxo-heptyl acetate	90438-79-2	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
pseudocumene	95-63-6	25 ppm	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	y	n	n	n	n	n	n
anti-settling agent	Sup. Conf.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
rheological additive	Sup. Conf.	10 mg/m3	not est.	not est.	not est.	5 mg/m3	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n

**Footnotes:**

C=Ceiling - Concentration that should not be exceeded, even instantaneously.

S=Skin - Additional exposure, over and above airborne exposure, may result from skin absorption.

n/a=not applicable  
not est=not established  
CC=CERCLA Chemical

ppm=parts per million  
mg/m3=milligrams per cubic meter  
Sup Conf=Supplier Confidential

S2=Sara Section 302 EHS  
S3=Sara Section 313 Chemical  
S.R.Std.=Supplier Recommended Standard

H=Hazardous Air Pollutant, M=Marine Pollutant  
P=Pollutant, S=Severe Pollutant  
Carcinogenicity Listed By:  
N=NTP, I=IARC, O=OSHA, y=yes, n=no



## HAZARDS IDENTIFICATION (ANSI Section 3)

**Primary route(s) of exposure :** Inhalation, skin contact, eye contact, ingestion.

### Effects of overexposure :

**Inhalation :** Irritation of respiratory tract. Prolonged inhalation may lead to mucous membrane irritation, fatigue, drowsiness, dizziness and/or lightheadedness, headache, uncoordination, nausea, vomiting, diarrhea, abdominal pain, chest pain, blurred vision, flu-like symptoms, coughing, sneezing, difficulty with speech, apathy, central nervous system depression, anesthetic effect or narcosis, difficulty of breathing, allergic response, fever and chills, tremors, abnormal blood pressure, severe lung irritation or damage, liver damage, kidney damage, pulmonary edema, pneumoconiosis, loss of consciousness, respiratory failure, asphyxiation, death. Possible sensitization to respiratory tract.

**Skin contact :** Irritation of skin. Prolonged or repeated contact can cause dermatitis, defatting, blistering, allergic response, severe skin irritation, severe skin irritation or burns. Possible sensitization to skin.

**Eye contact :** Irritation of eyes. Prolonged or repeated contact can cause conjunctivitis, blurred vision, tearing of eyes, redness of eyes, severe eye irritation, severe eye irritation or burns, corneal injury.

**Ingestion :** Ingestion may cause lung inflammation and damage due to aspiration of material into lungs, mouth and throat irritation, drowsiness, dizziness and/or lightheadedness, headache, uncoordination, nausea, vomiting, diarrhea, gastro-intestinal disturbances, abdominal pain, visual disturbances, apathy, central nervous system depression, anesthetic effect or narcosis, burns of the mouth, throat, stomach, liver damage, kidney damage, pulmonary edema, loss of consciousness, respiratory failure, death.

**Medical conditions aggravated by exposure :** Eye, skin, respiratory disorders, lung disorders, asthma-like conditions, respiratory disorders.

## FIRST-AID MEASURES (ANSI Section 4)

**Inhalation :** Remove to fresh air. Restore and support continued breathing. Get emergency medical attention. Have trained person give oxygen if necessary. Get medical help for any breathing difficulty.

**Skin contact :** Wash thoroughly with soap and water. If any product remains, gently rub petroleum jelly, vegetable or mineral/baby oil onto skin. Repeated applications may be needed. Remove contaminated clothing. Wash contaminated clothing before re-use. Dispose of contaminated leather items, such as shoes and belts. If irritation occurs, consult a physician.

**Eye contact :** Flush immediately with large amounts of water, especially under lids for at least 15 minutes. If irritation or other effects persist, obtain medical treatment.

**Ingestion :** If swallowed, obtain medical treatment immediately.

## FIRE-FIGHTING MEASURES (ANSI Section 5)

**Fire extinguishing media :** Dry chemical or foam water fog. Carbon dioxide. Closed containers may explode when exposed to extreme heat or fire. Vapors may ignite explosively at ambient temperatures. Vapors are heavier than air and may travel long distances to a source of ignition and flash back. Vapors can form explosive mixtures in air at elevated temperatures. Closed containers may burst if exposed to extreme heat or fire. May decompose under fire conditions emitting irritant and/or toxic gases.

**Fire fighting procedures :** Water may be used to cool and protect exposed containers. Firefighters should use full protective clothing, eye protection, and self-contained breathing apparatus. Self-contained breathing apparatus recommended.

**Hazardous decomposition or combustion products :** Carbon monoxide, carbon dioxide, oxides of nitrogen, oxides of sulfur, ammonia, aldehydes, toxic gases, barium compounds. Cyanides.

## ACCIDENTAL RELEASE MEASURES (ANSI Section 6)

**Steps to be taken in case material is released or spilled :** Comply with all applicable health and environmental regulations. Eliminate all sources of ignition. Ventilate area. Ventilate area with explosion-proof equipment. Spills may be collected with absorbent materials. Use non-sparking tools. Evacuate all unnecessary personnel. Place collected material in proper container. Complete personal protective equipment must be used during cleanup. Large spills - shut off leak if safe to do so. Dike and contain spill. Pump to storage or salvage vessels. Use absorbent to pick up excess residue. Keep salvageable material and rinse water out of sewers and water courses. Small spills - use absorbent to pick up residue and dispose of properly.

## HANDLING AND STORAGE (ANSI Section 7)

**Handling and storage :** Store below 80f. Store below 100f (38c). Keep away from heat, sparks and open flame. Keep away from direct sunlight, heat and all sources of ignition.

**Other precautions :** Use only with adequate ventilation. Do not take internally. Keep out of reach of children. Avoid contact with skin and eyes, and breathing of vapors. Wash hands thoroughly after handling, especially before eating or smoking. Keep containers tightly closed and upright when not in use. Empty containers may contain hazardous residues. Ground equipment when transferring to prevent accumulation of static charge.

## EXPOSURE CONTROLS/PERSONAL PROTECTION (ANSI Section 8)

**Respiratory protection :** Control environmental concentrations below applicable exposure standards when using this material. When respiratory protection is determined to be necessary, use a NIOSH/MSHA (Canadian z94.4) Approved elastomeric sealing- surface facepiece respirator outfitted with organic vapor cartridges and paint spray (dust/mist) prefilters. Determine the proper level of protection by conducting appropriate air monitoring. Consult 29CFR1910.134 For selection of respirators (Canadian z94.4).

**Ventilation :** Provide dilution ventilation or local exhaust to prevent build-up of vapors. Use explosion-proof equipment. Use non-sparking equipment.

**Personal protective equipment :** Eye wash, safety shower, safety glasses or goggles. Impervious gloves, impervious clothing, face shield, apron.

## STABILITY AND REACTIVITY (ANSI Section 10)

**Under normal conditions :** Stable see section 5 fire fighting measures

**Materials to avoid :** Oxidizers, acids, reducing agents, bases, aldehydes, ketones, halogens, amines, carbon tetrachloride (at elevated temperatures), aluminum, nitric acid, metal compounds, lewis acids, mineral acids.

**Conditions to avoid :** Elevated temperatures, moisture, contact with oxidizing agent, storage near acids, sparks, open flame, ignition sources.

**Hazardous polymerization :** Will not occur may polymerize in presence of aliphatic amines.

## TOXICOLOGICAL INFORMATION (ANSI Section 11)

**Supplemental health information :** Contains a chemical that is moderately toxic by ingestion. Contains a chemical that may be absorbed through skin. Excessive inhalation of fumes may lead to metal fume fever characterized by a metallic taste in mouth, excessive thirst, coughing, weakness, fatigue, muscular pain, nausea, chills and fever. Notice - reports have associated repeated and prolonged occupational overexposure to solvents with permanent brain and nervous system damage. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful or fatal. Other effects of overexposure may include toxicity to liver, kidney, central nervous system, blood.

**Carcinogenicity :** The international agency for research on cancer (IARC) has evaluated ethylbenzene and classified it as a possible human carcinogen (group 2b) based on sufficient evidence for carcinogenicity in experimental animals, but inadequate evidence for cancer in exposed humans. In a 2 year inhalation study conducted by the national toxicology program (NTP), ethylbenzene vapor at 750 ppm produced kidney and testicular tumors in rats and lung and liver tumors in mice. Genetic toxicity studies showed no genotoxic effects. The relevance of these results to humans is not known.

**Reproductive effects :** High exposures to xylene in some animal studies, often at maternally toxic levels, have affected embryo/fetal development. The significance of this finding to humans is not known.

**Mutagenicity :** Triethylenetetramine has demonstrated weak mutagenic activity in standard in vitro tests, and has caused embryo- fetal toxicity and fetal malformations when fed to rats. Triethylenetetramine did not exhibit carcinogenic potential in life-time mouse skin painting studies.

**Teratogenicity :** No teratogenic effects are anticipated

**ECOLOGICAL INFORMATION**

(ANSI Section 12)

No ecological testing has been done by ICI paints on this product as a whole.

**DISPOSAL CONSIDERATIONS**

(ANSI Section 13)

**Waste disposal :** Dispose in accordance with all applicable regulations. Avoid discharge to natural waters.

**REGULATORY INFORMATION**

(ANSI Section 15)

As of the date of this MSDS, all of the components in this product are listed (or are otherwise exempt from listing) on the TSCA inventory. This product has been classified in accordance with the hazard criteria of the CPR (controlled products regulations) and the MSDS contains all the information required by the CPR.

**Physical Data**

(ANSI Sections 1, 9, and 14)

Product Code	Description	Wt. / Gal.	VOC gr. / ltr.	% Volatile by Volume	Flash Point	Boiling Range	HMIS	DOT, proper shipping name
313B0250	do not use, use dc313b0250d instead	24.77	334.95	41.44	90 f	244-304	*231	paint, 3, UN1263, PGIII
313C0910	catha coat 313 organic zinc-rich epoxy primer clear converter	7.54	338.66	41.11	110 f	243-304	*320	paint, combustible liquid, UN 1263, PGIII

**Ingredients**

Product Codes with % by Weight (ANSI Section 2)

Chemical Name	Common Name	CAS. No.	313B0250	313C0910
benzene, ethyl-	ethylbenzene	100-41-4	.1-1.0	
2-heptanone	methyl amyl ketone	110-43-0	5-10	20-30
1,2,-ethanediamine, n,n'-bis(2-aminoethyl)-	triethylenetetramine	112-24-3		1-5
zinc oxide	zinc oxide	1314-13-2	1-5	
benzene, dimethyl-	xylene	1330-20-7	1-5	
oxirane,2,2'-((1-methylethylidene) bis (4,1-phenyleneoxymethylene) ) bis-	diglycidyl ether of bisphenol a	1675-54-3	1-5	
phenol, 4,4'-(1-methylethylidene)bis-, polymer with 2,2'-((1-methylethylidene)bis (4,1-phenyleneoxymethylene))bis(oxirane)	epoxy resin	25036-25-3	1-5	
fatty acids, c18-unsatd., dimers, reaction products with polyethylenepolyamines	polyamide resin	68410-23-1		40-50
1-butanol	n-butanol	71-36-3		10-20
zinc	zinc	7440-66-6	70-80	
sulfuric acid, barium salt	barium sulfate	7727-43-7	1-5	
amine adduct	amine adduct	Sup. Conf.		10-20

**Chemical Hazard Data**

(ANSI Sections 2, 8, 11, and 15)

Common Name	CAS. No.	ACGIH-TLV				OSHA-PEL				S.R. Std.	S2	S3	CC	H	M	N	I	O
		8-Hour TWA	STEL	C	S	8-Hour TWA	STEL	C	S									
ethylbenzene	100-41-4	100 ppm	125 ppm	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	y	y	y	n	n	y	n
methyl amyl ketone	110-43-0	50 ppm	not est.	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
triethylenetetramine	112-24-3	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
zinc oxide	1314-13-2	2 mg/m3	10 mg/m3	not est.	not est.	5 mg/m3	not est.	not est.	not est.	not est.	n	y	n	n	n	n	n	n
xylene	1330-20-7	100 ppm	150 ppm	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	y	y	y	n	n	n	n
diglycidyl ether of bisphenol a	1675-54-3	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
epoxy resin	25036-25-3	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
polyamide resin	68410-23-1	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
n-butanol	71-36-3	20 ppm	not est.	not est.	not est.	100 ppm	not est.	not est.	not est.	not est.	n	y	y	n	n	n	n	n
zinc	7440-66-6	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	y	y	n	n	n	n	n
barium sulfate	7727-43-7	10 mg/m3	not est.	not est.	not est.	5 mg/m3	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n
amine adduct	Sup. Conf.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	not est.	n	n	n	n	n	n	n	n

**Footnotes:**  
C=Ceiling - Concentration that should not be exceeded, even instantaneously.

S=Skin - Additional exposure, over and above airborne exposure, may result from skin absorption.

n/a=not applicable  
not est=not established  
CC=CERCLA Chemical

ppm=parts per million  
mg/m3=milligrams per cubic meter  
Sup Conf=Supplier Confidential

S2=Sara Section 302 EHS  
S3=Sara Section 313 Chemical  
S.R.Std.=Supplier Recommended Standard

H=Hazardous Air Pollutant, M=Marine Pollutant  
P=Pollutant, S=Severe Pollutant  
Carcinogenicity Listed By:  
N=NTP, I=IARC, O=OSHA, y=yes, n=no



---

---

## SECTION 3 - INSTALLATION

---

### GENERAL

This section describes the recommended installation procedure for the ACD-1500 Degasser. Instructions include equipment handling, equipment leveling, and electrical connections.

### SAFETY

Read and understand **ALL** safety information presented in this manual **before** installing and operating this equipment. Refer to Section 2 for a summary of Warnings affecting installation, operation, and maintenance of this equipment.

Before beginning the installation, review the information presented in *Equipment Hoisting* later in this section. Pay particular attention to the information concerning lift points.

Failure to observe proper equipment handling procedures may result in serious personal injury or death and/or damage to the equipment.



**WARNING! BE SURE THAT HANDLING DEVICES HAVE SUFFICIENT LIFTING CAPACITY TO SAFELY HANDLE THE WEIGHT OF THE EQUIPMENT.**



**WARNING! TO ENSURE PROPER BALANCE AND ORIENTATION WHEN UNIT IS RAISED AND PREVENT DAMAGE TO COMPONENTS, ATTACH LIFTING SLINGS ONLY TO LABELLED LIFTING POINTS. DO NOT ATTEMPT LIFTING BY ATTACHMENT TO ANY OTHER LOCATION.**

### INSTALLATION SEQUENCE

Following is the sequence of steps for installing the ACD-1500 Degasser. The sequence may vary depending on the user's facilities and previous experience with this type of equipment.

1. Read and understand all safety information in Section 2 before installing and operating this equipment.
2. Install the degasser in the drilling fluid tank downstream of the shale shaker.
3. Be sure the unit is secure and level on the tank.
4. Connect a 6" vent line to the exhaust fan flange to carry gas to a safe area.
5. Connect electrical power supply to the equipment.
6. Refer to Section 4 for startup and operating instructions.

## INSTALLATION

---

### STORAGE

#### Storage Before Use

If equipment is not being installed immediately, it should be stored in a dry environment (50 percent relative humidity or less). A dry environment will ensure that the machine remains in the same condition as when it was received.

If unit is stored outdoors, use a UV-resistant tarp, or UV-resistant shrink wrap. Install vents when using shrink wrap. Seal the Operation and Maintenance manual in plastic and attach to unit.

#### Storage After Use



**WARNING! BEFORE PREPARING THE DEGASSER FOR STORAGE, SHUT DOWN, DISCONNECT, AND LOCK OUT AND TAG OUT ELECTRIC POWER.**

Prior to an idle period of any duration the unit must be thoroughly cleaned inside and out to prevent damage from hardening of built-up mud. After cleaning the unit, cover outlet flange.

#### Preventive Maintenance During Storage

To prevent motor damage during the storage period, perform the following precautionary activities:

1. Check insulation resistance of the motor windings using a megohmmeter (Megger). Periodically measure and record the readings in a log. Investigate any significant drop in resistance immediately.
2. Rotate the motor shaft 10 full turns at least once every two months to decrease the likelihood of bearing deterioration during storage.



**Note! Do not lubricate bearings during storage. Motor bearings are packed with grease at the factory and can be damaged by excessive grease.**

### SITE PREPARATION AND CLEARANCE REQUIREMENTS

Prior to installation of equipment, verify that electricity is available at the installation site. Also ensure that clearances around the equipment are adequate. Prepare the installation site as follows:

1. Check that discharge chute, if used, is properly sized for the equipment (refer to general assembly drawing in Section 8 for discharge size).
2. Verify that available electric power supply at the site agrees with electric power requirements of the equipment.

### MOVING/POSITIONING THE EQUIPMENT

The degasser is shipped fully assembled. A label indicating the weight of the unit is affixed to the equipment. While the machine is still mounted on the wooden shipping skid, the unit should be transported on the ground using a forklift. After the machine is removed from the shipping skid, either a forklift or overhead-lifting device may be used.

## INSTALLATION



**WARNING! BE SURE THAT HANDLING DEVICES HAVE SUFFICIENT LIFTING CAPACITY TO SAFELY HANDLE THE WEIGHT OF THE EQUIPMENT.**



**WARNING! DO NOT REMOVE ORANGE SHIPPING BRACKETS UNTIL EQUIPMENT HAS BEEN POSITIONED AT FINAL INSTALLATION SITE.**



**WARNING! WHEN USING AN OVERHEAD LIFTING DEVICE, USE ONLY THE SINGLE LIFT POINT PROVIDED. DO NOT ATTEMPT TO LIFT MACHINE USING ANY OTHER LIFTING LOCATION.**

### Equipment Hoisting

A single lifting lug is attached to the top of the degasser to allow attachment of an overhead lifting device (Figure 3-1). The lug is labeled “**LIFT HERE ONLY**”. **DO NOT** attempt to lift the degasser by any other non-designated portion of the unit. Install a clevis that is capable of supporting the equipment weight through the lifting lug, and attach the hoisting sling to the clevis.




Figure 3-1 Hoisting Degasser

## INSTALLATION

---

### Positioning and Mounting

Position the degasser with sufficient space around unit to allow access to various components by operators and maintenance personnel. Approximately 2' to 3' space is required on all four sides of the equipment. The recommended installation is to weld rails close to the degasser to “trap” the machine in place. The degasser should not be welded to the tank as this installation will prevent access to the pump.

Typical operation and maintenance functions include the following activities:

- Removing the access panels
- Greasing drive shaft bearings
- Connection of exhaust line
- Access to electrical control panel

### Leveling

For proper operation, the degasser must be properly leveled along its length and width (Figure 3-2). A 4-foot level is recommended. Shim the equipment as required to level the unit.








Figure 3-2 Degasser Leveling

## INSTALLATION

### ELECTRIC POWER CONNECTIONS

	<b>WARNING! TO AVOID SERIOUS PERSONAL INJURY BE SURE POWER TO EQUIPMENT IS LOCKED OUT, TAGGED OUT, AND DE-ENERGIZED BEFORE BEGINNING ELECTRICAL INSTALLATION.</b>
	<b>WARNING! MOTOR MUST BE OPERATED AT THE DESIGNATED SUPPLY VOLTAGE AND FREQUENCY.</b>
	<b>WARNING! A FUSED-DISCONNECT PRIMARY POWER SUPPLY WITH SUFFICIENT INTERRUPTING CAPACITY TO CLEAR THE MAXIMUM FAULT CURRENT CAPABILITY OF THE SYSTEM IS REQUIRED.</b>
	<b>WARNING! ELECTRICAL CONNECTIONS MUST BE MADE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND ALL APPLICABLE LOCAL CODES. FAILURE TO COMPLY MAY RESULT IN AN UNSAFE CONDITION THAT COULD INJURE PERSONNEL OR DAMAGE EQUIPMENT. ENSURE THAT ALL ELECTRICAL AND CONDUIT CONNECTIONS ARE SECURE.</b>

The electrical connections should be performed only by trained, qualified personnel familiar with high-voltage applications and knowledgeable of National Electrical Code (NEC) standards and other applicable state or local codes for installation of industrial equipment. A fused disconnect is required for primary power supply.

The degasser is factory-wired to operate at either of the following two power configurations:

460/480Vac 60Hz Three-phase

380/400Vac 50Hz Three-phase

Refer to Section 8 for the wiring schematic for the machine's power requirements. The fused disconnect and wiring to the equipment shall be suitably sized and in accordance with NEC standards and all applicable state and local codes.

Make the following electric power connections:

1. Install a fused disconnect device having sufficient interrupting capacity to clear the maximum fault current capability of the power supply system.
2. Remove the plug from hole at bottom of the electrical control panel, install appropriate feed-through into the hole, and attach rigid conduit. Pass three-phase cable through the conduit and into the control panel.
3. Connect three-phase power leads to the terminal block at the lower left corner of the electrical control panel as shown in Figure 3-4.
4. Turn on electric power, press START button, and confirm that pump motor rotates in correct direction. Reverse two leads in electrical control panel, if motor rotation is opposite.



**Note! If rotation is opposite, connections are reversed. Refer to Section 3 for proper connection procedure.**

## INSTALLATION

---




Figure 3-4 Electrical Connections

### SPLASH PLATE ADJUSTMENT

The splash plate is adjustable in 1/4" increments within a range of 1/4" to 1-1/2". Generally, the gap should be set to accommodate the gas content of the drilling fluid. If gas content is high, it may be desirable to maximize release of gas by narrowing the splash plate gap. However, at the smallest opening, flow through the degasser will be approximately 500GPM; at its largest gap, flow is about 1500GPM. The setting should be consistent with process considerations and based on experience in operating the degasser.

To adjust the splash plate gap (Figure 3-5), proceed as follows:

1. Loosen bolts on both ends of the splash plate sufficiently to permit disengagement of the splash plate and guide teeth.
2. Move splash plate upward to increase the gap or down to reduce the gap, being certain that plate is parallel with top of riser.
3. When desired setting is achieved, engage teeth, and tighten bolts to secure splash plate in position.



Figure 3-5 Splash Plate Adjustment

### MACHINE STARTUP

Refer to Section 4 for startup and operating procedures.

---

---

## SECTION 4 - OPERATING INSTRUCTIONS

---

### GENERAL

This section includes initial and normal startup shutdown procedures for the ACD-1500 Degasser, as well as emergency shutdown.

### OPERATING SAFETY



**WARNING! ALL OPERATING AND MAINTENANCE PERSONNEL MUST READ AND UNDERSTAND ALL SAFETY INFORMATION IN THIS MANUAL BEFORE WORKING WITH THE EQUIPMENT.**

### INITIAL STARTUP

The initial startup procedure should be used when the equipment is being started for the first time, or when equipment has been returned to use after an extended period out of service.

1. Verify that all operators and maintenance personnel have read and understand all operating and safety information in Section 2.
2. Confirm that equipment has been installed in accordance with Section 3.
3. Check that correct electric power configuration is available in accordance with Section 3.
4. Be sure that all operators and maintenance personnel are clear of equipment before applying electric power to vacuum pump and centrifugal pump.
10. Open fused disconnect that supplies electric power to the machine. Press START button on the electrical control panel to turn on the centrifugal pump motor and exhaust fan motor. Liquid will then be drawn into the pump and circulated up to the spray tank. Check that centrifugal pump turns in proper direction to draw in liquid; if direction is opposite, reverse two electrical leads.



**Note! If rotation is opposite, connections are reversed. Refer to Section 3 for proper connection procedure.**

### NORMAL STARTUP AND OPERATION

The following procedure shall be performed at each machine startup:

1. Be sure that all operators and maintenance personnel are clear of the equipment before applying electric power to vacuum pump and centrifugal pump.
2. Turn on electric power to degasser.
3. Press START button on the electrical control panel to turn on the centrifugal pump motor and exhaust fan motor to begin circulating mud through the degasser.

## **OPERATING INSTRUCTIONS**

---

### **NORMAL SHUTDOWN**

The normal shutdown procedure is to be used for controlled stopping of operation. Normal shutdown is performed for routine activities such as cleaning, lubrication, inspection, or other routine procedure.

1. Press STOP button on the electrical control panel to stop the centrifugal pump and exhaust fan.
2. Open fused disconnect that supplies electric power to the machine.

### **EMERGENCY SHUTDOWN**

To immediately stop the machine in case of emergency, open the fused disconnect supplying electric power to the machine.



---

## SECTION 5 - MAINTENANCE

---

### GENERAL

Proper maintenance will ensure maximum life and trouble-free operation. While the maintenance schedule presented in this section is not rigid, modifications should be based on experience with operating the equipment at your facilities. A maintenance log should be kept to help establish a routine maintenance schedule, as well as to monitor and adjust the schedule as necessary throughout the equipment's life.

Consider the following factors when establishing a maintenance schedule:

- Duty cycle
- Ambient temperature
- Operating environment

### BEARING LUBRICATION



**WARNING! TO AVOID SERIOUS PERSONAL INJURY BE SURE EQUIPMENT IS LOCKED OUT, TAGGED OUT, AND DE-ENERGIZED PRIOR TO PERFORMING MAINTENANCE.**

The upper and lower shaft bearings (Figure 5-1) must be re-lubricated periodically based on hours of operation. For safety, lubrication is to be performed with the degasser shut down, locked out, and tagged out.



**Figure 5-1 Upper and Lower Shaft Bearing Lubrication**

## MAINTENANCE

---

---

### BEARING LUBRICATION (CONT'D)

The recommended lubricant for the shaft bearings is NLGI grade 2 mineral oil lithium or lithium complex base grease. Grease should be injected into grease fitting until purged through the fitting regardless of the quantity added. Bearings should be re-lubricated in accordance with the following schedule:

Daily Operating Hours	Interval (Weeks)
8	10
16	5
24	3

### TROUBLESHOOTING

As long as the mud level in the tank remains at or above 12" (305mm), the degasser will circulate fluid up to the spray tank. Malfunctions are generally caused by incoming power disruptions or tripping of overloads or blown fuse(s) in the electrical control panel. Always check these items and for correct incoming power first before proceeding with further checking and tests.

Refer to the electrical schematic diagram in Section 8 for assistance in tracing electrical malfunctions. Before performing electrical continuity checks, always shut down, lock out, and tag out electric power to degasser.



**WARNING! TO AVOID SERIOUS PERSONAL INJURY BE SURE EQUIPMENT IS LOCKED OUT, TAGGED OUT, AND DE-ENERGIZED PRIOR TO PERFORMING MAINTENANCE.**

### PARTS REPLACEMENT

Defective parts should be replaced as soon as possible to prevent further damage to the equipment. Refer to the applicable drawings in Section 8 for Derrick component locations and part numbers. Refer to Section 10 for supplier component data.

### SPARE PARTS

Since all potential part replacements cannot be predicted, the spare parts inventory should be based on the user's experience with similar equipment.

Consider the following factors when establishing a spare parts inventory:

- Duty cycle
- Ambient temperature
- Operating environment



---

---


## SECTION 8 - REFERENCE DRAWINGS

---

This section contains Derrick engineering drawings for your equipment. These drawings are included to provide assistance in troubleshooting, repair, and parts ordering.

<b>Number</b>	<b>Title</b>
<a href="#"><u>17171-00</u></a>	ACD-1500 Degasser General Arrangement
<a href="#"><u>17173-00</u></a>	ACD-1500 Degasser Parts List
<a href="#"><u>17199-00</u></a>	ACD-1500 Degasser 380/460V Electrical Component Parts List
<a href="#"><u>17197-00</u></a>	ACD-1500 Degasser 380/460V Electrical Control Panel Parts List
<a href="#"><u>17198-00</u></a>	ACD-1500 Degasser Wiring Schematic
<a href="#"><u>PE-S-014-09</u></a>	Thermal Unit Selection Table






RECOMMENDED MAINTENANCE AND ACCESS SPACE-	
FRONT-	1 METER [2-3 FEET]
SIDES-	1 METER [2-3 FEET]
REAR-	1 METER [2-3 FEET]

OVERALL DIM ± 1/4 [6]  
 DIMENSIONS IN [ ] = MM  
 APPROX WEIGHT 2800 LBS / 1270 KG


TAG	
DATE:	_____
EQUIPMENT NO.:	_____
DERRICK MODEL NO.:	_____
DERRICK DRAWING NO.:	17171-00
PARTS LIST NO.:	17173-00
PURCHASE ORDER NO.:	_____



J	1	ELECTRICAL COMPONENTS		REF 17199-00
I	1	ACCESS PANELS	17182-00	
H	1	GEAR UNIT	TO SPECIFICATION	
G	1	MOTOR	TO SPECIFICATION	
F	1	PUMP BOTTOM	17184-01	
E	1	PUMP RISER	17185-01	
D	1	PUMP	17174-01	
C	1	VENT	17181-01	
B	1	TANK	17176-01	
A	1	SKID	17179-01	
01	X	ACD-1500 ASSEMBLY		17173-01
ITEM	QTY	PART NAME	PART NUMBER/DESCRIPTION	PARTS LIST

REV		CHANGE	CHKD	DATE	FILE		GENERAL ARRANGEMENT	
D		N	F.C.		MP		ACD-1500 DEGASSER	
DATE		7/31/09	SCALE		1"=10"		DERRICK CORPORATION	
DRAWN BY			DERRICK		CORPORATION		590 DUKE ROAD BUFFALO, NY 14225 U.S.A.	
D		N	F.C.		17171-00			






ITEM	QTY	PART NAME	PART NUMBER	DESCRIPTION
31	1	STABILIZER BRACKET ASSEMBLY	17207-01	3/8 HRS
30	1	COUPLING INSERT	G0009176	2-PIECE HYTREL
29	1	KEY, SHAFT @ COUPLING (MOTOR SIDE)	G0009169	1/2 X 1/2 X 2 3/4 CRS
28	1	KEY, SHAFT @ COUPLING (IMPEL. SIDE)	G0009167	5/8 X 3/4 X 2 3/4 CRS
27	1	KEY, SHAFT @ IMPELLER	G0009168	5/8 X 3/4 X 3 CRS
26	1	BUSHING	G0009175	2 15/16 TAPER-LOCK
25	1	IMPELLER	17175-00	HRS, BALANCED
24	1	SHAFT	17178-01	Ø2 15/16 1045 CFS
23	1	SHAFT STABILIZER	17177-01	2-PIECE HRS/NYLON
22	1	BEARING	G0009171	RADIAL & THRUST LOAD
21	3	COLLAR	G0009172	CLAMPING 2 15/16 ID STL
20	1	BEARING	G0009170	RADIAL LOAD
19	1	COUPLING (IMPELLER SIDE)	G0009174	2 15/16 ID
18	1	COUPLING (MOTOR SIDE)	G0009173	2 1/8 ID
17	1	GEAR UNIT MOUNTING PLATE	17187-01	3/8 HRS
16	1	SPLASH PLATE	17183-01	HRS
15	1	CLOSE-OFF (UPPER)	17186-02	10GA HRS
14	1	CLOSE-OFF (LOWER)	17186-01	10GA HRS
13	1	ACCESS PANEL (NARROW)	17182-02	10GA HRS
12	1	ACCESS PANEL (WIDE)	17182-01	10GA HRS
11	1	ELECTRICAL COMPONENTS		TO SPECIFICATION
10	1	BLOWER/ MOTOR		TO SPECIFICATION
09	1	GEAR UNIT	REF 17199-00	TO SPECIFICATION
08	1	MOTOR		TO SPECIFICATION
07	1	PUMP BOTTOM	17184-01	HRS
06	1	PUMP RISER	17185-01	HRS
05	1	PUMP	17174-01	HRS
04	1	VENT	17181-01	HRS
03	1	TANK	17176-01	HRS
02	1	SKID	17179-01	HRS
01	1	ACD-1500 ASSEMBLY	17173-01	ASSEMBLY COMPLETE

GA REF 17171-00

REV		CHANGE		DATE	DATE	DWN	MP	CD	EJR	DATE	SCALE	REV	
1				12/22/08						7/31/09	NONE	1	
THE DESIGNS AND INFORMATION CONTAINED ON THIS DRAWING OR COPIES REMAIN THE EXCLUSIVE PROPERTY OF DERRICK CORPORATION BUFFALO, NEW YORK U.S.A. AND ARE NOT TO BE REPRODUCED WITHOUT THE WRITTEN PERMISSION OF DERRICK CORPORATION. THE INFORMATION CONTAINED ON THIS DRAWING SHALL ONLY BE USED BY CUSTOMERS OR PROSPECTS OR THEIR AGENCIES IN THE ARRANGEMENT OR INSTALLATION OF DERRICK EQUIPMENT, OR BY VENDORS IN QUOTING ON OR IN THE SUPPLY OF PARTS OR ASSEMBLIES TO DERRICK, OR BY OTHERS FOR THE SPECIFIC REASON OUTLINED IN THE TRANSMITTAL WHETHER WRITTEN OR VERBAL.													
DRAWING NO.										17173-00			
590 DUKE ROAD BUFFALO, NY 14225 U.S.A.													










OVERLOAD SETTINGS	VOLTAGE	RATING	SET TO FLA
DEGASSER MOTOR	460V 60HZ	25 HP	30.8 A
	380V 50HZ	18 KW/20 HP	30.0 A
FAN MOTOR	460V 60HZ	0.50 HP	0.8 A
	380V 50HZ	0.3KW/.33HP	0.7 A

QTY	ITEM	PART NO.	PART NAME	DESCRIPTION
2	1	17	G0009320	GROUND LUG #8 FOR DEGASSER MOTOR
2	6	16	G0003528	CAP,HEAT SHRINK-1"
2	6	15	G0003543	CONNECTOR,SPLIT BOLT-#8STR MECH/COMP
1	14	G0002739	ADAPTER	1.5 NPT M TO 0.75 NPT F ZPL STL
2	13	NPLE-75-COND	CLOSE NIPPLE	0.75 NPT GALV STL
2	12	CRH-EL 2	ELBOW 45 DEGREE	0.75 FPT MAL IRON
2	11	NOT USED		
2	10	NOT USED		
1	09	SKPP-75	PLUG, PIPE	0.75 NPT HEX SKT ZPL STL
2	08	CRH-EL-296	ELBOW 90 DEGREE	0.75 NPT MALE TO FEMALE
1	07	G0009220	FAN MOTOR	0.50 HP, 480/60, 0.37 KW, 380/50, 55 C
1	06	G0009188	PUMP MOTOR	25 HP, 480/60, 18 KW, 380/50, 55 C
1	05	<b>15688-01-003</b>	CORD, FAN POWER	ASSEMBLY
1	04	<b>17224-01</b>	CORD, MOTOR POWER	ASSEMBLY
1	03	17197-01	ELECTRICAL CONTROL PANEL, EP	380/460V COMPONENT ASSEMBLY
2	02	NOT USED		
1	01	17199-01	460V 60HZ, 380V 50HZ, 55 C ELECTRICAL	ASSEMBLY COMPLETE


REF: GA# 17171-00  
 REF: WS# 17198-00  
 REF: EPL# 17197-00

REV		CHANGE		CKD	DATE	TITLE		ELECTRICAL COMPONENT LIST FOR XP ATMOSPHERIC CENTRIFUGAL DEGASSER MODEL ACD-1500 380/460V								
2		REVISE QTY ITEM 08 (WAS 3), ADD ITEMS 12 TO 17, OMIT ITEMS 02, 10 AND 11. (WAS SEPERATE 380/50 COMPONENTS)		JWC	JFS	10/06/09	DWN	JWC	CKD	BTD	DATE	08/19/09	SCALE	NTS	REV	2
1		CHANGE ENCLOSURE TO SA1792 (WAS SA1264), REVISE QUANTITY OF ITEM 09 (WAS ITEM 08 AND 4), ADD ITEMS 02, 10 & 11, REVISE OTHER ITEM NUMBERS, ADD OVERLOAD CHART		JWC	JFS	09/15/09										
THE DESIGNS AND INFORMATION CONTAINED ON THIS DRAWING OR COPIES REMAIN THE EXCLUSIVE PROPERTY OF DERRICK CORPORATION BUFFALO, NEW YORK U.S.A. AND ARE NOT TO BE REPRODUCED WITHOUT THE WRITTEN PERMISSION OF DERRICK CORPORATION. THE INFORMATION CONTAINED ON THIS DRAWING SHALL ONLY BE USED BY CUSTOMERS OR PROSPECTS OR THEIR AGENCIES IN THE ARRANGEMENT OR INSTALLATION OF DERRICK EQUIPMENT, OR BY VENDORS IN QUOTING ON OR IN THE SUPPLY OF PARTS OR ASSEMBLIES TO DERRICK, OR BY OTHERS FOR THE SPECIFIC REASON OUTLINED IN THE TRANSMITTAL WHETHER WRITTEN OR VERBAL.							SHEET SIZE B N DWN F C CKD		DRAWING NO. <b>17199-00</b>				590 DUKE ROAD BUFFALO, NY 14225 U.S.A.			





EP PANEL




QTY	ITEM	PART NUMBER	PART NAME	DESCRIPTION
2	20	G0007341	DIN35 RAIL 3"	
1	19	G0008544	TERMINAL BLOCK END	
3	18	G0008543	TERMINAL BLOCK	2 PT 12AWG
2	17	G0009216	TERMINAL BLOCK END	
6	16	G0009215	TERMINAL BLOCK	2 PT 8AWG
7	15	G0008507	DIN RAIL END STOP/SPACER	END STOP, 6 MM
5	14	G0004286	DIN RAIL END STOP/SPACER	END STOP, 10 MM
1	13	G0007342	DIN35 RAIL 8.5"	
1	12	G0002013	GROUND LUG #2-#14	
1	11	G0005309	GROUND BAR	GROUND BAR 7 POINT
1	10	G0009185	CONTROL RELAY	24VDC COIL 1NO/1NC
1	09	G0009184	DC POWER SUPPLY	72 WATT
2	08	G0009183	PRIMARY FUSE	2 AMP CLASS CC TIME DELAY
1	07	G0009182	FUSE BLOCK	30 A RATED CLASS CC FUSES
1	06	G0009181	CONTACTOR, WITH 24 VDC COIL CONTROLLER	NON-REVERSING IEC SIZE A
1	05	G0009180	MANUAL MOTOR PROTECTOR AUXILIARY CONTACT	1NO/1NC CONTACT
1	04	G0009179	MANUAL MOTOR PROTECTOR	1.0-1.6 A OVERLOAD SETTING
1	03	G0009178	STARTER 3P WITH 24 VDC COIL CONTROLLER	NON-REVERSING IEC SIZE E (16-50 OVERLOAD SETTING)
1	02	G0009237	ENCLOSURE 10 X 14 X 6	EXPLOSIONPROOF SA1792
1	01	17197-01	460/480V 60HZ & 380/400V 50HZ CONTROL PANEL	ASSEMBLY COMPLETE

REF WS 17198-00  
REF EPL 17199-00

2		REVISE LOCATION OF CONDUIT HOLES ON RIGHT SIDE AND BOTTOM		JWC	10/06/08	TITLE: PARTS LIST FOR FP ELECTRICAL CONTROL PANEL FOR MODEL ACD-1500 DEGASSER 380/460V	
1		ADD TERMINAL BLOCKS ITEMS 15 TO 20, CHANGE ENCLOSURE TO SA 1792		JWC	09/15/09	DATE: 08/18/09	SCALE: NTS
REV	CHANGE	DATE	BY	CHK	DATE	SCALE	REV
C		N		DWN		DERRICK CORPORATION	
SHEET SIZE		F C		CHK		DRAWING NO. 17197-00	
590 DUKE ROAD		BUFFALO, NY 14225 U.S.A.		SHAWMUT		PDR	





SUPPLIED BY DERRICK CORP.

REF PL# 17199-00  
REF EPL# 17197-00

TITLE		WIRING SCHEMATIC FOR MODEL ACD-1500 DEGASSER			
REV	CHANGE	DATE	SCALE	REV	
1	ADD TERMINAL BLOCKS, REVISE CONTROL WIRE COLORS	09/15/09	NONE	1	
DWN		JWC	CKD	JFS	DATE
SHEET SIZE		B	N	DWN	
DRAWING NO.		F	C	CKD	
17198-00		590 DUKE ROAD BUFFALO, NY 14225 U.S.A.			





## RECOMMENDED THERMAL UNIT SELECTION TABLE FOR DERRICK® SUPPLIED MANUAL STARTERS

### DERRICK VIBRATING MACHINES

F, FX, K, KX, L, LX, T, TX MOTORS	575V.A.C.	60Hz	1.5HP =	SQD-B3.30	or	FUR-H19
	460V.A.C.	60Hz	1.5HP =	SQD-B4.15	or	FUR-H21
	230V.A.C.	60Hz	1.5HP =	SQD-B10.2	or	FUR-H26
	215V.A.C.	60Hz	1.5HP =	SQD-B10.2	or	FUR-H27
	440V.A.C.	50Hz	1.5HP =	SQD-B3.70	or	FUR-H19
	380V.A.C.	50Hz	1.5HP =	SQD-B4.15	or	FUR-H21
	220V.A.C.	50Hz	1.5HP =	SQD-B8.20	or	FUR-H26
E, EX, M, MX, SG, SGX MOTORS	575V.A.C.	60Hz	2.5HP =	SQD-B6.25	or	FUR-H24
	460V.A.C.	60Hz	2.5HP =	SQD-B7.70	or	FUR-H26
	230V.A.C.	60Hz	2.5HP =	SQD-B17.5	or	FUR-H32
	215V.A.C.	60Hz	2.5HP =	SQD-B17.5	or	FUR-H32
	440V.A.C.	50Hz	2.5HP =	SQD-B6.90	or	FUR-H24
	380V.A.C.	50Hz	2.5HP =	SQD-B7.70	or	FUR-H26
	220V.A.C.	50Hz	2.5HP =	SQD-B14.0	or	FUR-H31
R, RX MOTORS	575V.A.C.	60Hz	3.0HP =	SQD-B6.90	or	FUR-H25
	460V.A.C.	60Hz	3.0HP =	SQD-B9.10	or	FUR-H27
	230V.A.C.	60Hz	3.0HP =	SQD-B19.5	or	FUR-H33
	215V.A.C.	60Hz	3.0HP =	SQD-B19.5	or	FUR-H34
	440V.A.C.	50Hz	3.0HP =	SQD-B7.70	or	FUR-H26
	380V.A.C.	50Hz	3.0HP =	SQD-B9.10	or	FUR-H27
	220V.A.C.	50Hz	3.0HP =	SQD-B17.5	or	FUR-H32
A, C, N MOTORS	575V.A.C.	60Hz	5.0HP =	SQD-B11.5	or	FUR-H29
	460V.A.C.	60Hz	5.0HP =	SQD-B15.5	or	FUR-H32
	230V.A.C.	60Hz	5.0HP =	SQD-B36.0	or	FUR-H40
	215V.A.C.	60Hz	5.0HP =	SQD-B36.0	or	FUR-H40
	440V.A.C.	50Hz	5.0HP =	SQD-B12.8	or	FUR-H30
	380V.A.C.	50Hz	5.0HP =	SQD-B15.5	or	FUR-H32
	220V.A.C.	50Hz	5.0HP =	SQD-B32.0	or	FUR-H37

### DERRICK DEGASSER

575V.A.C.	60Hz	5.0HP =	SQD-B8.20	or	FUR-H28
460V.A.C.	60Hz	5.0HP =	SQD-B10.2	or	FUR-H30
230V.A.C.	60Hz	5.0HP =	SQD-B19.5	or	FUR-H38
415V.A.C.	50Hz	5.0HP =	SQD-B11.5	or	FUR-H31
380V.A.C.	50Hz	5.0HP =	SQD-B19.5	or	FUR-H32

### DERRICK PRIMER

575V.A.C.	60Hz	1.5HP =	SQD-B3.30
460V.A.C.	60Hz	1.5HP =	SQD-B3.70
230V.A.C.	60Hz	1.5HP =	SQD-B8.20
380V.A.C.	50Hz	1.5HP =	SQD-B3.70

NOTE: IF MOTOR VOLTAGE OR HORSE POWER IS NOT LISTED, CONTACT ENGINEERING DEPARTMENT.

\*\*\*\* FOR MAGNETIC STARTER OVERLOAD INFO REFER TO THE ELECTRICAL PARTS LIST THAT IS FOUND ON THE EQUIPMENTS GENERAL ARRANGEMENT DRAWING.

Derrick®, Flo-Line®, FLC 2000™, Flo-Line Scalper™, Pyramid®, Sandwich Screens®, DE-1000™, Hi-G™, Vacu-Flo™, GBG™, PMD™, PWP™, SWG™, DC™, DF™, DX™, and GST™, are trademarks of Derrick Corporation.







---

---

## SECTION 9 - INSTALLATION AND MAINTENANCE LOG

---

### **PURPOSE**

This section should be used by operating and maintenance personnel to record historical information gathered during the installation and operation of the Derrick equipment. If properly kept, the log will be useful for altering maintenance intervals and intercepting trends that may indicate the need for changing operating procedures. Each entry in the log should be dated for future reference and tracking. If required, additional pages may be added to the log by copying a blank page or simply inserting ruled paper at the rear of the section.

### **Installation and Maintenance Notes:**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---













---

---

## SECTION 10 - SUPPLIER DATA

---


### GENERAL

Documentation for ACD-1500 Degasser components manufactured by outside suppliers is included in this section. For Derrick engineering drawings, refer to Section 8.

COMPONENT	DESCRIPTION	DOCUMENT
Baldor 25HP Centrifugal Pump Motor	Wiring Diagram	<a href="#">Drawing CD0005</a>
	Installation and Operation	<a href="#">MN400-209</a>
	Specifications	<a href="#">CM7058-I</a>
Baldor 0.50HP Exhaust Fan Motor	Installation and Operation	<a href="#">MN400-209</a>
	Specifications	<a href="#">CM7006-I</a>
Cincinnati Fan Exhaust Blower	Operation and Maintenance Manual	<a href="#">OMM-09-0509</a>







NOTES:

1. INTERCHANGE ANY TWO LINE LEADS TO REVERSE ROTATION.
2. OPTIONAL THERMOSTATS ARE PROVIDED WHEN SPECIFIED.
3. ACTUAL NUMBER OF INTERNAL PARALLEL CIRCUITS MAY BE A MULTIPLE OF THOSE SHOWN ABOVE.
4. LEAD COLORS ARE OPTIONAL. LEADS MUST ALWAYS BE NUMBERED AS SHOWN.

REV. DESC: REVISE TO SHOW OPTIONAL COLORS

REV. LTR: E BY: JLP REVISED: 01/19/99 10:15 TDR: 0171435

FILE: AAA00005140 MDL: -

MTL: -

CD00005

**BALDOR ELECTRIC Co.**

3PH, DV, 9 LEADS



**BALDOR • RELIANCE**



**Integral Horsepower  
AC Induction Motors**

**Installation & Operating Manual**

Any trademarks used in this manual are the property of their respective owners.

# Table of Contents

---

<b>Section 1</b>	
<b>General Information</b> .....	1-1
Overview .....	1-1
Limited Warranty .....	1-1
Safety Notice .....	1-1
Receiving .....	1-2
Handling .....	1-2
Storage .....	1-3
Removal From Storage .....	1-4
<b>Section 2</b>	
<b>Installation &amp; Operation</b> .....	2-1
Overview .....	2-1
Location .....	2-1
Mounting .....	2-1
Alignment .....	2-1
Doweling & Bolting .....	2-2
Guarding .....	2-2
Power Connection .....	2-2
Conduit Box .....	2-2
AC Power .....	2-2
Rotation .....	2-3
First Time Start Up .....	2-4
Coupled Start Up .....	2-4
Jogging and Repeated Starts .....	2-4
<b>Section 3</b>	
<b>Maintenance &amp; Troubleshooting</b> .....	3-1
General Inspection .....	3-1
Relubrication & Bearings .....	3-1
Type of Grease .....	3-1
Relubrication Intervals .....	3-1
Relubrication Procedure .....	3-3
Troubleshooting Chart .....	3-4
Suggested bearing and winding RTD setting guidelines .....	3-5



# Section 1

## General Information

---

**Overview** This manual contains general procedures that apply to Baldor Motor products. Be sure to read and understand the Safety Notice statements in this manual. For your protection, do not install, operate or attempt to perform maintenance procedures until you understand the Warning and Caution statements. A Warning statement indicates a possible unsafe condition that can cause harm to personnel. A Caution statement indicates a condition that can cause damage to equipment.

**Important:** **This instruction manual is not intended to include a comprehensive listing of all details for all procedures required for installation, operation and maintenance. This manual describes general guidelines that apply to most of the motor products shipped by Baldor. If you have a question about a procedure or are uncertain about any detail, Do Not Proceed. Please contact your Baldor distributor for more information or clarification.**

Before you install, operate or perform maintenance, become familiar with the following:

- NEMA Publication MG-2, Safety Standard for Construction and guide for Selection, Installation and Use of Electric Motors and Generators.
- The National Electrical Code
- Local codes and Practices

### Limited Warranty

[www.baldor.com/support/warranty\\_standard.asp](http://www.baldor.com/support/warranty_standard.asp)

**Safety Notice:** This equipment contains high voltage! Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt installation, operation and maintenance of electrical equipment.

Be sure that you are completely familiar with NEMA publication MG-2, safety standards for construction and guide for selection, installation and use of electric motors and generators, the National Electrical Code and local codes and practices. Unsafe installation or use can cause conditions that lead to serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.

**WARNING:** **Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.**

**WARNING:** **Disconnect all electrical power from the motor windings and accessory devices before disassembly of the motor. Electrical shock can cause serious or fatal injury.**

**WARNING:** **Be sure the system is properly grounded before applying power. Do not apply AC power before you ensure that all grounding instructions have been followed. Electrical shock can cause serious or fatal injury. National Electrical Code and Local codes must be carefully followed.**

**WARNING:** **Avoid extended exposure to machinery with high noise levels. Be sure to wear ear protective devices to reduce harmful effects to your hearing.**

**WARNING:** **Surface temperatures of motor enclosures may reach temperatures which can cause discomfort or injury to personnel accidentally coming into contact with hot surfaces. When installing, protection should be provided by the user to protect against accidental contact with hot surfaces. Failure to observe this precaution could result in bodily injury.**

**WARNING:** **This equipment may be connected to other machinery that has rotating parts or parts that are driven by this equipment. Improper use can cause serious or fatal injury. Only qualified personnel should attempt to install operate or maintain this equipment.**

**WARNING:** **Do not by-pass or disable protective devices or safety guards. Safety features are designed to prevent damage to personnel or equipment. These devices can only provide protection if they remain operative.**

**WARNING:** **Avoid the use of automatic reset devices if the automatic restarting of equipment can be hazardous to personnel or equipment.**

**WARNING:** **Be sure the load is properly coupled to the motor shaft before applying power. The shaft key must be fully captive by the load device. Improper coupling can cause harm to personnel or equipment if the load decouples from the shaft during operation.**

**WARNING:** **Use proper care and procedures that are safe during handling, lifting, installing, operating and maintaining operations. Improper methods may cause muscle strain or other harm.**

**WARNING:** **Thermostat contacts automatically reset when the motor has slightly cooled down. To prevent injury or damage, the control circuit should be designed so that automatic starting of the motor is not possible when the thermostat resets.**

---

**Safety Notice** Continued

- WARNING:** UL Listed motors must only be serviced by UL Approved Authorized Baldor Service Centers if these motors are to be returned to a hazardous and/or explosive atmosphere.
- WARNING:** Pacemaker danger – Magnetic and electromagnetic fields in the vicinity of current carrying carrying conductors and permanent magnet motors can result result in a serious health hazard to persons with cardiac pacemakers, metal implants, and hearing aids. To avoid risk, stay way from the area surrounding a permanent magnet motor.
- WARNING:** Before performing any motor maintenance procedure, be sure that the equipment connected to the motor shaft cannot cause shaft rotation. If the load can cause shaft rotation, disconnect the load from the motor shaft before maintenance is performed. Unexpected mechanical rotation of the motor parts can cause injury or motor damage.
- WARNING:** Use only UL/CSA listed explosion proof motors in the presence of flammable or combustible vapors or dust.
- WARNING:** Motors that are to be used in flammable and/or explosive atmospheres must display the UL label on the nameplate along with CSA listed logo. Specific service conditions for these motors are defined in NFPA 70 (NEC) Article 500.
- WARNING:** Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.
- Caution:** To prevent premature equipment failure or damage, only qualified maintenance personnel should perform maintenance.
- Caution:** Do not over-lubricate motor as this may cause premature bearing failure.
- Caution:** Do not over tension belts. Excess tension may damage the motor or driven equipment.
- Caution:** Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load (gears, pumps, compressors, or other driven equipment) from the motor shaft before lifting the motor.
- Caution:** If eye bolts are used for lifting a motor, be sure they are securely tightened. The lifting direction should not exceed a 20° angle from the shank of the eye bolt or lifting lug. Excessive lifting angles can cause damage.
- Caution:** To prevent equipment damage, be sure that the electrical service is not capable of delivering more than the maximum motor rated amps listed on the rating plate.
- Caution:** If a HI POT test (High Potential Insulation test) must be performed, follow the precautions and procedure in NEMA MG1 and MG2 standards to avoid equipment damage.
- If you have any questions or are uncertain about any statement or procedure, or if you require additional information please contact your Baldor distributor or an Authorized Baldor Service Center.

**Receiving**

Each Baldor Electric Motor is thoroughly tested at the factory and carefully packaged for shipment. When you receive your motor, there are several things you should do immediately.

1. Observe the condition of the shipping container and report any damage immediately to the commercial carrier that delivered your motor.
2. Verify that the part number of the motor you received is the same as the part number listed on your purchase order.

**Handling**

The motor should be lifted using the lifting lugs or eye bolts provided.

- Caution:** Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load (gears, pumps, compressors, or other driven equipment) from the motor shaft before lifting the motor.
1. Use the lugs or eye bolts provided to lift the motor. Never attempt to lift the motor and additional equipment connected to the motor by this method. The lugs or eye bolts provided are designed to lift only the motor. Never lift the motor by the motor shaft or the hood of a WP11 motor.
  2. To avoid condensation inside the motor, do not unpack until the motor has reached room temperature. (Room temperature is the temperature of the room in which it will be installed). The packing provides insulation from temperature changes during transportation.
  3. When lifting a WP11 (Weather Proof Type 2) motor, do not lift the motor by inserting lifting lugs into holes on top of the cooling hood. These lugs are to be used for hood removal only. A spreader bar should be used to lift the motor by the cast lifting lugs located on the motor frame.



- 
4. If the motor must be mounted to a plate with the driven equipment such as pump, compressor etc., it may not be possible to lift the motor alone. For this case, the assembly should be lifted by a sling around the mounting base. The entire assembly can be lifted as an assembly for installation.

Do not lift the assembly using the motor lugs or eye bolts provided. Lugs or eye bolts are designed to lift motor only. If the load is unbalanced (as with couplings or additional attachments) additional slings or other means must be used to prevent tipping. In any event, the load must be secure before lifting. If the load is unbalanced (as with couplings or additional attachments) additional slings or other means must be used to prevent tipping. In any event, the load must be secure before lifting.

## **Storage**

Storage requirements for motors and generators that will not be placed in service for at least six months from date of shipment.

Improper motor storage will result in seriously reduced reliability and failure. An electric motor that does not experience regular usage while being exposed to normally humid atmospheric conditions is likely to develop rust in the bearings or rust particles from surrounding surfaces may contaminate the bearings. The electrical insulation may absorb an excessive amount of moisture leading to the motor winding failure.

A wooden crate “shell” should be constructed to secure the motor during storage. This is similar to an export box but the sides & top must be secured to the wooden base with lag bolts (not nailed as export boxes are) to allow opening and reclosing many times without damage to the “shell”.

Minimum resistance of motor winding insulation is 5 Meg ohms or the calculated minimum, whichever is greater. Minimum resistance is calculated as follows:  $R_m = kV + 1$

where: (Rm is minimum resistance to ground in Meg-Ohms and  
kV is rated nameplate voltage defined as Kilo-Volts.)

Example: For a 480VAC rated motor  $R_m = 1.48$  meg-ohms (use 5 MΩ).

For a 4160VAC rated motor  $R_m = 5.16$  meg-ohms.

## **Preparation for Storage**

1. Some motors have a shipping brace attached to the shaft to prevent damage during transportation. The shipping brace, if provided, must be removed and stored for future use. The brace must be reinstalled to hold the shaft firmly in place against the bearing before the motor is moved.
2. Store in a clean, dry, protected warehouse where control is maintained as follows:
  - a. Shock or vibration must not exceed 2 mils maximum at 60 hertz, to prevent the bearings from brinelling. If shock or vibration exceeds this limit vibration isolation pads must be used.
  - b. Storage temperatures of 10°C (50°F) to 49°C (120°F) must be maintained.
  - c. Relative humidity must not exceed 60%.
  - d. Motor space heaters (when present) are to be connected and energized whenever there is a possibility that the storage ambient conditions will reach the dew point. Space heaters are optional.  
Note: Remove motor from containers when heaters are energized, reprotect if necessary.
3. Measure and record the resistance of the winding insulation (dielectric withstand) every 30 days of storage.
  - a. If motor insulation resistance decreases below the minimum resistance, contact your Baldor District office.
  - b. Place new desiccant inside the vapor bag and re-seal by taping it closed.
  - c. If a zipper-closing type bag is used instead of the heat-sealed type bag, zip the bag closed instead of taping it. Be sure to place new desiccant inside bag after each monthly inspection.
  - d. Place the shell over the motor and secure with lag bolts.
4. Where motors are mounted to machinery, the mounting must be such that the drains and breathers are fully operable and are at the lowest point of the motor. Vertical motors must be stored in the vertical position. Storage environment must be maintained as stated in step 2.

- 
5. Motors with anti-friction bearings are to be greased at the time of going into extended storage with periodic service as follows:
    - a. Motors marked "Do Not Lubricate" on the nameplate do not need to be greased before or during storage.
    - b. Ball and roller bearing (anti-friction) motor shafts are to be rotated manually every 3 months and greased every 6 months in accordance with the Maintenance section of this manual.
    - c. Sleeve bearing (oil lube) motors are drained of oil prior to shipment. The oil reservoirs must be refilled to the indicated level with the specified lubricant, (see Maintenance). The shaft should be rotated monthly by hand at least 10 to 15 revolutions to distribute oil to bearing surfaces.
    - d. "Provisions for oil mist lubrication" – These motors are packed with grease. Storage procedures are the same as paragraph 5b.
    - e. "Oil Mist Lubricated" – These bearings are protected for temporary storage by a corrosion inhibitor. If stored for greater than 3 months or outdoor storage is anticipated, connected to the oil mist system while in storage. If this is not possible, add the amount of grease indicated under "Standard Condition" in Section 3, then rotate the shaft 15 times by hand.
  6. All breather drains are to be fully operable while in storage (drain plugs removed). The motors must be stored so that the drain is at the lowest point. All breathers and automatic "T" drains must be operable to allow breathing and draining at points other than through the bearings around the shaft. Vertical motors should be stored in a safe stable vertical position.
  7. Coat all external machined surfaces with a rust preventing material. An acceptable product for this purpose is Exxon Rust Ban # 392.

#### **Non-Regreaseable Motors**

Non-regreaseable motors with "Do Not Lubricate" on the nameplate should have the motor shaft rotated 15 times to redistribute the grease within the bearing every 3 months or more often.

#### **All Other Motor Types**

Before storage, the following procedure must be performed.

1. Remove the grease drain plug, if supplied, (opposite the grease fitting) on the bottom of each bracket prior to lubricating the motor.
2. The motor with regreaseable bearing must be greased as instructed in Section 3 of this manual.
3. Replace the grease drain plug after greasing.
4. The motor shaft must be rotated a minimum of 15 times after greasing.
5. Motor Shafts are to be rotated at least 15 revolutions manually every 3 months and additional grease added every nine months (see Section 3) to each bearing.
6. Bearings are to be greased at the time of removal from storage.

#### **Removal From Storage**

1. Remove all packing material.
2. Measure and record the electrical resistance of the winding insulation resistance meter at the time of removal from storage. The insulation resistance must not be less than 50% from the initial reading recorded when the motor was placed into storage. A decrease in resistance indicates moisture in the windings and necessitates electrical or mechanical drying before the motor can be placed into service. If resistance is low, contact your Baldor District office.
3. Regrease the bearings as instructed in Section 3 of this manual.
4. Reinstall the original shipping brace if motor is to be moved. This will hold the shaft firmly against the bearing and prevent damage during movement.

## Section 2

# Installation & Operation

---

### Overview

Installation should conform to the National Electrical Code as well as local codes and practices. When other devices are coupled to the motor shaft, be sure to install protective devices to prevent future accidents. Some protective devices include, coupling, belt guard, chain guard, shaft covers etc. These protect against accidental contact with moving parts. Machinery that is accessible to personnel should provide further protection in the form of guard rails, screening, warning signs etc.

### Location

It is important that motors be installed in locations that are compatible with motor enclosure and ambient conditions. Improper selection of the motor enclosure and ambient conditions can lead to reduced operating life of the motor.

Proper ventilation for the motor must be provided. Obstructed airflow can lead to reduction of motor life.

1. **Open Drip–Proof/WPI** motors are intended for use indoors where atmosphere is relatively clean, dry, well ventilated and non–corrosive.
2. **Totally Enclosed and WPII** motors may be installed where dirt, moisture or dust are present and in outdoor locations.

Severe Duty, IEEE 841 and Washdown Duty enclosed motors are designed for installations with high corrosion or excessive moisture conditions. These motors should not be placed into an environment where there is the presence of flammable or combustible vapors, dust or any combustible material, unless specifically designed for this type of service.

**Hazardous Locations** are those where there is a risk of ignition or explosion due to the presence of combustible gases, vapors, dust, fibers, or flyings. Facilities requiring special equipment for hazardous locations are typically classified in accordance with local requirements. In the US market, guidance is provided by the National Electric Code.

### **Caution:**

**Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load (gears, pumps, compressors, or other driven equipment) from the motor shaft before lifting the motor.**

### Mounting

The motor must be securely installed to a rigid foundation or mounting surface to minimize vibration and maintain alignment between the motor and shaft load. Failure to provide a proper mounting surface may cause vibration, misalignment and bearing damage.

Foundation caps and sole plates are designed to act as spacers for the equipment they support. If these devices are used, be sure that they are evenly supported by the foundation or mounting surface.

After installation is complete and accurate alignment of the motor and load is accomplished, the base should be grouted to the foundation to maintain this alignment.

The standard motor base is designed for horizontal or vertical mounting. Adjustable or sliding rails are designed for horizontal mounting only. Consult your Baldor distributor or authorized Baldor Service Center for further information.

### Alignment

Accurate alignment of the motor with the driven equipment is extremely important. The pulley, sprocket, or gear used in the drive should be located on the shaft as close to the shaft shoulder as possible.

It is recommended to heat the pulley, sprocket, or gear before installing on the motor shaft.

Forcibly driving a unit on the motor shaft will damage the bearings.

#### 1. **Direct Coupling**

For direct drive, use flexible couplings if possible. Consult the drive or equipment manufacturer for more information. Mechanical vibration and roughness during operation may indicate poor alignment. Use dial indicators to check alignment. The space between coupling hubs should be maintained as recommended by the coupling manufacturer.

#### 2. **End-Play Adjustment**

The axial position of the motor frame with respect to its load is also extremely important. The motor bearings are not designed for excessive external axial thrust loads. Improper adjustment will cause failure.

#### 3. **Pulley Ratio**

The pulley ratio should not exceed 8:1.

### **Caution:**

**Do not over tension belts. Excess tension may damage the motor or driven equipment.**

#### 4. **Belt Drive**

Align sheaves carefully to minimize belt wear and axial bearing loads (see End-Play Adjustment). Belt tension should be sufficient to prevent belt slippage at rated speed and load. However, belt slippage may occur during starting.

5. Sleeve bearing motors are only suitable for coupled loads.

---

**Doweling & Bolting** After proper alignment is verified, dowel pins should be inserted through the motor feet into the foundation. This will maintain the correct motor position should motor removal be required. (Baldor motors are designed for doweling.)

1. Drill dowel holes in diagonally opposite motor feet in the locations provided.
2. Drill corresponding holes in the foundation.
3. Ream all holes.
4. Install proper fitting dowels.
5. Mounting bolts must be carefully tightened to prevent changes in alignment. Use a flat washer and lock washer under each nut or bolt head to hold the motor feet secure. Flanged nuts or bolts may be used as an alternative to washers.

**WARNING:** Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.

**Guarding** Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions. This is particularly important where the parts have surface irregularities such as keys, key ways or set screws. Some satisfactory methods of guarding are:

1. Covering the machine and associated rotating parts with structural or decorative parts of the driven equipment.
2. Providing covers for the rotating parts. Covers should be sufficiently rigid to maintain adequate guarding during normal service.

**Power Connection** Motor and control wiring, overload protection, disconnects, accessories and grounding should conform to the National Electrical Code and local codes and practices. Flying leads must be insulated with two full wraps of electrical grade insulating tape or heat shrink tubing.

**Conduit Box** For ease of making connections, an oversize conduit box is provided.

The box can be rotated 360° in 90° increments.

Auxiliary conduit boxes are provided on some motors for accessories such as space heaters, RTD's etc.

**AC Power** Connect the motor leads as shown on the connection diagram located on the name plate or inside the cover on the conduit box. Be sure the following guidelines are met:

1. AC power is within  $\pm 10\%$  of rated voltage with rated frequency. (See motor name plate for ratings).  
**OR**
2. AC power is within  $\pm 5\%$  of rated frequency with rated voltage.  
**OR**
3. A combined variation in voltage and frequency of  $\pm 10\%$  (sum of absolute values) of rated values, provided the frequency variation does not exceed  $\pm 5\%$  of rated frequency.

Performance within these voltage and frequency variations are shown in Figure 2-2.

**Figure 2-1 Accessory Connections**

HEATERS



One heater is installed in each end of motor. Leads for each heater are labeled H1 & H2. (Like numbers should be tied together).

THERMISTORS



Three thermistors are installed in windings and tied in series. Leads are labeled T1 & T2.

WINDING RTDS




Winding RTDs are installed in windings (2) per phase. Each set of leads is labeled W1, W2, W3, W4, W5, & W6.

BEARING RTD



- \* One bearing RTD is installed in Drive endplate (PUPEP), leads are labeled RTDDE.
- \* One bearing RTD is installed in Opposite Drive endplate (FREPEP), leads are labeled RTDODE.
- \* Note RTD may have 2-Red/1-White leads; or 2-White/1-Red Lead.

**Figure 2-2 Typical Motor Performance VS Voltage Variations**



**Rotation** All three phase motors are reversible. To reverse the direction of rotation, disconnect and lock out power and interchange any two of the three line leads for three phase motors. For single phase motors, check the connection diagram to determine if the motor is reversible and follow the connection instructions for lead numbers to be interchanged. Not all single phase motors are reversible.

Adjustable Frequency Power Inverters used to supply adjustable frequency power to induction motors produce wave forms with lower order harmonics with voltage spikes superimposed. Turn-to-turn, phase-to-phase, and ground insulation of stator windings are subject to the resulting dielectric stresses. Suitable precautions should be taken in the design of these drive systems to minimize the magnitude of these voltage spikes. Consult the drive instructions for maximum acceptable motor lead lengths, and proper grounding.

- 
- First Time Start Up** Be sure that all power to motor and accessories is off. Be sure the motor shaft is disconnected from the load and will not cause mechanical rotation of the motor shaft.
1. Make sure that the mechanical installation is secure. All bolts and nuts are tightened etc.
  2. If motor has been in storage or idle for some time, check winding insulation integrity.
  3. Inspect all electrical connections for proper termination, clearance, mechanical strength and electrical continuity.
  4. Be sure all shipping materials and braces (if used) are removed from motor shaft.
  5. Manually rotate the motor shaft to ensure that it rotates freely.
  6. Replace all panels and covers that were removed during installation.
  7. Momentarily apply power and check the direction of rotation of the motor shaft.
  8. If motor rotation is wrong, be sure power is off and change the motor lead connections. Verify rotation direction before you continue.
  9. Start the motor and ensure operation is smooth without excessive vibration or noise. If so, run the motor for 1 hour with no load connected.
  10. After 1 hour of operation, disconnect power and connect the load to the motor shaft. Verify all coupling guards and protective devices are installed. Ensure motor is properly ventilated.

**Coupled Start Up** This procedure assumes a coupled start up. Also, that the first time start up procedure was successful.

1. Check the coupling and ensure that all guards and protective devices are installed.
2. Check that the coupling is properly aligned and not binding.
3. The first coupled start up should be with no load. Apply power and verify that the load is not transmitting excessive vibration back to the motor through the coupling or the foundation. Vibration should be at an acceptable level.
4. Run for approximately 1 hour with the driven equipment in an unloaded condition.

The equipment can now be loaded and operated within specified limits. Do not exceed the name plate ratings for amperes for steady continuous loads.

**Jogging and Repeated Starts** Repeated starts and/or jogs of induction motors generally reduce the life of the motor winding insulation. A much greater amount of heat is produced by each acceleration or jog than by the same motor under full load. If it is necessary to repeatedly start or jog the motor, it is advisable to check the application with your local Baldor distributor or Baldor Service Center.

**Heating** - Duty rating and maximum ambient temperature are stated on the motor name plate. Do not exceed these values. If there is any question regarding safe operation, contact your local Baldor District Office or Baldor Service Center.

## Section 3 Maintenance & Troubleshooting

**WARNING:** UL Listed motors must only be serviced by UL Approved Authorized Baldor Service Centers if these motors are to be returned to a hazardous and/or explosive atmosphere.

**General Inspection** Inspect the motor at regular intervals, approximately every 500 hours of operation or every 3 months, whichever occurs first. Keep the motor clean and the ventilation openings clear. The following steps should be performed at each inspection:

**WARNING:** Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.

1. Check that the motor is clean. Check that the interior and exterior of the motor is free of dirt, oil, grease, water, etc. Oily vapor, paper pulp, textile lint, etc. can accumulate and block motor ventilation. If the motor is not properly ventilated, overheating can occur and cause early motor failure.
2. Use a “Megger” periodically to ensure that the integrity of the winding insulation has been maintained. Record the Megger readings. Immediately investigate any significant drop in insulation resistance.
3. Check all electrical connectors to be sure that they are tight.

**Relubrication & Bearings** Bearing grease will lose its lubricating ability over time, not suddenly. The lubricating ability of a grease (over time) depends primarily on the type of grease, the size of the bearing, the speed at which the bearing operates and the severity of the operating conditions. Good results can be obtained if the following recommendations are used in your maintenance program.

**Type of Grease** A high grade ball or roller bearing grease should be used. Recommended grease for standard service conditions is **Polyrex EM (Exxon Mobil)**. Do not mix greases unless compatibility has been checked and verified.

Equivalent and compatible greases include:

Texaco Polystar, Rykon Premium #2, Pennzoil Pen 2 Lube and Chevron SRI.

**Relubrication Intervals** Recommended relubrication intervals are shown in Table 3-1. It is important to realize that the recommended intervals of Table 3-1 are based on average use.

Refer to additional information contained in Tables 3-2, 3-3 and 3-4.

**Table 3-1 Relubrication Intervals \***

NEMA / (IEC) Frame Size	Rated Speed - RPM					
	10000	6000	3600	1800	1200	900
Up to 210 incl. (132)	**	2700 Hrs.	5500 Hrs.	12000 Hrs.	18000 Hrs.	22000 Hrs.
Over 210 to 280 incl. (180)		**	3600 Hrs.	9500 Hrs.	15000 Hrs.	18000 Hrs.
Over 280 to 360 incl. (225)		**	* 2200 Hrs.	7400 Hrs.	12000 Hrs.	15000 Hrs.
Over 360 to 5800 incl. (300)		**	*2200 Hrs.	3500 Hrs.	7400 Hrs.	10500 Hrs.

\* Relubrication intervals are for ball bearings.

For vertically mounted motors and roller bearings, divide the relubrication interval by 2.

\*\* For motors operating at speeds greater than 3600 RPM, contact Baldor for relubrication recommendations.

**Table 3-2 Service Conditions**

Severity of Service	Hours per day of Operation	Ambient Temperature Maximum	Atmospheric Contamination
Standard	8	40° C	Clean, Little Corrosion
Severe	16 Plus	50° C	Moderate dirt, Corrosion
Extreme	16 Plus	>50° C* or Class H Insulation	Severe dirt, Abrasive dust, Corrosion, Heavy Shock or Vibration
Low Temperature		<-29° C **	

\* Special high temperature grease is recommended (Dow Corning DC44). Note that Dow Corning DC44 grease does not mix with other grease types. Thoroughly clean bearing & cavity before adding grease.

\*\* Special low temperature grease is recommended (Aeroshell 7).

**Table 3-3 Relubrication Interval Multiplier**

Severity of Service	Multiplier
Standard	1.0
Severe	0.5
Extreme	0.1
Low Temperature	1.0

Some motor designs use different bearings on each motor end. This is normally indicated on the motor nameplate. In this case, the larger bearing is installed on the motor Drive endplate. For best relubrication results, only use the appropriate amount of grease for each bearing size (not the same for both).

**Table 3-4 Bearings Sizes and Types**

Frame Size NEMA (IEC)	Bearing Description (These are the "Large" bearings (Shaft End) in each frame size)			
	Bearing	Weight of Grease to add * oz (Grams)	Volume of grease to be added	
			in <sup>3</sup>	teaspoon
56 to 140 (90)	6203	0.08 (2.4)	0.15	0.5
140 (90)	6205	0.15 (3.9)	0.2	0.8
180 (100-112)	6206	0.19 (5.0)	0.3	1.0
210 (132)	6307	0.30 (8.4)	0.6	2.0
250 (160)	6309	0.47 (12.5)	0.7	2.5
280 (180)	6311	0.61 (17)	1.2	3.9
320 (200)	6312	0.76 (20.1)	1.2	4.0
360 (225)	6313	0.81 (23)	1.5	5.2
400 (250)	6316	1.25 (33)	2.0	6.6
440 (280)	6319	2.12 (60)	4.1	13.4
5000 to 5800 (315-450)	6328	4.70 (130)	9.2	30.0
5000 to 5800 (315-450)	NU328	4.70 (130)	9.2	30.0
360 to 449 (225-280)	NU319	2.12 (60)	4.1	13.4
<b>AC Induction Servo</b>				
76 Frame 180 (112)	6207	0.22 (6.1)	0.44	1.4
77 Frame 210 (132)	6210	0.32 (9.0)	0.64	2.1
80 Frame 250(160)	6213	0.49 (14.0)	0.99	3.3

\* Weight in grams = .005 DB of grease to be added

Note: Not all bearing sizes are listed. For intermediate bearing sizes, use the grease volume for the next larger size bearing.



---

**Caution:** To avoid damage to motor bearings, grease must be kept free of dirt. For an extremely dirty environment, contact your Baldor distributor or an authorized Baldor Service Center for additional information.

**Relubrication Procedure** Be sure that the grease you are adding to the motor is compatible with the grease already in the motor. Consult your Baldor distributor or an authorized service center if a grease other than the recommended type is to be used.

**Caution:** Do not over-lubricate motor as this may cause premature bearing failure.

**With Grease Outlet Plug**

1. With the motor stopped, clean all grease fittings with a clean cloth.
2. Remove grease outlet plug.

**Caution:** Over-lubricating can cause excessive bearing temperatures, premature lubrication breakdown and bearing failure.

3. Add the recommended amount of grease.
4. Operate the motor for 15 minutes with grease plug removed.  
This allows excess grease to purge.
5. Re-install grease outlet plug.

**Without Grease Provisions**

**Note:** Only a Baldor authorized and UL or CSA certified service center can disassemble a UL/CSA listed explosion proof motor to maintain it's UL/CSA listing.

1. Disassemble the motor.
2. Add recommended amount of grease to bearing and bearing cavity. (Bearing should be about 1/3 full of grease and outboard bearing cavity should be about 1/2 full of grease.)
3. Assemble the motor.

**Sample Relubrication Determination**

Assume - NEMA 286T (IEC 180), 1750 RPM motor driving an exhaust fan in an ambient temperature of 43° C and the atmosphere is moderately corrosive.

1. Table 3-1 list 9500 hours for standard conditions.
2. Table 3-2 classifies severity of service as "Severe".
3. Table 3-4 shows that 1.2 in<sup>3</sup> or 3.9 teaspoon of grease is to be added.

Note: Smaller bearings in size category may require reduced amounts of grease.

**Table 3-5 Troubleshooting Chart**

Symptom	Possible Causes	Possible Solutions
Motor will not start	Usually caused by line trouble, such as, single phasing at the starter.	Check source of power. Check overloads, fuses, controls, etc.
Excessive humming	High Voltage.	Check input line connections.
	Eccentric air gap.	Have motor serviced at local Baldor service center.
Motor Over Heating	Overload. Compare actual amps (measured) with nameplate rating.	Locate and remove source of excessive friction in motor or load. Reduce load or replace with motor of greater capacity.
	Single Phasing.	Check current at all phases (should be approximately equal) to isolate and correct the problem.
	Improper ventilation.	Check external cooling fan to be sure air is moving properly across cooling fins. Excessive dirt build-up on motor. Clean motor.
	Unbalanced voltage.	Check voltage at all phases (should be approximately equal) to isolate and correct the problem.
	Rotor rubbing on stator.	Check air gap clearance and bearings. Tighten "Thru Bolts".
	Over voltage or under voltage.	Check input voltage at each phase to motor.
	Open stator winding.	Check stator resistance at all three phases for balance.
	Grounded winding.	Perform dielectric test and repair as required.
	Improper connections.	Inspect all electrical connections for proper termination, clearance, mechanical strength and electrical continuity. Refer to motor lead connection diagram.
	Bearing Over Heating	Misalignment.
Excessive belt tension.		Reduce belt tension to proper point for load.
Excessive end thrust.		Reduce the end thrust from driven machine.
Excessive grease in bearing.		Remove grease until cavity is approximately $\frac{3}{4}$ filled.
Insufficient grease in bearing.		Add grease until cavity is approximately $\frac{3}{4}$ filled.
Dirt in bearing.		Clean bearing cavity and bearing. Repack with correct grease until cavity is approximately $\frac{3}{4}$ filled.
Vibration	Misalignment.	Check and align motor and driven equipment.
	Rubbing between rotating parts and stationary parts.	Isolate and eliminate cause of rubbing.
	Rotor out of balance.	Have rotor balance checked and repaired at your Baldor Service Center.
	Resonance.	Tune system or contact your Baldor Service Center for assistance.
Noise	Foreign material in air gap or ventilation openings.	Remove rotor and foreign material. Reinstall rotor. Check insulation integrity. Clean ventilation openings.
Growling or whining	Bad bearing.	Replace bearing. Clean all grease from cavity and new bearing. Repack with correct grease until cavity is approximately $\frac{3}{4}$ filled.

**Suggested bearing and winding RTD setting guidelines**

Most large frame AC Baldor motors with a 1.15 service factor are designed to operate below a Class B (80°C) temperature rise at rated load and are built with a Class H winding insulation system. Based on this low temperature rise, RTD (Resistance Temperature Detectors) settings for Class B rise should be used as a starting point. Some motors with 1.0 service factor have Class F temperature rise.

The following tables show the suggested alarm and trip settings for RTDs. Proper bearing and winding RTD alarm and trip settings should be selected based on these tables unless otherwise specified for specific applications.

If the driven load is found to operate well below the initial temperature settings under normal conditions, the alarm and trip settings may be reduced so that an abnormal machine load will be identified.

The temperature limits are based on the installation of the winding RTDs imbedded in the winding as specified by NEMA. Bearing RTDs should be installed so they are in contact with the outer race on ball or roller bearings or in direct contact with the sleeve bearing shell.

**Winding RTDs – Temperature Limit In °C (40°C Maximum Ambient)**

Motor Load	Class B Temp Rise ≤ 80°C (Typical Design)		Class F Temp Rise ≤ 105°C		Class H Temp Rise ≤ 125°C	
	Alarm	Trip	Alarm	Trip	Alarm	Trip
≤ Rated Load	130	140	155	165	175	185
Rated Load to 1.15 S.F.	140	150	160	165	180	185

Note: • Winding RTDs are factory production installed, not from Mod-Express.  
 • When Class H temperatures are used, consider bearing temperatures and relubrication requirements.

**Bearing RTDs – Temperature Limit In °C (40°C Maximum Ambient)**

Bearing Type Oil or Grease	Anti-Friction		Sleeve	
	Alarm	Trip	Alarm	Trip
Standard*	95	100	85	95
High Temperature**	110	115	105	110

Note: \* Bearing temperature limits are for standard design motors operating at Class B temperature rise.  
 \*\* High temperature lubricants include some special synthetic oils and greases.

Greases that may be substituted that are compatible with Polyrex EM (but considered as “standard” lubricants) include the following:

- Texaco Polystar
- Mobilith SHC-100
- Darmex 707
- Rykon Premium #2
- Pennzoil Pennzlube EM-2
- Darmex 711
- Chevron SRI #2
- Chevron Black Pearl
- Petro-Canada Peerless LLG

See the motor nameplate for replacement grease or oil recommendation.  
 Contact Baldor application engineering for special lubricants or further clarifications.



## Baldor District Offices

### UNITED STATES

#### ARIZONA

PHOENIX  
4211 S 43RD PLACE  
PHOENIX, AZ 85040  
PHONE: 602-470-0407  
FAX: 602-470-0464

#### ARKANSAS

CLARKSVILLE  
1001 COLLEGE AVE.  
CLARKSVILLE, AR 72830  
PHONE: 479-754-9108  
FAX: 479-754-9205

#### CALIFORNIA

LOS ANGELES  
6480 FLOTILLA  
COMMERCE, CA 90040  
PHONE: 323-724-6771  
FAX: 323-721-5859  
HAYWARD  
21056 FORBES STREET  
HAYWARD, CA 94545  
PHONE: 510-785-9900  
FAX: 510-785-9910

#### COLORADO

DENVER  
3855 FOREST STREET  
DENVER, CO 80207  
PHONE: 303-623-0127  
FAX: 303-595-3772  
9980 PARK MEADOWS DRIVE  
SUITE 214  
LONE TREE, CO 80124-6739  
PHONE: 303-339-9629  
FAX: 303-339-9633

#### CONNECTICUT

WALLINGFORD  
65 SOUTH TURNPIKE ROAD  
WALLINGFORD, CT 06492  
PHONE: 203-269-1354  
FAX: 203-269-5485

#### FLORIDA

TAMPA/PUERTO RICO/  
VIRGIN ISLANDS  
3906 EAST 11TH AVENUE  
TAMPA, FL 33605  
PHONE: 813-248-5078  
FAX: 813-247-2984

#### GEORGIA

ATLANTA  
62 TECHNOLOGY DR.  
ALPHARETTA, GA 30005  
PHONE: 770-772-7000  
FAX: 770-772-7200  
5490 MCGINNIS FERRY PLACE  
SUITE 133  
ALPHARETTA, GA 30005  
PHONE: 770-752-4254  
FAX: 770-752-4257

#### ILLINOIS

CHICAGO  
4 SAMMONS COURT  
BOLINGBROOK, IL 60440  
PHONE: 630-296-1400  
FAX: 630-226-9420

#### INDIANA

COLUMBUS  
3300 TENTH ST  
COLUMBUS, IN 47201  
PHONE: 812-378-2556  
FAX: 812-378-2555  
INDIANAPOLIS  
5525 W. MINNESOTA STREET  
INDIANAPOLIS, IN 46241  
PHONE: 317-246-5100  
FAX: 317-246-5110

#### IOWA

DES MOINES  
1800 DIXON STREET, SUITE C  
DES MOINES, IA 50316  
PHONE: 515-263-6929  
FAX: 515-263-6515

#### KANSAS

5030 BOB BILLINGS PKWY STE B  
LAWRENCE, KS 66049  
PHONE: 785-749-4339  
FAX: 785-749-4217

#### MARYLAND

BALTIMORE  
6660 SANTA BARBARA RD.  
SUITE 22-24  
ELK RIDGE, MD 21075  
PHONE: 410-579-2135  
FAX: 410-579-2677

#### MASSACHUSETTS

BOSTON  
6 PULLMAN STREET  
WORCESTER, MA 01606  
PHONE: 508-854-0708  
FAX: 508-854-0291

#### MICHIGAN

DETROIT  
33782 STERLING PONDS BLVD.  
STERLING HEIGHTS, MI 48312  
PHONE: 586-978-9800  
FAX: 586-978-9969  
GRAND RAPIDS  
668 THREE MILE ROAD NW  
GRAND RAPIDS, MI 49504  
PHONE: 616-785-1784  
FAX: 616-785-1788

#### MINNESOTA

MINNEAPOLIS  
21080 134TH AVE. NORTH  
ROGERS, MN 55374  
PHONE: 763-428-3633  
FAX: 763-428-4551

#### MISSOURI

ST LOUIS  
422 INDUSTRIAL DRIVE  
MARYLAND HEIGHTS, MO 63043  
PHONE: 314-298-1800  
FAX: 314-298-7660  
KANSAS CITY  
1501 BEDFORD AVENUE  
NORTH KANSAS CITY, MO 64116  
PHONE: 816-587-0272  
FAX: 816-587-3735

#### NEW YORK

AUBURN  
ONE ELLIS DRIVE  
AUBURN, NY 13021  
PHONE: 315-255-3403  
FAX: 315-253-9923

#### NORTH CAROLINA

GREENSBORO  
1220 ROTHERWOOD ROAD  
GREENSBORO, NC 27406  
PHONE: 336-272-6104  
FAX: 336-273-6628

#### OHIO

CINCINNATI  
2929 CRESCENTVILLE ROAD  
WEST CHESTER, OH 45069  
PHONE: 513-771-2600  
FAX: 513-772-2219

CLEVELAND  
8929 FREEWAY DRIVE  
MACEDONIA, OH 44056  
PHONE: 330-468-4777  
FAX: 330-468-4778

29525 CHAGRIN BLVD SUITE 208  
CLEVELAND, OH 44122  
PHONE: 216-360-8296  
FAX: 216-360-4172

#### OKLAHOMA

TULSA  
2 EAST DAWES  
BIXBY, OK 74008  
PHONE: 918-366-9320  
FAX: 918-366-9338

#### OREGON

PORTLAND  
20393 SW AVERY COURT  
TUALATIN, OR 97062  
PHONE: 503-691-9010  
FAX: 503-691-9012

#### PENNSYLVANIA

KING OF PRUSSIA  
1060 FIRST AVE STE 400  
KING OF PRUSSIA, PA 19406  
PHONE: 610-768-8018  
FAX: 215-672-5759

PHILADELPHIA  
1035 THOMAS BUSCH  
MEMORIAL HIGHWAY  
PENNSAUKEN, NJ 08110  
PHONE: 856-661-1442  
FAX: 856-663-6363

PITTSBURGH  
159 PROMINENCE DRIVE  
NEW KENSINGTON, PA 15068  
PHONE: 724-889-0092  
FAX: 724-889-0094

#### TENNESSEE

MEMPHIS  
4000 WINCHESTER ROAD  
MEMPHIS, TN 38118  
PHONE: 901-365-2020  
FAX: 901-365-3914

#### TEXAS

ADDISON  
3939 BELT LINE ROAD #250  
ADDISON, TX 75001  
PHONE: 972-499-7746, 499-7747  
FAX: 972-242-1505

DALLAS  
3040 QUEBEC  
DALLAS, TX 75247  
PHONE: 214-634-7271  
FAX: 214-634-8874

HOUSTON  
4647 PINE TIMBERS  
SUITE # 135  
HOUSTON, TX 77041  
PHONE: 713-895-7062  
FAX: 713-690-4540

#### UTAH

SALT LAKE CITY  
2230 SOUTH MAIN STREET  
SALT LAKE CITY, UT 84115  
PHONE: 801-832-0127  
FAX: 801-832-8911

#### VIRGINIA

RICHMOND  
6767 FOREST HILL AVE STE 305  
RICHMOND, VA 23225  
PHONE: 804-545-6848  
FAX: 804-545-6840

#### WASHINGTON

KIRKLAND, WA  
550 KIRKLAND WAY STE 205  
KIRKLAND, WA 98033  
PHONE: 425-952-5000  
FAX: 775-255-8019

#### WISCONSIN

MILWAUKEE  
2725 SOUTH 163RD STREET  
NEW BERLIN, WI 53151  
PHONE: 262-784-5940  
FAX: 262-784-1215  
WAUKESHA  
N14 W23777 STONE RIDGE DRIVE  
SUITE 170  
WAUKESHA, WI 53188  
PHONE: 262-347-2000  
FAX: 262-437-0258

#### INTERNATIONAL SALES

FORT SMITH, AR  
P.O. BOX 2400  
FORT SMITH, AR 72902  
PHONE: 479-646-4711  
FAX: 479-648-5895

#### CANADA

EDMONTON, ALBERTA  
4053-92 STREET  
EDMONTON, ALBERTA T6E 6R8  
PHONE: 780-434-4900  
FAX: 780-438-2600

11428-168 STREET  
EDMONTON, ALBERTA T5M 3T9  
PHONE: 780-822-7865  
FAX: 780-822-7878

MISSISSAUGA, ONTARIO  
244 BRITANNIA ROAD EAST  
MISSISSAUGA, ONTARIO L4Z 1S6  
PHONE: 905-890-5110  
FAX: 905-890-5540

OAKVILLE, ONTARIO  
2750 COVENTRY ROAD  
OAKVILLE, ONTARIO L6H 6R1  
PHONE: 905-829-3301  
FAX: 905-829-3302

DORVAL, QUEBEC  
95 RUE LINDSAY  
DORVAL QUEBEC H9P 2S6  
PHONE: 514-422-8818  
FAX: 514-422-8982

MONTREAL, QUEBEC  
1844 WILLIAM STREET  
MONTREAL, QUEBEC H3J 1R5  
PHONE: 514-933-2711  
FAX: 514-933-8639

VANCOUVER,  
BRITISH COLUMBIA  
1538 KEBET WAY  
PORT COQUITLAM,  
BRITISH COLUMBIA V3C 5M5  
PHONE 604-421-2822  
FAX: 604-421-3113

WINNIPEG, MANITOBA  
54 PRINCESS STREET  
WINNIPEG, MANITOBA R3B 1K2  
PHONE: 204-942-5205  
FAX: 204-956-4251

#### AUSTRALIA

UNIT 3, 6 STANTON ROAD  
SEVEN HILLS, NSW 2147, AUSTRALIA  
PHONE: (61) (2) 9674 5455  
FAX: (61) (2) 9674 2495

UNIT 8, 5 KELLETTS ROAD  
ROWVILLE, VICTORIA, 3178  
AUSTRALIA

PHONE: (61) (3) 9753 4355  
FAX: (61) (3) 9753 4366

#### EL SALVADOR

RESIDENCIAL PINARES DE SUIZA  
POL. 15 #44,  
NVA. SAN SALVADOR, EL SALVADOR  
PHONE: +503 2288-1519  
FAX: +503 2288-1518

#### CHILE

LUIS THAYER OJEDA 166,  
OF 402 - PROVIDENCIA  
SANTIAGO, CHILE  
PHONE: 56-2-290-0762  
FAX: 56-2-290-0762

#### CHINA

5299 BEI SONG ROAD  
SONGJIANG  
201611 SHANGHAI, CHINA  
PHONE: +86 21 5760 5335  
FAX: +86 21 5760 5336

UNIT 905, 9TH FLOOR,  
TOWER B WANDA PLAZA  
NO. 93 JIANGUO ROAD,  
CHAOYANG DISTRICT  
BEIJING, 100022, CHINA  
PHONE +86 (010) 58205516  
FAX +86 (010) 58204231

#### GERMANY

DIESELSTRASSE 22  
D-85551 KIRCHHEIM  
MUNICH, GERMANY  
PHONE: +49 89 90 5080  
FAX: +49 89 90 50 8492  
HERMANN-HEINRICH-GOSSEN-  
STRASSE 3  
D-50858 KÖLN, GERMANY  
PHONE: 49 2234 37941 0  
FAX: 49 2234 37941 64

#### INDIA

14, COMMERCE AVENUE  
MAHAGANESH COLONY  
PAUD ROAD  
PUNE - 411038  
MAHARASHTRA, INDIA  
PHONE: 91 20 25452717, 25452718  
FAX: 91 20 25452719

#### ITALY

BALDOR ASR AG  
SUCCURSALE DI MENDRISIO  
VIA BORROMINI, 20A  
CH-6850 MENDRISIO  
SWITZERLAND  
PHONE: 0041 91 640 99 50  
FAX: 0041 91 630 26 33

#### JAPAN

DIA BLDG 802,  
2-21-1 TSURUYA-CHO,  
KANAGAWA-KU  
YOKOHAMA, 221-0835, JAPAN  
PHONE: 81-45-412-4506  
FAX: 81-45-412-4507

#### KOREA

RM 1715, SUSEO TOWER, 725,  
SUSEO-DONG, GANGNAM-GU,  
SEOUL 135-757 KOREA  
TEL : (82) 2 2226 9369  
FAX : (82) 2 2226 9368

#### MEXICO

LEON, GUANAJUATO  
KM. 2.0 BLVD. AEROPUERTO  
LEON 37545, GUANAJUATO, MEXICO  
PHONE: 52 477 761 2030  
FAX: 52 477 761 2010

#### MIDDLE EAST & NORTH AFRICA

VSE INTERNATIONAL CORP.  
P. O. BOX 5618  
BUFFALO GROVE, IL 60089-5618  
PHONE: 847 590 5547  
FAX: 847 590 5587

#### SINGAPORE

18, KAKI BUKIT ROAD 3  
#03-09 ENTREPRENEUR  
BUSINESS CENTRE  
SINGAPORE 415978  
PHONE: (65) 6744 2572  
FAX: (65) 6747 1708

#### PANAMA

AVE. RICARDO J. ALFARO  
EDIFICIO SUN TOWERS MALL  
PISO 2, LOCAL 55  
CIUDAD DE PANAMÁ, PANAMÁ  
PHONE: +507 236-5155  
FAX: +507 261-5355

#### SWITZERLAND

POSTFACH 73  
SCHUTZENSTRASSE 59  
CH-8245 FEUERTHALEN  
SWITZERLAND  
PHONE: +41 52 647 4700  
FAX: +41 52 659 2394

#### TAIWAN

1F, NO 126 WENSHAN 3RD STREET,  
NANTUN DISTRICT,  
TAICHUNG CITY 408  
TAIWAN R.O.C  
PHONE: (886) 4 238 04235  
FAX: (886) 4 238 04463

#### UNITED KINGDOM

6 BRISTOL DISTRIBUTION PARK  
HAWKLEY DRIVE  
BRISTOL BS32 0BF U.K.  
PHONE: +44 1454 850000  
FAX: +44 1454 859001

#### VENEZUELA

AV. ROMA, QTA EL MILAGRO. URB.  
CALIFORNIA NORTE  
CARACAS, 1070 VENEZUELA  
PHONE: 58-414-114-8623  
FAX: 58-412-322-5790



\* 4 0 0 - 0 2 0 9 \*



**BALDOR ELECTRIC COMPANY**  
**World Headquarters**  
**P.O. Box 2400 Fort Smith, AR 72901-2400**  
**(479) 646-4711 Fax (479) 648-5792**  
**[www.baldor.com](http://www.baldor.com)**

## Specifications: CM7058T-I

208V AMPS:	65
BLANK-22:	--
DESIGN CODE:	B
FL EFFICIENCY:	92.4
FRAME:	284TC
FRONT-BEARING:	6309
GREASE:	POLYREX EM
HERTZ:	60//50
INSULATION-CLASS:	F
KVA-CODE:	G
CATALOG NUMBER:	CM7058T-I
SPEC. NUMBER:	10E949X350H1
SPEED [rpm]:	1775//1470
MOTOR-WEIGHT:	--
NAMEPLATE-SERIAL-NUMBER:	--
OUTPUT [hp]:	25//20
PHASE:	3
POWER-FACTOR:	84
PULLEY-BEARING:	6311
RATING:	40C AMB-CONT
SERIAL-NUMBER:	--
SERVICE FACTOR:	1.15
TEMPERATURE-CODE:	T3C
VOLTAGE:	230/460//190/380
FL AMPS:	61.6/30.8//60/30






## Specifications: CM7006-I

208V AMPS:	1.8
BLANK-22:	--
DESIGN CODE:	B
FL EFFICIENCY:	75.5
FRAME:	56C
FRONT-BEARING:	6203
GREASE:	POLYREX EM
HERTZ:	60//50
INSULATION-CLASS:	F
KVA-CODE:	H
CATALOG NUMBER:	CM7006-I
SPEC. NUMBER:	35X724-1802G1
SPEED [rpm]:	1725//1425
MOTOR-WEIGHT:	45 LBS
NAMEPLATE-SERIAL-NUMBER:	--
OUTPUT [hp]:	.5//.33
PHASE:	3
POWER-FACTOR:	83
PULLEY-BEARING:	6205
RATING:	40C AMB-CONT
SERIAL-NUMBER:	--
SERVICE FACTOR:	1.15
TEMPERATURE-CODE:	T3C
VOLTAGE:	230/460//190/380
FL AMPS:	1.6/.8//1.4/.7





# cincinnati fan

Form: OMM-09-0509  
Effective: 5/4/09  
Supersedes: OMM-09-0207  
Part No.: 01231

## Installation, Safety, Operation & Maintenance Instructions And Parts List

For Models PB, PBS, SPB, LM and LMF.

Arrangement 4HM Blowers

### NOTE

**READ ENTIRE MANUAL, INCLUDING "SECTION IV. INITIAL UNIT STARTUP" BEFORE ATTEMPTING TO INSTALL AND OPERATE THIS EQUIPMENT.**

### BLOWER SPECIFICATIONS

**BLOWER SERIAL NUMBER:** 908313 **MFG. DATE:** 09/18/09

**NOTE:** The serial number above is a required reference for any assistance. It is stamped on the blower nameplate.

#### BLOWER SPECIFICATIONS:

**Model:** PB-10A **Arrangement:** 4HM **Rotation:** CW **Discharge:** TH

**Nominal Inlet Size:** 6 (in Inches) **Wheel Size and Type:** 10-1/4 X 3 BC

#### BLOWER PERFORMANCE DATA: (If entered on order)

**CFM:** 140 **SP:** 1.3 (Inches of Water Gauge) **Motor BHP:** 0.07

**Density:** 0.075 **Altitude:** \_\_\_\_\_ (Ft. above S.L.) **Airstream Temperature:** 70 °F.

**Fan RPM:** 1750 **Maximum Safe Fan RPM:** Call for > 1750 **DO NOT EXCEED THIS RPM**

#### MOTOR DATA: (This section is completed only if the motor was supplied by Cincinnati Fan)

**HP:** 1/2 **RPM:** 1750 **Voltage:** 230 **Phase:** 3

**Hz:** 60 **Frame Size:** 56 **Enclosure:** EXP **Efficiency:** \_\_\_\_\_

**IF Motor is EXP, Class(es) & Group(s) are:** \_\_\_\_\_

**Manufacturers Model Number:** \_\_\_\_\_ **CFV Part Number:** \_\_\_\_\_






### ATTENTION: RECEIVING DEPARTMENT

All Cincinnati Fan products are packaged to minimize any damage during shipment. The freight carrier is responsible for delivering all items in their original condition as received from Cincinnati Fan. The individual receiving this equipment is responsible for inspecting this unit for any obvious or concealed damage. If any damage is found, it should be noted on the bill of lading before the freight is accepted and the receiver must file a claim with the freight carrier.

### LONG TERM STORAGE NOTICE

If this blower will NOT be installed and put into operation within 30 days, refer to the "Long Term Storage Instructions" on pages 12 and 13. Failure to follow all applicable long term storage instructions, will void your warranty. This blower should be stored indoors in a clean, dry location.

 **DANGER**

				
Hazardous voltage can cause electrical shock and death.	High speed rotating equipment can cause severe personal injury.	Lock out/Tag out to prevent personal injury <u>BEFORE</u> starting <u>ANY</u> service or inspection.	Avoid injury. <u>NEVER</u> operate without <u>ALL</u> required safety guards in place.	Avoid injury. You <u>MUST</u> read and understand all instructions in this manual <u>BEFORE</u> installing.

**TABLE OF CONTENTS**

<p><b>I. GENERAL</b></p> <ul style="list-style-type: none"> <li>A. Unpacking and Handling .....2</li> <li>B. Safety Accessories &amp; Instructions .....2-3</li> </ul> <p><b>II. INSTALLATION</b></p> <ul style="list-style-type: none"> <li>A. Vibration.....3</li> <li>B. Mounting Methods.....3-4</li> <li>C. Duct Work Connections.....4</li> <li>D. Safety Guards.....4</li> <li>E. Dampers and Valves.....4</li> <li>F. Set Screw &amp; Taper-lock Bushing Torque Values .....5</li> </ul> <p><b>III. ELECTRICAL</b></p> <ul style="list-style-type: none"> <li>A. Disconnect Switches .....5</li> <li>B. Motors.....5-6</li> <li>C. Maximum Blower Speed.....6</li> </ul>	<p><b>IV. INITIAL UNIT STARTUP</b></p> <ul style="list-style-type: none"> <li>A. Pre-Startup &amp; Post-Startup Checks.....7</li> <li>B. Vibration.....8-9</li> </ul> <p><b>V. ROUTINE INSPECTION &amp; MAINTENANCE</b> .....9</p> <ul style="list-style-type: none"> <li>A. Hardware .....10</li> <li>B. Motor Bearing Lubrication .....10</li> <li>C. Wheel Balance .....10</li> <li>D. Vibration.....10</li> <li>E. Dampers and Valves.....10</li> <li>F. Safety Equipment or Accessories .....10-11</li> </ul> <p><b>VI. ORDERING PARTS</b> .....11</p> <p><b>VII. TROUBLESHOOTING</b> .....11-12</p> <p><b>VIII. LONG TERM STORAGE</b> .....12-13</p> <p><b>IX. WARRANTY, LIABILITY &amp; RETURNS</b>.....14</p> <p><b>X. PARTS DRAWING</b> .....15</p>
--	--

**I. GENERAL**

**A. Unpacking:**

Be careful not to damage or deform any parts of the blower when removing it from the packaging container. **All the packaging material should be kept in the event the blower needs to be returned.**

**Handling:**

Handling of the blower should be performed by trained personnel and be consistent with all safe handling practices. Verify that all lifting equipment is in good operating condition and has the proper lifting capacity. The blower should be lifted using well-padded chains, cables or lifting straps with spreader bars. **NEVER lift the blower by an inlet or discharge flange, motor shaft, motor eye bolt, or any other part of the blower assembly that could cause distortion of the blower assembly.**

**B. Safety Instructions & Accessories:**

**1. Safety Instructions:**

All installers, operators and maintenance personnel should read AMCA Publication 410-96, “**Recommended Safety Practices for Users and Installers of Industrial and Commercial Fans**”. This manual is included with the blower. Additional copies can be requested by writing us at Cincinnati Fan, 7697 Snider Rd., Mason, OH 45040-9135

**2. Sound:**

Some blowers can generate sound that could be hazardous to personnel. It is the responsibility of the user to measure the sound levels of the blower and/or system, determine the degree of personnel exposure, and comply with all applicable safety laws and requirements to protect personnel from excessive noise.

### 3. Air Pressure and Suction:

In addition to the normal dangers of rotating machinery, the blower can present additional hazards from the suction or pressure created at the blower inlet or discharge. Suction at the blower inlet can draw materials into the blower where they become high velocity projectiles at the discharge and cause severe personal injury or death. It can also be extremely dangerous to persons in close proximity to the inlet or discharge as the forces involved can overcome the strength of most individuals.

#### **WARNING**

**NEVER OPERATE A BLOWER WITH A NON-DUCTED INLET AND/OR DISCHARGE. IF THE BLOWER INLET AND/OR DISCHARGE IS NON-DUCTED, IT IS THE USERS RESPONSIBILITY TO INSTALL AN INLET AND/OR DISCHARGE GUARD.**

### 4. Temperature:

Many blowers, blower components and all motors operate at temperatures that could burn someone if they come in contact with them. If this potential hazard could exist in your installation, steps must be taken by the user to protect anyone from coming in contact with this equipment.

### 5. Spark Resistance; (Per AMCA Standard 99-0401-86 and ISO 13499)

#### **DANGER**

**NO GUARANTEE OF ANY LEVEL OF SPARK RESISTANCE IS IMPLIED BY SPARK RESISTANT CONSTRUCTION. IT HAS BEEN DEMONSTRATED THAT ALUMINUM IMPELLERS RUBBING ON RUSTY STEEL CAN CAUSE HIGH INTENSITY SPARKS. AIR STREAM MATERIAL AND DEBRIS OR OTHER SYSTEM FACTORS CAN ALSO CAUSE SPARKS.**

### 6. Safety Accessories;

#### **Guards:**

All moving parts must be guarded to protect personnel. Safety requirements can vary, so the number and types of guards required to meet company, local, state and OSHA regulations must be determined and specified by the actual user or operator of the equipment.

**NEVER start any blower without having all required safety guards properly installed. All blowers should be checked on a regular schedule, for missing or damaged guards. If any required guards are found to be missing or defective, the power to the blower should be immediately turned off and locked out in accordance with OSHA regulations. Power to the blower should NOT be turned back on until the required guards have been repaired or replaced.**

This blower can become dangerous due to a potential "windmill" effect, even though all electrical power has been turned off or disconnected. The blower wheel should be **carefully** secured to prevent any rotational turning **BEFORE** working on any parts of the blower/motor assembly that could move.

### 7. Access or Inspection Doors:

#### **DANGER**

**NEVER OPEN ANY ACCESS OR INSPECTION DOORS WHILE THE BLOWER IS OPERATING. SERIOUS INJURY OR DEATH COULD RESULT FROM THE AFFECTS OF AIR PRESSURE, AIR SUCTION OR MATERIAL THAT IS BEING CONVEYED. DISCONNECT OR LOCK OUT POWER TO THE BLOWER AND LET THE BLOWER WHEEL COME TO A COMPLETE STOP BEFORE OPENING ANY TYPE OF ACCESS OR INSPECTION DOOR.**

## **II. INSTALLATION**

### **A. Vibration:**

Before any mounting method is selected, the user should be aware of the effects vibration will have on the blower, motor and other parts. Improper blower installation can cause excessive vibration causing premature wheel and/or motor bearing failure, that is not covered under warranty.

#### **WARNING**

**SHUT THE BLOWER DOWN IMMEDIATELY IF THERE IS ANY SUDDEN INCREASE IN VIBRATION.**

## B. Mounting Methods:

An Arrangement 4HM blower is an Arrangement 4, direct driven blower without the bottom base under the motor. If the motor being supplied is a foot mounted motor, an angle base must be used to connect the blower to the motor. A C-Face motor can be bolted directly to the housing without using an angle bracket. Most Arrangement 4HM blowers are supplied with an inlet or discharge flange for mounting the blower to some type of equipment. Some are supplied with both inlet and discharge flanges.

### CAUTION

In all cases where the blower flange will be the only connection with another structure, the structure **MUST** be braced enough and/or rigid enough so as not to allow a resonance vibration to occur. Some form of additional bracing under the motor, supplied and installed by the customer, might be required to maintain vibration levels below the maximum limits as indicated in Fig. 3 on page 9. If the blower has an inlet and a discharge flange, be careful not to cause “binding” when bolting them down. That will most definitely cause a vibration problem.

#### 1. Mounting Blower By Inlet Flange only;

##### a. With motor shaft horizontal (parallel with floor):

If mounting the blower by the inlet flange only and with the motor shaft horizontal (parallel with floor), it is very likely additional support under the motor will be required.

##### b. With motor shaft vertical (perpendicular to floor):

This is the best way to mount an Arrangement 4HM blower as long as the mounting plate the flange will be bolted to is rigid enough to support the weight of the blower/motor assembly.

#### 2. Mounting Blower By Discharge Flange only;

##### a. With motor shaft horizontal or vertical:

Because of the forces involved, it will most likely be necessary to add additional support under the motor. Mount the blower and take the vibration readings as shown in Fig. 2 on page 8. If they exceed the maximums shown in Fig. 3 on page 9, you will need to add additional support.

## C. Duct Work Connections:

**All ducting or accessories, added by the user, should be independently supported. **DO NOT use the blower/motor assembly to support any additional weight.** Inlet and/or discharge duct elbows should be located a minimum of 2 blower wheel diameters from the blower. Any duct elbows located closer than 2 wheel diameters to the blower inlet or discharge **WILL** reduce the air performance and blower efficiency. Any duct elbows near the blower discharge should be in the **same rotational direction** as the **blower rotation**.**

### **Non-Ducted Blower Inlet:**

Any blower with no ducting on the inlet **must** have an inlet guard. The blower should be located so the blower inlet is, at least, 1 wheel diameter away from any wall or bulkhead to eliminate a reduction in air flow.

### **Non-Ducted Blower Discharge:**

Any blower with no ducting on the discharge **must** have a discharge guard.

## D. Safety Guards:

Cincinnati Fan offers guards, as optional, to keep your blower in compliance with OSHA safety regulations. These include inlet or discharge guards. Any blowers built with high temperature construction, a “heat slinger guard” is standard. It is the responsibility of the user to make sure this blower meets all local, state and OSHA safety regulations. If you have a specific guard requirement not covered by OSHA, please contact the local Cincinnati Fan sales office for assistance.

## E. Dampers and Valves: (Airflow control devices)

If the blower is supplied with any type of air flow control device, it should be closed before initial start-up of the blower to minimize overloading of the motor. Any airflow control device, with bearings, should be maintained in accordance with the manufacturers instructions. Any air flow control device, with an automatic control mechanism, should be adjusted per the manufacturers recommendations.

## F. Set Screw and Taper-lock Bushing Torque Values:

All blower wheel set screws are tightened to the proper torque prior to shipment. Some wheels may have taper-lock hubs and split, taper-lock bushings to secure the wheel to the motor shaft.

**NOTE:** Check all set screw or taper-lock bushing torques. Forces encountered during shipment, handling, rigging and temperature can affect factory settings. For correct torque values, see **Tables 1** and **2** below.

Table 1

SET SCREW TORQUE VALUES		
Diameter & Number of Treads/Inch	Hex Wrench Size (Across Flats)	Required Torque (Inch Pounds)
1/4-20	1/8"	65
5/16-18	5/32"	165
3/8-16	3/16"	228
7/16-14	7/32"	348
1/2-13	1/4"	504
5/8-11	5/16"	1104

Table 2

TORQUE VALUES FOR TAPER-LOCK BUSHINGS	
Taper-lock Bushing Size	Required Torque (Inch Pounds)
H	95
B	192
P	192
Q	350
R	350

### CAUTION

Set screws should **NEVER** be used more than once. If the set screws are loosened, they **MUST** be replaced. Use only knurled, cup-point, set screws with a nylon locking patch.

## III. ELECTRICAL

### A. Disconnect Switches:

All blower motors should have an independent disconnect switch located in close visual proximity to turn off the electrical service to the blower motor. **Disconnects must be locked out in accordance with OSHA "lock out-tag out" procedures any time inspection or maintenance is being performed on the blower and/or motor assembly.**

**The "lock out-tag out" procedure should be performed by a licensed electrician or authorized personnel.**

All disconnects should be sized in accordance with the latest NEC codes (National Electric Codes) and any local codes and should be installed only by a licensed electrician. "Slow blow" or "time delay" fuses or breakers should be used since the initial start-up time for the blower motor, although rare, can be up to 10 seconds.

### B. Motors:

### DANGER

**ALL WIRING CONNECTIONS, INSPECTION AND MAINTENANCE OF ANY MOTOR MUST BE PERFORMED BY A LICENSED ELECTRICIAN IN ACCORDANCE WITH THE MOTOR MANUFACTURERS RECOMMENDATIONS, ALL ELECTRICAL CODES AND OSHA REGULATIONS. FAILURE TO PROPERLY INSTALL, MAKE WIRING CONNECTIONS, INSPECT OR PERFORM ANY MAINTENANCE TO A MOTOR CAN RESULT IN MOTOR FAILURE, PROPERTY DAMAGE, EXPLOSION, ELECTRICAL SHOCK AND DEATH.**

- 1. DO NOT connect or operate a motor without reading the motor manufacturers instructions supplied with the blower.** The basic principle of motor maintenance is: **KEEP THE MOTOR CLEAN AND DRY.** This requires periodic inspections of the motor. The frequency of the inspections depends on the type of motor, the service and environment it will be subjected to and the motor manufacturers instructions.
- 2. Cleaning:** Cleaning should be limited to exterior surfaces only. **Follow motor manufacturers cleaning instructions.**
- 3. Lubrication:** Most small motors have sealed bearings that are permanently lubricated for the life of the motor. Some larger motors have grease plugs that should be replaced with grease fittings to perform re-lubrication. These motors, or any motor with grease fittings, should be lubricated in accordance with the motor manufacturers recommendations. Lubrication frequency depends on the motor horsepower, speed and service. **BE SURE** you use compatible grease and **DO NOT** over grease.
- 4. Location:** If the motor will be outside and subjected to the weather, it is recommended that a weather cover be installed to keep rain and snow off of the motor. No motors are guaranteed to be "watertight". Be careful to allow enough openings between the motor and the motor cover to let the motor "breathe". If the back end of the motor is covered, the cover should be no closer than 3" to the back of the motor for proper ventilation.

5. **Wiring Connections:** All wiring connections should be made for the proper voltage and phase as shown on the motor nameplate. Connections should follow the motor manufacturers recommendations as shown on the wiring schematic. This wiring diagram will be located on the outside of the motor, inside of the motor conduit box or on the motor nameplate. **Reversing some wires might be necessary to get the correct blower rotation.**
6. **Motors with Thermal Overload Protection:** If a motor is equipped with thermal overloads, the thermal overload must be wired per the wiring schematic to be operable. **There are 3 types of thermal overloads:**
- a. **Automatic:** These will automatically shut the motor down if the internal temperature exceeds the design limits.

**⚠ DANGER**

**MAKE SURE YOU LOCK OUT THE POWER TO THE MOTOR BEFORE INSPECTING ANY MOTOR WITH AUTOMATIC THERMALS. WHEN THE THERMALS COOL DOWN, THEY WILL ALLOW THE MOTOR TO AUTOMATICALLY START UP AGAIN, UNLESS YOU HAVE LOCKED OUT THE POWER TO THE MOTOR.**

- b. **Manual:** These motors will have a button on them. If the motor overheats, it will shut down. After you have inspected the motor and eliminated the over heating problem, you will need to “reset” it by pushing the button. **You should still lock out the power BEFORE inspecting the motor.**
  - c. **Thermostats:** This type of thermal is a temperature sensing device **ONLY**. If the motor overheats, the thermostats will open or close (depending on the type) and send a “signal” to the electrical box. **THEY WILL NOT TURN THE MOTOR OFF. These are pilot circuit devices that must be connected to the magnetic starter circuit.**
7. **EXPLOSION PROOF Motors:** No motor is explosion proof. Explosion proof (EXP) motors are designed so if there is an explosion **WITHIN** the motor, the explosion will be **CONTAINED INSIDE** the motor and not allowed to get out to the atmosphere. All explosion proof motors must be selected based on the atmosphere and/or the environment the motor will be operating in. Explosion proof motors are designed, rated, and labeled for their operating conditions based on Classes, Groups and “T” Codes. **The Class, Group and “T” Code of an EXP motor MUST be selected based on the atmosphere and/or environmental conditions the motor will be operating in. Consult the NEC (National Electric Code) and the NFPA (National Fire Protection Association) for the proper EXP motor Class, Group and “T” Code required for your specific application and location.**

**⚠ DANGER**

**IF AN EXPLOSION PROOF MOTOR IS USED IN AN AREA CONTAINING VOLITILE LIQUIDS, GASES, FUMES OR DUST FOR WHICH THE MOTOR WAS NOT DESIGNED TO OPERATE IN, AN EXPLOSION AND/OR FIRE CAN OCCUR.**

**NOTICE:**

- a. All EXP motors have some type of thermal overload as required by UL (Underwriters Laboratories). Refer to all of Section 6 above.
  - b. All EXP motors are required to have the UL (Underwriters Laboratories) and CSA (Canadian Standards Association) listing numbers on the motor name plate or on a separate plate attached to the motor. The Class, Group and “T” Code the motor is designed for must also be listed.
8. **Normal Motor Operating Temperatures:**  
Using your hand to test the normal running temperature of a motor can be a very painful experience;  
**The normal operating temperature of a fully loaded, open type, electric motor operating in a 70°F. (21° C.) ambient temperature is 174°F. (79° C.)**
- C. **Maximum Blower Speed and Motor Speed Controllers:**  
If you will be using any type of motor speed controller with this blower, **DO NOT** exceed the **maximum safe blower speed**. Installing and using a speed control devise requires special training and certification as required by the speed control manufacturer. See the manufacturers instructions for proper use, installation and wiring connections for the maximum speed settings. It may also be necessary to “block out” some speeds to eliminate a resonant vibration problem. The maximum safe blower speed is shown on the data sheet shipped with the blower. If you have lost the data sheet, contact Cincinnati Fan or our sales office for your area. You must have the serial number from the **blower** name plate for us to determine the maximum safe blower speed. Cincinnati Fan will only extend the motor manufacturers warranty, when used with a speed controlling devise, if the motor has the words “**Inverter Duty**” marked on the motor name plate. If the motor does not have “**Inverter Duty**” marked on the motor name plate, and you have a motor failure, you will be required to contact the motor manufacturer for any service or warranty claims.



#### IV. INITIAL UNIT STARTUP

**NOTICE: Failure to complete and document all the following pre-startup and both post-startup checks, listed in sections A (below) and B on page 8, could void all warranties.**


**A. Pre-Startup & Post-Startup Checks: (Check blocks as each step is completed. Retain this for your records.)**

A1. Pre-Startup Checks Completed By: \_\_\_\_\_ DATE: \_\_\_\_\_  
 A2. 8 Hour, Post-Startup Checks Completed By: \_\_\_\_\_ DATE: \_\_\_\_\_  
 A3. 3 Day, Post-Startup Checks Completed By: \_\_\_\_\_ DATE: \_\_\_\_\_

**MAKE SURE POWER TO THE MOTOR IS LOCKED OUT BEFORE STARTING PRE-STARTUP OR POST-STARTUP CHECKS.**

1.    If possible, *CAREFULLY* spin the blower wheel by hand to ensure it rotates freely and no rubbing or clicking noise is heard.
2.    Check all blower mounting flange and duct work hardware to make sure it is tight.
3.    Check all blower wheel set screws to make sure they are tight per **Table 1** on page 5.
4.    If the wheel has a taper-lock bushing, make sure the bolts are tightened per **Table 2** on page 5.
5.    Make certain there is no foreign material in the blower or duct work that can become a projectile.
6.    Make sure any inspection doors in the duct work are securely bolted or locked.
7.    Ensure all electrical power components are properly sized and matched for your electrical system.
8.    Check that all required guards are properly secured.
9.    Any dampers should be fully opened and closed to make sure there is no binding or interference.
10.    If your blower is mounted on an elevated support structure, make sure the structure is welded at all the joint connections and the structure is properly braced to prevent "side sway".
11.    Close any dampers to minimize load on motor. Especially on blowers with high temperature construction. **Never** subject a "cold" blower to a "hot" gas stream. If the blower will be handling "hot gases" greater than 150°F (65°C) it is imperative that the blower be subjected to a gradual rate of temperature increase, not to exceed 15°F/minute (8°C/minute). The same temperature limits are also important when the blower is experiencing a drop in temperature until the temperature drops down to 150°F (65°C). Only, when the entire blower has reached an equilibrium temperature of 150°F (65°C), or less, should the power be turned off.
12.    Make sure the power source connections to the blower motor are per the motor manufacturers instructions.
13.    Make sure the blower wheel is stationary prior to startup. **Starting a blower with a wheel that is rotating backwards can cause wheel damage.**
14.    Apply power to the blower motor momentarily (i.e. "bump start") to check for proper blower wheel rotation. If the blower is rotating in the wrong direction, reconnect the motor leads per the motor manufacturers wiring schematic. **Blower rotation is determined by viewing the blower from the motor side of the blower, NOT from the inlet side.** After reconnecting the leads, repeat this step. **See Fig. 1 below.**

**Fig. 1**



15.    Apply power to the blower motor and let it come up to full speed. **Turn off the power.** Look and listen for any unusual noise or mechanical abnormality while the blower wheel is still spinning. If any are noticed, lock out the power, wait for the blower wheel to come to a complete stop, locate the cause and correct it.
16.    Unlock power and start the blower.
17.    Measure, record and keep the following motor data for future reference and comparison:  
**(Single phase motors will only have L1 and L2 leads)**

**Amperage draw on each motor lead: L1 \_\_\_\_\_ L2 \_\_\_\_\_ L3 \_\_\_\_\_**

(Running amps **SHOULD NOT** exceed the motor nameplate amps for the voltage being operated on)

**Voltage coming to motor leads: L1 \_\_\_\_\_ L2 \_\_\_\_\_ L3 \_\_\_\_\_**

(Should be about the same input voltage on all leads)

**B. Vibration:**

The blower was balanced at the factory to comply with ANSI/AMCA Standard 204-05, Category BV-2. However, rough handling in shipment and/or erection, weak and/or non-rigid foundations, and misalignment may cause a vibration problem after installation. After installation, the vibration levels should be checked by personnel experienced with vibration analysis and vibration analysis equipment.

**NOTE:**

The blower **SHOULD NOT** be operated if the vibration velocity of the fan exceeds 0.50 inches per second, filter out, with the blower rigidly mounted.


Vibration readings for direct driven blowers should be taken on the motor at the top, sides and end as per **Fig. 2** below. After you have taken your vibration readings, write them down in the spaces below and keep for future comparison.

**⚠ DANGER**

If the blower is going to be conveying material, it is the users responsibility to periodically turn the blower off and lock out the power. The blower wheel should then be checked for material build-up and/or erosion. If material has built up on any parts of the wheel, it **MUST** be removed and cleaned before it is put back into service. If any parts of the wheel have been eroded, the wheel **MUST** be replaced. Failure to perform this inspection can cause excessive vibration that will damage the blower and/or motor bearings. When vibration becomes excessive, it will lead to complete blower failure that could cause property damage, severe personal injury and death. The user must determine the frequency of this inspection based on the actual circumstances of their operation, **BUT** checking the vibration readings should **NEVER** exceed a 12 month period. For the AMCA/ANSI standard for vibration limits, see Fig. 3 on page 9.

**Fig. 2**

VIBRATION METER PROBE POSITIONS				
For Arrangement 4HM Blowers				
1	2	3	4	5




<b>A</b>					
<b>B</b>					
<b>C</b>					

**A** Pre-Startup ..... Readings taken by: \_\_\_\_\_ Date: \_\_\_\_\_

**B** 8 Hour Post-Startup ..... Readings taken by: \_\_\_\_\_ Date: \_\_\_\_\_

**C** 3 Day Post-Startup ..... Readings taken by: \_\_\_\_\_ Date: \_\_\_\_\_

Fig. 3 Vibration Severity Chart



**V. ROUTINE INSPECTION & MAINTENANCE**

Periodic inspection of all the blower parts is the key to good maintenance and trouble-free operation. The frequency of inspections must be determined by the user and is dependent upon the severity of the application. **BUT**, it should **NEVER** exceed a 12 month period. The user should prepare an inspection and maintenance schedule and make sure it is adhered to.

**⚠ WARNING**

**BEFORE STARTING ANY INSPECTION OR MAINTENANCE, BE SURE BLOWER IS TURNED OFF, POWER IS LOCKED OUT AND THE BLOWER WHEEL HAS BEEN CAREFULLY SECURED TO PREVENT WIND MILLING. IF THE OPERATING CONDITIONS OF THE BLOWER ARE TO BE CHANGED (SPEED, PRESSURE, TEMPERATURE, ETC.) CONSULT CINCINNATI FAN, OR OUR SALES OFFICE FOR YOUR TERRITORY, TO DETERMINE IF THE UNIT WILL OPERATE SAFELY AT THE NEW CONDITIONS.**

## A. Hardware:

All blower and foundation hardware should be checked to make sure it is tight. Wheel set screws or taper-lock bushings should be tightened to the torque values shown in **Tables 1 and 2** on page 5.

**NOTE:** If any set screws have come loose, they must be thrown away and replaced. **NEVER** use set screws more than once. **Replace with knurled, cup-point set screws with a nylon locking patch.**

## B. Motor Bearing Lubrication:

### 1. Motor Bearings:

Most smaller motors have sealed bearings that never require re-lubrication for the life of the motor. For any motors with grease fittings, consult the motor manufacturers recommendations with reference to the lubrication frequency and the type of grease that should be used.

**DO NOT** over grease the motor bearings. Generally, 1-2 shots should be enough. Use a hand operated grease gun at no more than 40 PSI. **IF POSSIBLE, CAREFULLY lubricate the motor bearings while the motor is running.**

## C. Wheel Balance:

All blower wheels are balanced at the factory. It is not uncommon that additional “trim balancing” is required after the blower is assembled. Trim balancing of the blower assembly, in the field, is typically always necessary for all replacement wheels. **After any wheel is installed, the final balance of the entire blower assembly should be checked.** Refer to **Section B** on page 8 and **Fig. 3** on page 9. Air stream material or chemicals can cause abrasion or corrosion of the blower parts. This wear is generally uneven and, over time, will lead to the wheel becoming unbalanced, causing excessive vibration. When that happens, the wheel must be rebalanced or replaced. The other air stream components should also be inspected for wear or structural damage and cleaned or replaced if necessary. **After cleaning any blower wheel, it should be balanced and then “trim balanced” on the motor shaft.**

There are three ways to balance a blower wheel:

### 1. Add balancing weights for fabricated aluminum, steel or stainless steel wheels:

Balance weights should be rigidly attached to the wheel at a location that will not interfere with the blower housing nor disrupt air flow. They should (if at all possible) be welded to the wheel. When trim balancing the wheel, **on the blower**, be sure to ground the welder **directly** to the blower wheel. Otherwise, the welding current will likely pass through the motor and damage the motor bearings.

### 2. Grinding off material for cast aluminum wheels:

If you are grinding on the wheel to remove material, be very careful not to grind too much in one area. That could affect the structural integrity of the wheel.

### 3. Forward curved wheels, Models LM and LMF only (also known as squirrel cage or multivane wheels).

These wheels have balancing clips attached to individual blades around the wheel. That is the only proper way to balance this type of wheel.

#### **NOTE:**

Removing any forward curve wheel from the blower to clean it, requires special attention when reinstalling the wheel back into the blower housing. Make sure you reinstall the wheel so the proper wheel-to-inlet clearance is maintained. Failure to do this will affect the blowers airflow (CFM), static pressure (SP) capabilities and efficiency. Consult Cincinnati Fan or our local sales office for your area for assistance if necessary.

## D. Vibration:

As mentioned previously in this manual, excessive vibration can cause premature motor bearing failure that could lead to catastrophic failure of the blower. After performing any routine maintenance, the vibration readings should be taken again. New readings should be taken (maximum every 12 months) and compared to the readings you recorded in **Fig. 2** on page 8, during the initial startup. **If any major differences are present, the cause should be determined and corrected before the blower is put back into operation.**

The most common causes of vibration problems are:

1. Wheel unbalance.
2. Mechanical looseness.
3. Poor blower inlet and/or discharge conditions.
4. Foundation stiffness.

## E. Dampers and Valves: (Airflow control devices)

Turn off and lock out power to the blower motor. Any dampers or valves should be periodically inspected to make sure all parts are still operable within their full range and there is no interference with any other damper or blower components. Any bearings or seals should be checked for their proper function. The manufacturers maintenance instructions should be followed.

## F. Safety Equipment & Accessories:

It is the users responsibility to make sure that all safety guards required by the company, local, state and OSHA regulations are properly attached and fully functional at all times. If any guards become defective or non-functional at any time, **the power to the blower MUST be turned off and locked out** until complete repairs and/or replacements have been made, installed and inspected by authorized personnel.

Any accessories used in conjunction with the blower should also be inspected to make sure they are functioning within their intended limits and design specifications. The manufacturers maintenance manuals should be referred to for correct maintenance procedures. These accessories include, but are not limited to, the following:

Shaft seals, inspection doors, vibration isolators or vibration bases, air flow or pressure measuring equipment, hoods, controls, special coatings, silencers, expansion joints, valves, flexible connectors and filters.

## **VI. ORDERING REPLACEMENT PARTS:**

Under normal conditions, you should not need any spare or replacement parts for at least 24 months after shipment from Cincinnati Fan. That does not include any wear due to abrasion, corrosion, excessive temperatures, abuse, misuse, accident or any severe conditions the fan was not designed for.

### **NOTICE:**

1. **If this blower is vital to any process that could cost you lost revenue, we strongly recommend that you keep a replacement blower wheel and motor at your location.**
2. **If this blower is vital for the safety of any people and/or animals, we strongly recommend that you keep a complete blower/motor assembly, as originally ordered, at your location.**

To order any parts or complete units, contact us for the name of our sales office for your area. Or you can find them on our website at: [www.cincinnati-fan.com](http://www.cincinnati-fan.com)

**WE MUST HAVE THE BLOWER SERIAL NUMBER FROM THE BLOWER NAME PLATE TO IDENTIFY PARTS CORRECTLY.**

## **VII. TROUBLESHOOTING**

### **DANGER**

**Troubleshooting should only be performed by trained personnel. Any potential electrical problems should only be checked by a licensed electrician. All safety rules, regulations and procedures MUST be followed. Failure to follow proper procedures can cause property damage, severe bodily injury and death.**

Potential problems and causes listed below are in no order of importance or priority. The causes are only a list of the most common items to check to correct a problem. If you find the cause of a problem, **DO NOT** assume it is the **ONLY** cause of that problem. Different problems can have the same causes.

<b>PROBLEM</b>	<b>CAUSE</b>
<b>Excessive Vibration</b>	<ol style="list-style-type: none"> <li>1. Loose mounting bolts, wheel set screws, taper-lock hubs.</li> <li>2. Worn or corroded blower wheel.</li> <li>3. Accumulation of foreign material on blower wheel.</li> <li>4. Bent motor shaft.</li> <li>5. Worn motor bearings.</li> <li>6. Motor out of balance.</li> <li>7. Inadequate structural support.</li> <li>8. Support structure not sufficiently cross braced.</li> <li>9. Weak or resonant foundation.</li> <li>10. Foundation not flat and level.</li> </ol>
<b>Airflow (CFM) Too Low</b>	<ol style="list-style-type: none"> <li>1. Blower wheel turning in wrong direction (<b>rotation</b>).</li> <li>2. Actual system static pressure (<b>SP</b>) is higher than expected.</li> <li>3. Motor speed (<b>RPM</b>) too low.</li> <li>4. Dampers or valves not adjusted properly.</li> <li>5. Leaks or obstructions in duct work.</li> <li>6. Filters dirty.</li> <li>7. Inlet and/or discharge guards are clogged.</li> <li>8. Duct elbow too close to blower inlet and/or discharge.</li> <li>9. Improperly designed duct work</li> <li>10. Blower wheel not properly located relative to the inlet bell (Models <b>LM</b> and <b>LMF</b> only).</li> </ol>
<b>Airflow (CFM) Too High</b>	<ol style="list-style-type: none"> <li>1. Actual system static pressure (<b>SP</b>) is lower than expected.</li> <li>2. Motor speed (<b>RPM</b>) too high.</li> <li>3. Filter not in place.</li> <li>4. Dampers or valves not adjusted properly.</li> </ol>

PROBLEM	CAUSE
<b>Motor Overheating</b>	<p><b>NOTE: A normal motor will operate at 174°F. See B-8 on page 6.</b></p> <ol style="list-style-type: none"> <li>1. Actual system static pressure (<b>SP</b>) is lower than expected.</li> <li>2. Voltage supplied to motor is too high or too low.</li> <li>3. Motor speed (<b>RPM</b>) too high or defective motor.</li> <li>4. Air density higher than expected.</li> <li>5. Motor wired incorrectly or loose wiring connections.</li> <li>6. Cooling fan cover on back of motor is clogged. (Fan cooled motors only.)</li> </ol>
<b>Excessive Noise</b>	<ol style="list-style-type: none"> <li>1. Wheel rubbing inside of housing.</li> <li>2. Worn or corroded blower wheel.</li> <li>3. Accumulation of foreign material on blower wheel.</li> <li>4. Loose mounting bolts, wheel set screws, or taper-lock hubs.</li> <li>5. Bent motor shaft.</li> <li>6. Worn motor bearings.</li> <li>7. Motor out of balance.</li> <li>8. Motor bearings need lubrication.</li> <li>9. Vibration originating elsewhere in system.</li> <li>10. System resonance or pulsation.</li> <li>11. Inadequate or faulty design of blower support structure.</li> <li>12. Blower operating near “stall” condition due to incorrect system design or installation.</li> </ol>
<b>Fan Doesn't Operate</b>	<ol style="list-style-type: none"> <li>1. Motor wired incorrectly.</li> <li>2. Incorrect voltage supply.</li> <li>3. Defective fuses or circuit breakers.</li> <li>4. Power turned off elsewhere.</li> <li>5. Motor wired incorrectly or loose wiring connections.</li> <li>6. Defective motor.</li> </ol>

**VIII. LONG TERM STORAGE INSTRUCTIONS: (Storage exceeding 30 days after receipt of equipment)**

**NOTE: Failure to adhere to these instructions voids all warranties in their entirety.**

1. Storage site selection:
  - a. Level, well-drained, firm surface, in clean, dry and warm location. Minimum temperature of 50°F (10°C).
  - b. Isolated from possibility of physical damage from construction vehicles, erection equipment, etc.
  - c. Accessible for periodical inspection and maintenance.
2. The blower should be supported under each corner of its base to allow it to “breathe”. Supports (2 x 4's, timbers, or railroad ties) should be placed diagonally under each corner.
3. If the equipment is to be stored for more than three (3) months, the entire blower assembly must be loosely covered with plastic, **but not tightly wrapped**.
4. Storage Maintenance:

***A periodic inspection and maintenance log, by date and action taken, must be developed and maintained for each blower. See example below. Each item must be checked monthly.***

**EXAMPLE:**

**Storage / Maintenance Schedule Log**

ITEM	ACTION	DATES CHECKED
1	Re-inspect units to insure any protective devices used are functioning properly. Check for scratches in the finish which will allow corrosion or rust to form.	
2	Rotate wheel a minimum of 10 full revolutions to keep the motor bearing grease from separating and drying out. <b><i>This is a critical step.</i></b>	

**Long Term Storage instructions continued on page 13.**

5. General Motor Procedure:

If the motor is not put into service immediately, the motor must be stored in a clean, dry, warm location. Minimum temperature of 50°F. (10°C,). Several precautionary steps must be performed to avoid motor damage during storage.

- a. Use a "Megger" each month to ensure that integrity of the winding insulation has been maintained. Record the Megger readings. Immediately investigate any significant drop in insulation resistance.
- b. **DO NOT** lubricate the motor bearings during storage. Motor bearings are packed with grease at the factory.
- c. If the storage location is damp or humid, the motor windings **must** be protected from moisture. This can be done by applying power to the motor's space heaters, (IF AVAILABLE) while the motor is in storage. If the motor does not have space heaters, storing it in a damp or humid location will, very quickly, cause internal corrosion and motor failure which is not warranted.

**NOTE:**

**For specific storage instructions, for the actual motor and any accessory parts that were supplied, refer to the manufacturer's instructions.**



## **IX. LIMITED WARRANTY:**

Cincinnati Fan & Ventilator Company (Seller) warrants products of its own manufacture, against defects of material and workmanship under normal use and service for a period of eighteen (18) months from date of shipment or twelve (12) months from date of installation, whichever occurs first. This warranty does not apply to any of Seller's products or any part thereof which has been subject to extraordinary wear and tear, improper installation, accident, abuse, misuse, overloading, negligence or alteration. This warranty does not cover systems or materials not of Seller's manufacture. On products furnished by Seller, but manufactured by others, such as motors, Seller extends the same warranty as Seller received from the manufacturer thereof. Expenses incurred by Purchaser's in repairing or replacing any defective product will not be allowed except where authorized in writing and signed by an officer of the Seller.

The obligation of the Seller under this warranty shall be limited to repairing or replacing F.O.B. the Seller's plant, or allowing credit at Seller's option. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS AND LIABILITIES OF THE SELLER. THE PURCHASER ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE TO PURCHASER OR RELIED UPON BY PURCHASER WITH RESPECT TO THE QUALITY OR FUNCTION OF THE PRODUCTS HEREIN SOLD.**

Removal of the Seller's nameplate or any generic fan nameplate containing the fan serial number voids all warranties, either written or implied. Failure to complete and document all the pre-startup and post startup checks and perform the suggested routine maintenance checks voids all warranties, either written or implied.

## **LIMITATION OF LIABILITY:**

Notice of any claim, including a claim for defect in material or workmanship, must be given to Seller in writing within 30 days after receipt of the equipment or other products. Seller reserves the right to inspect any alleged defect at Purchaser's facility before any claim can be allowed and before adjustment, credit, allowance replacement or return will be authorized. See **RETURNS** below. Seller's liability with respect to such defects will be limited to the replacement, free of charge, of parts returned at Purchaser's expense F.O.B. Seller's plant and found to be defective by the Seller.

**IN NO EVENT WILL SELLER BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTACT, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE, INCLUDING WITHOUT LIMITATION DAMAGES FOR INJURY TO PERSONS OR PROPERTY, LOST PROFITS OR REVENUE, LOST SALES OR LOSS OF USE OF ANY PRODUCT SOLD HEREUNDER. PURCHASER'S SOLE AND EXCLUSIVE REMEDY AGAINST SELLER WILL BE THE REPLACEMENT OF DEFECTIVE PARTS AS PROVIDED HEREIN OR REFUND OF THE PURCHASE PRICE FOR DEFECTIVE PRODUCTS, AT SELLER'S SOLE OPTION. SELLER'S LIABILITY ON ANY CLAIM, WHETHER IN CONTRACT, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE, FOR ANY LOSS OR DAMAGE ARISING OUT OF OR IN CONNECTION WITH PURCHASER'S ORDER OR THE PRODUCTS OR EQUIPMENT PURCHASED HEREUNDER, SHALL IN NO CASE EXCEED THE PURCHASE PRICE OF THE EQUIPMENT GIVING RISE TO THE CLAIM.**

## **RESPONSIBILITY:**

It is the understanding of the Seller that Purchaser and/or User will use this equipment in conjunction with additional equipment or accessories to comply with all Federal, State and local regulations. The Seller assumes no responsibility for the Purchaser's or Users compliance with any Federal, State and local regulations.

## **RETURNS:**

Cincinnati Fan & Ventilator Company assumes no responsibility for any material returned to our plant without our permission. An **RMA** (Return Material Authorization) number must be obtained and clearly shown on the outside of the carton or crate and on a packing slip. Any items returned must be shipped freight prepaid. Failure to comply will result in refusal of the shipment at our receiving department.

### **DISCLAIMER**

This manual, and all its content herein, is based on all applicable known material at the time this manual was created. **Any parts of this manual are subject to change at any time and without notice.**

If any statements, diagrams and/or instructions contained herein, **for components not manufactured by the Seller**, conflict with instructions in the manufacturer's manual (i.e.: motors, dampers, etc.), the instructions in the manufacturer's manual, for that component take precedent.

Should you want the latest version of this manual, please contact us or our sales office for your area. Or, you can print a current version by going to our website at: [www.cincinnati-fan.com](http://www.cincinnati-fan.com)



7697 Snider Road, Mason, OH 45040-9135  
Phone: (513) 573-0600 Fax: (513) 573-0640  
E-Mail: [sales@cincinnati-fan.com](mailto:sales@cincinnati-fan.com)




## X. PARTS DRAWING:

### PLEASE NOTE

Cincinnati Fan manufactures many models and arrangements with special variations. For that reason, the maintenance manuals contained on our website do not include a parts drawing nor the completed blower or fan specifications on page 1. For the parts drawing of all the standard components and specifications for the specific blower or fan that you have, please contact our local Cincinnati Fan sales office for your area.

You will need to give them the serial number shown on the blower or fan nameplate so they can supply you the correct information.

Click on "**Contact a Sales Rep**" on our website for the name and contact information for our local sales office for your area. [www.cincinnati-fan.com](http://www.cincinnati-fan.com)



- 1. INLET FLANGE
- 2. INLET-SIDE HOUSING
- 3. BLOWER WHEEL
- 4. DRIVE-SIDE HOUSING
- 5. BASE, FAN
- 6. RISER BLOCKS\*
- 7. MOTOR
- \* IF REQUIRED

**PB 2-PIECE ARRANGEMENT 4HM ASSEMBLY  
(PB-8 TO PB-12A)**

The drawing shown above is a representation of the basic model blower or fan purchased on the serial number shown on page 1. It does not include any optional or accessory parts or any special construction features that might have been supplied with the original order.