

# User Manual

## FXO+FXS Gateway

### Model: HTM Series



DBL Technology Co.,Ltd.

[Http://www.dbltek.com/en](http://www.dbltek.com/en)

[sales@dbltek.com](mailto:sales@dbltek.com)

[Support@dbltek.com](mailto:Support@dbltek.com)

2009-12-15

# Contents

<b>1. Product Introduction.....</b>	<b>4</b>
1.1 General Information .....	4
1.2 Protocol .....	4
1.3 Hardware Specification.....	5
1.4 Software Specification .....	5
1.5 List of the Package.....	5
1.6 Appearance.....	5
1.7. Apply.....	6
<b>2. Connection .....</b>	<b>7</b>
2.1. Interface Description:.....	7
2.2. Indicator lights explanation:.....	8
2.3. Connection diagram: .....	9
<b>3. Configuration .....</b>	<b>10</b>
3.1. Factory setting parameters: .....	10
3.2. Log on to the Gateway .....	11
3.2.1. Get IP .....	11
3.2.2. Open browser and input IP.....	11
3.3 Gateway Configuration .....	15
3.3.1. User options .....	15
3.3.2. Network Configuration .....	17
3.3.3. Call Setting.....	19
3.3.3.1. H.323.....	19
3.3.3.1.1 FXS Configuration.....	20
3.3.3.1.2. FXO Configuration .....	22
3.3.3.1.3 Configuration mode .....	23
3.3.3.1.4. Encryption.....	24
3.3.3.2. H.323 Advanced Setting.....	24
3.3.3.3. SIP Protocol.....	26
3.3.3.3.1. FXS Configuration .....	26
3.3.3.3.2. FXO Configuration .....	30
3.3.3.3.3. Configuration Mode .....	32
3.3.3.3.4. SIP Advanced Configuration.....	32
3.3.3.3.5. Media Advanced Configuration .....	33
3.3.3.4. Firewall Traversal.....	35
3.3.3.4.1. H.323 Signaling NAT Traversal .....	35
3.3.3.4.2. SIP Signaling NAT Traversal .....	36
3.3.3.4.3. Media NAT Traversal .....	37
3.3.4. FXS Setting.....	38
3.3.5. FXO Setting .....	39
3.3.6. Save Changes .....	40
3.3.7. Abandon changes .....	41

<b>4. Tools.....</b>	<b>41</b>
4.1. Online Upgrade .....	41
4.2. Change Password .....	42
4.3. Restore factory settings .....	42
4.4. Reboot the system .....	42
<b>5. Dialing Rules.....</b>	<b>43</b>
5.1. Basic rules of grammar .....	43
5.2. With a limited number of digit dialing rules .....	44
<b>6. Understand More.....</b>	<b>44</b>
6.1. Gateway Initialization .....	44
6.2. Advanced Configuration .....	45
6.3. Notes .....	45

# 1. Product Introduction

## 1.1 General Information

HTM series VoIP gateways are the performance Gateway of FXO plus FXS, which developed by Technology Co., Ltd. HTM Series VoIP gateways built-in H.323 and SIP protocols. The lines can be configured into different numbers or used for Trunk Gateway. Highly reliable line detection prevents the line hanging death in the largest tent. It can forward outside Caller ID Number under the SIP protocol, which is an important function of PBX application. Super Echo Cancellation Algorithm and Balanced Circuit make line echo minimum. Low price, Stable and performance are pronoun of the HTM series products, it is the first choice of PXS Manufacturers, Call Center and System Integrators.

HTM series mainly include HTM-112, HTM-222, and HTM-442.

## 1.2 Protocol

- TCP/IP V4 (IP V6 auto adapt)
- ITU-T H.323 V4 Standard
- H.2250 V4 Standard
- H.245 V7 Standard
- H.235 Standard (MD5, HMAC-SHA1)
- ITU-T G.711 Alaw/Ulaw, G.729A, G.729AB, and G.723.1 Voice Codec
- RFC1889 Real Time Data Transmission
- Proprietary Firewall-Pass-Through Technology
- SIP V2.0 Standard
- Simple Traversal of UDP over NAT (STUN)
- Web-base Management
- PPP over Ethernet (PPPOE)
- PPP Authentication Protocol (PAP)
- Internet Control Message Protocol (ICMP)
- TFTP Client
- Hyper Text Transfer Protocol (HTTP)
- Dynamic Host Configuration Protocol (DHCP)
- Domain Name System (DNS)
- User account authentication using MD5
- Out-band DTMF Relay: RFC 2833 and SIP Info

## 1.3 Hardware Specification

- ARM9E Processor
- DSP for voice codec and voice processing
- Two 10/100 Base T Ethernet ports with full compliant with IEEE 802.3
- LEDS for Ethernet port status
- Direct Connect Ethernet cable
- Four PSTN Channels' Connection

## 1.4 Software Specification

- LINUX OS
- Built-in HTTP Web Server
- PPPOE Dial-up
- NAT Broadband Router Functions
- DHCP Client
- DHCP Server
- Firmware On-line upgrade
- PSTN Caller ID transmit
- Multiple Language Support
- Supported call divert
- Supported PSTN auto call out to PSTN
- Supported PSTN caller ID transparent to VoIP system in SIP protocol
- Supported RELAY encryption protocol

## 1.5 List of the Package

- a) One Gateway main unit
- b) One DC24V/500mA power adaptor
- c) One Ethernet cable (2 M)

## 1.6 Appearance


### 1) LAN


Connect this port to an Ethernet Switch/Router, the Ethernet of a DSL modem, or other network access equipment.

### 2) PC

- Connect a computer or other network device to this port. (Less than 100 mid-range)
- 3) **Power (DC24V/500mA)**  
Connect the 24V/500mA Adapter provided to this power jack.
- 4) **Reset**  
Reset switch, use to start the device or delete the configuration quickly.


## 1.7. Apply





## 2. Connection


### 2.1. Interface Description:



Interface Name	Connect to	Notes
FXO 1-4	Connected to four telephone lines	If exposed, note lightning
FXS 1-4	FXS output, connected to telephone	Length of line is below than 300 meters
LAN	Network input, connected to Network	10/100Base T
PC	Network output, connected to computer	10/100Base T
DC24V	Connected to power	
RESET	Restore the factory configuration	Press(more than 10 seconds)will ok

## 2.2. Indicator lights explanation:






HTM-112



HTM-222



HTM-442

Diagram 2-2

Name	Explanation	performance
Power	Power LED	Post-Long after start
RUN	Working status lights	Logged, flash 250 ms; login, slow flash 500 ms; upgrading, Continuous flashing 100 ms.
LAN	LAN Network Lights	Light after connect the Network, flash when Data Transmission
PC	PC Network Lights	Light after connect the Network, flash when Data Transmission
FXO 1-4	Telephone status lights	Light after Machine state is mentioned
FXS 1-4	Line status lights	Light when put up telephone

### 2.3. Connection diagram:




Diagram 2-3

HTM series have a LAN port and a PC port. Please connect as follows:

1. Open the package, there are a Gateway, a power, and a cable;
2. Take out of Ethernet cable and connect to the PC;
3. The PC supports Network share, connect to the computer or lower switch;
4. FXS is connected to normal telephone, FXO is connected to line PSTN.

Make transformer output terminal.

### 3. Configuration

#### 3.1. Factory setting parameters:

Parameter	Default setting	Explanation
-----------	-----------------	-------------

Username	admin	
Password	admin	Please remember the password after change
LAN Network Setting	DHCP	
PC Network Setting	Bridge mode	
LAN IP	*00(Chinese) *01(English)	Press “*00” or “*01” get IP address
LAN IP Setting	*03	Such as *03192*168*1*2#
Restore factory	*11983185922	After input password and hear “Toot”, then success, you just to pull power and restart the Gateway.

## 3.2. Logon to the Gateway

### 3.2.1. Get IP

- A) Make sure that there is DHCP sever: In accordance with connection diagram 2-3, connect the HTM\_XXX and plug power , check the RUN light flash or not. About the RUN light quick flashes 10 seconds, plug one telephone into anyone FXS port and press \*00, telephone will report IP address in Chinese; Press \*01, then will report in English.
- B) Without DHCP sever in the Network: Plug one telephone into anyone FXS port and press \*03+IP address, such as “\*03192\*168\*1\*2#”, indicates that IP temporary address is 192.168.1.2. If you want to know how setting is successful, just to press \*00 or \*01 and hear the IP again. Notice that the temporary IP is the same as the PC-segment and not conflict with other Network setting. The same PC-segment means the first three sections the number of IP must consistent, such as 192.168.1.3 and 192.168.1.5 are the same segment, 192.168.1.3 and 192.168.2.4 are not.
- C) HTM series’ PC port has fixed a LAN IP address in default setting, it is 192.168.8.1, and you can visit HTM\_XXX series’ gateways through this port;

### 3.2.2. Open browser and input IP

After get IP or set a segment IP, open the browser (IE), and input IP on the Address Field.



If the connection is correct, the Web Browser will prompt you to enter the “User name” and “Password” as shown below.



Input the username and password, enter state page, as following figure:




简体

### EasyPhone VoIP Gateway

Status	
<b>Gateway Information</b>	
Serial Number	HTM11209080253
Firmware Version	OSS-3.03-10
Hardware Model	1s1o
FXS Line1 Status	LOGOUT
FXO Line1 Status	NOT CONFIG
<b>Network Information</b>	
LAN Port	192.168.2.208
LAN MAC	00:11:BE:02:DA:D6
PC Port	In Bridge Mode
PPPoE	Disabled
Default Route	192.168.2.253
DNS Server	202.96.134.133

Navigation: Status, Configurations, Tools

State of HTM-112




简体中文

### EasyPhone VoIP Gateway

Status	
<b>Gateway Information</b>	
Serial Number	HTM222090600036
Firmware Version	OSS-3.03-10
Hardware Model	2s2o
FXS Line1 Status	LOGOUT
FXS Line2 Status	LOGOUT
FXO Line1 Status	NOT CONFIG
FXO Line2 Status	NOT CONFIG
<b>Network Information</b>	
LAN Port	192.168.2.247
LAN MAC	00:11:BE:02:B2:E6
PC Port	In Bridge Mode
PPPoE	Disabled
Default Route	192.168.2.253
DNS Server	202.96.134.133

Navigation: Status, Configurations, Tools

State of HTM-222



The screenshot shows the EasyPhone VoIP Gateway web interface. At the top left is the 'EasyPhone' logo with a colorful bar chart. The top right corner has '简体中文' (Simplified Chinese). Below the header is a navigation menu with 'Status', 'Configurations', and 'Tools'. The main content area is titled 'Status' and is divided into two columns: 'Gateway Information' and 'Network Information'.

Gateway Information		Network Information	
Serial Number		LAN Port	192.168.2.234
Firmware Version	OSS-3.03-10	LAN MAC	
Hardware Model	4s4o	PC Port	In Bridge Mode
FXS Line1 Status	NOT CONFIG	PPPoE	Disabled
FXS Line2 Status	LOGIN	Default Route	192.168.2.253
FXS Line3 Status	LOGIN	DNS Server	202.96.134.133
FXS Line4 Status	NOT CONFIG		

#### State of HTM-442

**Sequence number:** The Gateway factory serial number;

**Software version number:** HTM series' software version. This parameters is identified by the system automatically, users can change by upgrading the Gateway;

**Hardware model:** Its line configuration can be identified by system software;

**Registration status of FXS (1-4):** When normal registration, shows LOGIN, or shows LOGOUT;

**Registration status of FXO (1-4):** When normal registration, shows LOGIN, or shows LOGOUT;

**LAN port:** Shows the LAN IP;

**LAN's Hardware address:** LAN's MAC address;

**PC port:** Shows the PC IP;

**PPPOE:** Shows the status of PPPOE, Disabled or enabled;

**Default route:** The Gateway use;

**Domain Name Server:** The DNS Server of the Gateway.

## 3.3 Gateway Configuration

Click “Configure”, enter interface, and start to configure:

<b>Status</b>  <b>Configurations</b> Preferences Network Call Settings FXS Settings PSTN Settings Save Changes Discard Changes  <b>Tools</b>	<b>Preference</b>	
	Language(语言) <input type="text" value="简体中文"/>	Tone Mode <input type="text" value="China"/>
	Time Zone <input type="text" value="GMT+8"/>	China Phone Code Matching <input type="radio"/> Enable <input checked="" type="radio"/> Disable
	Time Server <input type="text" value="pool.ntp.org"/>	<input checked="" type="checkbox"/> Auto Reboot
	Auto Provision <input type="radio"/> Enable <input checked="" type="radio"/> Disable	Reboot Time <input type="text" value="04:00"/>
	<a href="#">Remote Control&gt;&gt;</a>	
	<b>Network Configuration</b>	
	LAN Port <input type="text" value="DHCP"/>	PC Port <input type="text" value="Bridge mode"/>
	802.1q VLAN <input type="radio"/> Enable <input checked="" type="radio"/> Disable	<a href="#">Advanced&gt;&gt;</a>
	<a href="#">Advanced&gt;&gt;</a>	
	<b>Call Settings</b>	
	Endpoint Type <input type="text" value="SIP Phone"/>	<a href="#">Advanced&gt;&gt;</a>
	FXO Mode <input type="text" value="FXO"/>	<a href="#">Media Settings&gt;&gt;</a>

### 3.3.1. User options

<b>Preference</b>	
Language(语言) <input type="text" value="简体中文"/>	Tone Mode <input type="text" value="China"/>
Time Zone <input type="text" value="GMT+8"/>	China Phone Code Matching <input type="radio"/> Enable <input checked="" type="radio"/> Disable
Time Server <input type="text" value="pool.ntp.org"/>	<input checked="" type="checkbox"/> Auto Reboot
Auto Provision <input type="radio"/> Enable <input checked="" type="radio"/> Disable	Reboot Time <input type="text" value="04:00"/>
<a href="#">Remote Control&gt;&gt;</a>	

#### A) Language

Enter the language page, you can configure it. If the current language is Chinese and you want it in English, choose “English” on top of webpage, then the webpage will changed to English at soon; but the page will still in old one when you reboot the devices or logon again; Also you can configure it with “Language option” in the upper right corner. As figure, click “English” and save this changed, devices will show English page when it reboot;

<b>Preference</b>		
Language(语言) <input type="text" value="简体中文"/>		
Time Zone <input type="text" value="English"/>		
Time Server <input type="text" value="pool.ntp.org"/>		
Auto Provision <input type="radio"/> Enable <input checked="" type="radio"/> Disable		

#### B) Time Zone

According to special place to configure, device use Network Time Protocol obey the information of time and date on the server, the lag will change automatically. For example:

the Pacific Standard Time is GMT-8, while Pacific daytime is GMT-7.

Preference	
Language(语言)	简体中文
Time Zone	GMT+8

Time Zone shows the place where users are, only fill it correctly, CND and billing information can show the right time.

### C) Time Server

Server address that the Gateway get Network time by Internet. The default is: pool.ntp.org.

Time Server	pool.ntp.org
-------------	--------------

### D) Auto Provision

Choose “Enable” and fill the server IP, if service provider do not support the service, then choose “Disable”, which make setting start-up speed fast.

Auto Provision	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Provision Server	
Provision Interval	
Remote Control>>	

### E) Remote Control

Input \*20# and initiate requests by Terminals device, doing this can control the remote device. Remote control server is supported by service provider, default port is 1920, logo terminals by SN. The address and password are the same.

Remote Control<<	
Remote Server	
Remote Server Port	1920
Remote Server ID	#{SN}
Remote Server Key	
	<input checked="" type="checkbox"/> Auto Connect to Provision
Connect Port	1920

As indicated in figure, fill 202.155.200.154, pick the phone and press \*20#, then hear a long tone, shows succeed. Open <http://202.155.200.154:8086>, and you will see the connected Gateway model and serial number, click “serial number”, you can configure it.

Remote Control<<	
Remote Server	202.155.200.154
Remote Server Port	1920
Remote Server ID	#{SN}
Remote Server Key	
	<input checked="" type="checkbox"/> Auto Connect to Provision
Connect Port	1920

### F) Tone Mode



It is dialing tone and ring back tone, and so on. You can choose different tone according to different countries.

<b>Tone Mode</b>	China
<b>China Phone Code Matching</b>	Australia
	<b>China</b>
	Hong Kong
	New Zealand
<b>Reboot Time</b>	United Kingdom
	United States
	Korea
	Slovenia
	Czechoslovakia
	Customized

**G) China Phone Code Matching**

Can match all the China phone code and make sure the fastest dial time.

<b>China Phone Code Matching</b>	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	<input checked="" type="checkbox"/> Auto Reboot
<b>Reboot Time</b>	04:00

**H) Reboot Time**

The Gateway will reboot within the specified time, in order to clean the equipment cache, and make sure the device running normally.

	<input checked="" type="checkbox"/> Auto Reboot
<b>Reboot Time</b>	04:00

**3.3.2. Network Configuration**

When you need to change the way of Network connection, you can choose “Network Configuration” and start to configure.


Access network has 3 kinds, get IP address automatically (DHCP)、Hand Set、and PPPOE. When choose getting IP address automatically, you just to click “DHCP”, do not need to fill parameters.




When choose Hand Set, click “standard IP” and fill the IP address, mask and Gateway address. When use standard IP, you should fill in “Main DNS” server-address to get Domain Name Service, getting this address you can consult your Internet access service providers.



When need to use PPOE, click it, and input the Username and password.



When use PPOE, need to enable Gateway routing, so that the PC that connected to the Gateway can connect to the Internet correctly. Change the PC Bridge Mode into Standard IP, configure as follows:




PC port enables standard IP, the mask 2555.2555.2555.0, after enable DHCP, the computer that connected to the PC port can get arbitrary IP in the range of start address and end address.

**Notes: The PC IP could not exist in the same segment with the LAN, in case of conflict.**

### 3.3.3. Call Setting

#### 3.3.3.1. H.323



HTM has PSTN and FXO mode, which can be chosen in the FXO Mode pattern:

Call Settings	
Endpoint Type	H.323 Phone <span>▼</span> <a href="#">Advanced&gt;&gt;</a>
FXO Mode	FXO <span>▼</span> <a href="#">Media Settings&gt;&gt;</a>
	<a href="#">FXS Calling Settings&gt;&gt;</a>
	<a href="#">FXO Calling Settings&gt;&gt;</a>

**PSTN:** In this mode, HTM series gateway's FXO ports will work like a PSTN by Pass port; you can choose PSTN phone or VOIP channel through star commands \*12 or \*21 to switch between normal telephone and VOIP.

**FXO:** In this mode, HTM series gateway's FXO port will work with FXO port state;

### 3.3.3.1.1 FXS Configuration

Click "FXS Setting", expand the page, configure all the parameters:

1. Choose the terminal mode H.323
2. Fill login information: Server address, Gatekeeper address, telephone number, H.323 ID. If need to fill certification information, please click "Enable Authentication", and fill the certification account and password.

Call Settings	
Endpoint Type	H.323 Phone <span>▼</span>
FXO Mode	PSTN By Pass <span>▼</span>
	<a href="#">FXS Calling Settings&lt;&lt;</a>
Phone Number	<input type="text"/>
H.323 ID	<input type="text" value=".test.dbl"/>
Gatekeeper Address	<input type="text" value="192.168.2.1"/>
	<input type="checkbox"/> Enable VOS/AVS Signaling Encryption
	<input checked="" type="checkbox"/> H.235 Auth
H.235 ID	<input type="text" value=".test.dbl"/>
Password	<input type="password" value="•••••"/>

HTM-112

Call Settings		Call Settings	
Endpoint Type	H.323 Phone	Endpoint Type	H.323 Phone
FXO Mode	PSTN By Pass	FXO Mode	PSTN By Pass
	FXS Calling Settings<<		FXS Calling Settings<<
Config by Line		Config by Line	
<input checked="" type="radio"/> Line 1	<input type="radio"/> Line 2	<input type="radio"/> Line 1	<input checked="" type="radio"/> Line 2
Phone Number		Phone Number	
H.323 ID	.test.1.	H.323 ID	.test.2
Gatekeeper Address	192.168.2.1	Gatekeeper Address	192.168.2.1
	<input type="checkbox"/> Enable VOS/AVS Signaling Encryption		<input type="checkbox"/> Enable VOS/AVS Signaling Encryption
	<input checked="" type="checkbox"/> H.235 Auth		<input type="checkbox"/> H.235 Auth
H.235 ID	.test.1.		
Password	•••••		

HTM-222

Call Settings		Call Settings	
Endpoint Type	H.323 Phone	Endpoint Type	H.323 Phone
FXO Mode	FXO	FXO Mode	FXO
	FXS Calling Settings<<		FXS Calling Settings<<
Config Mode		Config Mode	
<input checked="" type="radio"/> Line 1	<input type="radio"/> Line 2	<input type="radio"/> Line 1	<input checked="" type="radio"/> Line 2
<input type="radio"/> Line 3	<input type="radio"/> Line 4	<input type="radio"/> Line 3	<input type="radio"/> Line 4
Phone Number	196	Phone Number	197
H.323 ID	test.3	H.323 ID	test.4
Gatekeeper Address	192.168.2.1	Gatekeeper Address	192.168.2.1
	<input type="checkbox"/> Enable VOS/AVS Signaling Encryption		<input type="checkbox"/> Enable VOS/AVS Signaling Encryption
	<input checked="" type="checkbox"/> H.235 Auth		<input type="checkbox"/> H.235 Auth
H.235 ID	test.3		
Password	•••••		
	FXO Calling Settings>>		FXO Calling Settings>>

HTM\_442

3. As indicated in Figure, when choose H.323 protocol, you should choose “H.323 Terminal”. When several lines use the same number, choose “Single server mode”, when each line choose different numbers, choose “By wiring”. When choose “By wiring”, each line can login to different servers.

**A) H.323 telephone number**

Composed by a group of decimal number, use to certain the number in the Network. For example, 5551234 is a effective number, input this number in the bank. When login with telephone number, fill it; when login with number, you will hear dial-tone, then dial again.

**B) H.323 ID**

A mode of account certification, users can fill according to the service provider.

**C) Gatekeeper address**

Use to find right Gatekeeper, fill the IP: 192.168.2.1 or domain: **gk yourisp.com**. If your port is not the standard (1719, 1720), you can add the special port in the back of the IP or domain, for example: login with 7300: 192.168.2.1:7300 or **gk yourisp.com:7300**.

**Notes: Any character of the parameters should be filled with ASCII.**

**D) Use authentication**

Click “Enable authentication”, fill the bank in the corresponding option.

**3.3.3.1.2. FXO Configuration**

Click “FXO Configuration”, expand the page, configuration ways and parameters please refers to FXS Configuration.

Call Settings	
Endpoint Type	H.323 Phone <input type="button" value="v"/>
FXO Mode	FXO <input type="button" value="v"/>
	<a href="#">FXS Calling Settings&gt;&gt;</a>
	<a href="#">FXO Calling Settings&lt;&lt;</a>
Phone Number	<input type="text"/>
GateWay Prefix	<input type="text"/>
Display Name	<input type="text"/>
H.323 ID	<input type="text" value=".test.dbl"/>
Gatekeeper Address	<input type="text" value="192.168.2.1"/>
	<input type="checkbox"/> Enable VOS/AVS Signaling Encryption
	<input checked="" type="checkbox"/> H.235 Auth
H.235 ID	<input type="text" value=".test.dbl"/>
Password	<input type="password" value="•••••"/>

HTM-112

**Call Settings**

Endpoint Type: H.323 Phone

FXO Mode: FXO

FXS Calling Settings>>

FXO Calling Settings<<

Config Mode: Config by Line

Line 1  Line 2

Phone Number: 1945

H.323 ID:

GateWay Prefix: .dbl

Gatekeeper Address: 192.168.2.1

Enable VOS/AVS Signaling Encryption

H.235 Auth

**Call Settings**

Endpoint Type: H.323 Phone

FXO Mode: FXO

FXS Calling Settings>>

FXO Calling Settings<<

Config Mode: Config by Line

Line 1  Line 2

Phone Number: 1946

H.323 ID: .test

GateWay Prefix:

Gatekeeper Address: 192.168.2.1

Enable VOS/AVS Signaling Encryption

H.235 Auth

H.235 ID: .test

Password: ●●●●

HTM-222

**Call Settings**

Endpoint Type: H.323 Phone

FXO Mode: FXO

FXS Calling Settings>>

FXO Calling Settings<<

Config Mode: Config by Line

Line 1  Line 2  Line 3  Line 4

Phone Number: 1961

H.323 ID:

GateWay Prefix: .gateway

Gatekeeper Address: 192.168.2.1

Enable VOS/AVS Signaling Encryption

H.235 Auth

**Call Settings**

Endpoint Type: H.323 Phone

FXO Mode: FXO

FXS Calling Settings>>

FXO Calling Settings<<

Config Mode: Config by Line

Line 1  Line 2  Line 3  Line 4

Phone Number: 1962

H.323 ID: test.2

GateWay Prefix:

Gatekeeper Address: 192.168.2.1

Enable VOS/AVS Signaling Encryption

H.235 Auth

H.235 ID: test.2

Password: ●●●●

HTM-442

### 3.3.3.1.3 Configuration mode

When choose FXO, the configuration mode of FXS VOIP channel: 1) Single configure; 2) Configure by line; 3) Configure by group

- A) **Single Configure:** User can make several VOIP channel share the same configuration.
- B) **Configure by line:** Every VOIP channel can be supported service by different providers, also login 2 or 4 telephone numbers on the same server, each number is bundled with corresponding VOIP channel.
- C) **Configure by group:** In this mode, each group can bundled one or several lines, each line can exist in different groups. That is each line could login on 4 servers.

**Notes:** The special settings of 3 configuration mode refer to FXS configuration

### 3.3.3.1.4. Encryption

The Gateway is compatible of encryption of VOS and AVS, if need password, please enable it.

- A) **VOS Signaling Encryption:** Only make encryption on signaling.
- B) **VOS Signaling and Media Encryption:** Make encryption on the signaling and media.
- C) **AVS Signaling Encryption:** Only make encryption on signaling.
- D) **AVS Signaling and Media Encryption:** Only make encryption on signaling.

**Notes:** The 4 encryption modes only effective on VOS or AVS users, if you use other platform, you could use Firewall-penetrating technology Relay Agent by DBL. Special details .please refer to Firewall-penetrating.

### 3.3.3.2. H.323 Advanced Setting

HTM Gateway's advanced option, correspond "Advanced" and "Media". Click "Advanced", the page as following:



Advanced<<

RAS Port	<input type="text"/>
Q.931 Port	<input type="text"/>
H.245 Port	<input type="text"/>
Fast Start	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Register Mode	Register Multiple Nur <input type="button" value="v"/>
DTMF Signaling	Outband <input type="button" value="v"/>
Signaling QoS	None <input type="button" value="v"/>
Signaling NAT Traversal	None <input type="button" value="v"/>

Media Settings>>

**A) RAS Port**

RAS is communications protocol of Terminal and Gatekeeper, and state information of transferring login information, login information, broadband, and the relationship of the 2 H.323. This option can designate the UDP of this protocol, can be used by the router's port mapping.

**B) Call signaling port (Q.931)**

H.225-Q931 is call-control protocol of H.323, use to transfer the call-setting and uninstall information between the 2 H.323. This option can designate the terminal that receive the calling from Q.931 port, can be used by the router's port mapping.

**C) Media Control Port (H.245 Port)**

H.245 is media control port of H.323. This option can designate the Terminal that receive the calling from port connected to H.245, can be used by the router's port mapping.

**D) Quick Connect**

Use to check and solve compatibility problems. If uncertain, do not choose this option.

**E) Registration Mode**

Use to compatible different PBX, do not need to configure under normal circumstances.

Register Mode	Register Multiple Nur <input type="button" value="v"/>
DTMF Signaling	Register Multiple Numbe Register Multiple Times

**F) DTMF Signaling**

By using DTMF, the telephone transfer phone-signal to call clearinghouse by audio tape. That is to say, two different frequencies of sound are combined into 16 kind of tone. Telecommunications or telecom service hotline like 1860 identifies these special sounds by DSP, which use to certain the dial-number. DTMF has 2 styles: Inband and Outband.

DTMF Signaling	Outband <input type="button" value="v"/>
	Inband Outband

**1) Inband DTMF**

This style makes the special dial-tone together with talk-tone and transfer out without any treatment. So Inband only has one way to set DTMF signaling.


**2) Outband DTMF**

This style uses special methods and transfers the dial-tone to certain the correctness. The special methods are the called protocol, such as RFC2833.

**G) QOS Signaling**

QOS is network quality of service and ability of higher priority service that network supports, including dedicated broadband、control and delay jitter、packet loss rate improvement and so on. This option can label for QOS which is designated by call signaling packets, in order to improve the network quality of service.

Signaling QoS



### 3.3.3.3. SIP Protocol

SIP (Session Initiation Protocol) is identified by IETF, use to create, change and release the session of one or several participants. These sessions are like Internet Multimedia Conference, IP phone or Multimedia Distribution. The session participants could communicate by Multicast, Mesh Unicast, or mixture of the two.

If use SIP protocol, choose SIP Terminal, and enter SIP configuration page.

#### 3.3.3.3.1. FXS Configuration

Click “Call Setting” and enter, the FXS Configuration corresponds with FXS interface, and FXO Configuration corresponds with FXO interface.

**Call Settings**

Endpoint Type

FXO Mode

FXS Calling Settings<<

Phone Number

Display Name

SIP Proxy

SIP Registrar Server

Register Expiry

Outbound Proxy

Home Domain

Authentication ID

Password

Call Forward Type

Call Forward Number

Backup Server

HTM-112

**Call Settings**

Endpoint Type

FXO Mode

FXS Calling Settings<<

Config by Line

Line 1  Line 2

Phone Number

Display Name

SIP Proxy

SIP Registrar Server

Register Expiry

Outbound Proxy

Home Domain

Authentication ID

Password

Call Forward Type

Call Forward Number

Backup Server

**Call Settings**

Endpoint Type

FXO Mode

FXS Calling Settings<<

Config by Line

Line 1  Line 2

Phone Number

Display Name

SIP Proxy

SIP Registrar Server

Register Expiry

Outbound Proxy

Home Domain

Authentication ID

Password

Call Forward Type

Call Forward Number

Backup Server

HTM-222

Call Settings		Call Settings	
Endpoint Type	SIP Phone	Endpoint Type	SIP Phone
FXO Mode	PSTN By Pass	FXO Mode	PSTN By Pass
	FXS Calling Settings<<		FXS Calling Settings<<
Config by Line		Config by Line	
<input checked="" type="radio"/> Line 1	<input type="radio"/> Line 2	<input type="radio"/> Line 1	<input checked="" type="radio"/> Line 2
<input type="radio"/> Line 3	<input type="radio"/> Line 4	<input type="radio"/> Line 3	<input type="radio"/> Line 4
Phone Number	0101	Phone Number	0102
Display Name		Display Name	
SIP Proxy	192.168.2.1	SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1	SIP Registrar Server	192.168.2.1
Register Expiry	60	Register Expiry	300
Outbound Proxy		Outbound Proxy	
Home Domain		Home Domain	
Authentication ID	0101	Authentication ID	0102
Password	••••	Password	••••
Call Forward Type	Not Forward	Call Forward Type	Not Forward
Call Forward Number		Call Forward Number	
<input type="checkbox"/> Backup Server		<input type="checkbox"/> Backup Server	

HTM-442

Click FXS Configuration, expand the configuration interface, and set all the parameter of the HTM\_442. Two kinds of VOIP Channel formats: 1) By wiring; 2) Single-server mode. The default is “By wiring”, as following figure:

In this mode, there are more advance settings of VOIP Channel. At first, the four VOIP channels can be supported service by different providers. Secondly, you could login four different numbers by one provider, make one of numbers bundle with one VOIP channel.

**A) Telephone number**

Use to fill numbers of this line. This number indicates that called is the only parameter identification.

**B) SIP Proxy**

Use to fill address of SIP Proxy. If your SIP Proxy is special port (is not the default 5060), you can notes in the back of IP Proxy or Domain. Such as: 192.168.2.1:5070 or tester.com.cn:5070.

**C) SIP Registration Server**

Use to register account for the Gateway, and fill the IP or Domain of SIP Registration Server. If your server is special port (is not the default 5060), you can notes in the back of IP Proxy or Domain. Such as: 192.168.2.1:5070 or tester.com.cn:5070.

**D) Outbound Proxy**

Exist in the firewall/NAT. It is used to make signaling and stream can penetrate the firewall.

**E) Ownership of the domain**

Use to manage the Domain Management Host of SIP protocol.

**F) Certification ID**

Use to fill the certification account that the Gateway logs on the SIP registration server.

**G) Password**

Use to fill the certification password when the Gateway logs on the SIP registration server.

**H) Display Name**

When you call your friend John, then his phone will show you call.

**D) Backup Server**

Backup Server

Backup SIP Proxy

Backup SIP Registrar Server

Backup Home Domain

[FXO Calling Settings>>](#)

Use to register backup, when user have a Backup registration server, then can choose this option. If the Backup registration server is enable, while the main server is failure unexpectedly, the Gateway will register to the Backup server automatically.

Other lines configuration is the same.

If want to configure the four VOIP channel the same, you could choose “Single-server mode”, as follows:

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	FXO
<a href="#">FXS Calling Settings&lt;&lt;</a>	
Phone Number	261
Display Name	
SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1
Register Expiry	300
Outbound Proxy	
Home Domain	
Authentication ID	132
Password	...
Call Forward Type	Not Forward
Call Forward Number	
<input checked="" type="checkbox"/> Backup Server	

Specific parameters configuration please refers to “By wiring”.

### 3.3.3.3.2. FXO Configuration

Click FXO Configuration, open the interface, setting mode is the same as FXS. When VOIP inbound, it will adapter to PSTN; if PSTN inbound, then adapters to VOIP.

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	PSTN By Pass
FXS Calling Settings<<	
Phone Number	0088
Display Name	
SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1
Register Expiry	300
Outbound Proxy	
Home Domain	
Authentication ID	0088
Password	•••••
Call Forward Type	Not Forward
Call Forward Number	
<input type="checkbox"/> Backup Server	

HTM-112

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	FXO
	FXS Calling Settings>>
	FXO Calling Settings<<
Config Mode	Single Mode
Phone Number	199
Display Name	
SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1
Register Expiry	300
Outbound Proxy	
Home Domain	
Authentication ID	199
Password	●●●
	<input type="checkbox"/> Backup Server

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	FXO
	FXS Calling Settings>>
	FXO Calling Settings<<
Config Mode	Config by Line
	<input checked="" type="radio"/> Line 1 <input type="radio"/> Line 2
Phone Number	199
Display Name	
Gateway Prefix	
SIP Proxy	192.168.2.1
SIP Registrar Server	102.168.2.1
Register Expiry	300
Outbound Proxy	
Home Domain	
Authentication ID	199
Password	●●●●
	<input type="checkbox"/> Backup Server

HTM-222

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	FXO
	FXS Calling Settings>>
	FXO Calling Settings<<
Config Mode	Single Mode
Phone Number	1912
Display Name	
SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1
Register Expiry	60
Outbound Proxy	
Home Domain	
Authentication ID	1912
Password	●●●●
	<input type="checkbox"/> Backup Server

Call Settings	
Endpoint Type	SIP Phone
FXO Mode	FXO
	FXS Calling Settings>>
	FXO Calling Settings<<
Config Mode	Config by Line
	<input checked="" type="radio"/> Line 1 <input type="radio"/> Line 2 <input type="radio"/> Line 3 <input type="radio"/> Line 4
Phone Number	1912
Display Name	
Gateway Prefix	
SIP Proxy	192.168.2.1
SIP Registrar Server	192.168.2.1
Register Expiry	300
Outbound Proxy	
Home Domain	
Authentication ID	1912
Password	●●●●
	<input type="checkbox"/> Backup Server

HTM-442

### 3.3.3.3.3. Configuration Mode

When choose FXO, the configuration mode of FXS VOIP channel: 1) Single configure; 2) Configure by line; 3) Configure by group

- A) Single Configure:** User can make several VOIP channel share the same configuration.
- B) Configure by line:** Every VOIP channel can be supported service by different providers, also login 2 or 4 telephone numbers on the same server, each number is bundled with corresponding VOIP channel.
- C) Configure by group:** In this mode, each group can bundled one or several lines, each line can exist in different groups. That is each line could login on 4 servers.

**Notes:** **The special settings of 3 configuration mode refer to FXS configuration**

### 3.3.3.3.4. SIP Advanced Configuration

SIP advanced option, correspond “Advanced” and “Media”. Click “Advanced” and “Media”, the page as following:

#### A) Signaling Port

SIP local port is the local UDP port, use to communicate with SIP proxy or other SIP users.

#### B) NAT Keep

Use to keep the port when NAT communicate with SIP signaling, its unit is seconds.

#### C) DTMF Signaling

By using DTMF, the telephone transfer phone-signal to call clearinghouse by audio tape. That is to say, two different frequencies of sound are combined into 16 kind of tone. Telecommunications or telecom service hotline like 1860 identifies these special sounds by DSP, which use to certain the dial-number. DTMF has 2 styles: Inband and Outband.

#### 1) Inband DTMF



This style makes the special dial-tone together with talk-tone and transfer out without any treatment. So Inband only has one way to set DTMF signaling.

## 2) Outband DTMF

This style uses special methods and transfers the dial-tone to certain the correctness. The special methods are the called protocol, such as RFC2833.

DTMF Signaling	Outband
Outband DTMF type	RFC 2833
RTP Payload Type	RFC 2833
	SIP INFO

## D) QOS Signaling

QOS is network quality of service and ability of higher priority service that network supports, including dedicated broadband、control and delay jitter、packet loss rate improvement and so on. This option can label for QOS which is designated by call signaling packets, in order to improve the network quality of service.

Signaling QoS	None
	None
	IP TOS
	DiffServ

## E) Signaling Encryption

- a) **None:** Not encrypted.
- b) **RC4:** This is a variable key length stream encryption algorithm clusters, its S-box is random, generally 256 bytes.
- c) **Fast:** a long delay for high-speed networks, TCP Congestion Control Protocol, require server-side support.
- d) **VOS:** For VOS users.
- e) **AVS:** For AVS users.
- f) **N2C:** For N2C users.
- g) **ECM:** For ECM users.
- h) **ET263:** For ET263 users.

## F) NAT Signaling Penetration.

Special configurations please refer to firewall.

### 3.3.3.3.5. Media Advanced Configuration

Media Advanced Configuration Aimed at the gateway RTP media stream part of the advanced configuration options, click “Media” in the “call setting”.

#### A) KTP Port (range)

Use to designate the UDP of Real-Time Media Transfer Protocol (RTP), used with the router’s port mapping.


**Notes:** The terminal use several pairs of RTP, its value is the port range, such as

(5500-5520).

**B) RTP Packet Length**


The default time length of each wet packet is 20ms. Use to designate the size of media-packet, the unit is sampling time ms.

**C) Jitter delay processing mode**



Use to designate Jitter delay buffer algorithm model. Adaptive mode is the best, other modes are used for test, please do not use in the practical action.


**D) Media Encryption**




- a) **None:** Not encrypted.
- b) **RC4:** This is a variable key length stream encryption algorithm clusters, its S-box is random, generally 256 bytes.
- c) **ET263:** For ET263 users.

**E) Media QOS**

QOS is network quality of service and ability of higher priority service that network supports, including dedicated broadband、control and delay jitter、packet loss rate improvement and so on. This option can label for QOS which is designated by call signaling packets, in order to improve the network quality of service.



**F) Speech coding and sequencing**



【√】 indicate that coding is available, UP and DOWN on the currently selected voice compression coding to adjust priorities.


### 3.3.3.4. Firewall Traversal

In the advanced configuration of call settings, signal and media each has firewall configuration.

#### 3.3.3.4.1. H.323 Signaling NAT Traversal

There are four styles as follows:

Signaling NAT  
Traversal



**A) None**

Select **None** to turn off this feature.

**B) Nat Citron**


**Citron** is a dedicated firewall penetration agreement for GNUGK.

**C) Port Transparent/DMZ**

**Port Transparent** refers that put network port of the LAN into computer or inside of the LAN. The actual servers allow external users enjoy the servers of internal server(FTP、HTTP、Telnet) .

Port Transparent includes the Gateway address and response server address. Gateway is communications equipment that connect two different networks, response to the server is standard service equipment that perform ECHO protocol.

Signaling NAT  
Traversal



**D) Relay proxy**

**Relay proxy** is a proprietary NAT traversal technology. It includes relay proxy server address, port, username, and password.

Relay proxy makes encryption on the Gateway's communication, this function need the support of DBL. technology.

Signaling NAT Traversal	Relay Proxy
Address	202.96.136.145
Port	21080
User	111
Password	●●●
	<input checked="" type="checkbox"/> Encryption
Relay Mode	1

### 3.3.3.4.2. SIP Signaling NAT Traversal

SIP Signaling NAT Traversal has 3 kinds:

Signaling NAT Traversal	<div style="border: 1px solid #ccc; padding: 2px;"> <div style="background-color: #f0f0f0; padding: 2px;">None</div> <div style="background-color: #0056b3; color: white; padding: 2px;">None</div> <div style="padding: 2px;">STUN(RFC 3489)</div> <div style="padding: 2px;">Relay Proxy</div> </div>
-------------------------	---

#### A) None

Select **None** to disable this feature.

#### B) STUN (RFC 3489)

**STUN (Simple Traversal of UDP (User Datagram Protocol) through NATS (Network Address Translators))** is a network protocol allowing a client behind a NAT (or multiple NATS) to find out its public address, the type of NAT it is behind and the internet-side port associated by the NAT with a particular local port.

Select STUN (RFC 3489) to use a STUN server for Signaling NAT Traversal. Enter the IP Address or the domain name of the STUN server to be used.

Signaling NAT Traversal	STUN(RFC 3489)
STUN Server	

#### C) Relay Proxy

**Relay proxy** is a proprietary NAT traversal technology. Please consult your service provider for more information. It includes relay proxy server address, port, username, and password.

Relay proxy makes encryption on the Gateway's communication, this function need the support of DBL. technology.

Currently, the following 3 kinds of packaging mechanism are supported.

Signaling NAT Traversal	Relay Proxy
Address	202.96.136.145
Port	21080
User	111
Password	•••
	<input checked="" type="checkbox"/> Encryption
Relay Mode	1

### 3.3.3.4.3. Media NAT Traversal

Similar to Signaling NAT Traversal, this feature allows media packets (RTP) to be routed properly in various network environments.

Media NAT Traversal	None
	None
	STUN(RFC 3489)
	Port-forward/DMZ
	Relay Proxy

#### A) NONE

Select **None** to disable this feature.

#### B) Port Transparent/DMZ

**Port Transparent** refers that put network port of the LAN into computer or inside of the LAN. The actual servers allow external users enjoy the servers of internal server(FTP、HTTP、Telnet).It contains Gateway address and the responding to the server's address. Gateway is communications equipment that connect two different networks, response to the server is standard service equipment that perform ECHO protocol.

#### C) STUN(RFC3489)

**STUN (Simple Traversal of UDP (User Datagram Protocol) through NATS (Network Address Translators))** is a network protocol allowing a client behind a NAT (or multiple NATS) to find out its public address, the type of NAT it is behind and the internet-side port associated by the NAT with a particular local port.

Select STUN (RFC 3489) to use a STUN server for Signaling NAT Traversal. Enter the IP Address or the domain name of the STUN server to be used.

#### D) Relay Proxy

**Relay proxy** is a proprietary NAT traversal technology. Please consult your service provider for more information.

Currently, the following 3 kinds of packaging mechanism are supported:

- **Mode 1: The media uses UDP packets and (or) encrypt with multiple UDP port;**
- **Mode 2: The media uses UDP packets and (or) encrypt with single UDP port;**
- **Mode 3: The media uses TCP packets and (or) encrypt (UDP over TCP).**

### 3.3.4. FXS Setting

FXS Settings	
<input checked="" type="radio"/> Line 1	
Dial Plan	<input type="text"/>
Hot Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
FXS 48v Standby	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Hold Function	<input type="text" value="*42"/>
Transfer Function	<input type="text" value="*41"/>
Call Hold	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Call Transfer	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
NET Down Live Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Billing Support	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Ring Parameters>>	

HTM-112

FXS Settings	
<input checked="" type="radio"/> Line 1 <input type="radio"/> Line 2	
Dial Plan	<input type="text"/>
Hot Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
FXS 48v Standby	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Hold Function	<input type="text" value="*42"/>
Transfer Function	<input type="text" value="*41"/>
Call Hold	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Call Transfer	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
NET Down Live Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Billing Support	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Ring Parameters>>	

HTM-222

FXS Settings	
<input checked="" type="radio"/> Line 1 <input type="radio"/> Line 2 <input type="radio"/> Line 3 <input type="radio"/> Line 4	
Dial Plan	<input type="text"/>
Hot Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
FXS 48v Standby	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Hold Function	<input type="text" value="*42"/>
Transfer Function	<input type="text" value="*41"/>
Call Hold	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Call Transfer	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
NET Down Live Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Billing Support	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Ring Parameters>>	

HTM-442

**Dialing rules:** see the dialing rules

**Hotline:** dial number when pull the phone

**Key Hold:** in the state of “Enable call”, you can stop talking by pressing “\*42”

**Key Transfer:** Enable and press \*41, then input telephone number, you can achieve Call transfer.

**Call Hold:** Enable it.

**Call prequel:** Enable call transfer

**Net off escape:** After enable it, when the Net off or fail to login VOIP, FXS mentioned Machine will put up PSTN outline.

NET Down Live Line  Enable  Disable

**Use of billing:** you can bill all the lines by using DBL technology billing software.

Billing Support  Enable  Disable  
Billing Server   
Ring Parameters>>

**Notes:** Every line should be set separately.

### 3.3.5. FXO Setting

FXO Setting make users get practical function, its real is making calls adapter to responding number, and reduce calling time. What is more, routing setting also support password protection of “PSTN call IP” and “IP call PSTN”, but only authorized persons can use. **Please do not fill when you need not these functions.**

- 1. VOIP call the Gateway adapter to the standard phone, fill “Hotline number” in the “call PSTN adapter number”.

FXO Settings	
<input checked="" type="radio"/> Line1	
Forward to PSTN	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Forward Number (VoIP To PSTN)	<input type="text" value="88290211"/>
Forward Password (VoIP To PSTN)	<input type="text" value="1234"/>
Dial Plan(VoIP to PSTN)	<input type="text"/>
Forward to VoIP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Forward Number (PSTN To VoIP)	<input type="text" value="3306"/>
Forward Password (PSTN To VoIP)	<input type="text" value="1234"/>
Dial Plan(PSTN to VoIP)	<input type="text"/>
VoIP Auto Answer Time(s)	<input type="text" value="5"/>
PSTN Has Live Reversal	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
IVR	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

- a) As indicated in Figure, when IP calls HTM\_442, the Gateway will dial 88290211 directly, this function is very useful for the “Hotline” service.  
If the password needed when VOIP calls PSTN, then fill the password in the “dial PSTN certification password”.

Forward Password (VoIP To PSTN)	<input type="text" value="1234"/>
Dial Plan(VoIP to PSTN)	<input type="text"/>

b) As indicated in figure, when IP calls HTM\_442, HTM\_442 will give beep, only users input the password (1234) correctly can you get PSTN dial-tone and dial.

2. PSTN calls adapters to VOIP special number, fill the adapter number in the “call VOIP adapter number”.

Forward to VoIP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Forward Number (PSTN To VoIP)	<input type="text" value="3306"/>
Forward Password (PSTN To VoIP)	<input type="text" value="1234"/>
Dial Plan(PSTN to VoIP)	<input type="text"/>
VoIP Auto Answer Time(s)	<input type="text" value="5"/>
PSTN Has Live Reversal	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
IVR	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

a) As indicated in Figure, when PSTN calls, the phone will ring firstly in the Auto-Answer time, then dial VOIP 3306 terminal, then the two phones ring at the same time, when answer, HTM\_442 connected, the other phone stop ring. This function make persons who roam around the world can answer phone everywhere.

Dial VOIP certification password: if need password when PSTN calls VOIP, then fill the password in the “dial VOIP certification password”.

Forward Password (VoIP To PSTN)	<input type="text" value="1234"/>
Dial Plan(VoIP to PSTN)	<input type="text"/>

b) As indicated in Figure, when PSTN calls HTM\_442, HTM\_442 will give beep, only users input the password (1234) correctly can you get VOIP dial-tone and dial.

**Notes: The configuration of HTM-222 and HTM-442 is the same as HTM-112.**

### 3.3.6. Save Changes

When you finish settings, click “save change” save all the settings.



Status		FXS Settings		
<b>Configurations</b> Preferences Network Call Settings FXS Settings FXO Settings <b>Save Changes</b> Discard Changes	<input checked="" type="radio"/> Line 1	Hold Function	*42	
	Dial Plan		Transfer Function	*41
	Hot Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	Call Hold	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
	FXS 48v Standby	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	Call Transfer	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			NET Down Live Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			Billing Support	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			Ring Parameters>>	

### 3.3.7. Abandon changes

If your new settings are not saved, you can clean all the unsaved new parameters.

Status		FXS Settings		
<b>Configurations</b> Preferences Network Call Settings FXS Settings FXO Settings Save Changes <b>Discard Changes</b>	<input checked="" type="radio"/> Line 1	Hold Function	*42	
	Dial Plan		Transfer Function	*41
	Hot Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	Call Hold	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
	FXS 48v Standby	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	Call Transfer	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			NET Down Live Line	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			Billing Support	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
			Ring Parameters>>	

## 4. Tools

### 4.1. Online Upgrade

Online Upgrade	
Last Upgrade Time: 2009-12-16 10:33:44	
Current Version: OSS-3.03-10	
Upgrade Site:	<input type="text" value="192.168.2.1/update/OSS-3.03-10.pkg"/> <input type="button" value="Start"/>

Page shows current version information, input upgrade address, click start, wait after upgrade and start again. When the page shows “Upgrade successful”, click “OK”.

**Notes:** Please keep in touch with the company’s technology support, in case that get the latest information and upgrade address.

## 4.2. Change Password

The image shows two sections for changing passwords. The first section, titled "User Level", has a dark blue header. Below it are two text input fields: "New Password:" and "Confirm Password:". To the right of the "Confirm Password:" field is a button labeled "Change". The second section, titled "Administration Level", also has a dark blue header and follows the same layout with "New Password:", "Confirm Password:", and a "Change" button.

Include "Ordinary user-level" (user) and "Administrator Class" (admin), input the new password two times, click "change" is ok.

## 4.3. Restore factory settings



If you make sure that clean all configurations, click "OK", wait start again. If not, click "Cancel", back to current page.

**Notes: All the users' personal configuration include new changed password will be cleaned.**

You also finish these by pressing "RESET" in a long time.

## 4.4. Reboot the system



If you are sue to reboot the system, click “OK”, if not, then click “Cancel”, back to current page. Point the “RESET” gently with Small needle-like objects, then HTM\_442 will reboot.

**Notes: Press the “RESET” will lead HTM\_442 restore factory settings, all the parameters that users configure will be cleaned.**

## 5. Dialing Rules

Dialing rules make users configure number rules flexible, its expressions are:

Prefix: Action | Prefix: Action

Prefix is in front of the called number. “:” is Actions associated with Fu. “[” is Separator, separates different prefix. Matching sequence is longest match.

For example: the Gateway is connected to extension line, fill “0755:-0755+9,|07551:-0755” in PSTN, which indicates that dial 0755 Gateway, deleted (-0755) dial “9” to get outside line, then dial the remaining numbers after 0.5 seconds. If Dial 07551, which indicates that you dial inside number, the Gateway will dial the extension number.

Dial Plan

0:|13:+0|[2-8]:+0755

### 5.1. Basic rules of grammar

1. Rules can be separated by “[”, such as “00:-00|0|-0+86|:+86755”
2. Rules are matched by Sit-to-right, when encounter appropriate one, end the match immediately, or continue next one.
3. Syntax rules is “AA: -aa+bb”, such as “0:-0+86”, “AA” is the matching numbers, in the back of the colon is the corresponding concrete operation. If succeed, minus “aa” and “bb”, if not, continue next one. If the back of colon without operation, such as “00:”, do not make any operation and exit. If in front of the colon without string, such as “:+86755”, do operation.
4. Dialing rules have no range, its syntax rule is “[A-B]A:-aa+bb” or “A[A-B]:-aa+bb”. For example: The range of 2 to 8 is that: “[2-8]:-aa+bb” or 13 to 15 is “1[3-5]:-aa+bb”.

Such as:

1. Rules: “0:|:0755”.
  - a. Input “02083185711”, output “02083185711”;
  - b. Input “83185700”, output “075583185700”.
2. Rules: “00:-00|0”-0+86|:+86755“.
  - a. Input “008522343318”, output “8522343318”;
  - b. Input “02083185711”, output “862083185711”;
  - c. Input “83185700”, output “8675583185700”.
3. Rules: “00:|0:-0+086|:+0086755”.

- a. Input“008522343318”, output“008522343318”;
- b. Input“02083185711”, output“00862083185711”;
- c. Input“83185700”, output“008675583185700”.

4. Rules: “0:|1 [3-9]:+0|[2-8]:+0755|:+0755”.
- a. Input“076322343318”, output“076322343318”;
  - b. Input“13044557766”, output“013044557766”;  
or“13644557766”, output“013644557766”
  - c. Input“23185700”, output“075523185700”.  
Or“73185700”, output“075573185700”

## 5.2. With a limited number of digit dialing rules

If you want to do restriction on every phone number, the dialing number of **HT-3040** is configured as “AAXXXXXXX:-aa+bb”, AAXXXXXXX is the matched number and its length. Other numbers are instead of “X” or “x” except of “AA”; In the back of colon is the corresponding concrete operation of this number.

The configurations as following:

Like the above 3. “00:|0:-0+0086|:+0086755”.

Change like this “00:|0:-0+0086|[1-8]xxxxxxx:+0086755”.

The length is 8 if you dial the number that the beginning are 1 to 8, the Gateway will dial the number automatically add “0086755”. Or:

“0:|13:+0|:+0755”

Then add “0” in front of mobile number, and “0755” in front of city telephone number.

Change like this “0:|13 [0-9] xxxxxxxx:+0755”

This rule is like above, but the length of mobile number is limited 11.

As indicated above, the length of city telephone number is limited 8. 13[0-9] xxxxxxxx and [1-8] xxxxxxxx indict 130xxxxxxx to 139xxxxxxx and 1xxxxxxx to 8xxxxxxx.

**Notes:** After using the median number of definitions, the length of number is longer than the definition, then the superfluous numbers will be discarded, for example:

“0:|13[0-9]xxxxxxx:+0|[1-8]xxxxxxx:+0755”

The number is 075588990011.

## 6. Understand More

### 6.1. Gateway Initialization

When forget the password, users can press (more than 10 seconds) RESET or input \*11983185922, restore factory configuration.

## 6.2. Advanced Configuration

There are many configuration options in the advanced configuration, such as Agent Services, Speech Coding sequence and so on, if you are familiar with our product, you can configure directly, if not, please view our detailed description, or search our technology support: [support@at338.com](mailto:support@at338.com)

## 6.3. Notes

- a) When using HTM\_442, please notice that outside whether overhead line or not, take measures of lightning (purchase Lightning All, or put Lightning Terminal on the Wire frame).
- b) HTM\_442 has a certain degree of heat, please ventilate and do not cover flammable liquids.
- c) HTM\_442 has line detection, if line is not connected well, then break when you dial the Gateway.
- d) HTM\_442 has fast switch polarity detection function, which can prevent line hanging death and improve the Gateway's time to hang up.
- e) When device is upgrading, please notice that **absolutely you can not turn off the power**, or, the device will scrap!