# C C eration and Maintenance Man

Installation, Operation and Maintenance Manual for the

# PCM-875A Plasmarc Mechanized Cutting System



The equipment described in this manual is potentially hazardous. Use caution when installing, operating and maintaining this equipment.

Purchaser is solely responsible for the safe operation and use of all products purchased, including compliance with OSHA and other government standards. ESAB Cutting Systems has no liability for personal injury or other damage arising out of the use of any product manufactured or sold be ESAB. See standard ESAB terms and conditions of sale for a specific statement of ESAB's responsibilities and limitations on its liability.

ESAB Cutting Systems first priority is total customer satisfaction. We constantly look for ways to improve our products, service and documentation. As a result, we make enhancements and/or design changes as required. ESAB makes every possible effort to ensure our documentation is current. We cannot guarantee that each piece of documentation received by our customers reflects the latest design enhancements. Therefore, the information contained in this document is subject to change without notice.

This manual is ESAB Part Number F15753

This manual is for the convenience and use of the cutting machine purchaser. It is not a contract or other obligation on the part of ESAB Cutting Systems.

© ESAB Cutting Systems, 2002

Printed in U.S.A.

Section 1 Safety	Page 1-(_)
1.1 Introduction	1
1.2 Safety Notations And Symbols	2
1.3 General Safety Information	3-4
1.4 Installation Precautions	4
1.5 Electrical Grounding	5
1.6 Operating A Plasma Cutting Machine	5-8
1.7 Service Precautions	9-10
1.8 Safety References	11-16
1.8.1 National Standards	11
1.8.2 International Standards	12-16

Section 2 Description	Page 2-(_)
2.1 General	1
2.2 PCM-875A Power Console	1
2.2.1 Technical Specifications – PCM-875A	1
2.2.2 Dimensions and Weight	2
2.3 Remote Arc Starter (RAS2)	3
2.3.1 Technical Specifications	3
2.3.2 Dimensions and Weight	3
2.4 PT-20AMX Torch	4
2.4.1 Technical Specifications	4
2.4.2 Dimensions and Weight	5
2.4.3 Torch Spare Parts Kit	6

Section 3 Installation	Page 3-( )
	l age 5-(_)
	I
3.2 Installation of power console	1
3.2.1 Requirements	1
3.2.2 Location	2
3.2.3 Inspection before installation	2
3.2.4 Primary Electrical Input Connections	3
3.2.5 Connection of Plasma Console to CNC Interface	4
3.2.6 Secondary (Output) Connection	5-8
3.3 Connection of Remote Arc Starter (RAS2)	9
3.3.1 Mounting	9
3.3.2 Connecting Service Lines (Input)	10
3.3.3 Setting Spark Gap	11
3.3.4 RAS2 Output Connections	12
3.3.5 Termination of Torch Shield Braid	13-14
3.4 Installing Front-end torch Parts	15-17
3.5 Interconnecting Diagram	18-19

Section 4 Operation	Page 4-(_)
4.1 PCM-875A Console Operation General	1
4.2 Console Controls	2-3
4.3 RAS2	3
4.4 PT-20AMX Plasma Torch	4
4.5 Cut Quality	5
4.5.1 Introduction	5
4.5.2 Cut Angle	6
4.5.3 Cut Flatness	7
4.5.4 Surface Finish (Roughness)	8
4.5.5 Dross	9-10
4.5.6 Dimensional Accuracy	10-11
4.6 Process Data	11-23

Section 5 Maintenance	Page 5-(_)
5.1 PCM-875A Console	1
5.1.1 General	1
5.1.2 Inspection and Cleaning	2-3
5.1.3 Flow Switch	4
5.2 RAS2 (Remote Arc Starter)	5
5.2.1 General	5
5.2.2 Spark Gap Procedure	5
5.3 PT-20AMX Plasmarc Torch	6
5.3.1 General	6
5.3.2 Dirt or Contamination	7
5.3.3 Loose Consumables	7
5.3.4 Damage Caused by Loose Parts or Overheating	8
5.3.5 Consumables- Remove and Replace	8-10
5.3.6 Measuring Torch Gas Flows	10
5.3.7 Removal and Replacement of the Torch Body	11

Section 6 Troubleshooting	Page 6-(_)
6.1 Troubleshooting PCM-875A Plasmarc System	1
6.2 Console	2-8
6.2.1 Power Light (PL1) does not come on	2
6.2.2 No Air Flow	2
6.2.3 Power Light is on but nothing happens when signal is given to fire with no fault light	3
6.2.4 Fault light activates when torch fire signal is given	4-5
6.2.5 Air is on but nothing happens when torch fire signal is given	6
6.2.6 High Frequency and Pilot Arc are on but no main arc transfer	7
6.2.7 Poor Cutting Performance	7
6.2.8 Air does not shut off	7
6.2.9 Main arc difficult to start	8
6.3 Reference Voltage Checks	9
6.4 PT-20AMX Torch Troubleshooting10	10-11
6.4.1 Insufficient Penetration	10
6.4.2 Main Arc Extinguishes	10
6.4.3 Dross Formation	10
6.4.4 Double Arcing	11
6.4.5 Uneven Arc	11
6.4.6 Unstable Cutting Conditions	11
6.4.7 Main Arc Does Not Strike	11
6.4.8 Poor Consumable Life	11
6.5 230V Power Console Electrical Drawings	12-17
6.5.1 Schematic	12-13
6.5.2 Wiring Diagrams	14-17
6.6 400V Power Console Electrical Drawings	18-23
6.6.1 Schematic	18-19
6.6.2 Wiring Diagrams	20-23
6.7 Remote Arc Starter Schematic	24

Section 7 Replacement Parts	Page 7-(_)
7.1 General	1
7.2 Ordering	1
7.3 PCM875A Power Console – 230V	2-9
7.4 PCM-875A Power Console – 400V	10-18
7.5 Remote Arc Starter	19-21
7.6 PT-20AMX Plasmarc Cutting Torch	22-25
Customer/Technical Information	Back Manual Cover

#### 1.1 Introduction

The process of cutting metals with plasma equipment provides industry with a valuable and versatile tool. ESAB cutting machines are designed to provide both operation safety and efficiency. However, as with any machine tool, sensible attention to operating procedures, precautions, and safe practices is necessary to achieve a full measure of usefulness. Whether an individual is involved with operation, servicing, or as an observer, compliance with established precautions and safe practices must be accomplished. Failure to observe certain precautions could result in serious personnel injury or severe equipment damage. The following precautions are general guidelines applicable when working with cutting machines. More explicit precautions pertaining to the basic machine and accessories are found in the instruction literature. For a wide scope of safety information on the field of cutting and welding apparatus, obtain and read the publications listed in the Recommended References.

SECTION 1 PCM-875A Mechanized	Plasma Cutting System SAFETY
1.2 Safety Notations And Symbols	The following words and symbols are used throughout this manual. They indicate different levels of required safety involvement.
	ALERT or ATTENTION. Your safety is involved or potential equipment failure exists. Used with other symbols and information.
	Used to call attention to immediate hazards which, if not avoided, will result in serious personal injury or loss of life.
	Used to call attention to potential hazards that could result in personal injury or loss of life.
	Used to call attention to hazards that could result in minor personal injury or equipment damage.
	7
CAUTION	Used to call attention to minor hazards to equipment.
	Used to call attention to important
NOTICE	installation, operation or maintenance information not directly related to safety hazards.

#### SECTION 1 PCM-875A Mechanized Plasma Cutting System

SAFETY

#### 1.3 General Safety Information

## NOTICE

Some subjects listed are not related specifically to the type of equipment covered in this manual. However, the safety principles still apply. They are offered as a reminder that this equipment or related apparatus should be operated with alertness and understanding. Safety of operators, technicians, maintenance workers and observers should not be taken for granted.

## 



#### Machinery may start automatically.

Equipment positioning mechanized plasma torch moves in various directions and speeds.

- Moving machinery can crush.
- Only qualified personnel should operate or service this power source.
- Keep all personnel, materials, and equipment not involved in production process clear of entire system area.
- Fence off entire work cell to prevent personnel from passing through area or standing in the working envelope of the equipment.
- Post appropriate WARNING signs at every work cell entrance.
- Follow lockout procedure before servicing any equipment.

# 



## Failure to follow operating instructions could result in death or serious injury.

Read and understand this operator's manual before using machine.

- Read entire procedure before operating or performing any system maintenance.
- Special attention must be given to all hazard warnings that provide essential information regarding personnel safety and/or possible equipment damage.
- All safety precautions relevant to electrical equipment and process operations must be strictly observed by all having system responsibility or access.
- Read all safety publications made available by your company.

# 



# Failure to follow safety warning label instructions could result in death or serious injury.

Read and understand all safety warning labels on machine.

Refer to operator's manual for additional safety information.

#### **1.4 Installation Precautions**

# 

#### Improperly Installed Equipment Can Cause Injury Or Death.

Follow these guidelines while installing machine:

- Contact your ESAB representative before installation. He can suggest certain precautions regarding piping installation and machine lifting, etc. to ensure maximum security.
- Never attempt any machine modifications or apparatus additions without first consulting a qualified ESAB representative.
- Observe machine clearance requirements for proper operation and personnel safety.
- Always have qualified personnel perform installation, troubleshooting and maintenance of this equipment.
- Provide a wall mounted disconnect switch with proper fuse sizes close to the power supply.

#### SECTION 1 PCM-875A Mechanized Plasma Cutting System

#### **1.5 Electrical Grounding**

Electrical grounding is imperative for proper machine operation and SAFETY. Refer to this manual's Installation section for detailed grounding instructions.

# A WARNING

## Electric shock hazard.

Improper grounding can cause severe injury or death.

Machine must be properly grounded before put into service.

#### 1.6 Operating A Plasma Cutting Machine

	Flying debris and loud noise hazards.
	<ul> <li>Hot spatter can burn and injure eyes. Wear goggles to protect eyes from burns and flying debris generated during operation.</li> </ul>
	<ul> <li>Chipped slag may be hot and fly far. Bystanders should also wear goggles and safety glasses.</li> </ul>
	<ul> <li>Noise from plasma arc can damage hearing. Wear correct ear protection when cutting above water.</li> </ul>
	Burn hazard.
<b>M</b> WARNING	Hot metal can burn.
	<ul> <li>Do not touch metal plate or parts immediately after cutting. Allow metal time to cool, or douse with water.</li> </ul>
	<ul> <li>Do not touch plasma torch immediately after cutting. Allow torch time to cool.</li> </ul>

#### PCM-875A Mechanized Plasma Cutting System

## A WARNING



# Hazardous voltages. Electric shock can kill.

- Do NOT touch plasma torch, cutting table or cable connections during plasma cutting process.
- Always turn power off to plasma power supplies before touching or servicing plasma torch.
- Always turn power off to plasma power supplies before servicing any system component.
- Do not touch live electrical parts.
- Keep all panels and covers in place when machine is connected to power source.
- Wear insulating gloves, shoes and clothing to insulate yourself from workpiece and electrical ground.
- Keep gloves, shoes, clothing, work area, and equipment dry.
- Replace worn or damaged cables.

# 



## Fume hazard.

Fumes and gases generated by the plasma cutting process can be hazardous to your health.

- Do NOT breathe fumes.
- Do not operate plasma torch without fume removal system operating properly.
- Use additional ventilation to remove fumes if necessary.
- Use approved respirator if ventilation is not adequate.
- Provide positive mechanical ventilation when cutting galvanized steel, stainless steel, copper, zinc, beryllium, or cadmium. Do not breathe these fumes.
- Do not operate near degreasing and spraying operations. Heat or arc rays can react with chlorinated hydrocarbon vapors to form phosgene, a highly toxic gas and other irritant gases.

	Radiation hazard.
A WARNING	Arc rays can injure eyes and burn skin.
	Wear correct eye and body protection.
	• Wear dark safety glasses or goggles with side shields. Refer to following chart for recommended lens shades for plasma cutting:
	Arc Current Lens Shade
	Up to 100 Amps Shade No. 8
	100-200 AmpsShade No. 10
	200-400 AmpsShade No. 12
	Over 400 Amps Shade No. 14
	<ul> <li>Replace glasses/goggles when lenses are pitted or broken</li> </ul>
	<ul> <li>Warn others in area not to look directly at the arc unless wearing appropriate safety glasses.</li> </ul>
	<ul> <li>Prepare cutting area to reduce reflection and transmission of ultraviolet light.</li> </ul>
	<ul> <li>Use special paint on walls to absorb UV light.</li> </ul>
	<ul> <li>Install protective screens or curtains to reduce ultraviolet transmission.</li> </ul>
CAUTION	Do Not Use this Torch Under Water.
	The PT-20AMX is designed to be a dry cutting process.
	Cutting under water may result in:
	reduced consumable life
	- Ucyraualion or cut quality

• possible damaged torch

Cutting under water may result in poor cutting performance. Water vapor created when hot material or sparks contact liquid may cause arcing inside torch.

When cutting on a water table, reduce the water level to provide maximum clearance between water and material.

#### PCM-875A Mechanized Plasma Cutting System

# 



#### Burn Hazard.

Heat, spatter, and sparks cause fire and burns.

- Do not cut near combustible material.
- Do not have on your person any combustibles (e.g. butane lighter).

• Pilot arc can cause burns. Keep torch nozzle away from yourself and others when activating plasma process.

- Wear correct eye and body protection.
- Wear gauntlet gloves, safety shoes and hat.
- Wear flame-retardant clothing covering all exposed areas.
- Wear cuffless trousers to prevent entry of sparks and slag.
- Have fire extinguishing equipment available for use.

# 



## Explosion hazard.

• Certain molten aluminum-lithium (Al-Li) alloys can cause explosions when plasma cut OVER water.

- These alloys should only be dry cut on a dry table.
- DO NOT dry cut over water.
- Contact your aluminum supplier for additional safety information regarding hazards associated with these alloys.
- Do not cut in atmospheres containing explosive dust or vapors.
- Do not carry any combustibles on your person (e.g. butane lighter)
- Do not cut containers that have held combustibles.

#### **SECTION 1** PCM-875A Mechanized Plasma Cutting System

#### **1.7 Service Precautions**

# 

# Hazardous voltages. Electric shock can kill.

• Do NOT touch plasma torch, cutting table or cable connections during plasma cutting process.

• Always turn power off to plasma power supplies before touching or servicing plasma torch.

• Always turn power off to plasma power supplies before removing covers or panels to service any system component.

• Do not touch live electrical parts.

• Keep all panels and covers in place when machine is connected to power source.

• Keep gloves, shoes, clothing, work area, and equipment dry.

• Inspect power and ground leads cables for wear or cracking. Replace worn or damaged cables. Do not use if damaged.

- Never bypass safety interlocks.
- Follow lock-out procedures.



#### Hot Torch can cause skin burns.

Allow torch to cool before servicing.

# A DANGER



### Danger of Electric Shock.

Torch may be electrically active.

Turn off Plasma Power Console before servicing torch.

## CAUTION

Establish and adhere to preventive maintenance. A composite program can be established from recommended schedules.

Avoid leaving test equipment or hand tools on machine. Severe electrical or mechanical damage could occur to equipment or machine.



Extreme caution should be used when probing circuitry with an oscilloscope or voltmeter. Integrated circuits are susceptible to over voltage damage. Power off before using test probes to prevent accidental shorting of components.

All circuit boards securely seated in sockets, all cables properly connected, all cabinets closed and locked, all guards and covers replaced before power is turned on.

## SECTION 1 PCM-875A Mechanized Plasma Cutting System

SAFETY

#### 1.8 Safety References -- Regulations, Standards, Guidelines

	The following recognized publications on safety in welding and cutting operations are recommended. These publications have been prepared to protect persons from injury or illness and to protect property from damage, which could result from unsafe practices. Although some of these publications are not related specifically to this type of industrial cutting apparatus, the principles of safety apply equally.
1.8.1 USA	
	<ul> <li>"Precautions and Safe Practices in Welding and Cutting with Oxygen-Fuel Gas Equipment," Form 2035. ESAB Cutting Systems.</li> </ul>
	• "Precautions and Safe Practices for Electric Welding and Cutting," Form 52-529. ESAB Cutting Systems.
	• "Safety in Welding and Cutting" - ANSI Z 49.1, American Welding Society, 2501 NW 7th Street, Miami, Florida, 33125.
	• <i>"Recommended Safe Practices for Shielded Gases for Welding and Plasma Arc Cutting" - AWS C5.10-94</i> , American Welding Society.
	<ul> <li>"Recommended Practices for Plasma Arc Welding" - AWS C5.1, American Welding Society.</li> </ul>
	• <i>"Recommended Practices for Arc Cutting" - AWS C5.2</i> , American Welding Society.
	• "Safe Practices" - AWS SP, American Welding Society.
	<ul> <li>"Standard for Fire Protection in Use of Cutting and Welding Procedures" - NFPA 51B, National Fire Protection Association, 60 Batterymarch Street, Boston, Massachusetts, 02110.</li> </ul>
	<ul> <li>"Standard for Installation and Operation of Oxygen - Fuel Gas Systems for Welding and Cutting" - NFPA 51, National Fire Protection Association.</li> </ul>
	• <i>"Safety Precautions for Oxygen, Nitrogen, Argon, Helium, Carbon Dioxide, Hydrogen, and Acetylene," Form 3499.</i> ESAB Cutting Systems. Obtainable through your ESAB representative or local distributor.
	<ul> <li>"Design and Installation of Oxygen Piping Systems," Form 5110. ESAB Cutting Systems.</li> </ul>
	<ul> <li>"Precautions for Safe Handling of Compressed Gases in Cylinders", CGA Standard P-1, Compressed Gas Association.</li> </ul>
	Literature applicable to safe practices in welding and cutting with gaseous materials is also available from the Compressed Gas Association, Inc., 500 Fifth Ave., New York, NY 10036.

SECTION 1 PCM-875A Mechanized Plasma Cutting System

#### 1.8.2 International

## Accident Prevention VBG- Unfallverhütungsvorshriften

	General Provisions
VDG I	Allgemeine Unfallverhütungsvorshriften
VBG 4	Electrical Equipment and operating Equipment
	Elektrische Anlagen
VPC 15	Welding, Cutting and related working methods
VBG 15	Schweißen un Schneiden un verwandte Verfahren
	Shot Blasting Works
VBG 40	Strahlarbeiten
	Gases
VBG 01	Gase
VBG 62	Oxygen
	Sauerstoff
VBG 87	Operating liquid jet cutting machines
	Arbeiten mit Flüssigkeitsstrahlem
VBG 93	Laser beams, accident prevention and Electro- technology
	Laserstrahlung, Unfallverhütungs-vorschriften für Feinmechnik und Elektrotechnik
VPC 121	Noise
	Lärm

#### VDE Regulations VDE - Vorschriften

VDE 0100	Erection of power installations with normal voltages up to 1000 volts Bestimmungen für das Errichten von Stakstromanlagen mit Nennspannungen bis 1000 Volt	
VDE0113	Electrical equipment of industrial machines Elektrishe Ausrüstung von Industriemaschinen	
VDE 0837	Radiation safety of laser products; users guide (DIN EN 60825) Strahlungssicherheit von Lasereinrichtungen und Benutzungsrichtlinen (DIN EN 60825)	
VDE 0837- 50	Specification for laser guards Anforderung an Lasershcutzwänden	

#### TRAC Technical Rules for Acetylene and Carbide Stores TRAC- Techische Regein für Azetylenanlagen und Calciumcargidlager

TRAC-204	Acetylene lines	
	Azetylenleitungen	
TRAC-206	Acetylene cylinder battery systems	
	Azetylenflaschenbatterieanlagen	
TRAC-207	Safety devices	
	Sicherheitseinrichtungen	

#### TRG Technical Rules for Pressure gases TRG – Technische Regein für Druckgase

TRG 100	General regulations for pressure gases
	Allgemeine Bestimmungen für Druckgase
TRG 101	Pressure gases
	Druckgase
TRG 102	Technical gas mixtures
	Technishe Gasgemische
TRG 104	Pressure gases; alterative use of compressed gas tanks
	Druckgase, wahlweise Verwendung von Druckgasbehältem

#### SECTION 1 PCM-875A Mechanized Plasma Cutting System

#### TRGS – Technische Richtlinien für Gefahrstoffe

TRGS-102	Techn. Richtkonzentration (TRK) für gefährliche Stoffe
TRGS-402	Ermittlung u. Beurteilung der Konzentration gefährlicher Stoffe in der Luft im Arbeitsbereich
TRGS-900	Grenzwerte in der Luft am Arbeitsplatz (Luftgrenzwerte)
TA	TA-Luft un TA-Lärm (BLm SchV)

#### DIN Standards DIN-Normen

DIN 2310 Part 1	Thermal cutting; terminology and nomenclature
Teil 1	Thermsiches Schneiden, Allgemeine Begriffe und Bennungen
DIN 2310 Part 2	Thermal cutting; determination of quality of cut faces
Teil 2	Thermsiches Schneiden, Ermittein der Güte von Schnittflächen
DIN 2310	Thermal cutting; arc plasma cutting; process principles,
Part 4	quality, dimensional tolerances
Teil 4	Thermsiches Schneiden, Plasmaschneiden, Verfahrensgrundlagen, Güte, Maßtoleranzen
DIN 2310	Thermal cutting; laser beam cutting of metallic materials;
Part 5	process principles
Teil 5	Laserstrahlschneiden von metallischen Werkstoffen, Verfahrensgrundlagen, Güte, Maßtoleranzen
DIN 2310 Part 6	Thermal cutting; Classification, processes
Teil 6	Einführung, Verfahren
DIN 4844 Part 1	Safety markings (DIN EN 7287)
Teil 1	Sicherheitskennzeichen (Siehe EN 7287)

#### DIN EN ISO Harmonized Standards DIN EN ISO-Harmonisierte Normen

DIN EN 292/1 and 2	Safety of machinery	
	Sicherheit von Maschinen, Geräten und Anlagen	
	Hoses for welding, cutting and allied processes	
DIN EN 559	Schläuche für Schweißen, Schneiden und verwandte Verfahren	
DIN EN 560	Hose connections and hose couplings for equipment for welding, cutting and allied processes Schlauchanschlüsse und Schlauchverbindungen für Geräte zum Schweißen, Schneiden und verwandte Verfahren	
	Gas welding equipment hose couplings	
	Gasschweißgeräte, Kupplungen	
DIN EN	Safety of machines, reduction of risks to health	
626-1	Sichereit von Maschinen, Reduzierung des Gesundheitsrisikos	
DIN EN	Single spindle vertical milling machines	
848-1	Fräsmaschine für einseitige Bearbeitung mit drehendem Werkzeug	
DIN EN	High pressure water jet machines	
1829	Hochdruckwasserstrahlschneidmaschine	
DIN EN 9013	Thermal cutting, oxygen cutting, process principles, dimensional tolerances Thermisches Schneiden, Autogenes Brennschneiden, Verfahrensgrundlagen, Güte, Maßtoleranzen	
	Imperfections in oxy/fuel flame cuts, laser beam cuts and	
12584	Unregeimäßigkeiten an Brennschnitten, Laserstrahl- und Plasmaschnitten	
DIN EN	Laser processing machines	
12626	Laserbearbeitungsmaschinen	
DIN EN	Acceptance testing for oxygen cutting machines	
28206	Abnahmeprüfung für Brennschneidmaschinen	
DIN EN	Laser Equipment	
31252	Lasergeräte	

#### PCM-875A Mechanized Plasma Cutting System

SAFETY

DIN EN 31553	Laser and laser related equipment
	Laser und Laseranlagen
DIN EN 60204-1	Electrical equipment of machines
	Elekrische Ausrüstung von Maschinen
DIN EN 60825	Radiation safety of laser products
	Strahlensicherheit von Laseranlagen
DIN EN 999	Arrangement of protection devices
	Anordnung von Schutzeinrichtungen

#### **VDI Guidelines**

VDI 2906	Quality of cut faces on metallic workpieces; abrasive water jet cutting and arc plasma cutting Schnittflächenqualität beim Schneiden von Werkstücken aus Metall, Abrasiv- Wasserstrahischneiden und Plasmastrahischneiden
VDI 2084	Room air; Technical systems for welding workshops
	Raumluft techn. Anlagen für Schweißwerkstätten

SECTION 2	PCM-875A Mechanized Plasma Cutting System	Description
2.1 General		
	The PCM-875A Mechanized P System is a compact 60 ampe consisting of plasma power co starter, and PT-20AMX plasma bulkhead connections allow ea Connect to input power and a compressed air (5,18 to 5,87 b begin cutting up to 13 mm thic	lasma Cutting re package nsole, remote arc torch. Simple isy system assembly. source of clean, dry, par) and you can ik material.
2.2 PCM-875A Power	Console	
	There are 2 power console opt	ions available:
	230 V 50 Hz, 1 or 3 phase	P/N 0558003356
	400 V 50 Hz, 3 phase	P/N 0558003357

## 2.2.1 Technical Specifications: PCM-875A

Options		230V 50Hz, 3 Phase P/N 0558003356		400V 50Hz, 3 phase P/N 0558003357	
		1 phase	3 phase		
Potod Output	60% Duty Cycle	60 A at 120 VDC			
Rated Output	100 % Duty Cycle	50 A at 120 VDC			
Output Cur	rent Range	10 to 60 A/phase			
Open Circuit Voltage			275 VDC		
Rated Primary Input at 7,2 kW Maximum Output Power, 60 A at 120 VDC		55/49 A (230V, 1 phase)	26/24 A per phase (230V, 3 phase)	13 A/phase	
Power Factor at 60 Amperes Output		74% (230 V, 1 phase)	90% (230 V, 3 phase)	92% (400 V, 3 phase)	
Efficiency at 60 Amperes Output		90% typical			
Current Capacity		60 A DCSP			
Air Requirements		153,4 l/minute at 5,2 bars			
Power Cord Length Provided		1,8m 3,1m			

#### 2.2.2 Dimensions and Weight: PCM-875A Power Console



Weight = 39,5 kg

#### SECTION 2 PCM-875A Mechanized Plasma Cutting System Description

2.3 Remote Arc Starter (RAS-2)



The remote arc starter (RAS-2) is placed inline between power console and torch. The RAS is the source of high frequency energy used to start the plasma cutting process.

RAS-2 with 15,2 m leads RAS-2 with 30,4 m leads P/N 0558003601 P/N 0558003602

#### **Technical Specifications**

Input: 110 VAC, 50/60 Hz. Control power provided by PCM-875A console. Spark Gap: 1mm

#### **Dimensions and Weight**



Weight = 3,4kg

#### SECTION 2 PCM-875A Mechanized Plasma Cutting System

Description

#### 2.4 PT-20AMX

The patented PT-20AMX is a 100 amp capacity, pilot-arc mechanized torch available in 3 different torch lead length packages.

The torch uses clean, dry air as the cut gas for cutting carbon steel, aluminum, or stainless steel.

PT-20AMX Torch with 1,2 m lead	P/N 0558002632
PT-20AMX Torch with 5,7 m lead	P/N 0558002633
PT-20AMX Torch with 7,6 m lead	P/N 0558003381

DO NOT use oxygen with this torch!

A hazardous fire may result.



#### 2.4.1 Technical Specifications

Туре:	Air Cooled, single gas at 9,9 kl/hr
Rating:	100 Amperes at 100% Duty Cycle
Gas Purity:	Air: Needs to be clean, dry and free of all particulate matter. Nitrogen: 99.995% clean
Gs Type:	Air, nitrogen

## SECTION 2 PCM-875A Mechanized Plasma Cutting System Description

## 2.4.2 Dimensions



#### SECTION 2 PCM-875A Mechanized Plasma Cutting System

Description

#### 2.4.3 Torch Spare Part Kit



PT-20AMX Torch Spare Parts Kit is available for maintaining the PT-20AMX torch with minimum downtime.

P/N 0558002319

Description	P/Number	Quantity
Heat Shield (70/100 A) 🗙	21326	3
Cutting Nozzle (50 A) ★★	21330	5
Cutting Nozzle (70 A) ★ ★	23129	5
Electrode 50Hz	0558001617	5
Electrode Insulator	21373	1
Electrode Holder Assembly	21332	1
Baffle Tube	21374	1
Pilot Arc Adaptor	19497	1
O-ring	488157	5
Lubricant (1 oz.)	17672	1
Seat/Baffle Wrench	21375	1
1/16: Hex-Key Wrench	93750006	1



## \*

The description of the heat shield (P/N 21326) listed above indicates a range of 70 to 100 amperes. Testing has proven satisfactory results when used at 60 amps and lower.

## NOTICE



#### \* \*

The 50A cutting nozzle can be used at 50 amperes and lower.

The 70A cutting nozzle can be used at 50 to 70 cutting amperes.

#### 3.1 General

Proper installation is important for satisfactory and trouble free operation. Follow these instructions carefully.

## Failure to follow these directions carefully may lead to injury or death. Read this entire manual before proceeding.

Damage to property or equipment may occur.



3.2.1 Equipment Required

A source of clean dry air at 153,4 liters/minute at 5,2 to 5,9 bar. The maximum inlet pressure of the air filter-regulator is 10,4 bar and should not be exceeded.



#### SECTION 3 PCM-875A Mechanized Plasma Cutting System

Installation

#### 3.2.2 Location



Adequate ventilation is necessary to provide proper cooling of the PCM-875A.

Exposure to dirt, dust and excessive heat should be minimized.

There should be a minimum of 305 mm clearance between the power console and any wall or other obstruction for free air movement.

# CAUTION

Restricting airflow into the power console through the louvers will cause overheating. Do not install any type of air filtering device on to the power console cooling air passages. Warranty will be voided if such a device is used.

#### 3.2.3 Inspection of Power Console Before installation

- A. Remove equipment from the shipping containers.
- B. Remove all packing material and inspect for evidence of concealed damage, which may not have been initially apparent. Notify the shipping carrier of any damage at once.
- C. Check container for any loose parts prior to disposing of shipping materials.
- D. Check air louvers and all other openings to ensure that any obstruction is removed.

#### SECTION 3 PCM-875A Mechanized Plasma Cutting System Inst

Installation

#### 3.2.4 Primary electrical Input Connections



#### **Electric Shock Can Kill!**

Ensure all power is off by opening the line (wall) disconnect switch and power cord is disconnected before attempting to make any connections inside the power console.

# 

Ensure that the power source is properly configured for your input power supply. DO NOT connect a power console configured for 230V to a 460V input power. Damage to machine will occur.

The PCM-875A Power Console is equipped with a 3 m 4 conductor power cable for 3- phase connection. If single-phase 230V is required, tape back red wire on the input power cable.

A line (wall) disconnect switch with fuses or circuit breakers should be provided at the main power panel.

Input	Requirements Input and			
Volts	Phase	Amps	Ground Conductor (mm²)	Fuse Size (A)
230	1	49	16	80
230	3	24	16	50
400	3	13	6	25

PCM-875A Mechanized Plasma Cutting System

Installation

# **WARNING**



Failure to connect chassis to an approved electrical ground may result in electrical shock, severe burns or death.

The chassis must be connected to an approved electrical ground.

The PCM-875A power console is internally wired for connecting to an external power source.



**Console Power Lead** 

#### 3.2.5 Connection of Plasma Console To CNC Interface



The CNC interface (TB4) is mounted on the front left corner of the console base.

• Arc On Signal – This signal originates in the plasma console. It is a normally open contact, which closes on main arc transfer. Used to activate machine motion and arc voltage control.

• **Start Signal** – Signal is derived from CNC machine. It is a normally open contact, which closes starting the plasma sequence. The system is off when this contact closure is removed.

• 20:1 (+) Voltage Divider – The voltage divider provides a signal ouput, which is proportional to the cutting voltage. Signal reduction is 20 to 1 and controls whether the torch is raised or lowered in reference to the work piece. This is referred to torch to work distance. This distance is adjustable by varying arc voltage reference voltage.

Not Used

#### SECTION 3 PCM-875A Mechanized Plasma Cutting System Installation

#### 3.2.6 Secondary (Output) Connections to Power Console



**Electric Shock Can Kill!** 

Ensure all power is off by opening the line (wall) disconnect switch and power cord is disconnected before attempting to make any connections inside the power console.



Remove outside cover Insert power cable, pilot arc, and air hose through power cable bushing.

#### SECTION 3 PCM-875A Mechanized Plasma Cutting System

Installation



#### PCM-875A Mechanized Plasma Cutting System

Installation





115VAC RAS Cable 2 conductor 115VAC cable 115VAC cable

Insert 115VAC RAS cable through strain relief located in the lower right corner of the front panel.

Rout 115VAC RAS cable along inside edge in notches in insulating material to TB1.

#### SECTION 3 PCM-875A Mechanized Plasma Cutting System

Installation



Remove connection for internal arc start from TB1

TB1



Plug terminal connectors into 2 available lugs on TB1.

# 

Cable Terminals to TB1 should be insulated to prevent possible damage due to internal arcing in the power console. The above illustration shows the terminals un-insulated for clarity of wire positions.

Replace cover if next step is not required.
Installation

## 3.3 Connecting the Remote Arc Starter

## 3.3.1 Mounting RAS2

Mounting location of RAS unit is restricted by the length of torch leads, 1,2 m -- 5,4 m or 7,6 m.



Installation

### 3.3.2 Connecting Service Lines to Remote Arc Starter 2



Remove end covers on RAS2 box.

- Connect arc start cable to RAS2 box.
- Connect pilot arc cable to pilot arc lug using #10 screw and nut with lock washers.
- Connect power cable to power cable lug using 1/4" screw with washers and nut.

• Connect air hose fitting (left hand threads). Note that this hose has the same fittings on both ends and orientation does not matter.

Installation

## 3.3.3 Setting the Spark Gap in the RAS2



Factory set to 1mm.

Adjustment procedure:

- 1. Loosen screw "a" using a 1/8" (0.125") internal hex wrench.
- 2. Insert 1mm feeler gage between the tungsten electrodes.
- 3. Slide electrodes till slight pressure is felt on the gage.
- 4. Tighten locking screws on spark gap assembly.

Installation

## 3.3.4 RAS2 Output Connections to Torch



Connector

Torch Lead Voltage/Gas Hose

- Pilot Arc Connect pilot arc cable in torch bundle to pilot arc output lug using #10 screw, lock washers and nut.
- Torch left hand threads connect the torch gas (air) and plasma arc current. (Cable inside gas hose conducts the plasma cutting current)

Installation

## 3.3.5 Terminating Shield Braid at RAS2



Flair Braid

1. Insert Braid and hose bundle through RAS cover hole.

2. Flare braid by bending it back at 90 degrees about 25 mm from the end.



**Insert Ground Plate** 



**Fasten Ground Plate** 

3. Insert ground plate over torch leads.

4. Fasten ground plate with 4 screws inserted from the outside. Trim braid strands if desired.

#### **SECTION 3** Installation PCM-875A Mechanized Plasma Cutting System

## 3.4.1 Installing Torch Front End Parts



Make sure power switch on console is in OFF position and primary input power is de-energized.



Wrench 21375

Electrode Holder Assembly





Baffle Tube



1. The seat comes assembled to the front end of the torch. IF the seat becomes damaged, the torch body must be replaced. DO NOT attempt to remove the seat from torch body.

2. Electrode holder assembly (21332) includes the baffle tube (21374). If baffle tube becomes damaged, it can be replaced by un-threading the damaged tube out of the holder. Use small hex end of the wrench (21375) in hex broach on the tube. Tighten tube securely but do not overtighten.

### PCM-875A Mechanized Plasma Cutting System

Installation



3. Install the electrode insulator (21373) onto electrode holder assembly (21332) and then thread electrode (21150) onto the electrode holder assembly. Assemble electrode firmly by hand. Do not use wrenches or pliers. These three parts combined are the electrode assembly.

4. Install nozzle onto the electrode assembly by inserting small shoulder on electrode insulator into nozzle's rear opening. Place nozzle and electrode assembly into the heat shield as shown in page 6. If front end of the torch is facing down as normal in a setup, the nozzle and electrode assembly can be stacked in the heat shield and then assembled to the torch. Be sure to use proper heat shield and nozzle combination as noted in page 18.

5. Apply a thin film of lubricant (17672) to O-ring (488157).

## SECTION 3 PCM-875A Mechanized Plasma Cutting System Installation



6. Tighten heat shield fully to hold the parts in firm contact with each other and to the torch head. "Fully" means at least 5mm rotation after electrode seat contacts electrode holder.

7. After retainer/heat shield is tightened, try to rotate the nozzle with your finger tips. If it rotates, the sealing of components is not tight enough and will likely leak gas.

# NOTICE

See "Section 6 – Maintenance" for torch lead installation or replacement.



## **IMPORTANT:** See Maintenance section.

Follow all instructions in the booklet packed with your unit. DO NOT install or attempt to operate this torch without following these instructions.

## 3.5 Interconnecting Diagram



Installation

1	Air Supply
2	Wall Disconnect Switch (Grounded)
3	PCM-875A Power Supply Cable
4	Work Cable (Negative)
5	Pilot Arc Cable
6	Gas Connection
7	Power Supply Cable
8	115 V High Frequency Start Cable
9	RAS Input Bulkhead
10	Remote Arc Starter
11	RAS Output Bulkhead
12	Pilot Arc Cable
13	Power/Gas Hose
14	Torch Lead Bundle Shield Ground
15	PT-20 AMX Plasmarc Torch
16	Work Cable Clamp
17	Work Piece
18	Earth Ground
19	ATAS Start/Stop CSR
20	CSR Cable
21	Height Control Cable (Voltage Divider)
22	Voltage Divider (Height Control)

## SECTION 3 PCM-875A Mechanized Plasma Cutting System Installation

This page intentionally left blank.

## SECTION 4 PCM-875A Mechanized Plasma Cutting System Operation

## 4.1 PCM-875A Console Operation -- General



### Operation

### 4.2 PCM-875A Plasma Console Controls





**Power Switch** 

White Pilot Light

### Power Switch -- Rear Panel

- Located on the rear panel.
- On Position Front panel green pilot light will glow indication control circuit is energized and cooling fan will run.
- Off Position No Power to the control circuit.

### Output Current Control - Front Panel

• Adjustable from 10 to 60 Amperes

M-875A



**Air Test Switch** 

### Air Test Switch - Front Panel



## Test Position

Air filter-regulator can be adjusted to desired pressure 4,6 to 5,3 kgf/cm<sup>2</sup> (65 to 75 PSI). Allow a few minutes for air to flow to remove an accumulated condensation.

#### Operate Position

Place the toggle switch in this position for normal operation.

## SECTION 4 PCM-875A Mechanized Plasma Cutting System Operation



Fault Light – Operations are stopped.

Will illuminate amber under the following conditions:

• Light **mostly ON** but will blink off 1/10 of a second every second. Indicates airflow is low.

• Light is **mostly Off** but will blink on for 1/10 of a second every second. Indicates over temperature and duty cycle has been exceeded. Allow power console to cool before returning to operation.

• Light will **blink off and on** 5 times a second. Indicates the input voltage is outside the plus or minus 15% range of input rating.

• Light will be **on continuously**. Indicates input current has been exceeded. Over Current.

NOTICE	All fault lights will remain on for a minimum of 10 seconds. If fault is resolved, all will reset automatically except
	for over current. To clear over current, power must be shut off for 5 seconds and turned back on.

### 4.3 RAS Operation

The RAS is a self-contained unit and requires no operator intervention to function.

## Fault Light

#### **SECTION 4** Operation PCM-875A Mechanized Plasma Cutting System

4.4 PT-20AMX Plasma Torch.

# 

## **Electric Shock Can Kill!**

Plasma incorporates high voltages at dangerous amperage.

Do not touch the;

- Plasma torch
- **Torch lead**
- RAS
- **RAS supply lines**
- Console

while power is applied to console.

## **Electric shock Can Kill!**

Do not service torch or otherwise touch the plasma torch unless the power source has been disconnected or turned off.



## Hot Torch May Burn Skin.

Allow torch to cool before servicing.



SECTION 4	PCM-875A Mechanize	d Plasma Cutting System Operation
4.5 Cut Quality		
4.5.1 Introduction		
		Causes affecting cut quality are interdependent. Changing one variable affects all others. Determining a solution may be difficult. The following guide offers possible solutions to undesirable cutting results. To begin select the most prominent condition:
		<ul><li>4.5.2 Cut angle, negative or positive</li><li>4.5.3 Cut not flat, rounded or undercut</li><li>4.5.4 Surface roughness</li></ul>
		• 4.5.5 Dross
		<ul> <li>4.5.6 Dimensional Accuracy</li> <li>Process Data</li> </ul>
		Usually the recommended cutting parameters will give optimal cut quality. Occasionally conditions may vary and slight adjustments will be required. If so:
		<ul> <li>Make small incremental adjustments when making corrections.</li> </ul>
		<ul> <li>Adjust arc voltage in one volt increments, up or down as required.</li> <li>Adjust cutting speed 5% or less as required, until conditions improve.</li> </ul>
NO	TICE	Before attempting ANY corrections, check cutting variables with the factory recommended settings/consumable part numbers listed in Process Data.

Operation

## 4.5.2 Cut Angle



#### **Negative Cut Angle**

Top dimension is greater than the bottom.

- Misaligned torch
- Bent or warped material
- Worn or damaged consumables
- Standoff low (arc voltage)
- Cutting speed slow (machine travel rate)



#### **Positive Cut Angle**

Top dimension is less than the bottom dimension.

- Misaligned torch
- Bent or warped material
- Worn or damaged consumables
- High standoff high (arc voltage)
- Cutting speed fast
- Current high or low. (See process data for recommended current level for specific nozzles).
- Wrong secondary gas flow.

## SECTION 4 PCM-875A Mechanized Plasma Cutting System Operation

### 4.5.3 Cut Flatness



#### **Top And Bottom Rounded**

Condition usually occurs when material is 0.25" thick (6,4mm) or less.

• High current for given material thickness (See process data for proper settings).



Top Edge Undercut

Standoff low (arc voltage)

### Operation

### 4.5.4 Surface Finish



#### **Process Induced Roughness**

Cut face is consistently rough and may be confined to one axis.

• Worn or damaged consumables

#### Machine Induced Roughness

Can be difficult to distinguish from process induced roughness and is often confined to one axis. Roughness is inconsistent.

- Dirty rails, wheels and/or drive rack/pinion. (Refer to maintenance section in machine owner's manual).
- Carriage wheel adjustment

Operation

#### 4.5.5 Dross

Dross is a by-product of the cutting process. It is the undesirable material that remains attached to the part. In most cases, dross can be reduced or eliminated with proper torch and cutting parameter setup. Refer to Process Data.



#### **High Speed Dross**

Material weld or rollover on bottom surface along kerf. Difficult to remove. May require grinding or chipping. "S" shaped lag lines.

- Standoff high (arc voltage)
- Cutting speed fast

#### **Slow Speed Dross**

Forms as globules on bottom along kerf. Removes easily.

Cutting speed slow



#### Top Dross

Appears as splatter on top of material. Usually removes easily.

- Cutting speed fast
- Standoff high (arc voltage).

#### **Intermittent Dross**

Appears on top or bottom along kerf. Non-continuous. Can appear as any kind of dross

• Possible worn consumables

### **Other Factors Affecting Dross:**

- Material temperature
- Heavy mill scale or rust
- High carbon alloys
- Gas Purity

SECTION 4	PCM-875A Mechanize	d Plasma Cutting System	Operation	
4.5.6 Dimensiona	al Accuracy			
		Generally, using the slowest possible speed (within approved levels) will optimize part accuracy. Most material thickness overlap for different voltages. Select consumables to allow a lower arc voltage and slower cutting speed.		
4.6 Process Data				
N	OTICE	Recommended cutting speed give optimal cutting performa	d and arc voltage will nce.	
		Small incremental adjustment to material quality, material te alloy. The operator should re cutting variables are interdepo- setting affects all others and o deteriorate. Always start at th settings. Before attempting ANY corre variables with the factory reco consumable part numbers lis data.	ts may be needed due imperature and specific imember that all endent. Changing one cut quality could ne recommended ctions, check cutting ommended settings/ ted in the process	

PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 40 Amperes

Mild Steel

# **Material Thickness**

**mm** 2,0 3,0

## Air Pressure

Bar	5	5
-----	---	---

# Height Readings

Initial Height mm	3,0	3,0
Arc Voltage (Stand-off)	110	110

# **Travel Speed**

|--|

## Kerf Width

Millimeters 1,1 1,1

PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 50 **Amperes** Mild Steel

# **Material Thickness**

mm 5,0 6,0 10,0 13,0

# Air Pressure

Bar	6,0	6,0	6,0	6,0
-----	-----	-----	-----	-----

# Height Readings

Initial Height mm	3,0	5,0	6,0	8,0
Arc Voltage (Stand-off)	110	120	130	150

# Travel Speed

<b>mm per minute</b> 2540 1651 1016 457
-----------------------------------------

# Kerf Width

Millimeters	1,6	1,9	3,2	4,0
-------------	-----	-----	-----	-----

PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 40 **Amperes** Aluminum

# **Material Thickness**

**mm** 2,0 3,0

# Air Pressure

Bar	5	5
Bar	5	5

# Height Readings

Initial Height mm	3,0	3,0
Arc Voltage (Stand-off)	110	110

# Travel Speed

<b>mm per minute</b> 3810 2667
--------------------------------

# Kerf Width

**Millimeters** 1,57 1,57

PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 50 **Amperes** Aluminum

# **Material Thickness**

mm 5,0 6,0 10,0 13,0

# Air Pressure

Bar	6,0	6,0	6,0	6,0
-----	-----	-----	-----	-----

# Height Readings

Initial Height mm	3,0	5,0	6,0	8,0
Arc Voltage (Stand-off)	110	120	130	150

# Travel Speed

mm per minute 2286 1905 762 203					
	mm per minute	2286	1905	762	203

# Kerf Width

Millimeters	Not Available	3,2	4,7	4,7
-------------	------------------	-----	-----	-----

PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 40 Amperes

**Stainless Steel** 

# **Material Thickness**

**mm** 2,0 3,0

# Air Pressure

<b>Bar</b> 5 5
----------------

# Height Readings

Initial Height mm	3,0	3,0
Arc Voltage (Stand-off)	110	110

# Travel Speed

mm per minute	3302	1905

# Kerf Width



PCM-875A Mechanized Plasma Cutting System

Operation



Operation

# PT-20AMX Process Data

# 50 **Amperes** Stainless Steel

# **Material Thickness**

mm 5,0 6,0 10,0 13,0

# Air Pressure

# Height Readings

Initial Height mm	3,0	5,0	6,0	8,0
Arc Voltage (Stand-off)	110	120	130	150

# Travel Speed

mm per minute	1270	762	203	152
	1210	102	200	102

# Kerf Width

Millimeters	Not available	3,2	4,7	4,7
-------------	------------------	-----	-----	-----

## SECTION 4 PCM-875A Mechanized Plasma Cutting System Operation

This page intentionally left blank.
# 5.1 PCM-875A Console



# 5.1.1 General

	Stop work immediately if this equipment does not operate properly. Equipment damage or personal injury may result.
	Do not permit untrained persons to inspect, clean, or repair this equipment. Maintenance must be performed by specially trained personnel.
NOTICE	Use of replacement parts other than ESAB replacement parts may void warranty.
	Electric Shock Can Kill! Disconnect wall switch before inspection and maintenance of the power console.



#### 5.1.2 Inspection and Cleaning



Frequent inspection and cleaning of the PCM 875A system is recommended for safe and proper operation.

- A. Check work cable for secure connection to workpiece.
- B. Check safety earth ground at workpiece and at power console chassis.
- C. Check heat torch heat shield. Replace if damaged.
- D. Check torch electrode and cutting nozzle for wear at least once per 8 hours operation.
- E. Ensure cable and hoses are not damaged or kinked.
- F. Ensure all plugs, fittings and ground connections are tight.

Wear safety eye protection when using compressed air. Serious eye injury may result.



Maintenance



- G. With all input power disconnected, wearing proper eye and face protection, blow out the inside of the console using low-pressure dry compressed air.
- H. Periodically drain water from the filter beneath the air-filter regulator.

#### 5.1.3 Flow Switch



The Flow Switch (P/N 951202) may need to be cleaned if excessive contamination is found in the air supply.

Note: The flow switch can be disassembled and cleaned without extraction from the power supply.

- 1) Turn Off power supply
- 2) Remove piston plug
- 3) Remove the spring. Use care when handling spring to prevent distortion.
- 4) Remove the piston.
- 5) Clean all parts with warm water and a mild detergent. Allow parts to dry thoroughly before reassembly.
- 6) Reassemble switch in reverse order.

#### PCM-875A Plasmarc Cutting System

#### 5.2. Remote Arc Starter

#### 5.2.1 General

#### 5.2.2 Spark Gap



Check input and output bulkhead connections for tightness.

#### Factory set to 1mm.

Adjustment procedure:

- 1. Loosen screw "a" using a 1/8" (0.125") internal hex wrench.
- 2. Insert 1mm feeler gage between the tungsten electrodes.
- 3. Slide electrodes till slight pressure is felt on the gage.
- 4. Tighten locking screws on spark gap assembly.

# 5.3 PT-20AMX Plasmarc Torch



Before any maintenance is attempted on this torch, make sure the POWER SWITCH on the console is in the OFF position and the PRIMARY INPUT POWER is DE-ENERGIZED.

#### 5.3.1 General

1. Periodically check heat shield, electrode holder assembly, electrode nozzle seat, and electrode insulator. Replace if worn or damaged.

2. Apply a thin film of lubricant 17672 (supplied in spare parts kit) to O-ring. Check O-ring for damage whenever shield is removed. Replace if necessary.

3. Power and pilot arc cables should be inspected periodically. If cuts through protective sheath or if gas leaks are noted, replace damaged component.

#### 5.3.2 Dirt or Contamination

Dirt or other contamination in the torch and loose consumable parts can cause premature failure of the PT-20AM Torch through internal arcing. To avoid this, users are instructed to do the following:

1. Ensure that clean, dry, or oil-free air is being used.

2. Avoid excessive use of the silicone o-ring grease used to lubricate the torch o-ring. A thin film is sufficient.

3. Wipe the torch body insulator clean with a cloth before installing each fresh set of consumables. The ability of the insulator to resist arc tracking over its surface is reduced when dirt or other contamination is allowed to collect there.

#### 5.3.3 Loose Consumables



Tests have shown that with proper use of the torch within rated operating conditions (especially arc current and gas flow rate), the torch consumable parts do not become loose if they are firmly installed in the first place.

1. Tighten heat shield fully at each consumable change or inspection. "Fully" means at least 5 mm of rotation after electrode seat contacts electrode holder.

NOTE: trying to rotate the portion of the nozzle extending outside heat shield can check consumable tightness.

2. Check consumable tightness at beginning of each work shift, even if everything was working normally at the end of the previous shift.

3. Ensure that the torch electrode seat and electrode holder are clean and free of dust or dirt Debris may prevent mating surfaces from having solid contact.

PCM-875A Plasmarc Cutting System

Maintenance

# CAUTION

The torch requires good electrical contact between the electrode seat and electrode holder. If good contact is not maintained, then the resulting potential difference causes internal arcing and possible torch damage.

# 5.3.4 Damage Caused by Loose Parts and Torch Overheating.

#### Electrode Insulator (21373)



Arc tracking indicates loose parts. Make sure heat shield is tightened fully, at least 5mm of rotation after electrode seat contacts electrode holder. Check tightness again after a few minutes of use. Parts damaged by arcing will cause destruction of torch. Parts damaged by arcing must be replaced.

Deformation at this edge indicates torch overheating. Check gas pressure, gas flow rate and current setting. Deformation leads to loose parts and internal arcing. Do not operate torch with a deformed insulator.

# 5.3.5 Consumables- Remove and Replace

1. Bring torch to a position where it is easily accessed by machine operator, in its normal vertical position and at least 6 inches above the workpiece or the edge of the water table.

Make sure that the power source has been turned off and that the power cable has been unplugged at the wall receptacle before proceeding.



2. Unscrew the heat shield and lower it away from the torch, allowing nozzle and electrode assembly to remain with shield.

#### PCM-875A Plasmarc Cutting System

#### Maintenance



3. Remove the nozzle and electrode assembly from the shield and inspect for wear. The nozzle orifice should be round at both the entrance and the exit. If the nozzle orifice is worn in an oval shape or shows other signs of damage at either end, it should be replaced. The inside of the nozzle may have light gray deposits from the electrode. These may be removed with steel wool but care must be taken to remove all traces of the steel wool afterward.

If the electrode has a pit that is more than 1.5mm deep at its center, replace it. Grasp the electrode holder with the fingers using the two flats and grasp the electrode between the thumb and finger of the other hand and twist.

Inspect electrode insulator and electrode holder assembly for signs of damage such as arc tracking or cracking and replace them if any are found. Insure that the baffle tube is securely threaded into the electrode holder, but do not over tighten. Use the small hex end of the plastic wrench in the spare parts kit.

After installing the electrode insulator onto the electrode holder assembly, install electrode by reversing the procedure used to remove it. Note that firm tightening of the electrode by hand is sufficient. The use of tools such as wrenches or pliers is not required or recommended.

4. Inspect heat shield for signs of damage or wear. The gas holes inside shield should not be blocked by debris, and there should be no signs of arcing anywhere inside the shield. The outer insulating jacket of the shield should not be severely charred or eroded. Replace the heat shield if any of the above damage is found.



#### PCM-875A Plasmarc Cutting System

#### **Maintenance**



5. Inspect the o-ring on the torch. If it shows signs of wear or damage, replace it. If it is dry, lubricate it with a thin film of lubricant supplied with spare parts kit

6. Install the nozzle and the electrode assembly into heat shield and thread heat shield onto torch. The shield should be tightened fully to insure good electrical contact for electrode and nozzle. "Fully" means at least 3/16 inch of rotation after electrode seat contacts electrode holder.

#### 5.3.6 Measuring Torch Gas Flows



Check gas flow if suspected of causing poor cutting performance. Use Plasma Torch Flow Measuring Kit. (P/N 19765)The kit includes a hand held rotameter (flowmeter) that indicates the gas flow rate exiting the torch. The kit also includes a set of instructions that should be followed exactly to insure safe and accurate use of the rotameter.

Total air flow rate in the PT-20AMX should be 325cfh minimum with any nozzle at 75 psi.

Flow Measuring Kit -- P/N 19765

# 5.3.7 Removal and Replacement of the Torch Body



Make sure that the power source has been turned off and that the power cable has been unplugged at the wall receptacle before proceeding.

PT-20AMX Torch



1. Cut and remove the shrink wrap at the back end of the torch handle. Unscrew the handle from the torch body and slide it back onto the torch cable assembly in order to expose the torch connections.

2. Remove the electrical tape that secures the short piece of vinyl tubing on the pilot arc cable. Slide the tubing away from the torch and onto the pilot arc cable to expose the pilot arc connector.

3. Use the 1/16" Allen Wrench supplied in the spare parts kit to loosen the pilot arc connector set screw closest to the torch body, being careful not to totally remove the screw. Slip the torch's pilot arc lead out of the connector.

4. Unscrew the power cable fitting from the torch's power lead using a 7/16" open-end wrench and remove the torch body.

5. Connect the pilot arc cable and the power cable to the new torch body's pilot arc lead and power lead by reversing the steps taken to disconnect them. Tighten the pilot arc connector set screw fitting firmly but do not overtighten. Torque the power fitting to 20 lb. in.

6. Slide the vinyl tubing forward to cover the pilot arc connector and secure in place with electrical tape.

7. Slide the handle forward and thread it firmly onto the torch body.

8. Slide the new piece of shrink tube over the torch handle and shrink in place over the handle's end and the cable sheath.

This page intentionally left blank

# 6.1 Troubleshooting PCM-875A Plasmarc System



# **Electric Shock Can Kill!**

Ensure that all primary power to the machine has been externally disconnected.

Open the line disconnect switch or circuit breaker before inspection, maintenance or repair inside power console.

Match the problem with the conditions below. If problem is not listed,

- shut off input power,
- open unit by removing cover
- Visual inspection of all components and wiring
- Check for loose terminal connections
- Burned wiring or other components
- Bulged or leaking capacitors
- Any other signs of damage or discoloration.

#### 6.2 Troubleshooting guide for PCM-875A Plasmarc System

#### 6.2.1 Power Light (PL1) does not come on

- Visually inspect the machine for damage.
- Check if the cooling fan is running. If not running, check the following:
  - Check if machine input power is still connected.
- Measure input power at the receptacle. If not present, then check the wall disconnect switch and it's fuses.
- Check fuse (F1). If it is:
- Check input circuit breaker (CB1).
- If cooling fan is running, measure voltage between pins P2-11 and P2-14 of control board (should be 115VAC). If no voltage, replace transformer T2.
- If voltage is present, power light may be burned out.

The problem is internal if above items are ok. Send unit to Authorized Repair Station.

6.2.2 No air flow

- Check air inlet supply. Unit requires 9,2  $^{\rm 3}{\rm m/h}$  at 4,48 bar.

- Check air hose and connections. Tighten if leaking.
- Does air flow when "Air Test" switch is in test position?
  - If not, check torch consumables, replace if necessary.

If above items are OK, the problem is internal. Return to authorized repair station for service.

# 6.2.3 The Power light is on, but nothing happens when the torch is signaled to fire. Fault light does not activate.

# NOTE: Unplug high frequency connection before attempting to work on this problem.

- Check the Pilot Arc fuse (F2) located on the rear panel. An open fuse will indicate a short in the torch. If the fuse is all right, then check the following:
  - With the machine power on, depress the torch switch. On the control board the LED 1 should be lit as long as the switch is depressed. If not then check:
  - Turn power off to the machine. Unplug Control board. Put an ohmmeter across P5-1 and P5-2 to take resistance reading. Depress torch switch. Meter should read a short. If not, then one of the following is not working properly:
  - Torch switch or the leads. Unplug the torch switch leads at the machine. Put a meter across the two plug pins. Should read a short when the torch switch is depressed. If not, then either broken switch leads or malfunctioning switch.
  - Check T2 transformer secondary voltages at the plugs P1 and P2. Refer to system schematic.
     Replace the transformer if the correct secondary voltages are not present.

If everything above checks out all right, then the PCB1 Control Board should be replaced.

#### 6.2.4 Fault light activates when torch is signaled to fire

The Fault circuit is used to monitor conditions necessary for the safe operation of the PCM-875. The fault light will glow amber under the following conditions and operations will come to a complete stop:

• **High/Low line voltage**. The Fault Light will **rapidly blink on and off** (5 times per second). This indicates that the input voltage is outside the "+" or "-" 15% safe operating range rating.

• Flow fault - The fault light will be mostly on but will blink off for 1/10th of a second every second. This indicates that the air flow is low.

- Check the air pressure at the machine regulator. It should be adjusted to 65 psig. If no air pressure, check the air at the supply point. Also, check for any obstructions in the air hose.
- Air flow may be blocked at the torch tip. Check the torch consumables. Also check for any obstructions in the torch leads.
- NOTE: If above items check OK, the problem is internal. send unit to an Authorized Repair Station for repair.
- Put the 'Air Check' switch to On position. Air should flow through torch. If not, then the flow switch may be stuck due to oil in the air. Clean air flow switch per supplier's instructions or replace switch. To check if the flow switch is open, put voltmeter leads between P1-12 and P1-1. It should read about 12 VDC. When the flow switch closes, the voltage will drop to zero volts.
- Air Check switch may also be malfunctioning if the air is flowing continuously or putting in the On position does not turn air on.

Fault light activates (continued)

• Over Temperature. The fault light will be mostly off but will blink on for 1/10 of a second, every second. This generally indicates that the duty cycle has been exceeded. Allow the power source to cool before returning to operate.

- Thermal switch may be open. It will open if the temperature at the IGBT base reaches 94oC. With the machine power off, check the continuity between P1-1 and P1-2 of the control board. If the switch is OK, then the ohmmeter should read a direct short. If not then it should read open.
- If the switch is malfunctioning, replace it. Clean the surface of the heat sink before installing the switch.

• **Over Current**. The fault light will be on **continuously**. This indicates that the input current to the main transformer has exceeded preset limits.

To check if the output is shorted, measure the resistance by putting the ohmmeter leads (make sure to disconnect HI Frequency leads):"+" of the meter to Torch "+" output terminal and Work "-" lead of the meter to the "-" output terminal. Reading should be about 2 K Ohms. Reverse the voltmeter leads, the resistance reading should be less than 1.5 K Ohms.

If the resistance reading is different than above, check the torch, the output bridge and Filter Board (PCB-5).

#### 6.2.5 Air is On but nothing happens when torch is signaled to fire.

• Check pilot arc fuse located on rear panel. If it is open, nothing will happen when torch switch is depressed.

• Check torch. Make sure heat shield is very tight.

• Check to assure high frequency is present at torch. If not, then listen for high frequency at high frequency generator. It is located on bottom/right side of the unit. High frequency gap is set to .040". **Disconnect HI FREQUENCY leads**. Check for 115 volt supply to high frequency unit between P2-12 & P2-13 of control board with torch switch closed.

• With HI FREQUENCY leads disconnected, measure open circuit voltage. It should be 275 VDC between "Work" and "Torch" terminals. If it is not present then any one of the following may not be working properly:

- Check the operation of the Thermal Switch. See D.3.a. above.
- Check Air Check switch operation. It might be stuck in On position. Pilot arc will not initiate if this switch is in the ON position. (safety reasons)
- Check air flow switch. There may be internal short. See D.2.c above.
- Measure voltage across C1 or C2 capacitor. It should be as follows:
- approx. 325 VDC for the 208/230 volt unit.
- approx. 280 VDC to 325 VDC for 400 volt unit

If not, one of following could be malfunctioning:

- Check the capacitors C1 and C2 for any damage.
- Check input bridge/SCR Module (IBR) This can be checked without taking it out of the circuit using an volt/ohmeter. Replace it if found malfunctioning. Follow bridge installation instructions.
- Check Inrush current resistor, R10 and SCR1.
  Both are located on the input bridge heat sink.
  Replace it if malfunctioning.
- IGBTs (2 on 230 V, and 1 on the 400 V units) may be blown. See IGBT installation procedure. Before replacing IGBTs, make sure to check the zener diodes and pico fuses on the IGBT driver boards.

#### 6.2.6 High Frequency and Pilot Arc are on but Main Arc does not transfer.

- Make sure work clamp is connected to work material.
- Check the torch. Replace consumables if necessary.
- Make sure the current setting potentiometer is set above 10 amps. If it is, set below 10 amps, then HI FREQUENCY will go on and off at 5 sec intervals.

#### 6.2.7 Poor Cutting Performance.

• Check air supply regulator . It should be adjusted to 65-75 psig.

• The air supplied to the torch should be free of oil and water.

• Make sure the consumables in the torch are acceptable.

• Check open circuit voltage.

• Check the output. Use a calibrated current probe capable of measuring 100 amps in the presence of high frequency.

#### 6.2.8 Air does not shut off.

- Check air test, the gas solenoid valve is energized when the switch is in the "on" position.
- Does air flow stop when the torch switch is unplugged? If yes, check and repair the torch. If not, send unit to an Authorized Repair Station for repair.

• Check voltage to solenoid coil, if present when torch switch is unplugged, replace PCB1. If voltage is "0", replace solenoid valve.

6.2.9 Main arc is difficult to start.

• The most common reason is worn or missing consumables. Check and replace if necessary.

- Input air must be clean and dry.
- Input air pressure must be between 65 75 psig.
- Torch connections must be tight.

• Work cable and clamp must be in good condition and must make a good electrical connection to the material to be cut.

• If above items check OK , the problem is internal. Send unit to an Authorized Repair Station for repair.

• Missing or weak pilot arc. Check pilot arc fuse, open circuit voltage, pilot arc resistors and pilot arc wiring.

• Inoperative starter board (PCB-5).

• Check Spark gap in RAS unit. 1mm is desired gap. If gap is to large, spark will be weak or non-existent.

#### 6.3 Reference Voltage Checks

#### A. Control Board Assembly (PCB1)

LED's

LED-1	-	Torch Switch
LED-2	-	High Frequency
LED-3	-	Gas Solenoid Valve
Voltage Test Poin		

Tests are made with power on - no arc.

Disable High Frequency by disconnecting blue wire with black sleeve



For 208/230 VAC input, the IGBT off time is 3msec. For 400/460/575 VAC input, the IGBT off time is 6msec.

SECTION 6	PCM-875A Plasmarc S	ystem	Troubleshooting
6.4 PT-20AMX Tor	ch Troubleshooting		
	Cc	mmon Cutting Pro	oblems
	Lis foll pro PC ma ref ES	ted below are com owed by the proba oblems are determine M-875, refer to the anual. If the proble erring to the mainte AB distributor.	nmon cutting problems able cause of each. If ined to be caused by the e maintenance section of this m is not corrected after enance section, contact your
6.4.1 Insufficient F	Penetration		
	•	Current too low.	
	•	Cutting speed too	o fast.
	•	Damaged cutting	nozzle.
	•	Improper air pres	sure.
	•	Low air flow rate	Э.
6.4.2 Main Arc Ext	inguishes		
	•	Cutting speed too	o slow.
	•	Worn electrode.	
6.4.3 Dross Forma	ation.		
	(I ir	n some materials npossible to get dr	and thicknesses, it may be ross-free cuts.)
	•	Current too low.	
	•	Cutting speed too	o fast or too slow.
	•	Improper air pres	sure.
	•	Faulty nozzle or e	electrode.
	•	Low air flow rate	Э.

# PCM-875A Plasmarc System

# 6.4.4 Double Arcing • .Damaged Nozzle Orifice. • Low air pressure. • Damaged cutting nozzle. • Loose cutting nozzle. • Heavy spatter accumulation on nozzle. 6.4.5 Uneven Arc. Damaged cutting nozzle or worn electrode. ٠ 6.4.6 Unstable Cutting Conditions. • Incorrect cutting speed. • Loose cable or hose connections. Electrode and/or cutting nozzle in poor • condition. 6.4.7 Main Arc Does Not Strike • Worn electrode. • Loose connections.

#### 6.4.8 Poor Consumable Life

- Improper gas pressure.
- Contaminated air supply.

• Worn cable not attached

Low air flow rate

Part 1

# 6.5 230V Power Console Electrical Drawings

#### 6.5.1 230V Console Schematic



#### 230V Schematic Part 2



#### 6.5.2 230V Power Console Wiring Diagrams Part 1







# Troubleshooting

# 230V Power Console Wiring Diagrams Part 2

DETAIL "A" (PCB1)											
	P1		P2			P5			P6		
1	TS1-1	VIO	1	T2-X7	ORN	1	J1-1	CLR (TP	) 1	S2-1	BLU
2	TS1-2	vio	2	SOL1-1	WHT	2	J1-2	BLK (TP	2	S2-2	BLU
3	T2-X9	BRN	3	SOL1-2	GRY	3	T2-X1	YEL	3		_
4	T2-X10	BRN	3	S1-3	GRY	4	T2-X2	YEL	4		_
5	T2-X5	BLU	4	T2-X8	ORN	5	PL2-(+)	RED	5	PCB1 P6-6	ы wht
6	T2-X6	BLU	4	S1-2	ORN	6	PL2-(-)	BLK	6	R1-2 WH	т
7	T4-1	ORN	5							PCB1 P6	5-5 WHT
8	T4-2	ORN	6			7			7	TB4-1	YEL
9	T2-X3	WHT	7	BR-G YI	EL	8			8		_
10	T2-X4	wнт	8 1	BR(+) B	RN	9	R16-1	GRY	8	<u> </u>	—
11	FS-1	RED	9			10			9	TB4-2	ORN
12	S1-4	BLK	10			11			10	PCB4-3	BLK (TP)
			11	T2-X11	vio	12		_			
			11	PL1-1	YEL				11	PCB4-4	RED (TP)
			12	TB1-1	BLU				12	R1-1	BRN
			12	K1-A	BLU				13	R1-3	RED
			13	TB1-2	BLU						
			13	K1-B	BLU						
			14	PL1-2	YEL						
			14	T2-X12	vio						



# 230V Power Console Wiring Diagrams Part 3



#### 230V Power Console Wiring Diagrams Part 4





**RIGHT SIDE VIEW** 

SHEET 2 OF 2

# 6.6 400V Power Console Electrical Drawings

#### 6.6.1 400V Console Schematic Part 1



#### 400V Console Schematic Part 2



#### 6.6.2 400V Console Wiring Diagrams Part 1







# 400V Console Wiring Diagrams Part 2

	<b>P1</b>			P2		P5		P6			
1	TS1-1	VIO	1	T2-X1	ORŇ	1	J1-1	CLR (TP)	1	S2-1	BLU
2	TS1-2	VIO <sup>T</sup>	2	SOL1-1	WHT	2	J1-2	BLK (ŢP	2	S2-2	BLU
3	T2-X3	BRN	3	SOL1-2	GRY	3	T2-X9	YEĻ	3		—
4	T2-X4	BRN	3	S1-3	GRY	4	T2-X10	YEĈ	4		—
5	T2-X5	BLU	4	T2-X2	ORÑ	5	PL2-(+)	RED	5	PCB1 P6-6	WHT
6	T2-X6	BLU	4	S1-2	ORN	6	PL2-(-)	BLK	6	R1-2	WHT
7	T4-1	ORN	5							PCB1 P6-5	WHT
8	T4-2	ORN	6			7	<u> </u>		7	TB4-1	YEL
9	T2-X7	wнĵ	7	IBR-G	YEL	8		—	8		—
10	T2-X8	wнт	8	IBR(+)	BRN	9	R16-1	GRY	8		—
11	FS-1	RED	9			10			9	TB4-2	ORN
12	S1-4	BLK	10		—	11			10	PCB4-3	BLK (TP)
			11	T2-X11	vio	12					
			11	PL1-1	YEL				11	PCB4-4	RED (TP)
			12	TB1-1	BLU				12	R1-1	BRN
			12	K1-A	BLU				13	R1-3	RED
			13	TB1-2	BLU						
			13	K1-B	BLU						
			14	PL1-2	YEL						
			14	T2-X12	vio*						

#### DETAIL "A" (PCB1)



#### 400V Console Wiring Diagrams Part 3





# 400V Console Wiring Diagrams Part 4



TOP AND BOTTOM



# 6.7 Remote Arc Starter (RAS-2) Schematic


SECTION 7	Replacement Parts
7.1 General	
	Always provide the serial number of the unit on which the parts will be used. The serial number is stamped on the unit nameplate.
7.2 Ordering	
	To ensure proper operation, it is recommended that only genuine ESAB parts and products be used with this equipment. The use of non-ESAB parts may void your warranty.
	Replacement parts may be ordered from your ESAB Distributor or from:
	ESAB Cutting Systems GmbH Robert-Bosch-Strasse 20 P.O. Box 1128 D-61184 Karben Phone +011 49 60 39 400 Fax +011 49 60 39 40301 02 http://www.esab.de
	ESAB Welding and Cutting Products ATTN: Customer Service Department PO Box 100545 Ebenezer Road Florence, SC USA 29501-0545 Phone (843) 664-4405 (800) ESAB-123 (372-3123)
	ESAB Cutting Systems - Canada 6010 Tomken Road Mississauga, Ontario, Canada L5T 1X9 Phone (905) 670-0220 Fax (905) 670-4879
	Be sure to indicate any special shipping instructions when ordering replacement parts.
	Refer to the Communications Guide located on the last page of this manual for a list of customer service phone numbers.

### 7.3 PCM-875A Power Console - 230V- (P/N 0558003356)



Ref.	Part Number	Quantity	Description	Elect.
1	951754	1	Lamp, LED Yellow, 12V	PL2
2	0558001176	1	POT, 10K, 30W	R1
3	951526	1	Lamp, Neon, White	PL1
4	21711	1	Gauge, 1.5 160 PSI WHT CDM STL	
5	634518	1	Toggle Switch, 2 pos, 15A, 125V	S2
6	Not Required when RAS-2 is used	1	Reactor Assembly Reference Only	
7	182W12	4	Rubber Foot	
8	Not Required when RAS-2 is used		Spark Gap Assembly	
9	0558003618	1	Wire Kit	
10	673458	1	Contactor, 3 pole, 110VAC, 40A	K1

#### PCM-875A Power Console - 230V- (P/N 0558003356)





Ref.	Part Number	Quantity	Description	Elect.
1	951182	1	Axial Fan, AC	M1
2	17240310	2	Resistor, 10K, 25W	R2,15
3	952233	1	Output Inductor	L1
4	2091558	1	Label	
5			Label	
6	952026	1	Term block, 7 pos, 25A, 12-18AWG	TB4
7	951202	1	Switch, Flow, .25 GPN, SPST	FS
8	952597		Filter EMC, 250.440V 3ph	FN1
9	950249	1	Valve, Solenoid, ¼ NPT, 165 PSI, 24VAC	SOL1
10	Not used in conjunction with RAS-2		Spark Gap	
11	0558003618		Wire Kit	
12	673458		Contactor, 3 pole, 110VAC, 40A	

PCM-875A Power Console – 230V- (P/N 0558003356) Top View-and Right Side



Ref.	Part Number	Quantity	Description	Elect.
1	951340	1	Plug Female, 14 pos, PCB1	P6
2	951339	1	Plug Female, 12 pos, PCB1	P5
3	38214	1	PCB Control	PCB1
4	951339	1	Plug Female, 12 pos, PCB1	P1
5	951340	1	Plug Female, 14 pos, PCB1	P2
6	38131	1	PCB Startup	PCB5
7	31488	1	PCB Ay, Shunt Board	PCB4
8	36586	1	XFMR Assy, Main	T1
9	17300012	2	Resistor, 300W, 12 ohm	R11,12
10	952232	1	Inductor, PFC (used on 230V unit only)	L2
11	32914	1	XFMR Assy Control	T2
12	950487		Terminal Block, 2 pos, 20A	TB1

PCM-875A Power Console - 230V- (P/N 0558003356) Left Side

### 230V CE Detail



Ref.	Part Number	Quantity	Description	Elect.
1	36822	1	Hose, Assy, B/A-WX1/4NPT Rub	
2	0558001177	2	PCB Assy, Mosfet/IGBT Driver Bd	PCB2,3
3	952237	2	Capacitor, 1800uf, 400VDC, W/nut	C1,2
4	90858003	.75FT	Tubing, Plas, .25 od X .04 W BLK	
5	950487	1	Terminal Block, 2 pos, 20A	TB5
6	952235	1	Module, Input bridge/scr	IBR
7	951205	2	IGBT 600V, 100A, Ser H	Q1,2
8	17250010	1	Resistor, WW, Fixed, 50W, 10 ohm	R10
9	17750010	1	Resistor, WW, 50W, 3%, 10 ohm	R7
10	952255	1	Capacitor, 40 uf, 400VDC	C4
11	950711	1	Thermal Switch, 194 deg.	TS1
12	951940	2	Capacitor, 1uf, 630W VDC	C15,16
13	17721020	4	Resistor, WWFAHT, 25W, 1%, 20 ohm NI	R3,4,5,6
14	952150	1	Bridge, 60ADC, 100NS, 600V	D1
15	952208	1	Standoff, insulating	TB3
16	952002	1	Core, Saturable	L3

### 7.4 PCM-875A Power Console – 400V- (P/N 0558003357)



Ref.	Part Number	Quantity	Description	Elect.
1	951754	1	Lamp, LED Yellow, 12V	PL2
2	0558001176	1	POT, 10K, 30W	R1
3	951526	1	Lamp, Neon, White	PL1
4	21711	1	Gauge, 1.5 160 PSI WHT CDM STL	
5	634518	1	Toggle Switch, 2 pos, 15A, 125V	S2
6	Not Required when RAS-2 is used	1	Reactor Assembly Reference Only	
7	182W12	4	Rubber Foot	
8	Not Required when RAS-2 is used		Spark Gap Assembly	
9	0558003618	1	Wire Kit	
			See next illustration	

#### PCM-875A Power Console – 400V- (P/N 0558003357)





Ref.	Part Number	Quantity	Description	Elect.
1	951182	1	Axial Fan, AC	M1
2	17240310	2	Resistor, 10K, 25W	R2,15
3	952233	1	Output Inductor	L1
4	952026	1	Term block, 7 pos, 25A, 12-18AWG	TB4
5	951202	1	Switch, Flow, .25 GPN, SPST	FS
6	952253		Filter, EMC, 400V	FN1
7	950249	1	Valve, Solenoid, ¼ NPT, 165 PSI, 24VAC	SOL1
8	Not used in conjunction with RAS-2		Spark Gap	
9	0558003618		Wire Kit	
10	0558001193		Wire Kit, 400V CE	L2

PCM-875A Power Console – 400V- (P/N 0558003357)





Ref.	Part Number	Quantity	Description	Elect.
1	951340	1	Plug Female, 14 pos, PCB1	P6
2	951339	1	Plug Female, 12 pos, PCB1	Р5
3	38214	1	PCB Control	PCB1
4	951339	1	Plug Female, 12 pos, PCB1	P1
5	951340	1	Plug Female, 14 pos, PCB1	P2
6	38131	1	PCB Startup	PCB5
7	31488	1	PCB Ay, Shunt Board	PCB4
8	36586	1	XFMR Assy, Main	T1
9	673458	1	Contactor, 3 pole, 110VAC, 40A	K1
10	17300012	2	Resistor, 300W, 12 ohm	R11,12
11	32914	1	XFMR Assy Control	T2
12	950487		Terminal Block, 2 pos, 20A	TB1

PCM-875A Power Console – 400V- (P/N 0558003357)

### 400V CE



Ref.	Part Number	Quantity	Description	Elect.
1	36822	1	Hose, Assy, B/A-WX1/4NPT Rub	
2	0558001178	1	PCB Assy, IGBT Driver Bd	PCB2
3	952237	2	Capacitor, 1800uf, 400VDC, W/nut	C1,2
4	90858003	.75FT	Tubing, Plas, .25 od X .04 W BLK	
5	950487	1	Terminal Block, 2 pos, 20A	TB5
6	952235	1	Module, Input bridge/scr	IBR
7	17750010	1	Resistor, WW, 50W, 3%, 10 ohm	R7
8	Not used with RAS-2	1	Spark Gap	SG
9	951800	1	Module Dual IGBT 150V 1200A	Q1
10	952255	1	Capacitor, 40 uf, 400VDC	C4
11	950711	1	Thermal Switch, 194 deg.	TS1
12	951964	1	Capacitor, 2uf, 800VDC	C16
13	17721020	4	Resistor, WWFAHT, 25W, 1%, 20 ohm NI	R3,4,5,6
14	952150	1	Bridge, 60ADC, 100NS, 600V	D1
15	952208	1	Standoff, insulating	TB3
16	952002	1	Core, Saturable	L3

### 7.5 Remote Arc Starter (RAS-2) (P/N 0558003670)











Ref.	Part Number	Quantity	Description	Elect.
1	674969	1	PC Board Filter	PCB1
2	634090	1	Adapt ¼ NPTM C/A W*F Cable	
3	0558003679	1	Reactor Assembly H.F.	
4	Reference		Screw, PHTF #10-32 X .38 inch	

### Remote Arc Starter (RAS-2) (P/N 0558003670)



Ref.	Part Number	Quantity	Description	Elect.
4	37410		Cable Assembly, Arc Starter, 15,2m	
1	37411		Cable Assembly, Arc Starter, 30,4m	
2	0558003692		Hose Air/Oxy ¼ NPTF RAS2, 15,4m	
2	0558003693		Hose Air/Oxy ¼ NPTF RAS2, 30,4m	
2	0558003686		Cable, Pilot Arc, RAS2, 15,2m	
3	0558003687		Cable, Pilot Arc, RAS2, 30,4m	
4	37341		Cable, Power RAS, 15,2m	
4	37342		Cable, Power RAS, 30,4m	
5	0558002818		Spark Gap Electrode Holder Assembly	SG1
6	0558003675	2	Grounding Plate	
7	0558003672	2	Cover, Torch Connect, RAS2/PT20AMX	
8	0558003671	1	Cover, Box Side	
9	950853	2	Fitting, 1/4 NPT to 3/8 id Hose	
10	952860	2	Clamp, 1-ear w/insert 12.8 GER	
11	4600030		30mil Nomex	
12	Reference		Screw, PHTF #10-32 X .38 inch	

#### 7.6 PT-20AMX Plasmarc Cutting Torch



PT-20 AMX Plasma Torch with Coaxial Pilot Arc Cable

With 4 ft. torch leads, without handle rack	P/N 0558002632
With 17 ft. torch leads, without handle rack	P/N 0558002633
With 25 ft. torch leads, without handle rack	P/N 0558003381

Ref.	Description	Part Number
1	Torch Lead Assembly – 4 ft	0558002638
	Torch Lead Assembly – 17 ft	0558002639
	Torch Lead Assembly – 25 ft	0558003383
4	Lock Ring	57N70
5	Rubber Boot	0558001157
6	Wrap with electrical tape as shown	Reference
7	H.F. Connector	17974
8	Set screw 6-32 X 3/16	Reference
9	Insulate with vinyl tubing and secure with electrical tape	Reference
10	Handle and sleeve without rack	22329
11	Handle	Reference
12	Basic Torch Body Assembly	21359
13	O-ring supplied with torch body	5W92
14	O-ring supplied with torch body	488157
15	Shield Shroud – 25 ft	72020003
16	Lubricant	17672

### PT-20 AMX Front End and Spare Parts Kit





#### **Replacement Parts**

Ref.	Description	Part Number	
1	Wrench Seat/Baffle	21375	
2	Baffle Tube	21374	
3	Electrode 50Hz	0558001617	
4	Electrode Insulator	21373	
5	Electrode Holder Assembly	21332	
6	Heat Shield (70 and 100 Amp – Blue)	21326	
_	Nozzle (70 Amp)	21329	
1	Nozzle (50 Amp)	21330	
8	O-Ring	488157	
9	PT-20AMX Spare Parts Kit	0558002319	
	Contents Description	-	Quantity
	Contents Description Heat Shield (70/100 A)*	21326	Quantity 3
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A)	21326 21330	Quantity 3 5
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A)	21326 21330 23129	Quantity 3 5 5
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz	21326 21330 23129 0558001617	Quantity 3 5 5 5 5
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator	21326 21330 23129 0558001617 21373	Quantity 3 5 5 5 5 1
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly	21326 21330 23129 0558001617 21373 21332	Quantity 3 5 5 5 1 1
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly Baffle Tube	21326 21330 23129 0558001617 21373 21332 21374	Quantity 3 5 5 5 1 1 1 1
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly Baffle Tube Pilot Arc Adaptor	21326 21330 23129 0558001617 21373 21332 21374 19497	Quantity 3 5 5 1 1 1 1 1
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly Baffle Tube Pilot Arc Adaptor O-ring	21326 21330 23129 0558001617 21373 21332 21374 19497 488157	Quantity 3 5 5 1 1 1 1 1 5
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly Baffle Tube Pilot Arc Adaptor O-ring Lubricant (1 oz.)	21326 21330 23129 0558001617 21373 21332 21374 19497 488157 17672	Quantity 3 5 5 1 1 1 1 1 5 1
	Contents Description Heat Shield (70/100 A)* Cutting Nozzle (50 A) Cutting Nozzle (70 A) Electrode 50Hz Electrode Insulator Electrode Holder Assembly Baffle Tube Pilot Arc Adaptor O-ring Lubricant (1 oz.) Seat/Baffle Wrench	21326 21330 23129 0558001617 21373 21332 21374 19497 488157 17672 21375	Quantity 3 5 5 1 1 1 1 5 5 1 1 1



The description of the heat shield (P/N 21326) listed above indicates a range of 70 to 100 amperes. The PCM-875A is capable of a maximum of 60 amperes (60% duty cycle). Testing has proven satisfactory results when using this heat shield at 60 amps and lower.

This page intentionally left blank.

See back of Title Page for revision list.

Customer // Technical Support (843) 664-4405 (800) ESAB-123 (372-2123)

ESAB Welding and Cutting Products PO BOX 100545 Ebenezer Road Florence, SC 29501-0545 http://www.esab.com

ESAB Cutting Systems – Canada 6010 Tomken Road Mississauga, Ontario Canada L5T 1X9 Phone: (905) 670-0220 Fax: (905) 670-4879

> ESAB Cutting Systems GMBH Robert-Bosch-Strasse 20 Postfach 1128 D-61184 Karben 1 Phone 011-49-6039-400 Fax 011-49-6039-403-02 http://www.esab.de



ESAB CUTTING SYSTEMS

Printed in U.S.A