

# *Fast Ethernet Print Server*

## *2 Parallel, 1 USB*

## *Hardware User's Guide*

---

---

Rev. 01 (October, 2002)

## **Wichtige Sicherheitshinweise**

1. Bitte lesen Sie sich diese Hinweise sorgfältig durch.
2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie keine Flüssig- oder Aerosolreiniger. Am besten dient ein angefeuchtetes Tuch zur Reinigung.
4. Um eine Beschädigung des Gerätes zu vermeiden sollten Sie nur Zubehörteile verwenden, die vom Hersteller zugelassen sind.
5. Das Gerät ist vor Feuchtigkeit zu schützen.
6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Verletzungen hervorrufen. Verwenden Sie nur sichere Standorte und beachten Sie die Aufstellhinweise des Herstellers.
7. Die Belüftungsöffnungen dienen zur Luftzirkulation die das Gerät vor Überhitzung schützt. Sorgen Sie dafür, daß diese Öffnungen nicht abgedeckt werden.
8. Beachten Sie beim Anschluß an das Stromnetz die Anschlußwerte.
9. Die Netzanschlußsteckdose muß aus Gründen der elektrischen Sicherheit einen Schutzleiterkontakt haben.
10. Verlegen Sie die Netzzuleitung so, daß niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.
11. Alle Hinweise und Warnungen die sich am Geräten befinden sind zu beachten.
12. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
13. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. Elektrischen Schlag auslösen.
14. Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
15. Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
  - a– Netzkabel oder Netzstecker sind beschädigt.
  - b– Flüssigkeit ist in das Gerät eingedrungen.
  - c– Das Gerät war Feuchtigkeit ausgesetzt.
  - d– Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
  - e– Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
  - f– Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
16. Bei Reparaturen dürfen nur Originalersatzteile bzw. den Originaleilen entsprechende Teile verwendet werden. Der Einsatz von ungeeigneten Ersatzteilen kann eine weitere Beschädigung hervorrufen.
17. Wenden Sie sich mit allen Fragen die Service und Reparatur betreffen an Ihren Servicepartner. Somit stellen Sie die Betriebssicherheit des Gerätes sicher.
18. Zum Netzanschluß dieses Gerätes ist eine geprüfte Leitung zu verwenden. Für einen Nennstrom bis 6A und einem Gerätegewicht größer 3kg ist eine Leitung nicht leichter als H05VV-F, 3G, 0.75mm<sup>2</sup> einzusetzen.

# **Trademarks**

Copyright © 2000

Contents subject to change without prior notice.

All trademarks belong to their respective proprietors.

## **Copyright Statement**

No part of this publication may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission, as stipulated by the United States Copyright Act of 1976.

## **FCC Warning**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this user's guide, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## **CE Mark Warning**

This is a Class B product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

注意

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づく第一種情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

---

# **TABLE OF CONTENTS**

<b>ABOUT THIS GUIDE.....</b>	<b>V</b>
<b>INTRODUCTION.....</b>	<b>7</b>
PRINT SERVER FEATURES.....	7
EXTERNAL FEATURES.....	8
<i>Port Connectors.....</i>	9

<i>Network Cable Connector</i> .....	9
<i>DC Power Connector</i> .....	10
<i>LED Indicators</i> .....	10
<b>UNPACKING AND INSTALLATION</b> .....	<b>11</b>
UNPACKING AND INSPECTING THE PRINT SERVER.....	11
INSTALLING THE PRINT SERVER.....	12
POWER ON SELF-TEST .....	13
TESTING YOUR PRINT SERVER.....	14
<b>PRODUCT SPECIFICATIONS</b> .....	<b>15</b>
PRINTER CONNECTION .....	15
NETWORK CONNECTION .....	15
NETWORK PROTOCOLS.....	16
MANAGEMENT AND DIAGNOSTICS.....	16
ENVIRONMENTAL AND PHYSICAL.....	16
<b>PORT PINOUTS</b> .....	<b>17</b>
PARALLEL PORTS.....	17

---

# ***ABOUT THIS GUIDE***

This manual describes the 2 Parallel 1 USB Port Ethernet/Fast Ethernet Multiprotocol Print Server, including a description of the print server's features, as well as the print server installation procedures and troubleshooting selftest results.

For information about software configuration of the Print Server to allow it to be used with your network, consult the *PS Admin User's Guide* included with your Print Server.

---

# INTRODUCTION

The Print Server is a compact print server which connects to your Ethernet or Fast Ethernet network anywhere you wish to locate printer services. It manages the flow of print files from your workstations or file servers to its connected printers, delivering print jobs to high-performance printers much faster than a file server or a PC acting as a print server can.

---

## Print Server Features

---

The Print Server improve network printing services in three ways:

- ◆ The Print Server picks up the workload of managing print file traffic to its connected printers. This provides workload relief to your file servers, and allows the file servers' full capacity to be used for file access or other direct services to network users. On peer-to-peer networks, workstations can print directly to the Print Server without increasing the load of another workstation or server.
- ◆ The Print Server's parallel printer ports are IEEE 1284 compliant high-speed bi-directional ports, which can transmit to high-speed laser printers much faster than a PC's parallel printer port. High-speed laser printers connected to the Print Server's parallel ports can be operated at their full capacity.
- ◆ Because the Print Server is very portable and inexpensive compared to a PC-based print server, and because the Print Server connects to your file servers through the network, printers can be deployed to locations of maximum convenience to users.

The Print Server offers extraordinary flexibility, operating with all major network operating systems and protocols:

- ◆ **TCP/IP**

UNIX lpr/lpd (HP-UX, SunOS, Solaris, SCO, UnixWare, IBM AIX)

Windows NT/2000, Windows 95/98/Me, Windows XP

NetWare 5.x NDPS LPR Remote Printing

- ◆ **NetBEUI**

Windows NT/2000/XP, Windows 95/98/Me, Windows for Workgroups, Microsoft LAN Manager, IBM LAN Server

- ◆ **AppleTalk**

MacOS EtherTalk

Windows-based setup and administration software, *PS Admin*, is supplied with the Print Server, making configuration and management quick and easy. The Print Server also supports configuration and management via the `telnet` protocol for networks without Windows-compatible machines.

---

## External Features

---

This section describes the externally visible features of the Print Server.

### Port Connectors


The Print Server's three printer ports are located on its rear panel. One USB and two identical parallel ports are labeled USB, LPT1 and LPT2. These printer ports are independently configurable using the *PS Admin* program or the print server's `telnet` interface. (See the *PS Admin User's Guide* for information about configuring the print server's ports.)

The print server also supports web configuration permitting users to configure settings through the web browser. Default IP address as follows:

- ◆ Default IP address – 192.168.0.1
- ◆ Subnet Mask – 255.255.255.0

**Note:**

The PC's IP address must correspond with the print server's IP address in the same segment for the two devices to communicate.



Power            LPT2            LPT1            USB    RJ-45

### Rear Panel Connectors

## ***Network Cable Connector***


The Print Server's rear panel features an RJ-45 connector for connection to 10Base-T Ethernet cabling or 100Base-TX Fast Ethernet cabling (which should be Category 5 twisted-pair cable). The port supports the NWay protocol, allowing the print server to automatically detect or negotiate the transmission speed of the network.

## ***DC Power Connector***

The DC power input connector is located on the Print Server's rear panel and is labeled DC 5V.

## ***LED Indicators***

The front panel of the Print Server features five LED indicators:



**Front Panel LED Indicators**

### **◆ Power**

- ◊ Steady or flashing green confirms that the Print Server is powered on.

### **◆ Link/Act**

- ◊ Steady or flashing green confirms that the Print Server has a good connection to the Ethernet or Fast Ethernet network.
- ◊ The indicator blinks off briefly to indicate that the Print Server is receiving or transmitting from the network.

### **◆ USB, LPT1, LPT2**

- ◊ These LED indicators light to show that the Print Server is transferring print data through the appropriate parallel port or USB port.

These three indicators are also used by the print server's power-on self test (POST) to indicate any hardware failures.

---

# ***UNPACKING AND INSTALLATION***

This chapter explains how to install your Print Server and connect it to the network. It also describes the print server self test indications.

---

## **Unpacking and Inspecting the Print Server**

---

Carefully remove all items from the package. In addition to this *Hardware User's Guide*, be certain that you have:

- ◆ One Fast Ethernet print server
- ◆ One AC power adapter suitable for your country's electric power
- ◆ One Print Server Installation CD
- ◆ One Quick Installation Guide

If any item is missing, or if you find any damage or mismatch, promptly contact your dealer for assistance.

---

# Installing the Print Server

---

**WARNING:** *Configuration problems may result if the Print Server is powered up without first establishing its network connection. Follow this procedure to avoid complications at the configuration stage.*

---

---

1. Confirm proper operation of each of the printers to be connected to the Print Server.
2. When you have confirmed proper operation of each printer, switch its power off.
3. Confirm that your network is operating normally.
4. Connect the Print Server to the network, using the RJ-45 (10Base-T/100Base-TX) connector on the print server's rear panel.
5. While each printer is powered off, install a printer cable to connect its parallel port or USB port to the printer port of the Print Server.
6. Switch on each connected printer.
7. Plug the AC power adapter's DC output plug into the DC 5V power socket on the rear panel of the Print Server.
8. Plug the power adapter into an electric service outlet. This will supply power to the Print Server, as it has no external power switch. The Power LED on the Print Server's front panel should light steady green, and the Print Server's selftest will proceed.

---

## Power On Self-Test

---

When the Print Server is powered on, it automatically performs a selftest on each of its major components. The final result of the selftest is signaled by the state of the USB, LPT1 and LPT2 LED indicators following the selftest. Preliminary to the actual component tests, the three LED indicators are tested to confirm their steady and flashing operation.

Immediately after power-up, all five of the LED's should show steady green for several seconds. Then the USB, LPT1 and LPT2 LEDs should flash on simultaneously three times. Irregularity of any of the three LEDs during these LED tests may mean there is a problem with the LEDs themselves. Contact your dealer for correction of any LED problems before proceeding.

The actual component tests immediately follow the LED tests. A normal (no fault) result is signaled by a simultaneous flashing of these three LEDs, followed by a quiescent state with all three LEDs dark.

If the selftest routine traps any component error, then following the LED tests the selftest will halt and the LED's will continuously signal the error according to the following table. In the event of any such error signal, contact your dealer for correction of the faulty unit.

LED Name			Faulty Component
USB	LPT1	LPT2	
low speed flashing			Need Reload Firmware
on			DRAM error
1 long 2 short			Timer INT error
1 long 3 short			Flash Protected
1 long 5 short			Flash Erase/Program error
1 long 6 short			LAN Controller error
1 long 8 short			Parallel-1 Controller error
1 long 9 short			LPT1 error
1 long 12 short			Parallel-2 Controller error
1 long 13 short			LPT2 error
1 long 14 short			MII error
1 long 18 short			USB error

---

## Testing Your Print Server

---

The *PS Admin* software includes a Print Test function for confirmation of printer cable connections and functions. That operational test can be completed after you have installed the *PS Admin* software, and have configured your Print Server and its ports. See the *Testing Your Print Server* section of the *PS Admin User's Guide*.

A

---

# PRODUCT SPECIFICATIONS

---

## Printer Connection

---

**Standards:** IEEE 1284 bi-directional parallel interface

USB 1.1

**Ports:** Bi-directional 25-pin parallel ports × 2, USB port × 1

**Parallel Port Bi-directional Communication:** Hewlett-Packard PJL (Printer Job Language) supported

---

## Network Connection

---

**Network Standards:** IEEE 802.3 10Base-T Ethernet, IEEE 802.3u 100BASE-TX Fast Ethernet

**Network Data Transfer Rate:** 10/100Mbps

**Network Connector:** RJ-45 connector for 10Base-T or 100BASE-TX unshielded twisted pair connection; NWay automatic speed negotiation supported.

---

# Network Protocols

---

**Ethernet Frame Types:** 802.2, 802.3, Ethernet II, SNAP (auto-switching)

**Transport Protocols:** TCP/IP, NetBEUI, AppleTalk/EtherTalk

**TCP/IP Protocols Supported:** BOOTP, SNMP, Telnet, TFTP, FTP, LPD, RARP, DHCP

---

## Management and Diagnostics

---

**Standard:** SNMP

**MIBs:** MIB-II (RFC 1213)

**Diagnostic LED Indicators:** Power, Link/Act, USB, LPT1, LPT2

---

## Environmental and Physical

---

**Power Supply:** External power supply providing 5VDC input

**Dimensions:** 193mm × 117mm × 34mm

**Weight:** approx. 300g

**Operating Temperature:** 0 to 50°C

**Storage Temperature:** -25 to 55°C

**Humidity:** 5% to 95% non-condensing

**Emissions:** FCC Class B, CE Class B, VCCI Class B

---

# PORT PINOUTS

This appendix shows the pinouts of the Print Server parallel port connector.

---

## Parallel Ports

---

The following table lists the pinouts of the print server's 25-pin parallel port connector (identical to the connector used on most personal computers), as well as the 36-pin Centronics connector used on most printers.

Signal names beginning with *n* are active-low signals.

25-pin	Centronics	Signal	Source
1	1	nStrobe	Host
2	2	Data 1	Bi-directional
3	3	Data 2	Bi-directional
4	4	Data 3	Bi-directional
5	5	Data 4	Bi-directional
6	6	Data 5	Bi-directional
7	7	Data 6	Bi-directional
8	8	Data 7	Bi-directional
9	9	Data 8	Bi-directional
10	10	nAck	Printer
11	11	Busy	Printer
12	12	PError	Printer
13	13	Select	Printer
14	14	nAutoFd	Host
15	32	nFault	Printer
16	31	nInit	Host
17	36	nSelectIn	Host
18-25	16, 17, 19-30	Ground	

---