



Ascom Eurit 25

ISDN Telephone

User manual

((Bild (folgt)))

Dear Customer

Many thanks for purchasing this **Ascom** product.

This user manual will help you take full advantage of the features of your Ascom Eurit 25 phone. You will find the following features particularly useful:

– **Up to 3 users on the same set, with individual settings**

Because the Ascom Eurit 25 can handle up to 3 numbers, it is an ideal phone for households with several members.

The user key enables effortless switching between users. Everyone can immediately find his or her own number with customised settings.

Each number can be programmed with its own settings, including: ringing melody and volume, charge accounting per user, various call forwarding options etc.

– **Phonebook**

Up to 40 numbers and names can be stored in the phonebook.

– **Caller list**

This list stores the numbers of the last 20 callers who have tried to reach you. The display indicates the number of unanswered calls.

– **Short Message Service (SMS)**

You can send and receive SMS messages

– **Provider selection**


If you want the choice of several providers for telephoning, the Ascom Eurit 25 is the right phone for you. For example, you can program numbers in your phonebook with the provider prefix so that calls are always routed via the relevant provider.

– **A range of advanced features**

The Ascom Eurit 25 offers 3-way conferencing, callback on busy, and SMS. Added to this, your phone supports all other ISDN supplementary services.

Please read the safety precautions before starting up your phone, and keep the User Manual in a safe place!

Overview and operating elements



Overview and operating elements

- 1 **Handset hook**
- 2 **Loudspeaker key**
- 3 **◀ Scroll left (back) in text**
- 4 **ESCAPE-key**
Aborts functions, switches to standby mode.
- 5 **Delete-key (Clear)**
- 6 **OK key**
Confirms or performs functions etc. Accesses function menu.
- 7 **Mute key**
Deactivates the handset microphone so that the calling partner cannot hear.
- 8 **User key**
Change user.
- 9 **Menu key**
Opens access to main menu.
▶ Scroll right (forward) in text
- 10 **LED status display**
- 11 **Emergency mode switch**
- 12 **Speed dial keys**
- 13 **Dialling keypad, alphanumeric entry**
- 14 **Plus key**
Loudspeaker volume up.
- 15 **R key (enquiry key)**
- 16 **Redial key**
- 17 **Minus key**
Loudspeaker volume down.

LED status display

The LED indicates the status of your phone

LED lit: »Unconditional call forwarding« or »Ringing tone off« (ringing volume set to zero) has been activated by at least one user.

LED flashing: Incoming call with ringing tone volume set to zero (»Ringing tone off«), or message waiting in your inbox (MWI).

LED unlit: Normal mode.

Ascom Eurit 25

With your purchase of the Ascom Eurit 25 you have selected a Swiss-quality product. Congratulations and thank you for your confidence in us.

The Ascom Eurit 25 is designed for connection to the public ISDN network.

If you plan to use the Ascom Eurit 25 in conjunction with a PBX, please refer to the section on »PBX access«.

Please read this user manual carefully to learn about the benefits of your new Ascom Eurit 25 and get the maximum use from them.

Keep this user manual in a safe place!

Important information on your ISDN connection

This user manual describes all the functions for which you must apply your network provider. Some of these functions are provided at a charge.

The range of services available to you depends on the connection type.

For further information on the services available via your ISDN connection, contact your network provider.

Contents

Overview and operating elements II

 LED status display III

Introduction 5

 The phone 5

 User manual 6

 How to proceed 7

Startup 8

 Unpacking the phone 8

 Positioning 9

 Connecting the phone 9

 Write-on label 10

 The display 11

 Display symbols 12

 Using the function menu 13

 Setting up Multiple Subscriber Numbers (MSN) 14

Contents

Telephoning	16
User concept	16
Manual dialling	17
Call back on busy / no reply / autodial	18
Redialling	19
Dialling from the phonebook	20
Dialling numbers in the caller list	22
Dialling numbers in the call log	24
Speed dialling	26
Provider selection	27
Listening by loudspeaker	28
Setting the volume	28
Microphone off	28
Parking a call	29
Incoming calls	31
ETV® Online (only for Switzerland)	32
Conducting two calls/switching between calls	35
Transferring calls	37
Three-party conference	38
Call forwarding	40
Direct call	41
Phonebook	42
Entering number and name only	43
Assigning options to numbers	45
Changing entries	48
Deleting entries	50
Additional settings	51
Enter additional users (MSN)	51
Programming speed dial keys	54
Setting the date and time	57
Interception circuit (malicious call identification)	57
CLIR Calling Line Identification Restriction	58
Reject anonymous calls	59
Deactivating call waiting	59
Setting the ringing tone melody and volume.	60
Ascending ringing volume	61
Setting the language	61
Setting the charge factor and currency	62
Individual user charges, call charge total	63
Setting the contrast	64

Contents

Short Message Service (SMS)	65
Options	65
Incoming SMS signalling	65
Handling incoming SMS messages	66
Composing, sending, saving SMS messages	68
Retrieving, sending or deleting stored SMS messages	69
PBX access	70
PBX access on/off	70
Entering the Exchange Access Code (EAC) for outgoing calls	71
Entering EAC for incoming calls	72
Internal number length	72
Setting the transfer type	73
Keypad information	75
Send automatic keypad on/off	76
Attachment	77
Renumbering	77
Emergency operation	79
Resetting the phone	80
Headset connection	80
Show software version and checksums	81
PC dialling option (Office Manager)	81
Remote download	82
Troubleshooting	83
Care	83
Summary of default settings	84
Technical Data	85
Safety tips	85
Warranty conditions	86
Disposal	86
Approval and CE code	86
Declaration of conformity	87
Menu structure	88
Write-on labels	91
Warranty Certificate	93
Key words	95
Notes	97

Introduction

The phone

Connection type

Your phone is designed for use with an ISDN basic access (DSS1 protocol, Euro-ISDN) and can be operated on your subscriber connection (NT+2ab), an ISDN bus (S-Bus) or connected to a PBX. The phone is powered via the NT+2ab power supply or the PBX. In the event of a power failure, a backup supply powers the phone via the local exchange (for PBX operation, refer to the PBX documentation).

User concept

Every user can define his or her own settings. Separate call charges are recorded for each user (for details on the user concept, see »User concept« in the section on »Telephoning«).

Advanced features

Your dynamically managed phonebook can store up to 40 numbers.

Four speed dial keys, each for two numbers, allow you to dial numbers simply by pressing a key.

A wide range of user-friendly features make your new phone easy to operate and enhances calling comfort. For a summary of these features, see the contents list.

Introduction

User manual

This user manual will help you get to know all the functions of your ISDN phone. Keep the instructions near your phone.

The contents list and comprehensive list of key words will help you to find what you are looking for quickly.

Structure of user manual

The individual sections contain a full description of the functions. There is no need to leaf through the entire book to find out about an operating procedure.

Firstly, general information on the function is given. Then the procedure is described step by step. The left margin displays the keys to be activated. To the right of this you will find information on the procedure and the associated display.

The text may be followed by a comments section:

- ⇒ *This provides general information or tips and tricks which further simplify the use of your phone.*

Pictograms

Generally the operating steps are accompanied by the keys to be activated. For procedures which do not require keys or where the key covers several functions, the following pictograms are used:



Any entry via the keypad.



Lift the handset.



Replace the handset.

Or...

This comment appears in the left key margin to indicate alternatives.

...Continue

This appears in the left key margin after an alternative action to indicate that the procedure should be continued from this point.

Introduction

How to proceed

Read the section on »Startup« first.

If you plan to use the phone in conjunction with a PBX, please refer to the Section on »PBX access«.

Look up the procedure/function in the contents or key words list. Go to the relevant page and follow the instructions.

If you encounter problems, press the ESCAPE key briefly to go back one step in the menu or hold the ESCAPE key down longer to abort the function . Repeat the step again or refer to the section on »Troubleshooting«.

Enjoy getting to know your phone!

Startup

Your feature-rich Ascom Eurit 25 phone will only function to your satisfaction if you meet all the requirements for startup.

Unpacking the phone

Contents of the package

- 1 Ascom Eurit 25 phone
- 1 handset
- 1 handset cord
- 1 connection cord
- 1 operating manual

Checking the contents of the package

Before you set up and connect your Ascom Eurit 25, check the contents of the package carefully for

- damage to the actual packaging, which may indicate that the phone has been damaged in transit!
 - visible damage to the handset or phone!
 - damage to the connection cords, e.g. to the connectors or cable sheathing!
- ⇒ *Under no circumstances must the phone be put into operation if damaged! If in doubt, contact your dealer.*
- ⇒ *Please keep the original packaging. You can use it for transporting the phone during moves or sending in the phone for repairs.*

Positioning

Place the Ascom Eurit 25 on an even, dry surface within range of the connection socket (NT+2ab or wall socket). If the selected position is too far from the connection socket, use an approved extension cable which you can buy from a specialist dealer.

The phone is designed for normal operating conditions. Modern furniture features a wide range of varnishes and plastic veneers and is treated with a large number of different polishes. Some of these agents may contain ingredients that corrode and soften the plastic feet of the phone. If this happens, it may leave undesirable marks on the furniture surface. Understandably, Ascom cannot accept any liability for such damage.

- *Make sure the telephone connection cord is safely stowed to prevent tripping on it.*
- *Do not plug the connection cord in sockets other than the one for which it is intended.*

Connecting the phone

The connection sockets for the handset and connection cord are located on the base of the phone. Connect the handset first, then plug the phone in to the jack.


Connecting the handset

The connectors at both ends of the spiral cord are the same size.

Plug the connector at the longer, straight end of the cord into the socket on the phone base (1) marked with the handset symbol.

Press the cable into the cable duct (2). To do this, use a flat, thin object to press the cord under the grips.

Plug the connector at the other end of the spiral cord into the socket on the handset (3).



Startup

Connecting the phone

Plug the smaller of the two connectors on the telephone connection cord into the socket on the phone base (1) marked with the phone symbol.

Press the cable into the cable duct (2). To do this, use a flat, thin object to press the cord under the grips.


Turn the phone over again and set it on its feet. Lift the handset.

Plug the larger connector at the other end of the telephone connection cord into the wall socket (3) or NT+2ab.

The display shows "Please enter at least one MSN (subscriber number) with name>OK<". To set up multiple subscriber numbers or MSNs, refer to the section on "Setting up Multiple Subscriber Numbers (MSN)".

Lift the handset. You will hear the dialling tone. Now you can start telephoning!

- *Make sure the telephone connection cord is safely stowed to prevent tripping on it.*
- *Do not plug the connection cord in sockets other than the one for which it is intended.*



Write-on label


The phone is delivered with the write-on label already inserted.

The last page of this user manual contains additional labels for the speed dial keys. Cut a new label out whenever you need one.

Insert the cut-out label into the recess near the speed dial keys (1). If you already know which numbers are to be assigned to these keys, you can complete the label now.

Place the Perspex cover on the label field into the recess (2) and press lightly until it fits into position.

- *If you want to add other numbers or do not know at startup which numbers you will be using, you can easily remove the Perspex cover for subsequent modification. Lift the cover by placing a fingernail under the notch at its edge. Add the number(s) and replace the cover as described above.*




Startup

The display

Your Ascom Eurit 25 is equipped with a display which shows various pictograms indicating the menu function/status as well as a text line with explanatory text.

The display is always active to indicate the status of your phone.

Standby display



The standby display indicates the status of your phone.


Status symbols in standby mode (shown in example: user code)

Time

Date or current call

If unanswered calls have been registered, the date display disappears and is replaced by the call count.

Function display



The pictogram line shows the current status (e.g. user) or menu position.

The text line shows the current function, menu or sub-menu. Use the menu key and left arrow key to scroll through menu functions and press the OK key to confirm your selection.

The arrow keys are also used to select a specific entry position e.g. for entering names via the keypad.

Display symbols



User codes from A to C



TEXT MODE – The keypad is in text mode i.e. letters rather than numbers can be entered.



DIRECT CALL – The direct call is activated (lift handset and press any key).



CALL BACK – One or more call backs (on busy or no answer) are activated. The symbol disappears only when all call backs are deactivated. A flashing symbol indicates an automatic call back which you can activate by pressing OK.



CALL FORWARD – One or more call forwards have been activated. The symbol disappears only when all call forwards are deactivated.



LOUDSPEAKER – The loudspeaker is active.



MICROPHONE – The microphone is switched off (microphone mute).



SUPPRESS NO. – Your own (outgoing) number is suppressed i.e. it is withheld from the person you are calling.



HEADSET – The headset is activated.



RINGING TONE OFF – The loudspeaker is switched off (i.e. ringing volume = 0).



MWI – Your phone can evaluate special signalling (MWI).



CALLER LIST – List of unanswered calls to your Ascom Eurit 25.



SHORT MESSAGE SERVICE (SMS) - You have SMS messages waiting on your Ascom Eurit 25.



INCOMING SMS MESSAGES



UNSENT SMS MESSAGES



PROVIDER – calls are routed via a preset provider.

Using the function menu

Operation of your Ascom Eurit 25 is menu-guided.

To call up menus and scroll through sub-menus, you have two options:

Menu key




If the display is in default mode (standby) and the handset is on-hook, press the menu key to access the first main menu »Phonebook«. Press the menu key again repeatedly to scroll through the main menus.

Once you reach the end of the main menu list, press the menu key again to go back to the top.

Press the OK key to confirm the selected main menu.

OK key and arrow keys



The OK key is in the centre of the keypad under the display.

Press this key to confirm the menu or the item you have selected using the arrow keys.

The left arrow key (<) takes you back one step in the current menu. The right arrow key (>) takes you forward one step in the current menu. The arrow keys are used to select menus, change the entry position or set the volume.

Escape key



Press the ESCAPE key briefly to switch back one menu level, hold down to exit the selected menu or abort a function. The display returns to the default mode (standby).

- ➡ *Menus or functions you are currently in are aborted by incoming calls or can be exited by lifting the handset or pressing the loudspeaker button.*

Setting up Multiple Subscriber Numbers (MSN)

When applying for your ISDN connection from your network provider, you will have received at least three numbers for your connection (Your Eurit 25 supports 3 numbers). These numbers can be assigned to different devices or programmed on your Ascom Eurit 25 as user-specific numbers (MSN). For example, a different ringing tone melody can be set for different MSNs.

If you have not set an MSN for your phone, it will ring whenever any of the assigned numbers is called, even if you have assigned one of them to another device e.g. a fax machine.

To get the best out of your Ascom Eurit 25, you must set at least one user. This is done automatically by giving the phone an MSN. See the section on »Additional settings« for how to assign other users.

⇒ *You cannot assign the same MSN to several users.*

Programming the multiple subscriber number (MSN) on startup

The display shows the following text: »Please enter at least one MSN (subscriber number) with name>OK<«.



Press the OK key. »Set MSN« appears.



Press the OK key again. The display shows »MSN A«. You can use the arrow keys to scroll between the three possible MSNs (A, B or C). Go back to the »MSN A« display.



Press the OK key again. The display shows »No._« with the cursor position.



Using the keypad, enter one of the MSNs assigned to you by your network provider. Enter the number with prefix.
If you have entered the number incorrectly, press the left arrow key (<) until the cursor position reaches the error. Enter the correct number to overwrite the incorrect one and press the right arrow key (>) until you reach the end of your entry.



Press the OK key. The display shows »Name_« with the entered number. The phone is now in text mode. If you do not want to enter a name, the current display remains until you press the OK key.

Or...



You can enter the name of user A. Press the key containing the letter or character you wish until the letter appears, e.g. for K, press key 5 twice. Press the # key to switch between upper and lower case lettering.

In the case of double letters or if the following letter is on the same key, wait briefly before pressing the key again. Proceed as above for every letter you need.

If you have entered a letter incorrectly, press the left arrow key (<) until the cursor position reaches the error. Enter the correct letter to overwrite the incorrect one and press the right arrow key (>) until you reach the end of the text. The following letters and characters are available on the keys in text mode:

1	- . ? ! , ; ' "
2 OFF	A B C a b c Ä Å Æ Ç ä å á â ã æ ç
3 OFF	D E F d e f É ê ë ì
4 OFF	G H I g h i ï ï ï
5 OFF	J K L j k l
6 OFF	M N O m n o Õ Ñ Ø ö ñ ò ó ô õ ø
7 OFF	P Q R S p q r s ß
8 OFF	T U V t u v Ü ü ú û
9 OFF	W X Y Z w x y z ÿ
0	Space # +
*	* / () < = > % & @ \$ °
□	Upper/lower case

...Continue



Once you have entered the name or if you do not wish to enter a name, press the OK key. A short acoustic signal indicates that the MSN has been saved successfully. "MSN A" appears in the display. For additional MSNs, press the right arrow key to select the MSN to be assigned. Continue from the third operating step described above.



If you do not wish to assign additional MSNs and program other users, press the ESCAPE key. The display returns to default mode.

- If you have not entered any user names, the number is regarded as the user name.
- Once the MSN has been set, your phone only rings when this number is called.

Telephoning

This section describes the various options your Ascom Eurit 25 offers on the ISDN connection. All options listed here are valid for all users you have assigned to the phone. See »Additional settings« for how to assign three different users. This describes the different settings which can be made for different users.

Your Ascom Eurit 25 can also be operated in conjunction with a PBX with the same options as listed below. The range of additional features available to you and how you use them is dependent on the PBX type. See »PBX access« in the Attachment for how to connect your phone to a PBX.

- ⇒ *All options listed below assume that at least one MSN (Multiple Subscriber Number) and one user has been set, as described in the section on »Startup«.*

User concept

The Ascom Eurit 25 allows you to assign three different users to a single phone. For example, if you use the phone at home you can set it for the following users : »Mother«, »Father«, and »Daughter«, or for business purposes for »Company«, »Club« and »Private«. You can switch from one user to another by pressing the user key. The display shows the active user's code (A, B, C).

Once you have defined the relevant settings for each user, your Ascom Eurit 25 handles various functions individually depending on the set user.

For every call the active user makes, his number is presented to the called party. Incoming calls are distinguished from outgoing calls and displayed in the caller list. The phone calculates the charges separately for each user. Calls can be diverted according to the user's requirements etc.

- ⇒ *The detailed procedure for setting different users is described in the Section on »Additional settings« under »Entering additional users«.*

Manual dialling

- ⇒ *If only one user is assigned to your Ascom Eurit 25 or if your code is already displayed, there is no need to press the user key before making a call.*

Direct dialling (off-hook dialling)



Select the user.



Lift the handset.



Enter the number with prefix. The phone immediately begins dialling. Wait for the connection and make your call.



Replace the handset to terminate the call.

Dialling preparation (on-hook dialling)



Select the user.



Enter the number with prefix. If you have entered a wrong number, see instructions below.



Lift the handset. The phone dials the number entered. Wait for the connection and make your call.



Replace the handset to terminate the call.

- ⇒ *For both dialling modes: If you make a call while a user code other than your own is displayed, the call is made with the displayed user's attributes and at his cost.*
- ⇒ *On-hook dialling only: If you have entered a number incorrectly, press the left arrow key (<) until the cursor reaches the error. Press the right key to overwrite the incorrect number. To delete an individual number, press the clear key (DEL). Use the right arrow key to go to the end of your entry.*

Call back on busy / no reply / autodial

The automatic »Call back on busy« function saves you having to redial a busy number. If you hear a busy signal, activate »Call back on busy« and an acoustic signal will alert you that the person is now free.

If the person you are calling is not available (no reply), call back can be activated.

Called party is busy:



»Busy« is displayed along with the flashing display symbol \ddagger (call back prompt).

Press the OK key to access the function menu. »Call back« appears in the display.



Press the OK key to activate the call back.

Or...

The person you are calling does not reply:

The display symbol flashes (i.e. »Call back on no reply« is offered).



Press the OK key.

»Call back« appears in the display.



Press the OK key.



Replace the handset.

- ⇒ *A call back remains active for approximately 45 minutes. After this it is automatically cancelled by the exchange.*
- ⇒ *One MSN can activate several call backs. Up to 5 call backs can be activated for all users.*


Cancel call back

To cancel the call back before the person becomes free:



Press the redial key. The first number on the redial list is displayed.



Use the arrow keys (<) or (>) or  to select the number with the active call back.



Press the OK key to confirm.



»Delete call back« is displayed.
Press the OK key to confirm.

- ⇒ *The redial list and call back list are combined in your Ascom Eurit 25 .*

Redialling

Your Ascom Eurit 25 contains a redial memory which registers the last ten numbers dialled. This memory is user-independent. Once more than ten numbers have been dialled, the oldest is deleted from memory.



Selecting the user.



Press the redial key until the relevant number is displayed.

Or...



Press the arrow keys (<) or (>) to scroll through the redial list.



To obtain information on charges and call duration, press the OK key. The display shows the »Delete call back« menu if a call back has been activated for this number. In this case, press the right arrow key (>) to access the info menu.



When »Info« is displayed, confirm by pressing the OK key. The charge total and duration of the call are displayed.



...Continue



You have selected one of the numbers on the redial list. Lift the handset to have your phone automatically dial the number. Wait for the connection and make your call.



Replace the handset to terminate the call.

⇒ *With handset off-hook, select the entry by pressing the OK key, use the left arrow key (<) to go to »Dial« and press the OK key to confirm.*

Deleting the number from the redial memory



Press the redial key until the relevant number is displayed.



Press the OK key. The display shows »Info« or »Delete call back«.



Press the right arrow key (>) until the »Delete« display appears.



Press the OK key to confirm. The entry is deleted from the redial memory.



To exit the function, press the ESCAPE key.

Or...



Once the relevant number is displayed, press the delete key DEL. The entry is deleted from the redial memory.

Dialling from the phonebook

Your Ascom Eurit 25 has an electronic phonebook for storing 40 names and numbers. The phonebook is available to all users.

To set up the phonebook, see the section on »Phonebook«.

To dial from the phonebook, you have two options:

Alphabetic search for the number



Select the user.



Press the menu key. »Phonebook« appears in the display.



Press the OK key to show the first entry in the phonebook.



Keep pressing the key containing the first letter of the name you are looking for until the first entry beginning with this letter is displayed.

Example: You want to call »Natalie«: Press key »6« twice. On the first press, the first name beginning with M is shown. On the second press, the first name beginning with N is shown.



If the name you are looking for is still not shown i.e. because it comes after the first entry in the alphabet, press the right arrow key (>) to scroll down until you have found the name.



Lift the handset. The phone automatically dials the number. Wait for the connection and make your call.



Replace the handset to terminate the call.

- ⇒ *If you have scrolled down too far, press the left arrow key (<) to scroll up.*
- ⇒ *With handset off-hook, scroll through the phonebook. Select the entry by pressing the OK key, use the left arrow key (<) to go to »Dial« and press the OK key to confirm.*

Scrolling through the phonebook



Select the user.



Press the menu key. »Phonebook« appears in the display.



Press the OK key. The first phonebook entry is displayed.



Press the right arrow key (>) to scroll down the phonebook, and the left arrow key (<) to scroll up.



If you have found the name in this way, lift the handset. The phone automatically dials the number. Wait for the connection and make your call.



Replace the handset to terminate the call.



For both dialling modes: If you make a call while a user code other than your own is displayed, the call is made with the displayed user's attributes and at his cost.

Dialling numbers in the caller list

This allows your Ascom Eurit 25 to register all calls not answered by you. The caller list can contain up to 20 numbers.

For numbers registered in the caller list, the display shows two numbers separated by brackets. The number before the brackets indicates how many calls have been registered for the set user, the number after the brackets indicates the total number of unanswered calls.



Select the user.



Use the arrow keys to switch to the »Caller lists« menu. Press the OK key to confirm. The display shows »Unanswered calls«.



Press the OK key to show the number of the most recent missed call or, if this is stored in the phonebook, the caller's name.

Or...



Press the arrow keys (<) or (>) to scroll through the caller list. The end of the caller list is shown as »End of list«.



...Continue



To obtain information on the date and time of the call, press the OK key. »Info« is shown. Press the OK key to access the appropriate display.



You have selected one of the numbers on the caller list. Lift the handset to have your phone automatically dial the number. Wait for the connection and make your call.



Replace the handset to terminate the call.

- ⇒ *If your Ascom Eurit 25 is connected to a PBX, the PBX must also support the CLIP function (Calling line ID) in order to keep a list of calls.*
- ⇒ *With handset off-hook, scroll through the caller list. Select the entry by pressing the OK key, use the left arrow key (<) to go to »Dial« and press the OK key to confirm.*
- ⇒ *If a caller has suppressed his number or if no number could be transmitted, the entry in the caller list shows »Not available«.*

Saving numbers in the caller list

You can transfer the numbers in the caller list directly to your phonebook.

The caller list is open and the number is displayed.



Press the OK key to access »Info«.



Use the arrow keys to switch to the »Info Phonebook« menu. Press the OK key to confirm. You now have the option of assigning a name to the number »Name _« is displayed. The number is entered in the phonebook as soon as you press the OK key.



Lift the handset if you want to dial the number, or press the ESCAPE key to exit the function.

Deleting numbers in the caller list

You have opened the caller list as described above.



Press the arrow keys (<) or (>) to scroll down the caller list until you have found the number.

Press the OK key to access the sub-menu.



Use the arrow keys to switch to the »Delete« menu.

Press the OK key to delete the entry from the caller list.



To exit the function, press the ESCAPE key.

Or...



Once the relevant number is displayed, press the delete key. The entry is deleted from the caller list.

Dialling numbers in the call log

The last 10 calls answered on the Ascom Eurit 25 are stored in the call log. This list is available to all users. After ten calls, the oldest number is deleted from the list.



Select the user.



Press the menu key to access the »Caller list« menu. Press the OK key to confirm. The display shows »Unanswered calls«.



Use the arrow keys to switch to »Answered calls«. Press the OK key to show the number of the last answered call, or the name of the caller if stored in the phonebook.



Or...



Press the arrow keys (<) or (>) to scroll through the call log. The caller's name is displayed if stored in the phonebook.



...Continue



To obtain information on the date and time of the call, press the OK key next to the caller's number or name. »Info« is shown. Press the OK key to confirm.



You have selected one of the numbers on the caller list. Lift the handset to have your phone automatically dial the number. Wait for the connection and make your call.



Replace the handset to terminate the call.



With handset off-hook, scroll through the call log. Select the entry by pressing the OK key, use the left arrow key (<) to go to »Dial« and press the OK key to confirm.

Saving numbers in the call log

You can transfer the numbers in the call log directly to your phonebook.

The call log is open and the number is displayed.



Press the OK key and use the arrow keys to switch to the sub-menu until »Into Phonebook« appears .



Press the OK key again to enter the person's name (optional).



Press the OK key again to complete the entry. The number is now stored in the phonebook.

Lift the handset if you want to dial the number, or press the ESCAPE key to exit the function.

Deleting numbers in the call log



Press the menu key to access the »Caller list« menu. Press the OK key to confirm. The display shows »Unanswered calls«.



Use the arrow keys to switch to »Answered calls«. Press the OK key to show the number of the last call, or the name of the caller if stored in the phonebook.



Press the left or right arrow keys (<) (>) to scroll down the call log until you have found the number.



Press the OK key to confirm. »Info« is shown.



Use the arrow keys to switch to the »Delete« menu. Press the OK key to confirm. The entry is deleted from the call log.




To exit the function, press the ESCAPE key.

Or...



Once the relevant number is displayed, press the delete key DEL. The entry is deleted from the call log.

Speed dialling



Four speed dial keys are available for storing 8 frequently used numbers or functions/services. By pressing the relevant key once or twice, you can automatically dial the numbers or functions/services stored under this key.



Press the key once to display the first stored number. Press twice to display the second stored number.



Lift the handset. The phone automatically dials the number. Wait for the connection and make your call.



Replace the handset to terminate the call.

- ⇒ *Your Ascom Eurit 25 is delivered with the first speed dial key programmed for »Send SMS«*
- ⇒ *You have the option of deleting this function and reprogramming the speed dial key.*

Provider selection

You can also telephone via another provider if you subscribe to their service. You have the option of assigning a provider to phonebook entries (see »Phonebook«): Outgoing calls to these telephone numbers are always carried by the defined provider.

Defining a fixed provider

If you always want to dial via the same provider, you can define a fixed provider:



Press the menu key repeatedly until the display shows »Provider«.



Press the OK key to confirm.



The display shows »Fixed provider«. Press the OK key to confirm. The display shows »Fixed provider_« and the current setting.



Press the right arrow key to select the provider.



Press the OK key to confirm. The pictogram **P** (Provider) is displayed.

Programming the provider list

If you want to use different providers, you can enter these in the provider list. You may program up to 4 providers.



Press the menu key repeatedly until the display shows »Provider«. Press the OK key. The display shows »Fixed provider«.



Press the menu key. The display shows »Provider list«.



Press the OK key to access »1:Provider«. Press the OK key again. »No_« and the cursor position are shown.



Enter the provider's code, press OK to confirm. »Name_« and the cursor position are shown. Enter the provider's name (max. 8 characters).



Press the OK key to confirm. To enter a second provider, proceed as described above.

Telephoning

Listening by loudspeaker

If you press the loudspeaker key during a call, anyone present in the room can listen in to your call.

You are talking on the handset and want others in the room to listen in.



Press the loudspeaker key to activate the loudspeaker.



Press the loudspeaker key again to deactivate the loudspeaker.



Replace the handset to terminate the call.

Setting the volume

If the loudspeaker is activated, you can change the volume.



Press the plus key. The volume is increased each time you press the key.



Press the minus key. The volume is decreased each time you press the key.

Microphone off

If you do not want your call partner to hear you e.g. if you want to ask a question or talk to someone in the room, you can switch the handset microphone off. You can still hear the call partner.

You are conducting a call:



Press the mute key. The symbol ☒ is displayed and your call partner no longer hears you.



Press the mute key again to resume talking to your call partner (the symbol ☒ disappears and the call partner can hear you again).

Parking a call

You can park a call for up to 3 minutes and retrieve it on another phone during this time. It is also possible to unplug the phone, reconnect it at another phone socket on the same ISDN connection, and continue your call.

You can park a call automatically or manually:

- ⇒ *After plugging the phone into another socket on the ISDN bus, lift the handset and replace it again.*

Automatic call parking

The connection is automatically parked. The programmed park code is used (see »Entering the park code«).



Press the OK key and the arrow keys (<) or (>) until »Park/Unpark« is displayed.



Press the OK key.



Replace the handset.

Continue your call



Press the OK key and the arrow keys (<) or (>) until »Park/Unpark« is displayed.



Press the OK key.



Lift the handset.

a) The call is automatically retrieved.

or:



b) Enter the programmed park code and press the OK key to confirm.



- ⇒ *A call can be parked for up to three minutes. After this time the connection is terminated.*
- ⇒ *You can also park a call using speed dialling (see »Additional settings«, »Programming speed dial keys«).*

Manual call parking

(If no park code is programmed.)



Press the OK key and the arrow keys (<) or (>) until »Park/Unpark« is displayed.



Press the OK key.



Enter a (temporary) park code.



Press the OK key to confirm.



Replace the handset.

Entering the park code

Every user can enter his or her own park code if he or she wishes to park calls using a code other than the default code 1.



Press the menu key repeatedly until the display shows »User settings«.



Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Park code«.



Press the OK key to confirm.



Enter the code.
Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Incoming calls

If you have not entered a Multiple Subscriber Number (MSN) i.e. no user is programmed, your phone will ring for every incoming call to any of your MSNs.

If several users have been defined and each assigned an MSN, you can program an individual ringing tone for each user. This allows you to determine the person for whom the call is intended.

The caller's number is displayed. If the number is stored in the phonebook, the caller's name is also displayed.

Before the number or name, the display indicates the user (A, B or C) for whom the call is intended.

Call acceptance



Lift the handset and make your call.



Terminate the call by replacing the handset.

Reject call

If you do not wish to talk to the caller on the display, you can reject the call.



The display shows the caller's number/name. Press the OK key. This takes you to the submenu where you can use the arrow keys (<) and (>) to switch between »Reject« and »Accept«. Go to »Reject«.



Press the OK key. The call is rejected. The caller's number is stored in the relevant user's caller list.

ETV® Online (only for Switzerland)

ETV® Online is a new service provided by your Ascom Eurit 25 which gives you direct access to Swisscom's electronic telephone phonebook (ETV® = Elektronisches Teilnehmerverzeichnis der Swisscom Directories AG). As soon as an unknown number appears on your display, you can access the ETV® and within a few seconds obtain the caller's name.

You can call up the ETV® directly:

- while the phone is ringing
- during a call
- when entering numbers with handset on-hook (dialling preparation)

You can call up the ETV® indirectly from the following lists:

- Caller list
- Call log (list of answered calls)
- Redial list

Installing ETV® Online

ETV® Online is delivered ready to use on your Ascom Eurit 25. No installation is necessary.

The ETV® Online access number is pre-installed.

If you need to change the ETV® Online access number, proceed as follows:



Press the menu key until »ETV Online« appears.

Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Gateway No.«

Press the OK key to confirm.



Change the ETV® gateway number.



Press the OK key twice to save the number.

Telephoning

ETV® Online query for incoming calls

The phone is ringing and a number is displayed.



Press the OK key.



Press the right arrow key (>) until »ETV query« appears.



Press the OK key. In a few seconds the caller's name is displayed.

⇒ *ETV® online queries can also be made directly by pressing the preprogrammed speed dial key 2 (see »Speed dialling«).*

ETV® Online query during a call



Press the OK key during the call.



Press the right arrow key (>) until »ETV query« appears.



Press the OK key. In a few seconds the caller's name is displayed.

⇒ *ETV® online queries can also be made directly by pressing the preprogrammed speed dial key 2 (see »Speed dialling«).*

ETV® Online query during on-hook dialling



Always enter the prefix along with the number (handset on-hook).



Press the OK key.



Press the right arrow key (>) until »ETV query« appears.



Press the OK key. In a few seconds the corresponding name is displayed.

⇒ *ETV® online queries can also be made directly by pressing the preprogrammed speed dial key 2 (see »Speed dialling«).*

ETV® Online queries from lists (caller list, call log, redial list)

Select the number from the relevant list. The number is displayed.



Press the OK key.



Press the right arrow key (>) until »ETV query« appears.



Press the OK key. In a few seconds the corresponding name is displayed.

⇒ *ETV® online queries can also be made directly by pressing the preprogrammed speed dial key 2 (see »Speed dialling«).*

Programming ETV® Online queries under a speed dial key

- ⇒ *Your Ascom Eurit 25 is delivered with the second speed dial key programmed for »ETV Query« You can delete this function and reprogram the speed dial key.*

You can program the phone to activate an ETV® Online query for incoming calls, during a call, for on-hook dialling or dialling from any list, simply by pressing a speed dial key. This saves you a great deal of time! To program a speed dial key, see »Additional settings« under «Programming speed dial keys«.



The number is displayed.

Press the programmed key.

In a few seconds the corresponding name is displayed.

Saving ETV® Online Information in your phonebook

Once you have obtained the information from the ETV® Online, you have the option of directly inserting the number and name in your phonebook.

The name obtained from ETV® Online is displayed.



Press the OK key. »Into phonebook« appears.



Press the OK key several times (for »Name«, »Number«, »Save«). The number and name are saved to your phonebook. If you want to link the number with an option, change the phonebook entry (see »Phonebook«, »Assigning options to numbers«).

Conducting two calls/switching between calls

ISDN allows you to conduct two calls on your phone simultaneously.

- ⇒ *The following instructions govern calls made over the ISDN basic access. For information on operating your Ascom Eurit 25 when connected to a PBX, refer to your PBX documentation and the section on »PBX Access« in this manual.*

Accept call

In the middle of a call, the call waiting signal is heard. The display shows the caller's number or name if stored in the phonebook. The display also indicates the user for whom the call is intended.



Press the OK key. This takes you to the submenu where you can use the arrow keys (<) and (>) to switch to »Accept call«.



Press the OK key to confirm. The existing call is put on hold. You can now talk to the second caller.

Reject call



Press the OK key. This takes you to the submenu where you can use the arrow keys (<) and (>) to switch to »Reject call«.



Press the OK key to confirm. The incoming call is rejected and the number is stored in the relevant user's caller list.

Initiating a second call, enquiry call

During a call you wish to call another subscriber, for example to ask a question or switch between calls.



Press the R key. The active call is put on hold.



Enter the number with prefix. Conduct your enquiry call.

- ⇒ *To terminate the enquiry call, see under »Terminating individual calls«. To switch between both calls, see under »Switching between calls«.*

Telephoning

Switching between calls

Your phone has two active calls, one of which is on hold as described in the previous section.



Press the R key. The existing call is put on hold. The previously held call is retrieved and you can resume talking.

Press the R key to switch from one call partner to the other.

Terminating individual calls

You wish to terminate one of the active calls.



Replace the handset to terminate the active call. A signal tone is heard.



Lift the handset. The second call is active. To terminate this call too, replace the handset again.

Transferring calls

You can transfer a call from your phone to another.

Transferring an existing call

Your phone has two active calls between which you have been switching. You want to connect one party with the other but no longer wish to take part in the discussion.



Press the OK key and the arrow keys (<) or (>) until »Call transfer« is displayed.



Press the OK key again. Your call partners are connected with each other. You will hear the busy tone. Both public lines required for the calls become free again.

- ⇒ *Your network provider will advise you on the availability of this service.*
- ⇒ *If your phone is connected to a PBX, you can transfer calls internally. See Attachment, »PBX access«, »Setting the PBX type«.*

Transferring a call to a new connection

During a call you realise that the calling party should speak to another person.



Press the R key. The active call is put on hold.



Enter the subscriber's number with prefix. Wait for him or her to pick up and advise that you wish to transfer a call.



During the active call, press the OK key and the arrow keys (<) or (>) until »Call transfer« is displayed.



Press the OK key again. Your call partners are connected with each other. You will hear the busy tone. Both public lines required for the calls become free.

Three-party conference

You are conducting two calls and switching between them. Now you want all parties to be able to speak to each other.

- ⇒ *The following instructions govern calls made over the ISDN basic access. For information on operating your Ascom Eurit 25 when connected to a PBX, refer to your PBX documentation and the section on »PBX Access« in this manual.*

Three-party conference with existing connections

Your phone has two active calls between which you have been switching.



Press the OK key and the arrow keys (<) or (>) until »Conference« is displayed.

Press the OK key. All connections are linked up. Everyone can hear and speak to each other.

Setting up a three-party conference

You want to involve another person in an active call.



Press the R key. The active call is put on hold.



Enter the subscriber's number with prefix. Wait for the call to be answered and ask the person to participate in a three-party conference call.



Stay connected and press the OK key and the arrow keys (<) or (>) until »Conference« is displayed.



Press the OK key. All connections are linked up. Everyone can hear and speak to each other.

- ⇒ *Inform your call partner that he will hear nothing during the time required for you to call the third person, although he will stay connected.*

Terminating a three-party conference

You wish to terminate a three-party conference call and, for example, only switch between your call partners.



Press the OK key. The display shows »Conference activated«. Press the arrow keys (<) and (>) to switch to »End 3-party conference«.



Press the OK key. You are connected with the last active call partner and the other is on hold.

Terminating individual calls

You wish to terminate one of the two active calls between which you are switching.



Replace the handset to terminate the active call. A signal tone is heard.



Lift the handset. The second call is active. To terminate this call too, replace the handset again.

- *If you have replaced the handset while a call is still on hold, a signal is heard. The display shows »Call Active«. Lift the handset to return to the held call, and terminate it by replacing the handset.*
- *If all active calls have been correctly terminated and the handset is again lifted, the dialling tone is heard.*

Call forwarding

Call forwarding can only be activated if at least one user is programmed for this function! Every user can program the three call forwarding options under any speed dial key (several call forwarding types can be active simultaneously):

Unconditional forwarding Incoming calls are forwarded immediately.

Forwarding on no reply Incoming calls are forwarded after 15 seconds.

Forwarding on busy Calls are forwarded if the user is busy.

⇒ *The caller pays only the cost of the connection from his telephone to yours. Connection charges for forwarding calls to an alternative telephone are charged to you.*

Call forwarding setup



Press the menu key repeatedly until the display shows »Forward«. Press the OK key to confirm.



Use the right arrow key to select a call forwarding option. Press the OK key to confirm.



Use the right arrow key to activate/deactivate the function. Press the OK key to confirm.



Once the call forwarding option has been activated, enter the speed dial number with prefix.

Or...



Press the menu key (after activation) if you have stored the speed-dial number in the phonebook.



Press the right arrow key (>) until you have found the number you are looking for.

...alle weiter




Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Execute«. Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

⇒ *When call forwarding is active, the symbol  (call forward activated) and the LED remains lit if unconditional (direct) forwarding is active.*

⇒ *Call forwarding can only be activated if at least one user is programmed for this function.*

⇒ *Every user can program one of the three call forwarding options under any speed-dial key (several call forwarding types can be active simultaneously).*

Direct call

You can program a direct call (hotline function) on your Ascom Eurit 25. Once this function is set and the handset is lifted, any key can be pressed to automatically dial the programmed number.



Press the menu key repeatedly until »Direct call« is displayed.



Press the OK key to confirm.



Use the right arrow key to activate/deactivate the function. Press OK to confirm.



Enter the direct call number with prefix.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Phonebook

Your Ascom Eurit 25 contains a phonebook

- for dynamic management of up to 40 stored numbers and names
- available to all users.

You can save new entries (name and number), and change and delete existing ones.

To phone via the phonebook, see »Dialling from the phonebook«.

For new entries you can enter options in addition to the name and number. These options define how your phone responds when dialling or accepting calls from this number.

EAC	For PBX access you can enter the exchange access code, if required (displayed as Option »X«).
CLIR	Calling Line Identification Restriction You can define whether your number is to be transmitted to a specific number (displayed as Option »C«).
Subaddress	You can enter a subaddress after the number. This is used for remote control of devices which support subaddresses. The Ascom Eurit 25 does not evaluate incoming subaddresses (displayed as Option »Z«).
Keypad	You can enter keypad information to control PBX functions (displayed as Option »K«).
Provider	You can program a number with provider preselection (displayed as Option »P«).

Entering number and name only

Entries in the phonebook are user-independent. Even if you enter them under your MSN code, all users can use these entries.



Press the OK key. The display shows »Phonebook«. Press OK to confirm.



Use the arrow keys (<) or (>) to scroll to the end of the list until »New entry« is displayed. Press the OK key. The display shows »Name _« and the cursor position. The phone is in text mode.



You can now enter the name. To do this, press the key with the relevant letter repeatedly until the letter is displayed, e.g. for K, press key 5 twice. Press # to switch between upper and lower case lettering.

If you wish to write the same letter twice in succession, or if the following letter is under the same key, wait briefly before pressing the key again. Continue in this way for every letter you need to enter.

If you have made a mistake, press the left arrow key (<) until the cursor position is under the incorrect letter. Enter the correct letter. This overwrites the incorrect letter. Press the right arrow key (>) until you reach the end of the text. For details on letters and special symbols assigned to the keys, see »Setting up Multiple Subscriber Numbers (MSN)«.



You have now entered the name. Press the OK key. The display shows »No. _« and the cursor position.



Enter the number with prefix.



Press the OK key. The display shows »Save«.

Press the OK key to confirm. The number is now saved.

Or...



If you do not wish to make another entry, hold down the ESCAPE key.

Or...



If you wish to change an existing entry, press the OK key twice to select the »Change« menu and proceed as described under »Changing entries«

Or...

Phonebook



If you wish to delete an existing entry, press the OK key and use the arrow keys to switch to »Delete«.



Press the OK key again and continue as described under »Deleting entries«.



Press the arrow keys (<) or (>) to scroll through this menu.

- ⇒ *The »Change« menu allows you to delete entries backwards, letter by letter, using the delete key.*
- ⇒ *Once your phonebook contains 40 numbers and names (memory full), »New entry« is no longer shown.*

Assigning options to numbers

This section follows on from the previous section »Entering number and name only«.

As described in the previous section, enter a name and confirm until »No._« and the cursor position is shown.

You can enter one or more of the following options before or after the number.

- Enter keypad (ISDN control).
 - Enter Exchange Access Code (EAC)
 - Enter calling line identification restriction.
 - Enter subaddress.
 - Enter provider.
- ⇒ If you make an incorrect entry, you can correct this by pressing the left arrow key (<) to return to the error. Enter the correct letter or number. This overwrites the incorrect entry. Press the right arrow key (>) to go to the end of your entry.
- ⇒ *You can also assign functions to phone numbers. A list of all available functions is given in the section on »Additional settings«, »Programming speed dial keys«.*

Enter keypad (ISDN control).

Keypad information is required in PBX operations to control functions. Attributes can also be activated/deactivated in the PBX. For further information, refer to your PBX user manual.



The first line of the display shows »No. _« and the cursor position. If you have already entered a number, this number is shown.



Press the OK key to display »Save«.

Press the right arrow key (>) repeatedly until »Insert keypad K« is displayed.



Press the OK key again. a »K« is shown after »No._« .



Enter the number.



Press the OK key to access »Save«.

CLIP/CLIR (show/suppress number)



The first line of the display shows »No. _« and the cursor position. You have not yet entered a number.



Press the OK key. »Save« is displayed.



Press the right arrow key (>) repeatedly until »Suppress No. C« is shown.

Press the OK key again. A »C« is shown after »No._«

Enter EAC



Press the OK key. The display shows »Save«.



Press the right arrow key repeatedly until »Insert extern X« appears.



Press the OK key again. An »X« is shown after »No._«

☞ *Refer to the »PBX« menu to find the exchange access code to be entered (see »PBX access«). The EAC is only inserted when the phone is used in conjunction with a PBX.*

Enter subaddress.



The display shows »No. _« and the cursor position.
Enter the number with prefix.



Press the OK key. »Save« is displayed.



Press the right arrow key (>) until the display shows »Insert subaddress Z«.



Press the OK key to display »Z« for subaddress.



Enter the subaddress.



Press the OK key and confirm »Save« by pressing OK again. Your number is saved and the display shows the entered name and user code.

Enter provider



The display shows „No. _» and the cursor position. You have not yet entered a number. Press the OK key. »Save« is displayed.



Press the right arrow key (>) until the display shows »Insert provider P«.



Press the OK key again. A »P« is shown after »No._« .



Enter the provider's code and number with prefix.



Press the OK key to access »Save« again.

Or...



If you do not wish to make another entry, hold down the ESCAPE key.

Or...



If you wish to make another entry, use the arrow key to scroll through the phonebook until »New entry« appears and proceed as described above.

Or...



If you wish to change an existing entry, press the OK key twice to select the entry and the »Change« menu and proceed as described under »Changing entries«

Or...



If you wish to delete an existing entry, press the OK key.



Use the arrow keys to scroll and select » Delete«.



Press the OK key again and continue as described under »Deleting entries«.

Or...



Press the arrow keys (<) or (>) to scroll through this menu.

Return to standby display



If you do not wish to make any more entries, exit this menu by holding down the ESCAPE key.

Changing entries



Press the menu key »Phonebook« is displayed.



Press the OK key to show the first entry in the phonebook.



Press the key containing the first letter of the name you are looking for until the first entry beginning with this letter is displayed. Example: You are looking for »Natalie«: Press key 6 twice. On the first press, the first name beginning with M is shown. On the second press, the first name beginning with N is shown.



If the name you are looking for is still not shown i.e. because it comes after the first entry in the alphabet, press the right arrow key (>) to scroll down until you have found the name.

Or...

Stepwise searching for an entry



Press the menu key. »Phonebook« is displayed.



Press the OK key to show the first entry in the phonebook.



Press the right arrow key (>) to scroll down the phonebook, and the left arrow key (<) to scroll up.



...Continue

Once you have found the entry, press the OK key.



The display switches to »Change«. Press the OK key to confirm. The name to be changed is displayed.

If you do not wish to change the name, press the OK key again.



Press the left arrow key (<) until you reach the error or delete the error by pressing the delete key several times.



Press the OK key. The number is displayed.



Press the left arrow key (<) until you reach the error or delete the numbers by pressing the delete key several times. If you do not wish to change the number, continue to the next step.



Press the OK key. »Save« is displayed.

Or...

You wish to insert or change options and did not save the entry in the previous step.

Phonebook



Press the right arrow key (>) to scroll through the available options if the option you wish has not yet been shown.



Press the OK key. The option symbol is added to the number.



If necessary, use the left arrow key (<) to go to an error and correct it by overwriting it.



Press the OK key. »Save« is displayed.

...Continue You have now completed changing the options.



Press the OK key. The entry is completed.
The display shows the changed name. Continue as described above if you wish to change another entry.

Return to standby display



If you do not wish to make any more entries, exit this menu by pressing the ESCAPE key.

Deleting entries



Press the menu key. »Phonebook« is displayed.



Press the OK key to show the first entry in the phonebook.



Keep press the key containing the first letter of the name you are looking for until the first entry beginning with this letter is displayed. Example: You are looking for »Natalie«: Press key 6 twice. On the first press, the first name beginning with M is shown. On the second press, the first name beginning with N is shown.



If the name you are looking for is still not shown i.e. because it comes after the first entry in the alphabet, press the right arrow key (>) to scroll down until you have found the name.

Or...

Stepwise searching for an entry



Press the menu key. »Phonebook« is displayed.



Press the right arrow key (>) to show the first entry in the phonebook.



Press the right arrow key (>) to scroll down the phonebook, and the left arrow key (<) to scroll up.



...Continue On reaching the relevant entry,



press the OK key and the arrow keys (<) or (>) until »Delete« is displayed.

Or...



Press the Delete key. »Delete« is displayed.

...Continue



Press the OK key to confirm. After a brief confirmation message, the entry is deleted. The next phonebook entry is displayed.

To delete additional entries, proceed as described above.



If you wish to exit this menu, hold down the ESCAPE key.

Additional settings

This section lists additional settings which can be made on your Ascom Eurit 25:

- Enter additional users (MSN)
- Program speed dial keys
- Set date and time
- Interception circuit (malicious call registration)
- CLIR Calling Line Identification Restriction
- Suppress call waiting.
- Set ringing tone melody and volume
- Set language
- Individual user charges, call charge total
- Set display contrast

Enter additional users (MSN)

To program a Multiple Subscriber Number (MSN) i.e. a user, refer to the section on »Startup«.

You can use any MSN you have obtained from your network provider for any of the three users.

You cannot assign the same MSN to several users.

If you assign a user an MSN which has already been assigned to another device, make sure this does not cause overlaps.

Example: You have a fax which must be available to all users. Assign this fax its own number.

Or: You have a dedicated fax (no handset) for use by a specific user. Give the user and the fax the same number.

Additional settings

Assigning additional users (MSN)



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the menu key repeatedly until »Set MSN« is displayed.
Press the OK key to confirm. »MSN A« is displayed.



You can use the arrow keys to scroll between the three possible MSNs (A, B or C). Select the MSN and press OK to confirm.



Using the keypad, enter one of the MSNs assigned to you by your network provider. Enter the number with prefix. If you have entered a number incorrectly, press the left arrow key (<) until the cursor position reaches the error.

Enter the correct number to overwrite the incorrect one and press the right arrow key (>) until you reach the end of your entry.



Press the OK key. The display shows »Name_« with the entered number. The phone is now in text mode. If you do not want to enter a name, the current display remains until you press the OK key.

Or...



You can enter the user's name.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Additional settings

Deleting an MSN (user)

You can delete any of the set users.



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



»Set MSN« is displayed.
Press the OK key to confirm. »MSN A« is displayed.



You can use the arrow keys to scroll between the three possible MSNs (A, B or C). Select the MSN and press OK to confirm.



The Multiple Subscriber Number is displayed.
Press the delete key repeatedly until the number is deleted.



Press the OK key.



»Delete user« is displayed.
Use the arrow key to switch to »Yes«.




Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Programming speed dial keys



Your phone offers the option of dialling frequently used numbers or functions by simply pressing a speed dial key. There are four keys available for this purpose. Each can be programmed twice to give a total of 8 numbers or functions.


- ⇒ The numbers or functions/services stored under speed dial keys are available to all users.
- ⇒ Your Ascom Eurit 25 is delivered with the first speed dial key programmed for »Send SMS« and the second for »ETV Query«



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the menu key repeatedly until »Speed dial« is displayed.
Press the OK key to confirm.



Press the relevant speed dial key briefly to access the first number or function under this key.
Press twice to access the second number or function.
The display shows »M« with the key number.

... Programming a speed dial key with a number



Enter the number with prefix.
Press the OK key to confirm. You can also assign options to the number (see under »Phonebook«, »Assigning options to numbers«).



The display shows »Save«.
Press the OK key to confirm.

Additional settings

... Programming a speed dial key with a function



Press the OK key to display »Save«.

Press the right arrow key (>) until »Function F« is displayed.

Press the OK key to confirm. An »F« is shown after the »M«.

Enter the function code (see list of functions below) and press the OK key to confirm.

If you wish to exit the menu, hold down the ESCAPE key.

The following functions may be assigned:

F01	Manual rejection of incoming calls
F02 xx..xx	Send DTMF .
F03 xx..xx	Send keypad
F04 xx	Park/retrieve active call via Code xx.
F05	Interception (MCID)
F06	Three-party conference
F07	Call transfer
F08	Microphone off (Mic Mute) and on.
F11 xx..xx	Direct dial (no additional function permissible).
F21 xx..xx	Unconditional call forwarding to number xx..xx.
F22 xx..xx	Call forwarding to number xx..xx on no answer.
F23 xx..xx	Call forwarding to number xx..xx on busy.
F31	Activate user A
F32	Activate user B
F33	Activate user C
F50	ETV® Online query
F51	Send SMS (with editing option)
F52	Send SMS direct

⇒ You can also save these functions in the phonebook. Follow the same procedure described in the section on »Phonebook« under »Assigning options to numbers« but enter a function instead of an option.

Additional settings


Changing speed dial key settings



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the menu key repeatedly until »Speed dial« is displayed.
Press the OK key to confirm.



Press the relevant speed dial key briefly to change the first number or function under this key.

Press twice to change the second number or function.

The display shows »M« with the key number.



Change the speed dial number (or function/service):

Use the arrow keys (<) and (>) to move to the numbers to be changed and overwrite them.

You can delete backwards using the delete key (C).



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Additional settings

Setting the date and time

On startup or following a power cut, the time display flashes. The time and date are automatically updated after the first outgoing call and the time is displayed without flashing.



You can also set the time and date manually. Press the menu key. Press the right arrow key (>) until »Installation« appears. Press the OK key to confirm.



Press the arrow keys (<) or (>) until »Date/Time« is shown. Press the OK key. The display shows »Date:« with the current setting and the cursor position ready for overwriting.



Use the numerical keys to enter the day, month and year. Press OK to confirm.

The display shows »Time:« with the current setting and the cursor position ready for overwriting.



Use the numerical keys to enter the hours and minutes. Press OK to confirm.



The display again shows date/time. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Press the arrow keys (<) or (>) to scroll through this menu.

⇒ *The date and time are displayed unless there are unanswered calls. As soon as your Ascom Eurit 25 registers unanswered calls, the call count and time of call are displayed.*

Interception circuit (malicious call identification)

If available, this service must be requested from your network provider. It retains the call-related data during a call and up to 20 seconds after the handset is replaced. The exchange registers number, date and time even if the caller has suppressed his number (CLIR). If you have subscribed to this service you can also activate it using a speed dial key (see »Additional settings« under »Programming speed dial keys«).



You receive a call and want to register it. Press the OK key.



Press the right arrow key (>) until the display shows »MCID«.



Press the OK key to confirm.

Additional settings

CLIR Calling Line Identification Restriction

If you call someone your number (i.e. your MSN) is displayed at the called person's end. When you are called, your number is displayed at the caller's end immediately on lifting the handset.

Every user can suppress their number for outgoing and incoming calls:

Permanent CLIR Calling Line Identification Restriction



Select the user.



Press the menu key. Press the right arrow key (>) until »Settings« appears. Press the OK key to confirm.



Use the arrow keys to scroll down until »Suppress No.« is displayed along with the current setting. Press the OK key.



The display shows the current setting e.g. »Suppress No.<ON>«. To change this setting, use the arrow keys (<) and (>) <ON> (suppressed) or <OFF> (i.e. send number).



Press the OK key to confirm the setting.



The display again shows e.g. »Suppress No. <OFF>« together with the user code.



If you do not wish to make another entry, hold down the ESCAPE key.

⇒ If you suppress your number, the letter C appears before the number when it is entered and the ID pictogram is crossed through (~~ID~~).

CLIR for specific calls



Select the relevant user.



The phone is in standby mode. Press the OK key without selecting a menu.



The display shows »Suppress No.«. Press the OK key again to confirm.

The display shows »Suppressed«.



Lift the handset.



Enter the number with prefix. The phone immediately dials the number. The display adds a »C« before the number (number suppressed). Wait for the connection and conduct your call.



Replace the handset to terminate the call.

⇒ If you suppress the number, the letter C appears before the number when entering the number.

Additional settings

Reject all anonymous calls

You can universally reject anonymous incoming calls (where the user has suppressed the number). Once this service is activated, no anonymous calls are forwarded to your Ascom Eurit 25. To activate this function:



Select the relevant user.



Press the menu key. Press the right arrow key (>) until »Settings« appears. Press the OK key to confirm. »Ringing Tone« appears in the display.



Press the menu key until »Reject anonymous calls« is displayed. Press the OK key.



Press the menu key until »YES« is displayed.



Press the OK key. Anonymous calls are now automatically rejected.

⇒ *You can determine whether »Reject anonymous calls« is active by checking the relevant menu (no display symbol).*

Deactivating call waiting

When you are talking on the phone, a signal indicates another incoming call.

Every user can deactivate call waiting in order to avoid being disturbed during calls.



Select the relevant user.



Press the menu key. Press the right arrow key (>) until »Settings« appears.



Press the OK key to confirm.



Use the arrow keys to scroll down until »Call waiting« is displayed along with the current setting. Press the OK key.



The display shows the current setting e.g. »Call waiting<OFF>«. To change this setting, use the arrow keys (<) and (>) for <ON> or <OFF> .



Press the OK key to confirm the setting.



The display again shows e.g. »Call waiting <ON>« together with the user code.



If you do not wish to make another entry, hold down the ESCAPE key.

Additional settings

Setting the ringing tone melody and volume

Every user has a choice of 12 different ringing melodies und 7 volumes (0-7).



Select the relevant user.



Press the menu key. Press the right arrow key (>) until »Settings« appears. Press the OK key to confirm.



»Ringing tone« is displayed. Press the OK key. The display shows »Melody« and the set number (1-12).



For example, the display shows »Melody <1>« to indicate that Melody 1 is set for the selected user. Use the arrow keys to change the melody display. The melody is played.



Press the OK key to complete the setting.



The display again shows »Melody« followed by the set number. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Use the arrow keys (<) or (>) to scroll to »Volume«. The number shows volumes 1 to 7. Press the OK key.



The display shows the set volume, represented by a bar. Use the arrow keys (<) and (>) to adjust the volume. The volume is played.



Press the OK key to complete the setting.



The display again shows »Volume«. If you do not wish to make another entry, hold down the ESCAPE key.

⇒ The volume can also be set to »0«. In this case you hear no ringing melody, the symbol 📞 »Ringing tone off« is displayed and the LED is lit.

⇒ The LED flashes to indicate an incoming call.

Additional settings

Ascending ringing volume

Every user can choose whether to have the ringing tone volume constant (default) or ascending – i.e. from soft to loud. To set an ascending ringing volume:



Select the user.



Press the menu key. Press the right arrow key (>) until »Settings« appears. Press the OK key to confirm. »Ringing Tone« appears in the display.



Press the OK key. »Melody« appears in the display. Press the menu key until »Ascending« is displayed.



Press the OK key.



Press the menu key until »ON« is displayed.



Press the OK key. Ascending ringing volume is activated.

Setting the language

You can set the display language (the languages offered are country-specific). Your set is delivered with German as the default. This setting is user-independent.



To change the language: Press the menu key. Press the right arrow key (>) until »Installation« appears. Press the OK key to confirm.



Press the arrow keys (<) or (>) until »Language« is shown. Press the OK key.



The display shows »DEUTSCH« i.e. the current setting



Use the arrow keys (<) or (>) to change the display language.



Press the OK key. The setting is confirmed by a brief signal tone.



The display again shows »Language«. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Press the arrow keys (<) or (>) to scroll through this menu.



Additional settings

Setting the charge factor and currency

⇒ *Some network operators provide defined currencies and charge factors. In this case you cannot set the charge factor and currency on your telephone.*

Charge factor

You must set the charge factor before you can display call charges. Your telephone is delivered with the preset charge factor DM 0.00.



To change the charge factor: Press the menu key. Press the right arrow key (>) until »Charges« appears. Press the OK key to confirm.



Press the arrow keys (<) or (>) to display »Set Factor«. Press the OK key. The display shows »DM 0.00« and the cursor.



Use the numerical keypad to enter the charge factor.



Press the OK key to complete the setting. A signal confirms the setting.



»Set Factor« is again displayed. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Press the arrow keys (<) or (>) to scroll through this menu to find the currency.

Currency



To set the currency for the charge factor: Press the menu key. Press the right arrow key (>) until »Charges« appears. Press the OK key to confirm.



Press the arrow keys (<) or (>) to display »Set Currency«. Press the OK key. The display shows "Currency:" DM« with the cursor under the first position.



The phone is now in text mode. The cursor is set for overwrite. You can use the arrow keys to go back or forward or use the delete key to delete the letter under the cursor. Press the OK key to complete the setting.



»Set Currency« is again displayed. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Press the arrow keys (<) or (>) to scroll through this menu to find the charge factor.

⇒ *Contact your network operator to find out the charge factor applicable for you.*

Individual user charges, call charge total

Advice of charge

You can display the charges per user as well as the charge total for all calls made from the phone.



Press the menu key repeatedly until »Charges« is displayed.
Press the OK key to confirm.



Press the menu key repeatedly until »Request« is displayed.
Press the OK key to confirm.
The charges for the active user are displayed.



Press the OK key again to display the charge total for all users.



If you wish to exit the menu, hold down the ESCAPE key.

Deleting user charges



Press the menu key repeatedly until »Charges« is displayed.
Press the OK key to confirm.



Press the menu key repeatedly until »Delete« is displayed.
Press the OK key to confirm.
The display shows a prompt, »Are you sure?«



Press the right arrow key (→) for »Yes«.
Press the OK key to confirm.
The charges of the active user are deleted.



If you wish to exit the menu, hold down the ESCAPE key.

- ⇒ *The charge total always shows the total for all users and cannot be deleted directly. It is only deleted when the charges for all users are deleted.*
- ⇒ *Note that for technical reasons the displayed charges may differ from the amount billed. The amount indicated on your bill is binding.*
- ⇒ *To display charges for the last 10 calls in the redial list, press the OK key for the relevant number: »Info« is displayed. Press the OK key to confirm.*

Additional settings

Setting the contrast

To enhance the legibility of the display to changing light conditions in your room or office, you can set the display contrast.



Press the menu key. Press the right arrow key (>) until »Installation« appears. Press the OK key to confirm.



Press the arrow keys (<) or (>) until »Contrast« is shown. Press the OK key. The display shows the current setting represented by a bar.



Use the arrow key (<) or (>) to change the contrast. Press the OK key. The setting is confirmed by a brief signal tone.



The display again shows »Contrast«. If you do not wish to make another entry, hold down the ESCAPE key.

Or...



Press the arrow keys (<) or (>) to scroll through this menu.

Short Message Service (SMS)

Handling incoming SMS messages

Read SMS




Select the user.
Only calls/SMS outside brackets are intended for you.



Press the menu key repeatedly to display »Caller list«. Press the OK key.



Press the OK key to confirm. The number of the last call/SMS is displayed (along with the caller's/sender's name if the number is stored in the phonebook). If the SMS pictogram »« appears before the number/name, this indicates an SMS. If not, it is a voice call.



Press the OK key. »Read« appears in the display.



Press the OK key. The SMS message is shown as scrolled text.



If you want to know the date and time the SMS was received, go to »Info« rather than »Read« and press the OK key. The date and time are displayed.



Delete, reply, forward or save SMS

You have read the SMS and want to delete it:



Press the OK key. »Delete« appears in the display.



Press the OK key. The SMS is deleted.

Or...

You have read the SMS and want to reply:



Press the OK key. »Delete« appears in the display.



Press the right arrow key (>) until »Reply« appears.



Press the OK key. The display shows the sender's SMS.



Delete unnecessary text by pressing the DEL key.



Write your message.



Press the OK key. »SMS Recipient« appears in the display.



Press the OK key to confirm. The sender number is displayed.



Press the OK key. »Send« appears in the display.



Press the OK key. The reply is sent.

⇒ You can delete the entire SMS text in one go by holding down the DEL key (long-click DEL).

Short Message Service (SMS)

Or...

You have read the SMS and want to forward it:



Press the OK key. »Delete« ppears in the display.



Press the right arrow key (>) until »Forward« appears.



Press the OK key. The display shows the sender's SMS.



Press the OK key. »SMS Recipient« appears in the display.



Press the OK key. »No.« appears in the display.



Enter the number with area code.

Or...

To search for a number in the phonebook:



Press the OK key. »Send« appears in the display.



Press the right arrow key (>) until »From Phonebook« appears. Press the OK key to confirm. Select the entry.



...Continue



Press the OK key. »Send« is shown.



Press the OK key. The SMS is sent.

Or...

You have read the SMS and want to save it:



Press the OK key. »Delete« ppears in the display.



Press the menu key until "Save" appears.



Press the OK key. The SMS is saved.

- ⇒ *The storage capacity of your phone is limited (see also »Storage capacity«).*
- ⇒ *After saving, the SMS is removed from the caller list and can be retrieved from the »Messages (SMS)« menu / »Saved SMS« submenu.*

Short Message Service (SMS)

Write, send, save SMS messages



Select the user.



Press the menu key repeatedly. »Messages (SMS)« appears in the display. Press the OK key.



"Send SMS" appears in the display. Press the OK key.

To send the SMS to a mobile phone or an ISDN phone which supports SMS:



Write your message.



Press the OK key. »SMS Recipient« appears in the display.



Press the OK key to confirm.



Enter the number.

Or...



If the number is stored in the phonebook, press the OK key until »Send« appears.



Press the right arrow key until (>) until »From Phonebook« appears.



Press the OK key.



Use the arrow keys to navigate the phonebook until you find the number.



Press the OK key.



...Continue



Press the OK key. »Send« appears in the display.



Press the OK key.

Or...

To save the SMS for sending at a later stage:



»SMS Recipient« appears in the display. Press the right arrow key (>) until »Save« appears.



Press the OK key. The SMS is saved.

...Continue














To exit the menu, hold down the ESCAPE key.

Short Message Service (SMS)

Retrieve, send, delete saved SMS messages


To retrieve saved SMS messages:

- 
- Press the menu key repeatedly. »Messages (SMS)« appears in the display. Press the OK key.
- 
- Press the right arrow key (>) until the display shows »Saved SMS«. Press the OK key. The first entry in the list of saved incoming SMS messages »▶□◀ or unsent SMS messages »◀□◀ is displayed.
- 
- Press the right arrow key (>) to scroll down the list, and the left arrow key (<) to scroll up.
- 
- Once you have found the entry, press the OK key.
- 
- Press the right arrow key repeatedly (>) to access the following submenus:
- 
- Send SMS Press the OK key to display the SMS text (you can still edit it if necessary). Press the OK key to confirm. »SMS Recipient« appears in the display. Press the OK key. Enter the number and press the OK key to confirm. »Send« appears in the display. Press the OK key. The SMS is sent. (See »Write, send, save SMS messages«).


Or...

- 
- Read SMS Press the OK key. The SMS message is shown as scrolled text.


Or...

- 
- Info Press the OK key. The display shows the date/time when the saved SMS was received (no information on your own SMS!).

Or...

- 
- Delete SMS Press the OK key. The SMS is deleted.

...Continue

- 
- To exit the menu, hold down the ESCAPE key.

PBX access

You can also connect your Ascom Eurit 25 to a PBX. Since the functionality is dependent on your PBX type, please refer to your PBX instruction manual before connecting the telephone.

You can also program several users when connected to a PBX and assign them different extension numbers.

PBX access on/off

Check whether PBX access is activated and activate it if necessary:



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the right arrow key (→) until the display shows »PBX«. Press the OK key to confirm.



The display shows »PBX access« with the current setting (On/Off).
Press the OK key to confirm.



Use the right arrow key to activate/deactivate the function.
Press the OK key to confirm.



If you wish to exit the menu, hold down the Escape key.

⇒ *Once »PBX access« is activated, all PBX settings (EAC, automatic sending of keypad, transfer via ...) are activated.*

Entering the Exchange Access Code (EAC) for outgoing calls

The access code is required by some systems to allow the PBX to assign you a public exchange line for external calls. If your PBX has no automatic external line selection, you need to program an access code:



Press the menu key repeatedly until »Installation« appears. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »PBX«. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »Outgoing access code«. Press the OK key to confirm.



Enter the new EAC (up to 4 digits) as instructed by your PBX manual.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Entering EAC for incoming calls

External calls directed to your phone through your PBX are also stored in the caller list. To enable these numbers to be called back, the EAC must be set. Some PBXs automatically insert the EAC, in which case there is no need to reprogram your phone since the default setting does not contain an EAC.



Press the menu key repeatedly until »Installation« appears. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »PBX«. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »Incoming access code«. Press the OK key to confirm.



Enter the new EAC (up to 4 digits) as instructed by your PBX manual.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

⇒ *You can conduct a test to find out which settings you need to make. Once you have connected the phone, have someone call you from outside. If the display shows the EAC before the caller's number, e.g. 0, there is no need to set the EAC. Please do not confuse the 0 in a local code (e.g. 031) with the EAC. In this case the zero should appear twice.*

Internal number length

For PBX operation, the length of internal numbers (number of digits) must be programmed to allow internal calls to be distinguished from external calls (the phone is delivered with the internal number length set to 4 digits).



Press the menu key repeatedly until the display shows »Installation«.



Press the OK key to confirm.



Press the right arrow key (>) until the display shows »PBX«.



Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Internal number length«.



Press the OK key to confirm.

PBX access



Enter the new internal number length.



Press the OK key to confirm.



To exit the menu, hold down the ESCAPE key.

⇒ For further information on internal number lengths, refer to your PBX documentation.

Setting the transfer type

To transfer calls internally over the PBX network, you need to set a transfer type. The type of transfer (functional or with disconnect) depends on your PBX.

Transfer with disconnect



Press the menu key repeatedly until »Installation« is displayed.



Press the OK key to confirm.



Press the right arrow key (>) until the display shows »PBX«.



Press the right arrow key (>) repeatedly until the display shows »Disconnect transfer«.



Use the right arrow key to activate/deactivate the function.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

⇒ You can conduct a test to find out which settings you need to make. During a call, set up a second call via »«Enquiry» and try to connect the two call partners (see »Transferring calls«). If this is impossible, you need to change the transfer type.

Call transfer on-hook

You can transfer a call within the PBX network or externally by replacing the handset. To do this, you need to set the phone:



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the right arrow key (>) until the display shows »PBX«. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »On-hook transfer«. Press the OK key to confirm.



Use the right arrow key to activate/deactivate the function.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

- ⇒ *»Call transfer on-hook: off« means that the active call is terminated when replacing the handset and the held call is signalled.*
- ⇒ *»Call transfer on-hook: on« means that the active call is transferred to the held call when the handset is replaced.*

Keypad information

Keypad information are data in which the keypad characters are converted to specific functions in the PBX. Normally the asterisk or hash key are used to switch the function. Your PBX documentation will advise you on which keypad functions your PBX supports.

Keypad before dialling

On-hook dialling:



Press the asterisk or hash key first. The phone switches to »Send keypad«.



Enter the relevant keypad function. If necessary, complete the entry by pressing the hash key.



Lift the handset (or press the loudspeaker key for listening by loudspeaker). The keypad information is transmitted to your PBX.

Send keypad during a call

You are conducting a call and the display shows the calling partner's number:



Press the OK key.



Press the menu key repeatedly until the display shows »Send keypad«.



Press the OK key.



Enter the relevant keypad function.



Press the OK key to confirm. The keypad information is transmitted to your PBX.

⇒ *Frequently used keypad functions can also be activated by pressing a speed dial key. See under »Additional settings«, »Programming speed dial keys«.*

Send automatic keypad on/off

If the asterisk or hash key is pressed before dialling, the phone automatically switches to »Keypad signalling« (default setting: on). In some PBXs e.g. those in which automatic EAC selection is activated, you need to deactivate automatic keypad sending in order to initiate an internal call by pressing the asterisk key.



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the right arrow key (>) until the display shows »PBX«. Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »Send automatic keypad«. Press the OK key to confirm.



Use the right arrow key (>) to activate/deactivate the function.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

Renumbering

If a country introduces renumbering (national access code changed), you can pre-program the national prefix for Switzerland and the international traffic selection digit (TSD) for calls abroad:

Setting the national traffic selection digit (TSD)

The national traffic selection digit is the first digit in the prefix. This pre-programmed number must only be changed or deleted if you are unable to make domestic calls from the caller list or call log. If this problem arises and you are connected to a PBX, refer to the section on »PBX access«.



Press the menu key until »Installation« appears. Press the OK key.



Press the menu key until »Location« appears. Press the OK key.



When »National TSD« is displayed, confirm by pressing the OK key.
The display shows the pre-programmed national TSD and the cursor position.



Enter the relevant national TSD (the preset TSD is overwritten).



Press the OK key.

Setting the international TSD

The international traffic selection digit is the digit you need to dial before the national prefix. This pre-programmed number must only be changed or deleted if you are unable to make domestic calls from the caller list or call log. If this problem arises and you are connected to a PBX, refer to the section on »PBX access«.



Press the menu key until »Installation« appears. Press the OK key.



Press the menu key until »Location« appears. Press the OK key.



When »National TSD« is displayed, press the right arrow key (>).

The display shows the pre-programmed international TSD and the cursor position.



Enter the relevant international TSD (the preset TSD is overwritten).



Press the OK key to confirm.

Emergency operation

Your phone remains operational even during a power failure (emergency operation). How you activate emergency operation is dependent on your phone connection.

Emergency operation on network termination unit (NT+2ab)



If your phone is directly connected to the NT+2ab bus, the exchange provides the emergency power supply directly. The emergency power is sufficient for one phone. Not all features are available during emergency operation but you can still receive incoming calls and make outgoing calls.

To set a phone for emergency operation:

Remove the cover of the speed-dial label field by slipping a fingernail under the edge and lifting the cover and label field.

Press the snap-in key until it locks into place. Emergency operation is activated.

To deactivate emergency operation, use a screwdriver or similar object to prise out the clip (to the right).



➡ *If you set more than one phone for emergency operation, none of the phones are able to function.*

Emergency operation on a PBX

If your phone is connected to a PBX, emergency power is supplied via the PBX. The features available to you during emergency operation and the number of phones which can be set for emergency operation is dependent on your PBX. Refer to the PBX user manual for details.

Resetting the phone

You can reset the phone to default status as follows:



Press the menu key repeatedly until the display shows »Installation«.



Press key 1 on the dialling keypad. The display shows the reset option: »Full reset«.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

⇒ *»Full reset« deletes all settings e.g. call transfer procedure, EAC etc., and all the data you have stored e.g. phonebook entries, speed dial keys etc.*

Headset connection

You can connect a headset (earpiece and external microphone) to your Ascom Eurit 25.

The headset is available from any specialist dealer. When purchasing a headset from a specialist dealer, make sure it is compatible with your Ascom Eurit 25.

For details on how to connect and operate the headset, refer to the headset instructions.

The following settings need to be made before you operate the headset:



Press the menu key repeatedly until »Installation« is displayed.



Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Headset«. Press the OK key to confirm.



Use the right arrow key (>) to activate/deactivate the function.



Press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

⇒ *Once you have set the phone for headset operation, you can accept and terminate calls by pressing the loudspeaker key.*

Show software version and checksums

You can display the name and checksum of the software version installed in your Ascom Eurit 25.



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the right arrow key (>) until the display shows »Software«. Press the OK key to confirm.



Use the right arrow key (>) to select the following functions:
»Get version« shows the name of the installed software.
»Get checksum« shows the checksum of the installed software.
Select the function and press the OK key to confirm.



If you wish to exit the menu, hold down the ESCAPE key.

PC dialling option (Office Manager)

The Office Manager is an add-on for the Ascom Eurit 25 that enables Computer Telephone Integration (CTI).

The software delivered with the Office Manager contains a TAPI driver and a program for configuring and operating the Ascom Eurit 25 on your PC. Calls are then automatically displayed on the screen. If the caller is stored in your database, all important data on the caller is displayed on screen. So you know all the facts even before answering the call. This is a boon to telephoning in a work environment: No office should be without one!

The TAPI driver allows you to connect certain database programs directly to your Ascom Eurit 25.

The Office Manager software is undergoing further development which cannot always be incorporated in the shipped CD-ROM.

However, you can obtain free updates for your version at any time by accessing www.estos.de/euritelpro/. Select from this page **Download Updates** and start the download by clicking on **EuriTel Pro Version 1.0**. Details on any modifications is also available on this home page under **EuriTel Pro Releasenotes**.

To carry out an update on your computer:

Download the update file from the above home page to your computer. A setup is started which automatically identifies an existing installation and performs a correct update.

⇒ *Attention: The PC-Dialer II (the predecessor of the Ascom Office Manager) is not compatible with the Ascom Eurit 25.*

Remote download

The Ascom Eurit 25 software is continually adapted to the latest state of the art. You can download the current software over the telephone line in a few minutes (subject to charge). If your phone already has the most recent software installed, the connection is cleared within a few seconds. The access number for remote download is stored in the phone.



Press the menu key repeatedly until »Installation« is displayed.
Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »Software«.
Press the OK key to confirm.



Press the right arrow key (>) repeatedly until the display shows »Remote download«.
Press the OK key to confirm. »Host No.« is shown.



To change the access number for remote download, use the arrow keys (<) or (>) to move to the number and overwrite it. You can also delete the existing access number backwards with the aid of the delete key (DEL) and then enter the new number.
Press the OK key to confirm the access number (Host No.).



The display shows »Execute«.
Press the OK key to start the download.
The display shows the progress of the download as a percentage (from 0% to 100%).
The download is complete as soon as the display shows »Update successful«.



Press the OK key to return to standby display.

- ⇒ *Should the remote download be unsuccessful, you may need to enter a new access number. In this case please contact your Ascom national agent.*
- ⇒ *Under no circumstances unplug the connection cable from the phone during a download.*

Troubleshooting

If your phone is not functioning as it should, try first to find the fault in the following table.
The following tips should help you correct the fault:

Problem	Possible cause	Remedy
No dialling tone.	The connection cord of the phone is not plugged in correctly	Unplug it and plug it in again
No ringing signal is heard after dialling.	The connection type (operation with a PBX) is incorrectly set.	For operation with a PBX, your telephone must be set to the right connection type.
The phone does not offer full functionality	Power cut: phone is set for emergency operation	Deactivate emergency mode
No dialling tone. Display shows: »Install. Error«.	ISDN installation faulty No termination resistance on S-bus or network fault.	Contact your network provider

⇒ Even if you have followed all the instructions correctly, faults may occur which are caused by the exchange or installation errors.

Care

Your phone is designed for a long, maintenance-free life.
Please note

- Do not dismantle the phone or attempt to repair it yourself.
- Clean the phone exterior at regular intervals. Use a damp, fluff-free cloth. For stubborn stains dab some dishwashing liquid on the cloth. Do not use abrasive cleaning agents or solvents since they can damage the housing surface. Make sure no liquid seeps into the phone when cleaning it.

Summary of default settings

To allow you to use your phone immediately after setup, it is set for general-purpose use. You can change these settings to your own requirements and connection conditions. To do this, refer to the relevant function description.

The following is a list of default settings which remain valid even after a reset:

Function	Preset	Options
Display language	German	The languages offered are country-specific.
Speed dial keys	First speed dial key: Send SMS. Second speed dial key: ETV® Online query	4 dual-programmable
Date/time	Setting dependent on software status	Automatically updated network
Phonebook	No entries	40 entries
Redial list	No entries	—
Caller list	No entries	—
Incoming/outgoing EAC	None (no entry)	User setting
Ringing tone	Melody 1, volume 4	User setting
Handset/loudspeaker volume	Volume 4 (medium)	User setting
CLIR	Deactivated	On/Off
Call waiting	On	On/Off
Park code	1	User setting
MSN	No MSN set	User setting
Display contrast	Level 7 (high)	User setting
Internal number length	4	User setting
Call transfer on-hook	Off	On/Off
Disconnect transfer	Off	On/Off
Send keypad automatically	On	On/Off
PBX access	Off	On/Off
Call forwarding	Off	On/Off
Direct call	Off, no number	On/Off
Headset	Off	Off

Technical Data

Model	Ascom Eurit 25 phone
Connection	Basic access
Protocol	DSS1 (Euro-ISDN)
Ambient temperature for operation	+5° C to +45° C
for transport	-25° C to +70° C
for storage	-25° C to +70° C
Data storage	approx. 10 years (no battery required)
Dimensions	215 mm x 189 mm x 53 mm

Safety tips

Note the following precautions to protect yourself from physical harm:

Never

- open the phone yourself!
- touch contacts with sharp, metallic objects!

Stow connection cables carefully to avoid tripping over them.

Note the following tips for positioning, connecting and operating the phone.

- Position the phone away from:
 - heat sources,
 - direct sun,
 - other electrical equipment.
- Protect your phone against dust and avoid getting it wet or exposing it to aggressive liquids and steam.
- Do not plug the connection cord in sockets other than the one for which it is intended.
- Connect only authorised accessories.
- Clean the phone with a soft, damp cloth. Do not use abrasive cleaning agents or solvents.
- The phone may only be repaired by authorised service personnel.

Ascom accepts no liability for damage resulting from inappropriate use.

Warranty Conditions

During the warranty period Ascom agrees to correct all faults arising from material or manufacturing defects. Ascom may choose whether to repair the defective product or replace it.

The warranty does not cover damage arising from inappropriate use or normal wear and tear.

The warranty is invalid for products opened by the purchaser or unauthorised third parties and for products fitted with spare parts and accessories other than the original parts and accessories or those recommended by Ascom.

Proof of warranty must be provided by presenting an official confirmation of purchase (receipt or invoice) or the completed warranty card enclosed at the back of these instructions.

Disposal

Please observe local bylaws when disposing of the telephone set.

Approval and CE code

The Ascom Eurit 25 is designed for connection to the public ISDN network.

Country-specific regulations are taken into account. For questions on discrepancies between public telephone networks, contact your specialist dealer or network operator.

The CE symbol signifies conformity with the applicable directives governing telephones connected to the public network.



Liability

Ascom accepts no liability for:

- damage or loss resulting from the application of these operating instructions.
- damage or third-party claims arising from the use of this product
- damage resulting from loss of data.
- Ascom offers no warranty on the actual transmission of SMS messages.

Declaration of conformity

ascom

**Konformitätserklärung
Declaration of Conformity
Déclaration de Conformité**

Wir:
We:
Nous:

Ascom Business Systems AG

Adresse:
Address:
Adresse:

**Postfach 500
CH-8634 Hombrechtikon**

erklären, dass das Produkt / declare that the product / déclarons que le produit:

Type:

ISDN - Telephone

Model:

Eurit 25 (Abraxas K20i-A)

die grundlegenden Anforderungen gemäss Artikel 3 der nachstehenden EU-Richtlinie erfüllt:
meets the essential requirements according to article 3 of the following EC-Directive:
est conforme aux exigences essentielles de l'article 3 de la Directive CE:

Richtlinie 1999/5/EG des Europäischen Parlaments und des Rates vom 9. März 1999 über Funkanlagen und Telekommunikationsendeinrichtungen und die gegenseitige Anerkennung ihrer Konformität

Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity

Directive 1999/5/CE du Parlement Européen et du Conseil du 9 mars 1999 concernant les équipements hertziens et les équipements terminaux de télécommunications et la reconnaissance mutuelle de leur conformité

und dass die folgenden harmonisierten Normen angewandt wurden:
and that the following harmonised standards have been applied:
et que les standards harmonisés suivants ont été appliqués:


EN 60950 / 1997

EN 55022 / 1998, EN 55024 / 1998

Hombrechtikon, 02.05.2001




T. Frei




i.V. F. Ryser

Menu structure




Attachment







siehe nächste Seite

1



Write-on labels



Warranty Certificate

Warranty Certificate

Garantieschein, Bon de garantie, Certificato di garanzia, Garantiebewijs, Takuutodistus, Garantibevis, Garantisedel, Garantibevis, Certificado de Garantía, Talão de garantia

device type:	(Gerätetyp, type d'appareil, tipo di apparecchio, toesteltype, laitetyyppi, maskintype, apparattyp, apparat-type, modelo del aparato, modelo do aparelho):
serial number:	(Seriennummer, numéro de série, numero di serie, serienummer, sarjanumero, serienummer, serienummer, serienummer, número de serie, número de série):
dealer's stamp:	(Händlerstempel, sceau du vendeur, timbro del rivenditore, stempel van de dealer, kauppiaa leima, forhandlerens stempel, försäljarens stämpel, forhandlerstempel, sello del comerciante, carimbo do vendedor):
dealer's signature:	(Unterschrift des Händlers, signature du vendeur, firma del rivenditore, handtekening van de dealer, kauppiaa allekirjoitus, forhandlerens underskrift, försäljarens underskrift, forhandlers underskrift, firma del comerciante, assinatura do vendedor):
date of purchase:	(Kaufdatum, date d'achat, data d'acquisto, datum van aankoop, ostopäiväys, kjøpsdato, datum för köpet, salgsdato, fecha de adquisición, data de compra):



Key words

A	
AKZ	71
Amtskennziffer (AKZ)	71
Anklopfen	59
Ankomende Anrufe	31
Anonyme Anrufe generell abweisen	59
Anruf abweisen	31
Anruf annehmen	31
Aufstellort	9
Automatisch parken	29
B	
Bedienfeld	II
Benutzergebühren löschen	63
Benutzerkonzept	16
Beschriftungsschild	10
Beschriftungsschilder	91
Betrieb an einer Telefonanlage	70
Betrieb an Telefonanlage ein-/ausschalten ..	70
Bildsymbole für die Bedienung	6
C	
CE-Kennzeichnung	86
Checksumme	81
D	
Datum	57
Direkt-/Babyruf	41
Direktwahl	17
Display	11
Displaykontrast	64
Dreierkonferenz	38
E	
Eingegangene SMS handhaben	66
Eintrag ändern	48
Eintrag gesamt löschen	50
Entsorgung	86
ETV® Online	32
ESC-Taste	13
F	
Fangschaltung	57
Ferndownload	82
Fester Provider	27
Funktionsmenü	13
G	
Garantiebestimmungen	86
Garantiekarte	93
Gebührenfaktor und Währung einstellen ..	62
Gebühren pro Benutzer	63
Gebührensomme	63
Gesamtansicht	II
Gespeicherte SMS abrufen, senden oder löschen	69
Gesprächsliste	24
H	
Headset	80
Hilfe	83
I	
In Betrieb nehmen	8
Information zu Ihrem ISDN-Anschluss	1
K	
Keypad automatisch senden	76
Keypad-Informationen	75
Konformitätserklärung	87
Kopfhörer	80
L	
Lauthören	28
Lautstärke	60
Lautstärke einstellen	28
LED	III
M	
Makeln	35
Manuell parken	30
Mehrfachrufnummer	14
Menüstruktur	88
Menütaste	13
MSN (Benutzer) löschen	53
MSN bei Inbetriebnahme einrichten	14
MWI	12
N	
Nationale Verkehrsausscheidungsziffer	
(VAZ)	77
Notbetrieb	79

Key words

O	
Office Manager	81
OK-Taste	13
P	
Parkcode eingeben	30
Parken	29
Pfeiltasten	13
Pflege	83
Providerliste	27
R	
Registrieren böswilliger Anrufe	57
Reparatur	86
Rückfragen	35
Rückruf bei besetzt / nicht melden / auto- matische Wahlwiederholung	18
Rufnummer dauernd unterdrücken	58
Rufnummer für einzelne Anrufe unterdrücken	58
Rufnummer mit Optionen eingeben	45
Rufnummer und Namen eingeben	43
Rufnummer unterdrücken	58
Ruheanzeige des Displays	11
S	
Sicherheitshinweise	85
Signalisierung eingehender SMS	65
SMS erstellen, senden oder speichern	68
Softwareversion	81
Sprache	61
Sprechgarnitur	80
Störungen	83
Stummschalten	28
T	
Technische Daten	85
Telefon anschliessen	9
Telefonbuch	42
Telefonieren	16
Textmitteilungen (SMS)	65
Textmodus	12
Tonruflautstärke ansteigend	61
Tonrufmelodie und Lautstärke	60
U	
Über das Telefonbuch wählen	20
Über Zielwahltaste wählen	26
Uhrzeit	57
Umleitung	40
Umleitung bei besetzt	40
Umleitung bei nichtmelden	40
Umleitung sofort	40
Umnummerierung	77
Update	81
V	
Vermitteln	37
Vermitteln durch Auflegen	74
Vermitteln mit Disconnect	73
Vermittlungsart	73
Verpackungsinhalt	8
W	
Wahl ab PC	81
Wählen aus der Anruferliste	22
Wählen aus der Gesprächsliste	24
Wählen über Provider	26
Wahlvorbereitung	17
Wahlwiederholung	19
Wartung	83
Weitere Benutzer (MSN) eingeben	51
Weiteres Gespräch	35
Werkseinstellungen	84
Z	
Zielwahltasten belegen	54
Zulassung	86
Zurücksetzen	80
Zustandsanzeige LED	III

Hergestellt in der Schweiz durch:

Ascom Business Systems AG

Eichtal

Postfach 500

CH-8634 Hombrechtikon

<http://www.ascom.ch>

Vertrieben in Deutschland durch:

Ascom Deutschland GmbH

Fachbereich Endgeräte

Victor-Slotosch-Str. 11

60388 Frankfurt

<http://www.ascom.de>

Vertrieben in Österreich durch:

Ascom Austria

Gesellschaft m.b.H.

Hohenbergstrasse 20-22

A-1120 Wien

<http://www.ascom.at>

20323163en_ba_a0

ABSC 20323163