



Gas boiler

Gaz 6000 W

WBN 6000-30-H-E-N/L-S2400



BOSCH

Installation and maintenance instructions for the contractor

Contents

1	Key to symbols and safety instructions	3	9	Service menu settings	18
1.1	Key to symbols	3	9.1	Operating the service menu	18
1.2	General safety instructions	3	9.2	Service functions overview	18
			9.2.1	Menu 1	18
			9.2.2	Menu 2	20
			9.2.3	Menu 3	21
2	Product details	4	10	Converting the appliance to different gas types	22
2.1	Standard delivery	4	10.1	Converting to a different gas type	22
2.2	Overview of the gas categories that can be used	4	10.2	Gas settings (natural and LPG)	22
2.3	Data plate	4	10.2.1	Preparations	22
2.4	Description of appliance	4	10.2.2	Nozzle pressure setting method	22
2.5	Accessories	4			
2.6	Dimensions and minimum clearances	5	11	Flue gas testing	23
2.7	Appliance layout	6	11.1	Setting the appliance output	23
2.8	Electrical wiring diagram	7	11.2	Testing for flue gas tightness	23
2.9	Technical data	8	11.3	Measuring CO level in flue gas	23
			11.4	Measuring flue gas loss	23
3	Regulations	9	12	Environment / disposal	24
4	Flue gas routing	9	13	Inspection/Maintenance	24
4.1	Approved flue accessories	9	13.1	Description of various maintenance operations	24
4.2	Installation instructions	9	13.1.1	Calling up the last fault saved	24
			13.1.2	Opening the appliance	24
5	Installation	9	13.1.3	Cleaning the burner pan, nozzles and burner	26
5.1	Important notes	9	13.1.4	Cleaning the heat exchanger	26
5.2	Checking the size of the expansion vessel	10	13.1.5	Checking the expansion vessel (also see page 10)	26
5.3	Siting the appliance	10	13.1.6	Setting the heating system pressure	26
5.4	Fitting the appliance	11	13.1.7	Checking electrical wiring	26
5.5	Installation of the supply pipes	13	13.2	Checklist for inspection and maintenance	27
5.6	Checking the connections	13			
5.7	Connecting the flue accessories	13	14	Displays	28
6	Electrical connections	14	15	Fault mode	28
6.1	General notes	14	15.1	Troubleshooting	28
6.2	Connecting appliances with power cable and mains plug	14	15.2	Faults that are shown on the display	29
6.3	Control unit terminals	14	15.3	Faults that are not shown on the display	30
6.3.1	Connecting the on/off controller or Open Therm controller	14	15.4	Sensor values	30
6.3.2	Replacing the power cable	15	15.4.1	Flow temperature sensor	30
7	Commissioning	15	16	Commissioning report for the appliance	31
7.1	Displays	16			
7.2	Before commissioning	16			
7.3	Switching the appliance on/off	16			
7.4	Setting the maximum flow temperature	16			
7.5	Setting the heating control unit	17			
7.6	After commissioning	17			
7.7	Setting summer mode	17			
7.8	Setting frost protection	17			
8	Heating pump	17			
8.1	Changing the heating circuit pump curve	17			
8.2	Pump anti-seizing function	17			

1 Key to symbols and safety instructions

1.1 Key to symbols

Warnings



Warnings in this document are identified by a warning triangle printed against a grey background. Keywords at the start of a warning indicate the type and seriousness of the ensuing risk if measures to prevent the risk are not taken.

The following keywords are defined and can be used in this document:

- **NOTICE** indicates a situation that could result in damage to property or equipment.
- **CAUTION** indicates a situation that could result in minor to medium injury.
- **WARNING** indicates a situation that could result in severe injury or death.
- **DANGER** indicates a situation that will result in severe injury or death.

Important information



This symbol indicates important information where there is no risk to people or property.

Additional symbols

Symbol	Explanation
▶	Step in an action sequence
→	Cross-reference to another part of the document
•	List entry
–	List entry (second level)

Table 1

1.2 General safety instructions

These installation instructions are intended for gas fitters, plumbers, heating engineers and electricians.

- ▶ Read any installation instructions (boiler, heating controls, etc.) carefully before starting the installation.
- ▶ Observe the safety instructions and warnings.
- ▶ Observe national and regional regulations, technical rules and guidelines.
- ▶ Record all work carried out.

If you smell gas

A gas leak could potentially cause an explosion. If you smell gas, observe the following rules.

- ▶ Prevent flames or sparks:
 - Do not smoke, use a lighter or strike matches.
 - Do not operate any electrical switches or unplug any equipment.

- Do not use the telephone or ring doorbells.
- ▶ Turn off the gas at the meter.
- ▶ Open windows and doors.
- ▶ Warn your neighbours and leave the building.
- ▶ Prevent anyone from entering the building.
- ▶ Well away from the building: call the fire brigade, police and gas supplier.
- ▶ **CALL** The federal governments safety hotline on 13 17 92
- ▶ **LPG BOILERS** Call the supplier's number on the side of the LPG TANK/ CYLINDER
- ▶ **TURN OFF** The ECV (Emergency control valve) at the meter
- ▶ Put out naked flames
- ▶ Keep people away from the affected area

Intended use

This boiler must only be used as a heat appliance in a sealed hot water heating system for domestic purposes.

Any other use is considered inappropriate. Any damage that results from such use is excluded from liability.

Installation, commissioning and servicing

Installation, commissioning and servicing must only be carried out by an authorised contractor.

- ▶ Carry out a gas tightness test after completing work on gas-carrying components.
- ▶ Only use original spares.

Electrical work

Electrical work must only be carried out by a qualified electrician.

- ▶ Before starting electrical work:
 - Isolate the mains electrical supply and secure against unintentional reconnection.
 - Check for zero potential.
- ▶ Also observe connection diagrams of other system components.

Handover to the user

When handing over, instruct the user how to operate the heating system and inform them about its operating conditions.

- ▶ Explain how to operate the heating system and draw the user's attention to any safety-relevant action.
- ▶ Explain that modifications and repairs must only be carried out by an authorised contractor.
- ▶ Point out the necessity of inspection and servicing for safe and environmentally compatible operation.
- ▶ Leave the installation instructions and the operating instructions with the user.

THIS APPLIANCE IS NOT FOR USE AS A POOL OR SPA POOL HEATER.

2 Product details

WBN 6000-30-H-E-N/L-S2400 are appliances for central heating.

2.1 Standard delivery




Fig. 1

- [1] Wall-mounted gas boiler
- [2] Fixing material
- [3] Set of printed documents for the appliance
- [4] Flue pipe
- [5] Grommet
- [6] Regulator (Only for NG appliance)

2.2 Overview of the gas categories that can be used

The code number indicates the gas family according to AS 4552:

Code number	Wobbe index (W_s) (15 °C)	Gas type
23	12.2 - 55.0 MJ/m ³	NG
31	72.9 - 87.2 MJ/m ³	LPG

Table 2

LPG type ¹⁾	Use
Commercial Propane	recommended
Commercial Butane	permitted
General Product	permitted
Universal LPG (U-LPG)	permitted

Table 3

1) according to NZS 5435

2.3 Data plate




Fig. 2

On the data plate, you will find details on the appliance output, approval information and the series number.

2.4 Description of appliance

- Gas boiler only for external installation
- Gas boiler only for central heating
- Gas boiler for wall installation
- Power cable
- Liquid Crystal Display
- Automatic ignition
- Continuously controlled output
- Full backup via the electronics with flame monitoring and solenoid valves according to EN 298
- Three-stage heating circuit pump with automatic air vent valve
- No minimum water circulation rate required
- Fixed connections for flue gas/combustion air as concentric pipe Ø 60/100 mm
- Curve-controlled fan
- Temperature sensor and temperature control for central heating
- Temperature limiter in the flow
- Safety valve, pressure gauge, expansion vessel

2.5 Accessories



Below is a list of typical accessories for this appliance. You can find comprehensive details of all available accessories in our catalogue.

- Digital thermostat

2.6 Dimensions and minimum clearances





Fig. 3

2.7 Appliance layout



8 716 473 216-04.40

Fig. 4

- | | |
|--|-----------------------------------|
| [1] Expansion vessel | [20] Front cover for outer casing |
| [2] Fan | [21] Main cover for outer casing |
| [3] Combustion chamber | [22] Back plate for outer casing |
| [4] Burner pan with blast tube connection | [23] Interface cap |
| [5] Ignition electrode | [24] Type plate |
| [6] Safety valve (heating circuit) | [25] Plastic cover |
| [7] Automatic air vent valve | [26] Base plate for outer casing |
| [8] Heating circuit pump | |
| [9] Pump speed selector switch | |
| [10] Gas valve | |
| [11] Pressure gauge | |
| [12] Control device | |
| [13] Monitoring electrode | |
| [14] Flow temperature sensor | |
| [15] Temperature limiter for heating block | |
| [16] Air baffle | |
| [17] Differential pressure switch | |
| [18] Combustion air inlet | |
| [19] Flue pipe | |

2.8 Electrical wiring diagram




Fig. 5

- | | |
|--|--|
| [1] Differential pressure switch | [12] Hot water temperature sensor(N.A) |
| [2] Fan | [13] 240 V power cable |
| [3] Flow temperature sensor | [14] OTM connection or on/off controller ¹⁾ |
| [4] Temperature limiter for heating block | [15] Connection for outside temperature sensor |
| [5] Monitoring electrode | [16] Diagnostic interface |
| [6] Ignition electrode | [17] Transformer |
| [7] Gas valve | [18] Ignition transformer |
| [8] Cylinder temperature sensor connection (N.A) | |
| [9] Turbine (N.A) | |
| [10] 3-way valve (N.A) | |
| [11] Heating circuit pump | |

1) Remove jumper before connection

2.9 Technical data

	Unit	WBN 6000-30	
		NG	LPG
Max. rated heat output (P_{\max}) 80/60 °C	kW	30	30
Max. rated heat input (Q_{\max}), central heating	kW	33.2	33.2
Min. rated heat output (P_{\min}) 53/47 °C	kW	9	9
Min. rated heat input (Q_{\min}), central heating	kW	10.2	10.2
Gas supply rate			
Natural gas type H ($H_i(15\text{ °C}) = 9.5\text{ kWh/m}^3$)	MJ/hr	132.8	–
Butane/propane ($H_i = 12.9\text{ kWh/kg}$)	MJ/hr	–	132.8
Permissible gas supply pressure			
NG	Kpa	1.13	–
LPG	Kpa	–	2.75
Expansion vessel			
Pre-charge pressure	bar	0,5	0,5
Total capacity	L	8	8
Calculation values for calculating cross-section to EN 13384			
Flue gas temperature 80/60 °C max. rated	°C	145	145
Flue gas temperature 80/60 °C min. rated	°C	73	73
Flue gas mass flow rate, max. rated	g/s	13.6	13.5
Flue gas mass flow rate, min. rated	g/s	10,3	10,4
CO ₂ at max. rated output	%	5.5 – 6.0	5.6 – 7.0
CO ₂ at min. rated output	%	2.0 – 2.5	2.3 – 2.8
Flue gas rating group to G 636/G 635		G ₆₁ /G ₆₂	G ₆₁ /G ₆₂
NO _x content	mg/kWh	132	132
NO _x class		3	3
Flue gas connection		60/100	60/100
General data			
Power supply voltage	AC ... V	240	240
Frequency	Hz	50	50
Max. power consumption (central heating mode)	W	<130	<130
Standby power consumption	W	2	2
Noise output level	≤ dB(A)	≤ 38	≤ 38
Max. flow temperature	°C	40 – 82	40 – 82
Max. permissible operating pressure (P_{MS}) heating	bar	3	3
Permissible ambient temperature	°C	0 – 50	0 – 50
Nominal capacity of appliance heating	l	1,6	1,6
Weight (excl. packaging)	kg	42	42
Dimensions, W x H x D	mm	440 x 898x 315	440 x 898x 315

Table 4

3 Regulations

Where no specific instruction is given, reference should be made to the following standards:

- AS/NZS 5601 Gas Installations,
- AS 1596 LPG storage and handling,
- AS 4552 Gas fired water heaters for hot water supply and/or central heating,
- AS/NZS 3000 Electrical Installations,
- AS1697 Installation and maintenance of steel pipe systems for gas,
- AS 4032 Water supply - valves for the control of hot water supply temperatures,
- AS 3498 Authorization requirements for plumbing products - water heaters and hot-water storage tanks.
- AS 1910 Water supply - float control valves for use in hot and cold water, AS 3500 National plumbing and drainage code.

4 Flue gas routing

Before fitting the gas boiler and the flue system, check with the local planning authority and flue gas inspector whether there are any restrictions.

The surface temperature at the combustion air pipe is below 85 °C for concentric pipes. No minimum clearances to flammable building materials are therefore required. Local regulations may differ from this information and may stipulate minimum clearances to flammable building materials.

4.1 Approved flue accessories

The flue accessories form part of the CE approval for the appliance. For this reason, only the provided original flue accessories must be installed.

- Flue accessories, concentric pipe Ø 60/100 mm

4.2 Installation instructions

Fan stage :1 (Reference to service function 2.b.d (→ page 21).



CAUTION: Low efficiency and functional problems if an incorrect fan stage is used!

- ▶ Before fitting the flue kits:
Apply a thin coating of solvent-free grease (e.g. Vaseline) to the joint seals.
- ▶ When fitting the balanced flue, always push the pipe fully home into the sockets.

5 Installation



DANGER: Risk of explosion!

- ▶ Turn off gas valve before working on gas-carrying components.
- ▶ Check for leaks before working on gas-carrying components.



Installation, power connection, connection on the gas and flue gas side and commissioning must only be carried out by a contractor approved for such work by the local gas or power supply authority.



Not suitable for pool or spa pool application.

5.1 Important notes

- ▶ Before installing the appliance, consult your gas supply utility and your local flue gas inspector [where appropriate].

Fill and top-up water for the heating system

Unsuitable fill and top-up water in the heating system can result in the heat exchanger scaling up and failing prematurely.

Hardness range	Water treatment
soft (≤ 8.4 °dH)	not required
medium (8.4 - 14 °dH)	recommended
hard (≥ 14 °dH)	required

Table 5



For straightforward water treatment:

- ▶ Use the system approved by us.

Open vented heating systems

- ▶ Open vented heating systems must be converted to sealed systems.

Gravity fed heating systems

- ▶ Connect the appliance to the existing pipework via a low loss header with a dirt separator.

Galvanised radiators and pipes

To prevent gas formation:

- ▶ Do not use galvanised radiators or pipes.

If a room thermostat is used

- ▶ Do not fit a thermostatic radiator valve to the radiator in the primary room.

Anti-freeze

The following anti-freeze fluids are permitted:

Designation	Concentration
Varidos FSK	22 - 55 %
Alphi - 11	25 - 40 %
Glythermin NF	20 - 62 %
Antifrogen N	20 - 40 %

Table 6

Corrosion inhibitor

The following corrosion inhibitors are permissible:

Designation	Concentration
Fernox	see supplier information
Sentinel	see supplier information

Table 7

Sealants

In our experience, adding sealants to the heating water may result in problems (deposits in the heating block). We therefore advise against using them.

Water circulation noises

To prevent water circulation noises:

- ▶ Fit an overflow valve or, with 2-pipe heating systems, a 3-way valve to the radiator furthest from the boiler.

Mono-lever taps and thermostatic mixer taps

All mono-lever taps and thermostatic mixer taps can be used.

LPG

To protect the appliance against excessive pressure:

- Fit a pressure regulator with a safety valve.

5.2 Checking the size of the expansion vessel

The following diagram provides you with a rough estimate of whether the installed expansion vessel is sufficient or whether an additional expansion vessel is required.

The characteristic curves shown are based on the following key data:

- 1% water volume in expansion vessel or 20% of nominal volume of expansion vessel
- Differential operating pressure of the safety valve of 0.5 bar, according to DIN 3320
- Pre-charge pressure of expansion vessels matches static head of the system above the heat exchanger
- Maximum operating pressure of 3 bar




Fig. 6

- I Pre-charge pressure 0.2 bar
- II Pre-charge pressure 0.5 bar (default setting)
- III Pre-charge pressure 0.75 bar
- IV Pre-charge pressure 1.0 bar
- V Pre-charge pressure 1.2 bar
- t_v Flow temperature
- V_A System content in litres
- A Operating range of the expansion vessel
- B Additional expansion vessel required

- If intersection is on the limit: determine the exact size of the vessel according to DIN EN 12828.
- If the intersection is to the right of the curve: install additional expansion vessel.

5.3 Siting the appliance

Regulations concerning the installation site




Fig. 7

Key to illustration

Fan assisted flue terminal position		
Terminal Position		Minimum Spacing
A	Directly below, an opening window, air vent or other ventilation opening	1000mm
B	Below guttering, drain pipes or soil pipes	75mm
C	Below eaves	300mm
D	Below balconies or a car port roof*	300mm
E	From vertical drain pipes or soil pipes	75mm
F	From internal or external corners	300mm
G	Above adjacent ground, roof or balcony level	300mm
H	From a surface facing the terminal	1500mm
I	From a terminal facing the terminal	1200mm
K	Vertically from a terminal on the same wall	1500mm
L	Horizontally from a terminal on the wall	300mm
M	Adjacent to opening	300mm
N	Above intersection with roof	500mm
O	For a vertical structure on the roof	500mm

Table 8



Installations in car ports are not recommended.

- Plumbing will occur at the terminal so terminal positions where this could cause a nuisance should be avoided.
- The air supply and the flue gas exhaust must meet the applicable general regulations. Please consult the instructions provided with the flue terminal kits prior to installation.
- The boiler must be installed so that the terminal is exposed to the external air.
- It is important that the position of the terminal allows the free passage of air at all times.
- Minimum acceptable spacing from the openings are specified above, for domestic situations in accordance with AS 5601.

Combustion air

In order to prevent corrosion, the combustion air must not contain any corrosive substances.

Substances classed as corrosion-promoting include halogenated hydrocarbons which contain chlorine and fluorine compounds. They may be found in solvents, paints, adhesives, aerosol propellants and household cleaners, for example..

Industrial sources	
Chemical cleaners	Trichloroethylene, tetrachloroethylene, fluorinated hydrocarbons
Degreasing baths	Perchloroethylene, trichloroethylene, methylchloroform
Printing shops	Trichloroethylene
Hairdressing salons	Aerosol propellants, hydrocarbons containing fluorine and chlorine (difluorodichloromethane)
Household sources	
Cleaning and degreasing agents	Perchloroethylene, methylchloroform, trichloroethylene, methylene chloride, carbon tetrachloride, hydrochloric acid
Hobby rooms	
Solvents and thinners	Various chlorinated hydrocarbons
Aerosols	Chlorofluorinated hydrocarbons (Freon)

Table 9 Corrosive materials

Surface temperature

The maximum surface temperature of the appliance is below 85 °C. That means that no special safety precautions are required with regard to flammable building materials and fitted furniture. If regulations differ in individual countries they must be observed.

5.4 Fitting the appliance

- Fix the mounting template supplied with the documents to the wall, observing a lateral clearance of at least 100 mm (→ page 5).
- Drill the holes for the screw hooks according to the mounting template.




Fig. 8 Mounting template

- Remove the mounting template.



NOTICE: Residues in the pipework can damage the appliance.

- Flush out the system to remove all dirt residues.

- Remove packing, taking care to observe the instructions on the packing.
- Check the destination country on the type plate and make sure that the gas type specified on the identification plate matches that of the gas supplied by the gas utility company (→ page 6).

Flipping down the front cover

1. Undo screws.
2. Flip the front cover down.




Fig. 9

Taking out inner foam

1. Take out the down foam.
2. Take out the upper foam.




Fig. 10

1. Fit dowels.
2. Fit screw hooks.
3. Position the appliance on the wall and mount it on the screw hooks.




Fig. 11 Mounting the appliance on the screw hooks

Flipping down the control unit

The casing is secured with two screws against unauthorised removal (electrical safety).
 ► Always secure the outer casing with these screws.

1. Undo screws.
2. Pull the control unit down.
3. Flip the control unit down.




Fig. 12

5.5 Installation of the supply pipes

- ▶ Determine the internal pipe diameter for the gas supply in accordance with AS/NZS 5601.
- ▶ All pipe connections in the heating system must be suitable for a pressure of 3 bar.
- ▶ Install regulator¹⁾ (only for NG appliance) and convert connection¹⁾.
- ▶ For filling and draining the system, fit drain & fill valves at the lowest point of the system.
- ▶ Use corrosion-resistant materials to produce the drain for the safety valve.
Such materials include: vitrified clay pipes, hard PVC pipes, PVC pipes, PE-HD pipes, PP pipes, ABS/ASA pipes, cast-iron pipes with enamel lining or coating, steel pipes with plastic coating, stainless steel pipes, borosilicate glass pipes.
- ▶ The PRV is a safety device for the boiler and if activated may discharge boiling water steam through the relief valve drain line.



CAUTION:

- ▶ Do not modify or seal off drain pipes.
- ▶ Pipe work must always slope downwards.

5.6 Checking the connections

Water connections

- ▶ Open the heating flow and return valves and fill the heating system.
- ▶ Check sealing points for tightness (testing pressure: max. 2.5 bar at the pressure gauge).

Gas Connection:

- Fit a union to the water heater gas inlet for easy connection and removal. The thread diameter is 20 mm. THIS DOES NOT INDICATE THE SIZE OF THE GAS SUPPLY.
- Fit an AGA / NZGA approved isolating gas valve in the supply line adjacent to the water heater gas connection..
- Ensure that the supply pipe and the gas pressure regulator (LPG or Natural Gas) has sufficient flow capacity for this and other appliances connected to the fitting line.
- For LPG appliances ensure that gas cylinders are of sufficient size.
- Before connecting the appliance to the gas service, purge any debris or air from the gas service.

- Check all joints for leaks with an approved leak tester after connection.

Refer to AS/NZS 5601 Installation Code for pipe sizing and details. Ensure that the gas pipe size is correct. If undersized the appliance will not operate correctly. For Natural Gas installations where the inlet pressure exceeds 1.5kPa an appliance regulator is supplied. SERVICE CALLS ARE CHARGEABLE FOR UNITS WITH INCORRECT PIPE SIZES OR BLOCKED GAS OR WATER FILTERS.

Testing Gas Supply Pipe

- ▶ Close the gas valve to protect the gas train from pressure damage.
- ▶ Check sealing points for leaks (testing pressure: max. 15Kpa).
- ▶ Release the pressure on the gas supply pipe.

5.7 Connecting the flue accessories



The adapter has been installed in advance. If it needs to be installed again, please follow the below installation instruction.

- ▶ Ensure that the gasket is fitted inside the flue outlet.
- ▶ Push on the flue gas elbow and secure with the screws supplied.




Fig. 13 Securing flue accessories

- [1] Screws
- [2] Flue/adaptor
- [3] Gasket

1) accessory

Fixing the flue pipe

1. Fix the short flue pipe.
2. Fix the flue weather seal.




Fig. 14

6 Electrical connections

6.1 General notes



DANGER: Risk of electric shock

- Before carrying out work on electrical components, disconnect the power supply (240 V AC) (fuse, circuit breaker) and secure against unintentional reconnection.

All appliance modulation, control and safety components are tested and ready-wired for use.

Observe safety measures according to the relevant regulations and AS/NZS 3000. No other electrical consumer units may be connected to the same power cable.

Fuses

The appliance is protected by two fuses. They are located on the circuit board.



Replacement fuses are located on the cover of the control unit.

6.2 Connecting appliances with power cable and mains plug

- Insert the power cable plug into an earthed power socket.

6.3 Control unit terminals



NOTICE: Cable residues can damage the control unit.

- Only remove the insulation from the cable outside the control unit.

Flipping down the control unit



The casing is secured with two screws against unauthorised removal (electrical safety).

- Always secure the outer casing with these screws.

1. Undo screws.
2. Pull the control unit down.
3. Flip the control unit down.




Fig. 15

6.3.1 Connecting the on/off controller or Open Therm controller

Only operate this appliance with a controller.

The controller must be suitable for mains voltage (from boiler) and must not have its own earth connection.

For installation and electrical connection, see the relevant installation instructions.

The controller connection on the control unit is located underneath a cover.

- Remove the cover.
- Remove the jumper from the TH terminals.
- Connect the controller to the TH terminals.




Fig. 16

6.3.2 Replacing the power cable

Use only original power cable.

The control unit must be opened to connect the power cable.

- ▶ Disconnect the ignition cable.
- ▶ Remove cover.
- ▶ Remove old cable.
- ▶ Plug new cable connector on the conductor board.
- ▶ Plug strain relief to the case.
- ▶ Mount cover.
- ▶ Connect ignition cable.




Fig. 17

7 Commissioning




Fig. 18

- [1] Drain hose
- [2] Heating return valve (accessory)
- [3] Cold water valve (accessory)
- [4] Gas valve (closed) (accessory)
- [5] Heating flow valve (accessory)
- [6] Automatic air vent valve
- [7] Standby key
- [8] Display
- [9] "Back" key (= exit service function/submenu without saving)
- [10] + key
- [11] OK button (= confirm selection, save value)
- [12] - key (mode)
- [13] Pressure gauge
- [14] System top-up fixture
- [15] Test point
- [16] Cold water supply

7.1 Displays




Fig. 19 Displays

- [1] Burner operation
- [2] Fault display/standby mode display
- [3] Heating mode active
- [4] DHW heating active
- [5] Summer mode active
- [6] Service Mode
- [7] Temperature display (in °C)

7.2 Before commissioning

NOTICE: Commissioning without water will destroy the appliance.

- ▶ Only operate the appliance once it has been filled with water.

- ▶ Adjust pre-charge pressure of expansion vessel to static head of the heating system (→ page 10).
- ▶ Open the automatic air vent valve (leave open) (→ Fig. 18, [7], page 15).
- ▶ Open all system radiator valves.
- ▶ Open the heating flow valve and heating return valve (→ Fig. 18, [6] and [2], page 15).
- ▶ Fill the heating system to 1 - 2 bar and close the fill valve.
- ▶ Bleed radiators.
- ▶ Top up heating system to pressure of 1 - 2 bar.
- ▶ Check that the gas type specified on the type plate matches that of the gas supply (→ see Fig. 24).
- ▶ Open the gas valve (→ Fig. 18, [4]).
- ▶ Plug in the power plug: the appliance enters standby mode.

7.3 Switching the appliance on/off

Initial switching on/setting the fan stage

At the factory, fan stage 0 is selected, i.e. fan and burner will not start.

- ▶ Start the appliance at the standby key (→ Fig. 20).
- The following fault display is shown:



Fig. 20

Set fan stage:

- ▶ Determine a suitable fan stage.
- ▶ Hold down "Back", + and - at the same time until **L.1** is shown on the display.
- ▶ Press + until **L.2** is shown on the display.
- ▶ Press OK to make settings in menu 2.

- ▶ Press + or - to call up service function 2.b.d (→ page 21).
- ▶ Press OK to switch to the service function.
The value flashes on the display.
- ▶ Press + or - to set the required value.
- ▶ Hold down OK until the selected service function appears on the display.
The display switches to the selected service function automatically.
- ▶ Press standby.
The boiler returns to standard mode.

Switching on

- ▶ Start the appliance at the standby key.
The display shows the heating water flow temperature.

Switching off/standby mode

- ▶ Shut down the appliance at the standby key.
Only the warning symbol continues to be displayed.
- ▶ If the appliance is to be switched off for a longer period of time: observe correct frost protection procedures (→ chapter 7.8).




Fig. 21

i The appliance has an anti-seizing function which prevents the heating circuit pump and the 3-way valve seizing up following long periods of inactivity. The anti-seizing function remains active during standby mode.

7.4 Setting the maximum flow temperature

The maximum flow temperature can be set between 40 °C and approx. 82 °C. The current flow temperature is shown on the display.

- ▶ Keep pressing - until the symbol appears on the display.
- ▶ Press OK.
The set maximum flow temperature is displayed.
- ▶ Press + or - to set the required maximum flow temperature.
- ▶ Press OK to save the setting.
The display shows the current flow temperature.

You can find typical maximum flow temperatures in Tab. 10.

i When selecting . ., heating mode is disabled (appears on the display, summer mode).

When the burner is active in heating mode, the symbol and the burner symbol appear on the display.

Flow temperature	Sample application
. . (symbol appears)	Summer mode
Approx. 75 °C	Radiator heating system
approx. 82 °C	Convactor heating system

Table 10 Maximum flow temperature

7.5 Setting the heating control unit



Observe the operating instructions of the heating controller. This shows you:

- ▶ how to adjust the room temperature,
- ▶ how to heat economically and save energy.

The Bosch TRZ200 Open Therm controller (programmable heating controller) can be used.

7.6 After commissioning

- ▶ Check the gas supply pressure (→ page 22).
- ▶ Record the settings in the commissioning report (→ page 31).

7.7 Setting summer mode

The heating circuit pump and consequently central heating are switched off. The DHW and power supply for the heating control unit and timer are retained.



NOTICE: Heating system at risk through frost. In summer mode, only the appliance is protected against frost.

- ▶ Observe frost protection measures where there is a risk of frost (→ Chapter 7.8).

To set summer mode:

- ▶ Keep pressing – until the symbol appears on the display.
- ▶ Press OK.

The set maximum flow temperature is displayed.

- ▶ Keep pressing – until . . appears on the display.
 - ▶ Press OK to save the setting.
- is permanently displayed.

Additional instructions are contained in the operating instructions for the heating programmer.

7.8 Setting frost protection

Frost protection for the heating system:

Frost protection for the heating system is only ensured if the heating circuit pump is operational and is pumping heating water through the entire system.

- ▶ Leave the heating switched on.
- ▶ Set the maximum flow temperature to at least 40 °C (→ chapter 7.4).

-or- If you want to leave the appliance switched off:

- ▶ Add anti-freeze to the heating water (→ page 9) and drain the DHW circuit.



For further information, see the heating controller operating instructions.

Appliance frost protection:

The appliance frost protection function switches the burner and heating circuit pump on when the temperature in the installation room (at temperature sensor for heating flow) falls below 5 °C. This prevents the boiler freezing up.

- ▶ Activate summer mode (→ chapter 7.7) or set the appliance to standby mode (→ chapter 7.3).



NOTICE: Heating system at risk through frost. In summer/standby mode, only the appliance is protected against frost.

8 Heating pump

8.1 Changing the heating circuit pump curve

The speed of the heating pump can be changed at the pump terminal box.




Fig. 22

- [1] Curve for switch position 1
- [2] Curve for switch position 2
- [3] Curve for switch position 3 (default setting)
- [H] Residual head
- [Q] Amount of circulating water



- ▶ In order to save as much energy as possible and keep flow noise to a minimum, set a low pump curve.

8.2 Pump anti-seizing function



This function prevents the heating pump and the 3-way valve seizing up following long periods of inactivity. The anti-seizing function remains active during standby mode.

Every time the pump is switched off, a timer is started. If after 24 hours the pump has not run again, it is switched on briefly.

9 Service menu settings

9.1 Operating the service menu

The service menu enables the convenient adjustment and checking of many appliance functions.

The service menu splits into three submenus:

- Menu 1, for setting level one service functions (→ page 19)
- Menu 2, for setting level two service functions (→ page 20)
- Menu 3, for setting the appliance type and output (→ page 21)

For an overview of service functions, see chapter 9.2 from page 18.

Selecting a service function

Calling up the service functions is different from one menu to the next. For a description, see the beginning of each menu overview.

- ▶ Calling up a menu:
 - Menu 1 (→ page 19)
 - Menu 2 (→ page 20)
 - Menu 3 (→ page 21)
- ▶ Press + or – to scroll through the menu's service functions.

Making a setting

- ▶ Press OK to switch to the service function.
The value flashes on the display.
- ▶ Press + or – to set the required value.

Saving a setting

- ▶ Hold down OK until the selected service function appears on the display.
The display switches to the selected service function automatically.



If you do not press a key for 15 minutes, the service menu will be closed automatically.

Exiting the service function without saving settings

- ▶ Press standby.
The boiler returns to standard mode.

Restoring values to standard setting

To restore all values from service levels 1 and 2 to their default settings:

- ▶ Select service function 2.8.E in the second service menu and save value **01**. The appliance starts with the default setting.

9.2 Service functions overview

9.2.1 Menu 1

To call up a service function in this menu:

- ▶ Hold down “Back”, + and – at the same time until **L.1** is shown on the display.
- ▶ Press OK to make settings in menu 1.
- ▶ Press + or – to scroll through the menu's service functions.

The user is responsible for the safety and environmental compliance of the heating system.

You should therefore arrange a maintenance and inspection contract with an authorised contractor, covering an annual inspection and demand-dependent maintenance. This guarantees you high efficiency and environmentally compatible combustion.

For service/parts and maintenance in AU please contact 1300 30 70 37. For NZS 0800 54 33 52.

Service function		Possible settings/display
1.2.C	Venting function	<p>The venting function can be activated after maintenance.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 00: Venting function off • 01: Venting function is switched on and after completion automatically reset to 00 <p>Default setting is 00.</p>
1.2.d	Thermal disinfection of the DHW cylinder (WBN 6000-...H...)(N.A)	<ul style="list-style-type: none"> • 0: Switched off • 1: Switched on <p>This service function activates the heating of the DHW cylinder to 75 °C.</p> <p>► Implement thermal disinfection as described in chapter 8.2, page 17.</p> <p>Thermal disinfection will not be displayed.</p> <p>Thermal disinfection terminates after the water has been held at 75 °C for 35 minutes.</p>
1.2.F	Operation Mode	<p>With this service function, you can temporarily change the appliance operating mode.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 00: Standard operation; the appliance runs according to controller specifications. • 02: The appliance runs for 15 minutes at the set maximum output. After 15 minutes, the appliance switches to standard mode. • 03: The appliance runs for 15 minutes at minimum output. After 15 minutes, the appliance switches to standard mode. • 04: The appliance runs for 15 minutes at maximum output. After 15 minutes, the appliance switches to standard mode. <p>Default setting is 0.</p>
1.3.b	Time interval for starting and stopping the burner	<p>The time interval determines the minimum delay between the burner stop and restart.</p> <p>Setting range: 1 to 10 minutes.</p> <p>Default setting is 3 minutes.</p>
1.3.C	Temperature differential for stopping and restarting the burner	<p>The temperature differential determines the level by which the flow temperature must drop below the set flow temperature before the drop is interpreted as a heat demand.</p> <p>Settings in 1 K steps are possible.</p> <p>The temperature differential can be selected between 0 and 10 K.</p> <p>Default setting is 5 K.</p>
1.3.F	Duration of heat retention	<p>Heating mode is disabled for this period of time following DHW heating.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 1 ... 10 minutes <p>Default setting is 1 minute.</p>
1.5.b	Fan run-on time	<p>This service function allows you to set the fan run-on time.</p> <p>The run-on time can be set from 01 to 18 (10 - 180 seconds).</p> <p>Standard setting is 03 (30 seconds).</p>
1.6.A	Calling up the last fault saved	<p>The function enables you to retrieve the last fault stored.</p> <p>The service function is reset at 00.</p>
1.6.d	Current turbine flow rate	<p>The current turbine flow rate is displayed.</p> <p>Possible displays are:</p> <ul style="list-style-type: none"> • 0.0 - 20.0: 0.0 to 20 l/min
1.7.A	Liquid crystal display illumination	<p>The following settings are possible:</p> <ul style="list-style-type: none"> • 00: Off • 01: on <p>Default setting is 00.</p>
1.7.C	Minimum DHW flow rate(N.A)	<p>DHW heating is activated if amounts above this value are drawn off.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 2.5 ... 5 litres per minute <p>Default setting is 2.5 l/min.</p>

Table 11 Menu 1

9.2.2 Menu 2

To call up a service function in this menu:

- ▶ Hold down “Back”, + and – at the same time until **L.1** is shown on the display.
- ▶ Press + until **L.2** is shown on the display.
- ▶ Press OK to make settings in menu 2.
- ▶ Press + or – to scroll through the menu's service functions.

Service function		Possible settings/comments/displays
2.1.A	Maximum output	<p>Some gas supply utilities charge a basic rate based on output.</p> <p>The output can be limited to the specific heat demand between the minimum rated output and maximum rated output.</p> <p>Default setting is the maximum rated output.</p> <ul style="list-style-type: none"> ▶ Set the output in per cent. ▶ Measure the gas flow rate and compare it with the information from the setting tables . If they do not match, change the setting.
2.1.b	Maximum output (DHW)(N.A)	<p>The output can be limited to the specific heat demand between the minimum rated output and maximum rated output.</p> <p>Default setting is the maximum rated output for DHW.</p> <ul style="list-style-type: none"> ▶ Set the DHW output in percent. ▶ Measure the gas flow rate and compare it with the information from the setting tables.If they do not match, change the setting.
2.2.b	Maximum flow temperature	<p>The maximum flow temperature can be set to between 40 °C and 82 °C.</p> <p>Default setting is 85.</p>
2.3.d	Minimum rated output (heating)	<p>The output can be set to any percentage value between the minimum and maximum rated output.</p> <p>The default setting is the minimum rated output (heating), which varies according to appliance.</p>
2.4.E	Internal parameter	Do not change value 0.
2.8.A	Software version	The current software version is displayed.
2.8.E	Returning the appliance to its standard settings	<p>This service function enables you to reset the appliance to its standard settings.</p> <p>Setting 00.</p>

Table 12 Menu 2

Service function		Possible settings/comments/displays
2.9.A	Permanent operating mode	<p>This function permanently sets an operating mode.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 00: Standard operation; the appliance runs according to controller specifications. • 01: The appliance runs at minimum output. • 02: The appliance runs at maximum output. <p>Default setting is 0.</p>
2.9.b	Current fan speed	Current fan speed in 1/s.
2.9.E	Signal turbine delay (WBN 6000-..C..)(N.A)	<p>Through spontaneous pressure change in the water supply, the flow meter (turbine) can signal that water is being drawn off. This means the burner starts briefly although no water is drawn off.</p> <p>The turbine signal delay can be set from 01 to 06. One step corresponds to 0.25 seconds.</p> <p>Default setting is 02 (0.5 seconds).</p>
2.9.F	Heating circuit pump run-on time	<p>The pump run-on time is started by the control system at the end of the heat demand.</p> <p>The following settings are possible:</p> <ul style="list-style-type: none"> • 0 to 10: run-on time in minutes (steps of 1 minute) <p>Default setting is 3 minutes.</p>
2.A.A	Temperature at flow temperature sensor	This service function allows you to display the temperature at the flow temperature sensor.
2.A.b	DHW temperature (WBN 6000-..C..)(N.A)	This service function allows you to display the DHW temperature.
2.A.C	Temperature at cylinder temperature sensor (WBN 6000-..H..)(N.A)	This service function allows you to display the temperature in the DHW cylinder.
2.b.d	fan stage	<p>This service function allows you to match the fan performance to the flue length.</p> <p>Default setting is 00 (fan does not start).</p>
2.b.F	DHW heating delay (solar mode)(N.A)	<p>Heating will be suppressed until the DHW temperature sensor detects that the water preheated by solar energy has reached the required outlet temperature. Set the heating delay in accordance with system conditions.</p> <p>The start delay can be set between 0 - 50 seconds.</p> <p>Default setting is 0 (disabled).</p>
2.0.A	Gas type for appliance type	<p>This service function allows you to set the gas type.</p> <p>Possible displays are:</p> <ul style="list-style-type: none"> • 00: Appliance for natural gas • 01: Appliance for LPG
2.0.B	Ionisation current	<ul style="list-style-type: none"> • With operational burner: <ul style="list-style-type: none"> – $\geq 1 \mu\text{A}$ = OK – $< 1 \mu\text{A}$ = faulty • With burner off: <ul style="list-style-type: none"> – $< 1 \mu\text{A}$ = OK – $\geq 1 \mu\text{A}$ = faulty

Table 12 Menu 2

9.2.3 Menu 3

To call up a service function in this menu:

- Hold down “Back”, + and – at the same time until **L.1** is shown on the display.
- Press + until **L.3** is shown on the display.
- Press OK to make settings in menu 3.
- Press + or – to scroll through the menu's service functions.

Service function		Possible settings/comments/displays
3.1.A	Appliance type, output, DHW heating	This service function allows you to adjust the control unit to the appliance output and the type of DHW heating. This is necessary when the control unit is replaced.

Table 13 Menu 3


10 Converting the appliance to different gas types

10.1 Converting to a different gas type

The following gas conversion kits are available:

Appliance	Conversion to	Part no.
WBN 6000-30-H-E-N/L-S2400	LPG	8 733 201 156
	NG	8 733 201 155

Table 14



DANGER: Risk of explosion!

- ▶ Turn off gas valve before working on gas-carrying components.
- ▶ Check for leaks before working on gas-carrying components.

- ▶ Install the conversion kit according to the accompanying installation instructions.
- ▶ Make the gas settings after every conversion (→ section 10.2).

10.2 Gas settings (natural and LPG)

10.2.1 Preparations

- ▶ Flip the control unit down (→ page 12).
- ▶ Mount the control unit at the bottom of the appliance so that the gas train and the control unit can be operated at the same time.




Fig. 23 Control unit, mounted in the frame, allowing the gas train and control unit to be operated at the same time

The rated output can be set using the nozzle pressure or volumetrically.

- ▶ Always initially adjust at maximum output and then at minimum output.
- ▶ To ensure heat transfer, open radiator valves or hot water draw-off point.




Fig. 24 Gas train

- [1] Test port (for nozzle pressure)
- [2] Adjusting screw, maximum gas volume
- [3] Cap
- [4] Adjusting screw, minimum gas volume
- [5] Test nipple for gas supply pressure

10.2.2 Nozzle pressure setting method

Nozzle pressure at maximum output

- ▶ Select service function 1.2.F and operating mode **04 (= maximum rated output)** (→ page 19).
- ▶ Loosen the sealing screw at the test nipple for the nozzle pressure (→ Fig. 24, [1]) and connect the U-tube pressure gauge.
- ▶ Remove the cover (→ Fig. 24, [4]).
- ▶ For “max.” specified nozzle pressure (mbar). Use the setting screw to set the nozzle pressure for the max. gas volume (→ Fig. 24, [2]). Turn clockwise = more gas; turn anti-clockwise = less gas.

Nozzle pressure at minimum output

- ▶ Select service function 1.2.F and operating mode **03 (= minimum rated output)** (→ page 19).
- ▶ For “min.” specified nozzle pressure (mbar). Use the setting screw to set the nozzle pressure for the min. gas volume (→ Fig. 24, [3]).
- ▶ Check the set min. and max. values and correct them if required.

Checking the gas supply pressure

- ▶ Switch off the gas boiler, close the gas valve, remove the U-tube pressure gauge and tighten the sealing screw [1].
- ▶ Loosen the sealing screw at the test nipple for the gas supply pressure (→ Fig. 24, [5]) and connect the pressure gauge.
- ▶ Open the gas valve and switch on the gas boiler.
- ▶ Select service function 1.2.F and operating mode **04 (= maximum rated output)** (→ page 19).
- ▶ Check required gas supply pressure according to table.

Gas type	Nominal pressure [Kpa]	Permissible pressure range at max. rated output [Kpa]
Natural gas H (23)	1.13	1.13 - 3.0
LPG (Propane) ¹⁾	2.75	2.5 - 3.5
LPG (Butane)		

Table 15

1) Standard figure for LPG with fixed cylinders with capacities up to 15 000 l



Never commission the appliance above or below these values. Identify the cause and rectify the fault. Where that is not possible, isolate the appliance from the gas side and notify the customer.

Resetting the appliance to standard operating mode

- ▶ Select service function 1.2.F and operating mode **00** (= **standard mode**) (→ page 19).
- ▶ Switch off the appliance, close the gas valve, remove the pressure gauge and tighten the sealing screw.
- ▶ Reattach the cover and seal it.

11 Flue gas testing

11.1 Setting the appliance output

To select the **maximum appliance output**:

- ▶ Select service function 1.2.F and operating mode **04** (→ page 19).

To select the **minimum appliance output**:

- ▶ Select service function 1.2.F and operating mode **03** (→ page 19).



You have 15 minutes in which to take your measurements. Afterwards, the appliance returns to standard mode.

To select **Standard mode**:

- ▶ Select service function 1.2.F and operating mode **00** (→ page 19).

-or-

- ▶ Press standby.

The boiler returns to standard mode.

11.2 Testing for flue gas tightness



You can test for flue gas tightness by measuring the O₂ or CO₂ content of the combustion air.

An annular gap probe is required for carrying out the test.

This test is only possible with flue routing type C₁₂ and C₃₂.

The O₂ level must not be below 20.6 %. The CO₂ level must not exceed 0.2 %.

- ▶ To ensure heat transfer, open radiator valves or hot water draw-off point.
- ▶ Switch on the appliance and wait a few minutes.
- ▶ Remove the sealing plug from the combustion air testing socket (2).
- ▶ Insert the probe into the test port.




Fig. 25

- [1] Test port for flue gas
- [2] Test port for combustion air

- ▶ Seal the test port.
- ▶ Select service function 1.2.F and operating mode **04** (→ page 19).

- ▶ Measure the O₂ or CO₂ level.
- ▶ Select service function 1.2.F and operating mode **00** (→ page 19).
- ▶ switch off the appliance.
- ▶ Remove the probe.
- ▶ Refit plug.

11.3 Measuring CO level in flue gas

A multi-port probe is required for carrying out the test.

- ▶ To ensure heat transfer, open radiator valves or hot water draw-off point.
- ▶ Switch on the appliance and wait a few minutes.
- ▶ Remove the sealing plug from the flue gas testing socket (1).
- ▶ Insert the probe as far as it will go into the test port.
- ▶ Seal the test port.
- ▶ Select service function 1.2.F and operating mode **04** (→ page 19).
- ▶ Measure the CO level.
- ▶ Select service function 1.2.F and operating mode **00** (→ page 19).
- ▶ switch off the appliance.
- ▶ Remove the probe.
- ▶ Refit plug.




Fig. 26

- [1] Test port for flue gas
- [2] Test port for combustion air

11.4 Measuring flue gas loss

A flue gas probe and a temperature sensor are required for carrying out the test.

- ▶ To ensure heat transfer, open radiator valves or hot water draw-off point.
- ▶ Switch on the appliance and wait a few minutes.
- ▶ Remove the sealing plug from the flue gas testing socket (1).
- ▶ Insert the flue gas probe approx. 60 mm into the test port or to the position at which the flue gas temperature is highest.
- ▶ Seal the test port.
- ▶ Remove the sealing plug from the combustion air testing socket (2).
- ▶ Push the temperature sensor approx. 20 mm into the port.
- ▶ Seal the test port.
- ▶ Select service function 1.2.F and operating mode **04** (→ page 19).
- ▶ Measure the flue gas loss or boiler efficiency at a boiler temperature of 60 °C.
- ▶ Select service function 1.2.F and operating mode **00** (→ page 19).
- ▶ switch off the appliance.
- ▶ Remove the probe.
- ▶ Remove the temperature sensor.
- ▶ Refit plug.

12 Environment / disposal

Environmental protection is a fundamental corporate strategy of the Bosch Group.

The quality of our products, their efficiency and environmental safety are all of equal importance to us and all environmental protection legislation and regulations are strictly observed.

We use the best possible technology and materials for protecting the environment taking into account of economic considerations.

Packaging

We participate in the recycling programmes of the countries in which our products are sold to ensure optimum recycling.

All of our packaging materials are environmentally friendly and can be recycled.

Used appliances

Used appliances contain valuable materials that should be recycled. The various assemblies can be easily dismantled and synthetic materials are marked accordingly. Assemblies can therefore be sorted by composition and passed on for recycling or disposal.

13 Inspection/Maintenance

To ensure that gas consumption and environmental impact remain as low as possible over an extended period of time, we recommend that you take out an inspection/maintenance contract with an authorised contractor covering an annual inspection, and maintenance at other times as required.



DANGER: Risk of explosion!

- ▶ Turn off gas valve before working on gas-carrying components.
- ▶ Check for leaks before working on gas-carrying components.



DANGER: Risk of poisoning

- ▶ Check for leaks before working on gas-carrying components.



DANGER: Risk of electric shock

- ▶ Before carrying out work on electrical components, disconnect the power supply (240 V AC) (fuse, circuit breaker) and secure against unintentional reconnection.



WARNING: Risk of scalding

Hot water can lead to severe scalding.

- ▶ Close all valves and possibly drain appliance prior to working on parts carrying water.



NOTICE: Escaping water can damage the electronics.

- ▶ Cover the electronics prior to working on parts carrying water.

Important notes



For an overview of faults, see page 29.

- The following test equipment is required:
 - Electronic flue gas emission meter for CO₂, CO and exhaust temperature
 - Pressure gauge for 0 - 30 mbar (resolution at least 0.1 mbar)
- Special tools are not required
- Permissible lubricants:
 - For components in contact with water: Unisilikon L 641 (8 709 918 413).
 - Unions: HfT 1 v 5 (8 709 918 010).
- ▶ Use 8 719 918 658 as heat conducting paste.
- ▶ Only use genuine spare parts!
- ▶ Refer to the spare parts catalogue when ordering spare parts.
- ▶ Always renew seals and O-rings removed during servicing or repair work.

After inspection/maintenance

- ▶ Retighten all loosened threaded fittings.
- ▶ Recommission the appliance (→ page 15).
- ▶ Check all connections for leaks.

13.1 Description of various maintenance operations

13.1.1 Calling up the last fault saved

- ▶ Select service function **1.6.A** (→ page 19).



For an overview of faults, see page 29.

13.1.2 Opening the appliance

Taking down flue pipe

1. Take down the sealing.
2. Take the short flue pipe.




Fig. 27

Flipping down the front cover

1. Undo the screws.
2. Flip the front cover down.




Fig. 28

Flipping down the control unit

The casing is secured with two screws against unauthorised removal (electrical safety).
 ► Always secure the outer casing with these screws.

1. Undo screws.
2. Pull the control unit down.
3. Flip the control unit down.




Fig. 29

Removing the front casing

The front casing is secured with two screws against unauthorised removal (electrical safety).
 ► Always secure the outer casing with these screws.

1. Remove both safety screws from the appliance front.
2. Lift off the case.




Fig. 30

13.1.3 Cleaning the burner pan, nozzles and burner

- ▶ Loosen five screws and lift out the combustion chamber cover by pulling it forwards.




Fig. 31 Opening the burner

- [1] Screws
- [2] Combustion chamber cover

- ▶ Remove burner.
- ▶ Remove the nozzle holder.
- ▶ Clean burner using a brush. Ensure that the blades and nozzles are clear. **Do not use a metal brush to clean the nozzles.**
- ▶ Check electrodes for contamination and clean or replace if required.
- ▶ Check the gas setting (→ page 22).




Fig. 32

- [1] Blast tube connection
- [2] Burner half
- [3] Gas train
- [4] Nozzle

13.1.4 Cleaning the heat exchanger

1. Disconnect the cable.
2. Remove screw fittings.
3. Pull the heat exchanger out towards the front.




Fig. 33

- ▶ Clean the heat exchanger in water using a rinsing agent and reinstall it.
- ▶ Carefully straighten any distorted fins on the heat exchanger.

13.1.5 Checking the expansion vessel (also see page 10)

According to DIN 4807, Part 2, Section 3.5, the expansion vessel must be checked annually.

- ▶ Depressurise the appliance.
- ▶ Adjust the pre-charge pressure of the expansion vessel to the static head of the heating system, if necessary.

13.1.6 Setting the heating system pressure



NOTICE: Damage to appliance due to cold water!

Stress cracks can occur on the hot heat exchanger when the heating water is topped up.

- ▶ Only top up the heating water when the appliance is cold.

Pressure gauge reading

1 bar	Minimum system pressure (when cold)
1 - 2 bar	Optimum system pressure
3 bar	Maximum system pressure at highest heating water temperature:: must not be exceeded (safety valve opens).

Table 16

- ▶ If the pointer is below 1 bar (when the system is cold), top up with water to the system until the pointer is between 1 bar and 2 bar again.
- ▶ If there is a pressure drop: check the expansion vessel and heating system for leaks.

13.1.7 Checking electrical wiring

- ▶ Check wiring for mechanical damage and replace faulty cables/leads.

13.2 Checklist for inspection and maintenance

Date						
1	Call up the last fault saved in the electronics, service function 1.6.A (→ page 19).					
2	Perform a visual check of the air/flue gas routing.					
3	Check the gas supply pressure, (→ page 22).	mbar				
4	Check for leaks on the gas and water connections (→ page 13).					
5	Check heat exchanger, (→ page 26).					
6	Check burner (→ page 26).					
7	Check electrodes (→ page 26).					
8	Check the expansion vessel pre-charge pressure matches the static head of the heating system.	bar				
9	Check the heating system pressure.	bar				
10	Check electrical wiring for damage.					
11	Check the heating controller settings.					
12	Check the set service functions.					

Table 17

14 Displays

The display shows the following (tab.Fig. 18 and Fig. 19):

Value displayed	Description
Number, point, number or letter, point followed by a letter	Service function (→ Tab. 11 to Tab. 13, page 19 to 21)
Letter followed by number or letter	Fault code flashes (→ Tab. 20, page 29)
Two numbers or one number, point followed by number or Three numbers	Decimal figure e.g. flow temperature

Table 18 Displays





Special display	Description
	Venting function enabled (approx. 2 minutes).
	Summer mode (appliance frost protection)
e.g. EA	Fault code (→ chapter 15.1)
	Fan stage 0 is set, → service function 2.b.d.
only 	Standby

Table 19 Special displays

15 Fault mode

15.1 Troubleshooting



DANGER: Risk of explosion!

- Turn off gas valve before working on gas-carrying components.
- Check for leaks before working on gas-carrying components.



DANGER: Risk of poisoning

- Check for leaks before working on gas-carrying components.



DANGER: Risk of electric shock

- Before carrying out work on electrical components, disconnect the power supply (240 V AC) (fuse, circuit breaker) and secure against unintentional reconnection.



WARNING: Risk of scalding



- Hot water can lead to severe scalding.
- Close all valves and possibly drain appliance prior to working on parts carrying water.





NOTICE: Escaping water can damage the electronics.

- Cover the electronics prior to working on parts carrying water.

All safety, modulation and control components are monitored by the Heatronic system.

If a fault occurs during operation, the display shows the  symbol and possibly , and a fault code (e.g. **EA**) flashes.

If  and  appear:

- Press and hold down OK until the  and  symbols are no longer displayed.
The appliance will start up again and the flow temperature will be displayed.

If only  appears:

- Switch the appliance first off and then on again by means of the standby key.
The appliance will start up again and the flow temperature will be displayed.

If a fault persists:

- Contact your approved installer or Customer Service for assistance, providing details of the fault and the appliance.



For an overview of faults, see page 29.
For an overview of displays, see page 28.

If a fault persists:

- Check the circuit board, replace it if required and reset the service functions.

15.2 Faults that are shown on the display


Display code	Description	Remedy
A7	Temperature sensor for hot water is faulty.	► Check the temperature sensor and connecting lead for breaks or short-circuits; replace them if required.
Ad	Cylinder temperature sensor not detected.	Check cylinder temperature sensor and connecting lead.
C1	Fan speed too low.	► Check power supply. ► Check flue gas system; clean or repair if required.
C4	The differential pressure switch will not respond if the fan is switched off.	Check pressure switch and wiring, check connection hoses.
C6	Pressure switch not closing.	Check fan lead and connector, check fan, replace as necessary. Check pressure switch, sensor and connecting pipes.
C7	Fan not running.	Check fan lead and connector, check fan, replace as necessary.
CE	Filling pressure of the heating system is too low.	► Top up the system with water.
d7	Gas valve faulty.	► Check lead. ► Check gas train; replace if required.
E2	Flow temperature sensor faulty (lead break).	Check the temperature sensor and connecting lead for breaks or short-circuits.
E9	Temperature limiter for heating block has responded.	► Check heat exchanger temperature limiter and lead for breaks; replace if required. ► Check the operating pressure of the heating system. ► Check temperature limiter; replace if required. ► Check pump starter; replace pump if required. ► Check the fuse; replace if required (→ page 7). ► Bleed the appliance. ► Check heating block on the water side; replace if required. ► Check flue gas temperature limiter and lead for breaks; replace if required.
EA	Flame not detected.	► Check earth lead is correctly connected. ► Check whether gas valve is open. ► Check gas supply pressure; correct if required. ► Check power supply. ► Check electrodes with lead; replace if required. ► Check flue gas system; clean or repair if required. ► Check gas settings; correct if required. ► For natural gas: Check external gas flow limiter; replace if required. ► For open flue operation, check air supply or ventilation apertures. ► Clean heat exchanger (→ page 26). ► Check gas train; replace if required.
F7	A flame is detected although the appliance is switched off.	► Check electrodes for contamination; replace if required. ► Check flue gas system; clean or repair if required. ► Check PCB for moisture; dry if required.
FA	A flame is detected after the gas has been switched off.	► Check gas train; replace if required. ► Check electrodes and lead; replace if required. ► Check flue gas system; clean or repair if required.
	Fan stage not selected.	► Select fan stage.
P	Appliance type not defined.	► Set appliance type (→ service function 3.1.A).
Fd	Key was held down for too long (over 30 secs).	► Press the key again for less than 30 secs.

Table 20

15.3 Faults that are not shown on the display

Appliance faults	Remedy
Flow noises	▶ Correctly set the pump speed at the pump terminal box.
Heat-up takes too long	▶ Correctly set the pump speed at the pump terminal box.
Flue gas readings incorrect; CO levels too high	<ul style="list-style-type: none"> ▶ Check gas type. ▶ Check gas supply pressure; adjust if required. ▶ Check flue gas system; clean or repair if required. ▶ Check gas settings; replace gas train if required.
Ignition too violent, poor	<ul style="list-style-type: none"> ▶ Check gas type. ▶ Check gas supply pressure; adjust if required. ▶ Check power supply. ▶ Check electrodes with lead; replace if required. ▶ Check flue gas system; clean or repair if required. ▶ Check gas settings; replace gas train if required. ▶ For natural gas: Check external gas flow limiter; replace if required. ▶ Check burner; replace if required.
DHW outlet temperature is not reached	<ul style="list-style-type: none"> ▶ Check appliance type and gas type; see service function 2.0.A. ▶ Check turbine. Replace if required.

Table 21 Faults that are not shown on the display

15.4 Sensor values

15.4.1 Flow temperature sensor

Temperature/ °C Measuring tolerance ± 10 %	Resistance/ Ω
0	33 242
10	19 947
20	12 394
30	7 947
40	5 242
50	3 548
60	2 459
70	1 740
80	1 256
90	923

Table 22

16 Commissioning report for the appliance

Customer/system user:	
Surname, first name	Street, house number
Telephone/fax	Postcode, town
System installer:	
Order number:	
Appliance type (Complete a separate report for every appliance!)	
Serial number:	
Date commissioned:	
<input type="checkbox"/> Individual appliance <input type="checkbox"/> Cascade, Number of appliances:	
Boiler room: <input type="checkbox"/> Cellar <input type="checkbox"/> Attic Other:	
Ventilation apertures: Number:, Size: approx. cm ²	
Flue routing: <input type="checkbox"/> Twin pipe system <input type="checkbox"/> LAS <input type="checkbox"/> Duct <input type="checkbox"/> Separate pipe routing	
<input type="checkbox"/> Plastic <input type="checkbox"/> Stainless steel <input type="checkbox"/> Aluminium	
Total length: approx. m 90° bend: pce 15 - 45° bend: pce	
Flue tightness test (with combustion air flowing in countercurrent): <input type="checkbox"/> Yes <input type="checkbox"/> No	
CO ₂ value in the combustion air at maximum rated output: %	
O ₂ value in the combustion air at maximum rated output: %	
Notes regarding underpressure or overpressure operation:	
Gas setting and flue gas test:	
Set gas type: <input type="checkbox"/> Natural gas H <input type="checkbox"/> Propane <input type="checkbox"/> Butane	
Gas supply pressure: Kpa	Gas static supply pressure: Kpa
Selected maximum rated output: kW	Selected minimum rated output: kW
Gas flow rate at maximum rated output: mj/hr	Gas flow rate at minimum rated output: mj/hr
Net calorific value H _{IB} : kWh/m ³	
Measuring the flue gas loss at maximum rated output: %	Measuring the flue gas loss at minimum rated output: %
CO at maximum rated output: ppm	CO at minimum rated output: ppm
Flue gas temperature at maximum rated output: °C	Flue gas temperature at minimum rated output: °C
Maximum measured flow temperature: °C	Minimum measured flow temperature: °C
System hydraulics:	
<input type="checkbox"/> Low loss header, type:	<input type="checkbox"/> Additional expansion vessel Size/pre-charge pressure: Automatic air vent valve installed? <input type="checkbox"/> Yes <input type="checkbox"/> No
<input type="checkbox"/> Heating circuit pump:	
<input type="checkbox"/> DHW cylinder/type/number/heating surface output:	
<input type="checkbox"/> System hydraulics checked, notes:	

[illegible]

Notes

Notes

Notes



Robert Bosch (Australia) Pty Ltd
Thermotechnology Division
1555 Centre Road
Clayton Victoria 3168

Australia
Phone: 1300 30 70 37
Fax: 1300 30 70 38
www.bosch-climate.com.au

New Zealand
Phone: 0800 54 33 52
Fax: 0800 54 33 55
www.bosch-climate.co.nz