


tirak[®]

XE301P



Date: 06/28/05
Version:1

Service & Maintenance Manual for Electric Powered Hoists

BASIC TROUBLESHOOTING



WARNING



This sheet is to be used by certified Tirak technicians only!

Repair and maintenance of the Tirak hoist should always be accomplished in a safe environment!

The purpose of this sheet is for quick reference only. Most troubleshooting solutions can be found on pgs. 17 & 18 of the Tirak Instruction Manual included with each hoist.

| PROBLEM | POSSIBLE CAUSE |
|---|---|
| High amps and/or heat | Low power |
| | Centrifugal switch (stuck closed) |
| | Start capacitor defective |
| | Stator burned |
| | Brake drag |
| | Water damage |
| | Hoist overloaded |
| Hoist frozen electrically (ie. Won't run in either direction) | Brake rectifier defective |
| | Run capacitor defective |
| | Brake coil defective |
| | Fuse defective |
| Hoist goes up but not down | Blocstop has been activated |
| Up and/or Down button does nothing | E-stop button has been activated |
| | Fuse defective |
| Hoist goes down when up button is pressed | Centrifugal switch (stuck open) defective |
| | Capacitor (start and/or run) defective |
| Hoist will not lift a suspended load | Start capacitor defective |
| | Low power |
| Slightly higher amps than normal | Run capacitor defective |
| Fuse in control circuit blows immediately | Main relay coil short circuit |
| | Fuse defective |
| | Thermal protector is burned |

Table 001

TABLE OF CONTENTS: TIRAK XE301P1

| | <u>Page</u> | | <u>Page</u> |
|---|-------------|--|-------------|
| 1) GENERAL INFORMATION | | | |
| 1-1 UL Listing Card | 4 | 5-12 Modification Comment | 39 |
| 1-2 Model Identification Table | 5 | 5-13 Assembly and Adjusting | 39 |
| 1-3 Test Certificate | 6 | | |
| | | 6) MOTOR | |
| 2) SECONDARY BRAKE ATTACHMENT | | 6-1 Replacement of Motor Winding (Stator) | 40 |
| 2-1 BSO500 - Secondary Brake Mounting Parts List | 7 | 6-2 Centrifugal Switch Replacement | 42 |
| | | 6-3 Motor Parts List (E-3075 & E3076) | 50 |
| | | 7) CONTROL BOX | |
| 3) WIRE ROPE DRIVING SYSTEM | | 7-1 Tools Required | 52 |
| 3-1 Introduction | 8 | 7-2 Control Box Cover Inspection | 52 |
| 3-2 Tools Required | 8 | 7-3 Ground (Cord/Plug) Check | 52 |
| 3-3 Blocstop Removal | 8 | 7-4 Wiring Diagram Location | 53 |
| 3-4 External Inspection | 8 | 7-5 Stator/Winding Check | 53 |
| 3-5 Casing Cover Removal | 9 | 7-6 Fuse Check, F1 | 54 |
| 3-6 Internal Inspection | 10 | 7-7 Thermal Protector | 54 |
| 3-7 Reassembly | 13 | 7-8 Relay Coil Resistance, K1, K2, K3 | 55 |
| 3-8 Casing Cover Installation | 13 | 7-9 Brake Coil Resistance Check | 55 |
| 3-9 Pressure System Replacement | 14 | 7-10 Capacitor Checks | 55 |
| 3-10 Wire Rope Guide Band Replacement | 15 | 7-11 Centrifugal Switch | 57 |
| 3-11 Radial Packing Ring Replacement | 16 | 7-12 Pushbutton Check | 57 |
| 3-12 Driver Disc Bearing Replacement | 16 | 7-13 Control Box Check | 57 |
| 3-13 Wire Rope Drive System Parts List (Drawing # 27610) | 18 | 7-14 Power Check | 58 |
| | | 7-15 Brake Rectifier Check | 58 |
| 4) GEARBOX | | 7-16 Control Box Parts List XE301P Direct Control 110V | 59 |
| 4-1 Gearbox Disassembly | 20 | 7-17 Control Box Parts List XE301P Direct Control 220V | 61 |
| 4-2 Gearbox Reassembly | 20 | | |
| 4-3 Emergency Controlled Descent Brake | 28 | 8) WIRING INFORMATION | |
| 4-4 Disassembly and Check of Emergency Controlled Descent Brake | 28 | 8-1 Wiring Diagram XE301P Direct Control 110V, Plan | 63 |
| 4-5 Reassembly of Emergency Controlled Descent Brake | 28 | 8-2 Wiring Diagram XE301P Pendant Control, 110V Plan | 65 |
| 4-6 Oil Level Gearbox | 29 | 8-3 Wiring Diagram XE301P Direct Control 220V, Plan | 67 |
| 4-7 Gearbox Parts List (E-3205) | 30 | 8-4 Wiring Diagram XE301P Pendant Control, 220V Plan | 69 |
| 5) PRIMARY BRAKE FOR MOTOR | | 8-5 Wiring Connection of Stator XE301P | 71 |
| 5-1 Brake Type | 32 | | |
| 5-2 Tools Required | 32 | 9) WIRE ROPE / ADDITIONAL INFORMATION | |
| 5-3 Brake Inspection | 32 | 9-1 Wire Rope Specification Tirak | 72 |
| 5-4 Brake Removal | 34 | 9-2 Labels and Nameplates | 74 |
| 5-5 Reassembly | 35 | 9-3 Checklist | 75 |
| 5-6 Disc Inspection | 36 | 9-4 Hoist Specification XE301P | 76 |
| 5-7 Brake Air Gap Adjustment | 36 | | |
| 5-8 Release Stirrup Replacement | 37 | | |
| 5-9 Operational Check | 38 | | |
| 5-10 Coil Resistance Inspection | 38 | | |
| 5-11 Primary Brake Parts List | 38 | | |



NOTE:

Throughout the text, parts will be referred to as codes and positions (e.g stirrup bar, Code #47867, Pos. 86). These codes and positions can be found at the end of each chapter in the "Parts Lists" and "Exploded Views".

1) GENERAL INFORMATION

1-1 UL Listing Card



TRACTEL INC
GRIPHOIST DIV
110 SHAWMUT RD
PO BOX 188
CANTON, MA 02021

Northbrook, Illinois (847) 272- 8800
Melville, New York (631) 271-6200
Santa Clara, California (408) 985-2400
Research Triangle Park,
North Carolina (919) 549-1400
Camas, Washington (360) 817-5500

TUFV
Equipment, Scaffolding

April 18, 2002

TRACTEL INC GRIPHOIST DIV
110 SHAWMUT RD PO BOX 188, CANTON MA 02021

SA4785

Electric scaffold hoists, Models ETH-32L, XE301P, maximum load 700 lbs; Models ETH35C, ETH35C3, ETH35X, LE500P, **LE501P**, TE401P, -401PA, XE500P, -501P, -501PA, **maximum load 1000lbs**; Models TE1000P, -1001P, -1001PA, XE501PO, XE700P, -701P, XE720P, XE721P, maximum load 1500lbs; Models TE1020P, -1021P, -1021PA, maximum load 2000 lbs; Model XE1020P, maximum load 2400 lbs; Model XE2050P, maximum load 4400 lbs.

Manually operated scaffold hoists, Model TMS-600, maximum load 1320 lbs; Model TU-17, maximum load 1500 lbs; Model TU-28, maximum load 3000 lbs; Model TU-32, maximum load 6000 lbs; Model 408, maximum load 880 lbs.

Pneumatic scaffold hoists, Models ATH32L, -32LB, XA300P, -300PB, maximum load 700 lbs; Models ATH35C, ATH35X, -35XB, LA500P, XA500P, -500PB, maximum load 1000 lbs; Models XA700P, -700PB, XA720PB, maximum load 1500 lbs; Model XA1030PO, maximum load 1850 lbs; Model TA1020P, maximum load 2000 lbs; Model XA1020P, maximum load 2400 lbs; Model XA2050P, maximum load 4400 lbs; Model XA2650P, maximum load 5300 lbs.

Independent secondary brakes, Model BS15.301, maximum load 1500 lbs; Model BS20.301, maximum load 3000 lbs; Model BS35.30, maximum load 6000 lbs.

Modular work platform, "Modular Staging", 2 to 12 m, rated 750 lbs; Models KD01, MP03, 2 to 18m, rated 750 to 1500 lbs; "PFD", 2 to 15m, load 6000 lbs.

Work Cages, Model PMR0700D, PMR0701D, VSMV-PMR0710D, rated 1000 lbs; Model WC01, rated 400 lbs.

This equipment consists of separate parts inspected at the factory by Underwriters Laboratories Inc. and is intended for use in complete complete installations. Installations are not inspected by Underwriters Laboratories Inc. but should be made in accordance with requirements of authorities having jurisdiction.

LOOK FOR CLASSIFICATION MARK ON PRODUCT

Figure 101



1-2 Model Identification Table

Type Designation of TIRAK Scaffolding Hoist

X SD 5 0 2 P
X E 3 0 1 P 1

Tirak-type

X = 1 driver disc
L = **lightweight**
T = 2 driver discs
G = Gripwinch (for material handling only, US-version)

Capacity lbs. [kg]

3 = 700 [300]
5 = 1000 [500]
7 = 1500 [700]
8 = 1600 [800]
10 = 2200 [1000]
16 = 3500 [1600]
20 = 4400 [2000]
30 = 6600 [3000]

Wire Rope in. [mm]

0 = 5/16 [8]
1 = 1/4 [6]
2 = 3/8 [9]
3 = [10]
4 = [11]
5 = 9/16 [14]
6 = 5/8 [16]

Secondary Brake

1 = BSO500
2 = BS/BSO500

Execution

P = Man riding
PA = 220 V, 1 Ph, 60 Hz, 500 kg for USA/CAN only
PO = with overload
No declaration = material handling

Operation

A = Air operated
D = Dual wire rope Tirak
E = Electric operated Tirak USA/Canada
H = Hydraulic operated
HB = Hydraulic operated with brake
N = Hand crank on motorshift
S = Silo hand crank on gear box

Working Speed f/m [m/min]

| | Kind of Motor | 50Hz | | 60Hz | | for X2000/3000 | | | |
|---------------------------------|---------------|---|-----------|-----------|-------------|----------------|--------|-------|-----------|
| | | | | | | 50Hz | | 60Hz | |
| 0 = | 3 Ph | 30 | [9] | 35 | [11] | 20 | [6] | 23 | [7] |
| or Air motor or Hydraulic motor | | | | | | | | | |
| 2 = | 3 Ph | 60 | [18] | 70 | [22] | 50 | [12] | 45 | [14] |
| 3 = | 3 Ph | 30/60 | [9/18] | 35/70 | [11/22] | 20/40 | [6/12] | 23/45 | [7/14] |
| 4 = | 3 Ph | 15 | [4, 5] | 17 | [5, 5] | 10 | [3] | 12 | [3, 5] |
| 5 = | 3 Ph | 15/30 | [4, 5/9] | 17/35 | [5, 5/11] | 10/20 | [3/6] | 12/23 | [3, 5/7] |
| 6 = | 3 Ph | 15/60 | [4, 5/18] | 17/70 | [5, 5/22] | 10/40 | [3/12] | 12/45 | [3, 5/14] |
| 7 = | 3 Ph | variable speed, 0 to 35/70/100 [0 to 9/18/30] | | | | | | | |
| 1 = 1 Ph | | 15 | [9] | 35 | [11] | - | - | - | - |
| 9 = | G | 39 | [12] | 39 | [12] | - | - | - | - |

Kind of motor

3 Ph = 3 phase motor
1 Ph = single phase motor
G = DC motor

1-3 Test Certificate XE301P

| Prüf-Zertifikat / Test certificate / Certificat d'essai | | Greifzug-Auftrags-Nr. | | Verteiler: Partnerfirma | |
|---|--|---|--|---|--|
| 1.1 Gerät/Machine/Appareil/Typ/Type | | Kunde/Customer/Client | | Baujahr Year of const. | |
| 1.2 Tragfähigkeit (Material) Safe working load (Material) Capacité de charge (Matériau) | | Zul. Belastung (Personen/transport) Admissible load (personnel) Charge admissible (levage de personnes) | | Seil-ID Wire rope ID (D du câble) | |
| Motor / Moteur | | Nenn-/Nominale Nominal voltage Tension nominale | | 50 Hz 60 Hz | |
| 2.1 Typ Type | | Nr. No. | | Steuerung Control Commande | |
| 2.2 Leistung Output Puissance | | Mindest-/Minimum Minimum voltage Tension minimum | | Arbeits-/Working Working speed Vitesse de travail | |
| 3.1 Betriebsbremse / Service brake / Frein de service | | Speisepannung Cable voltage Tension de la bobine | | 3.2 Sonstiges / Other / Autre | |
| Sonderausstattung / Special equipment / Équipement spécial | | 4.1 Mobile Winde mit Mobile winch with Tourel mobile avec | | 4.2 Misseilarten Installed wire rope Câble installé | |
| 4.3 Mit/With/avec BLOCSTOP | | 4.4 Sonstiges Other Autre | | 4.5 | |
| 5.1 Sichtkontrolle / Visual check / Contrôle visuel | | 5.2 Funktionstests / Function control / Contrôle de fonctionnement | | 5.3 Hubkraftbegrenzer / Lifting force limiter | |
| 5.2 Typen-/Modellbezeichnung Name plate marking Marquage plaque d'identité | | 5.3 Motorleistung Motor power Puissance moteur | | 5.4 Überlasttest Overload test Essai de surcharge | |
| 5.4 Betriebsbremse Service brake Frein de service | | 5.5 Hubkraft Lifting force Force de levage | | 5.6 Notablass Emergency descent Descente d'urgence | |
| 5.6 Sonstiges Other Autre | | 5.7 Geräusch Noise Bruit | | 5.8 Sekundärbremse Secondary brake Frein secondaire | |
| Bei Sonderausführungen / For special equipment / Pour équipement spécial | | 7.1 Endschalterkontrolle Limit switch test Contrôle fin de course | | 7.2 Funktion Schwenk-/Sollstrom Function of rope retractor Fonct. remorqueur/cabre de câble | |
| 7.3 Hubkraftbegrenzer / Lifting force limiter | | 7.4 Einbaufestigkeit Installation Régler à | | 7.5 | |
| 7.6 | | 7.7 | | 7.8 | |
| 7.9 | | 7.10 | | 7.11 | |
| 7.12 | | 7.13 | | 7.14 | |
| 7.15 | | 7.16 | | 7.17 | |
| 7.18 | | 7.19 | | 7.20 | |
| 7.21 | | 7.22 | | 7.23 | |
| 7.24 | | 7.25 | | 7.26 | |
| 7.27 | | 7.28 | | 7.29 | |
| 7.30 | | 7.31 | | 7.32 | |
| 7.33 | | 7.34 | | 7.35 | |
| 7.36 | | 7.37 | | 7.38 | |
| 7.39 | | 7.40 | | 7.41 | |
| 7.42 | | 7.43 | | 7.44 | |
| 7.45 | | 7.46 | | 7.47 | |
| 7.48 | | 7.49 | | 7.50 | |
| 7.51 | | 7.52 | | 7.53 | |
| 7.54 | | 7.55 | | 7.56 | |
| 7.57 | | 7.58 | | 7.59 | |
| 7.60 | | 7.61 | | 7.62 | |
| 7.63 | | 7.64 | | 7.65 | |
| 7.66 | | 7.67 | | 7.68 | |
| 7.69 | | 7.70 | | 7.71 | |
| 7.72 | | 7.73 | | 7.74 | |
| 7.75 | | 7.76 | | 7.77 | |
| 7.78 | | 7.79 | | 7.80 | |
| 7.81 | | 7.82 | | 7.83 | |
| 7.84 | | 7.85 | | 7.86 | |
| 7.87 | | 7.88 | | 7.89 | |
| 7.90 | | 7.91 | | 7.92 | |
| 7.93 | | 7.94 | | 7.95 | |
| 7.96 | | 7.97 | | 7.98 | |
| 7.99 | | 7.100 | | 7.101 | |
| 7.102 | | 7.103 | | 7.104 | |
| 7.105 | | 7.106 | | 7.107 | |
| 7.108 | | 7.109 | | 7.110 | |
| 7.111 | | 7.112 | | 7.113 | |
| 7.114 | | 7.115 | | 7.116 | |
| 7.117 | | 7.118 | | 7.119 | |
| 7.120 | | 7.121 | | 7.122 | |
| 7.123 | | 7.124 | | 7.125 | |
| 7.126 | | 7.127 | | 7.128 | |
| 7.129 | | 7.130 | | 7.131 | |
| 7.132 | | 7.133 | | 7.134 | |
| 7.135 | | 7.136 | | 7.137 | |
| 7.138 | | 7.139 | | 7.140 | |
| 7.141 | | 7.142 | | 7.143 | |
| 7.144 | | 7.145 | | 7.146 | |
| 7.147 | | 7.148 | | 7.149 | |
| 7.150 | | 7.151 | | 7.152 | |
| 7.153 | | 7.154 | | 7.155 | |
| 7.156 | | 7.157 | | 7.158 | |
| 7.159 | | 7.160 | | 7.161 | |
| 7.162 | | 7.163 | | 7.164 | |
| 7.165 | | 7.166 | | 7.167 | |
| 7.168 | | 7.169 | | 7.170 | |
| 7.171 | | 7.172 | | 7.173 | |
| 7.174 | | 7.175 | | 7.176 | |
| 7.177 | | 7.178 | | 7.179 | |
| 7.180 | | 7.181 | | 7.182 | |
| 7.183 | | 7.184 | | 7.185 | |
| 7.186 | | 7.187 | | 7.188 | |
| 7.189 | | 7.190 | | 7.191 | |
| 7.192 | | 7.193 | | 7.194 | |
| 7.195 | | 7.196 | | 7.197 | |
| 7.198 | | 7.199 | | 7.200 | |
| 7.201 | | 7.202 | | 7.203 | |
| 7.204 | | 7.205 | | 7.206 | |
| 7.207 | | 7.208 | | 7.209 | |
| 7.210 | | 7.211 | | 7.212 | |
| 7.213 | | 7.214 | | 7.215 | |
| 7.216 | | 7.217 | | 7.218 | |
| 7.219 | | 7.220 | | 7.221 | |
| 7.222 | | 7.223 | | 7.224 | |
| 7.225 | | 7.226 | | 7.227 | |
| 7.228 | | 7.229 | | 7.230 | |
| 7.231 | | 7.232 | | 7.233 | |
| 7.234 | | 7.235 | | 7.236 | |
| 7.237 | | 7.238 | | 7.239 | |
| 7.240 | | 7.241 | | 7.242 | |
| 7.243 | | 7.244 | | 7.245 | |
| 7.246 | | 7.247 | | 7.248 | |
| 7.249 | | 7.250 | | 7.251 | |
| 7.252 | | 7.253 | | 7.254 | |
| 7.255 | | 7.256 | | 7.257 | |
| 7.258 | | 7.259 | | 7.260 | |
| 7.261 | | 7.262 | | 7.263 | |
| 7.264 | | 7.265 | | 7.266 | |
| 7.267 | | 7.268 | | 7.269 | |
| 7.270 | | 7.271 | | 7.272 | |
| 7.273 | | 7.274 | | 7.275 | |
| 7.276 | | 7.277 | | 7.278 | |
| 7.279 | | 7.280 | | 7.281 | |
| 7.282 | | 7.283 | | 7.284 | |
| 7.285 | | 7.286 | | 7.287 | |
| 7.288 | | 7.289 | | 7.290 | |
| 7.291 | | 7.292 | | 7.293 | |
| 7.294 | | 7.295 | | 7.296 | |
| 7.297 | | 7.298 | | 7.299 | |
| 7.300 | | 7.301 | | 7.302 | |
| 7.303 | | 7.304 | | 7.305 | |
| 7.306 | | 7.307 | | 7.308 | |
| 7.309 | | 7.310 | | 7.311 | |
| 7.312 | | 7.313 | | 7.314 | |
| 7.315 | | 7.316 | | 7.317 | |
| 7.318 | | 7.319 | | 7.320 | |
| 7.321 | | 7.322 | | 7.323 | |
| 7.324 | | 7.325 | | 7.326 | |
| 7.327 | | 7.328 | | 7.329 | |
| 7.330 | | 7.331 | | 7.332 | |
| 7.333 | | 7.334 | | 7.335 | |
| 7.336 | | 7.337 | | 7.338 | |
| 7.339 | | 7.340 | | 7.341 | |
| 7.342 | | 7.343 | | 7.344 | |
| 7.345 | | 7.346 | | 7.347 | |
| 7.348 | | 7.349 | | 7.350 | |
| 7.351 | | 7.352 | | 7.353 | |
| 7.354 | | 7.355 | | 7.356 | |
| 7.357 | | 7.358 | | 7.359 | |
| 7.360 | | 7.361 | | 7.362 | |
| 7.363 | | 7.364 | | 7.365 | |
| 7.366 | | 7.367 | | 7.368 | |
| 7.369 | | 7.370 | | 7.371 | |
| 7.372 | | 7.373 | | 7.374 | |
| 7.375 | | 7.376 | | 7.377 | |
| 7.378 | | 7.379 | | 7.380 | |
| 7.381 | | 7.382 | | 7.383 | |
| 7.384 | | 7.385 | | 7.386 | |
| 7.387 | | 7.388 | | 7.389 | |
| 7.390 | | 7.391 | | 7.392 | |
| 7.393 | | 7.394 | | 7.395 | |
| 7.396 | | 7.397 | | 7.398 | |
| 7.399 | | 7.400 | | 7.401 | |
| 7.402 | | 7.403 | | 7.404 | |
| 7.405 | | 7.406 | | 7.407 | |
| 7.408 | | 7.409 | | 7.410 | |
| 7.411 | | 7.412 | | 7.413 | |
| 7.414 | | 7.415 | | 7.416 | |
| 7.417 | | 7.418 | | 7.419 | |
| 7.420 | | 7.421 | | 7.422 | |
| 7.423 | | 7.424 | | 7.425 | |
| 7.426 | | 7.427 | | 7.428 | |
| 7.429 | | 7.430 | | 7.431 | |
| 7.432 | | 7.433 | | 7.434 | |
| 7.435 | | 7.436 | | 7.437 | |
| 7.438 | | 7.439 | | 7.440 | |
| 7.441 | | 7.442 | | 7.443 | |
| 7.444 | | 7.445 | | 7.446 | |
| 7.447 | | 7.448 | | 7.449 | |
| 7.450 | | 7.451 | | 7.452 | |
| 7.453 | | 7.454 | | 7.455 | |
| 7.456 | | 7.457 | | 7.458 | |
| 7.459 | | 7.460 | | 7.461 | |
| 7.462 | | 7.463 | | 7.464 | |
| 7.465 | | 7.466 | | 7.467 | |
| 7.468 | | 7.469 | | 7.470 | |
| 7.471 | | 7.472 | | 7.473 | |
| 7.474 | | 7.475 | | 7.476 | |
| 7.477 | | 7.478 | | 7.479 | |
| 7.480 | | 7.481 | | 7.482 | |
| 7.483 | | 7.484 | | 7.485 | |
| 7.486 | | 7.487 | | 7.488 | |
| 7.489 | | 7.490 | | 7.491 | |
| 7.492 | | 7.493 | | 7.494 | |
| 7.495 | | 7.496 | | 7.497 | |
| 7.498 | | 7.499 | | 7.500 | |
| 7.501 | | 7.502 | | 7.503 | |
| 7.504 | | 7.505 | | 7.506 | |
| 7.507 | | 7.508 | | 7.509 | |
| 7.510 | | 7.511 | | 7.512 | |
| 7.513 | | 7.514 | | 7.515 | |
| 7.516 | | 7.517 | | 7.518 | |
| 7.519 | | 7.520 | | 7.521 | |
| 7.522 | | 7.523 | | 7.524 | |
| 7.525 | | 7.526 | | 7.527 | |
| 7.528 | | 7.529 | | 7.530 | |
| 7.531 | | 7.532 | | 7.533 | |
| 7.534 | | 7.535 | | 7.536 | |
| 7.537 | | 7.538 | | 7.539 | |
| 7.540 | | 7.541 | | 7.542 | |
| 7.543 | | 7.544 | | 7.545 | |
| 7.546 | | 7.547 | | 7.548 | |
| 7.549 | | 7.550 | | 7.551 | |
| 7.552 | | 7.553 | | 7.554 | |
| 7.555 | | 7.556 | | 7.557 | |
| 7.558 | | 7.559 | | 7.560 | |
| 7.561 | | 7.562 | | 7.563 | |
| 7.564 | | 7.565 | | 7.566 | |
| 7.567 | | 7.568 | | 7.569 | |
| 7.570 | | 7.571 | | 7.572 | |
| 7.573 | | 7.574 | | 7.575 | |
| 7.576 | | 7.577 | | 7.578 | |
| 7.579 | | 7.580 | | 7.581 | |
| 7.582 | | 7.583 | | 7.584 | |
| 7.585 | | 7.586 | | 7.587 | |
| 7.588 | | 7.589 | | 7.590 | |
| 7.591 | | 7.592 | | 7.593 | |
| 7.594 | | 7.595 | | 7.596 | |
| 7.597 | | 7.598 | | 7.599 | |
| 7.600 | | 7.601 | | 7.602 | |
| 7.603 | | 7.604 | | 7.605 | |
| 7.606 | | 7.607 | | 7.608 | |
| 7.609 | | 7.610 | | 7.611 | |
| 7.612 | | 7.613 | | 7.614 | |
| 7.615 | | 7.616 | | 7.617 | |
| 7.618 | | 7.619 | | 7.620 | |
| 7.621 | | 7.622 | | 7.623 | |
| 7.624 | | 7.625 | | 7.626 | |
| 7.627 | | 7.628 | | 7.629 | |
| 7.630 | | 7.631 | | 7.632 | |
| 7.633 | | 7.634 | | 7.635 | |
| 7.636 | | 7.637 | | 7.638 | |
| 7.639 | | 7.640 | | 7.641 | |
| 7.642 | | 7.643 | | 7.644 | |
| 7.645 | | 7.646 | | 7.647 | |
| 7.648 | | 7.649 | | 7.650 | |
| 7.651 | | 7.652 | | 7.653 | |
| 7.654 | | 7.655 | | 7.656 | |
| 7.657 | | 7.658 | | 7.659 | |
| 7.660 | | 7.661 | | 7.662 | |
| 7.663 | | 7.664 | | 7.665 | |
| 7.666 | | 7.667 | | 7.668 | |
| 7.669 | | 7.670 | | 7.671 | |
| 7.672 | | 7.673 | | 7.674 | |
| 7.675 | | 7.676 | | 7.677 | |
| 7.678 | | 7.679 | | 7.680 | |
| 7.681 | | 7.682 | | 7.683 | |
| 7.684 | | 7.685 | | 7.686 | |
| 7.687 | | 7.688 | | 7.689 | |
| 7.690 | | 7.691 | | 7.692 | |
| 7.693 | | 7.694 | | 7 | |

2) SECONDARY BRAKE ATTACHMENT XE301P

2-1 BSO500 Secondary Brake Mounting Parts List

| # | Code | Qty | Description | Dimensions / Comments |
|---|-------|-----|------------------|-------------------------------------|
| 1 | 45735 | 1 | Blocstop Pin | 12 x 68 mm |
| 2 | 9816 | 4 | Blocstop Washer | Ø 12 / Ø 19 x 1 mm (Qty. as needed) |
| 3 | 46847 | 1 | Mounting Strap A | 163.5 mm w/lug (no bend) |
| 4 | 67015 | 1 | Mounting Strap B | 163.5 mm |
| 5 | 61645 | 1 | Casing Pin | 10 x 66 mm |
| 6 | 20676 | 2 | Casing Washer | Ø 10 / Ø 16 x 1 mm (Qty. as needed) |
| 7 | 46496 | 4 | Cotter Pin | 4 x 25 mm |

Table 201




Figure 201

3) WIRE ROPE DRIVING SYSTEM XE301P

3-1 Introduction



NOTE

Regular Inspection services will decrease downtime.

Although the drive system of the Tirak hoist is one of the most simple and reliable system in the market, it still requires service from an authorized repair station for safe and efficient operation. It is recommended the following service procedures are performed every six (6) months but they may need to be repeated more often depending on the work environment the hoist is subjected to.



NOTE

Parts and codes referred to in this section are found on the spare parts list at the end of the chapter (E-27610, Section 3-13).

3-2 Tools Required (Figure 301)

- Hammer
- Screwdriver (2, flat)
- 10mm Box wrench
- Rubber mallet
- Diagonal cutting pliers
- 5 mm Allen key
- Pry Bars



Figure 301

3-3 Blocstop Removal

Using diagonal cutting pliers, detach the Blocstop BSO500 strap from the hoist by removing the cotter pin shown in Figure 302.



Figure 302

3-4 External Inspection

- 1) Inspect outer casing {Code #63695, Pos. 2} for damage. Pay extra attention to the area indicated shown in Figure 303. Look for deformation or marks that may indicate further damage inside.



Figure 303

- 2) Inspect the stirrup adapter and the surrounding area as shown in Figure 304 for wear, cracks or damage. If the stirrup bar {Code #47867, Pos. 86} is bent, it indicates improper rigging. Replace if necessary.



Figure 304

3-5 Casing Cover Removal

- 1) Remove the four (5) cap screw assemblies in the corners (Figure 305) consisting of the following:
 - a. M6x50 socket head cap screws {Code #12016, Pos. 31}
 - b. Lock-washers {Code #16616, Pos. 32}
 - c. Flat washers {Code #36306, Pos. 71}
 - d. Square nuts {Code #39356, Pos. 33}
 - e. M6x16 socket head cap screw {Code #5336, Pos. 52}



Figure 305

- 2) Insert a screwdriver in the casing above the stirrup adapter as shown in Figure 306. Carefully pry the casing open.



Figure 306

- 3) When the cover opens enough, insert a second screwdriver. Begin to lift evenly at the corners of the cover as shown in Figure 307.



Figure 302

- 4) Inspect inside of cover {Code #63695, Pos. 2} for damage or evidence of wire rope jams (Figure 308) and cracking near the stirrup bar pocket (Figure 309).




Figure 308





Figure 309

All surfaces should be smooth to prevent cutting or snagging of the wire rope. Replace the cover if it is cracked or distorted.

3-6 Internal Inspection



- 1) Remove and inspect the stirrup adapter {Code #47867, Pos. 86} in Figure 310. Ensure it is straight and the anchor pin is secure.



- 2) Remove and inspect the exit tube {Code #63725, Pos. 41} shown in Figure 311. Ensure it's free of debris inside. Replace as needed.



- 3) Remove the two socket head cap screws {Code #8926, Pos. 53} and two locking washers {Code #16616, Pos. 32} in Figure 312 & 313.



- 4) Inspect the upper wire rope guiding plate {Code #63715, Pos. 46} and compare it to Figures 314 and 315.



Figure 315 shows how the guiding plate should look like. Figure 314 shows a bent or damaged wire rope guiding plate which must be replaced.



NOTE

IF the plate shows damage, this indicates a wire rope jam has occurred and the pressure system must be carefully inspected.

- 5) Remove the entrance tube {Code #40365, Pos. 49} and snap ring {Code #6846, Pos.57} as shown in Figure 320. Inspect the entrance tube and snap ring for damage. Ensure the entrance tube is free of debris. Clean or replace as necessary.




Figure 320

- 6) Inspect the wire rope guiding device {Code #63705, Pos. 47} in Figure 321. Replace as necessary.



Figure 321

- 7) Inspect the lower wire rope guiding plate {Code #40405, Pos. 48, Figure 322} for wear or damage. Replace as necessary.



Figure 322

- 8) Inspect the wire rope guiding band {Code #24187, Pos. 9} (Figure 323) for wear or damage. Replace as necessary (See Section 3-10).



Figure 323

- 9) Remove screw bushing located under wire rope guiding device assembly (Figure 324).



Figure 324

- 10) Inspect the two roller pressure system {Code #23257 Pos. 80} shown in Figure 316. This inspection must be carried out every time the casing cover is removed.

Perform the following check to determine if damage has occurred to the system:

- a) remove pressure system pin (Figure 325).



Figure 325

- b) check taper on pressure system pin (Figure 326).




Figure 326

- c) remove the two pressure system screws {Code #7146 Pos. 77} (Figure 327).



Figure 327

- d) Be careful not to lose the two spring washers {Code#16616 Pos. 32} and nyloc nuts {Code #7996 Pos.81}. (Figure 328).




Figure 328

- e) Inspect the pressure system {Code #23257 Pos. 80} with a straight edge to make sure there are no deformations. (Figure 329).



Figure 329

- f) Inspect the pressure system's pin to ensure the rollers are held in place. (Figure 330).



Figure 330

- g) Inspect the rollers to ensure they roll freely and are not damaged. (Figure 331).



Figure 331

- 11) Inspect the carrying handle for damage and {Code #40335 Pos. 34} shown in Figure 332.



Figure 332



NOTE

The regular service inspection is now complete. Clean all components with mineral spirits and dry thoroughly.

3-7 Reassembly

- 1) Re-grease the pressure system {Code #23257, Pos. 80} with wheel bearing or white lithium grease.



WARNING



DO NOT use molybdenum disulphide (moly-b) grease or graphite type grease!

- 2) Reinstall the lower guide plate {Code #40405, Pos. 48, Figure 322}, wire rope guiding device {Code #63705, Pos. 47, Figure 321} and upper guide plate {Code #63715, Pos. 46, Figure 312}.
- 3) Reinstall the wire rope entrance tube {Code #40365, Pos. 49} and snap ring {Code #6846, Pos.57} in Figure 320. Place the snap ring onto the entrance tube rotate it so the tabs are up. This extra bit of clearance eases installation of the casing cover.
- 4) Reinstall the exit tube {Code #63725, Pos. 41, Figure 311}. Ensure the tube is not blocked.
- 5) Reinstall the stirrup anchor bar {Code #47867, Pos. 86, Figure 310}.

3-8 Casing Cover Installation

- 1) Using a hammer and dowel punch, gently tap the roll pins (clamping sleeves) flush into the casing cover (#63695, Pos. 2, Figure 333).



Figure 333

- 2) Carefully place the casing cover over the pressure system dowel pin. Ensure it sits directly over the pin!!! (Figure 334).



- 3) Place one hand on the casing cover. Using a dead blow RUBBER mallet, tap the cover onto the base as shown in Figure 335.



NOTE

Keep pressure on the cover to prevent damage to the cover.



- 4) Using a hammer and dowel pin, realign the roll pins flush with the base.
- 5) Reinstall the M6 casing cover screws, washers and square nuts (See Figure 305).
- 6) Reinstall the Blocstop straps and Blocstop.



CAUTION



Ensure that the cotter pins are bent completely over to prevent any sharp edges.

- 7) Load test the hoist and check the Blocstop functions properly.



NOTE

General service of the wire rope drive system is now complete. If during the general service damage was discovered proceed as follows.



WARNING



It is prohibited to attempt repair of the pressure system.

3-9 Pressure System Replacement {Code #23257, Pos. 80}

If damage has occurred to the pressure system by a rope jam (see Section 3-6, Step 4), the pressure system must be replaced.

- 1) Carefully remove the pressure system dowel pin by lifting it straight out its position. Be sure not to damage the pin. If damage does occur, gently remove any burrs with emery cloth.
- 2) Lift the pressure system from the casing base. Replace the unit.
- 3) After removal of the old system replace it with a new unit {Code #23257, Pos. 80}.
- 5) Install the pressure system dowel pin into the casing base first.
- 6) Grease the pressure system with wheel bearing grease or white lithium grease.



WARNING



DO NOT use molybdenum disulphide (moly-b) grease or graphite type grease!

3-10 Wire Rope Guide Band Replacement {Code #24187, Pos. 9}

Though replacement is rare, it may be necessary if damaged beyond repair. This procedure requires that the drive sheave is removed.

- 1) Remove the oil drain plug as shown in Figure 336. Ensure that gearbox is lying with the oil plug to the high side to prevent excessive oil loss. This will allow air pressure to neutralize in the gearbox.
- 2) Reinstall the oil plug. Do not apply too much torque.




NOTE

You will be removing the oil plug again.



- 3) Turn the gearbox over so the driver disc {Code #22357, Pos. 4} is face up. Use a block of wood to level the gearbox. Remove the wire rope guiding device (see Section 3-6, step 6).
- 4) Carefully with two pry bars remove the driver disc as shown in Figure 337.



- 5) Remove the damaged wear band. Inspect and repair the casing base retaining lip as needed. Place a light coat of grease on the back of the new wear band.
- 6) Install the new wear band. Make sure the band sits firmly into the casing base recess as shown in Figure 338.



- 7) Using vise grips, twist the band into the recess (Figure 339).



- 8) Reinstall the driver disc to the gearbox. There will be resistance due to the air trapped below the disc.
- 9) While holding the sheave in place, turn the hoist over so that the oil plug is to the high side again. Remove the oil plug same as before.

- 10) Press or use a rubber mallet to push the sheave into place. The air will expel from the oil plug. The sheave should move into position as air escapes (Figure 340).



NOTE

DO NOT stand in front of the oil plug hole as oil may spray.

- 11) Reinstall the oil plug and tighten.



Figure 340

3-11 Radial Packing Ring Replacement {Code #39516, Pos. 10}

Replacement is only necessary if oil is leaking and the original packing ring is damaged (cut or bent).

- 1) Remove the oil plug, pressure system, wire rope guiding device and driver disc as above.
- 2) Clean the area carefully.
- 3) With two pry bars gently remove the old packing ring. Do not damage the base.
- 4) Lightly grease the new packing ring and place it in its position.
- 5) Using a brass punch or wooden dowel, tap the packing ring into its position. Tap alternately at the 12-6-9-3 o'clock positions as shown in Figure 341.



Figure 341

- 6) Reinstall the driver disc and remove excess air as in Section 3-10.

3-12 Driver Disc Bearing Replacement {Code #23836, Pos. 35}

Though this is rarely required proceed as follows.

- 1) Follow the procedure as above. Do not remove the radial packing ring.
- 2) Carefully remove the driver disc with two pry bars.
- 3) Inspect both top and bottom bearing for wear or damage (Figure 342).




Figure 342

- 4) If replacement is necessary, using the correct gear puller remove the bad bearing as shown in Figure 343.



- 5) Reinstall the new bearing and gently seat using a press.
- 6) Reinstall the driver disc. (Follow the procedure as outlined in Section 3-10)
- 7) Reinstall all drive components as in an outlined in Section 3-7.
- 8) Reinstall the casing cover per Section 3-8.

| | | | | |
|--------------------|--|--|------------|-------|
| Spare Parts | XE301P - 110V Wire rope drive | | Drawing No | 27610 |
| | | | Edition | US-1 |
| | | | Date | 1/05 |
| | | | Page | 1 / 2 |

| Position | Part # | Qty. | Description | Specifications | List Price |
|----------|--------|------|--|-------------------|------------|
| -- | 22048 | 1 | Wire rope drive complete X300 | 700#, 8mm | \$2,618.47 |
| 2 | 63695 | 1 | CASING COVER X300 | | \$204.39 |
| 4 | 22357 | 1 | DRIVER DISC FOR WIRE ROPE DIA.8 MM | 8mm | \$546.10 |
| 9 | 24187 | 1 | WIRE ROPE GUIDING BAND,COMPLETE F. 8 MM | | \$25.44 |
| 10 | 39516 | 1 | RADIAL PACKING RING 160/180/10 | 160x180x10 | \$32.76 |
| 16 | 40996 | 1 | BALL BEARING 6201 | 12x32x10 | \$7.27 |
| 23 | 39306 | 1 | SHAFT SEAL 25/52/7 | 25x52x7 | \$9.47 |
| 24 | 39316 | 1 | KEY A 5X5X45 DIN 6885 | 5x5x45 | \$0.39 |
| 27 | 41996 | 1 | O-RING FOR MOTOR SIZE 80 120 X 2,5 | 120x2.5 | \$4.77 |
| 28 | 39346 | 1 | CENTRIFUGAL BRAKE 1500 U/MIN | 1900 rpm | \$137.16 |
| 31 | 12016 | 4 | SOCKET HEAD CAP SCREW M 6X50 DIN 912 | M6x50 | \$0.39 |
| 32 | 16616 | 9 | SPRING WASHER A6 DIN 127 | A6 | \$0.13 |
| 33 | 39356 | 4 | SQUARE NUT M6 DIN 557 | M6 | \$0.26 |
| 34 | 40335 | 1 | CARRYING HANDLE | | \$23.14 |
| 35 | 23836 | 1 | Ball bearing 6201-2RS1 | 12x32x10 | \$9.82 |
| 36 | 39366 | 5 | ROLL PIN 8 X 30 DIN 7346 | 8x30 | \$0.61 |
| 39 | 39376 | 1 | CUP SEAL | 32x9.5 | \$9.47 |
| 41 | 63725 | 1 | Wire rope exit tube X300 | X300 S/N > 5336 | \$0.00 |
| 42 | 16286 | 1 | ROLL PIN 8 X 12 DIN 7346 | 8x12 | \$0.39 |
| 46 | 63715 | 1 | UPPER WIRE ROPE GUIDING PLATE | X300 S/N > 5336 | \$10.97 |
| 47 | 63705 | 1 | WIRE ROPE GUIDING DEVICE F. 8 MM | X300 S/N > 5336 | \$58.64 |
| 48 | 40405 | 1 | LOWER WIRE ROPE GUIDING PLATE | | \$6.66 |
| 49 | 40365 | 1 | WIRE ROPE ENTRY TUBE | | \$10.82 |
| 51 | 4186 | 2 | Socket head cap screw | M6x16 | \$0.00 |
| 52 | 5336 | 1 | Socket head cap screw | M6x30 | \$0.00 |
| 53 | 8926 | 2 | SOCKET HEAD CAP SCREW M 6 X 40 DIN 912 | M6x40 | \$0.26 |
| 57 | 6846 | 1 | Retaining washer | | \$0.00 |
| 68 | 37646 | 1 | Oil plug screw for petroleum gearboxes | M16x1.5 | \$3.76 |
| 69 | 4176 | 1 | Socket head cap screw | M6x20 | \$0.00 |
| 70 | 37656 | 1 | Copper gasket for gearbox oil plug | 16x22x1.5 - Cu | \$0.39 |
| 71 | 36306 | 4+1 | WASHER A 6,5X14X1,6 DIN 6902 | A6.5 | \$0.56 |
| 72 | 41006 | 1 | SOCKET HEAD CAP SCREW M6X10 DIN 7984 | | \$0.46 |
| 77 | 7146 | 2 | SOCKET HEAD CAP SCREW M 6 X 25 DIN 912 | M6x25 | \$0.26 |
| 79 | 16236 | 4 | RIVET 2 X 6 DIN 1476 | 2x6 | \$0.13 |
| 80 | 23257 | 1 | PRESSURE SYSTEM COMPLETE | | \$334.61 |
| 81 | 7996 | 1 | Nyloc nut | M6 | \$0.15 |
| 83 | | | included with pos. 86 (one piece design) | | |
| 85 | 22760 | 1 | Tirak nameplate | Metal | \$9.47 |
| 86 | 47867 | 1 | Tirak stirrup adapter | | \$86.98 |
| 87 | 42487 | 1 | Brake coil assembly | FDB 13 / 96V | \$0.00 |
| 87.1 | 66145 | 2 | BS/BSO Pin | 10x72 | \$10.82 |
| 87.2 | 61645 | 1 | Tirak pin | 10x66 | \$12.42 |
| 87.3 | 45735 | 1 | Blocstop pin | 12x68 | \$7.12 |
| 87.4 | 9816 | 6 | WASHER 13 X 19 X 1 DIN 988 | 13x19x1 | \$2.01 |
| 87.5 | 46496 | 4 | COTTER PIN 4 X 25 DIN 94 | 4x25 | \$0.26 |
| 100 | 41747 | 1 | Casing base without gears X300 | for motor size 80 | \$586.07 |
| 100.1 | 42707 | 1 | Casing base with gears X300 | for motor size 80 | \$1,917.80 |
| 102 | 14347 | 1 | Control descent pin with lanyard | | \$18.93 |

4) GEARBOX

4-1 Required Tools (Figure 401)

- 17 mm wrench or adjustable wrench
- Allen keys 8 mm, 5 mm
- internal and external snap ring pliers
- 2 pry bars
- 2 screwdrivers
- 1 gear puller
- 1 plastic or rubber mallet
- Brass punch
- Rags or towels

Figure 401



4-2 Gearbox Disassembly

The following procedure is for complete disassembly of the gearbox. We recommend that the procedure be carried out by a Tirak repair facility. If repair is essential at the site proceed as follows:

- 1) Remove the 4 {Code #26097, Pos. 12, refer to E-3075, Section 3-13} M5x10 mm screws as shown in Figure 402. Remove the motor per Section 6-1.



Figure 402

- 2) Remove the casing cover and internal drive parts as shown in Figures 403, 404, 405, 406, 407, 408 and 409.



Figure 403

- 2a) Remove all the casing cover screws {Code #12016 Pos. 31, & Code #5336 Pos. 52 refer to 27610, Section 3-13} and pry off the casing cover {Code #63695, Pos. 2, refer to 27610, Section 3-13} as shown in Figure 404.



Figure 404

- 2b) Remove the exit tube {Code #63725, Pos. 41, refer to 27610, Section 3-13} as shown in Figure 405.



Figure 405

2c) Remove the pressure spring {Code #23257, Pos. 80, refer to 27610, Section 3-13} as shown in Figure 406.



Figure 406

2d) Remove the inlet tube {Code #40365, Pos. 49, refer to 27610, Section 3-13} as shown in Figure 407.



Figure 407

2e) Remove the guiding device {Code #63705, Pos. 47, refer to 27610, Section 3-13} held in place by 2 screws {Code #8926, Pos. 53, refer to 27610, Section 3-13} as shown in Figure 408.



Figure 408

2f) Pry off the driver disc {Code #22357, Pos. 4, refer to 27610, Section 3-13} using 2 large screwdrivers as shown in Figure 409.



Figure 409

2g) Remove the following items from the gearbox casing (Figure 410):

- Plastic plug {Code #67746, refer to 27610, Section 3-13}
- Wearband pins




Figure 410

2h) Remove the (4) roll pins {Code #39366, Pos. 36, refer to 27610, Section 3-13} should they have remained inside the base as shown in Figure 411.



Figure 411

- 3) Using a 10 mm hex, remove the oil plug {Code #37646, Pos. 68} and drain the synthetic gear oil into a clean bucket. Inspect the oil for brass flakes or metal filings (Figure 412).



Figure 412

- 4) Inspect the plug and copper gasket {Code #37656, Pos. 70} for wear or damage as shown in Figure 413. Replace if necessary.




Figure 413

- 5) Remove the (4) M6x20 socket head screws {Code #4176, Pos. 69} as shown in Figure 414.



Figure 414

- 6) Rotate the gearbox cover {Code #40505, Pos. 3} slightly with a brass hammer (or soft hammer) and tap upwards as shown in Figure 415.



Figure 415

- 7) Carefully pry off the gearbox cover {Code #40505, Pos. 3} as shown in Figure 416. Avoid damaging the casing base.



Figure 416

- 8) Inspect the cover {Code #40505, Pos. 3} for damage (Figure 417). Replace the 'O'-ring {Code #39286, Pos. 12}.



Figure 417


- 9) Remove the snap ring {Code #536, Pos 13} that sits on the input shaft (Figure 418).



- 10) Remove the seal {Code #39306, Pos. 23, Figure 419}. The seal is destroyed during removal and must be replaced after reassembly of the gearbox.



- 11) Remove the large internal snap ring {Code #16576, Pos. 22} as shown in Figure 420.



- 12) Remove any and all spacers {Code #25136, Pos. 21} as shown in Figure 421.



NOTE:

There may be more than one spacer below the internal snap ring.

- 13) Carefully turn the gearbox over and remove the cup seal {Code #39376, Pos. 39} at the bottom of the hoist as shown in Figure 422. Dispose of the old seal.



- 14) Remove the internal snap ring {Code #37796, Pos. 38} under the cup seal (Figure 423).



- 15) Using a rubber dead blow mallet, hit the shaft pinion {Code #22367, Pos. 5} as shown in Figure 424. After several careful hits, the pinion gear assembly should come out through the front of the gearbox.



Figure 424

- 16) Inspect the pinion and bearing for any wear, damage, or discoloration (Figure 425).



Figure 425

- 17) If a press is available, carefully press the complete worm gear assembly from the top of the gearbox out of the bottom of the gearbox (Figure 426).




Figure 426

- 17a) If no press is available, carefully tap the worm gear assembly with a hammer or brass punch from the top of the base out the bottom of the base as shown in Figure 427.



Figure 427

- 18) Once the worm gear exits the base, the lower bearing {Code #40996, Pos. 16} must be removed (Figure 428).



Figure 428

- 19) Install the gear puller as shown in Figure 429 and remove the bearing.



Figure 429

- 20) Remove the steel worm {Code #22397, Pos. 7} through the large gearbox opening as shown in Figure 430.




Figure 430



NOTE:

The bearing **MUST** be replaced in the same orientation. Failure to do so will cause the hoist to malfunction.

- 21) Inspect the worm gear for wear, damage, or discoloration (Figure 431). Replace if necessary.



Figure 431

4-2) Gearbox Reassembly

- 1) Install the top bearing {Code #37356, Pos. 20} on the steel worm gear and insert the assembly into the casing. With a brass hammer and punch, press the bearing into the gearbox as shown in Figure 432.




Figure 432

- 2) Install the bearing {Code #40996, Pos. 16} on the opposite end of the worm shaft as shown in Figure 433.



Figure 433

- 3) Install the lower snap ring {Code #37796, Pos. 38} as shown in Figure 434 on the next page. Make sure that the snap ring is fitted into the groove.



Figure 434

- 4) Install the lower cup seal {Code #39376, Pos. 39} as shown in Figure 435.



Figure 435

- 5) Insert the large brass gear {Code #22387, Pos. 6} into the gear case as shown in Figure 436.



Figure 436

- 6) With a press or punch, seat the large brass gear {Code #22387, Pos. 6} into the gearbox as shown in Figure 437. Be careful not to damage worm wheel.



Figure 437

- 7) Install the spacer(s) {Code #25136, Pos. 21} and snap ring {Code #16576, Pos. 22} above the bearing as shown in Figures 438-440. Make sure that the snap ring is fitted into the groove.



Figure 438



Figure 439



Figure 440

- 8) Take the tool for inserting the top seal {Code #39306, Pos. 23} and place the seal on the tool as shown in Figure 441.



Figure 441

- 8a) Hammer the seal {Code #39306, Pos. 23} into place as shown in Figure 442.



Figure 442

- 9) Inspect the O-ring {Code #39286, Pos. 12} and put the cover {Code #40505, Pos. 3} on the gearbox opening as shown in Figure 443 and 444.



Figure 443



Figure 444

- 10) Tighten the 4 screws {Code #4186, Pos. 69} and lockwashers {Code #16616, Pos. 72} as shown in Figure 445.



Figure 445

- 11) Refill the gearbox with 1.4 liters of mineral oil per specification.



Figure 446

- 12) Replace all wire rope drive and motor components. Load test the hoist.



WARNING



Once this procedure has been performed and the complete Tirak reassembled, the Tirak must be load tested to 125% of it's rated capacity (875 lbs.).

4-3 Emergency Controlled Descent Brake XE301P

The controlled descent brake is found between the motor and gearbox. It is sealed and therefore should be clean and not worn. It only functions during intentional use for emergency descent.

4-4 Dissassembly an Checks of Emergency Controlled Descent Brake XE301P

- 1) Remove the motor from the gearbox by unscrewing the 4 M5x153 threaded bolts {Code #26097, Pos. 12}.
- 2) Remove the centrifugal brake assembly {Code #39346, Pos. 28}. If it is stuck, you can thread in 2 M6 screws and use them to pull out the brake (See Figure 447).



Figure 447

- 3) Inspect the brake pocket. The ring should show no wear. There should be no oil, dust, or debris inside. Clean if necessary with brake cleaner (See Figure 448).



Figure 448

- 4) Remove the O-ring seal {Code #41996, Pos. 27}. Inspect it for damage and replace if flattened or damaged (Figure 449).



Figure 449

- 5) Examine the brake assembly. The shoes should not be worn and the springs should be correctly in place (See Figure 450). The lining should be secure.



Figure 450

- 6) Check that the speed marked on the brake in RPM corresponds to the motor nameplate UPM. 1900 is normal.

4-5 Reassembly of Emergency Controlled Descent Brake XE301P

- 1) Make sure the snap ring is on the shaft. Insert the key {Code #40986, Pos. 11}. Grease the shaft lightly for ease of brake removal for future inspections (See Figure 448).
- 2) Insert the brake assembly with the threaded holes upward (See Figure 451). Replace the o-ring.



Figure 451

- 3) Refit the motor to the gearbox.



USE MINERAL OIL ONLY!

Hoist-Position for Oil Level Inspection




Figure 452

Temperature Range: 14 to 122 °F
 -10 to +50 °C




API Specification: SAE85W-140 GL5

Sample Oils: BP Hypogear EP 90
 SHELL Spirax HD 90
 TEXACO Multigear EP6 S80 W90

| | | | | |
|--------------------|--|--|------------|--------|
| Spare Parts | XE301P - 110V Gearbox | | Drawing No | E-3205 |
| | | | Edition | US-1 |
| | | | Date | 1/05 |
| | | | Page | 2 / 2 |

| Position | Part # | Qty. | Description | Specifications | List Price |
|--------------------|--------|------|--|-------------------|------------|
| -- | 42707 | 1 | Casing base with gears X300 | for motor size 80 | \$1,917.80 |
| 1 | 41747 | 1 | Casing base without gears X300 | for motor size 80 | \$586.07 |
| 3 | 40505 | 1 | GEARBOX COVER X300/L500 | | \$63.00 |
| 5 | 22367 | 1 | Shaft pinion | | \$0.00 |
| 6 | 22387 | 1 | WORM WHEEL | | \$167.00 |
| 7 | 22397 | 1 | Worm shaft | | \$0.00 |
| 8 | 40305 | 1 | Distance tube for gearbox | 21x30x66 | \$0.00 |
| 9 | 24187 | 1 | WIRE ROPE GUIDING BAND, COMPLETE F. 8 MM | | \$25.44 |
| 10 | 39516 | 1 | RADIAL PACKING RING 160/180/10 | 160x180x10 | \$32.76 |
| 11 | 40986 | 1 | KEY | 6x6x22 | \$0.35 |
| 12 | 39286 | 1 | O-ring | 88x3 | \$0.00 |
| 13 | 536 | 1 | Snap ring | 20x1.2 | \$0.00 |
| 14 | 25406 | 1 | Ball bearing 16004 | 20x42x8 | \$15.88 |
| 15 | 42016 | 1 | Ball bearing 6304 | 20x52x15 | \$13.87 |
| 16 | 40996 | 1 | BALL BEARING 6201 | 12x32x10 | \$7.27 |
| 18 | 9996 | 1 | Snap ring | 25x1.2 | \$0.39 |
| 19 | 39296 | 1 | Adjusting washer | 25x35x1 | \$0.00 |
| 20 | 37356 | 1 | Ball bearing 6205 | 25x52x15 | \$0.00 |
| 21 | 25136 | 1 | Adjusting washer | 42x52x1 | \$0.00 |
| 22 | 16576 | 1 | SNAP RING 52X2 DIN472 | 52x2 | \$1.38 |
| 23 | 39306 | 1 | SHAFT SEAL 25/52/7 | 25x52x7 | \$9.47 |
| 30 ¹⁾ | 41066 | 2 | ADJUSTING WASHER 20X28X0.5 DIN 988 | 20x28x0.5 | \$0.11 |
| 30.1 ¹⁾ | 41046 | 1 | Adjusting washer | 20x28x0.1 | \$0.00 |
| 30.2 ¹⁾ | 41056 | 2 | ADJUSTING WASHER 20X28X0.2 DIN 988 | 20x28x0.2 | \$0.11 |
| 37 | 576 | 1 | SNAP RING | 12x1 | \$0.11 |
| 38 | 37796 | 1 | SNAP RING J 32X1.2 DIN 472 | 32x1.2 | \$0.18 |
| 39 | 39376 | 1 | CUP SEAL | 32x9.5 | \$9.47 |
| 45 | 21940 | 1.4 | Petroleum gearbox oil (per liter) | 80/90W | \$0.00 |
| 51 | 4176 | 2 | Socket head cap screw | M6x20 | \$0.00 |
| 68 | 37646 | 1 | Oil plug screw for petroleum gearboxes | M16x1.5 | \$3.76 |
| 69 | 4186 | 4 | Socket head cap screw | M6x16 | \$0.00 |
| 70 | 37656 | 1 | Copper gasket for gearbox oil plug | 16x22x1.5 - Cu | \$0.39 |
| 72 | 16616 | 4 | SPRING WASHER A6 DIN 127 | A6 | \$0.13 |

1) To compensate for eventual clearance between distance tube (8) and/or worm wheel (6) and ball bearing (14)



5) PRIMARY BRAKE FOR MOTOR



WARNING



Upon completion of any brake maintenance, it is mandatory that a load test of the hoist be completed!

5.1 Brake Type

All Tirak XE301P hoists are fitted with the adjustable Precima type brake. This section covers the service and repair of this brake only. The XE301P has a 96V or 190V DC brake. Prior to maintenance, verify the brake voltage. This voltage is stamped on the brake nameplate, located on the wiring diagram (Figure 501), on the fan cover (Figure 502), and is stamped on the top of Precima brakes (Figure 503).




Figure 501



Figure 502




Figure 503

5.2 Tools Required (Figure 504)

- 5 mm Allen key
- Snap-ring pliers
- 10 mm crescent wrench
- 8 mm crescent wrench
- 2 Flat screwdrivers
- Silicone (RTV) sealant
- Tape
- Calipers (micrometer)
- Feeler gauges



Figure 504

5.3 Brake Inspection

- 1) Unscrew the 4 screw {Code #16086, Pos 31} and washer assemblies using an 8mm crescent wrench. Remove the fan cover {Code #26607, Pos. 8} as shown in Figure 505 on the next page. If crushed, replace and ensure that the fan spins unobstructed (Figure 506 on the next page).




Figure 505




Figure 506

- 2) Inspect the inside of the fan cover for excessive brake dust (Figure 507). This indicates brake wear caused by an incorrectly adjusted brake or possibly low voltage usage. It may also be an indication of excessive EMERGENCY DESCENT usage.



Figure 507

- 3) Measure the clearance (a) between the pressure plate and the black brake body with a feeler gauge. This should be done in all three places between the 3 fixing screws every 120 degrees (Figure 508).




Figure 508

- 4) Measurement of the air gap (a) should be 0.012" (0.3mm) (Figure 509 and Figure 510). If the air gap (a) needs an adjustment, refer to Section 5.6.




Figure 509




Figure 510

5.4 Brake Removal



NOTE:

Prior to removal, pay attention to the brake orientation and mark it for realignment (Figure 511).




Figure 511

- 1) Remove the fan snap ring {Code #3866, Pos. 21} shown in Figure 512.




Figure 512

- 2) Remove the fan {Code #16186, Pos. 7} with two screwdrivers placed under the fan and against the motor shaft and pry upward (Figure 513).



Figure 513

- 3) If the fan key {Code #16256, Pos. 23} is removable, do so. If not, just wrap some tape around the keyway for safety (Figure 514, 515).



Figure 514



Figure 515

- 4) Remove the three socket head fixing screws w/ locking washers.
- 5) Remove the whole brake assembly {Code #49746 (110 V), or #47406 (220 V) Pos. 35} as shown in Figure 516.



Figure 516

**NOTE:**

It is not necessary to unwind the brake.

- 6) Remove the brake rotor {Code #47416, Pos. 38} and inspect it (Refer to Section 5-6). Replace if worn or damaged (Figure 517).



Figure 517

- 7) Remove the snap ring {Code #3866, Pos. 21} and carefully pry the brake hub {#47426, Pos. 39} and key {Code #16256, Pos. 23} from the motor shaft as shown in Figure 518. Inspect the brake hub and replace if necessary.



Figure 518

**NOTE:**

Care must be taken when replacing the hub not to damage it.

- 8) Inspect the friction plate {Code #62026, Pos. 36} for wear (Figure 519). Replace all worn or damaged components.
- 3) Slide the brake disc {Code #47416, Pos. 38} down the motor shaft so it fits over the brake hub.




Figure 519

5.5 Reassembly

**NOTE:**

Prior to reassembly, it is MANDATORY that the 3 brake end shield holes have silicone applied to seal the screws. This must be done to prevent water entry into the motor (Figure 520).



Figure 520

- 1) Place the friction plate {Code #62026, Pos. 36} over the motor shaft. Rotate it until the holes of the friction plate are directly over the 3 brake end shield holes.
- 2) Position the key {Code #16256, Pos. 23} onto the motor shaft and slide the brake hub {Code #47426, Pos. 39} down to the bottom of the shaft. Place the snap ring {Code #3866, Pos. 21} on top of the brake hub to secure it.

- 4) Place the whole brake assembly {Code #49746 (110 V), or #47406 (220 V) Pos. 35} (Figure 516) over the motor shaft.
- 5) Using a 5mm allen wrench, screw the three socket head fixing screws w/ locking washers to hold the brake assembly in place.
- 6) Position the fan key {Code #16256, Pos. 23} onto the motor shaft.
- 7) Align the fan {Code # 16186, Pos. 7} key hole with the fan key {Code #16256, Pos. 23} and press downward.
- 8) Replace the fan snap ring {Code #3866, Pos. 21} shown in Figure 512.
- 9) Place the fan cover {Code #68287, Pos. 6} as shown in Figure 511 over the brake. The handle should face in the direction of the control box.
- 10) Install the 4 screw {Code #16086, Pos 31} and washer assemblies using an 8mm wrench.

5-6 Disc Inspection

A new brake disc has a thickness of 5 mm, which is indicated on the top of the brake. If excessive brake wear is apparent or the air gap is significantly greater than 0.012" (0.3mm), measure the brake disc with a caliper. See Figure 521.

Maximum brake wear is 0.040" [1mm] - If disc thickness is less than 4 mm, the brake disc must be replaced.

| Model | Brake Size | New Disc Thickness |
|----------------|------------------------|--------------------|
| XE 301P - 110V | FDB 10 / 96V (#49746) | 5 mm |
| XE 301P - 220V | FDB 10 / 190V (#47406) | 5 mm |



Figure 521

5-7 Brake Air Gap Adjustment

If adjustment is required proceed as follows.

The air gap should be 0.012" [0.3mm]. If necessary, adjust by means of the three set screws and counter nuts as follows:

- 1) Loosen the three socket head fixing screws a few turns as shown in Figure 522.



Figure 522

- 2) Adjust each of the three 8mm adjustment screws (Figure 523) AN EQUAL # OF DEGREES to either increase or decrease the air gap (a) to 0.012" [0.3mm]. Unbalanced adjustments will lead to excessive brake wear.



Figure 523

- 3) Tighten down the three socket head fixing screws w/locking washers.
- 4) Measure the air gap as shown in Figure 524. If necessary, repeat steps 1-3 until an air gap of 0.012" (0.3mm) is achieved.



Figure 524

- 5) Remove each of the three socket head fixing screws separately and apply a bead of silicone (Figure 525) to the tip to prevent water entry into the motor. Replace all three screws.



Figure 525



NOTE:

The adjustment of the gap on the brake release stirrup has NOTHING TO DO with the adjustment of the air gap of the brake!

5-8 Release Stirrup Replacement

- 1) Carefully remove all sealant (Figure 526) if the brake release stirrup is to be replaced.




Figure 526

- 2) Use a C-clamp to hold the brake assembly together as shown in Figure 527.



Figure 527




Figure 528

- 3) Unscrew the two fixing screws as shown in Figure 528 ("E" in Figure 530 on next page).
- 4) Install the new brake release stirrup (B) {Code #61716, Pos. 40}.
- 5) Install the new fixing screws (Figure 529).




Figure 529

- 6) Install the brake onto the motor. Apply silicone to the brake end shield holes prior to installation to prevent water from entering the motor. Replace all three screws.




Figure 530

- 7) Measure distance (b) between the brake retraction plate (C) and washer (D) in Figure 530. This distance must be 0.039" (1mm). If necessary, adjust symmetrically on both sides by means of the two screws (E).

5-9 Operational Check

Testing must be carried out once the brake has been completely reassembled. With the fan cover removed, proceed with the operational check:

- 1) With the correct power supplied to the hoist, push the up or down button.
- 2) Visually inspect that the anchor disc ("C" in Figure 530) lifts evenly upward away from the brake disc. A pronounced "click" or "snap" should be heard when it retracts magnetically.
- 3) CAREFULLY feel for heat (Figure 531) around the entire electromagnetic brake being cautious around the rotating fan.



Figure 531

- 4) If there is any heat being generated, re-inspect the brake air gap because the disc is most likely dragging.
- 5) If no heat is generated, reinstall the fan cover. When installing the fan cover, pull back as shown in Figure 532 to gain more clearance for the emergency descent lever.



Figure 532

5-10 Coil Resistance Inspection

Measure the resistance of the brake coil as shown in the Electrical Control Box chapter.

XE301P brake resistances listed in table 501.

Brake coil resistance is also found on the wiring diagram.



WARNING



Upon completion of any brake maintenance, it is **MANDATORY** that a load test of the hoist be completed.

5-11 Parts List Primary Brake

| Brake Type | Code Complete | Disc Code | Release Code | Hub Code |
|--|---------------|-----------|--------------|----------|
| 110 V Precima Model FDB10 Resistance 332 Ohms | 49746 | 47416 | 61716 | 47416 |
| 220 V Precima Model FDB10 Resistance 1430 Ohms | 47406 | 47416 | 61716 | 47416 |

Table 501

5-12 Modification Comment

Subject : Adjusting of the brake release lever.

Reason : Simplify assembly and inspection

The former instructions regarding the adjustment of the distance “b” (Figure 530) for the brake release lever “B” in (Figure 530) “with the brake opened” were based on an internal production instructions of the manufacturer by means of a special tool.

After discussion with the manufacturer the procedure can be simplified by checking the distance “b” (Figure 530) “with the brake closed”; in consequence the manufacturer’s value of 0.039” [1mm] must be reduced by the air gap (a) 0.012” [0.3mm], which gives the new checking dimension of 0.028” [0.7mm].




Figure 530

5-13 Assembly and Adjusting

Fix the new brake to the motor and connect it into the control box.

Check the air gap (a) = 0.012” [0.3mm] around the brake with a feeler gauge - if necessary, adjust by means of set screws “A” (See Section 5-3).

When assembling a new brake check adjustment of brake release lever “B” (See Section 5-7).

With the brake closed the distance (b) between anchor disk “C” and washers “D” must be 0.028” [0.7mm]. If necessary, adjust symmetrically on both sides by means of screws “E”.



WARNING



The adjustment of the brake release lever must not be changed afterwards, even in case of an air gap (a) readjustment, as security is adversely affected.

6) MOTOR


6-1 Replacement of Motor Winding (Stator)




NOTE:

The motor and control box must be removed before attempting to replace the motor winding (stator).

- 1) Remove the fan cover M5x10 hex screws {Code #16086, Pos. 31} as shown in Figure 601.



- 2) Remove the fan snap ring {Code #3866, Pos. 21} shown in Figure 602.



- 3) Remove the fan {Code #16186, Pos. 7} using two screwdrivers. Placed them under the fan and against the motor shaft. Pry upward. (Figure 603).



- 4) Remove the whole brake assembly {Code #49746 (110 V), or #47406 (220 V) Pos. 35} by removing the three socket head fixing screws w/locking washers. (Figure 604).



- 5) Remove the brake disc {Code #47416, Pos. 38} and the brake hub {Code #47426, Pos. 39}. Remove the snap ring {Code #536, Pos. 20} and carefully pry the hub from the motor shaft as shown in Figure 605.



- 6) Remove the friction plate {Code #62026, Pos. 36} shown in Figure 606.




Figure 606

- 7) Remove the four M5x153 mm hex head screws {Code #26097, Pos. 12} holding onto brake flange shown in Figure 607.



Figure 607



NOTE:

Prior to removal, pay attention to the brake orientation and mark it for realignment (Figure 608).



Figure 608



Figure 609

- 8) Using a rubber mallet, drive out the motor shaft {Code #26587, Pos. 15} as shown in Figures 609 and 610.



Figure 610

- 9) Remove the ring terminal winding wires (black-w, red-z, red-u and black-v) as shown in Figure 611.






Figure 611

- 10) Remove the small thermal protector wires from grey X1 and X2 (Figure 612).



- 11) Remove the four socket head cap screws and lock washers that are holding the control box to the motor. Remove the control box (Figure 613).



- 12) Replace the old winding with a new winding as shown in Figure 614.



6-2 Centrifugal Switch Replacement XE301P

- 1) Remove the motor and control box from the hoist (See Figure 615 on the next page). Remove the fan cover 4x8mm hex head screws {Code #16086, Pos. 31}.



WARNING



**Discharge the start and run capacitors
before proceeding.**



Figure 615

- 2) Remove the fan snap ring {Code # 3866, Pos. 21, Figure 616} and pry off the fan {Code #16186, Pos. 7} using 2 screwdrivers (See Figure 617). Make sure the screwdrivers are against the motor shaft when prying.



Figure 616



Figure 617

- 3) Take off the primary brake {Code #49746 (110 V), or #47406 (220 V) Pos. 35} by removing the 3 socket head cap screws (See Figure 618).



Figure 618

- 4) Remove the brake disc {Code #47416, Pos. 38}, friction disc {Code #62026, Pos. 36}, snap ring {Code #3866, Pos. 21}, hub {Code #47426, Pos. 39} and key {Code #16256, Pos. 23} shown in Figure 619.



Figure 619

- 5) Remove the 4 M5X153 threaded bolts {Code #26097, Pos. 12} that hold the cast aluminum brake end bell housing to the motor (See Figure 620).



Figure 620

- 6) Mark the position of the white centrifugal switch for easy alignment during reassembly as shown in Figure 621.



- 7) Loosen the 2 screws holding the centrifugal switch wires and remove the 2 spade connectors from beneath the screws (See Figures 622 and 623).



- 8) Unscrew the 3 M4x16 screws {Code #16996, Pos. 30} holding the centrifugal switch (See Figure 624).



- 9) Mark the flange for reassembly (See Figure 625).



- 10) With a rubber mallet, tap the cast aluminum brake end bell {Code #26107, Pos. 5, Figure 626}.



- 11) Remove the motor shaft assembly {Code #26587, Pos. 15, Figure 627}.



- 12) Loosen the set of screws holding the mechanical part of the centrifugal switch (See Figure 628) and push the assembly away from the ball bearing to allow room for a puller (See Figure Figure 629).



- 13) Remove the ball bearing 6004-RS1 {Code #16536, Pos. 18} by removing the snap ring {Code #536, Pos. 20, Figure 630} and pulling with a bearing puller (See Figures 631 and 632).



- 14) Remove the bearing. Notice that one side is sealed and the other side is not (See Figure 633).



- 15) Remove the snap ring {Code #536, Pos. 20} in Figure 634.



- 16) Remove the bearing cover {Code #27935, Pos. 6} in Figure 635.



- 17) Remove the white centrifugal switch and mechanical actuating mechanism (See Figure 636 and 637).



NOTE

We suggest you layout the parts on the workbench for ease of reassembly (See Figure 638).



- 18) Check the centrifugal switch contacts for burn, malfunction, etc. Manipulate the switch to see if the contacts open and close (See Figure 639).




Figure 639



NOTE

Sometimes contact cleaner and emery cloth can repair a malfunctioning switch (See Figure 640).



Figure 640

- 19) Before installation of a new switch, check that it functions properly with a meter. Open and close the switch. The meter should indicate open (Figure 641) and closed (Figure 642) when manipulated on the bench.



Figure 641



Figure 642

- 19a) If it stays open, clean the contacts with contact cleaner and emery cloth (See Figure 643 and 644).



Figure 643



Figure 644

- 20) Reassemble the new mechanical and electrical switch on the motor shaft (See Figure 645).



Figure 645

21) Replace the bearing cover {Code #27935, Pos. 6, Figure 637} and reaffix the snap ring {Code #536, Pos. 20, Figure 636}. Repack the ball bearing with grease. Note that the seal is on the bottom and the bearing is open to the top (See Figure 646).



Figure 646

22) With a metal tube (Figure 647) tap the bearing onto the shaft until it contacts the snap ring below it (See Figure 618).



Figure 647



Figure 648

23) Replace the snap ring {Code #536, Pos 20} on the shaft (See Figure 630).

Squeeze the mechanical portion of the centrifugal switch while sliding it up the shaft (See Figure 651). With the set screw lock it into position on the shaft (See Figure 628).

23) Manipulate the new switch to see if it opens and closes properly (See Figure 649).



Figure 649

24) Reattach the wires to the switch (Figure 650).



Figure 650

25) Check the winding for burns or damage (See Figure 651).




Figure 651

- 26) Put the cast aluminum brake end shield on the motor shaft (See Figure 652).



- 27) Realign the switch and retighten the 3 M4x16 screws {Code #16996, Pos. 30, Figure 629}. Place silicone around the bottom of the cast aluminum end shield to seal the joint between the winding and shield.
- 28) Place the motor shaft assembly into the winding, align the marks and tighten the 4 M5x153 {Code #26097, Pos. 12} bolts.
- 29) Reassemble the brake per Section 5-12.
- 30) Replace the fan cover. Refit the motor and test.


| | | | | |
|-------------|-------------------------------|--|------------|----------|
| Spare Parts | XE301P - 110V | | Drawing No | E - 3075 |
| | 110V / 1ph. 0.55 kW / 60Hz | | Edition | US-1 |
| | Motor type: UBE 80/11-4F-100V | | Date | 1/05 |
| | | | Page | 1 / 1 |



| Position | Part # | Qty. | Description | Specifications | List Price |
|----------|--------|------|-------------------------------------|----------------|------------|
| - | 15648 | 1 | Motor complete UBE80/11-4F, XE301 | 0.55kW, 110V | \$1,550.68 |
| 1 | 26597 | 1 | Stator for UBE80/11-4F, XE301 | 0.55kW, 110V | \$496.57 |
| 5 | 26107 | 1 | BRAKE END SHIELD | Sz. 80 | \$140.58 |
| 6 | 27935 | 1 | BEARING COVER | | \$47.07 |
| 7 | 16186 | 1 | Fan for Motor | | \$7.14 |
| 8 | 26607 | 1 | FAN COVER XE301p | Sz. 80 | \$125.03 |
| (8a*) | 47837 | 1 | Replacement rain cover w/ handle | Size 80 | \$0.00 |
| (8b*) | 69536 | 1 | Plastic cap for fan cover with hole | | \$0.00 |
| 10 | 41996 | 1 | O-RING FOR MOTOR SIZE 80 120 X 2,5 | 120x2.5 | \$4.77 |
| 12 | 26097 | 4 | THREADED BOLT C/W NUT | M5x153 | \$4.62 |
| 14 | 15796 | 1 | CENTRIFUGAL SWITCH XE301P, LE501P | 2 pieces incl. | \$72.61 |
| 15 | 26587 | 1 | MOTOR SHAFT WITH ROTOR | | \$258.95 |
| 18 | 16536 | 1 | Ball bearing 6004-RS1 | 20x42x12 | \$12.12 |
| 19 | 26376 | 1 | SHAFT SEAL DIA.20/35/7 BASL | 20x35x7 | \$4.16 |
| 20 | 536 | 2 | Snap ring | 20x1.2 | \$0.00 |
| 21 | 3866 | 3 | Snap ring | 15x1 | \$0.00 |
| 22 | 39316 | 1 | KEY A 5X5X45 DIN 6885 | 5x5x45 | \$0.39 |
| 23 | 16256 | 2 | Key | A5x5x16 | \$0.26 |
| (25*) | 16206 | 1 | Motor nameplate | Metal | \$1.90 |
| (26*) | 16236 | 2 | RIVET 2 X 6 DIN 1476 | 2x6 | \$0.13 |
| (27*) | 16706 | 1 | Brake nameplate | Metal | \$2.26 |
| (28*) | 3776 | 2 | Blind rivet | 2.4x6 | \$0.00 |
| 30 | 16996 | 3 | Cheese head screw | M4x16 | \$0.00 |
| 31 | 16086 | 4 | HEXAGONAL SCREW M5X10 DIN933 | M5x10 | \$0.13 |
| 33 | 16246 | 8 | SPRING WASHER DIA.5 DIN 127 | A5 | \$0.13 |
| 35 | 49746 | 1 | Electromagnetic brake complete | FDB 10 / 96V | \$0.00 |
| 36 | 62026 | 1 | FRICTION PLATE FDB10 | FDB 10 | \$17.33 |
| 37 | 62446 | 1 | Brake coil assembly | FDB 10 / 96V | \$0.00 |
| 38 | 47416 | 1 | BRAKE ROTOR FDB 10 | FDB 10 | \$75.82 |
| 39 | 47426 | 1 | BRAKE HUB SIZE FDB10 | FDB 10 | \$61.49 |
| 40 | 61716 | 1 | BRAKE RELEASE STIRRUP CPL. FDB 10 | FDB 10 | \$97.20 |

*) not shown

| | | | | |
|-------------|--|--|------------|----------|
| Spare Parts | XE301P - 220V/1ph. 220V / 1ph. 0.55 kW / 60Hz Motor type: UBE 80/11-4F-200V | | Drawing No | E - 3076 |
| | | | Edition | US-1 |
| | | | Date | 1/05 |
| | | | Page | 1 / 1 |



| Position | Part # | Qty. | Description | Specifications | List Price |
|----------|--------|------|--|-------------------|------------|
| - | 15638 | 1 | Motor complete UBE80/11-4F, XE301 | 0.55kW, 220V/1ph. | \$1,535.51 |
| 1 | 26577 | 1 | Stator for UBE80/11-4F, XE301 | 0.55kW, 220V/1ph. | \$495.60 |
| 5 | 26107 | 1 | BRAKE END SHIELD | Sz. 80 | \$140.58 |
| 6 | 27935 | 1 | BEARING COVER | | \$47.07 |
| 7 | 16186 | 1 | Fan for Motor | | \$7.14 |
| 8 | 26607 | 1 | FAN COVER XE301p | Sz. 80 | \$125.03 |
| (8a*) | 47847 | 1 | Replacement rain cover w/ handle | Size 90 | \$77.17 |
| (8b*) | 69536 | 1 | Plastic cap for fan cover with hole | | \$0.00 |
| 10 | 41996 | 1 | O-RING FOR MOTOR SIZE 80 120 X 2,5 | 120x2.5 | \$4.77 |
| 12 | 26097 | 4 | THREADED BOLT C/W NUT | M5x153 | \$4.62 |
| 14 | 15796 | 1 | CENTRIFUGAL SWITCH XE301P, LE501P | 2 pieces incl. | \$72.61 |
| 15 | 26587 | 1 | MOTOR SHAFT WITH ROTOR | | \$258.95 |
| 18 | 16536 | 1 | Ball bearing 6004-RS1 | 20x42x12 | \$12.12 |
| 19 | 26376 | 1 | SHAFT SEAL DIA.20/35/7 BASL | 20x35x7 | \$4.16 |
| 20 | 536 | 2 | Snap ring | 20x1.2 | \$0.00 |
| 21 | 3866 | 3 | Snap ring | 15x1 | \$0.00 |
| 22 | 39316 | 1 | KEY A 5X5X45 DIN 6885 | 5x5x45 | \$0.39 |
| 23 | 16256 | 2 | Key | A5x5x16 | \$0.26 |
| (25*) | 16206 | 1 | Motor nameplate | Metal | \$1.90 |
| (26*) | 16236 | 2 | RIVET 2 X 6 DIN 1476 | 2x6 | \$0.13 |
| (27*) | 16706 | 1 | Brake nameplate | Metal | \$2.26 |
| (28*) | 3776 | 2 | Blind rivet | 2.4x6 | \$0.00 |
| 30 | 16996 | 3 | Cheese head screw | M4x16 | \$0.00 |
| 31 | 16086 | 4 | HEXAGONAL SCREW M5X10 DIN933 | M5x10 | \$0.13 |
| 33 | 16246 | 8 | SPRING WASHER DIA.5 DIN 127 | A5 | \$0.13 |
| 35 | 47406 | 1 | ELECTROMAGNETIC BRAKE CPL. FDB 10 190V | FDB 10 / 190V | \$207.51 |
| 36 | 62026 | 1 | FRICTION PLATE FDB10 | FDB 10 | \$17.33 |
| 37 | 62016 | 1 | BRAKE COIL ASSY. FDB 10/190V | FDB 10 / 190V | \$125.00 |
| 38 | 47416 | 1 | BRAKE ROTOR FDB 10 | FDB 10 | \$75.82 |
| 39 | 47426 | 1 | BRAKE HUB SIZE FDB10 | FDB 10 | \$61.49 |
| 40 | 61716 | 1 | BRAKE RELEASE STIRRUP CPL. FDB 10 | FDB 10 | \$97.20 |

*) not shown

7) CONTROL BOX XE301P



NOTE:

All of the following checks are done without power to the motor or hoist.

7-1 Tools Required

- Volt/Ohm meter (left in Figure 701)
- Digital Capacitor meter (up to 275uF)
- 2 insulated screwdrivers

Figure 701



7-2 Control Box Cover Inspection

- 1) Check that all labels are legible and in the right place (Figure 702). If not, replace those labels. See sec. 9-2 for correct location and code.



Figure 702

- 2) Check that the emergency stop button functions normally. (Figure 703). Press it to lock in the "Off" position. Twist it to check that it springs open into the "On" position. Check that it is not loose. If it is, open the cover and tighten the 2 screws that hold it in place.



Figure 703

- 3) Check that the protective cover around the emergency stop button is in good condition and is not loose. Replace it if necessary. The 3 screws must be tightened and have silicone applied to seal against water entry.



Figure 704

- 4) Check that the voltage indicator light is not damaged (Figure 704).

7-3 Ground (Cord/Plug) Check

- 1) With an ohm meter, check each prong to the case of the TIRAK. The long ground prong should show continuity (Figure 705).



Figure 705

The two shorter prongs should not show continuity (Figure 706).



Figure 706



NOTE:

If either of the shorter prongs show continuity to ground, a short circuit has occurred and must be fixed. It is possible that the plug is wired incorrectly or the insulation is cut. Open the plug and investigate. Also check the cord grip.

7-4 Wiring Diagram Location

- 1) Using a screwdriver, open the control box (Figure 707).




Figure 707

- 2) A tag tied to wires indicates the control box type, L10.3B, and wiring diagram, #34427 (Figure 708).




Figure 708

- 3) A full size diagram should be folded and tucked in place next to the relays. Check that the full size diagram matches the tag (Figure 709).




Figure 709

709).



NOTE:

When using an ohm-meter, deduct the test probe resistance from any reading for accuracy. Shown as 0.2 ohms (Figure 710).



Figure 710

7-5 Stator/Winding Check

- 1) With an ohm-meter, measure the resistance of the starting winding W/Z by placing test probes on Position 1(W) and Position 2(Z) of terminal board M1 (3.9 ohms is normal. Figure 711 (on the next page), shows $4.0 - 0.2 = 1.73$ ohms, OK). This is found on the wiring diagram #34427. If the connection is open, the stator must be replaced.




Figure 711

- 2) Check that the starting winding is not shorted to ground. There should be no continuity between W or Z and the control box casing (Figure 712). If the connection is shorted, the stator must be replaced.




Figure 712

- 3) With an ohm-meter, measure resistance of the run winding U/V by placing the test probes on position 4(U) and position 5(V) of terminal board M1 (.93 ohms is normal Figure 713, shows 2.2-0.2 = 2.0 ohms). This is found on the wiring diagram #34427. If the connection is open, the stator must be replaced.




Figure 713

- 4) Check that the run winding is not shorted to ground. There should be no continuity between U or V and the control box casing (Figure 714). If the connection is shorted, the stator must be replaced.



Figure 714

7-6 Fuse Check, F1 {Code #22366 (110V), Pos. 11, Code #21076 (220V), Pos. 13}

- 1) With an ohmmeter, check continuity by placing the test probes on X1 and X2 of the fuse. If no continuity is found, replace the fuse with the spare by lifting the grey fuse holder (Figure 715).




Figure 715



NOTE:

The thermal protector opens when the motor is hot in order to prevent damage. It is normally closed and automatically resets.

7-7 Thermal Protector Check

With the ohmmeter, place the test probes on the fuse terminal and X1 of the grey terminal board where the two small wires are fixed (Figure 716 on the next page). If the connection is open, the stator must be replaced.




Figure 716

7-8 Relay Coil Resistance, K1, K2, K3

- 1) Main relay K3 coil resistance should be approximately 310 ohms. Place the ohmmeter test probes on the A1 and A2 screws of the K3 relay. Check the resistance (Figure 717, shows 315 ohms, OK). If the connection is open or shorted, replace the K3 relay {Code #60406 (110 V), #60356 (220 V), Pos. 7}.



Figure 717

- 2) The DOWN relay, K2, coil resistance should also be approximately 310 ohms. Place the ohmmeter test probes on the A1 and A2 screws of the K2 relay. Check the resistance (Figure 718, shows 312 ohms, OK). If the connection is open or shorted, replace the UP/DOWN double relay {Code #60456 (110 V), #60466 (220 V) Pos. 8}.



Figure 718

- 3) The UP relay, K1, coil resistance should be approximately 310 ohms. Place the ohmmeter test probes on the A1 and A2 screws of the K3 relay. Check the resistance (Figure 719, shows 305 ohms, OK). If the connection is open or shorted, replace the UP/DOWN double relay {Code #60456 (110 V), #60466 (220 V) Pos. 8}.



Figure 719

7-9 Brake Coil Resistance Check

With the ohmmeter test probes placed on the center two positive(+) and negative(-) terminals of the brake rectifier U1, measure the resistance (Figure 720, shows 333 ohms, OK). It should be approximately 332 ohms. If the connection is open or shorted, replace the brake coil .




Figure 720

7-10 Capacitor Checks

- 1) Discharge the capacitors by sliding the K1 or K2, and K3 relays to the right with 2 insulated screwdrivers for several seconds (Figure 721 on the next page).




Figure 721




Figure 723

- 2) With a digital capacitor tester, measure the start and run capacitance by placing the test clips on position 4 and position 6 of the terminal board M1 (Figure 722, shows 277uF, OK). This number is the combination of the start capacitor CA(180uF) + run capacitor(s) CB(35uF) = 250uF +/- 10%. If the total is outside this range, check each capacitor as follows.




Figure 722

- 3) The start capacitor CA(180uF) is located on the cover of the control box (Figure 723 shows 196uF, OK). Detach the two insulated spade connectors. With the digital capacitor meter, measure the capacitance. It should be 180uF +/- 10% (162 to 198 uF). If the reading is outside this range, replace the start capacitor {Code #19196 (110 V), #38546 (220 V, Pos. 31)}.

- 4) The run capacitor CB(35uF) is located in the control box and is larger in size than the start capacitor (Figure 724, shows 39uF, OK). Detach the two insulated space connectors from the capacitor and attach the digital capacitor meter clips to the capacitor. Measure the capacitance. It should read 35uF +/- 10% (32 to 38uF). If the reading is outside this range, replace the run capacitor {Code #23686 (110 V), #42766 (220 V), Pos. 32}.



Figure 724

Remember that all the previous tests/rules also apply to the (20mF & 60mF) 220 V Capacitors.

Note: The 220 V XE301P only contains one run capacitor.

7-11 Centrifugal Switch Check

With an ohmmeter, place the the probes on position 5 and 6 of the terminal board M1 (Figure 725 on the next page). The switch should be closed when the motor is not running. When the motor runs, the motor draws high amps and the switch opens. If it stays closed, it is stuck and the switch should be repaired or replaced.



Figure 725

7-12 Pushbutton Checks

- 1) Contacts are marked NO = “Normally Open” or NC = “Normally Closed”. Figure 726 shows continuity for a NC contact. If the button is pressed it should open. A NO switch operates in an opposite manner. Pressing the button closes the switch and creates continuity.



Figure 726

7-13 Control Box Check

- 1) Tighten the 4 socket head screws {Code #33156, Pos. 37} that hold the control box to the motor (Figure 727).



Figure 727

- 2) Check that the control box base is not distorted or cracked especially at the junction of the box to the motor. If damaged, it must be replaced.

7-15 Power Check



WARNING



The following checks are performed with power to the hoist motor. Whenever power is applied to the hoist, use extreme caution especially with the control box open as part are energized. Only trained and qualified personnel should service the hoist to avoid injury or death.

- 1) Open the emergency stop by twisting the red knob. It should spring open. This should cause the main relay, K3, to energize.
- 2) Measure the AC input voltage with a voltmeter at terminal 1 and 3 of the K3 relay (Figure 728). If no voltage occurs, check the fuse and bimetal protector per sections 7-5.




Figure 728

7-16 Brake Rectifier Check {Code #10917, Pos. 10}

- 1) Push either the up or down button on the control box cover. The motor should run.
- 2) While the motor is running, measure the AC voltage to the brake rectifier by placing the voltmeter probes on the AC screws of the rectifier (left side terminals marked ~ ~). See Figure 729 which shows 116.6 volts AC to rectifier, OK.




Figure 729

- 3) The AC voltage to the rectifier should be the same as the input power measured in Section 7-12.
- 4) Measure the DC voltage from the rectifier. Change the voltmeter to DC. Measure the voltage output from the rectifier at the positive(+) and negative(-) screw terminals (2 center screws) while pressing the UP or DOWN button on the control box cover (Figure 730, which shows 103.2 DC volts from the rectifier, OK). It should read approximately 110 volts. If not approximately 110 volts, replace the rectifier.
For 220 V XE301P: If not approximately 220 volts, replace the rectifier.



Figure 730



NOTE:

General service on the control box is now complete.

| Spare Parts | | XE301P - 110V- Direct | | Drawing No | E - 3068 |
|-------------|--------|-----------------------|--|----------------------|------------|
| | | 110V / 1ph. / 60Hz | Wiring Diagram #19225 | Edition | US-1 |
| | | GG 13/10.14 | Plan #19226 | Date | 1/05 |
| | | | | Page | 1 / 2 |
| Position | Part # | Qty. | Description | Specifications | List Price |
| - | 26647 | 1 | Control box complete GG13/10.14, XE301 | 110V, Direct | \$1,377.25 |
| 1 | 47917 | 1 | Terminal box, empty | | \$0.00 |
| 2 | 17846 | 1 | GASKET | DK80-112R/02 | \$2.26 |
| 3 | 65115 | 1 | Angle bracket | 25x100x3 | \$0.00 |
| 4 | 22905 | 1 | Mounting rail | 35x180 | \$0.00 |
| 6 | 35435 | 1 | SWITCH PROTECTION | | \$64.98 |
| 7 | 60406 | 1 | Contactor / Relay | LC1 K 09 10 F - 110V | \$62.70 |
| 8 | 60456 | 1 | Double Contactor / Relay | LC2 K 09 10 F - 110V | \$141.82 |
| 9 | 22426 | 1 | TERMINAL BOARD COMPLETE | | \$20.49 |
| 10 | 10917 | 1 | RECTIFIER | | \$55.46 |
| 11 | 22366 | 1 | FUSE BLOCK WITH PLATE | | \$8.76 |
| 12 | 21076 | 2 | 2 AMP FINE WIRE FUSE | 5x20 | \$1.26 |
| 13 | 40796 | 1 | EARTH BLOCK M4/6P | | \$4.90 |
| 14 | 24346 | 3 | TERMINAL BLOCK | | \$2.80 |
| 15 | 18566 | 2 | Identification labels 1-10 | | \$0.00 |
| 17 | 22856 | 1 | End plate | | \$0.00 |
| 18 | 21706 | 2 | PUSH BUTTON BLOCK | ZB2BZ105 - NO+NC | \$28.80 |
| 19 | 21716 | 2 | PUSH BUTTON COVER | ZB2BA78 | \$19.63 |
| 21 | 21746 | 1 | "EMERGENCY STOP" BUTTON BLOCK | ZB2BZ102 - NC | \$19.48 |
| 22 | 18296 | 1 | "EMERGENCY STOP" BUTTON COVER | ZB2BS54 | \$31.73 |
| 23 | 37776 | 1 | "EMERGENCY STOP" LABEL | | \$7.27 |
| 24 | 103 | 1 | Power cord for single phase, per ft. | 3 x 10 AWG | \$0.00 |
| 25a | 2311 | 1 | Hubbell plug 20A 125V | | \$0.00 |
| 25b | 6031 | 1 | Hubbell plug boot for 3 pol | | \$0.00 |
| 27 | 15026 | 1 | CABLE BUSHING WITH STRAIN RELIEF PG21-MS | Pg. 21 | \$10.93 |
| 28 | 18276 | 1 | BLIND PLUG PG 16 MS | Pg. 16 | \$1.51 |
| 29 | 18256 | 1 | BLIND PLUG PG 11 MS | Pg. 11 | \$1.13 |
| 30 | 25056 | 2 | CABLE BUSHING PG 7 | Pg. 7 | \$1.61 |
| 31 | 19196 | 1 | START CAPACITOR | 180 mF | \$76.27 |
| 32 | 23686 | 2 | WORKING CAPACITOR 350 VF 35 MF | 35 mF | \$82.33 |
| 33 | 18906 | 1 | PIPE CLAMP | | \$1.90 |
| (34*) | 10991 | 8 | Conductor (black) | | \$0.00 |
| (35*) | 11021 | 3 | INSOLATING TUBE 4.2X0.6 | | \$2.49 |
| 37 | 33156 | 4 | SOCKET HEAD CAP SCREW M5X16 | M5x15 | \$0.50 |
| 38 | 17016 | 2 | CHEESE HEAD SKREW M3X12 DIN 84 | M3x12 | \$0.07 |
| 40 | 33126 | 5 | CHEESE HEAD SCREW M4X10 DIN84 | M4x10 | \$0.26 |
| 41 | 16 | 5 | Cheese head screw | M4x8 | \$0.00 |
| 43 | 7536 | 4 | HEXAGON HEAD CAP SCREW 6X12 DIN 933 | M6x12 | \$1.05 |
| 44 | 16246 | 4 | SPRING WASHER DIA.5 DIN 127 | A5 | \$0.13 |
| 46 | 456 | 4 | Washer | A6.4 | \$0.00 |
| 47 | 44466 | 1 | Label "UP" | | \$0.00 |
| 48 | 44476 | 1 | Label "DOWN" | | \$0.00 |


Spare Parts

XE301P - 110V- Direct

110V / 1ph. / 60Hz
GG 13/10.14

Wiring Diagram #19225
Plan #19226

Drawing No E - 3068
Edition US-1
Date 1/05
Page 2 / 2



| Spare Parts | | XE301P - 220V/1ph. - Direct 220V / 1ph. / 60Hz GG 13/10.3 | | Drawing No Edition Date Page | E - 3061 US-1 1/05 1 / 2 |
|-------------|--------|--|--|---------------------------------------|-----------------------------------|
| | | Wiring Diagram #19219 Plan #19220 | | | |
| Position | Part # | Qty. | Description | Specifications | List Price |
| - | 26637 | 1 | Terminal box complete XE301 220V | 220V/1ph., Direct | \$0.00 |
| 1 | 42757 | 1 | Control box, empty, XE301 | | \$0.00 |
| 3 | 17846 | 1 | GASKET | DK80-112R/02 | \$2.26 |
| 4 | 43285 | 1 | MOUNTING RAIL | 35x244 | \$12.18 |
| 5 | 35805 | 1 | Distance tube | | \$0.00 |
| 6 | 35435 | 1 | SWITCH PROTECTION | | \$64.98 |
| 7 | 60356 | 1 | Contactor / Relay | LC1 K 09 10 P - 220V | \$62.70 |
| 8 | 60466 | 1 | Double Contactor / Relay | LC2 K 09 10 P - 220V | \$141.82 |
| 9 | 22426 | 1 | TERMINAL BOARD COMPLETE | | \$20.49 |
| 10 | 10917 | 1 | RECTIFIER | | \$55.46 |
| 12 | 22366 | 1 | FUSE BLOCK WITH PLATE | | \$8.76 |
| 13 | 21076 | 1 | 2 AMP FINE WIRE FUSE | 5x20 | \$1.26 |
| 14 | 24346 | 1 | TERMINAL BLOCK | | \$2.80 |
| 15 | 18566 | 1 | Identification labels 1-10 | | \$0.00 |
| 16 | 40796 | 1 | EARTH BLOCK M4/6P | | \$4.90 |
| 17 | 22856 | 1 | End plate | | \$0.00 |
| 18 | 21706 | 1 | PUSH BUTTON BLOCK | ZB2BZ105 - NO+NC | \$28.80 |
| 19 | 21716 | 1 | PUSH BUTTON COVER | ZB2BA78 | \$19.63 |
| 21 | 21746 | 1 | "EMERGENCY STOP" BUTTON BLOCK | ZB2BZ102 - NC | \$19.48 |
| 22 | 18296 | 1 | "EMERGENCY STOP" BUTTON COVER | ZB2BS54 | \$31.73 |
| 23 | 37776 | 1 | "EMERGENCY STOP" LABEL | | \$7.27 |
| 24 | 103 | 1 | Power cord for single phase, per ft. | 3 x 10 AWG | \$0.00 |
| 25a | 2421 | 1 | Hubbell plug 20A/250V/4 pole | | \$0.00 |
| 25b | 6031 | 1 | Hubbell plug boot for 3 pol | | \$0.00 |
| 27 | 15026 | 1 | CABLE BUSHING WITH STRAIN RELIEF PG21-MS | Pg. 21 | \$10.93 |
| 28 | 18256 | 1 | BLIND PLUG PG 11 MS | Pg. 11 | \$1.13 |
| 29 | 23926 | 1 | CABLE BUSHING PG 9 | Pg. 9 | \$1.90 |
| 30 | 25056 | 1 | CABLE BUSHING PG 7 | Pg. 7 | \$1.61 |
| 31 | 38546 | 1 | STARTING CAPACITOR 60MF XE301 220V XE701 | 60 mF | \$45.97 |
| 32 | 42766 | 1 | RUN CAPACITOR | 20 mF | \$105.31 |
| 33 | 18906 | 1 | PIPE CLAMP | | \$1.90 |
| (34*) | 10991 | 1 | Conductor (black) | | \$0.00 |
| (35*) | 11021 | 1 | INSOLATING TUBE 4.2X0.6 | | \$2.49 |
| 36 | 18276 | 1 | BLIND PLUG PG 16 MS | Pg. 16 | \$1.51 |
| 37 | 33156 | 1 | SOCKET HEAD CAP SCREW M5X16 | M5x15 | \$0.50 |
| 38 | 17016 | 1 | CHEESE HEAD SKREW M3X12 DIN 84 | M3x12 | \$0.07 |
| 39 | 10236 | 1 | CHEESE HEAD SCREW M5X8 DIN84 | M5x8 | \$0.39 |
| 40 | 33126 | 1 | CHEESE HEAD SCREW M4X10 DIN84 | M4x10 | \$0.26 |
| 41 | 7536 | 1 | HEXAGON HEAD CAP SCREW 6X12 DIN 933 | M6x12 | \$1.05 |
| 43 | 16616 | 1 | SPRING WASHER A6 DIN 127 | A6 | \$0.13 |
| 44 | 16246 | 1 | SPRING WASHER DIA.5 DIN 127 | A5 | \$0.13 |
| 45 | 456 | 1 | Washer | A6.4 | \$0.00 |
| 46 | 23616 | 1 | HEXAGON NUT M5 DIN 934 | M5 | \$0.26 |
| 47 | 44466 | 1 | Label "UP" | | \$0.00 |
| 48 | 44476 | 1 | Label "DOWN" | | \$0.00 |






Spare Parts

XE301P - 220V/1ph. - Direct


220V / 1ph. / 60Hz
GG 13/10.3

Wiring Diagram #19219
Plan #19220

Drawing No E - 3061
Edition US-1
Date 1/05
Page 2 / 2




XE 301P 110V Direct




| | | | | | | | | | | | | | |
|---|---|--|------------------------------|---|---|--|------------------------------|---|--|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| A | Betriebsmittel | | Benennung | | Betriebsmittel | | Benennung | | Erläuterung: Kontaktdarstellung + Kontaktspiegel | | | | |
| | Kennzeichnung | | und Verwendung | | Kennzeichnung | | und Verwendung | | explanation: contact representation + contact configuration | | | | |
| | nach DIN 40719 /2 | | | | nach DIN 40719 /2 | | | | explication: contact presentation + contact formation | | | | |
| | material specification according to DIN 40719/2 | | specification and use | | material specification according to DIN 40719/2 | | specification and use | | | | | | |
| | specification du matériel selon DIN 40719/2 | | specification et destination | | specification du matériel selon DIN 40719/2 | | specification et destination | | | | | | |
| B | CA | Anlaufkondensator starting capacitor condensateur de demarage | | | 1X1 | Netzanschlußstecker current supply connector commut. des tensions d'aliment. | | | <div>Kontaktdarstellung contact representation contact presentation</div> <div><div>K 1 2</div><div>Schließer make contact contact de fermer</div></div> <div><div>K 21 22</div><div>Öffner break contact contact de ouvrir</div></div> <div>Kontaktspiegel contact configuration contact formation</div> <div><div>(1.4) 2L</div><div><div>A1</div><div>A2</div></div><div><div>Blatt Nr. page no. page no.</div><div>Blatt Nr. page no. page no.</div><div>Strompfad Nr. index at top of page no. de trajet du courant</div><div>Blatt Nr. page no. page no.</div><div>Strompfad Nr. index at top of page no. de trajet du cour</div><div>Kontakt Nr. contact no. no. de contact</div><div>Schließer make contact contact de fermer</div><div>Öffner break contact contact de ouvrir</div></div></div> | | | | |
| | CB1 + CB2 | Betriebskondensator run capacitor condensateur de marche | | | Y1 | Brems brake frein | | | | | | | |
| | F1 | Steuersicherung control fuse commande fusible | | | | | | | | | | | |
| | F2 | Bim.Stator bim.stator sonde stator | | | | | | | | | | | |
| | K1 | Schütz "Auf" contactor "up" contacteur "montee" | | | | | | | | | | | |
| | K2 | Schütz "Ab" contactor "down" contacteur "descente" | | | | | | | | | | | |
| | K3 | Hauptschütz main contactor contacteur principal | | | | | | | | | | | |
| | M1 | Motorklemmbrett motor terminal board moteur planche a bornes | | | | | | | | | | | |
| | S0 | Taster "Not Aus" push button "emergency stop" bouton "arret d'urgence" | | | | | | | | | | | |
| | S5 | Taster "Auf" push button "up" bouton "montee" | | | | | | | | | | | |
| D | S6 | Taster "Ab" push button "down" bouton "descente" | | | | | | | | | | | |
| | S16 | Fliehkraftschalter centrifugal switch interrupteur centrifugal | | | | | | | | | | | |
| | U1 | Brückengleichrichter bridge rectifier redresseur | | | | | | | | | | | |
| | X | Klemmleiste connector block plate de borne | | | | | | | | | | | |
| | tirak mono phase with 100V control voltage / tirak mono phase avec tension de commande 100V | | | | | | | | | | | | |
| E | Datum | | 10.06.1997 | | Name | | Neu. | | Greifzug GmbH | | | | |
| | Zustand | | Anderung | | Datum | | Name | | Tirak, Wechselstrom (Motor UBE80/11-4F) XE301P 100V/60Hz Stromlaufplan für GG13/10.14 | | | | |
| | Zustand | | Anderung | | Datum | | Name | | wiring diagram schema de connection | | | | |
| | Zustand | | Anderung | | Datum | | Name | | Gruppe: 27885 | | | | |
| | Zustand | | Anderung | | Datum | | Name | | Blatt: 2 von: 2 | | | | |
| F | Laufwerk 1 Dos 613101 | | | | | | | | | | | | |
| | Blatt Nr. von Nr. page no. of no. page no. par no. | | | | | | | | | | | | |
| | Blatt Nr. von Nr. page no. of no. page no. par no. | | | | | | | | | | | | |
| | Blatt Nr. von Nr. page no. of no. page no. par no. | | | | | | | | | | | | |
| | Blatt Nr. von Nr. page no. of no. page no. par no. | | | | | | | | | | | | |

XE 301P 110V Pendant



| | | | | | | | | | | | | | |
|---|--|------------------------------|--|---|---|------------------------------|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| Betriebsmittel | | Benennung | | Betriebsmittel | | Benennung | | Erläuterung: Kontaktdarstellung + Kontaktspiegel | | | | | |
| Kennzeichnung | | und Verwendung | | Kennzeichnung | | und Verwendung | | explanation: contact representation + contact configuration | | | | | |
| nach DIN 40719 /2 | | | | nach DIN 40719 /2 | | | | explication: contact presentation + contact formation | | | | | |
| material specification according to DIN 40719/2 | | specification and use | | material specification according to DIN 40719/2 | | specification and use | | | | | | | |
| specification du materiel selon DIN 40719/2 | | specification et destination | | specification du materiel selon DIN 40719/2 | | specification et destination | | | | | | | |
| CA | Anlaufkondensator starting capacitor condensateur de demarage | 1X1 | Netzanschlußstecker current supply connector commut. des tensions d'aliment. | | | | | | | | | | |
| CB1 + CB2 | Betriebskondensator run capacitor condensateur de marche | Y1 | Bremse brake frein | | | | | | | | | | |
| F1 | Steuersicherung control fuse commande fusible | | | | | | | | | | | | |
| F2 | Bim.Stator bim.stator sonde stator | | | | | | | | | | | | |
| K1 | Schütz "Auf" contactor "up" contacteur "montee" | | | | | | | | | | | | |
| K2 | Schütz "Ab" contactor "down" contacteur "descente" | | | | | | | | | | | | |
| K3 | Hauptschütz main contactor contacteur principal | | | | | | | | | | | | |
| M1 | Motorklemmbrett motor terminal board moteur planche a bornes | | | | | | | | | | | | |
| S0 | Taster "Not Aus" push button "emergency stop" bouton "arret d'urgence" | | | | | | | | | | | | |
| S5 | Taster "Auf" push button "up" bouton "montee" | | | | | | | | | | | | |
| S6 | Taster "Ab" push button "down" bouton "descente" | | | | | | | | | | | | |
| S16 | Fliehkraftschalter centrifugal switch interrupteur centrifugal | | | | | | | | | | | | |
| U1 | Brückengleichrichter bridge rectifier redresseur | | | | | | | | | | | | |
| X | Klemmleiste connector block plate de borne | | | | | | | | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> | | | | | |
| | | | | | | | | <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schließer make contact contact de fermer</div> <div>K 21 22 Öffner break contact contact de ouvrir</div> <div>K Kontaktdarstellung contact representation contact presentation</div> <div>K 1 2 2 22 Schlie</div> | | | | | |



| | | | | | | | | | | | | | |
|---|---|--|---|---|--|--|---------|---|---|----|----|------------------|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| A | Betriebsmittel | Benennung | Betriebsmittel | Benennung | Erläuterung: Kontaktdarstellung + Kontaktspiegel | | | | | | | | |
| | Kennzeichnung | und Verwendung | Kennzeichnung | und Verwendung | explanation: contact representation + contact configuration | | | | | | | | |
| | nach DIN 40719 /2 | | nach DIN 40719 /2 | | explication: contact presentation + contact formation | | | | | | | | |
| | material specification according to DIN 40719/2 | soecification and use | material specification according to DIN 40719/2 | specification and use | <div>Kontaktdarstellung contact representation contact presentation</div> <div><div><div>K</div><div>11</div><div>2</div></div><div>Schließer make contact contact de fermer</div></div> <div><div><div>K</div><div>21</div><div>22</div></div><div>Öffner break contact contact de ouvrir</div></div> <div>Kontaktspiegel contact configuration contact formation</div> <div><div><div>(1.4)</div><div>2L</div></div><div><div><div>Blatt Nr. page no. page no.</div><div>Strompfad Nr. index at top of page no.de trajet du courant</div></div><div><div><div>1.8</div><div>1</div><div>2</div></div><div><div>1.8</div><div>3</div><div>4</div></div><div><div>1.8</div><div>5</div><div>6</div></div><div><div>1.8</div><div>61</div><div>62</div></div><div><div>1.8</div><div>13</div><div>14</div></div></div><div><div>—Blatt Nr. page no. page no.</div><div>—Strompfad Nr. index at top of page no.de trajet du cour.</div><div>—Kontakt Nr. contact no. no.de contact</div><div>—Schließer make contact contact de fermer</div><div>—Öffner break contact contact de ouvrir</div></div></div></div> | | | | | | | | |
| | specification du matériel selon DIN 40719/2 | specification et destination | specification du matériel selon DIN 40719/2 | specification et destination | | | | | | | | | |
| B | CA | Anlaufkondensator starting capacitor condensateur de demarage | 1X1 | Netzanschlußstecker current supply connector commut.des tensions d'aliment. | <div>Strompfad Nr. index at top of page no.de trajet du courant</div> | | | | | | | | |
| | CB | Betriebskondensator run capacitor condensateur de marche | Y1 | Bremse brake frein | | | | | | | | | |
| | F1 | Steuersicherung control fuse commande fusible | | | | | | | | | | | |
| | F2 | Bim.Stator bim.stator sonde stator | | | | | | | | | | | |
| | K1 | Schütz "Auf" contactor "up" contacteur "montee" | | | | | | | | | | | |
| C | K2 | Schütz "Ab" contactor "down" contacteur "descente" | | | <div>Blatt Nr. page no. page no.</div> <div><div><div>Strompfad Nr. index at top of page no.de trajet du courant</div><div><div>1.8</div><div>1</div><div>2</div></div><div><div>1.8</div><div>3</div><div>4</div></div><div><div>1.8</div><div>5</div><div>6</div></div><div><div>1.8</div><div>61</div><div>62</div></div><div><div>1.8</div><div>13</div><div>14</div></div></div><div><div>—Blatt Nr. page no. page no.</div><div>—Strompfad Nr. index at top of page no.de trajet du cour.</div><div>—Kontakt Nr. contact no. no.de contact</div><div>—Schließer make contact contact de fermer</div><div>—Öffner break contact contact de ouvrir</div></div></div> | | | | | | | | |
| | K3 | Hauptschütz main contactor contacteur principal | | | | | | | | | | | |
| | M1 | Motorklemmbrett motor terminal board moteur planche a bornes | | | | | | | | | | | |
| | S0 | Taster "Not Aus" push button "emergency stop" bouton "arret d'urgence" | | | | | | | | | | | |
| | S5 | Taster "Auf" push button "up" bouton "montee" | | | | | | | | | | | |
| D | S6 | Taster "Ab" push button "down" bouton "descente" | | | <div>Blatt Nr. page no. page no.</div> <div><div><div>Strompfad Nr. index at top of page no.de trajet du courant</div><div><div>1.8</div><div>1</div><div>2</div></div><div><div>1.8</div><div>3</div><div>4</div></div><div><div>1.8</div><div>5</div><div>6</div></div><div><div>1.8</div><div>61</div><div>62</div></div><div><div>1.8</div><div>13</div><div>14</div></div></div><div><div>—Blatt Nr. page no. page no.</div><div>—Strompfad Nr. index at top of page no.de trajet du cour.</div><div>—Kontakt Nr. contact no. no.de contact</div><div>—Schließer make contact contact de fermer</div><div>—Öffner break contact contact de ouvrir</div></div></div> | | | | | | | | |
| | S16 | Fliehkraftschalter centrifugal switch interrupteur centrifugal | | | | | | | | | | | |
| | U1 | Brückengleichrichter bridge rectifier redresseur | | | | | | | | | | | |
| | X | Klemmleiste connector block plate de borne | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| E | | | | | <div>Blatt Nr. page no. page no.</div> <div><div><div>Strompfad Nr. index at top of page no.de trajet du courant</div><div><div>1.8</div><div>1</div><div>2</div></div><div><div>1.8</div><div>3</div><div>4</div></div><div><div>1.8</div><div>5</div><div>6</div></div><div><div>1.8</div><div>61</div><div>62</div></div><div><div>1.8</div><div>13</div><div>14</div></div></div><div><div>—Blatt Nr. page no. page no.</div><div>—Strompfad Nr. index at top of page no.de trajet du cour.</div><div>—Kontakt Nr. contact no. no.de contact</div><div>—Schließer make contact contact de fermer</div><div>—Öffner break contact contact de ouvrir</div></div></div> | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| F | | | | | <div>Blatt Nr. page no. page no.</div> <div><div><div>Strompfad Nr. index at top of page no.de trajet du courant</div><div><div>1.8</div><div>1</div><div>2</div></div><div><div>1.8</div><div>3</div><div>4</div></div><div><div>1.8</div><div>5</div><div>6</div></div><div><div>1.8</div><div>61</div><div>62</div></div><div><div>1.8</div><div>13</div><div>14</div></div></div><div><div>—Blatt Nr. page no. page no.</div><div>—Strompfad Nr. index at top of page no.de trajet du cour.</div><div>—Kontakt Nr. contact no. no.de contact</div><div>—Schließer make contact contact de fermer</div><div>—Öffner break contact contact de ouvrir</div></div></div> | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| tirak mono phase with 200V control voltage / tirak mono phase avec tension de commande 200V | | | | | | | | | | | | | |
| | | Datum 09.06.1997 | GREIFZUG GMBH | | | Tirak, Wechselstrom (Motor UBE80/11-4F) XE301P 200V/60Hz Stromlaufplan für G613/10.3 | | | wiring diagram schema de connection | | | Gruppe: 19221 | |
| | | Name Neu. | | | | | | | | | | | |
| | | Gepr. | | | | | | | | | | | |
| Zustand | Änderung | Datum | Name | Norm | Urspr. | Ers. f. | Ers. d. | | | | | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |


Laufwerk *

Dos G61310

Gruppe:

von: 2

| | | | | | | |
|------------------|---|----------------------|----|--------|----------|----|
| 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| Steuerspannung | | Hauptschütz | | Auf | Ab | |
| control voltage | | main contactor | | up | down | |
| commande voltage | | contacteur principal | | montee | descente | |
| 200V~ | | | | | | |



| | | | | | | | | | | | | |
|------------------|---|---|---|--|--|-----------------------|---|--|--------|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 |
| A | Betriebsmittel | Benennung | Betriebsmittel | Benennung | Erläuterung: Kontaktdarstellung + Kontaktspiegel | | | | | | | |
| | Kennzeichnung | und Verwendung | Kennzeichnung | und Verwendung | explanation: contact representation + contact configuration | | | | | | | |
| | nach DIN 40719 /2 | | nach DIN 40719 /2 | | explication: contact presentation + contact formation | | | | | | | |
| | material specification according to DIN 40719/2 | specification and use | material specification according to DIN 40719/2 | specification and use | | | | | | | | |
| | specification du materiel selon DIN 40719/2 | specification et destination | specification du materiel selon DIN 40719/2 | specification et destination | | | | | | | | |
| B | CA | Anlaufkondensator starting capacitor condensateur de demarage | 1X1 | Netzanschlußstecker current supply connector commut. des tensions d'aliment. | <div>Kontaktdarstellung contact representation contact presentation</div> <div>K ¹/₂ Schließer make contact contact de fermer</div> <div>K ²¹/₂₂ Öffner break contact contact de ouvrir</div> <div>Kontaktspiegel contact configuration contact formation</div> <div><div>(1.4) 2L</div><div><div>Blatt Nr. page no. page no.</div><div>Strompfad Nr. index at top of page no.de trajet du courant</div><div><div>1.8 1 2 1.8 3 4 1.8 5 6 1.8 61 62 1.13 13 14</div><div><div>10 1 2 11 21 22</div></div></div><div><div>---Blatt Nr. page no. page no.</div><div>---Strompfad Nr. index at top of page no.de trajet du cou.</div><div>---Kontakt Nr. contact no. no.de contact.</div><div>---Schließer make contact contact de fermer</div><div>---Öffner break contact contact de ouvrir</div></div></div></div> | | | | | | | |
| | CB | Betriebskondensator run capacitor condensateur de marche | Y1 | Bremse brake frein | | | | | | | | |
| | F1 | Steuersicherung control fuse commande fusible | | | | | | | | | | |
| | F2 | Bim.Stator bim.stator sonde stator | | | | | | | | | | |
| | K1 | Schütz "Auf" contactor "up" contacteur "montee" | | | | | | | | | | |
| C | K2 | Schütz "Ab" contactor "down" contacteur "descente" | | | | | | | | | | |
| | K3 | Hauptschütz main contactor contacteur principal | | | | | | | | | | |
| | M1 | Motorklemmbrett motor terminal board moteur planche a bornes | | | | | | | | | | |
| | S0 | Taster "Not Aus" push button "emergency stop" bouton "arret d'urgence" | | | | | | | | | | |
| | S5 | Taster "Auf" push button "up" bouton "montee" | | | | | | | | | | |
| D | S6 | Taster "Ab" push button "down" bouton "descente" | | | | | | | | | | |
| | S16 | Fliehkraftschalter centrifugal switch interrupteur centrifugal | | | | | | | | | | |
| | U1 | Brückengleichrichter bridge rectifier redresseur | | | | | | | | | | |
| | X | Klemmleiste connector block plate de borne | | | | | | | | | | |
| | E | tirak mono phase with 200V control voltage / tirak mono phase avec tension de commande 200V | | | | Laufwerk Dos 66131 | | | | | | |
| Date: 09.06.1997 | | | | Tirak, Wechselstrom (Motor UBE80/11-4F) | | | | wiring diagram schema de connection | | | | |
| Name: Neu. | | | | XE301P 200V/60Hz | | | | Gruppe: | | | | |
| Sepr. | | | | Stromlaufplan für G613/10.4 | | | | 31009 | | | | |
| Zustand | | | | Ers. f. | | | | Ers. d. | | | | |
| F | Urspr. | | | | Blatt: 2 | | | | von: 2 | | | |
| | Name | | | | Blatt: 2 | | | | von: 2 | | | |
| | Date | | | | Blatt: 2 | | | | von: 2 | | | |
| | Name | | | | Blatt: 2 | | | | von: 2 | | | |
| | Date | | | | Blatt: 2 | | | | von: 2 | | | |

8-5 Wiring Connection of Stator XE301P




Figure 801

9) WIRE ROPE SPECIFICATION TIRAK

There seems to be some question as to selection of wire rope due to the many people offering wire rope today

Before Tractel chooses a supplier of wire rope we run an endurance test or cycle test to make certain that the rope functions well in the hoist and has good life. The European norms require 1000 cycles minimum, UL testing requires 500 cycles. We require 2000 cycles and test with a high-speed hoist 60 ft./ min. to give a more severe dynamic load to the wire rope during starts and stops. After 2000 cycles we allow a certain number of broken wires (not strands) in a given length of rope. Too many breaks are a test failure. We have no idea how or if other rope suppliers test a rope with our hoist. We generally do not test other peoples ropes because it is time consuming and expensive to conduct. We would be inundated with samples.

5 X 19 vs. 5 X 26 Construction 5 strands of 26 wires have smaller wires making up the strands. This provides greater flexibility but smaller outside wires wear out faster during normal use. Smaller wires are less resistant to abrasion. Therefore we primarily recommend 5 X 19. PI equipment often uses 5 X 26 because winders are part of the system and it coils better.

Quality of Manufacture- If a good control is not made on the tension during manufacture, then a loose strand can occur. This shows when lowering a load. It can cause a jam. Preforming requires that tension be monitored. To get a high quality rope requires that high quality wires be used creating very tight tolerances. A poor zinc plating process can cause slippage. Ropes must be lubricated properly or the friction coefficient is poor between the wire rope and the sheave. There should not be a change in the diameter of the wire rope when worn.

Summary- There is much more to wire rope selection than number of strands and number of wires. Tractel supplies only high quality and rigorously tested wire rope from a very few carefully selected and monitored manufacturers.

9-1 Wire Rope Specifications - XE301P (Page 1 of 2)

| | 1st Choice | 2nd Choice |
|----------------------------------|---|------------|
| Hoist Types: | Tirak | Tirak |
| Construction: | 5 x 19 | 5 x 26 |
| Strands | 5 | 5 |
| Wires per strand | 19 | 26 |
| Core Type | Polypropylene splitfilm | same |
| Type | Warrington Seale | same |
| Diameter: | 8.4 mm +0 -0.3mm{8.1 - 8.4 mm} 5/16" approx. {0.319 - 0.326" } | same |
| Minimum Breaking Load: | 10,000 lbs. [4590 kg] | same |
| Material of Construction: | Galvanized Steel wire rope XIPS 200/220 n/ sq. mm | same |
| Rope Lay: | Right hand Regular Lay | same |
| Lubrication: | Core Lubricated | same |
| Preformed: | Yes | same |

Table 1001

9-1 Wire Rope Specifications - XE301P (Page 2 of 2)



NOTE:

As of 2/15/2002, 5/16" diameter should be used (as taken from various product literature).

| 4 x 26 | 6 x 19 | 6 x 31 | 5 x 19 | 5 x 26 |
|---|--|------------------------------------|--|---|
| Skyclimber CX1250 Compact Alpha1000 | Skyclimber CS1250 IWRC/RC Alpha1500 3/8 | Hilo | Tirak/Saturn all models 1st choice L-series | Skyclimber CX1250 Compact Alpha1000 |
| Tirak 3rd choice T-series X-series | Spider Z-Mac1000 IWRC SC40 IWRC | | | |
| Saturn 3rd choice 35X series 32L series | Power Climber PC400 IWRC/RC Astro IWRC/FC 5/16 or 3/8 | Power Climber PC400 IWRC/FC | | Power Climber PC400, Astro Compacted |
| | Skyman 6 x17 IWRC | Lisbon Hoist 180-050 180-030 | | Tirak/Saturn all models 2nd choice (1st for reelers) L-series |
| | Saturn 4th choice 35X series 32L series | | | |
| | Tirak 4th choice T-series X-series | | | |


Table 1002




GripHoist Division

9-2 Labels and Nameplates

(1) Advice Label (secondary brake operation)
(Please call for pricing)



(4) Emergency Descent Label
(Please call for pricing)




(5) Motor nameplate
Code # 16206



(6) Primary brake nameplate
Code # 16706 \$2.15



(9) Wire rope diameter label
(Please call for pricing)




(10) General Warning & Advice Label
(Please call for pricing)




(2) TIRAK nameplate
Code # 22760 \$8.10




(7) Warning Label (wire rope jam)
(Please call for pricing)



(3) BLOCSTOP nameplate
Code # 25920 \$6.40



(8) BLOCSTOP check plate
(Please call for pricing)



9-3 Checklist



NOTE:

Completion of the checklist MUST always be done before operating the hoist.

TIRAK Hoist Inspection Check List

See Preventive Maintenance Section of instruction manual for details.

Check only components applicable for specific equipment and inspection type.

TIRAK hoist model: _____

Serial-No: _____

| | | YES | NO | | | YES | NO |
|--|--------------------------|--------------------------|--------------------------|---|--------------------------|--------------------------|--------------------------|
| WIRE ROPE HOOKS | | | | WIRE ROPE | | | |
| Cracks | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Broken wires at ends | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Excessive wear | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Broken wires excessive | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Bent | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Excessive wear | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Spreading | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Kinked or distorted | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Latch damaged/missing | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Corrosion | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| BRAKES | | | | OPERATING CONTROLS | | | |
| Motor brake worn or not operating | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Contactor pitting | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Excessive load brake drift or backlash | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Operating properly | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Excessive disc wear | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Damaged Control Box | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| LIMIT SWITCHES | | | | LUBRICATION | | | |
| Operating properly | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Oil leaks | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| HOUSING | | | | LABELS | | | |
| Distorted | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Missing | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Cracks | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Illegible | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Loose hardware | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | DRUM & SHEAVES | | | |
| Beating noise | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Worn excessively | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| WIRING | | | | SUPPORTING STRUCTURE | | | |
| Loose connections | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Continued ability to support imposed load | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Frayed | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Worn or distorted parts | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Damaged | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | |
| Proper grounding | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | |

NOTE: IF ANY () IS CHECKED DO NOT OPERATE THE HOIST UNTIL REPAIRS HAVE BEEN MADE!

Remarks and repairs made: _____

Signature: _____

Date: _____

Clock Number: _____



Griphoist Division

9-4 Hoist Specification LE501P1




Figure 1001

| | | |
|--|------------|--|
| Wire rope classification/construction | | 5x19 or 5x26 with fiber core lubricated, preformed IPS or XIPS |
| nominal diameter | <i>in.</i> | 5/16 in. |
| | <i>mm</i> | 8.4 mm |
| maximum allowed diameter tolerances | <i>in.</i> | 0.319 to 0.331 |
| | <i>mm</i> | 8.1 to 8.4 |
| minimum actual breaking strength | <i>lbs</i> | 10,000 |
| | <i>kN</i> | 44.5 |

Table 1003

| | | | |
|---|--------|-----|---------|
| Hoist Model | | | XE301P |
| with BLOCSTOP model | | | BSO 500 |
| Rated Load | lbs | | 700.0 |
| | kg | | 300.0 |
| Lifting Speed | ft/min | | 35.0 |
| | m/min | | 11.0 |
| Weight (with BSO) | lbs | | 77.0 |
| | kg | | 35.0 |
| Dimensions over all | a | in. | 28.9 |
| | | mm | 735.0 |
| | b | in. | 11.2 |
| | | mm | 286.0 |
| | c | in. | 12.5 |
| | | mm | 314.0 |
| Motor Specifications | | | |
| Single phase 110V / 60 cycles | Kw | | |
| | A | | 10.5 |
| Single phase 220V / 60 cycles | Kw | | |
| | A | | 5.2 |
| wire rope diameter | in. | | 5/16" |
| | mm | | 8.4 |
| Misc. Info: | | | |
| - Hoist shall self reeve the wire rope | | | |
| - Continuously duty motor TEFC | | | |
| - Secondary brake shall be externally attached to the hoist mechanism. | | | |
| - Emergency lowering without power shall be by means of a mechanical centrifugal brake. | | | |

TRACTEL Inc
GRIPHOIST Division
110, Shawmut Road
Canton, MA 02021
Tel: 800-421-0246
Fax: 781-828 3642
griphoist.usa@tractel.com

TRACTEL LTD
GRIPHOIST Division
11020 Mirabeau St
Anjou QUEBEC, H1J 2S3
Tel. +1 (514) 493 3332
Fax. +1 (514) 493 3342
griphoist.canada@tractel.com

TRACTEL Inc
GRIPHOIST Division
Branch Office: 315 Cloverleaf Dr.
Building E Baldwin Park CA 91706
Tel. +1 (626) 937 6727
Fax. +1 (626) 937 6730

© Copyright - All rights reserved

