




INSTRUCTION MANUAL

651200700E

QQQT
Quad QPSK/QAM Transcoder
Stock No. 6189A



The Standard of Quality in TV Signal Distribution

One Jake Brown Road, P.O. Box 1000
Old Bridge, NJ 08857-1000 USA
(800) 523-6049 • (732) 679-4000 • FAX: (732) 679-4353
www.blondertongue.com

QPSK/QAM Transcoder Instruction Manual

We recommend that you write the following information in the spaces provided below.

Purchase Location Name:	
Purchase Location Telephone Number:	
Transcoder Digital Address:	

The information contained herein is subject to change without notice. Revisions may be issued to advise of such changes and/or additions.

Correspondence regarding this publication should be addressed directly to:

Blonder Tongue Laboratories, Inc.
One Jake Brown Road
Old Bridge, NJ 08857

Document Number: 651200700


Printed in the United States of America.

All product names, trade names, or corporate names mentioned in this document are acknowledged to be the proprietary property of the registered owners.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Reverse engineering or disassembly is prohibited. ©2001 Blonder Tongue Laboratories, Inc. All Rights Reserved.


QPSK/QAM Transcoder Instruction Manual

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.



CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER FROM THIS UNIT. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO PREVENT SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE

NOTE TO CATV INSTALLERS

This reminder is provided to call the CATV System Installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

<i>Table of Contents</i>	Page
Introduction	5
The Unit	5
Front Panel	5
Rear Panel	5
Programming the Unit	6
Understanding the Switch Functionality	6
Programming the Unit Input	6
Programming the Unit Output	7
Installing the Transcoder	8
Installing the Transcoder in a Rack	8
Optional Remote Monitoring & Control Software	8
Technical Specifications	9
Stacked LNB Splitter Tree	10
Dual LNB Splitter Tree	11
Troubleshooting	12
QAM Signal Level Testing	12
Appendix A - L-Band Frequencies	12
Appendix B - CATV Channel Frequency Chart 121 MHz to 750 MHz	13
Appendix C - Dish Network™ Stacked LNB System Application Examples	14
Appendix D - Rear Headend Diagram	17
Limited Warranty	18


QPSK/QAM Transcoder Instruction Manual

Safety Instructions



You should always follow these instructions to help ensure against injury to yourself and damage to your equipment.

- ◆ Read all safety and operating instructions before you operate the transcoder.
- ◆ Retain all safety and operating instructions for future reference.
- ◆ Heed all warnings on the transcoder and in the safety and operating instructions.
- ◆ Follow all installation, operating, and use instructions.
- ◆ Unplug the transcoder from the AC power outlet before cleaning. Use only a damp cloth for cleaning the exterior of the transcoder.
- ◆ Do not use accessories or attachments not recommended by Blonder Tongue, as they may cause hazards, and will void the warranty.
- ◆ Do not operate the transcoder in high-humidity areas, or expose it to water or moisture.
- ◆ Do not place the transcoder on an unstable cart, stand, tripod, bracket, or table. The transcoder may fall, causing serious personal injury and damage to the transcoder. Install the transcoder only in a mounting rack designed for 19" rack-mounted equipment.
- ◆ Do not block or cover slots and openings in the transcoder. These are provided for ventilation and protection from overheating. Never place the transcoder near or over a radiator or heat register. Do not place the transcoder in an enclosure such as a cabinet without proper ventilation. Do not mount equipment in the rack space directly above or below the transcoder.
- ◆ Operate the transcoder using only the type of power source indicated on the marking label. Unplug the transcoder power cord by gripping the plug, not the cord.
- ◆ The transcoder is equipped with a three-wire ground-type plug. This plug will fit only into a ground-type power outlet. If you are unable to insert the plug into the outlet, contact an electrician to replace the outlet. Do not defeat the safety purpose of the ground-type plug.
- ◆ Route power supply cords so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the unit.
- ◆ Be sure that the outdoor components of the antenna system are grounded in accordance with local, federal, and National Electrical Code (NEC) requirements. Pay special attention to NEC Sections 810 and 820. See the example shown in the following diagram:



QPSK/QAM Transcoder Instruction Manual

Safety Instructions - continued

- ◆ We strongly recommend using an outlet that contains surge suppression or ground fault protection. For added protection during a lightning storm, or when the transcoder is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the lines between the transcoder and the antenna. This will prevent damage caused by lightning or power line surges.
- ◆ Do not locate the antenna near overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing the antenna, take extreme care to avoid touching such power lines or circuits, as contact with them can be fatal.
- ◆ Do not overload wall outlets or extension cords, as this can result in a risk of fire or electrical shock.
- ◆ Never insert objects of any kind into the transcoder through openings, as the objects may touch dangerous voltage points or short out parts. This could cause fire or electrical shock.
- ◆ Do not attempt to service the transcoder yourself, as opening or removing covers may expose you to dangerous voltage and will void the warranty. Refer all servicing to authorized service personnel.
- ◆ Unplug the transcoder from the wall outlet and refer servicing to authorized service personnel whenever the following occurs:
 - The power supply cord or plug is damaged;
 - Liquid has been spilled, or objects have fallen into the transcoder;
 - The transcoder has been exposed to rain or water;
 - The transcoder has been dropped or the chassis has been damaged;
 - The transcoder exhibits a distinct change in performance.
- ◆ When replacement parts are required, ensure that the service technician uses replacement parts specified by Blonder Tongue. Unauthorized substitutions may damage the transcoder or cause electrical shock or fire, and will void the warranty.
- ◆ Upon completion of any service or repair to the transcoder, ask the service technician to perform safety checks to ensure that the transcoder is in proper operating condition.


QPSK/QAM Transcoder Instruction Manual

Introduction

The QOQT is designed to transcode an existing 30 MHz digital QPSK satellite signal to a 6 MHz QAM signal. The unit is used in conjunction with QAM set-top decoders that are designed to be compatible with EchoStar™ DVB Satellite signals. For convenience of installation, the chassis fits into a standard 19" wide by 1.75" high rack mount.


The Unit

Front Panel



1. **Power LED** - Indicates power to the unit
2. **Signal Status LED** - a) A solid green LED indicates locked signal
b) A non-lit green LED indicates a loss of QPSK signal lock
c) A flashing green LED indicates the QAM signal was shut off remotely
3. **Output Level** - A POT adjustment to increase or decrease the level of the output gain with a 10 dB range.
4. **Input CH Button** - Used to set the unit input information (transponder)
5. **Output CH Button** - Used to set the unit output information (channel)
6. **Reset Button** - Used to reset the unit input and output information to the previously programmed state
7. **Channel Selector Digit 1** - Thumbwheel switch used to set the unit transcoder number information
8. **Channel Selector Digit 2, 3, & 4** - Thumbwheel switches used to set the input transponder and output channel
9. **Input Channel Label** - To be filled in at installation for reference
10. **Output Channel Label** - To be filled in at installation for reference
11. **Verify LED** - a) A brief solid green LED flash will indicate the unit accepted an input entry
b) A continuous flashing green LED will indicate an invalid entry
12. **Unit Identification Label** - Each QOQT unit is assigned a unique identification number. This I.D. number is used with the Optional Remote Monitoring & Control Software.

Rear Panel



1. **Power Cord Socket** - The unit power cord plug socket
2. **RS 232 Serial Data Ports** - Used to plug into and daisy chain the QOQT units for remote monitoring and configuration
3. **-20 dB Test Point** - Convenient 75Ω RF point to test output signal
4. **QAM CATV RF Output** - A combined 4 channel QAM output signal
5. **QPSK RF Input** - 4 Independent 75Ω RF connectors for feeding the appropriate QPSK satellite input signal
6. **Fuse** - .75 Amp, 250V, Slo Blo fuse
7. **Unit Identification Label** - Each QOQT unit is assigned a unique identification number. This I.D. number is used with the Optional Remote Monitoring & Control Software.

QPSK/QAM Transcoder Instruction Manual

Programming the Unit

Understanding the Switch Functionality

Reset

Depressing the RESET button will reload all of the unit output channels and transponder settings from the unit's memory. The previous programmed state for all 4 transcoder sections is stored in non-volatile memory.

Channel Selector

Stacked LNB Feed

The first digit (Digit 1) of the Channel Selector thumbwheel switch is used to select the corresponding QOQT transcoder section. Digit 1 numbers 1 to 4 are used for Stacked LNB feed for transcoders 1 to 4 respectively. Digit 2 remains a 0 (zero). (i.e., Select 1 for transcoder 1 with a stacked LNB feed).

Note: Refer to Appendix A for detailed transponder frequency range.

Dual LNB Feed

The first digit (Digit 1) of the Channel Selector thumbwheel switch is used to select the corresponding QOQT transcoder section. Digit 1 numbers 5 to 8 are used for a Dual LNB feed for transcoders 1 to 4 respectively. Digit 2 remains a 0 (zero). (i.e., Select 5 for transcoder 1 with a dual LNB feed).

Note: Refer to Appendix A for detailed transponder frequency range.

NAS Stacker Feed

The second digit (Digit 2) is used to indicate a NAS Stacker Feed. Set the Digit 2 switch to 9. The first digit (Digit 1) of the Channel Selector thumbwheel switch is then used to select the corresponding QOQT transcoder section. Digit 1 numbers 1 to 4 are used for NAS Stacker feed for transcoders 1 to 4 respectively. (i.e., Select 1 in Digit 1 and 9 in Digit 2 for a NAS Stacked Feed.)

Note: Refer to Appendix A for detailed transponder frequency range.

The last 3 digits (Digits 2, 3 and 4) of the Channel Selector thumbwheel switch are used to select the appropriate satellite transponder or the corresponding output channel. (i.e., Select 05 for transponder 5 and 078 for CATV channel 78).


Note: Refer to Appendix B for CATV Channel Frequency Chart, 121 MHz to 750 MHz, Channels 14-116. Channel 95-99 are not used since the frequency range is not within 121-750 MHz.

Programming the Unit Input

1. Set the appropriate transcoder section.
2. Set the appropriate satellite transponder section.
(Adjust the Channel Selector thumbwheel switches as instructed above).
3. Press the INPUT CH button for the QOQT unit to accept your selection.
4. The green VERIFY indicator will light briefly to indicate that the unit accepted your input. If the green VERIFY LED flashes continuously, it indicates an inappropriate transponder number entry was made and was not accepted by the unit. Repeat Steps 1 thru 4 again for each of the 4 transcoder sections.

☞ Record the input channel transponder information on the white INPUT CH square for future reference.

Stacked LNB Feed




This example shows Transcoder #1 is tuned to Transponder #3 after depressing the INPUT CH button.

QPSK/QAM Transcoder Instruction Manual


Programming the Unit Input - continued

Dual LNB Feed



This example shows Transcoder #2 is tuned to Transponder #12 after depressing the INPUT CH button.

NAS Stacker Feed



This example shows Transcoder #2 is tuned to Transponder #4 after depressing the INPUT CH button.

CAUTION


Do not leave the unit set with a zero in Digit 1 of the Channel Selector thumbwheel switch. The verification of this setting will cause the QQQT to be put into a manufacturing test condition that can only be reset by recycling power to the unit.

Programming the Unit Output

1. Set the appropriate transcoder section.
2. Set the appropriate Output Channel number on the Channel Selector thumbwheel switch. The available channel tuning range is EIA channel 14-116 (the corresponding CATV channel frequency, 121 to 750 MHz, will be automatically set. Refer to Appendix B for details.). Channel 95-99 are not used since the frequency range is not within 121-750 MHz.
3. Press the OUTPUT CH button for the QQQT unit to accept your selection.
4. The green VERIFY indicator will light briefly to indicate that the unit accepted your input. If the green VERIFY LED flashes continuously, it indicates an out of range channel number entry was made and was not accepted by the unit.

Repeat Steps 1 thru 4 again for each of the 4 sections.

 *Record the output channel*



This example shows Transcoder #4 is tuned to Output Channel #38 after depressing the OUTPUT CH button.

Note: When adjusting Output Channel information of the Channel Selector thumbwheel switch, Digit 1 numbers 1-4 are only used to represent the appropriate transcoder section.

CAUTION

Do not leave the unit set with a zero in digit 1 of the Channel Selector thumbwheel switch. The verification of this setting will cause the QQQT to be put into a manufacturing test condition that can only be reset by recycling power to the unit.

QPSK/QAM Transcoder Instruction Manual

Installing the Transcoder

Installing the Transcoder in a Rack

Mounting

The transcoder is 1.75 inches tall, 19 inches wide, and 19 inches deep.

You can mount the transcoder in a standard EIA, 24 inch (610 mm) deep, enclosed rack. Secure the transcoder front panel to the rack by inserting four machine screws, with cup washers, through the four mounting holes in the front panel.

 *Do not block the fan on the side of the transcoder, or any of the unit's ventilation holes.*

ATTENTION!



Blonder Tongue strongly recommends using a vented blank front panel to aid in air circulation. This part, Stock No. 3988, Model name BFP-19V is available from the Blonder Tongue factory.

CAUTION

Failure to have at least one empty 1.75" rack space between each transcoder when mounting several QQQT units together will void the manufacturers warranty.

We recommend that you support the transcoder by some means in addition to the front panel screws. You can use rear rail support brackets or rack slides. Rear rail support brackets are available from Blonder Tongue at a nominal cost. (Order PN 622280100A)

Power

60 Hz, 90 to 265 VAC

WARNING!



For safe and reliable operation, the transcoder requires a proper ground connection for the third prong of the transcoder power cord plug.

Optional Remote Monitoring & Control Software

An optional Remote Monitoring & Control Software package is available from Blonder Tongue. This custom software application is designed to be used for the ability to monitor and configure a QQQT headend. The software is a program that can be used locally in the direct mode via a null modem cable or remotely in the dial out mode using a standard modem at the headend.

The software features a user friendly graphical interface and is compatible with widely available Windows® 95/98 based computers. It gives the operator the ability to purchase an individual headend license and create a unique file for each independent Triple QT headend. The operator can then access the software to monitor, control and configure the Triple QT units. The QAM output signal can be remotely turned off allowing the operator the ability to "remotely heal" a problem transcoder channel by shutting it down and activating a spare transcoder. The transponder signal from the problem transcoder can be activated on the spare and the output QAM signal placed on any available output channel within the unit range. A Non-modem Starter Kit is included, consisting of 12 Data Cables, 1 Null Modem and Adapter and a QQQT Headend Modem Adapter with the purchase of each Headend Software License. Sample data cable wiring is demonstrated on the rear headend diagram, Appendix D.

This option can be ordered from Blonder Tongue as Stock No. 2701, Model name QQQT-RMCS.

QPSK/QAM Transcoder Instruction Manual

Technical Specifications

QPSK Input (4 Input Ports)	Item	Unit
Input Frequency Range:	920 - 2150	MHz
Frequency Step:	1	MHz
Capture Range:	±5	MHz
Input Level Range:	-65 to -25	dBm
RF Input Impedance:	75Ω	QPSK
Input Feed:	Stacked/Dual LNB	
Decoding:	DVB	
IF Bandwidth:	36	MHz
Symbol Rate	1 to 45	Msym/sec
Code Rate for DVB:	1/2, 2/3, 3/4, 5/6, 7/8	Viterbi Auto Recognition
I - Q Format:	Normal/Inverted	

QAM RF Output (1 Output Port)

Modulation:	16, 32, 64, 128, 256	QAM
Symbol Rate:	5, Max. 7	Msym/sec
Bandwidth:	6	MHz
Spectral Inversion:	Auto Recognition	
Carrier Suppression:	45	dB
Roll Off:	15	%
S/N:	>40	dB
I - Q Offset:	<1	Degrees
RF Output Impedance:	75Ω	Combined QAM
Frequency Range:	121 - 750	MHz
Frequency Step:	1	MHz
Output Level:	+40	dBmV
Spurious:	-60	dBc
Broadband Noise:	-75	dBc

Power

Requirement:	90 to 265	VAC
Frequency:	50 to 60	Hz
Power Consumption:	40	Watts
Operating Temperature:	0 to 50	°C

Physical

Dimensions:	19" x 1.75" x 19 (max) inches, (482.6 x 44.4 x 482.6 mm)	W x H x D
Operating Temperature:	32 to 122° F, (0 to 50°C)	
Storage Temperature:	-4 to 158°F, (-20 to 70°C)	
Humidity:	0 to 90% RH (non-condensing)	
Mounting:	Standard 1 unit high EIA 1.75", 19" wide rack mount	


Agency Approvals

Safety:	UL Listed 1409	
---------	----------------	--

QPSK/QAM Transcoder Instruction Manual


Stacked LNB Splitter Tree

119° - 21 Transponders




Parts List	
LPD-4	#6411
LA-922-15	#6407
LPD-8	#6415
LPI-122 PS	#6446
LPI-2200	#6424
LPI-188 PS	#6430

110° - 29 Transponders




61.5° - 19 Transponders



Drawings are samples for illustration purposes only

QPSK/QAM Transcoder Instruction Manual

Dual LNB Splitter Tree



Drawings are samples for illustration purposes only

QPSK/QAM Transcoder Instruction Manual

Troubleshooting

QAM Signal Level Testing

Due to the fact that the output channel is a complete high-frequency modulation signal using the full 6 MHz spectrum, a typical spectrum analyzer is unable to read the true amplitude of the signal since it does not have a 6 MHz setting. It is therefore necessary to make measurements at lower frequencies and normalize (compensate) the results with the following table:

Spectrum Analyzer Bandwidth	Add to Correct to 6 MHz BW
300 KHz	13 dB
1 MHz	7.8 dB
3 MHz	3 dB

Appendix A

L-Band Frequencies

Transponder No	Dual Feed Frequency (MHz)	Polarity Voltage	Switching Voltage (VDC) (Optimal)	Cal Amp Stacked Frequency (MHz)	NAS Stacked Frequency Inverted Spectrum (MHz)
1	974.00	RHCP	13	974.00	974.00
2	988.58	LHCP	18	1563.58	1986.42
3	1003.16	RHCP	13	1003.16	1003.16
4	1017.74	LHCP	18	1592.74	1957.26
5	1032.32	RHCP	13	1032.32	1032.32
6	1046.90	LHCP	18	1621.90	1928.10
7	1061.48	RHCP	13	1061.48	1061.48
8	1076.06	LHCP	18	1651.06	1898.94
9	1090.64	RHCP	13	1090.64	1090.64
10	1105.22	LHCP	18	1680.22	1869.78
11	1119.80	RHCP	13	1119.80	1119.80
12	1134.38	LHCP	18	1709.38	1840.62
13	1148.96	RHCP	13	1148.96	1148.96
14	1163.54	LHCP	18	1738.54	1811.46
15	1178.12	RHCP	13	1178.12	1178.12
16	1192.70	LHCP	18	1767.70	1782.30
17	1207.28	RHCP	13	1207.28	1207.28
18	1221.86	LHCP	18	1796.86	1753.14
19	1236.44	RHCP	13	1236.44	1236.44
20	1251.02	LHCP	18	1826.02	1723.98
21	1265.60	RHCP	13	1265.60	1265.60
22	1280.18	LHCP	18	1855.18	1694.82
23	1294.76	RHCP	13	1294.76	1294.76
24	1309.34	LHCP	18	1884.34	1665.66
25	1323.92	RHCP	13	1323.92	1323.92
26	1338.50	LHCP	18	1913.50	1636.50
27	1353.08	RHCP	13	1353.08	1353.08
28	1367.66	LHCP	18	1942.66	1607.34
29	1382.24	RHCP	13	1382.24	1382.24
30	1396.82	LHCP	18	1971.82	1578.18
31	1411.40	RHCP	13	1411.40	1411.40
32	1425.98	LHCP	18	2000.98	1549.02

QPSK/QAM Transcoder Instruction Manual

Appendix B

**CATV Channel Frequency Chart
121 MHz to 750 MHz**

EIA Chan.	MHz Center Frequency
14	123
15	129
16	135
17	141
18	147
19	153
20	159
21	165
22	171
23	219
24	225
25	231
26	237
27	243
28	249
29	255
30	261
31	267
32	273
33	279
34	285
35	291
36	297
37	303
38	309
39	315
40	321
41	327
42	333
43	339
44	345
45	351
46	357

EIA Chan.	MHz Center Frequency
47	363
48	369
49	375
50	381
51	387
52	393
53	399
54	405
55	411
56	417
57	423
58	429
59	435
60	441
61	447
62	453
63	459
64	465
65	471
66	477
67	483
68	489
69	495
70	501
71	507
72	513
73	519
74	525
75	531
76	537
77	543
78	549
79	555

EIA Chan.	MHz Center Frequency
80	561
81	567
82	573
83	579
84	585
85	591
86	597
87	603
88	609
89	615
90	621
91	627
92	633
93	639
94	645
100	651
101	657
102	663
103	669
104	675
105	681
106	687
107	693
108	699
109	705
110	711
111	717
112	723
113	729
114	735
115	741
116	747

QPSK/QAM Transcoder Instruction Manual

Appendix C

dish™ 500 Stacked LNB Application Example 450 MHz System

EchoStar 5 - 110° W				
Transponder	Stacked Frequency*	Output Channel	Center Frequency*	
000T1	1	974.00	42	333
	2	1563.58	41	327
	3	1003.16	40	321
	4	1592.74	39	315
	5	1032.32	38	309
000T2	6	1621.90	37	303
	7	1061.48	36	297
	8	1651.06	35	291
000T3	9	1090.64	34	285
	10	1680.22	33	279
	11	1119.80	32	273
	12	1709.38	31	267
000T4	13	1148.96	30	261
	14	1738.54	29	255
	15	1178.12	28	249
	16	1767.70	27	243
	17	1207.28	26	237
000T5	18	1796.86	25	231
	19	1236.44	24	225
	20	1826.02	23	219
000T6	21	1265.60	22	171
	22	1855.18	21	165
	23	1294.76	20	159
	24	1884.34	19	153
	25	1323.92	18	147
	26	1913.50	17	141
000T7	27	1353.08	16	135
	29	1382.24	15	129
13	31	1411.40	14	123
	Spare Transcoder			

110° Total: 29

* This value is automatically set by the QOQT unit when an Input Transponder or Output Channel entry is made.

EchoStar 1 & 2 - 119° W				
Transponder	Stacked Frequency*	Output Channel	Center Frequency*	
000T8	1	974.00	62	453
	2	1563.58	61	447
	3	1003.16	60	441
	4	1592.74	59	435
	5	1032.32	58	429
000T9	6	1621.90	57	423
	7	1061.48	56	417
	8	1651.06	55	411
000T10	9	1090.64	54	405
	10	1680.22	53	399
	11	1119.80	52	393
	12	1709.38	51	387
000T11	13	1148.96	50	381
	14	1738.54	49	375
	15	1178.12	48	369
	16	1767.70	47	363
	17	1207.28	46	357
000T12	18	1796.86	45	351
	19	1236.44	44	345
	20	1826.02	43	339
13	21	1265.60	42	333
	Spare Transcoder			

119° Total: 21

QPSK/QAM Transcoder Instruction Manual

Appendix C - continued

dish™ 500 Stacked LNB Application Example 550 MHz System

EchoStar 5 - 110° W				
	Stacked Frequency*	Output Channel	Center Frequency*	
000T1	1	974.00	57	423
	2	1563.58	56	417
	3	1003.16	55	411
	4	1592.74	54	405
000T2	5	1032.32	53	399
	6	1621.90	52	393
	7	1061.48	51	387
	8	1651.06	50	381
000T3	9	1090.64	49	375
	10	1680.22	48	369
	11	1119.80	47	363
	12	1709.38	46	357
000T4	13	1148.96	45	351
	14	1738.54	44	345
	15	1178.12	43	339
	16	1767.70	42	333
000T5	17	1207.28	41	327
	18	1796.86	40	321
	19	1236.44	39	315
	20	1826.02	38	309
000T6	21	1265.60	37	303
	22	1855.18	36	297
	23	1294.76	35	291
	24	1884.34	34	285
000T7	25	1323.92	33	279
	26	1913.50	32	273
	27	1353.08	31	267
	29	1382.24	30	261
13	31	1411.40	29	255
	Spare Transcoder			

110° Total: 29

Note: EchoStar recommends Transponder 1 from 119° W be set at Output Channel 78 - 549 MHz.

* This value is automatically set by the QOOT unit when an Input Transponder or Output Channel entry is made.

EchoStar 1 & 2 - 119° W				
	Stacked Frequency*	Output Channel	Center Frequency*	
000T8	1	974.00	78	549
	2	1563.58	77	543
	3	1003.16	76	537
	4	1592.74	75	531
000T9	5	1032.32	74	525
	6	1621.90	73	519
	7	1061.48	72	513
	8	1651.06	71	507
000T10	9	1090.64	70	501
	10	1680.22	69	495
	11	1119.80	68	489
	12	1709.38	67	483
000T11	13	1148.96	66	477
	14	1738.54	65	471
	15	1178.12	64	465
	16	1767.70	63	459
000T12	17	1207.28	62	453
	18	1796.86	61	447
	19	1236.44	60	441
	20	1826.02	59	435
13	21	1265.60	58	429
	Spare Transcoder			

119° Total: 21

QPSK/QAM Transcoder Instruction Manual

Appendix C - continued

dish™ 500 Stacked LNB Application Example 750 MHz System

EchoStar 5 - 110° W				
	Transponder	Stacked Frequency*	Output Channel	Center Frequency*
000T1	1	974.00	116	747
	2	1563.58	115	741
	3	1003.16	114	735
	4	1592.74	113	729
000T2	5	1032.32	112	723
	6	1621.90	111	717
	7	1061.48	110	711
	8	1651.06	109	705
000T3	9	1090.64	108	699
	10	1680.22	107	693
	11	1119.80	106	687
	12	1709.38	105	681
000T4	13	1148.96	104	675
	14	1738.54	103	669
	15	1178.12	102	663
	16	1767.70	101	657
000T5	17	1207.28	100	651
	18	1796.86	94	645
	19	1236.44	93	639
	20	1826.02	92	633
000T6	21	1265.60	91	627
	22	1855.18	90	621
	23	1294.76	89	615
	24	1884.34	88	609
000T7	25	1323.92	87	603
	26	1913.50	86	597
	27	1353.08	85	591
	29	1382.24	84	585
13	31	1411.40	83	579
	Spare Transcoder			

110° Total: 29

Note: EchoStar recommends Transponder 1 from 119° W be set at Output Channel 78 - 549 MHz.

* This value is automatically set by the QOQT unit when an Input Transponder or Output Channel entry is made.


EchoStar 1 & 2 - 119° W				
	Transponder	Stacked Frequency*	Output Channel	Center Frequency*
000T8	1	974.00	78	549
	2	1563.58	79	555
	3	1003.16	80	561
	4	1592.74	81	567
000T9	5	1032.32	77	543
	6	1621.90	76	537
	7	1061.48	75	531
	8	1651.06	74	525
000T10	9	1090.64	73	519
	10	1680.22	72	513
	11	1119.80	71	507
	12	1709.38	70	501
000T11	13	1148.96	69	495
	14	1738.54	68	489
	15	1178.12	67	483
	16	1767.70	66	477
000T12	17	1207.28	65	471
	18	1796.86	64	465
	19	1236.44	63	459
	20	1826.02	62	453
13	21	1265.60	82	573
	Spare Transcoder			

119° Total: 21

QPSK/QAM Transcoder Instruction Manual

Appendix D

Rear Headend Diagram



Drawings are samples for illustration purposes only and are not to scale

QPSK/QAM Transcoder Instruction Manual

Limited Warranty

Blonder Tongue Laboratories, Inc. (BT) will at its sole option, either repair or replace (with a new or factory reconditioned product, as BT may determine) any product manufactured by BT which proves to be defective in materials or workmanship or fails to meet the specifications which are in effect on the date of shipment or such other specifications as may have been expressly agreed upon in writing (i) for a period of one (1) year from the date of original purchase (or such shorter period of time as may be set forth in the license agreement specific to the particular software being licensed), with respect to iCentral™ (hardware and software) and all other software products (including embedded software) licensed from BT, (ii) for a period of one (1) year from the date of original purchase, with respect to all fiber optics receivers, transmitters, couplers and integrated receivers/distribution amplifiers (including TRAILBLAZER™, RETRO-LINX™ and TWIN STAR™ products) as well as for VideoCipher® & DigiCipher® satellite receivers, and (iii) for a period of three (3) years from the date of original purchase, with respect to all other BT products. Notwithstanding the foregoing, in some cases, the warranty on certain proprietary sub-assembly modules manufactured by third-party vendors and contained in BT products and on certain private-label products manufactured by third-parties for resale by BT are of shorter duration or otherwise more limited than the standard BT limited warranty. In such cases, BT's warranty with respect to such third-party proprietary sub-assembly modules and private-label products will be limited to the duration and other terms of such third-party vendor's warranty. In addition, certain products that are not manufactured, but are resold by BT, carry the original OEM warranty for such products.

To obtain service under this warranty, the defective product, together with a copy of the sales receipt or other satisfactory proof of purchase and a brief description of the defect, must be shipped freight prepaid to: Blonder Tongue Laboratories, Inc., One Jake Brown Road, Old Bridge, New Jersey 08857.

This warranty does not cover damage resulting from (i) use or installation other than in strict accordance with manufacturer's written instructions, (ii) disassembly or repair by someone other than the manufacturer or a manufacturer-authorized repair center, (iii) misuse, misapplication or abuse, (iv) alteration, (v) lack of reasonable care or (vi) wind, ice, snow, rain, lightning, or any other weather conditions or acts of God.

OTHER THAN THE WARRANTIES SET FORTH ABOVE, BT MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND, EXPRESS OR IMPLIED, AS TO THE CONDITION, DESCRIPTION, FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR AS TO ANY OTHER MATTER, AND SUCH WARRANTIES SUPERSEDE ANY ORAL OR WRITTEN WARRANTIES OR REPRESENTATIONS MADE OR IMPLIED BY BT OR BY ANY OF BT'S EMPLOYEES OR REPRESENTATIVES, OR IN ANY OF BT'S BROCHURES MANUALS, CATALOGS, LITERATURE OR OTHER MATERIALS. IN ALL CASES, BUYER'S SOLE AND EXCLUSIVE REMEDY AND BT'S SOLE OBLIGATION FOR ANY BREACH OF THE WARRANTIES CONTAINED HEREIN SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT F.O.B. SHIPPING POINT, AS BT IN ITS SOLE DISCRETION SHALL DETERMINE. BT SHALL IN NO EVENT AND UNDER NO CIRCUMSTANCES BE LIABLE OR RESPONSIBLE FOR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL, PUNITIVE, DIRECT OR SPECIAL DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT LIABILITY OR OTHERWISE OR ANY OTHER LEGAL THEORY, ARISING DIRECTLY OR INDIRECTLY FROM THE SALE, USE, INSTALLATION OR FAILURE OF ANY PRODUCT ACQUIRED BY BUYER FROM BT.

All claims for shortages, defects, and non-conforming goods must be made by the customer in writing within five (5) days of receipt of merchandise, which writing shall state with particularity all material facts concerning the claim then known to the customer. Upon any such complaint, the customer shall hold the goods complained of intact and duly protected, for a period of up to sixty (60) days. Upon the request of BT, the customer shall ship such allegedly non-conforming or defective goods, freight prepaid to BT for examination by BT's inspection department and verification of the defect. BT, at its option, will either repair, replace or issue a credit for products determined to be defective. BT's liability and responsibility for defective products is specifically limited to the defective item or to credit towards the original billing. All such replacements by BT shall be made free of charge f.o.b. the delivery point called for in the original order. Products for which replacement has been made under the provisions of this clause shall become the property of BT. Under no circumstances are products to be returned to BT without BT's prior written authorization. BT reserves the right to scrap any unauthorized returns on a no-credit basis. Any actions for breach of a contract of sale between BT and a customer must be commenced by the customer within thirteen (13) months after the cause of action has accrued. A copy of BT's standard terms and conditions of sale, including the limited warranty, is available from BT upon request. Copies of the limited warranties covering third-party proprietary sub-assembly modules and private-label products manufactured by third-parties are also available from BT on request. VideoCipher® & DigiCipher® are registered trademarks of Motorola Corp.



**BLONDER
TONGUE**
LABORATORIES, INC.

The Standard of Quality in TV Signal Distribution

One Jake Brown Road, P.O. Box 1000
Old Bridge, NJ 08857-1000 USA
(800) 523-6049 • (732) 679-4000 • FAX: (732) 679-4353
www.blondertongue.com