


Operating and Installation instructions



Ceramic hobs with induction

KM 5731 / KM 5732 / KM 5733

KM 5736 / KM 5737 / KM 5752

KM 5753 / KM 5755 / KM 5757

KM 5775

To avoid the risk of accidents or damage to the appliance it is **essential** to read these instructions before it is installed and used for the first time.




Contents

Guide to the appliance	4
KM 5731	4
KM 5732 / KM 5736 / KM 5737	5
KM 5733	6
KM 5752 / KM 5757	7
KM 5753	8
KM 5755	9
KM 5775	10
Cooking zone sensors and displays	11
Timer control and display	12
Cooking zones	12
Warning and Safety instructions	16
Caring for the environment	23
Before using for the first time	24
General notes	24
Cleaning and heating up for the first time	24
Induction	25
How it works	25
Noises	26
Pans	27
Use	28
Sensor switches	28
Switching on	28
Settings	29
Auto heat-up	30
Booster function	32
Switching off and residual heat indicators	33

Safety features	34
Safety lock	34
Stop and Go	35
Safety switch-off	36
Overheating protection	37
Timer	38
Setting the minute minder	38
Switching a cooking zone off automatically	39
Combi mode	40
Timer factory settings	40
Cleaning and care	41
Programming	43
Problem solving guide	46
After sales service	48
Installation	49
Safety instructions for installation	49
Hob with frame or bevelled edge	53
Sealant	62
Flush-fitted hobs	63
Electrical connection	68
Wiring diagram	70

Guide to the appliance

KM 5731



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see “Cooking zone controls and displays”)


⑥ Timer control and display (see “Timer control and display”)

⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

KM 5732 / KM 5736 / KM 5737



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see "Cooking zone controls and displays")

⑥ Timer control and display (see "Timer control and display")


⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

Guide to the appliance

KM 5733



①②③ Cooking zones

⑤ Cooking zone controls and displays (see “Cooking zone controls and displays”)


⑥ Timer control and display (see “Timer control and display”)

⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

KM 5752 / KM 5757



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see “Cooking zone controls and displays”)

⑥ Timer control and display (see “Timer control and display”)


⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

Guide to the appliance

KM 5753



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see "Cooking zone controls and displays")


⑥ Timer control and display (see "Timer control and display")

⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

KM 5755



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see “Cooking zone controls and displays”)

⑥ Timer control and display (see “Timer control and display”)


⑦ Safety lock indicator lamp

⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch

Guide to the appliance

KM 5775



①②③④ Cooking zones

⑤ Cooking zone controls and displays (see “Cooking zone controls and displays”)

⑥ Timer control and display (see “Timer control and display”)

⑦ Safety lock indicator lamp


⑧ Safety lock sensor switch

⑨ Hob ON/OFF sensor switch



Guide to the appliance

Timer control and display



- 15 Sensor switch for activating the timer, switching between functions and selecting automatic switch-off for a cooking zone.
- 16 Sensor switch for setting the time
- 17 Time display
- 18 Indicator lamp for automatic switch-off, e.g. of the rear right cooking zone
- 19 Indicator lamp for minute minder

Cooking zones

Cooking zone	KM 5731 / KM 5752 / KM 5755 / KM 5757	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	14 - 20	normal: 1850 with booster: 2500
	14 - 20	normal: 1850 with booster: 2500
	16 - 23	normal: 2300 with booster: 3200
	10 - 16	normal: 1400 with booster: 1800
		Total: 7400

* Pans of any base diameter within the given range may be used.

** The wattage quoted may vary depending on the size and material of the pans used.

Guide to the appliance

Cooking zone	KM 5732 / KM 5736	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	14 - 20	normal: 1850 with booster: 2500
	10 - 16	normal: 1400 with booster: 1800
	16 - 23	normal: 2300 with booster: 3200
	10 - 16	normal: 1400 with booster: 1800
		Total: 7400

Cooking zone	KM 5733	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	18 - 28	normal: 2400 with booster: 3200
	14 - 20	normal: 1850 with booster: 2500
	10 - 16	normal: 1400 with booster: 1800
		Total: 6900

* Pans of any base diameter within the given range may be used.

** The wattage quoted may vary depending on the size and material of the pans used.

Guide to the appliance

Cooking zone	KM 5737	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	14 - 20	normal: 1850 with booster: 2500
	10 - 16	normal: 1400 with booster: 1800
	16 - 23	normal: 2300 with booster: 3200
	10 - 16	normal: 1400 with booster: 1800
		Total: 7400

Cooking zone	KM 5753	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	18 - 28	normal: 2400 with booster: 3200
	10 - 16	normal: 1400 with booster: 1800
	14 - 20	normal: 1850 with booster: 2500
	14 - 20	normal: 1850 with booster: 2500
		Total: 7400

* Pans of any base diameter within the given range may be used.

** The wattage quoted may vary depending on the size and material of the pans used.

Guide to the appliance

Cooking zone	KM 5775	
	minimum to maximum Ø in cm*	Rating in watts for 230 V**
	16 - 23	normal: 2300 with booster: 3200
	10 - 16	normal: 1400 with booster: 1800
	14 - 20	normal: 1850 with booster: 2500
	14 - 20	normal: 1850 with booster: 2500
		Total: 7400

* Pans of any base diameter within the given range may be used.

** The wattage quoted may vary depending on the size and material of the pans used.

Warning and Safety instructions

To avoid the risk of accidents and damage to the appliance, please read these instructions carefully before using it for the first time. They contain important notes on its installation, safety, use and maintenance.

The use of the appliance by the elderly or infirm or those who have not used the appliance before should be supervised by a competent and responsible person to avoid the risk of injury.

A data plate for your appliance is supplied with this documentation. It should be stuck into the space provided at the end of the instruction book.

Keep these instructions in a safe place for reference, and pass them on to any future user.

Technical safety

■ The appliance must be installed and connected by a suitably qualified and competent person in strict accordance with current local and national safety regulations. The manufacturer cannot be held liable for damage caused by incorrect installation or connection.

■ The electrical safety of this appliance can only be guaranteed when continuity is complete between it and an effective earthing system which complies with current local and national safety regulations. It is most important that this basic safety requirement is present and regularly tested, and where there is any doubt, the household wiring system should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

■ Do not connect the appliance to the mains electricity supply by an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

Warning and Safety instructions

■ Never open the casing of the appliance.

Tampering with electrical connections or components is highly dangerous to the user and can cause operational faults.

■ On hobs with bevelled glass edges a small gap may be visible between the hob and the worktop during the first few days after installation. This gap will reduce with time as the appliance is used and will not affect the electrical safety of your appliance.

Correct usage

■ For safety reasons this appliance must only be operated after it has been built in. This is necessary to ensure that all electrical components are shielded.

■ This appliance is intended for domestic use only and is not to be used for commercial purposes.

■ If the hob is built in over a pyrolitic oven, the hob should not be used whilst the pyrolitic process is being carried out, as this could trigger the overheating protection mechanism on the hob (see relevant section).

■ Use this appliance for the preparation of food only. Any other usage is at the owner's risk and could be dangerous. The manufacturer cannot be held liable for damage resulting from incorrect or improper use or operation.

Warning and Safety instructions

Safety with children

■ Use the safety lock to prevent children operating the appliance or altering the settings.

■ The appliance is only intended for use by adults who have read these instructions.

■ This appliance is not a toy! To avoid the risk of injury, keep children well away, and do not allow them to play with it or use the controls. They will not understand the potential dangers posed by it. They should be supervised whenever you are working in the kitchen.

■ Older children may use the appliance only when its operation has been clearly explained to them and they are able to use it safely, recognising the dangers of misuse.

■ The appliance gets hot when in use and remains hot for quite a while after being switched off. To safeguard against burning, keep children well away from the appliance at all times.

■ Do not store anything which might arouse a child's interest in storage areas above or next to the appliance. Otherwise they could be tempted into climbing onto the appliance with the risk of burning themselves.

■ Keep all pans out of reach of children. Turn pan handles inwards away from the edge of the hob. Danger of burning or scalding. Special hob guards are available from good retail outlets.

■ Packaging, e.g. cling film, polystyrene and plastic wrappings, must be kept out of the reach of babies and young children. Danger of suffocation. Dispose of or recycle all packaging safely as soon as possible.

■ Old appliances must be disconnected from the power supply, any plug rendered useless and the cable cut off directly behind the appliance to prevent misuse. This should be done by a competent person.

Protecting the appliance from damage

■ Do not drop anything on the ceramic surface. Even a light object could cause damage in certain circumstances.

■ Do not use pots or pans on the ceramic hob with bases with pronounced edges or ridges, e.g. cast iron pans. These could scratch or scour the hob surface permanently. Grains of salt and sand can also scratch.

■ Do not allow either solid or liquid sugar, or pieces of plastic or aluminium foil to get onto the cooking zones when they are hot. If this should occur, switch off the appliance, and carefully, scrape off all the sugar, plastic or aluminium residues from the hob whilst they are still hot, using a shielded scraper blade. Take care not to burn yourself. If residues are allowed to cool before being removed, the ceramic surface will be susceptible to pitting or even cracking. Clean the appliance once it has cooled down.

■ Do not use a steam cleaner to clean this appliance. The steam could reach electrical components and cause a short circuit. Pressurised steam could also cause permanent damage to the surface and to other components, for which the manufacturer cannot accept liability.

■ Never place hot pans near the control area. This could damage the electronic unit underneath.

■ If a drawer is fitted directly underneath the hob, ensure that there is sufficient space between the drawer and its contents and the underside of the appliance in order to ensure sufficient ventilation for the hob.

■ In countries where there are areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the appliance and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the guarantee.

Warning and Safety instructions

Protection from burning and scalding

■ The appliance gets hot when in use and remains hot for quite a while after being switched off. There is a danger of burning until the residual heat indicators go out.

■ For added protection, it is advisable to use heat-resistant pot holders or gloves when using the appliance. Do not let them get damp or wet, as this causes heat to transfer through the material more quickly with the risk of scalding or burning yourself.

■ Do not heat up unopened tins of food on the hob, as pressure will build up in the tin and it can explode. This could result in injury and scalding or damage.

■ Do not use the appliance as a resting place for anything else. Take particular care never to place cutlery or other metal objects on the hob. When the appliance is switched on either deliberately or by mistake, or when there is residual heat present, there is the risk of metal objects heating up, with a danger of burning. Depending on the material, other objects left on the hob could also melt or catch fire. Switch the cooking zones off after use.

■ Do not cover the appliance, e.g. with a cloth, kitchen foil, etc. This could be a fire hazard if the appliance is switched on by mistake.

■ Never leave the appliance unattended when cooking with oil or fat as these are fire hazards if overheated. Very hot oil can catch fire and could even set a cooker hood above on fire. Always heat fat slowly, watching as it heats.

■ If, despite this, oil or fat does catch fire, do not attempt to put out the flames with water. Use a suitable fire blanket, saucepan lid, damp towel or similar to smother the flames.

■ Do not flambé under a cooker hood. The flames could set the cooker hood on fire.

Appliance faults

■ In the event of damage or a defect, switch off the appliance immediately. Disconnect completely from the electricity supply. If the appliance has not yet been fully installed, the electricity cable must be disconnected from the supply point. If connected via a plug and socket, switch off at the socket and withdraw the plug. Contact the Miele Service Department. Do not reconnect the appliance to the mains electricity supply until after it has been repaired.

■ If there is any damage to the ceramic surface, the appliance must be disconnected from the mains electricity supply immediately, and not used until it has been repaired. Danger of electric shock.

■ Repairs may only be carried out by a suitably qualified and competent person. Repairs and other work by unqualified persons could be very dangerous and could damage the appliance. The manufacturer cannot be held liable for unauthorised work. Never open the housing of the appliance.

■ While the appliance is under guarantee, repairs should only be undertaken by a service engineer authorised by the manufacturer. Otherwise the guarantee is invalidated.

Warning and Safety instructions

Futher safety notes

 For people fitted with a heart pacemaker:

Please note that the area immediately surrounding the hob is electromagnetically charged, and that this could affect a pacemaker. If in any doubt, consult the manufacturer of the pacemaker or your doctor.

 Ensure pans are placed centrally over the cooking zone to prevent unnecessary exposure to the electromagnetic field.

 When using an electric socket near the appliance, care should be taken that the cable of the electrical appliance does not come into contact with the hot appliance. The insulation on the cable could become damaged, giving rise to an electric shock hazard.

 Always ensure that food is sufficiently cooked or reheated. Many factors will affect the overall cooking time, including the size and amount of food and its temperature. Some foods may contain micro-organisms which are only destroyed by thorough cooking at a sufficiently high temperature for long enough. Therefore when cooking or reheating food such as poultry, it is particularly important the food is completely cooked through. If in doubt, select a longer cooking or reheating time.

 Do not use plastic or aluminium foil containers. These melt at high temperatures and could damage the ceramic surface. Fire hazard.

 To prevent damage to items which are susceptible to magnetic fields, e.g. credit cards, diskettes, pocket calculators etc, do not leave them in the immediate vicinity of the hob.

 Spray canisters, aerosols and other inflammable substances must not be stored in a drawer under the hob. Cutlery inserts must be heat-resistant.


Disposal of packing material

The transport and protective packing has been selected from materials which are environmentally friendly for disposal and can normally be recycled.

Packaging, e.g. cling film, polystyrene and plastic wrappings must be kept out of the reach of babies and young children. Danger of suffocation. Dispose of or recycle all packaging materials as soon as possible.

Disposal of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Please do not therefore dispose of it with your household waste.



Please dispose of it at your local community waste collection / recycling centre and ensure that it presents no danger to children while being stored for disposal.

It should be unplugged or disconnected from the mains electricity supply by a competent person. The plug must be rendered useless and the cable cut off directly behind it to prevent misuse.

Before using for the first time

General notes

Your appliance has a "programming" function which you can use to customise the appliance to your particular requirements (see "Programming").

Cleaning and heating up for the first time

Before using for the first time, clean the appliance with a damp cloth only and then wipe dry.

Do not use washing up liquid to clean the ceramic surface as it can leave a blue sheen which may be difficult to remove.

Metal components have a protective coating which may give off a slight smell when heated up for the first time. The smell and any vapours will dissipate after a short time, and do not indicate a faulty connection or appliance.

How it works

An induction coil is located under each cooking zone. When a cooking zone is switched on, this coil creates a magnetic field which impacts directly on the base of the pan and heats it up. The cooking zone itself is heated up indirectly by the heat given off by the pan.

Induction cooking zones only work when a ferromagnetic pan is placed on it (see "Pans").

Induction automatically recognises the size of the pan, i.e. heat is only generated in the area covered by the base of the pan.

The cooking zone will not work:

- if it is switched on without a pan in place, or if the pan is unsuitable (non-magnetic base).
- if the diameter of the base of the pan is too small.
- if the pan is taken off the cooking zone when it is switched on.

If this happens, **E** will flash in the relevant cooking zone display alternating with **0** or the last power setting selected .

If a suitable pan is placed on the cooking zone within 3 minutes, the **E** will go out and you can continue as normal.

If no pan or an unsuitable pan is placed on the cooking zone, the cooking zone and the hob will switch off automatically after 3 minutes.

Take particular care never to place cutlery or other metal objects on the hob. When the appliance is switched on, either deliberately or by mistake, or when there is residual heat present, there is the risk of metal objects heating up, with a danger of burning.

Depending on the material, other objects left on the hob could also melt or catch fire. Switch the zones off after use.

Induction

Noises

When using an induction cooking zone, the following noises can occur in the pan, depending on what it is made of and how it has been constructed.

- On the higher power settings, it might buzz. This will decrease or cease altogether when the power setting is reduced.
- If the pan base is made of layers of different materials (e.g. in a sandwiched base), it might emit a cracking sound.
- Whistling might occur if linked zones (see "Booster function") are being used on the highest setting at the same time, and the pans also have bases made of layers of different materials.
- You might hear a clicking sound from the electronic switches, especially on lower settings.

The appliance has a cooling fan to help extend the life of the electronics. When the hob is being used intensively, this will come on and you will hear a whirring sound. The fan may continue to run after the appliance has been switched off.

Pans

Suitable pans include:

- stainless steel pans with a magnetic base
- enamelled steel pans
- cast iron pans

Unsuitable pans:

- stainless steel pans without a magnetic base
- aluminium and copper pans
- glass, ceramic or earthenware pots and pans

To test whether a pot or pan is suitable for use on an induction hob, hold a magnet to the base of the pan. If the magnet sticks, the pan is suitable.

Please be aware that the properties of the pan base can affect the evenness with which food heats up in the pan.

Unless the pan manufacturer states that you can do so, do not use pans with very thin bases on this hob, and never heat up empty pans as they could get damaged. This could also damage the appliance.


Pan size

To make optimum use of the cooking zones, choose pans with diameters larger than the innermost markings but smaller than the outermost markings. If the diameter of the pan is smaller than the innermost marking, the induction heating will not work. The zone will behave as if it had no pan on it.

Please note that the maximum diameter quoted by manufacturers often refers to the diameter of the top rim of the pot or pan. The diameter of the base (generally smaller) is more important.

Tips on saving energy

Use a pan lid whenever possible to minimise heat loss.




Use

Sensor switches

This hob is equipped with electronic sensor switches which react to finger contact.

To operate a cooking zone touch the relevant sensor switch. Each time you touch a sensor switch an audible tone sounds.



Make sure that you only touch the sensor you require (except when switching off a cooking zone), and that you touch the centre of the sensor.

Take care to keep the control area clean. Do not place anything on the control area. The sensors may fail to react or they could mistake the article or any dirt for a fingertip contact, thereby activating a function or even causing the hob to switch off automatically (see Safety switch-off.)

Never place hot pans on the sensors. The electronic unit underneath could get damaged.

Switching on

The hob must be switched on before any of the zones can be used.

To switch the hob on:

- Touch the ON/OFF sensor ①.

A **0** appears in the display for each of the zones. If no further entry is made, the hob will switch itself off after a few seconds for safety reasons.

To switch a cooking zone on:

- Select a power setting between **1** and **9** by touching the - or + sensor.

To select cooking **with** Auto heat-up, press the - sensor first, see "Auto heat-up". To select cooking **without** Auto heat-up press the + sensor first.

If you wish to switch on **another** cooking zone, and the **0** for that zone has already gone out, simply press the - or + briefly. The **0** will appear and you can select a power setting (with or without Auto heat-up).

Settings

Cooking process	Settings*	
	standard factory settings (9 settings)	extended settings** (17 settings)
Melting butter Dissolving gelatine	1 - 2	1 - 2.
Warming small quantities of food/liquid Keeping warm food which sticks easily Cooking rice Defrosting frozen vegetables	3	3 - 3.
Warming liquid and semi-solid foods Thickening sauces, e.g. Hollandaise Making porridge Preparing omelettes, lightly fried eggs Steaming fruit	4	4 - 4.
Defrosting deep frozen food Steaming vegetables, fish Cooking broths, pulse soups	5	5
Bringing large quantities of food to the boil Cooking dumplings	6	5. - 6
Gentle braising (without overheating the fat) of meat, fish, vegetables, fried eggs	7	6. - 7.
Frying pancakes etc.	8	8 - 8.
Boiling large quantities of water Bringing to the boil	9	9

* These settings, which envisage approx. 4 helpings, should only be taken as a guide. With deep pans, larger quantities or when cooking without a lid, a higher setting is required. For smaller quantities, select a lower setting.

** If you wish to fine-tune a setting, you can extend the power setting range (see "Programming"). The intermediate setting will be represented by an illuminated dot next to the number.

Auto heat-up

When Auto heat-up has been activated, the cooking zone switches on automatically at the highest setting and then switches to the continued cooking setting which you have previously selected. The heat-up time depends on which continued cooking setting has been chosen (see chart).


Taking a pan off the zone whilst Auto heat-up is in operation interrupts the Auto heat-up. It will resume if a pan is placed back on the zone within 3 minutes.

Continued cooking setting*	Heat-up time in minutes and seconds (approx.)
1	0 : 15
1.	0 : 15
2	0 : 15
2.	0 : 15
3	0 : 25
3.	0 : 25
4	0 : 50
4.	0 : 50
5	2 : 00
5.	5 : 50
6	5 : 50
6.	2 : 50
7	2 : 50
7.	2 : 50
8	2 : 50
8.	2 : 50
9	-

* The continued cooking settings with a dot after the number are only available if the power level range has been extended (see "Programming").

How to activate Auto heat-up

- Press the - sensor until the required continued cooking setting appears, e.g. 5.



During the heat-up time a dot will light up to the right of the continued cooking setting, and go out at the end of it.

At any point during the Auto heat-up time you can use - or + to lower or increase the continued cooking setting. The Auto heat-up time will alter accordingly.

In the **extended** range of settings (see "Programming - P6."), *H* flashes alternately with the continued cooking setting until the heat-up time has finished.

Use

Booster function


All of the cooking zones are equipped with a booster function, i. e. an increase in the power level.

If activated, the zones will operate on power setting **9** with an extra boost of power for a period of 10 minutes. This boost is intended for quickly bringing large quantities of water to the boil, e.g. when cooking pasta.

A maximum of two booster functions can be used at any one time.

Taking a pan off the zone whilst the booster is in operation interrupts the booster function. It will resume if a pan is placed back on the zone within 3 minutes.

The extra boost of energy is only available by taking a proportion of energy away from another cooking zone. For this reason, the cooking zones are networked in pairs as shown.



When the booster is switched on, the following happens:

- if Auto heat-up is activated on either zone in the same network, this will be switched off.
- the power level on the other linked cooking zone will sometimes decrease.

Proceed as follows:

- Touch the **B** sensor for the relevant cooking zone.

Power setting **9** will show in the cooking zone display, and the indicator lamp for the booster will also light up.

After 10 minutes, the zone will automatically revert to power setting **9**.

To switch off the booster before this, touch either the **B** sensor or the **-** sensor for the appropriate cooking zone.


If a power setting is selected before the booster function is switched on, the zone will revert to this pre-selected power setting when the booster is switched off, or automatically at the end of the booster time.

Switching off and residual heat indicators

To switch off a cooking zone:

- Touch the - and + sensors for the zone you want to switch off **at the same time**.

A  will light up in the display for that zone for a few seconds. If the cooking zone is still hot, residual heat will then be indicated in the display.



To switch off the hob:

- Touch the ON/OFF sensor ①.

This switches off all cooking zones. The residual heat indicator will appear in the display of any cooking zone which is still hot.

The lines of the residual heat indicator go out one after another as the cooking zones cool down. The last horizontal line only goes out when the cooking zone is safe to touch.

The residual heat indicators also react to hot dishes and plates being placed on a cooking zone that is not switched on.

Do not touch any zone or place any heat sensitive items on a zone where the residual heat indicator is lit up. Danger of burning, and fire hazard.

Please note that the residual heat indicators do not light up when there is a fault message, even if the cooking zones are hot.

Safety features

Safety lock

Keep children away from the hob for their own safety.

Your appliance is equipped with a safety lock to prevent the hob and the cooking zones being switched on or any settings being altered.

The safety lock can be activated when the hob is switched off as well as when it is in use.

If the safety lock is activated **when the hob is switched off**, then the hob cannot be switched on.

If the safety lock is activated **when the hob is in use**:

- The power levels for the cooking zones and the timer settings cannot be altered.
- The cooking zones and hob can be switched off but once switched off cannot be switched on again.

To activate the safety lock:

- Touch the safety lock sensor  until the relevant indicator lamp comes on.

The indicator lamp will go out after a short while.

The lamp will come on again to show that the safety lock has been activated, if

- you touch the safety lock  sensor.
- you try to change a setting.

To deactivate the safety lock:

- Touch the safety lock sensor  until the indicator lamp goes out.

You can alter the setting from one finger to three finger operation (see "Programming - P4") to make it harder for children to operate the appliance.

Please note that the safety lock will deactivate if there is a power cut.

Stop and Go

Your appliance has a Stop and Go feature which, when activated, reduces the power of all cooking zones that have been switched on. This allows you to leave the hob unattended for a short time without any danger of pans boiling over or burning.

If you wish to use this feature, you will need to alter the factory setting (see "Programming - P5").

To activate Stop and Go:

- Touch the  sensor until you hear two consecutive beeps.
Be careful not to continue touching the  sensor for too long, as this will activate the safety lock.

The indicator lamp for the safety lock will start to flash. The power of the cooking zone in use will be reduced to setting 1, and a 1 will appear in the corresponding cooking zone display.

If automatic switch-off is programmed for a cooking zone, activating Stop and Go will interrupt the count down to the switch-off time. When Stop and Go is deactivated, the automatic switch-off programme time will continue to run without further interruption.

If a minute minder time has been set, this will continue running and will not be affected by Stop and Go.

To deactivate Stop and Go:

- Touch the safety lock sensor  until the indicator lamp goes out.

The cooking zones will now run at the level that was previously set.

Safety features

Safety switch-off

Safety switch-off with an over-long cooking time

Your hob is fitted with a safety switch-off feature in case you forget to switch it off yourself.

If one of the cooking zones is heated for an unusually long period of time (see chart), and the power settings are not altered, the hob will switch itself off automatically and the appropriate residual heat indicator will appear.

Power setting*	Maximum operating time in hours
1 / 1.	10
2 / 2.	5
3 / 3.	5
4 / 4.	4
5 / 5.	3
6 / 6.	2
7 / 7.	2
8 / 8.	2
9	1

* The power settings with a dot after the number are only available if the power setting range has been extended (see "Programming - P6.").

- To use the cooking zones again, switch the hob back on in the usual way.

Safety switch-off if the sensors are covered

Your hob will switch off automatically if one or several of the sensors remain covered for longer than 10 seconds, for example, by finger contact, food boiling over or by an object such as an oven glove or tea towel.

An audible tone will sound every 30 seconds (for a maximum of ten minutes) and an *F* will flash in the display for the sensor which is covered.



- Clean the control area or remove the obstruction.

This will turn off the tone and the *F* will go out.

- Switch the hob back on again with the ON/OFF sensor ①. The cooking zones can now be used again as normal.

Overheating protection

All of the induction coils and the cooling element for the electronics are fitted with an overheating protection mechanism. To prevent the induction coils and cooling element from overheating, the overheating protection mechanism works on the affected cooking zone or on the entire hob in the following ways:

- If the booster function is being used, this will be switched off.
- The power level will be reduced.
- If an induction coil is affected, the hob will switch off. The **FE99** fault message will be displayed.

The cooking zone can be used again as soon as it has cooled down to a safe level.

- If the cooling element is affected, the power supply to the cooking zones will be reduced, and the set power level will continue to be displayed.

As soon as the cooling element has cooled down sufficiently, the cooking zones will automatically continue to operate at the original power setting.

Overheating can be caused by:

- heating up an empty pan
- fats or oils being heated up on the highest power setting.
- there being insufficient ventilation to the under side of the appliance.

If the overheating protection mechanism triggers again, contact the Service department.

Timer

The hob is fitted with a timer which can be used both as a minute minder and to switch off the cooking zones automatically.

These functions are explained below. The Combi mode is described in the section of that name.

You can set a time of 1 to 99 minutes. Use the - sensor to reduce the time from 99 to 00 and the + sensor to increase the time from 00 to 99. The display can be put back to 00 by touching - and + at the same time.

When the set time has elapsed, 00 will appear in the timer display for a few seconds. At the same time an audible tone will sound for a few seconds. To turn the audible tone off before this, touch the ⌚ sensor.

Setting the minute minder


The minute minder can be used with the hob switched on or off. It works like a manual kitchen timer.

Proceed as follows:

- Touch the ⌚, - or + sensor.

00 appears in the timer display, and the minute minder indicator lamp will flash.

- Whilst the indicator light is flashing, touch the - or + sensor until the time you require appears in the display, e.g. 15 minutes.



The time then counts down in minutes. The time remaining can be seen in the display and changed at any time by touching - or +.

Switching a cooking zone off automatically

It is only possible to programme a cooking zone to switch off automatically if a power setting has already been selected for that zone. All of the cooking zones can be programmed at the same time.

Proceed as follows:

- Select a power setting for the zone you require, e.g. back right, in the usual way.

- Touch the ⊕ sensor.

00 appears in the timer display, and the minute minder indicator lamp will flash.

- Touch the ⊕ sensor again.

The indicator lamp for the minute minder in the timer display goes out, and an indicator lamp for automatic switch-off of a cooking zone flashes.

- If several cooking zones are being used, touch the ⊕ sensor repeatedly until the indicator lamp flashes next to the cooking zone you wish to use this function for, e.g. back right.

The indicator lamps for the cooking zones being used light up clockwise, starting with the front left.

- Touch the - or + sensor until the time you require appears in the display, e.g. 15 minutes.



The time then counts down in minutes. The time remaining can be seen in the display and changed at any time by touching - or +.

If you want to set another cooking zone to switch off automatically, follow the same steps as described above.

If more than one switch-off time is programmed, the shortest time remaining will show in the display, and the indicator lamp for that particular cooking zone will flash. All the other indicator lamps will light up constantly. If you want to check on the remaining time for another zone, touch the ⊕ sensor until the indicator lamp for the zone you require flashes.

Timer

Combi mode

The minute minder and automatic switch-off functions can be used at the same time.

If you have programmed in one or more switch-off times, and would like to use the **minute minder as well**:

Touch the ⊖ sensor repeatedly until the minute minder indicator lamp flashes.

If you are using the minute minder, and would like to programme in one or more switch-off times **as well**:

Touch the ⊖ sensor repeatedly until the indicator lamp flashes for the cooking zone required.

Shortly after the last entry, the shortest remaining time will come up in the display. If you want to check on another remaining time, touch the ⊖ sensor until the relevant indicator lamp flashes.

Starting with the shortest remaining time which is showing in the display, all cooking zones that are in use and the minute minder are selected clockwise.

Timer factory settings

The timer is set at the factory so that it starts with **01** or **99** when the + or - sensor is touched.

This setting can be adjusted so that the time you last used appears in the display when you press + or - (see "Programming - P4. ").

Example:

If P4., S1 has been programmed, and the last time the minute minder was used was for 5 minutes, **00** will appear in the display when you switch on the Timer; when you then touch + or -, the display will change to **05**.

You can still select any time you want, even if you have adjusted the timer default setting.

Do not use a steam cleaner to clean this appliance. The steam could reach electrical components and cause a short circuit. Pressurised steam could also cause permanent damage to the surface and to components, for which the manufacturer cannot accept liability.

Do not use any sharp objects which could damage the seal between the ceramic surface and the surrounding frame and between the frame and the worktop.

Never use cleaners containing sand, soda, alkalis, acids or chlorides, oven sprays, dishwasher detergents, nor steel wool, abrasive cleaning agents, hard brushes, scouring pads and cloths. You should also avoid using sponges etc. which have previously been used with abrasive cleaning agents, as this will damage the surface.

Do not use washing up liquid to clean the ceramic surface as it can leave a blue sheen which may be difficult to remove.

Clean the appliance regularly, preferably after each use. Allow the hob to cool down before cleaning.

To prevent the risk of spillages burning on, remove any soiling as soon as possible, and ensure that pan bases are clean, dry and free of grease.

Most soiling can be wiped off using a damp cloth. Stubborn soiling may need to be removed with a shielded scraper blade.

After cleaning, dry thoroughly with a soft cloth to prevent a build-up of limescale deposits

To remove any limescale deposits, caused for example by water boiling over as well as metallic marks e.g. from saucepan bases, the ceramic surface can be cleaned using a proprietary cleaning agent for ceramic surfaces (available from the Miele Spare Parts Department). Follow the manufacturer's instructions on the packaging.

Finally, wipe the hob surface with a damp cloth and then dry it with a clean soft cloth. Ensure that every trace of cleaner has been removed from the surface. Any remaining trace could have a corrosive effect on the hob when it is next heated up.

Note that some cleaning agents contain a protective additive designed to prevent water marks and smears adhering to the surface.

E-Cloth

A microfibre "E-Cloth" is available from the Miele UK Spare Parts Department which is suitable for cleaning surfaces such as stainless steel, glass, plastic and chrome without the use of chemicals.

Cleaning and care

Should any **sugar, plastic or aluminium foil** spill or fall on to a hot cooking zone while it is in use, first switch off the appliance. Then carefully scrape off all the sugar, plastic or aluminium residues from the hob whilst they are still hot, using a shielded scraper blade. Take care not to burn yourself.

Allow the cooking zone to cool down, and then clean as described above with a suitable proprietary ceramic hob cleaner.

You can change the standard settings of your hob (see chart).

Proceed as follows:

- With the hob switched off, touch the hob ON/OFF sensor ① and the safety lock sensor  **at the same time** until the indicator lamp for the safety lock flashes.

A **P** (Programme) and an **5** (Status) will appear in the cooking zone display with a number which shows the current setting (see chart).

- To select the programme you want, touch the **+** or **-** sensor for the **front left** cooking zone, then select the required **status** by touching the **+** or **-** sensor for the **front right** cooking zone (see chart). You can alter several programmes one after the other in this manner.

To store the new settings in **memory**, touch the hob ON/OFF sensor ① until the displays go out.

If you **do not** wish to store the settings in memory, touch the safety lock sensor  until the displays go out.

Programming

Programme*		Status**	Setting
P 0	Demonstration mode and factory default settings	S 0	Demonstration mode on
		S 1	Demonstration mode off
		S 9	Factory default settings reinstated
P 1	Keypad tone when a sensor is touched	S 0	Off
		S 1	On
P 2	Induction warning tone when there is no pan or the pan is unsuitable	S 0	Off
		S 1	On
P 3	Audible tone for the Timer	S 0	Off
		S 1	Audible tone on for 10 seconds
		S 2	Audible tone on for 4 minutes
P 4	Safety lock	S 0	One finger locking using 
		S 1	Three finger locking using  and + on the two right-hand cooking zones
P 5	Stop and Go	S 0	Off
		S 1	On
P 0.	Power setting when the cooking zone is switched on	S 0	0
		S 1	5 (can only be selected when Auto heat-up is activated)

* Programmes/Statuses not shown here have no allocation.

** The factory default settings are shown in bold.

Programme*	Status**	Setting
P 2. Auto heat-up	S 0	Off
	S 1	Activated by selecting the power setting using -
	S 2	Activated by selecting the power setting using +
	S 3	Activated every time the hob is switched on
P 3. Residual heat indicator	S 0	<i>H</i> as the residual heat indicator symbol
	S 1	<i>E</i> as the residual heat indicator symbol
P 4. Timer factory settings	S 0	01 or 99
	S 1	The most recently set time (see "Timer default setting")
P 5. Timer functions	S 0	Minute minder only
	S 1	Auto switch-off only
	S 2	Minute minder and Auto switch-off
P 6. Power setting range	S 0	9 power settings (1 to 9)
	S 1	17 power settings (1, 1., 2, 2., 3 ... to 9) If the Auto heat-up setting is selected, an <i>H</i> will flash alternately with the continued cooking setting in the display.

* Programmes not shown here have no allocation.

** The factory default settings are shown in bold.

Problem solving guide

Installation work and repairs to electrical appliances must only be carried out by a suitably qualified and competent person in strict accordance with current local and national safety regulations (BS 7671 in the UK). Repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

What to do if, ...

... the hob or cooking zones cannot be switched on

Check whether

- the pans being used are suitable.
- the safety lock is activated.
If necessary, deactivate it (see "Safety lock").
- the mains fuse has blown.

If none of the above is the case, then disconnect the appliance from the electricity supply for approx. 1 minute. To do this:

- switch off at the mains, or
- withdraw the mains fuse.

Reset the trip switch in the mains fuse box, and switch the appliance back on. If it still will not switch on, contact a qualified electrician or the Miele Service Department.

... the hob can be switched on and settings selected, but the cooking zones do not heat up

Check whether you set the demo-mode setting by mistake (see "Programming - P0").

... an $\cup$ appears in the display for a cooking zone

Check whether

- the zone was switched on by mistake without a pan on it.
- the pan being used is suitable for use on an induction zone, and that it is large enough (see "Suitable pans").

... an individual cooking zone or the whole hob has switched itself off automatically

The safety switch-off feature or the overheating protection mechanism has been triggered (see "Safety switch-off" and "Overheating protection").

... one of the following has occurred:

- The booster has automatically switched off early.
- The power level has dropped.
- The cooking zone is not working in the usual way at the power level set.

The overheating protection mechanism has been triggered (see "Overheating protection").

... the food in the pan hardly heats up or does not heat up at all when the Auto heat-up function is switched on

This could be because:

- there is too much food in the pan.
- the pan is not conducting heat properly.

Select a higher continued cooking setting next time, or start cooking at the highest setting and then turn down to a lower setting manually later on.

... The cooling fan continues to run after the appliance has been switched off

This is not a fault. The fan will continue running until the appliance has cooled down. It will then switch itself off automatically.

... an *F* appears in the display for the rear cooking zones, an *E* appears in the display for the front cooking zones and numbers appear in the timer display.

FE99:

The overheating protection mechanism for the induction coil has been triggered. The cooking zone can be used again as soon as it has cooled down to a safe level.

With other fault messages:
Interrupt the power supply to the hob for approx. 1 minute.

If the problem persists after reconnecting the appliance to the power supply, please contact the Miele Service department.


After sales service, data plate

In the event of any faults which you cannot remedy yourself, or if the appliance is under guarantee, please contact:

- Your Miele dealer, or
- the Miele Service Department (see back cover for address).

When contacting the Service Department, please quote the model and serial number of your appliance, which are given on the data plate.

Space in which to stick the extra data plate supplied with the appliance. Ensure that the model number is the same as the one on the front of these instructions.



Safety instructions for installation

Fit wall units and extractor hood before fitting the hob to avoid damaging the surface.

■ The veneer or laminate coatings of worktops (or adjacent kitchen units) must be treated with 100 °C heat-resistant adhesive which will not dissolve or distort.

Any backmoulds must be of heat-resistant material.

■ This equipment may only be used in mobile installations such as ships, caravans, aircraft etc. if a risk assessment has been carried out by a suitably qualified engineer.

■ The hob may not be built in over a fridge, fridge freezer, freezer, dishwasher, washing machine or tumble dryer.

■ These hobs must not be installed above ovens or cookers unless these have a built-in cooling down fan.

■ After installing the hob, ensure that the connection cable cannot come into contact with the underside of the appliance. Make sure that there is no mechanical obstruction, such as a drawer, which could damage it.

■ If a protective shelf is installed under the built-in hob, there must be a minimum distance of 150 mm between it and the top of the worktop to allow for ventilation to the appliance.


■ Observe carefully the safety distances given on the following pages.

■ Do not use any sealant except where expressly instructed to do so. The seal underneath the appliance provides a sufficient seal for the worktop (see "Sealant").

All dimensions in this instruction booklet are given in mm.

Installation

Safety distance above the hob



When two or more appliances are installed together below a cooker hood, e.g. an electric hob and a gas wok combiset, which have different safety distances given in the installation instructions, you should select the greater distance of the two.

A minimum safety distance must be maintained between the hob and the cooker hood above it. See the cooker hood manufacturer's operating and installation instructions for details.


If the manufacturer's instructions are not available for the cooker hood, a minimum safety distance of at least 760 mm must be maintained. For any flammable objects, e.g. utensil rails, wall units etc. a minimum distance of at least 760 mm must be maintained between them and the hob below.

Safety distances to the sides of the hob


Ideally the hob should be installed with plenty of space on either side. There may be a wall at the rear and a tall unit or wall at one side. On the other side, however, no unit or divider should stand higher than the hob (see illustrations).

The following minimum distances should be adhered to for safety reasons:


- 50 mm to the right or left of the worktop cut-out to the nearest piece of furniture (e.g. tall unit).
- 50 mm from the worktop cut-out to the rear wall.



Not allowed



Recommended



Not recommended


Installation

Safety distance when installing the appliance near a wall with additional niche cladding


There must be a minimum distance of 50 mm between the niche cladding and the worktop cut-out.

This distance is only necessary for niche cladding made of wood or any other combustible material. For non-combustible materials (metal, ceramic tiles or similar), this dimension can be reduced by the thickness of the niche cladding material. The materials can warp or distort when subjected to high temperatures.

Flush-fitted hobs




Hob with frame or bevelled edge



- ① Masonry
- ② Niche cladding
- ③ Backmould
- ④ Worktop
- ⑤ Worktop cut-out
- ⑥ Minimum distance of 50 mm

Hob with frame or bevelled edge


Building-in dimensions for KM 5731



- ① Front
- ② Building-in depth
- ③ Building-in depth for mains connection cable
- ④ Mains connection cable, L = 1440 mm

Installation

Building-in dimensions for KM 5732




① Front

② Building-in depth

③ Mains connection cable, L = 1440 mm


Building-in dimensions for KM 5733



- ① Front
- ② Building-in depth
- ③ Building-in depth for mains connection cable
- ④ Mains connection cable, L = 1440 mm

Installation

Building-in dimensions for KM 5736




① Front

② Building-in depth

③ Mains connection cable, L = 1440 mm


Building-in dimensions for KM 5752



- ① Front
- ② Building-in depth
- ③ Mains connection cable, L = 1440 mm


Installation

Building-in dimensions for KM 5753



- ① Front
- ② Building-in depth
- ③ Building-in depth for mains connection cable
- ④ Mains connection cable, L = 1440 mm


Building-in dimensions for KM 5755



① Front

② Building-in depth

③ Mains connection cable, L = 1440 mm



- ① Front
- ② Building-in depth
- ③ Building-in depth for mains connection cable
- ④ Mains connection cable, L = 1440 mm

Preparing the worktop

- Make the worktop cut-out following the dimensions applicable. Remember to maintain a minimum safety distance of 50 mm from the back wall, as well as from any tall unit or side wall to the right or left of the hob. See "Safety instructions for installation".
- Seal the cut surfaces with a suitable heat-resistant sealant to avoid swelling caused by moisture.

If, during installation, you find that the seals on the corners of the frame are not flush with the worktop, the corner radius $\leq R4$, can be carefully scribed to suit.


These hobs have a seal underneath them to keep the hob securely in position. Any gap between the frame and worktop will reduce with time.

Installing the hob

- Feed the hob connection cable down through the cut-out.
- Place the hob centrally in the cut-out. When doing this make sure that the seal under the hob sits flush with the worktop on all sides. This is important to ensure an effective seal all round. Do not use sealant.
- Connect the hob to the mains.
- Check that the hob works.

Installation

Sealant




Do not use any sealant unless expressly instructed to do so. The sealing strip under the edge of the top part of the hob provides a sufficient seal for the worktop.

Do not use sealant between the frame of the top part of the hob and the worktop.

This could cause difficulties if the hob ever needs to be taken out for servicing and possibly result in damage to the frame or the worktop.

Flush-fitted hobs

Building-in dimensions for KM 5737




- ① Front
- ② Building-in depth
- ③ Mains connection cable,
L = 1440 mm
- ④ Stepped cut-out for granite or marble
worktops

**Cut-out dimensions for granite or
marble worktops.
Please take careful note of the inset
diagram.**

Installation

Building-in dimensions for KM 5757



- ① Front
- ② Building-in depth
- ③ Mains connection cable,
L = 1440 mm
- ④ Stepped cut-out for granite or marble
worktops

**Cut-out dimensions for granite or
marble worktops.**
**Please take careful note of the inset
diagram.**

Flush fit hobs are only suitable for installation in granite, marble, tiled or solid wood worktops. Other materials such as Corian and Askilan are not suitable.

An 800 mm wide base unit is required for building in.

The hob must be accessible from below for servicing purposes and to ensure that the seal around it is not dislodged.


The hob can be installed

- directly into a suitable cut-out in a granite or marble worktop.
- in a suitable cut-out in a tiled or solid wood worktop with a wooden support frame. The frame must be provided on site, and is not supplied with the appliance.

Installation

Making the worktop cut-out and building in the hob

Granite and marble worktops



⑤ Worktop

⑥ Hob


⑦ Gap

Corner radius of the worktop ≤ R4

- Make the worktop cut-out as shown in the drawings.
- Feed the hob connection cable down through the cut-out.
- Centre the hob ⑥ in the cut-out.
- Connect the hob to the mains.
- Check that the hob works.
- Seal the remaining gap ⑦ with a silicone sealant that is heat-resistant to at least 160 °C.

As the ceramic glass and the worktop cut-out have a certain dimensional tolerance, gap ⑦ can vary (min. 2 mm).

Solid wood and tiled worktops



① Wooden frame (13 mm, to be provided on site)

⑤ Worktop

⑥ Hob

⑦ Gap

Corner radius of the tiled worktop $\leq R4$

- Make the worktop cut-out as shown in drawings.
- Fix the wooden frame ① 7mm below the top edge of the worktop (see diagram).
- Feed the hob connection cable down through the cut-out.
- Centre the hob ⑥ in the cut-out.
- Connect the hob to the mains.
- Check that the hob works.
- Seal the remaining gap ⑦ with a silicone sealant that is heat-resistant to at least 160 °C.

As the ceramic glass and the worktop cut-out have a certain dimensional tolerance, gap ⑦ can vary (min. 2 mm).

Installation

Electrical connection

All electrical work should be carried out by a suitably qualified and competent person, in strict accordance with current local and national safety regulations (BS 7671 in the UK).

Installation, repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

Ensure power is not supplied to the appliance until after installation or repair work has been carried out.

The appliance must only be operated when built-in. This is to ensure that all electrical parts are shielded. Live parts must not be exposed.

Do not connect the appliance to the mains electricity supply by an extension lead. These do not guarantee the required safety of the appliance.

Please make sure that the connection data quoted on the data plate match the household mains supply.

Connection should be made via a suitable isolator which complies with national and local safety regulations, and the On/Off switch should be easily accessible after the appliance has been built in.

If the switch is not accessible after installation (depending on country) an additional means of disconnection must be provided for all poles.

For extra safety it is advisable to install a residual current device (RCD), with a trip current of 30 mA.

When switched off there must be an all-pole contact gap of at least 3 mm in the isolator switch (including switch, fuses and relays).

Important U.K.

The appliance is supplied for connection to a 230-240 V, 50 Hz supply with a 3-core cable.

The wires in the mains lead are coloured in accordance with the following code:

Green/yellow	= earth
Blue	= neutral
Brown	= live


WARNING **THIS APPLIANCE MUST BE** **EARTHED**

The electrical safety of this appliance can only be guaranteed when continuity is complete between it and an effective earthing system, which complies with current local and national safety regulations. It is most important that this basic safety requirement is present and regularly tested and where there is any doubt, the electrical wiring in the home should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system such as an electric shock.

The manufacturer cannot be held liable for damage which is the direct or indirect result of incorrect installation or connection.

Installation

Wiring diagram



N.B. This appliance is supplied single phase only in the U.K. / AUS / NZ

United Kingdom:

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Tel.: (01235) 554455
Fax.: (01235) 554477
Service Office Tel.: (08707) 554466
E-mail: info@miele.co.uk
Internet: www.miele.co.uk

Ireland:

Miele Ireland Ltd.
Broomhill Road, Tallaght, Dublin 24
Tel: (01) 46 10 710, Fax: (01) 46 10 797
Email: info@miele.ie
Internet: <http://www.miele.ie>

Australia:

Miele Australia Pty. Ltd.
A.C.N. 005635398
1 Gilbert Park Drive
Knoxfield, VIC 3180
Telephone: (03) 9764 7100
Fax: (03) 9764 7129
Internet: www.miele.com.au

Distributor New Zealand:

Steelfort Engineering Company. Ltd.
500 Rangitikei Street
Palmerston North, Priv. Bag 11045, NZ
Telephone: (06) 350 1350
Fax: (06) 356 1507

South Africa:

Miele (Pty) Ltd
63 Peter Place
Bryanston 2194
P.O. Box 69434
Bryanston 2021
Tel.: (011) 548 1900
Telefax (011) 548 1935
E-mail: info@miele.co.za
Internet: www.miele.co.za

Singapore:

Miele Southeast Asia
Miele Pte. Ltd.
163 Penang Road
04 - 02/03 Winsland House II
Singapore 238463
Tel : +65-67351191
Fax: +65-67351161
Email: infosea@miele.com.sg
Internet: www.miele.sg

Hong Kong:

Miele (Hong Kong) Limited
AIA Plaza, 24th Floor
18 Hysan Avenue
Causeway Bay
Hong Kong
Tel.: (852) 2610 1331
Fax: (852) 2610 1013
E-mail: mielehk@miele.com.hk