




ELBA

STEAM IRON

MODEL: ESI-A2230S(BL)

Owner's Manual

Please read this manual carefully
before operating your set.

Retain it for future reference.

Record model number and serial
number of the set.

See the label attached on the set and
quote this information to your dealer
when you require service.


For The Warranty Terms & Conditions, Please Refer To Warranty Certificate.

IMPORTANT SAFEGUARDS

When using this appliance, basic precautions should always be followed, including the following:


1. Read all instructions before using.
2. Never leave the iron unattended when it is connected to the power.
3. Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron on your own. Return the iron to the nearest authorized dealer or after-sales service centre for examination, repair or mechanical adjustment. Incorrect reassembly can cause a risk of electric shock when the iron is used.
4. To protect against a risk of electric shock, do not immerse the iron in water or any other liquids.
5. Never yank cord to disconnect from outlet instead, grasp plug and pull to disconnect.
6. Do not allow the power cord to touch hot surfaces. Let the iron cool down completely before putting away. Loop cord loosely around iron when storing.
7. **Warning:** The soleplate of the iron can become extremely hot right after use and may cause burns if touched.
8. **Do not add chemical additive, scented substances or decalcifiers into the water tank.**
9. Always disconnect iron from electrical outlet when filling with water or emptying and when not in use.
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
11. Children should be supervised to ensure that they do not play with the iron.
12. Do not operate the iron for other than its intended use.
13. Do not use the iron outdoors.
14. Save these instructions for future reference.

PRODUCT DESCRIPTION



- | | |
|------------------------|------------------------------------|
| (1) Steam spray outlet | (9) Indicator light |
| (2) Lid | (10) Transparent water tank |
| (3) Steam/dry dial | (11) Temperature control dial |
| (4) Spray button | (12) Maximum water level indicator |
| (5) Short-steam button | (13) Stainless steel soleplate |
| (6) Handle | (14) Self-clean button |
| (7) Swivel power cord | (15) Water cup |
| (8) Supply cord | |

STEAM/DRY DIAL



USING THE IRON FOR THE FIRST TIME

When using the iron for the first time, you may notice a slight emission of steam and hear some sounds made by the expanding plastics. This is considered normal and it stops after a short time. We also recommend passing the iron over an ordinary cloth before using it for the first time.

PREPARATIONS

Soft the laundry to be ironed according to the international symbols on the garment label, or if this is missing, according to the type of fabric.

GARMENT LABEL	FABRIC TYPE	TEMPERATURE CONTROL
	synthetic	· min./low temperature
	silk - wool	·· medium temperature
	Cotton - linen	... max./high temperature
	Fabric not to be ironed	

Start ironing the garments requiring a low temperature.

This reduces the waiting times (the iron takes less time to heat up than to cool down) and eliminates the risk of scorching the fabric.

STEAM IRONING

FILLING THE RESERVOIR

- Check that the plug is disconnected from the socket.
- Move the steam dial (3) to “0” [Fig. 1](please refer to page 8).
- Open the lid (2).
- Raise the tip of the iron to help the water enter the opening without overflowing.
- Slowly pour the water into the water tank (10) using the water cup (15) and never overfill the maximum level (about 350ml) indicated by “MAX” on the reservoir [Fig. 2].
- Close the lid (2).

SELECT THE TEMPERATURE

- Put the iron in a vertical position.
- Connect the plug to the wall outlet.
- Adjust the temperature control dial (11) according to the international symbol on the garment label [Fig. 3]. The indicator light (9) indicates that the iron is heating up. Wait until the indicator light goes off before ironing.

Warning: during ironing, indicator light (9) comes on at intervals, indicating that the selected temperature is maintained. If you lower the temperature after ironing at a high temperature, do not start ironing until the indicator light comes on again.

SELECT THE STEAM

- The quantity of steam is regulated by the steam dial (3).
- Turn the steam dial to the position between minimum and maximum steam depending on the quantity of steam required and the temperature selected.

Warning: the iron gives off steam continuously only if you hold the iron horizontally. You can stop the continuous steam by placing the iron in a vertical position or by moving the steam dial to "0". As indicated on the temperature control dial (11) and in the initial table, you can only use steam at the highest temperatures. **If the selected temperature is too low, water may drip onto the soleplate.**

SELECT THE SHORT-STEAM

- Press the shot-steam button (5) to generate a powerful burst of steam that can penetrate the fabrics and smooth the most difficult and tough creases. Wait for a few seconds before pressing it again [Fig. 4].
- By pressing the shot-steam button at intervals you can also iron vertically (curtains, hung garments, etc.) [Fig. 5].

Warning: the shot-steam function can only be used at high temperatures. Stop the emission when the indicator light (9) has light up then start ironing again only after the indicator light has gone off.

SPRAY IRONING

- Make sure that there is water in the water tank (10). Press the spray button (4) slowly (for a dense spray) or quickly (for a vaporized spray) [Fig. 6].

Warning: for delicate fabrics, we recommend moistening the fabric beforehand using the spray function or putting a damp cloth between the iron and the fabric. To avoid staining, do not use the spray on silk or synthetic fabrics.

DRY IRONING

To iron without steam-dry ironing, turn the dry dial (3) to “0” position (no steam).

CLEANING

- Before cleaning the iron in any way, make sure that the appliance plug is not connected to the wall outlet.
- Any deposits, starch residue or size left on the soleplate can be removed using a damp cloth or an unabrasive liquid detergent.
- Avoid scratching the soleplate with steel wool or metallic objects.
The plastic parts can be cleaned with a damp cloth then wiped over with a dry cloth.

SELF-CLEAN FUNCTION

- The self-clean feature helps to cleans inside the plate, removing impurities. We recommend using it every 10-15 days.
- Directions:
 - Fill the water tank (10) according to the maximum water level indicator.
 - Connect the plug into a standard 220-240V AC electrical outlet near a sink, turn the temperature control dial (11) to the MAX position. Rest the iron in vertical position and stable surface and allow it to heat until the indicator light (9) goes off.
 - Hold the iron horizontally over the sink and press the self-clean button (14) [Fig. 7]. Boiling water and steam will be released from the soleplate (13), taking impurities with them. Move the iron forward and backward until the water tank is empty. Then, turn the steam dial (3) to “0” position and the temperature control dial to MIN. Disconnect the plug from the wall outlet and let the iron to cool down.
 - If it appears that more self-clean is necessary (e.g., if impurities can still be seen), repeat above steps until the soleplate and water tank are clean. Dry thoroughly until impurities are totally cleaned.
 - When the soleplate has cooled down, you can clean it with a damp cloth.

STORING THE IRON

- Disconnect the plug of the iron from the wall outlet.
- Empty the water tank (10) by moving the iron forward and backward.
- Leave the iron to cool down completely.
- Roll up the supply cord [Fig. 8].
- Always put the iron in a vertical position.

IRONING TIPS









- We recommend using the lowest temperature with fabrics that have unusual finishes (sequins, embroidery, flush, etc.).
- If the fabric is mixed (e.g. 40% cotton 60% synthetics), set the temperature to the temperature of the fibre requiring the lower temperature.
- If you do not know the composition of the fabric, determine the suitable temperature by testing on a hidden corner of the garment. Start with a minimum temperature and increase it gradually until it reaches the ideal temperature.
- Never iron areas with traces of perspiration or any other marks. The heat of the soleplate fixes the stains on the fabric, making them irremovable.
- The size is more effective if you use a dry iron at a moderate temperature, excess heat scorches it with the risk of forming a yellow mark.
- To avoid marking on silk, woolen or synthetic garments shiny, iron them inside out.
- To avoid marking velvet garments shiny, iron in one direction (following the fibre) and do not press down on the iron.
- The heavier the washing machine is loaded, the more creased can be appeared on the garment. This also happens when the spin drying revolutions are very high.
- Many fabrics are easier to iron if they are not completely dry. For example, silk should always be ironed damp.

ENVIRONMENT-FRIENDLY DISPOSAL



You can help to protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal centre.



ELBA