

# USER MANUAL

---

## SHDTU03 NTU/E1





SHDTU03-NTU/E1 SHDSL Modem  
Installation and Operation Manual  
Version 1.1

## Revision Marks

Revision	Date	Notes
V 1.0	N/A	<b>Software: Version: 1.5X7001r-XAT0</b>
V 1.1	2003.10	<b>Auto-configuration added</b> <b>Software: Version 1.19 FW: 2.2</b>



# ***Table of Contents***

---

<b>Chapter 1. Introduction .....</b>	
I. Features .....	1-1
II. Specification.....	1-2
III. Application. ....	1-3
<b>Chapter 2. Hardware Installation .....</b>	
I. Front Panel .....	2-1
II. Rear Panel.....	2-3
III. Hardware Installation .....	2-4
<b>Chapter 3. What's Auto Configuration .....</b>	
I. Wet Current .....	3-1
II. AIS (Alarm Indication Signal).....	3-1
<b>Chapter 4. Configuration with Keypad and LCD .....</b>	
I. Purpose .....	4-1
II. How to use key pads ?.....	4-1
III. Menu Tree .....	4-2
1. Menu tree for SHOW STATUS.....	
2. Menu tree for SHOW STATISTIC.....	
3. Menu tree for SETUP TYPE.....	
4. Menu tree for SAVE CONFIGURATION.....	
5. Menu tree for DISGNOSTIC.....	

## ***Table of Contents***

---

<b>Chapter 5. Configuration with Console Port .....</b>	
I. Login Procedure .....	5-1
II. Window structure.....	5-2
III. System Management Terminal(SMT) .....	5-3
1. Menu Command .....	
2. Navigating the SMT interface.....	
IV. Main Menu Summary .....	5-5
V. Changing the password and user profile.....	5-6
VI. Configuration the SHDSL NTU .....	5-9
1. Configure SHDSL type.....	
2. Configure SHDSL parameters.....	
3. Configure E1 parameters.....	
4. Restore factory default .....	
VII. Write the setup parameters.....	5-22
VIII. Reboot the SHDSL NTU.....	5-23
IX. View the system status .....	5-24
X. View the system configuration .....	5-26
XI. Upgrade the SHDSL NTU.....	5-27
XII. Diagnostic .....	5-30
XIII. EXIT SMT .....	5-33
<b>Appendix A .....</b>	A-1
<b>Appendix B .....</b>	
I. Connector Architecture .....	A-2
<b>Appendix C .....</b>	
I. Cable Connection .....	A-4

# ***Chapter 1. Introduction***

---

## **I. Features**

The SHDSL NTU offers two different ways to connect customers to high-speed TDM services with two G.703 E1 interfaces (balance 120 Ohm RJ45 jack or unbalance 75 Ohm dual BNCs). The G.703 interface will carry data at N\*64kbps rates (where n=1~32).

The SHDSL NTU can be configured and managed via EOC, or menu-driven VT100 compatible Asynchronous Terminal Interface, either locally or remotely.

The SHDSL NTU is equipped with an auto rate capability that identifies the maximum line rate supported by the copper loop. This powerful automatic configuration capability makes installation and service provisioning simple and painless. Further flexibility is provided in the ability to manually set the maximum NTU speed at different levels for different customer-tailored service offerings.

- ❑ Standard G.shdsl (ITU G.991.2) supports improved reach/speed and greater interoperability
- ❑ Fast and cost-effective provisioning of traditional frame relay (FR or T-HDLC) or TDM leased line services
- ❑ Uses existing copper loop infrastructures
- ❑ Can operate in back to back connection
- ❑ Efficient single wire pair usage
- ❑ Up to 2.312Mbps symmetric service bit rate
- ❑ Auto rate installation maximizes data rate based on loop conditions
- ❑ Local management interface with LCD display
- ❑ Remote line loopback
- ❑ SHDSL Line performance monitoring
- ❑ Raw and per time interval statistics
- ❑ Bandwidth guaranteed transmission equipment

## **II. Specification**

### **Network Interface**

- Line Rate: SHDSL per ITU G.991.2
- Coding: trellis coded pulse amplitude modulation
- Support: ANSI (Annex A) and ETSI (Annex B)
- Payload rates: 64kbps to 2.304Mbps (N x 64kbps N=1 to 36)
- Connection: RJ-45 jack (2-wire)

### **G.703 Interface**

- Connection: RJ-45 for balanced 120 Ohm E1 cable
- Connection: BNC for unbalanced 75 Ohm E1 cable

### **Framing**

- G.703/G.704
- CRC 4 enable/disable
- CCS/CAS
- Framed / Unframed

### **DSL Timing**

- Network / Internal / DTE

### **Performance Monitoring**

- ES, SES, UAS, Alarms, Errors for E1, SHDSL

### **Loopback Tests**

- Local / Digital / Remote Loopback

### **Management**

- Configuration with keypad and LCD display
- Console port
- Supports firmware upgrade


### **Physical/Electrical**

- Dimensions: 19.5 x 4.8 x 16.8 cm
- Input: 90~240VAC with 50~60Hz
- Power Consumption: 10W Max
- Operation: 0 to 50°C ; Humidity: Up to 95% (non-condensing)



**Warning! High voltage. Do not open**

## **III. Application**



**CTC**  
union CTC Union Technologies Co., Ltd  
ISO 9001

## *Chapter 1. Introduction*

---

This page is left in blank intentionally


## **Chapter 2. Hardware Installation**

---

This chapter shows the front panel and how to install the hardware.

### **I. Front Panel**

The front panel contains LED status



The LCD can show the status and configuration of the product. The local management interface will be done by push button keys and LCD display. For more detail, refer to Chapter 4: Configuration.

The purpose of key pad is to configure the SHDSL NTU. Review Chapter 4 for detail configuration.

Key Pad	Description
Exit/-	● Return to previous configuration menu.
Enter/+	■ Skip to next configuration menu or configure the items.
L	◀ Select other parameter in the same level menu.
R	▶ Select other parameter in the same level menu.

## **Chapter 2. Hardware Installation**


The following table describes the LEDs' function of the SHDTU03.

LED	Color	Action	Description
PWR	Green	On	Power is on.
		Off	Power is off.
System ALM	Red	On	Major alarm occurs.
		Off	System is working normally.
TST	Yellow	On	System is testing for connection.
		Off	System is working normally.
SHDSL	SYN	On	SHDSL line is connected.
		Off	SHDSL line has dropped.
SHDSL	ERR	Blink	There are error seconds.
		Off	There are not any error seconds.
G.703	LBK	On	Loopback is on.
		Off	Loopback is off.
G.703	SYN	On	E1 line is connected.
		Off	E1 line has dropped sync.
G.703	ERR	Blink	There are error seconds.
		Off	There are not any error seconds.
G.703	LBK	On	Loopback is on.
		Off	Loopback is off.

## **Chapter 2. Hardware Installation**

### **II. Rear Panel**

From left to right, the rear panel of SHDSL NTU includes the power switch, power socket, RJ-45 console, RJ-45 G.703, BNC jacks for transmitting and receiving and the RJ-45 for SHDSL.



Rear Panel with the AC Type



Rear Panel with the DC Type

### **Connector Description**


Power	Power switch. Press 1 to turn on and press 0 for off.
100~240V AC	Power socket. It has power adapting function from 90~240VAC.
36~72VDC	Power socket . It has power adapting function from 36~72VDC.
Console	RJ-45 for system configuration and maintenance.
E1/120Ω	RJ-45 for 120 Ohm E1 connection with PABX (Private Automatic Branch Exchange) or Router
TX	BNC for 75 Ohm E1 transmitting
RX	BNC for 75 Ohm E1 receiving
G.SHDSL	RJ-45 for G.SHDSL connection

## **Chapter 2. Hardware Installation**

### **III. Hardware Installation**

Note: To avoid possible damage to the SHDTU03, do not turn on the product before hardware installation.

1. Plug the power cord in the power socket.
2. Plug the console port in console if you want to configure the NTU with VT100 program of NB or PC.
3. Plug in the E1 cable (Either 75 Ohm BNC cables or 120 Ohm twisted pair cable)
4. Plug in the SHDSL cable
5. Power on



Warning! High voltage. Do not open

## **Chapter 3. What is Auto Configuration**


Some of the embedded functions do not have a separate command to setup but some of them are auto sense with some configurations and change itself configuration. Some of them are always enable function.

### **I. Wetting Current**

Wetting current, also known as loop sealing current, is a low-level DC current applied to a loop for the specific purpose of maintaining cable splice integrity by preventing the build-up of oxidation. The “enable” applies a relative  $-42 \pm 2$  V DC voltage to the cables and allows 2~3 mA of current to flow at all times. As with all STU-C type devices, they have the ability to source wetting current. The SHDTU03 will automatically enable wetting current as STU-C type. As STU-R type, it always terminates the wetting current.

### **II. AIS (Alarm Indication Signal)**

Alarm Indication Signal (RAI) is an always enabled signal transmitted automatically to the connected device when the remote E1 line drops or the SHDSL line drops. For example: When STU-R E1 RX line is dropped, STU-R will send the status to STU-C via EOC or command. STU-C will send AIS (Alarm Indication Signal) to DTE.



## ***Chapter 3. What is Auto Configuration***

---

This page is left in blank intentionally

## ***Chapter 4. Configure via Keypad and LCD***

---

### **I. Purpose**

This chapter provides information about configuration your SHDSL NTU via the front panel LCD display and keypads.

Note: After you have completed all necessary settings for your SHDSL NTU, make sure to write the new configuration to NVRAM by “write” command and reboot the system for the of new configuration to take effect.

### **II. How to use key pads**


The SHDTU03 is designed for user-friendly configuration with keypads and LCD display without using PC or NB with VT100 terminal.

Key Pad		Description
Exit/-		Return to previous configuration menu.
Enter/+		Skip to next configuration menu or configure the item.
L		Select other parameter in the same level menu.
R		Select other parameter in the same level menu.

## **Chapter 4. Configure via Keypad and LCD**

### **III. Menu Tree**

After turning on the SHDTU03, the LCD will prompt **SHDSL NTU (E1)**. Press **Enter** to enter. There are five main commands, show status, show statistics, system setup, write configuration and system diagnostic. For more detail, refer to each title.




## **Chapter 4. Configure via Keypad and LCD**

---

### **Menu tree for SHOW STATUS**

You can check three kinds of status via LCD display: Type, SHDSL status and E1 status. The SHOW STATUS menu tree is as follows.




# Chapter 4. Configure via Keypad and LCD

## Menu tree for SHOW STATISTIC

The SHDTU03 can display for current 15 minutes and current 24 hours.


The menu tree is as follows.



# Chapter 4. Configure via Keypad and LCD

## Menu tree for SETUP TYPE


The menu tree is as follows.



# **Chapter 4. Configure via Keypad and LCD**

## **Menu tree for SETUP E1**

The route of setup E1 is SHDSL NTU ↗ SYSTEM SETUP ↗ SETUP E1.



## ***Chapter 4. Configure via Keypad and LCD***

---

### **Menu tree for SAVE CONFIGURATION**

After configuration, the new parameters have to be saved in NVRAM by following these steps. Choose WRITE CONFIGURATION by using **L** or **R** key and press **Enter**. Choose SAVE & REBOOT YES and then press **Enter**.




*Congratulation! You are done. The configuration is complete.*

## ***Chapter 4. Configure via Keypad and LCD***

---

### **Menu tree for DIAGNOSTIC**

The route for diagnostic is SHDSL NTU  $\swarrow$  SYSTEM DIAGNOSTIC  $\swarrow$  DIAG LOOPBACK.



## **Chapter 5. Configure via Console Port**

---

This chapter provides information about configuring the SHDTU03 via the console port with VT100 terminal.

Note: After you have completed all necessary settings for your SHDSL NTU, make sure to write the new configuration to NVRAM by “write” command and reboot the system for the of new configuration take effect.

### **I. Login Procedure**

Check the connectivity of the RS-232 cable from your computer to the console port of SHDTU03. Start your terminal access program with VT100 terminal emulation. Configure the serial link with baudrate of 9600, 8 data bits, no parity check, 1 stop bit, and no flow-control, and press the SPACE key until the login screen appears. When you see the login screen, you can logon to the SHDTU03.

User : admin

Password: \*\*\*\*\*

Note: If you have not set any user profile for the SHDSL NTU, enter the factory default user “admin”. When the system prompts you for a password, type “admin” to enter SHDSL NTU.



A screenshot of a terminal window with a light gray background and a thin black border. Inside, there are two lines of text: "User: admin" and "Password: \*\*\*\*\*". The "\*\*\*\*\*" is represented by five asterisks, indicating a masked password entry. The rest of the window is blank white space.

```
User: admin
Password: *****
```

## **Chapter 5. Configure via Console Port**

After you type the password, the SMT displays the main menu.

```
SHDSL NTU
-----
>> setup          Configure system
status           Show running system status
show            View system configuration
write            Update flash configuration
reboot          Reset and boot system
diag             Diagnostic utility
admin            Setup management features
upgrade         Software upgrade
exit             Quit system

-----
Command: setup <more...>
Message:

-----
<I/K> Move up/down, <L/J> Select/Unselect, <U/D> Move top/bottom, <^Q> Help
```

## **II. Window Structure**

From top to bottom, the window will be divided into four parts:

1. Product name
2. Menu field: Menu tree is prompted on this field. “>>” symbol indicates the cursor place.
3. Configuring field: You will configure the parameters in this field.      <**parameters**> indicates the parameters you can choose and <**more...>** indicates that there have submenu in the title.
4. Operation command for help

# **III. System Management Terminal (SMT)**

## **Menu Commands**


Before changing the configuration, familiarize yourself with the operations list in the following table. The operation list will be shown on the window.

<b>Keystroke</b>	<b>Description</b>
[UP] or I	Move to above field in the same level menu.
[DOWN] or K	Move to below field in the same lever menu.
[LEFT] or J	Move back to previous menu.
[RIGHT] or L	Move forward to submenu.
[ENTER]	Move forward to submenu.
[TAB]	To choose another parameters.
Ctrl + C	To quit the configuring item.
Ctrl + Q	For help

# Chapter 5. Configure via Console Port

## Navigating the SMT interface

Use the SMT (System Management Terminal) interface to configure the NTU. The following figure is an overview of the menu tree.



# **IV. Main Menu Summary**

The main menu is prompt as follows.

<b>Menu Title</b>	<b>Function</b>
Setup	Use this menu to setup SHDSL type, SHDSL parameters and E1 parameters or restore factory default setting.
Status	Use this menu to show SHDSL status, E1 status and statistics or clear the statistics
Show	Use this menu to show general information, all configurations and all configurations in command script.
Write	Use this menu to save your configuration.
Reboot	Use this menu to reset and reboot the system
Diag	Use this menu to setup diagnostic utility
Admin	Use this menu to manage user profile and change user password
Upgrade	Use this menu to upgrade kernel and FPGA.
Exit	Use this menu to exit STM

# **V. Changing the password and user profile**

The SHDSL NTU comes pre-configured with user profile 1 already established, that is, user “admin” and password “admin” with menu driven interface. The maximum number of user profile is limited to 5 users. You can add, delete and modify the users in Admin menu.

For system security, suggest to change the default user name and password by performing the following steps.

**Step 1:** Move the cursor to **admin** and press [ENTER] or [RIGHT].

---

```
setup      Configure system
status     Show running system status
show       View system configuration
write      Update flash configuration
reboot    Reset and boot the system
diag       Diagnostic utility
>> admin   Setup management features
upgrade   Software upgrade
exit      Quick system
```

---

**Step 2:** Choose **user** and press [ENTER] or [RIGHT].

---

```
>> user    Manage user profile
passwd    Change supervisor password
```

---

## **Chapter 5. Configure via Console Port**

---

**Step 3:** Move to **modify** and press [ENTER] or [RIGHT].

---

```
-----  
      clear      Clear user profile  
>> modify     Modify user profile  
      list       List user profile  
-----
```

**Step 4:** The default user name and password is pre-configured in user profile 1. For changing the default setting, type **1** to modify.

---

```
Command: admin user modify <1~5> <more...>  
Message: Please input the following information.
```

```
Legal access user profile number <1~5> :1
```

---

**Step 5:** Move the cursor to **profile** and press [ENTER] or [RIGHT]

---

```
-----  
      attrib     UI mode  
>> profile    User name and password  
-----
```

**Step 6:** Type the new user name, old password (admin), new password and retype the new password to confirm. The passwords are prompted as star symbols.

**Note:** After setting the user name and password, strongly suggest you to save them. In the next time when you login, you have to use the new user name and password.

## **Chapter 5. Configure via Console Port**

---

```
-----  
Command: admin user modify 1 profile <name> <passconf>  
Message: Please input the following information.
```

```
Legal user name (Enter for default) <admin>:test  
Input the old Access password:*****  
Input the new Access password:*****  
Re-type Access password:*****  
-----
```

There are two UI modes, command mode and menu mode, used for setting the product. User can determine one kind for configuration the product in the **attrib** command.

```
-----  
>> attrib UI mode  
profile User name and password  
-----
```

```
Command: admin user modify 1 attrib <Command|Menu>  
Message: Please input the following information.
```

```
User interface (Tab select) <Menu> :Menu  
-----
```

# **VI. Configure the SHDSL NTU**

This section provides information about configuring the SHDSL NTU.  
Follow the procedures:

In main menu, select **setup** and press [ENTER] or [RIGHT].

---

```
>> setup      Configure system
      status     Show running system status
      show       View system configuration
      write      Update flash configuration
      reboot     Reset and boot the system
      diag       Diagnostic utility
      admin      Setup management features
      upgrade    Software upgrade
      exit       Quick system
```

---

The screen will prompt as follows

---

```
>> type       Configure shdsl type
      shdsl     Configure shdsl parameters
      e1        Setup e1 parameters
      default   Restore factory default setting
```

---

## **Chapter 5. Configure via Console Port**

---

### Configure SHDSL type

This section will introduce the configuring of SHDSL type: STU-R, STU-C-INTCLK, STU-C-EXTCLK. The default operation type is STU-R.

Select **type** and press [ENTER] or [RIGHT] to setup SHDSL type. Press [TAB] to select the operating type and press enter to finish setting.

```
-----  
-> type      Configure shdsl type  
shdsl       Configure shdsl parameters  
serial      Setup serial parameters  
default     Restore factory default setting
```

```
-----  
Command: setup type <STU-R, STU-C-INTCLK, STU-C-EXTCLK>
```

```
Message: Please input the following information.
```

```
SHDSL operation type (TAB Select) <STUR>: STU-C-INTCLK
```

```
-----  
INTCLK: The device will generate the appropriate clock speed defined by  
the speed setting of the interface.
```

```
EXTCLK: The device will accept the clock from the interface and will use  
that clock to receive and transmit data across the interface.
```

```
Most applications use Internal Clock. If the DTE provides a clock with TX  
data, the clock can set to be External Clock.
```

## **Chapter 5. Configure via Console Port**

---

### Configure SHDSL parameters

This section provide the setup for SHDSL parameters: Annex type, margin, psd, wetting current, power backoff and framer.  
Select SHDSL and press [ENTER] or [RIGHT].

---

```
-----  
      type      Configure shdsl type  
>> shdsl     Configure shdsl parameters  
      e1        Setup e1 parameters  
      default   Restore factory default setting
```

For setting the SHDSL Annex type, move the cursor to **annex** and press [ENTER]. Select the annex type by using [TAB] key.

---

```
-----  
>> annex      Configure shdsl annex  
      margin     Configure shdsl margin  
      psd        Configure shdsl psd  
      pwr_backoff Configure power backoff  
      framer    Configure shdsl framer
```

Command: setup shdsl annex <Annex\_A|Annex\_B>  
Message: Please input the following information.

Annex Type (TAB Select) <Annex\_A>:**Annex\_B**

---

For setting SHDSL Margin, move the cursor to **margin** and press [ENTER].  
Select the startup margin via [TAB] key and key in the Next margin.

---

```
-----  
      annex      Configure shdsl annex  
>> margin     Configure shdsl margin  
      psd        Configure shdsl psd  
      pwr_backoff Configure power backoff  
      framer    Configure shdsl framer
```

## **Chapter 5. Configure via Console Port**

---

```
-----  
Command: setup shdsl margin <0~10|Disable>  
Message: Please input the following information.
```

```
Set Startup Margin (TAB Select 0~10): Disable  
-----
```

--

SNR margin is an index of line connection. You can see the actual SNR margin in STATUS SHDSL. The larger SNR margin, the better line connection. If you set SNR margin in the field as 2, the SHDSL connection will drop and reconnect when the SNR margin is lower than 2.

For configuring SHDSL PSD, move the cursor to **psd** and press [ENTER]. Select the parameter via [TAB] key.

---

annex	Configure shdsl annex
margin	Configure shdsl margin
<b>&gt;&gt; psd</b>	Configure shdsl psd
pwr_backoff	Configure power backoff
framer	Configure shdsl framer

## **Chapter 5. Configure via Console Port**

---

```
-----  
-  
Command: setup shdsl psd  
      <r1_asym|r2_asym|sym_enable|asym_disable>  
Message: Please input the following information.  
  
SHDSL PSD (TAB Select) <r1_asym>:r2_asym  
-----  
--
```

The SHDSL PSD will enable the transceiver to use an asymmetric power spectral density, as specified in the G.991.2 standard.

Possible values for PSD are:

r1\_asym: 786kbps for Annex A, 2312kbps for Annex B  
r2\_asym: 1552kbps for Annex A, 2056kbps for Annex B  
sym\_enable: Symmetric and Asymmetric enable.  
asym\_disable: Symmetric enable but asymmetric disable.

For configuring power backoff, move the cursor to **pwr\_backoff** and press [ENTER]. Select enable or disable via [TAB] key.

```
-----  
--  
-----
```

```
annex          Configure shdsl annex  
margin         Configure shdsl margin  
psd            Configure shdsl psd  
>> pwr_backoff  Configure power backoff  
framer         Configure shdsl framer  
-----  
-
```

Command: setup shdsl pwr\_backoff <enable|disable>  
Message: Please input the following information.

```
SHDSL Power Backoff (TAB Select) <disable>:enable  
-----
```

## **Chapter 5. Configure via Console Port**

---

The power backoff of SHDSL is a transmit power negotiation mechanism applied between STU-C and STU-R to limit the power transmitted on the SHDSL line to the minimum necessary for a clear signal to be received at the STU-C.


For configuring framer, move the cursor to **framer** and press [ENTER]. Select the parameters via [TAB] key.

```
-----  
annex          Configure shdsl annex  
margin         Configure shdsl margin  
psd            Configure shdsl psd  
pwr_backoff   Configure power backoff  
>> framer      Configure shdsl framer  
-----  
--
```

Command: setup shdsl framer <e1|Nx64k> <1~32> <1~31>  
Message: Please input the following information.


```
SHDSL Framer (TAB Select) <E1>:Nx64k  
Set Time Slot Number (Enter for default) <0>:8  
Set First Time Slot (Enter for default) <1>:1  
-----  
--
```

Though ITU 991.2 (SHDSL) supports data rate of 2304kbps, G.703 (E1) only supports data rate of 2048kbps so the maximum data rate of SHDSL line, connected with E1 DCEs, depends on data rate of E1, 2048kbps. There are two types of frames on SHDSL line, E1 and N x 64k. E1 frame only use for connection with E1 DCEs.



If the connection is E1 vs V.35 or V.35 vs E1, the frame has to be used N x 64k. In this case, the data rate depends on value of N. Same as above case, SHDSL and V35 can support 2304kbps data rate ( $36 \times 64k$ ) but E1 supports maximum data rate of 2048kbps ( $32 \times 64k$ ).


# Chapter 5. Configure via Console Port




Time slot, N value, is place of data in the frame. Time Slot Number 1~31 (N=1~31) is Fractional E1 and Time Slot Number 32 (N=32) is unframed.

## Fractional E1


For fractional E1, FE1, the data rate is from 64k, N=1, to 1984k, N=31, according to the E1 frame. If the E1 frame is FAS or FAS+CRC4, there are 1~31 available time slot for use data. If the data rate of SHDSL line set to be 512k, the time slot number is 8 and first time slot number is 1. The frame is shown as below.



The First Time Slot setting of FAS and FAS+ CRC4 have to follow the rule:




Using E1 frame of FAS+CAS or FAS+CAS+CRC4, the FAS will occupy Time Slot 0 and CAS Time Slot 16. There are only 30 Time Slot left for data. On the other hand, the data rate is 1920kbps.




The First Time Slot setting of FAS+CAS and FAS+CAS+CRC4 have to

## Chapter 5. Configure via Console Port

follow the rule:



### Unframed E1



### Configure EI parameters

This section introduce the setting of E1 code, frame, rai, built out and e\_bit. Select E1 and press [ENTER] or [RIGHT].

---

```
-----  
type      Configure shdsl type  
shdsl     Configure shdsl parameters  
>> e1      Setup el parameters  
default   Restore factory default setting
```

---

```
-----  
>> code      Configure el code  
frame      Configure el frame  
rai        Configure el rai  
build_outs  Configure el build outs  
e_bit      Configure el e_bit
```

---

For configuring code, move the cursor to **code** and press [ENTER]. Select the parameter via [TAB] key.

---

## ***Chapter 5. Configure via Console Port***

---

```
>> code           Configure el code
     frame          Configure el frame
     rai            Configure el rai
     build_outs     Configure el build outs
     e_bit          Configure el e_bit
```

## **Chapter 5. Configure via Console Port**

---

Command: setup e1 code <AMI|HDB3>

Message: Please input the following information.

SHDSL E1 code (TAB Select) <HDB3>:**HDB3**

---

HDB3      In this line coding, the transmitter substitutes a deliberate bipolar violation when excessive zeros in the data stream are detected. The receiver recognizes these special violations and decodes them as zeros. This method enables the network to minimum pulse density requirements. Unless AMI is required for your application, HDB3 should be used whenever possible.

AMI      Alternate Mark Inversion defines a pulses as a “mark,” a binary one, as opposed to a zero. In an E1 network connection, signals are transmitted as a sequence of one and zero. One is sent as pulse, and zero is sent as spaces, i.e. no pulse. Every other pulse is inverted from the previous pulse in polarity, so that the signal can be effectively transmitted. This means, however, that a long sequence of zero in data stream will cause problems, since the NTU receiving the signal relies on the signal to recover the 2048kbps clock.

For configuring frame, move the cursor to **frame** and press [ENTER]. Select the parameter via [TAB] key.

---

code	Configure e1 code
>> frame	Configure e1 frame
rai	Configure e1 rai
build_outs	Configure e1 build outs
e_bit	Configure e1 e_bit

# Chapter 5. Configure via Console Port

Command: setup e1 frame


<FAS|FAS+CRC4|FAS+CAS|FAS+CRC4+CAS|UNFRAMED>

Message: Please input the following information.

SHDSL E1 frame (TAB Select) <fas+crc4+cas> **:unframed**

## FAS


Frame Alignment Signal use 7-bit patterns to establish and maintain frame synchronization. The FAS word is located in timeslot 0 of frame. In FAS mode there are 1~31 timeslot available for use data.



## CAS

Also known as time slot 16 multiframing. It requires a multiframe alignment signal to be present for frame sync. The Multiframe Alignment Signal (MFAS) is inserted into the 16th timeslot of frame 0 of the 16-frame multiframe.


In CAS mode, there are 30 channels available for user data. If timeslot 16 is included in the unit's mapping, it will be disregarded.



## Chapter 5. Configure via Console Port

---

CRC4	The CRC-4 checksum bits are transmitted in the outgoing E1 data stream. Also the received signal is checked for errors. CRC-4 checksum cannot be sent in unframed mode.
Unframed	In this mode, user data is inserted into all 32 channels ( $64k \times 32 = 2048k$ ) of the E1 stream. The object of running without framing is to utilize the full bandwidth of the E1 line.



For configuring RAI, move the cursor to **rai** and press [ENTER]. Select the parameter via [TAB] key.

```
-----  
      code          Configure e1 code  
      frame         Configure e1 frame  
>> rai           Configure e1 rai  
      build_outs    Configure e1 build outs  
      e_bit          Configure e1 e_bit  
-----
```


```
Command: setup e1 rai <enable|disable>  
Message: Please input the following information.
```

```
SHDSL E1 rai (TAB Select) <disable>:enable  
-----
```

## **Chapter 5. Configure via Console Port**

---

Remote Alarm Indication (RAI) is a signal which transmits automatically when E1 line drop. For example: When STU-R E1 RX line is dropped, STU-R will send the status to STU-C via EOC or command. At the same time it will send RAI to DTE. STU-C will send AIS (Alarm Indication Signal) to DTE if AIS function is enabled.



For configuring build outs, move the cursor to **built\_outs** and press [ENTER]. Select the parameter via [TAB] key.

---

code	Configure el code
frame	Configure el frame
rai	Configure el rai
<b>&gt;&gt; build_outs</b>	Configure el build outs
e_bit	Configure el e_bit

---

Command: setup el built\_outs <120\_Ohm|75\_Ohm>  
Message: Please input the following information.

SHDSL E1 built\_outs (TAB Select) <120\_Ohm>:**75\_Ohm**

---

## **Chapter 5. Configure via Console Port**

---

For configuring e\_bit, move the cursor to **e\_bit** and press [ENTER]. Select the parameter via [TAB] key.

```
-----  
      code          Configure e1 code  
      frame         Configure e1 frame  
      rai           Configure e1 rai  
      build_outs    Configure e1 build outs  
>> e_bit        Configure e1 e_bit  
-----
```

```
-----  
Command: setup e1 e_bit <enable|disable>  
Message: Please input the following information.  
-----
```

```
SHDSL E1 e_bit (TAB Select) <disable>:enable  
-----
```

### Restore factory default

If you want to restore factory default setting in setup, select **default** and press [ENTER] or [RIGHT].

```
-----  
      type          Configure shdsl type  
      shdsl         Configure shdsl parameters  
      e1            Setup e1 parameters  
>> default      Restore factory default setting  
-----
```

```
-----  
Command: setup default  
Message: Please input the following information.  
-----
```

```
Are you sure? (y/n):y  
-----
```

If you enter “y” the setup field will be automatically configured to factory default setting.

# **VII. Write the Setup Parameter**

After configuration, write the new configured parameters into NVRAM and reboot the SHDSL NTU to work with new parameters. Follow the procedure;

**Step 1:** In main menu, move the cursor to **write** and press [ENTER].

```
-----  
setup      Configure system  
status     Show running system status  
show       View system configuration  
>> write    Update flash configuration  
reboot    Reset and boot the system  
diag       Diagnostic utility  
admin      Setup management features  
upgrade   Software upgrade  
exit       Quick system  
-----
```

**Step 2:** Type “y” to write the new parameters

```
-----  
Command: write <CR>
```

```
Message: Please input the following information.
```

```
Are you sure? (y/n): y  
-----
```

# **VIII. Reboot the SHDSL NTU**

For the SHDSL NTU to work with new parameters, you must reboot it after writing the parameters into NVRAM. Follow the procedure;

**Step 1:** In main menu, move the cursor to **reboot** and press [ENTER].

---

```
-----  
setup      Configure system  
status     Show running system status  
show       View system configuration  
write      Update flash configuration  
>> reboot   Reset and boot the system  
diag       Diagnostic utility  
admin      Setup management features  
upgrade   Software upgrade  
exit       Quick system  
-----
```

**Step 2:** Type “y” to reboot the SHDSL NTU.

---

```
Command: reboot <CR>  
Message: Please input the following information.
```

```
Do you want to reboot? (y/n):y
```

---

# **IX. View the System Status**

You can use the status command to view the status of SHDSL, E1 as well as statistic and clear the statistic log. Select **status** and press [ENTER].

```
-----  
      setup      Configure system  
>> status     Show running system status  
      show       View system configuration  
      write      Update flash configuration  
      reboot     Reset and boot the system  
      diag       Diagnostic utility  
      admin      Setup management features  
      upgrade    Software upgrade  
      exit       Quick system  
-----
```

Select **SHDSL** command to show the status of SHDSL.

```
-----  
>> shdsl      Show shdsl status  
      e1         Show e1 status  
      statistic  Show statistic  
      clear      Clear statistic  
-----
```

Select **e1** command to show the status of E1.

```
-----  
      shdsl      Show shdsl status  
>> e1        Show e1 status  
      statistic  Show statistic  
      clear      Clear statistic  
-----
```

## **Chapter 5. Configure via Console Port**

---

Select **statistic** command to show the statistic information in 15 minutes  
or

24 hour via [TAB] to choose.

---

```
shdsl      Show shdsl status
e1         Show e1 status
>> statistic Show statistic
clear      Clear statistic
```

---

---

```
Command: status statistic <15m|24h>
```

```
Message: Please input the following information.
```

---

```
SHDSL Statistic (TAB Select):15m
```

---

To clear the statistic log file, select **clear** and press [ENTER].

---

```
shdsl      Show shdsl status
e1         Show e1 status
statistic Show statistic
>> clear      Clear statistic
```

---

# **X. View the System Configuration**

You can use the status command to view the system configuration. Select **show** and press [ENTER] or [RIGHT].

```
-----  
      setup      Configure system  
      status     Show running system status  
>> show      View system configuration  
      write       Update flash configuration  
      reboot     Reset and boot the system  
      diag        Diagnostic utility  
      admin       Setup management features  
      upgrade    Software upgrade  
      exit        Quick system  
-----
```

To show system information, select **system** and press [ENTER] or [RIGHT]. The screen will prompt the system information.

```
-----  
>> system    Show general information  
      script     Show all configuration in command script  
-----
```

To show the system configuration, select **script** and press [ENTER] or [RIGHT]. The screen will prompt the configuration in script type.

```
-----  
      system    Show general information  
>> script   Show all configuration in command script  
-----
```

# **XI. Upgrade the SHDSL NTU**

This section will introduce how to upgrade the kernel and FPGA of the SHDSL NTU. Select **upgrade** in main menu and press [ENTER] or [RIGHT].

---

```
setup      Configure system
status     Show running system status
show       View system configuration
write      Update flash configuration
reboot    Reset and boot the system
diag       Diagnostic utility
admin      Setup management features
>> upgrade Software upgrade
exit       Quick system
```

---

Before upgrading the NTU you must have the main software or FPGA code in your computer.

If you want to upgrade the kernel:

1. Select **kernel** and press [ENTER] or [RIGHT].

---

```
>> kernel   Upgrade main software
          FPGA    Upgrade FPGA code
```

---

2. Confirm the process via pressing “y”

---

```
Command: upgrade kernel <CR>
Message: Please input the following information.
```

```
Are you sure (y/n)?: (Note: this will erase flash)y
```

---

## **Chapter 5. Configure via Console Port**

---

3. After entering “y”, the SMT will show

```
-----  
Utility running window...  
Starting XModem download...CCC  
-----
```

4. Click Send file in terminal access program, hyper terminal, to send the file.
5. Select the source file in window and press OK.
6. After upgrading the product, press “y” to write in flash.

If you want to upgrade the FPGA code:

1. Select **FPGA** and press [ENTER] or [RIGHT].

```
-----  
          kernel      Upgrade main software  
>>      FPGA       Upgrade FPGA code  
-----
```

```
Command: upgrade FPGA <CR>  
Message: Please input the following information.  
-----
```

```
Are you sure (y/n)?: (Note: this will erase flash)y  
-----
```

2. After entering “y”, the SMT will show

```
-----  
Utility running window...  
Starting XModem download...CCC  
-----
```

## ***Chapter 5. Configure via Console Port***

---

3. Click Send file in terminal access program, hyper terminal, to send the file.
4. Select the source file in window and press OK.
5. After upgrading the product, press “y” to write in flash.

# **XII. Diagnostic**

The diagnostic facility allows you to test the different aspects of your SHDSL NTU to determine if it is working properly. Select **diag** and press [ENTER] or [RIGHT].

```
-----  
      setup      Configure system  
      status     Show running system status  
      show       View system configuration  
      write      Update flash configuration  
      reboot    Reset and boot the system  
>> diag     Diagnostic utility  
      admin      Setup management features  
      upgrade   Software upgrade  
      exit       Quick system  
-----
```


Loopback can test whether the NTU is properly working with the connected device.

Press [ENTER] or [RIGHT] to setup the loopback.

```
-----  
>> loopback  Loopback  
      ber_test   Ber_test  
-----  
Command: loopback  
      <...local|remote_line|remote_payload|Farend_line|Farend_pa  
      yload>  
Message: Please input the following information.  
  
SHDSL Loopback Type (TAB Select) <disable>:  
      e1_line  
-----
```


# Chapter 5. Configure via Console Port

## Loopback Define E1 vs E1



E1_Line	La
Local	Lb
Remote Line	Lc
Remote Payload	Ld
Far End Line	Le
Far End Payload	Lf

## Loopback Define Fractional E1 vs V35



E1_Line	La
Local	Lb
Remote Line	Lc
Remote Payload	Ld
Far End Line	Le
Far End Payload	Lf

## ***Chapter 5. Configure via Console Port***

---

The SHDTU03 supports Bit Error Rate Testing (BERT). To configure the BERT, move the cursor to ber\_test and press enter.

---

loopback	Loopback
ber_test	Ber_test

---

Command: diag ber\_test <disable|2047|resync>

Message: Please input the following information.

SHDSL Ber\_test Type (TAB Select) <disable>**:2047**

---

### **XIII. Exit SMT**

For exiting SMT without saving any configuration, you can use the **exit** command to exit the SMT. Select **exit** and press [ENTER] or [RIGHT].

---

```
setup      Configure system
status     Show running system status
show       View system configuration
write      Update flash configuration
reboot    Reset and boot the system
diag       Diagnostic utility
admin      Setup management features
upgrade   Software upgrade
>> exit    Quick system
```

---

```
Command: exit <CR>
Message: Please input the following information.
```

```
Do you want to disconnect? (y/n) :y
```

---

After press [ENTER], the SMT will be disconnected.

## ***Chapter 5. Configure via Console Port***

---

This page is left in blank intentionally



# **APPENDIX**

---

## **Appendix I**

<b>AMI</b>	Alternate mark inversion
<b>B8ZS</b>	Bipolar 8 zero substitution
<b>CAS</b>	Also known as timeslot 16 multiframe, requires a multiframe alignment signal to represent for frame sync.
<b>CRC4</b>	Cyclic redundancy check 4 bit
<b>E BIT GEN</b>	Remote End Block Error Bit generation
<b>EOC</b>	Embedded operations channel
<b>ES</b>	Number of Error second (Errors/Second)
<b>ESF</b>	Extended super frame
<b>FAS</b>	Frame alignment signal
<b>LINE BUILD OUTS</b>	Cable used between NTU and Router or PABX
<b>LOSW</b>	Loss of synchronization word
<b>PSD</b>	Power spectral density
<b>RAI</b>	Remote alarm indication
<b>R1 ASYM</b>	Symmetric speed, 784kbps for Annex A or 2312kbps for Annex B
<b>R2 ASYM</b>	Symmetric speed, 1552kbps for Annex A or 2056kbps for Annex B
<b>SES(Severe Error Second)</b>	Number of SES (more than 832 CRC errors / second). Approximately equivalent to a bit error rate of $1 \times 10^{-3}$ .
<b>SF</b>	Super Frame
<b>SNR MARGIN</b>	Signal to noise ration margin
<b>SYNC</b>	Synchronization
<b>TX POWER</b>	Transmission power
<b>UAS</b>	Number of Unavailable second (more than 10 seconds.)

## **APPENDIX**

### **Appendix II**

#### **Connector Architecture**

Console Connector (RJ-45)

**The Console Port interface is a 8 position Modular Jack.**

**The table below displays the pin out assignments.**

<b>Pin Number</b>	<b>Description</b>	<b>Figure</b>
1	No connection	
2	No connection	
3	No connection	
4	GND	
5	RC	
6	TD	
7	No connection	
8	No connection	


Top View

Front View

## APPENDIX

### G.703 120O Connector (RJ-45)


The 120O E1 Port interface is a 8 position modular jack, the following table displays the pin our assignments.

Pin Number	Description	Figure
1	E1 interface receive pair-ring	 <b>Top View</b>
2	E1 interface receive pair-tip	
3	No connection	
4	E1 interface transmit pair-ring	
5	E1 interface transmit pair-tip	
6	No connection	
7	No connection	
8	No connection	

### SHDSL Interface Pin Assignments (RJ-45)

The SHDSL interface is standard eight-pin modular jack.

The table below displays the pin out assignments.

Pin Number	Description	Figure
1	No connection	 <b>Top View</b>
2	No connection	
3	No connection	
4	ANALOG Input/Output	
5	ANALOG Input/Output	
6	No connection	
7	No connection	
8	No connection	


# **APPENDIX**

---

## **Appendix III**

### **Cable Connection**

#### **DB9 vs. RJ45 Cable (Console)**



## **APPENDIX**

---

## **APPENDIX**

---





# **Transmission Units**

***CTC Union Technologies Co., Ltd.***

Far Eastern Vienna Technologies Center  
(NeiHu Technology Park)

8F, No. 60, ZhouZi St., NeiHu, Taipei, Taiwan

Phone:(886) 2.2659.1021 Fax:(886) 2.2.799.1355

E-mail: info@ctcu.com <http://www.ctcu.com>