


i-on160EX

Security System Engineering Guide



© Cooper Security Ltd. 2010

Every effort has been made to ensure that the contents of this book are correct. However, neither the authors nor Cooper Security Limited accept any liability for loss or damage caused or alleged to be caused directly or indirectly by this book. The contents of this book are subject to change without notice.

Printed and published in the U.K.

About this Guide

This manual applies to software used in the i-on160EX control unit with version 2.00 software.

This guide contains a detailed description of programming an i-on160EX system using the Installer Menu.

Other i-on160EX Publications

To install, connect and start up an i-on160EX control unit please read *i-on160EX Installation Guide*.

If you need to add or administer users (and their remote controls, PA buttons and proximity tags) then you must enter the User Menu. This is described in detail in the *i-on160EX Administrator's Guide*.

Setting the time and date is also an administrative user function.

If you wish to program an i-on160EX from a PC or laptop please read *i-on160EX Web Server Setup Guide* first.

Contents

About this Guide	ii
Other i-on160EX Publications	ii
Introduction.....	1
System Overview	1
System Design	1
The Control Unit	1
Keypads	3
Expanders	3
Communications.....	4
Programming the System	4
Part Setting or Partitioned System	4
System Security Grade.....	5
System Capacities	5
Basic Programming Procedures	6
Programming Before Installation	6
Entering and Leaving the Installer Menu.....	6
To Enter the Installer Menu:.....	6
To leave the Installer Menu at any time:	7
Important! Saving Changes.....	8
Defaulting the System	8
Restoring Factory Defaults	9
Defaulting Access Codes	11
Editing Text	12
The System Bus.....	14
Device Addressing on the Bus	14
Bus Device Addresses	15
Detector Connection Point Addresses.....	16
Output Numbering	17
Other Radio Device Addressing	18
Other Devices Connected to the Control Unit	18
Bus Scanning and Re-configuring	18
Zone Numbering	19
Mapping Zones to Device Connections	19
Adding/Removing Expanders and Zone Numbering	21
Zone 000	21
Processing Priority	22
Tampers and the Bus.....	22
Installer Menu.....	23
Installer Menu Options.....	32
Detectors/Devices	32
Detectors	32
Expanders	38
Wired Keypads	40
Deleting Keypads	41
Radio Keypads	42
External Sirens.....	43
WAMs	44
Outputs.....	44
Bell and Strobe	44
Wired Outputs.....	45
Control Unit Plug-By Outputs.....	45
Radio Outputs	45
Output Types	46
Programming User Defined Outputs	51

“Setting Options” and “Partitions” Menus	52
Part Setting or Partitioned System?	52
Options	54
Full Set Link	56
Calendar Set	56
System Options	60
Wired Zone Type	60
User Access	60
User Reset	61
DD243 (UK Only)	62
Masking	64
Mask Override	66
Language	66
Restore Defaults	66
Installer Name	67
Installer Code	67
Keypad Text	68
Remote needs Entry	68
PA Response	68
Auto Rearm	68
Siren Delay	69
Siren Time	69
Panel Loudspeaker	69
Entry Alarm Delay	70
Supervision	70
Jamming	70
Force Set	70
Tamper Omit	71
Anti-Code Reset	71
Silence Alerts	71
Mains Fail Delay	72
Battery 2	72
Communications	72
ARC Reporting	73
Speech Dialler	79
SMS	82
Line Fail Response	84
Line Fail Delay	85
IP Network (Own)	85
Downloading	87
Test	90
Sirens and Sounders	90
Wired Keypad	91
Radio Keypad	91
Walk test	91
Zone Resistances	92
Signal Strengths	93
Outputs	93
Remotes	94
User Panic Alarms	94
Prox Tags	94
ARC Reporting	94
Speech Dialler	95
PSU Current	95
Locate Bus Device	95
View Log	96
About	96
Panel	96

Comms	96
Zone Mapping	97
Non-Programmable Functions	97
Alarm Abort	97
Remote Reset (RedCare Reset)	97
Step By Step Programming Procedures.....	99
Addressing Keypads and Expanders on the Bus.....	99
To Manually Default The Bus Address Of An Expander.....	99
To Manually Default The Bus Address Of A Keypad	99
To Add An Expander Or Keypad To The Bus:	100
To Delete A Keypad or Expander From The Bus:	102
Expanders	103
To Disable or Enable an Expander:	103
To Replace an Expander:	105
Naming Wired and Radio Expanders	107
Assigning Wired and Radio Expanders to Partitions	108
Changing the Wiring Type of Wired Expanders	109
Editing Zones.....	110
Learning radio detectors	110
Deleting individual radio detectors	111
Deleting all radio detectors	112
Changing Zone Names, Type, Attributes and Partitions	113
Keypads	115
Naming a Wired Keypad	115
Assigning a Wired keypad to Partitions	116
Adding a Radio Keypad.....	117
Deleting a Radio Keypad.....	118
Naming a Radio Keypad.....	119
Assigning a Radio Keypad to Partitions	120
Naming and Programming Quick Set Keys.....	121
Sirens	123
Adding a Radio Siren.....	123
Allocating Sirens To Partitions	124
Deleting a Radio Siren.....	125
WAMs	127
Adding a WAM.....	127
Naming a WAM	128
Deleting a WAM.....	129
Outputs.....	130
Adding Radio Outputs.....	130
Giving a Radio Output a Type:.....	131
Naming a Radio Output	132
Giving a Wired Output a Type:	133
Naming a Wired Output.....	135
Changing the Polarity of a Wired Output:	136
Calendar Set.....	137
To add an exception:	137
To add an event:	138
To edit an event:.....	140
To delete an event:.....	141
System Options.....	142
Programming Remote Code Reset	142
Testing	144
To start testing	144
To walk test.....	144
Testing a Remote Control:	147
Testing a Radio Panic Alarm:.....	148

Testing a Proximity Tag:.....	148
Sending a Test Call to an ARC Number:	148
Sending a Test Call to a Speech Dialler Number:	149
Log.....	150
Viewing the Log.....	150
About	150
Finding The Current Panel Software and Language Version	150
Seeing Which Communications Module Is Currently Installed:	151
Finding IP Network Information For The Built-In Ethernet Port:	152
Appendix I: ARC Communication Formats	154
Fast Format.....	154
Contact ID.....	154
SIA 1, SIA 2, SIA 3 and Extended SIA 3.....	154
Appendix II: Programming a Common Area	156
Installation and Programming	156
Zone Programming	157
Partition and Other Programming	157
User Programming	158
User Operation	158
To set:	158
To Unset:	158
Appendix III: Using A WAM As A Repeater	160
Introduction.....	160
Before You Begin.....	160
Teach the Expander the Identity of the WAM	161
At The Control Unit:	161
On the WAM:	162
At the Control Unit.....	162
Teach the WAM the Identity of the Detectors	163
Deleting Devices	163
Appendix IV: Programming a 762 or 768/769 as an Output Module 165	165
Introduction.....	165
Before You Begin.....	165
Set Up the 762 or 768	165
Enter Programming Mode	165
Disable Infra-red learning	165
Set to manual learn	166
Select channel	166
Teach the i-on160EX to the 762r.....	166
At the Control Unit:	166
At the 762r.....	167
At the Control Unit.....	168
Index	169

Introduction

System Overview

i-on160EX is the control unit for a hybrid wired/wirefree alarm system intended for commercial use. One i-on160EX control unit can operate up to 160 zones by using expanders communicating over a single bus cable. Different types of expander allow either wired or wirefree detectors in the same system. The single bus cable also allows the installer to connect keypads, output modules or extra power supplies wherever they are needed.

System Design

The i-on160EX is designed to support a wide range of alarm system sizes. The control unit printed circuit board (pcb) itself provides ten zones and four outputs. To increase the size of the alarm system the Installer can connect expanders and keypads to a single "bus" which carries all the data between the control unit and its peripherals.

The control unit pcb provides connections only for wired zones and outputs. Expanders provide connections to either extra wired zones and outputs, or radio detectors and radio outputs. Both wired and radio devices can exist in the same alarm system.

The Control Unit

Case

A coated steel case houses the control unit's pcb, power supply and backup batteries. The case is designed for vertical mounting on a wall, and provides three fixing points. The case can be butted up to side walls or a ceiling without blocking the opening or closing of its lid. The case lid is fixed by a single screw, and can be hung from the case back when open. The back of the case provides pre-cut holes for cable access, and stands 14mm off from the mounting surface to allow trunking to pass behind.

As well as the pcb, the case provides room for two 17Ah backup batteries. Cooper Security provide securing clamps for each battery with the case.

Back tamper/Lid tamper. The back of the case provides a plastic shrouded slot through which the Installer can fit the combined back tamper/lid tamper switch. This switch is mounted on a metal blade that slides through the slot and touches the mounting surface. Once fitted and connected to the pcb, removing the lid or prising the case from the wall activates the switch.

Printed Circuit Board

All of the control unit functions and connectors are provided by a single pcb. A plastic pcb carrier holds the pcb within the case.

Bus Connections

The control unit provides connectors for one four-wire bus cable. All keypads, expanders and other equipment connect to the same bus. The cable can be run as one single line, or as a three or four armed star branched at the control unit. See *i-on160EX Installation Guide* for details of bus configuration, maximum bus length and cabling type.

Zone Connections

The control unit provides connections for up to 10 wired zones. These zones can be either all Closed Circuit (CC) or all Fully Supervised Loop (FSL). The Installer can select the zone wiring type during initial commissioning, or at any time after. Note that the Installer can make the wiring type of the expanders either CC or FSL, independent of the wiring type of the zones on the control unit.

Transistor Outputs

The control unit provides connectors for two programmable transistor outputs, which can be used to control external equipment. The outputs are normally switched negative, from 12V to 0V on activation. In this mode each output can sink up to 500mA from a dc source.

The installer can program these outputs to be switched positive (from 0V to 12V on activation). In this mode the outputs can deliver up to 500mA to an external load.

Relay Outputs

There are also sets of connectors for two relay outputs, providing voltage free changeover contacts. Both relay outputs are programmable by the Installer.

Digital Communicator Outputs

A set of 16 pins on the control unit pcb provide programmable outputs designed to control a separate digital communicator.

By default each output is switched negative (switched from +12V to 0V when active). When at 0V each communicator output can sink up to 100mA.

The installer can program these outputs to be switched positive when active (switched from 0V to +12V). When at +12V each output can provide up to 50mA to an external load.

USB Port

The USB (Universal Serial Bus) and Ethernet ports on the control unit pcb provide two different methods of connecting an external PC (personal computer) to the control unit.

The USB port allows an Installer to program the control unit through a local connection by USB cable from PC to control unit. The PC must be running Cooper Security's i-on Downloader.

The USB port also allows an Installer to apply software updates to the control unit, or install alternate language text files for the keypad display. To do this the Installer must run Cooper Security's i-on Updater software on the connected PC.

Ethernet Port

The Ethernet port also allows a local connection to a PC. The Ethernet connection is designed to allow an Installer to program the control unit through a series of web pages presented by a built-in web server running on the control unit. Cooper Security recommend that you use Internet Explorer 8 to browse the pages.

External Bell Output

The control unit has one external bell output to drive standard Self-Activating Bell (SAB) or Self-Contained Bell (SCB) modules. Expanders also provide connectors for additional external sounders. See *i-on160EX Installation Guide* for details of maximum current available for external bells.

Extension Loudspeaker Connectors

If required the Installer can connect one 16Ohm extension loudspeaker to increase the audibility of setting and unsetting tones. Each expander also provides connectors for a 16Ohm extension loudspeakers. Note that you must not connect another loudspeaker in parallel to these connectors.

Battery Backup

As noted above, the case provides space for two 17Ah backup batteries. Each battery has its own connector on the control unit pcb, and is charged by the control unit while mains power is present.

It is possible to run the system with a single backup battery (although the resulting standby time may not meet the Grade 2 or Grade 3 requirements). If you chose to use a single battery, then you should connect the battery to connector "BATT1" and program the control unit to suppress alerts that Battery 2 is missing, see page 72.

Keypads

The i-on160EX uses i-kp01 keypads with keypad firmware version 2.0 and above. The keypad has a two line by 20 character backlit LCD display and a built in proximity tag (prox tag) reader. All keypads connect directly to the system bus.

Users can set and unset the system or partitions from the keypad, either by keying-in access codes or presenting a prox tag.

Provided that they are in separate partitions, the control unit can process up to five keypads in use at the same time. Within a partition, the control unit responds to just one keypad at a time. In a part setting system (one not using partitions) the control unit responds to just one keypad at a time.

The Installer can also program the system from the keypad.

Expanders

Wired Expander The EXP-W10 wired expander provides connections for:

Either 10 FSL zones or five CCL zones.

One loudspeaker

Four wired programmable outputs

Radio Expander The radio expanders provide channels for either 10 radio detectors (EXP-R10) or 30 radio detectors (EXP-R30). In addition each radio expander provides channels for: two radio keypads, two external radio sounders and two Wireless Accessory Modules (WAMs). Each radio expander also provides wired connections for a Loudspeaker.

Note: The total number of radio detectors that can be

handled by an i-on160EX control unit depends partly on the density of radio transmitters within a given volume. If there are more than 30 transmitters within 10 meters radius of an expander then some mutual jamming may occur. Please read "Guidance Notes For Radio Alarm System" available from www.coopersecurity.co.uk.

Communications

The i-on160EX provides a socket for an add-on communication module. To comply with EN50131 you must fit a module. The available modules are:

- i-sd-02 A speech dialler and public switched telephone network (PSTN) module that allows the control unit to send recorded speech messages and also report alarm information using standard protocols such as Fast Format and Contact ID. This module also allows remote maintenance over the PSTN.
- i-gsm02 A GSM module that allows speech messaging, alarm reporting and SMS text messaging over the mobile phone network.
- 8750 An Ethernet module that allows alarm reporting and remote maintenance over the internet.
- 8844 A GPRS module that allows internet protocol access over the mobile phone network.
- i-dig02 A PSTN module that allows the control unit to report alarm information using standard protocols such as Fast Format and Contact ID. This module also allows remote maintenance over the PSTN.

Programming the System

As an installer you can program the system in any of three separate ways:

- a) From the keypad.
- b) From a PC or laptop connected to the control unit via Ethernet cable, and using a web browser (IE 8 recommended).
- c) From a PC or laptop connected to the control unit either over the PSTN or via the USB port, using i-on Downloader software.

This manual describes programming the i-on160EX from the keypad. However, the settings and options provided through the keypad are the same as those provided by the web server or i-onDownloader.

Part Setting or Partitioned System

The i-on160EX offers two basic ways of behaving as an alarm system:

Part Set Mode. In Part Set Mode the i-on160EX can set in one of four ways: either Full set or three varieties of Part Set. In Full Set the control unit pays attention to all detectors. In each of the three Part Sets, the control unit ignores all detectors that do not have the appropriate Part Set attribute (see page 37).

Partition Mode. In Partition Mode the i-on160EX provides the equivalent of 20, smaller, independent alarm systems. Each system is a "Partition" of the i-on160EX. You can allocate any set of zones to each Partition. Each zone can also belong to more than one Partition. Each Partition can have a Full Set level and one Part Set level. During programming the installer can allocate keypads, sounders or outputs to any of the partitions.

System Security Grade

During initial power up (and if you reset a system to factory defaults) the system provides an opportunity for you to set various system options in one step in order to program the system for either Security Grade 2 or Security Grade 3.

Grade 2 The system uses four digit user codes, puts Masking OFF, defaults User Reset – Tamperers to "yes", and ensures that Tamperers are communicated as Alarms.

Grade 3 The system uses six digit user codes, puts Masking ON, defaults User Reset – Zone Tamperers and User Reset – Zone Alarms to Installer. The system communicates tamperers as tamperers, and also defaults the Omittable zone attribute to "No".

You can override any of the settings by selecting individual options in other parts of the Installer Menu. Note that if you do so then the system may no longer comply with the selected Grade.

User Codes

When using four digit access codes, the default Installer code is "7890" and the default User01 code is "1234".

When using six digit access codes the default Installer code is "567890", and the default User01 code is "123456".

System Capacities

Zones	160 max
Outputs	164 max
Partitions:	20 max
Bus devices:	45 max, shared between expanders and keypads
Radio Keypads:	20 max, two per expander
Radio sounders	20 max, two per expander
WAMs	20 max, two per expander
Users:	500 max
Remote Controls	500 max (one per user)
Proximity tags	500 max (one per user)
Radio PAs	500 max (one per user)

Basic Programming Procedures

Programming Before Installation

If you prefer, you can program the control unit before installing the system in its final location. You will need to temporarily connect a keypad to the control unit.

It is possible to operate the control unit from battery power (or a 12Vdc supply) without connecting the unit to a mains supply. However, in order to start the control unit processor running you must briefly short the Kick Start pins together after connecting the battery.

When programming the system while it is running on battery only, remember to leave the Installer Menu before removing power. If you do not do so all your changes will be lost, see *Important! Saving Changes* on page 8.

If you wish to program the control unit from a laptop or PC you can do this by connecting the control unit to your PC via Ethernet. You will need a CAT 5 patch cable and a laptop or PC with a standard web browser. See the separate publication *i-on160EX Web Server Set Up Guide* for instructions on how to set up your PC/laptop and the control unit.

Entering and Leaving the Installer Menu

When you enter the Installer Menu from a keypad, the alarm system is effectively disabled. While the system is in Installer Menu:

Any other user trying to set the system from a keypad will see the message "Installer on Site".

All PAs (including radio PAs), fire alarm zones, 24 hour zones and tampers are disabled.

Note that this does not apply if you are using the web browser interface from a PC. If you have logged into the system from a PC then the alarm system is active.

To Enter the Installer Menu:

1. Make sure the system is unset and showing the standby screen (time and date).
2. Key in the Installer access code. When delivered from the factory, at Security Grade 2 the default Installer access code is "7890". The default user code is "1234". At Security Grade 3 the codes are "567890" and "123456" respectively.

```
i-on160EX
12:00 23/07/2010
```

As you start to key in the code the display shows:

```
Enter Access Code:
(*)
```

When you key in the last digit of the access code the display MAY show:

```
User Code Required
( )
```

If this happens key in a valid user code (not a Set Only user code see note 1).

When you key in the last digit of the access code the display shows "Installer Menu" on the top line. The bottom line shows the first option in the Installer menu: Detectors/Devices. (See note 2.)

```
INSTALLER MENU
Detectors/Devices >
```

3. Press ▲ or ▼ to display more options from the menu.

Each option appears on the bottom line of the display in turn, for example:

```
INSTALLER MENU
Outputs >
```

4. Press ► or ✓ to select that option of the menu.

The option you selected now appears on the top line. If there are any sub-options for that selection, then the first of them appears on the bottom line. Press ▲ or ▼ to display the other sub-options.

```
OUTPUTS
Radio Outputs >
```

Notes:

1. After you initially gain access to the Installer Menu, you may leave and re-enter using the Installer access code by itself for up to 30 minutes after you last exited the Installer Menu. After that time you will need to enter a valid user access code to complete your entry into the Installer Menu (note that you cannot use a Set Only user code). To disable this feature see System Options – User Access – User Code Required on page 61.
2. If you key in the code incorrectly, the display shows the time and date again, and gives an error tone. Key in the code again. If you key in a total of ten consecutive incorrect codes then the system locks you out for 90 seconds.

To leave the Installer Menu at any time:

1. Press ✕ until the display shows:
2. Replace the control unit lid (if you removed it earlier). Ensure the control unit tamper switch is closed.
3. Press ✓ to leave Installer menu.
(Press ✕ if you do not want to leave the menu.)

```
Leave
installer mode ?
```

The display shows:

```
Please wait...
```

The control unit scans the bus to check for any devices that have been added or removed without using the installer menu. On a large system this may take tens of seconds.

When the control unit has finished scanning the bus, the display time and date. The system is

```
i-on160EX
12:00 02/11/2010
```

ready for use.

If the control unit finds a device missing, or one with an address that has not been added using the Installer Menu then the display shows, for example:

```
FOUND 0, LOST 1  
Lost R1-03
```

The top line of the display shows the number of new devices found, and the number of existing devices missing (lost). The bottom line of the display shows the first in the list of found and lost devices.

4. **Either:** press **✕** to put the control unit back into Installer Menu (so that you can go and check that all the bus devices you have installed are connected, powered up and addressed correctly).

Note: To check an expander address remove the lid and briefly press the addressing button. The two digit display will show the bus address for a few seconds.

OR: Press **✓** to make the control unit update its internal record of devices attached to the bus.

The display shows:

```
Accept all changes  
to bus
```

5. Press **✓** to accept the change to the bus. (You can still press **✕** to return to the installer menu if you do not want to change the number of devices on the bus.)

*Note: If you attempt to leave the Installer Menu when there is a fault (for example a detector–, control unit lid–, siren– or keypad tamper is active, or the battery is missing) then the keypad displays a fault message telling you which device is causing the problem. Press **✕** to return to the Installer Menu. You must rectify the fault (or delete the device from the system) before you can leave the Installer Menu.*

Important! Saving Changes

When you make changes to the Installer Menu the control unit holds those changes in temporary memory until you leave the Installer Menu. As you leave the Installer Menu the control unit writes those changes into a permanent store. If you remove all power BEFORE you leave the Installer Menu then the control unit will lose your changes. Note that this does not apply if you restore Factory Defaults; that change takes place immediately.

Defaulting the System

If you wish to restore the control unit to its factory defaults then you must do this from a keypad. You cannot restore factory defaults from a connected PC.

Note that this procedure deletes all radio detector identities.

Restoring Factory Defaults

1. Enter the Installer Menu.

```
INSTALLER MENU
```

2. Press ▼ until the bottom line shows System Options:

```
Detectors/Devices >
```

```
INSTALLER MENU
```

```
System Options >
```

3. Press ✓.

The display shows:

```
SYSTEM OPTIONS
```

```
Wired zone type
```

4. Press ▼ until the bottom line shows:

```
SYSTEM OPTIONS
```

```
Restore defaults >
```

5. Press ✓.

The display shows:

```
RESTORE DEFAULTS
```

```
Country defaults >
```

6. Press ▼ until the bottom line shows:

```
RESTORE DEFAULTS
```

```
Factory defaults >
```

7. Press ✓.

The display asks for confirmation.

```
FACTORY DEFAULTS
```

```
Are you sure?
```

8. Press ✓ to load defaults.

(Press ✕ to go back to the Installer Menu without changing defaults.)

The display asks you to select Partition Mode or Part Set Mode. (See page 4.)

```
A : Partition mode
```

```
B : Part set mode
```

9. EITHER: Press A to create a partition based system.

OR Press B to create a part setting system.

The display asks you to select the Security Grade. (See page 5.)

```
SYSTEM GRADE
```

```
*Grade 3
```

10. Press ▲ or ▼ to select either Security Grade 3 or Security Grade 2 settings.

Note: If you change Grades then the keypad display reminds you that all user codes will be defaulted.

(If you change your mind at this point and do not wish to default user codes then press ✕ to stay with the current security grade.)

Press ✓ to confirm your selection.

The display asks you to select the zone wiring type. (See page 60.)

```
WIRED ZONE TYPE
```

```
*2-wire FSL 2k2/4k7
```

11. Press ▲ or ▼ to display the desired wiring type on the bottom line of the display.
12. Press ✓ to confirm the selection.

```
WIRED ZONE TYPE
4-wire CC
```

The system loads all defaults except for the Log.

Note: The log is protected and cannot be erased by the Installer or any user.

The display briefly shows:

```
Factory defaults
restored
```

Followed by:

```
RESTORE DEFAULTS
Factory defaults >
```

13. Press ✕ until the display shows:

```
Leave
Installer mode?
```

14. Press ✓.

The display shows:

```
Please wait...
```

The control unit scans the bus. After a delay of anywhere between a few seconds to a few tens of seconds (depending on the number of expanders fitted) the display shows, for example:

```
FOUND 3, LOST 0
Found R1-01
```

The top line of the display shows the number of new devices found. Because you have restored factory defaults the control unit has erased its internal list of bus devices and the display should not show any missing devices. So, if a device is attached to the bus but not powered up then the control unit will not detect it. The bottom line of the display shows the first in the list of found devices. Press ▼ to see any other items in the list.

15. Press ✓.

The display shows:

```
Accept all changes
to bus?
```

16. Press ✓.

The control unit saves your changes and the display shows the time and date:

```
i-on160EX
12:00 02/11/2010
```

Note: If the control unit has an i-sd02 fitted then the keypad will show an alert when you leave Installer Mode. The alert is for PSTN Line Fault. The reason for the alert is that defaulting the system has deleted all programmed telephone numbers. Re-enter Installer Menu and either re-key the appropriate telephone numbers, or disable communications by setting Communications – ARC Reporting – Call Mode to "Disabled".

Defaulting Access Codes

If the User and/or Installer codes are lost then you can set the installer and Master User codes to their default and delete all the other users, including their tags, remote controls and PAs.

1. If possible, enter the Installer menu.

```
INSTALLER MENU
Detectors/Devices >
```

Note: If you cannot enter Installer Menu then the control unit will start a tamper alarm when you open its lid.

2. Remove mains power, then open the control unit and disconnect all batteries.

Note: This procedure will not work if the control unit lid tamper remains closed.

3. Identify the Reset Codes pins on the main PCB (see *i-on160EX Installation Guide*).
4. Short the Reset Codes pins together using a small screwdriver or jumper link. (Keep the short on until step 6.)
5. Apply mains power.

The control unit loads the factory default access codes:

Grade 2: User 01=1234, Installer=7890.

Grade 3: User 01=123456, Installer=567890.

The control unit starts a tamper alarm. After a pause of several seconds (during which the keypad display shows first the software revision of the keypad and then the words "Please wait...") the keypad display shows the time and date.

The red LEDs glow to show an alert that the control unit lid is open.

6. Remove the short from the Reset pins.
7. Reconnect the batteries.
8. Close the control unit lid (to restore the tamper switch).

```
I-ON160EX
00:00 01/11/2010
```

The display shows the time and date, for example:

9. Key in the default User 01 code to silence the sounders.

The display shows:

```
Call Installer
Panel lid open
```

10. Enter Installer Menu and then leave it again.
The LEDs around the navigation key should now be green. If they glow red then there may be an alert for a missing battery that needs acknowledgement.
11. To force the control unit to check the battery:
Press ✓, key in 1234 (or 123456 for Grade 3), press ✓ again.

The navigation key LEDs should now glow green.

```
i-on160EX
12:00 02/11/2010
```

Editing Text

In the i-on160EX zones, setting levels, partitions, keypads, expanders, outputs and users can all be named. Also, account numbers for i-on Downloader can take letters as well as numbers. Whenever you have to edit the text for an item the steps are the same:

Each number on the keypad is associated with a range of letters in the same way as on many mobile phones. Figure 1 shows which letters appear on each key.




Figure 1. Letters Assigned to Keys

A cursor on the display shows where the next character will go when you key it in. If you are keying in capitals the cursor is a block, for small letters the cursor is an underline.

To change between capital and small letters press #.

When you first select a name to edit, the display shows the cursor at the beginning of the bottom line. If you press a number or letter key then the bottom line clears and the character you keyed-in appears at the beginning of the line.

Alternatively, if you press ► when you first select a name to edit, then the existing text shifts right one character and you can insert a new character in the empty space.

To move the cursor left or right press ▲ or ▼ respectively. To delete characters press ◀.

Note: If you wish to leave a name or text unchanged then press ✕. The display leaves the name change screen and restores the name to its previous value.

Press ✓ when you have finished entering text.

The System Bus

The system bus carries all the data between the control unit and its expanders and keypads. Electrically the bus is a single set of four conductive paths. Two paths carry dc power and two carry data. Physically the bus cable can connect the devices in either daisy-chain or star arrangements – see Figure 2.




Figure 2. Bus Layout Example

See *i-on160EX Installation Guide* for details of bus configuration, maximum bus length and cabling type. As part of programming the i-on160EX you will need to understand how devices are addressed, and how to add and delete them correctly.

Device Addressing on the Bus

Each device on the bus has a unique address. The device obtains this address from the control unit, either during the commissioning stage of a new installation, or at some later date under control of the Installer Menu when the installer adds the device. Once the device has obtained a bus address, the device stores that address in non-volatile memory.

During subsequent programming at the control unit the Installer also assigns other information to each bus device, for example allocating them to partitions, or programming the zone types and attributes of any zones attached to expanders. The control unit stores this information within itself (NOT within the bus device).

This means that if you need to remove a bus device, and perhaps install it on another system then you must:

Delete the device information from within the control unit. Each type of device has its own "delete" command in the Installer menu.

Reset the bus address on the device to zero.

See page 99 for detailed instructions on adding and deleting bus devices.

If a bus device is damaged and you suspect it is faulty then you can use the Installer menu to temporarily disable the device. The control unit will ignore any input from the device while it is disabled, and not send any output commands to the device. When the time comes to replace the damaged device then the Installer menu provides a "Replace" command that you can use to swap out the damaged unit for a new one, retaining all the device information from the old unit. See page 105 for detailed instructions on disabling and replacing bus devices.

Bus Device Addresses

The control unit reports the addresses of bus devices as two groups of characters, separated by a "-":

An-dd

A = A letter showing the device type: P=panel, K=keypad, W=Wired Expander, R=Radio Expander, O=Output Module.

n = Bus number. In an i-on160EX the bus number is always 1.

dd = Bus device number. In an i-on160EX this can be any number 01 to 99 (but there can only be a total of 45 devices).

Expanders always have bus device numbers in the range 01 to 49. Keypads and output modules always have bus device numbers in the range 51 to 97.

Figure 3 shows an example of how the control unit in a small system might address each device attached to the bus. The system has two 10-zone expanders and three keypads. Each device has one address.




Figure 3. Bus Device Addressing Example

The EXPR-30 is a bus device that uses more than one device address. In Figure 4 the second expander on the bus is an EXPR-30. The EXPR-30 always takes three consecutive bus device numbers. In Figure 4 the control unit gives this one device the numbers R1-02, R1-03 and R1-04. In the Installer menu the keypad display shows only "R1-02" but also adds the characters "(R30)" at the end of the line as a reminder.




Figure 4. Bus Device Addressing for EXP-30.

Detector Connection Point Addresses

Each connection point for a detector has an address. This address is an extension of the bus device address.

The control unit shows the connection point address as three groups of characters:

$$An < dd < ii$$

$An < dd$ The first two groups are the address of the bus device, see the previous page. The "A" can be either "R" for a radio expander or "W" for a wired expander.

< The "<" character is a reminder that the address is a detector (a form of input).

ii = The last group is the input number. For wired expanders this can be any number from 0 to 9. For radio expanders this can be any number from 0 to 9 for the EXP-R10, or 00 to 29 for the EXP-R30.

The detector connection points on the control unit pcb are numbered P0<00<00 to P0<00<09 (FSL wiring) or P0<00<01 to P0<00<05 (CCL wiring).

See Figure 5 for examples:




Figure 5. Detector Connection Point Addressing on an i-on160EX.

Output Numbering

Output numbering is an extension of the way that devices are addressed on the bus. Each output has a connection point address. The address contains three groups of digits:

$$A n > d d > o o$$

$A n > d d$ The first two groups are the address of the bus device (see page 15). The "A" can be a "P" for the panel, "W" for a wired expander or "R" for a radio expander.

$>$ The ">" character is a reminder that the address is an output.

$o o =$ The last group is the output number.

Outputs connected directly to the control unit are numbered $P 0 > 0 0 > 0 1$ to $P 0 > 0 0 > 0 4$. See Figure 6 for examples:




Figure 6. Output Numbering on an i-on60.

Other Radio Device Addressing.

For radio keypads, radio sirens and WAMs, during the learning process the installer selects a specific radio expander to learn the identity of the radio device. This means that when programming these devices the control unit refers to them by a number containing three groups of characters (similar to the characters the system uses to refer to zones and outputs):

Rn-dd-zz

Rn-dd The first two groups are the address of the bus device (see page 15).
The "R" indicate that the device is a radio expander.

zz = The last group is the radio device number.

Radio Device Numbering

When reporting alarms to an ARC using CID or SIA protocols the control unit reports each device as a number (not as an address). Each type of device has its own numbering range:

Radio Siren	Ext.01 to Ext.20
WAMs	WAM01 to WAM20

Other Devices Connected to the Control Unit

Other devices connected directly to the control unit use a simpler addressing scheme:

Sirens/Strobe	"Siren" and "Strobe"
Loudspeakers	01 and 02
Plug-by Outputs	01 to 16.

Bus Scanning and Re-configuring

The control unit keeps an internal list of every bus device that it has learned. In order to keep the list up to date the control unit carries out two functions: **bus scan** and **bus re-configure**.

During a **bus scan** the control unit asks every device on the bus to report its bus address. The control unit compares the addresses reported with the addresses that it has stored in its list. If a device has a default bus address the control unit ignores it.

Bus scanning takes place during power up and when the installer leaves the Installer Menu.

If the devices reporting to the control unit do not match the stored list of devices, then the control unit offers to **re-configure** the bus. If there are additional devices on the bus then the control unit will add those to the list of devices that it knows about. If there are fewer items on the bus than on the list, then the control unit will remove those missing devices from its list.

The control unit re-configures the bus while it is still in the Installer Menu. When the control unit leaves Installer Menu it stores the changed bus device list in non-volatile memory (nvram).

This has the following implications:

- Carrying out a bus scan does not change the bus configuration. Note that on large systems a bus scan may take some minutes.
- If you are confident that the control unit has already learned all the devices on the bus you do not have to carry out a bus scan (but it may be a useful check).

If you have temporarily removed a bus device you can reconnect it to the bus, provided that you carry out a bus scan and do not change its bus address.

- If, as a result of a bus scan, the control unit offers to re-configure the bus (and you accept) then new devices will be added to the system only if they already have a bus address. Missing devices will be removed from the system (along with all details of the partitions they belong to, and any zone information).
- A bus re-configure is not saved until you leave Installer Menu. If the control unit loses power before leaving Installer Menu then the bus re-configure does not take effect.

Zone Numbering

When reporting alarms to an ARC using CID or SIA protocols the control unit reports each detector as a zone number. The i-on160EX numbers zones in a continuous range from 001 to 159. The zone numbers are independent of the physical connection points for each detector. The process of assigning zone numbers to detector connection points is called "mapping".

Mapping Zones to Device Connections

The control unit assigns blocks of zone numbers to each bus device sequentially.

1. The connection points on the control unit pcb take zone numbers 001 to 009 (for FSL wiring) or 001 to 005 (for CC wiring).
2. Each bus device takes a sequential block of zone numbers, running on from the previous bus device.

Figure 7 shows the zone numbers used by the example system in Figure 5.




Figure 7. Zone Numbering Example.

In table form, the zone numbering for the example in Figure 3 would look like this:

Control Unit			EXPW-10 (device 1-01)			EXPR10 (device 1-02)		
Zone No.	Address	Used	Zone	Address	Used	Zone	Address	Used
Zone 0	P0<00<00	*	Zone 10	W0<01<00	*	Zone 20	R0<02<00	*
Zone 1	P0<00<01	*	Zone 11	W0<01<01	*	Zone 21	R0<02<01	*
Zone 2	P0<00<02	*	Zone 12	W0<01<02	*	Zone 22	R0<02<02	*
Zone 3	P0<00<03	*	Zone 13	W0<01<03	*	Zone 23	R0<02<03	*
Zone 4	P0<00<04		Zone 14	W0<01<04	*	Zone 24	R0<02<04	*
Zone 5	P0<00<05		Zone 15	W0<01<05		Zone 25	R0<02<05	
Zone 6	P0<00<06		Zone 16	W0<01<06		Zone 26	R0<02<06	
Zone 7	P0<00<07		Zone 17	W0<01<07		Zone 27	R0<02<07	
Zone 8	P0<00<08		Zone 18	W0<01<08		Zone 28	R0<02<08	
Zone 9	P0<00<09		Zone 19	W0<01<09		Zone 29	R0<02<09	

The control unit has allocated each device a block of zone numbers, up to the capacity of the device.

Figure 8 shows the zone numbering when an EXPR-30 forms part of the system.

Zone 1 -> P0<00<01
...
Zone 4 -> P0<00<04

Zone 20 -> R1<02<00
...
Zone 49 -> R1<02<29




Figure 8. Zone Numbering with EXR-30.

Note how the EXPR-30 takes three consecutive bus device addresses, and the zone numbers occupy a contiguous block of 30.

Adding/Removing Expanders and Zone Numbering

At some point after the initial installation you may wish to replace one of the expanders:

You can replace an EXPR-30 with up to three EXPR-10 or EXPW-10 expanders. The control unit will use the three bus device numbers that were allocated to the EXPR-30.

If you wish to add an EXPW-30 but there are not three spare device numbers next to each other, then the control unit will not let you add the device.

Zone 000

Connection point P0<00<00 (the first zone terminal on the control unit pcb) is available for use as a valid zone. However, please note that SIA and CID cannot report any alarms on zone 000. Cooper Security suggest that you might find this zone useful as a Log Only zone.

Processing Priority

When several detectors are activated at the same time, the control unit always processes PA and Normal Alarm detectors first, followed by Fire, and then all other alarm types. The control unit always processes alarms before Alerts.

Tampers and the Bus

Every device that can be attached to the bus has its own anti-tamper switch. When this switch is triggered the device sends a message down the bus to the control unit, which then starts the appropriate alarms, shows a tamper alert on the keypad and communicates a tamper message to the ARC.

If a bus device is disabled, and cannot send any messages on the bus then the control unit marks it as "missing". (A bus device might be disabled by physical damage, loss of power, or by a cut bus cable. The control unit starts a tamper alarm and displays an alert at the keypad, for example "P1:Missing R1-03" for an expander or "P1:Missing K1-52" for a keypad. In a Grade 3 system the control unit will also communicate a missing bus device to the ARC as a tamper.

Installer Menu

Important: Where noted below the defaults listed enable the control unit to comply with EN50131 requirements. If you change those settings then the installation may no longer comply. If the control unit does not comply with EN50131 you must remove any labelling that indicates compliance.

MENU Option	Factory Default	Notes
1 DETECTORS/ DEVICES		
Detectors		
Add/Del Detectors		
Zone 1-160...		Appears only if a radio detector is learned in.
Delete all		
Program Zones		
Zone 1...160		
Name	"Zone nnn"	
Type	Not used	
Partitions	Partition 1	Appears only in a Partitioned system and when zones have a type other than "Not Used".
Attributes	Chime: No Soak Test: No Double Knock: No Part Set B: No Part Set C: Yes Part Set D: Yes Part Set: No (not in a level setting system) Omittable: No Force Set Omit: No Masking: No	Appears when zone is given a type other than "Not Used"
Zone Mapping		Appears only if "Manual Mapping" selected during initial power up.
Address Bus Devices		
Wired Expanders		
Address Bus Device		
Edit Expander		
Expander 1-01...1-45		
Name	"Exp. W1-nn"	nn is between 01 and 45
Partitions	Partition 1.	Appears only in a partitioned system.
Wired zone type		FSL 2k2/4k7
Loudspeaker volume		Zero when first added to bus.
Delete Expander		
Expander 1-01...1-45		
Enable Expander	Yes	All expanders enabled.
Replace Expander		
Radio Expanders	"Exp. R1-nn"	nn is between 01 and 45
Address Bus Device		
Edit Expander		
Expander 1-01...1-45		
Name		"Exp.-" plus bus address

Partitions	Partition 1	Appears only in a partitioned system.
Loudspeaker Volume		
Delete Expander		
Expander 1-01...1-45		
Enable Expander	Yes (all expanders enabled).	
Replace Expander		
Wired Keypads		
Address Bus Device		
Edit Keypad		
Keypad K1-51...K1-99		
Name	"Keypad K1-nn".	nn is between 51 and 99
Partitions	Partition 1	Appears only in a Partitioned system.
Key A	Name: "Key A" Action: Partition 1 Full Set OR Full Set	Appears only in a Partitioned system.
Key B	Name: "Key B" Action: Partition 2 Full Set OR Part Set B	
Key C	Name: "Key C" Action: Partition 3 Full Set OR Part Set C	
Key D	Name: "Key D" Action: Partition 4 Full Set OR Part Set D	
Delete Keypad		
Radio Keypads		
Add/Del Radio Keypad		
Edit Keypads		
Name	"Radio Kpd 0n"	
Partitions	Partition 1	Appears only in a Partitioned system.
Key A	Name: "Key A" Action: Partition 1 Full Set OR Full Set	Appears only in a Partitioned system.
Key B	Name: "Key B" Action: Partition 2 Full Set OR Part Set B	Appears only in a Partitioned system.
Key C	Name: "Key C" Action: Partition 3 Full Set OR Part Set C	Appears only in a Partitioned system.
Key D	Name: "Key D" Action: Partition 4 Full Set OR Part Set D	Appears only in a Partitioned system.
External Sirens		
Add/Delete Ext. Siren		
Edit external siren	Partition 01	Appears only in a Partitioned system.
WAMs		
Add/Del WAM		
Edit WAM		

2 OUTPUTS																																																					
Radio outputs																																																					
Add Outputs																																																					
Edit Outputs																																																					
Exp. R1>nn>01...08	<table><tr><th>Name</th><th>Type</th><th>Polarity</th></tr><tr><td>O/P R1>00>01</td><td>Not Used</td><td>Normal</td></tr><tr><td>...</td><td></td><td></td></tr><tr><td>O/P R1>00>08</td><td></td><td></td></tr></table>	Name	Type	Polarity	O/P R1>00>01	Not Used	Normal	...			O/P R1>00>08																																										
Name	Type	Polarity																																																			
O/P R1>00>01	Not Used	Normal																																																			
...																																																					
O/P R1>00>08																																																					
Wired outputs																																																					
Panel	<table><tr><th>Name</th><th>Type</th><th>Polarity</th></tr><tr><td>Siren</td><td>Siren</td><td>Normal</td></tr><tr><td>Strobe</td><td>Strobe</td><td>Normal</td></tr><tr><td>P0>00>01</td><td>Siren</td><td>Normal</td></tr><tr><td>P0>00>02</td><td>Strobe</td><td>Normal</td></tr><tr><td>P0>00>03</td><td>Siren</td><td>Normal</td></tr><tr><td>P0>00>04</td><td>Strobe</td><td>Normal</td></tr></table>	Name	Type	Polarity	Siren	Siren	Normal	Strobe	Strobe	Normal	P0>00>01	Siren	Normal	P0>00>02	Strobe	Normal	P0>00>03	Siren	Normal	P0>00>04	Strobe	Normal																															
Name	Type	Polarity																																																			
Siren	Siren	Normal																																																			
Strobe	Strobe	Normal																																																			
P0>00>01	Siren	Normal																																																			
P0>00>02	Strobe	Normal																																																			
P0>00>03	Siren	Normal																																																			
P0>00>04	Strobe	Normal																																																			
Partitions		Appears only in a Partitioned system. All outputs allocated to all partitions.																																																			
Exp. X1-nn	<table><tr><th>Name</th><th>Type</th><th>Polarity</th></tr><tr><td>X1>nn>01</td><td>Not Used</td><td>Normal</td></tr><tr><td>X1>nn>02</td><td>Not Used</td><td>Normal</td></tr><tr><td>X1>nn>03</td><td>Not Used</td><td>Normal</td></tr><tr><td>X1>nn>04</td><td>Not Used</td><td>Normal</td></tr></table>	Name	Type	Polarity	X1>nn>01	Not Used	Normal	X1>nn>02	Not Used	Normal	X1>nn>03	Not Used	Normal	X1>nn>04	Not Used	Normal	"X" = W: wired expander "X" = R: radio expander "nn" = bus address																																				
Name	Type	Polarity																																																			
X1>nn>01	Not Used	Normal																																																			
X1>nn>02	Not Used	Normal																																																			
X1>nn>03	Not Used	Normal																																																			
X1>nn>04	Not Used	Normal																																																			
Partitions		Appears only in a Partitioned system. All outputs allocated to all partitions.																																																			
Plug-by outputs																																																					
Output 1...16	<table><tr><th>Name</th><th>Type</th><th>Polarity</th></tr><tr><td>Output 01</td><td>Fire</td><td>Normal</td></tr><tr><td>Output 02</td><td>Panic Alarm</td><td>Normal</td></tr><tr><td>Output 03</td><td>Burglar Alarm</td><td>Normal</td></tr><tr><td>Output 04</td><td>Open / Close</td><td>Inverted</td></tr><tr><td>Output 05</td><td>Omit (System)</td><td>Normal</td></tr><tr><td>Output 06</td><td>Alarm Abort</td><td>Normal</td></tr><tr><td>Output 07</td><td>Confirmed</td><td>Normal</td></tr><tr><td>Output 08</td><td>Technical</td><td>Normal</td></tr><tr><td>Output 09</td><td>Panel AC Fail</td><td>Normal</td></tr><tr><td>Output 10</td><td>Panel Batt Fault</td><td>Normal</td></tr><tr><td>Output 11</td><td>General Fault</td><td>Normal</td></tr><tr><td>Output 12</td><td>Tamper</td><td>Normal</td></tr><tr><td>Output 13</td><td>Ext PSU Low Volt</td><td>Normal</td></tr><tr><td>Output 14</td><td>Ext PSU Fault</td><td>Normal</td></tr><tr><td>Output 15</td><td>24 Hour Alarm</td><td>Normal</td></tr><tr><td>Output 16</td><td>RF Fault</td><td>Normal</td></tr></table>	Name	Type	Polarity	Output 01	Fire	Normal	Output 02	Panic Alarm	Normal	Output 03	Burglar Alarm	Normal	Output 04	Open / Close	Inverted	Output 05	Omit (System)	Normal	Output 06	Alarm Abort	Normal	Output 07	Confirmed	Normal	Output 08	Technical	Normal	Output 09	Panel AC Fail	Normal	Output 10	Panel Batt Fault	Normal	Output 11	General Fault	Normal	Output 12	Tamper	Normal	Output 13	Ext PSU Low Volt	Normal	Output 14	Ext PSU Fault	Normal	Output 15	24 Hour Alarm	Normal	Output 16	RF Fault	Normal	
Name	Type	Polarity																																																			
Output 01	Fire	Normal																																																			
Output 02	Panic Alarm	Normal																																																			
Output 03	Burglar Alarm	Normal																																																			
Output 04	Open / Close	Inverted																																																			
Output 05	Omit (System)	Normal																																																			
Output 06	Alarm Abort	Normal																																																			
Output 07	Confirmed	Normal																																																			
Output 08	Technical	Normal																																																			
Output 09	Panel AC Fail	Normal																																																			
Output 10	Panel Batt Fault	Normal																																																			
Output 11	General Fault	Normal																																																			
Output 12	Tamper	Normal																																																			
Output 13	Ext PSU Low Volt	Normal																																																			
Output 14	Ext PSU Fault	Normal																																																			
Output 15	24 Hour Alarm	Normal																																																			
Output 16	RF Fault	Normal																																																			
Partitions		Appears only in a Partitioned system. All outputs allocated to all partitions.																																																			
3 SETTING OPTIONS			Appears only in a Level Setting system.																																																		
Full Set																																																					
Name	"Full Set"																																																				
Exit mode	Timed Set																																																				
Settle time	7 seconds		Appears only if Exit Mode is "Final Door".																																																		
Exit time	40 seconds		Appears only if Exit Mode is "Timed Exit" or "Silent Set".																																																		
Entry time	40 seconds																																																				
Strobe on Set																																																					
Strobe on Unset																																																					

Part Set B		
Name	"Part Set B"	
Exit Mode	Instant Set	
Settle time		Appears only if Exit Mode is "Final Door".
Exit time	40s	This setting is required in order to comply with EN50131. Appears only if Exit Mode is "Timed Exit" or "Silent Set".
Entry time	45s	<i>The maximum time permitted by EN50131-1 Clause 8.3 is 45 seconds.</i>
Alarm Response	Internal+Siren	
Part Set Final Exit	Final exit	
Part Set Entry Route	Entry Route	
Strobe on Set	Disabled	This setting is required in order to comply with EN50131.
Strobe on Unset	Disabled	
Part C, D	(See Part Set B)	
Calendar Set	None	
3 PARTITIONS		Appears only in a Partitioned system and when zones have a type other than "Not Used".
Partition 1		
Name	"Partition 1"	
Exit Mode	Timed Set	
Settle Time		Appears only if Exit Mode is "Final Door".
Exit Time	40	Appears only if Exit Mode is "Timed Exit" or "Silent Set".
Entry Time	40	<i>The maximum time permitted by EN50131-1 Clause 8.3 is 45 seconds.</i>
Alarm Response	Siren + Comms	
Strobe on Set	On	
Strobe on Unset	On	
Part Set Exit Mode	Instant Set	
Part Set Settle Time		Appears only if Exit Mode is "Final Door".
Part Set Exit Time		Appears only if Exit Mode is "Timed Exit" or "Silent Set".
Part Set Entry Time		
Part Set Alarm Response	Siren + Comms	This setting is required in order to comply with EN50131.
Part Set Final Exit	Final exit	
Part Set Entry Route	Entry Route	
Part Set Strobe Set		
Part Set Strobe Unset		
Partition 2....20	"Partition 20"	All other defaults as for Partition 1.
Full Set Link	Partitions 2-20: No	
Calendar Set	None	No events or partitions

4 SYSTEM OPTIONS		
Wired Zone type		To comply with EN50131 select this option manually during initial power up.
Panel Zones	2 Wire FSL 2k2/4k7	
All Zones	2 Wire FSL 2k2/4k7	
User Access		
PA keys active	No	
Quick Set	No	This setting is required in order to comply with EN50131.
Quick Omit	No	
User code req'd	Yes	
User reset		
Zone alarms ⁷	Yes	<i>This option does not appear if DD243 Confirmation is ON</i>
Zone tampers	Yes	For INCERT approval set to NO.
System tampers	No	
DD243		
Confirmation	On	DD243 is a UK requirement. If this option is disabled in non-UK countries then the control unit will still comply with EN51031. This menu is visible only when <i>System Options – Restore Defaults – Country defaults</i> is set to "UK".
Confirmation time	30 mins	
After Entry	2 zones	
Entry Keypad Lock	Off	
Sounder on	Unconfirmed	
Siren on	Unconfirmed	
Unconfirmed reset	User	
Confirmed reset	User	
Masking	Off	
Language	English	
Restore Defaults		
Country defaults		
Staged defaults		
Factory defaults		
Installer Name	"Installer"	
Installer Code	"7890" Grade 2, "567890" Grade 3	
Keypad text	i-on160EX	
Remote Needs Entry	Disabled	
PA Response	Audible	
Auto Rearm	Never	<i>This setting is required in order to comply with EN50131. Appears only when System Options – DD243 – Confirmation is "off".</i>
Siren Delay	0 min	
Siren Time	15 minutes	To comply with EN50131-1 Clause 8.6 minimum is 90s, maximum is 15mins.

Panel Loudspeaker		
Loudspeaker 1 (2)		
Volume		
Partitions 01...20	Yes	Appears only in a Partitioned system. Assigned to all partitions
Entry Alarm Delay	Enabled	<i>This setting is required in order to comply with EN50131 8.3.8.2.</i>
Supervision	Enabled	
Jamming	Enabled	
Force Set	Off	
Tamper Omit	Disabled	This setting is required in order to comply with EN50131.
CSID Code	0000	
Silence Alerts	User Code	
Mains Fail Delay	0 minutes	This setting is required in order to comply with EN50131.
Battery 2	Disabled	
5 COMMUNICATIONS		
ARC Reporting		Only visible when suitable communications module fitted. To comply with EN50131 you must fit a communicator module.
Call Mode	Enabled	This setting is required in order to comply with EN50131.
Phone book	empty	
IP Network		Only visible when suitable communications module fitted.
Account Number	000000	Part setting system has one account number. A partitioned system has one account number per partition.
Report Type	Fast Format	
Fast Format channels	Channel1: Fire Channel 2: Panic alarm Channel 3: Burglar Channel 4: Open / Close Channel 5: Zone Omit (System) Channel 6: Alarm Abort Channel 7: Confirmed Alarm Channel 8: Technical Alarm Channels 9 to 16: Not used	Appears only in a Level Setting system. Appears only when Report Type=Fast Format

CID/SIA Events	Fire: Yes Panic: Yes Burg: Yes Technical Alarm: No Tampers: Yes Set/Unset: Yes (<i>see Note 2</i>) Part Set: Yes(<i>see Note 2</i>) Reset: Yes (<i>see Note 2</i>) Exit timeout: Yes Omit: Yes RF Supervision: Yes RF Jamming: Yes (<i>see Note 2</i>) RF Battery/PSU: Yes (<i>see Note 2</i>) Panel Battery: Yes (<i>see Note 2</i>) Mains Fail: Yes (<i>see Note 2</i>) Faults: Yes (<i>see Note 2</i>) Installer Mode: Yes (<i>see Note 2</i>) User Code Changed: No Date/Time Reset: No Downloading: No	1. Appears when Report Type=CID or SIA. 2. This setting is required in order to comply with EN50131.
Restorals	Enabled	Appears when Report Type=CID or SIA.
Burg Comms Rearm	Disabled	Appears only when Report Type=Fast Format.
21CN FF Ack time	800ms	Appears only when Report Type=Fast Format.
Send tamper as burg	Disabled	Appears when Report Type=CID or SIA.
Dynamic Test Call	Enabled	
Static Test Call	Disabled	Appears only when Report Type=Fast Format. To comply with EN50131, either Static or Dynamic test calls must be enabled. This is available only when an i-sd02 is fitted and ARC Communications enabled.
Speech Dialler		Only visible when suitable communications module fitted.
Call Mode	Disabled	
Messages	None	
Phone Book	Empty	
Triggers	None	
Destinations	None	
Call Acknowledge	Enabled	
SMS		Only visible when suitable communications module fitted.
Call Mode	Disabled	
Messages	Blank	
Phone Book	Empty	
Triggers	None	
PSTN SMS		
Protocol	TAP 8N1	
Service Centre Tel	07860980480	O2-UK
Line Fail Response	Audible	Only visible when suitable communications module fitted.
Line Fail Delay	9s	This setting is required in order to comply with EN50131. Only visible when suitable communications module fitted

IP Network (Own)		
Web Server		
Status	Disabled	
Port number	80	
IP Address	192.168.0.100	
IP Sub-net mask	255.255.255.0	
Gateway IP address	Blank	
GPRS		Only visible when suitable communications module fitted
Ethernet		Only visible when suitable communications module fitted
Downloading		
Account		
Name	Blank	
Serial Number	Blank	
Connection Type	Remote	
Rings to Answer	5	Only visible when suitable communications module fitted
Answer on one ring	Disabled	Only visible when suitable communications module fitted
Access Mode	Call Out Only	Only visible when suitable communications module fitted. This setting is required in order to comply with EN50131.
Phone Book	Blank	Only visible when suitable communications module fitted
IP Network	IP Address 1: Blank IP Port 1: Blank IP Address 2: Blank IP Port 2: Blank	Only visible when suitable communications module fitted
Secure Callback	Disabled	Only visible when suitable communications module fitted
Modem Baud Rate	Auto	Only visible when suitable communications module fitted
6 TEST		
Sirens & Sounders		
Wired Keypad		
Walk Test		
Zone Resistances		
Signal Strengths		
Detectors		
Radio Keypads		
External Sirens		
WAMs		
Outputs		
Radio Outputs		
Wired Outputs		
Plug-by outputs		
Expander Outputs		
Remotes		
User Panic Alarms		
Prox Tags		
ARC Reporting		Only visible when suitable communications module fitted

Speech Dialler		Only visible when suitable communications module fitted
PSU Current		
Locate Bus Device		
7 VIEW LOG		
8 ABOUT		
Panel		
Comms		
Module		
Panel Ethernet		
Zone mapping		
Zone Numbers		
Zone Addresses		

Installer Menu Options

This section contains reference information for the options provided in the Installer Menu.

Detectors/Devices

Detectors

Adding or Deleting Radio Detectors

Add a Radio Detector To The System

To learn radio detectors select *Detectors/Devices - Detectors - Add/Delete Detectors*. See page 110 for detailed instructions.

To use a radio zone the control unit must learn the identity of the radio detector. When learning detectors you first select a radio expander to assign that detector to, and then learn the detector's identity. Remember that EXP-R10 expanders can learn 10 radio detectors, while EXP-R30 expanders can learn 30 detectors.

Deleting All Radio Detectors From The System

If you wish to remove all the radio detectors from the system then select *Detectors/Devices - Detectors - Add/Delete Detectors*. When the display shows the first radio expander press ▲ and you will see *Delete All* on the bottom line of the display. See page 112 for detailed instructions.

When you delete all radio detector the control unit sets all radio zones to Not Used, and erases the identities of all the radio transmitters that it has learned.

Deleting All Zones From A Radio Expander

To delete all detectors from a single wireless expander then select *Detectors/Devices - Detectors - Add/Delete Detectors* from the Installer Menu. The bottom line of the display shows the first of the radio expanders. Press ▲ or ▼ to display the expander you wish to delete detectors from. Press ✓ to select the expander. The bottom line of the display shows the first of the zones belonging to that expander. Press ▲ and will see *Delete All* on the display. Press ✓ to select the option. The display asks you to confirm your choice. Press ✓ to finish deleting all the zones from the expander, or ✕ if you wish to keep the detectors.

If you press ✓ the control unit sets all zones belonging to the expander to Not Used, and deletes the identities of all radio transmitters assigned to the expander.

Deleting a Single Detector

To delete an individual detector select *Detectors/Devices - Detectors - Add/Delete Detectors* from the Installer Menu. See page 111 for detailed instructions.

There are two options:

Delete Detector ID

Use this option to make the control unit "forget" the ID of the detector, but leave any zone programming in place.

Default zone

If you select this option then the control unit “forgets” the ID of the detector **and** sets all the zone programming back to default values: Type = Not Used, no attributes.

Note: The deletion will take place immediately, and not when you leave Installer Mode.

Program Zones

You can program each zone's behaviour at any time, whether or not a wired detector is connected, or the control unit has learned the identity of a radio detector. See page 113 for detailed instructions.

Note: If a wired zone does not have a detector connected to it then make sure that you set the zone type to “Not Used”. When delivered from the factory the control unit has all zones set to “Not Used”.

Changing Zone Names

You can give each zone a 12 character name to help you remember its purpose or location. The control unit displays this name when you program the zone, or in first to alarm and keypad fault displays. Use *Detectors/Devices - Detectors – Program Zones*. See page 113 for detailed instructions.

For hints on editing zone names see page 12.

Zone Types

When programming zone types the bottom line of the keypad display shows a “*” at the beginning to show the zone's current type.

You can select a zone type quickly by keying the number shown in brackets after the type's name in the list below. For example: key in “05” to select Final Exit, “02” to select Fire Alarm, “11” to select External PSU A/C Fail. The number does not appear on the keypad display.

The list below shows the available zone types. When the description mentions “system” then this means either the alarm system itself in a part setting system, or those partitions the zone is allocated to in a partitioned system.

Not Used (00)

The alarm system will not respond when an event triggers this detector. This is the default zone type for all zones when the control unit is delivered from the factory.

Panic Alarm (01).

Operating a device programmed as ‘Panic Alarm’ (PA) will start an audible alarm. If a communications module is fitted there may also be an alarm transmission to the Alarm Receiving Centre (ARC), depending on how you have programmed the ARC Reporting option (see page 73). PA alarms operate whether the system is set or unset.

Fire Alarm (02).

Smoke or heat detectors connected to Fire Alarm zones cause the sirens to give a pulsing fire signal. Fire alarms operate whether the system is set or unset, and will always trigger communications, if a communications module is fitted and enabled.

Normal Alarm (03).

When triggered, a zone programmed as 'Normal Alarm' will start an alarm provided the system is set.

When the control unit first learns a radio detector the zone type defaults to Normal Alarm.

24 Hour Alarm (04).

Activating this zone causes an internal alarm (keypads and speakers) whether the system is set or unset.

Final Exit (05).

Zones of this type must be the last detector to be activated on exit, or the first to be activated on entry. You can use zones of this type to finally set the system or partition, or to start the entry procedure. See page 54 to set the exit mode type.

Note: If you give a Final Exit zone any of the Part Set attributes then you can program that zone to behave like a Normal Alarm zone if the user part sets the system. See page 55 .

Entry Route (06).

Use this zone type for detectors sited between the Final Exit door/detector and the keypad. If an 'Entry Route' zone is triggered when the system is set, an alarm will occur. If the entry/exit timer is running when an Entry Route zone is triggered then no alarm occurs until the entry/exit timer expires.

Note: If you give an Entry Route zone one of the Part Set attributes then you can program that zone to behave like a Final Exit zone if the user part sets the system. See page 55 .

Technical Alarm (07).

Use this zone type when you want to monitor equipment, for example a freezer, without raising a full alarm. If a technical alarm zone is activated then the control unit logs the event and (if the control unit is correctly programmed, see page 72) starts communication.

If the technical alarm occurs while the system is set, then system makes no audible alarm. When a user unsets the system the keypad shows an alert.

If a technical alarm zone is activated while the system is unset then the system starts an alert immediately and gives a brief tone from the keypad every few seconds. When a user enters a valid access code the keypad stops the tone and displays the zone causing the alarm.

When the user acknowledges the alert by pressing ✓ the control unit resets the technical alarm ready for the next event.

Key Switch Momentary (08).

Use this zone type to connect a momentary keyswitch to a single zone. In a Part Setting system the keyswitch can Full Set or unset.

In a Partitioned system you can allocate the keyswitch to one or more partitions.

Each time a user operates the keyswitch the control unit changes the current set state.

Key Switch Latched (09).

Use this zone type to connect a fixed position keyswitch to a single zone.

In a Part Setting system the keyswitch can Full Set or unset. As with Momentary keyswitches, you can allocate the zone to one or more Partitions (see above).

When the user closes the keyswitch contacts then the control unit sets the allocated Partition. When the user opens the contacts then the control unit unsets the allocated Partition.

Notes:

- 1. The keyswitch zone types are intended for use on zones that connect to an access control keypad, electronic key or other type of hardwired device used to set or unset the system.*
- 2. When the user operates the keyswitch while the system is unset then the control unit starts the programmed exit mode.*
- 3. When the user operates the keyswitch while the system is set then the control unit unsets the system immediately.*
- 4. The user cannot reset the system from a Keyswitch zone.*
- 5. Do not assign more than one Latched Key Switch zone to a partition.*

Tamper (10)

Use this zone type to monitor the tamper status of external equipment. The control unit monitors a Tamper zone at all times. When triggered in the unset condition, only internal sounders operate. When triggered in the set condition, the alarm response determines whether external sounders, strobe and communications also respond to the alarm.

External PSU A/C Fail (11)

Use this zone type to monitor the A/C Fail output of an external power supply unit. If a power supply unit triggers a zone with this type then the control unit waits for a random time between 52 and 59 minutes before activating any output programmed as "AC Fail" and causes an alert that displays "External mains fail" on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Battery Fault (12)

Use this zone type to monitor the Battery Fault output of an external power supply unit. If an external PSU triggers a zone with this type then the control unit activates any output programmed as "Battery Fault" and causes an alert that displays "External Battery Fault" on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Low Volts (13).

Use this zone type to monitor the Low Voltage output of an external power supply unit. If a power supply triggers a zone with this type then the control unit activates any output programmed as "Low Volts" and causes an alert that displays "External Low Volts" on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Fault (14).

Use this zone type to monitor the fault output of an external PSU. (This zone type is available for power supplies that do not provide specific fault outputs that can be used by zone types 11, 12 and 13.) If a power supply triggers a zone with this type then the control unit activates any output programmed as "External PSU Fault" and causes an alert that displays "External power fault" on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

Note: Zone type 15 is not used.

Log Only (16)

When a detector triggers a zone with this type the control unit logs the event and activates any outputs that are programmed to follow this zone. The zone is active whether the system is set or unset. Typical uses for this zone type are for integrating the alarm system with a CCTV system.

Note: Zone Follow outputs will activate on both Alarm and Tamper of a Log Only zone.

Partitions

Note: This menu does not appear if a zone has the type "Not Used".

In a partitioned system you can assign zones to any of the partitions. Any zone can belong to one or more partitions.

Note: If you assign a zone to more than one partition then that zone will only be set when all the partitions it belongs to are set.

When delivered from the factory, or if you restore the control unit to factory settings, then all zones belong to partition 1.

Once you have entered the Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ► or ◀ to allocate/deallocate the zone to each partition as necessary.

If you wish to allocate/deallocate the zones to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the zone to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of zones as necessary.

Zone Attributes

Note: This menu does not appear if a zone has the type "Not Used".

You can assign more than one attribute to a zone. Some attributes are not available for certain zone types. The display shows only the available attributes for the zone type you select.

To enable an attribute for a zone press ► or ◀ until the bottom line of the display shows "Yes" at the right hand end.

Chime

When enabled by the user, the system gives a non-alarm warning tone when any zones programmed as 'Chime' are opened. This facility operates only while the system is unset.

Soak Test

Use this zone attribute if you want to place under long term test a detector that you suspect is giving false alarms. Zones with this attribute are disabled for 14 days after you return the control unit to user/unset mode. If the zone remains inactive for the whole fourteen days then after midnight on the 14th day the control unit returns the zone to normal use. If the zone is activated during those 14 days while the system is set then the control unit logs the event as a "Soak Test Fail Z1-ee-nn" (ee is the bus device number and nn is the zone number, see page 17) without sounding any sirens or starting communications. The control unit also lights the red LEDs around the navigation key on the keypad to alert the user. An installer must key in their access code to reset the alert.

You can apply the soak test attribute to Normal Alarm, Entry Route and Tamper zone types.

During setting the keypad displays a brief message to inform the user that one or more zones are in soak test.

Double Knock

Zones programmed with this attribute will cause an alarm only if the zone is EITHER triggered, restored and triggered again within a five minute period, OR if the zone remains active for 10 seconds.

You can apply the Double Knock attribute to the Normal Alarm and Entry Route zone types.

Part Set B

(Not visible in a partitioned system.) When a user presses button B (part set), the control unit sets only those zones where the Part Set B attribute = "Yes". (See also "Part Set Exit Mode" on page 54).

Part Set C

(Not visible in a partitioned system.) When a user presses button C the control unit sets only those zones where Part Set C attribute = "Yes".

Part Set D

(Not visible in a partitioned system.) When a user presses button D the control unit sets only those zones where Part Set D attribute = "Yes".

Part Set

(Not visible in a Part Setting system.) When a partition is Part Set, zones in that partition with this attribute are set. Note that if a zone is in more than one partition, all partitions have to be set or part set before this zone will be set.

Omittable

This attribute applies to the following zone types only: Normal Alarm, 24hr, Technical, Entry Route, Tamper, External PSU A/C Fail, External PSU Battery Fault, External PSU Low Volts and External PSU Fault.

A) When a zone has this attribute, a user can omit it before setting the system.

B) If a user tries to set the system when a zone with this attribute is open

(active) the control unit alerts them and pauses the setting procedure. The user can acknowledge the alert by pressing ✓ and continue setting. You must enable this feature in the *System Options – User Access – Quick Omit* menu, see page 61.

Note: In a Security Grade 3 system this attribute is defaulted to "No". If you change the attribute to "Yes" the system will no longer comply with Security Grade 3.

If the system you are installing communicates using Fast Format or with a plug-by communicator, then you must program either a Fast Format channel or a plug-by output as Omit. This ensures that the control unit can communicate an omit event if the user omits a zone.

Force Set Omit

When this attribute is set to Yes a user with a remote control can set the system while the zone is open (active). (You must enable this feature in the *System Options – Force Set* menu. See page 70.)

Masking

Apply this attribute EITHER if you have connected a detector that reports masking by changing the resistance between its alarm contacts, OR if you have connected the masking/trouble contacts of a detector using the "3 resistor method" (for details of wiring trouble/masking contacts see *Fully Supervised Loop Connections* in the i-on160EX Installer Guide). See page 64 for more details on programming masking options.

Expanders

Note: If you need to add or remove expanders or keypads from the bus then make sure that you remove all power from the system before physically disconnecting them. See page 99 for detailed instructions.

Adding Expanders

To add an expander to the bus use the Installer Menu option *Detectors/Devices – Address Bus Device*. See page 100 for detailed instructions.

When you add an expander the control unit gives the unit the next free device number and allocates a block of zones, depending on device type (see page 19).

If the expander you are adding already has a bus device number stored within it, from a previous installation, then this will cause problems in the new installation. Always ensure that you default the bus device address before adding it to the bus. You can do this either manually (see page 99) or by using the option *Detectors/Devices – Wired Expander – Delete Expander*. (See below.)

Deleting Expanders

When you wish to remove an expander from the bus always use the Installer Menu option *Detectors/Devices – Wired Expander – Delete Expander* or *Detectors/Devices – Radio Expander – Delete Expander*. See page 102 for detailed instructions.

Using these options defaults the bus device number stored within the device itself (making the device safe to add to other i-on160EX alarm systems), frees all the zone numbers allocated to the device, and also removes the device from any partitions it was allocated to.

Note: Cooper Security recommend that you remove all power from the system (battery and mains) before disconnecting any device from the bus.

Disabling/Enabling Expanders

If you suspect that an expander is faulty, and wish to remove it from service temporarily, then use the Installer Menu option *Detectors/Devices – Wired Expanders – Enable Device*. (There is a similar option for radio expanders.) Select the device you wish to disable and use the ◀ or ▶ keys to set the enable status to “No”. See page 103 for detailed instructions.

To return the expander to service use the same Installer Menu option and set the enable status to “Yes”.

While the expander is disabled the control unit ignores all signals from the device, but retains the zone numbers and other programming allocated to the device. The keypad shows an alert (navigation key LEDs glow red) will show When a user tries to set the system the keypad disp

Replacing Expanders

if you wish to replace an expander with a new device, but leave that expander’s programming intact on the control unit, then use the Installer Menu option *Detectors/Devices – Wired Expander – Replace Expander*. (See page 105 for detailed instructions. Radio Expanders have a similar menu option.)

When you use the Replace Expander option the control unit disables the selected expander and retains all the expander’s zones and other programming. You can then power down the system, disconnect the expander from the bus, and reconnect a new expander (of the same type) to the bus.

When you power up the control unit again, the keypads will show an alert that the expander has been disabled. Go into the Installer Menu and select *Detectors/Devices – Wired Expander – Replace Expander* again. The keypad display shows an “Add” option for the replaced expander. Select the “Add” option and then hold down the address request button on the new expander (remember to remove the lid in order to activate the tamper). The control unit will assign the bus device address of the expander you removed to the new expander, along with all the zones and other programming from the old expander. The new expander will not need any further programming.

Note: If you replace a wireless expander then you must teach the identity of the new wireless expander to any receivers or output module that had previously learned the old expander’s identity. This includes any 762s, 768s or WAMs.

Naming Expanders

The i-on160EX allows you to give each expander a name (see page 107 for detailed instructions). The name appears in the log, in alerts, and when programming the expanders.

Partitions and Expanders

You can assign each expander to one or more partitions. When assigned to a partition an expander will:

- Give notification tones for the associated partitions through the expander’s loudspeaker (if one is connected).

Control the response to tampers for the associated partitions. If any associated partition is set then a tamper will cause an unconfirmed alarm. If there is an outstanding unconfirmed alarm then this will cause a confirmed alarm to be generated.

When delivered from the factory, or if you restore the control unit to factory settings, then all expanders belong to partition 1.

Once you have entered the Edit Expander - Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ► or ◀ to allocate/deallocate the expander to each partition as necessary.

If you wish to allocate/deallocate the expander to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the expander to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of expanders as necessary.

Expander Loudspeaker Volume

To change the volume of notification tones from loudspeakers attached to expanders use the *Detectors/Devices – Wired Expander – Edit Expander – Loudspeaker volume* menu. Press ◀ to lower the volume or ► to raise the volume. The display shows the current volume setting by a row of stars (for example "*****"). This volume control does NOT change the volume of alarm tones.

Press ✓ to leave the menu.

Note: When you first add an expander to the bus, the control unit defaults the loudspeaker volume to zero.

Wired Expanders Zone Wiring

You can change the zone wiring method for each wired expander individually.

During commissioning the Installer can select a system-wide zone wiring method as part of the initial power-up (see the i-on160EX Installation Manual). If you wish to change the zone wiring method for an individual Expander use the *Detectors/Devices – Wired Expander – Edit Expander – Wired Zone Type* menu. See page 109 for detailed instructions.

The zone wiring types available are: 4-wire CC, 4k7/2k2, 1k0/1k0, 2k2/2k2, or 4k7/4k7.

When using 4-wire CC wiring each wired expander provides connections for five zones. When using FSL wiring each wired expander provides connections for 10 zones.

NOTE: If you change the overall system zone wiring type (see page 60) AFTER selecting the expander wiring type then the expander will adopt the wiring type you selected for the system. You must then re-enter the expander menu to change the expander zone wiring type back to the one you want the expander to use.

Wired Keypads

The i-on160EX allows you to give each wired keypad a name, and assign a keypad to one or more partitions.

The control unit displays the name you give to the keypad when it is reporting faults or other events, making it easier to locate the affected device.

Assigning Wired Keypads to Partitions

The i-on160EX allows you to assign keypads to any of the partitions.

When delivered from the factory, or if you restore the control unit to factory settings, then all keypads belong to partition 1.

Once you have assigned a keypad to a partition then that keypad will display messages and give tones for the assigned partition(s).

Note: If you do not assign a keypad to a partition (and there is no loudspeaker assigned to the partition) then users of that partition will not be able to hear entry/exit tones and alerts for the partition.

Any user can use any keypad. While they are using a keypad the display shows information from partitions assigned to the user, not to the keypad.

Once you have entered the Edit Keypads - Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ► or ◀ to allocate/deallocate the keypad to each partition as necessary.

If you wish to allocate/deallocate the keypads to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the keypad to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of keypads as necessary.

Programming Quick Set Keys

Note: If you enable the quick set keys the control unit no longer complies with EN50131. See page 61.

You can program the quick set keys (A, B, C and D keys) to perform one of several actions. The actions depend on the setting type of the system: partitioned or part set.

In a part setting system the installer can program the quick set keys to Full Set, Part Set B, Part Set C or Part Set D.

In a partitioned system you can program a quick set key to full set or part set individual partitions.

Each keypad can have a different arrangement of quick set keys. For example the A key on keypad 1-02-01 might part set partitions 1 and 2, but on keypad 1-02-02 it could be programmed to full set partition 3.

In either part setting or partitioned systems you can program a quick setting key to trigger a user defined output. See page 51 for a description of user defined outputs.

In addition, each of the A, B, C or D keys can have a name. The keypad displays this name while the system is setting after the user presses that key.

See page 121 for an example of how to program a quick setting key.

Deleting Keypads

Use this menu option to delete keypads from the system. See page 102 for detailed instructions.

Notes:

1. *If you are working on a system with only one keypad (for example when programming a new control unit before installation) then do not delete the keypad you are using. If you do so then power down and up again in order to make the control unit recognise the keypad.*
2. *DO NOT hold down D and ✕ to delete a keypad from a system while the keypad is still connected to the bus. Always delete keypads from a system first by using the Installer Menu, see page 102. If you have inadvertently erased a keypad's address by holding down D and ✕ then:*
 1. Make the control unit re-scan the bus by leaving the Installer Menu.
 2. Press ✓ when the control unit displays "Accept all changes to bus?".
 3. Add the keypad back to the system, as described in page 100.

Radio Keypads

The Radio Keypad is a transmitter that users can employ to set and unset the system remotely. The Radio Keypad is a transmitter only, and does not display any system information. The LEDs on the Radio Keypad glow to show that it is transmitting a signal.

Note:

1. *Radio keypads transmit four-digit access codes only. If you change the system to use six-digit access codes then radio keypads will not function with access codes (they will still function with prox tags).*
2. *If the system uses a radio keypad the it will not comply with Security Grade 3.*

When installing a Radio Keypad you must first teach the control unit the Radio Keypad's identity, and then program the control unit with the function of each of the Radio Keypad's A, B, C or D buttons. In addition, you can give each Radio Keypad a name.

In a partitioned system you can assign a Radio Keypad to any combination of partitions, just as you can for the wired keypads.

When delivered from the factory, or if you restore the control unit to factory settings, then all radio keypads belong to partition 1. The A, B, C and D keys operate on partition 1 only.

After assigning a keypad to any other partition(s) you must re-program the A, B, C and D keys to make sure that they operate correctly. The A, B, C and D keys will only work with partitions that you have assigned to the radio keypad.

Teaching Radio Keypads to the Control Unit

To make the control unit learn a Radio Keypad's identity. Select *Detectors/Devices – Radio Keypad – ADD/DEL Radio Keypad*. Select the radio expander you wish to use, followed by the radio keypad address that you want to allocate the keypad to. You must then activate the radio keypad's tamper to make the control unit learn the identity of the keypad. See page 117 for detailed instructions.

To remove a Radio Keypad from the system Select *Detectors/Devices – Radio Keypad – ADD/DEL Radio Keypad*. Select the radio expander the keypad is allocated to, followed by the device address of the keypad that you want to delete. See page 118 for detailed instructions.

See page 18 for a description of radio keypad numbering.

Radio Keypad Naming

To name a radio keypad select *Detectors/Devices – Radio Keypad – Edit Keypads - Name*. See page 119 for detailed instructions.

Assigning Radio Keypads to Partitions

To assign radio keypads to one or more of the partitions select *Detectors/Devices – Radio Keypad – Edit Keypads - Partitions*.

Once you have entered the Edit Keypads - Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ► or ◀ to allocate/deallocate the radio keypad to each partition as necessary.

If you wish to allocate/deallocate a radio keypad to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the radio keypad to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of radio keypads as necessary.

Programming Radio Keypad Quick Set Keys

In a partitioned system Radio Keypad quick set keys can be programmed in the same way as wired keypad quick set keys. You can allocate each key to setting and unsetting any combination of partitions that the keypad belongs to. Select *Detectors/Devices – Radio Keypads – Edit Keypads*. Select the keypad you wish to edit. Select the key you wish to edit. Allocate partitions as required. See page 121 for detailed instructions.

In a part setting system the Radio Keypad quick set keys are fixed in function as follows: A = Full Set, B = part set B, C = part set C, D = part set D.

External Sirens

The 760ES external radio siren is a weather-proof battery powered siren designed to operate on external walls. In an alarm the control unit triggers the external siren at the same time as the internal siren. The 760ES external siren runs for either: five seconds, three minutes, or 15 minutes depending on the position of a link within the sounder.

Each expander can learn up to two external radio sirens. The control unit (and hence the system) can learn a maximum of 20 radio sirens.

To program the external siren select *Detectors/Devices – External Siren*.

Radio Sirens and Partitions

In a partitioned system you can assign a radio siren to any of the partitions. Any radio siren can belong to one or more partitions.

Assigning a radio siren to partitions controls the response to tampers of those partitions. If any assigned partition is set then a tamper to the radio siren will cause an unconfirmed alarm. If there is an outstanding unconfirmed alarm then this will cause a confirmed alarm to be generated.

When delivered from the factory, or if you restore the control unit to factory settings, then all radio sirens belong to partition 1.

Once you have entered the Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ► or ◀ to allocate/deallocate the radio siren to each partition as necessary.

If you wish to allocate/deallocate the radio siren to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the radio siren to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of the radio siren as necessary.

WAMs

The i-on160EX can operate up to 20 770r WAM modules. Although the WAM provides five different modes, when working with an i-on160EX only mode 1, repeater module, is relevant. The installer must select the repeater mode when commissioning the WAM hardware.

When working as a repeater module the WAM repeats the signals from any detectors within its range, amplifying them to a level that the i-on160EX control unit can detect. This allows you to increase the area covered by detectors.

Naming WAMs

Use the Edit WAM option to give each WAM a meaningful name. The name can be up to 12 characters long.

Outputs

The i-on160EX control unit provides three different sets of outputs:

- Dedicated Bell and Strobe outputs.

- 4 hardwired outputs.

- 16 plug-by outputs.

(See *i-on160EX Installation Guide* for the position of connectors.)

In addition to the outputs wired directly into the control unit, expanders also provide outputs:

- Each wired expander provides 4 outputs on its pcb.

- Radio expanders each provide 10 radio output channels.

All these sets of outputs, both on the control unit and on expanders, can be programmed as any of the output types listed on page 45.

The software within an i-on160EX control unit can handle up to 164 outputs in total. If the number of physical outputs attached to the system exceeds this maximum then the installer menu will not let you program some of those outputs.

Bell and Strobe

You can program the behaviour of the dedicated Bell and Strobe outputs on the control unit pcb with the following options:

Name You can assign a 12 character name to the Bell and Strobe

outputs.

Polarity You change the polarity of either output, to suit the type of equipment that the output must work with. There are two options:

Normal. The output is held at +12V while inactive, and at 0V when activated.

Inverted. The output is held at 0V while inactive, and at +12V when activated.

Partition In a partitioned system you can assign the outputs to any of the partitions.

Wired Outputs

To use wired outputs you must program their behaviour by giving them an output type. See page 45 for a list of the output types available. See page 133 for detailed instructions on how to change the type. You can also give each wired output a name (see page 133).

Polarity

The i-on160EX lets you change the polarity of each wired output, to suit the type of equipment that the output must work with. There are two options:

Normal

The output is held at +12V while inactive, and at 0V when activated.

Inverted

The output is held at 0V while inactive, and at +12V when activated.

For instructions on how to change the polarity , see page 136.

Control Unit Plug-By Outputs

The plug-by outputs on the control unit are designed for use by standalone communicators (see *i-on160EX Installation Guide* for connection details). You can give each output a name, a type, and change its polarity. Programming plug-by outputs is the same as programming wired outputs, but you must use the *Outputs – Plug-by Outputs* menu.

Notes:

1. The activity of the plug-by outputs is affected by the alarm response you select. For example, if you select the alarm response "Siren" for Part Set B, then the control units will not trigger the Plug-by-Outputs if there is an alarm when the system is in part set B. To make the plug-by outputs operate you must select an alarm response that has communications.

2. Plug-by outputs cannot take the type "User Defined".

Radio Outputs

To use a radio output on a WAM see page 127 .

To use a radio output on a 762r, 768r or 769r receiver you must teach the identity of the i-on160EX control unit to the receiver.

Note: If you are teaching 762r, 768r, or 769r receivers then make sure that you disable IR learn on the receivers first.

Once a receiver has learned an output from the control unit you must set up the output behaviour at the control unit by giving the output a type. You can also give each output a text name.

Output Types

You can select an output type quickly by keying the number shown in brackets after the type's name, for example: "04" to select Open/Close, "02" to select Panic Alarm, "19" to select General Fault. The number does not appear on the keypad display.

Some output types can be assigned to zones or partitions. If you select those types then the keypad display will show a further menu allowing you to select the appropriate zones or partitions.

The output types available are:

Type:	Active when:	Assign to Partitions?
Not Used (00)	(Never)	
Fire Alarm (01)	The control unit starts a fire alarm.	Yes
Panic Alarm (02)	The control unit starts a panic alarm.	Yes
Burglar Alarm (03)	Any of the following zones are triggered: Normal Alarm Tamper (in a set system) Entry Route Tamper Zone (in a set system) Entry time expires 24 hour (in a set system)	Yes
Open/Close (04)	The output is active when the system (or partition) is unset. Inactive when the system (or partition) is set. If you allocate this output to multiple partitions then the output will deactivate if any one partition is set or part set. <i>Note: This output is inverted relative to other outputs, it is normally at 0V for an unset (open) system.</i>	Yes
Alarm Abort (05)	An alarm in the selected partition has been aborted by the user within the 90s abort period. Deactivates when the alarm is reset.	Yes
Technical Alarm (06)	There is a technical alarm.	Yes
Confirmed Alarm (07)	There is a confirmed alarm. Deactivates when the system is reset. The operation of	Yes

Type:	Active when:	Assign to Partitions?
	<p>this output type depends on whether DD243 is on or off:</p> <p>DD243 Confirmation Off – The output does not operate.</p> <p>DD243 Confirmation On – The output activates when a second alarm zone is triggered within the period of the confirmation timer, and in the same partition as the first alarm zone to be triggered.</p> <p>If the unconfirmed alarm is caused by the expiry of the entry timer, a further two zones which are not on the entry route must be triggered to activate the output.</p>	
RF Low Battery (08)	A wirefree detector reports a low battery. The output remains active until all detectors stop reporting low batteries.	Yes
RF Supervision (09)	There is a supervision failure on any radio zone. The output remains active until all supervision failures are reset.	Yes
RF Jamming (10)	The control unit detects jamming. The output remains on until all jamming disappears.	No
RF Fault (11)	There are any of the following faults: RF Low Battery, RF supervision, RF jamming.	Yes
Panel A/C Fail (12)	<p data-bbox="318 932 810 1091">Either Mains power is absent for between 52 and 59 minutes, OR a zone of type "External PSU A/C Fail" has been triggered. The control unit deactivates the output if a user keys in a valid access code after mains power has been restored.</p> <p data-bbox="318 1102 818 1230"><i>Note: If the External PSU A/C Fail zone is activated while the control unit is still receiving mains power then the control unit will activate this output within a few seconds.</i></p> <p data-bbox="318 1241 785 1343"><i>If the control unit is not receiving mains power then it assumes that there is a general power cut and waits for 52 to 59 minutes.</i></p>	No

Type:	Active when:	Assign to Partitions?
Panel Battery Fault (13)	<p>The control unit detects a fault with its backup battery, OR a zone of type "External PSU Battery Fault" has been triggered. If the alert was caused by an "External PSU Battery Fault" zone then the control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code.</p> <p>If the alert was caused by a fault with the control unit's backup battery then the control unit deactivates the output when it detects a good battery and a user acknowledges the alert.</p> <p><i>Note: To cause the control unit to check its backup battery enter and leave the Installer Menu.</i></p>	No
External PSU Low Volts (14)	<p>An external power supply has triggered an External PSU Low Volts zone.</p> <p>The control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code.</p>	No
External PSU Fault (15)	<p>An external power supply fault signal triggers a Power output fault zone.</p> <p>The control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code.</p>	No
Tamper (16)	<p>The control unit detects tamper on any the following devices:</p> <ul style="list-style-type: none"> Control unit, lid or wall tamper. Radio or wired keypad. Zone type "Tamper" activates. Detectors or Expanders Sounders <p>The control unit deactivates the output when tamper is reset.</p>	Yes
Zone Omit (Setting) (17)	<p>The user Omits a zone while setting the system. The output deactivates when the control unit restores the zone.</p>	Yes

Type:	Active when:	Assign to Partitions?
Zone Omit (System) (18)	(Operates only when DD243 is enabled.) In the event of an unconfirmed alarm, the system will rearm itself when the confirmation timer expires. If the zone that caused the unconfirmed alarm is still active at the time of the rearm, the control unit will omit that zone and activate the output. The control unit will restore the zone and output when a user or engineer resets the system.	Yes
General Fault (19)	There is any event that causes an alert indication on the keypad. This includes: RF Low Battery, RF Supervision, RF Jamming, AC Fail, Battery Fault, PSU Fault, Tamper, Masking	Yes
ATS Test (20)	(This output type appears only for Plug-by outputs.) The line fault input signal goes to 12V. The operation of the Line Fault input and the ATS test output complies with the requirements of BSIA form 175.	No
Siren (21)	The control unit starts a full alarm, a panic alarm or a fire alarm (the siren has a distinctive tone during a fire alarm). The control unit deactivates this output at the end of the siren time. See page 69 to choose the siren duration.	Yes
Strobe (22)	a) The control unit starts a Full alarm, panic alarm or fire alarm. The output remains active until the user disarms the system. b) Setting or unsetting, if you have selected "strobe on set" and/or "strobe on unset", see pages 55 and 55.	Yes
Entry Exit Follow (23)	The entry or exit time starts and deactivates at the end of the entry/exit time, or if the entry/exit time is terminated. The output can be used for a separate entry/exit buzzer. Note that the output does not operate if the exit mode is silent set or instant set.	Yes
Armed (24)	The system (or partition) is full or part set.	Yes

Type:	Active when:	Assign to Partitions?
PIR Set Latch (25)	The system or partition is set. Inactive when the system or partition is unset or an alarm condition occurs. The output is active for one second when a reset is performed or when the control unit leaves installer mode.	Yes
Shock Sensor Reset (26)	Exit time starts. The output remains active for five seconds. Use this output to reset shock sensors (for example, the "Viper").	Yes
Walk Test (27)	A user starts Installer- or User Walk Tests. Also active during the time between silencing and resetting the system. This output can be used on movement detectors that are able to switch off the Walk Test lamp in any state other than a Walk Test.	No
Smoke Sensor Reset (28)	This output is active (0V) all the time except when a user acknowledges a fire alarm: after which the control unit deactivates the output for three seconds. This output type is designed to be connected to low-voltage smoke detector reset terminals.	Yes
24 Hour Alarm (29)	The control unit starts a 24 hour alarm.	Yes
Setting Complete (30)	The control unit finishes setting. Active for 10 seconds.	Yes
Unset Complete (31)	Someone unsets the system or disarms it after an alarm. The output is active for 10 seconds.	Yes
Full Set Ready (32)	None of the detectors are reporting "alarm" signals.	Yes (all partitions by default)
Full Set (33)	The system is full set. If the system is partitioned, then the output is active only when all assigned partitions are Full Set.	Yes
Part Set (34)	The system is part set.	Yes
Part Set B (35)	Setting Part Set B. Deactivated on unsetting Part Set B. (Available only in a Part Setting system)	No
Part Set C (36)	Setting Part Set C. Deactivated on unsetting Part Set C. (Available only in a Part Setting system)	No

Type:	Active when:	Assign to Partitions?
Part Set D (37)	Setting Part Set D. Deactivated on unsetting Part Set D. (Available only in a Part Setting system)	No
Set Fail (38)	A set command fails. Remains active until the user acknowledges the set fail.	Yes
Zone Follow (39)	A specified zone has been triggered. When you select this type for a zone the display shows an extra "Follow" option for the output. Use this option to select the zone you wish the output to follow. (You can also follow a "not used" zone or a "Log Only".)	No
Zone Alarm (40)	The selected zone causes an alarm. Deactivated when the alarm has been reset. When programming this output type the installer can select a specific zone for the output to follow. (You can follow a "not used" zone.)	No
Masking (41)	The control unit operates this output whenever a detector is giving a "mask" signal (see page 64).	
Autoset Warning (42)	The control unit starts the Calendar Set Warning period (see page 58). Deactivates when the system sets, or if a user defers or cancels the calendar set.	Yes (all partitions by default)
User Defined (43)	The user switches the output on or off from the keypad, or a remote control. Assign this output type to any outputs that you want the user to control. <i>Note: You cannot assign this output type to a control unit plug-by-output.</i> See "Programming User Defined Outputs" on page 51 for more details.	Yes

Programming User Defined Outputs

Output type 43 allows you to program User Defined Outputs.

User Defined outputs can be activated by one of the following events:

A user presses a button on a remote that has been programmed to activate a User Defined output.

A user operates the output from the User Menu – Outputs On/Off option.

A user press one of the A, B, C or D keys on a keypad that the installer has programmed to operate a User Defined output.

The timer associated with the output reaches its on or off time.

In the Installer Menu, while programming a user output type, the control unit gives you the following options:

Polarity

Polarity can be either Normal or Inverted. This option works the same way as described for Wired Outputs – see page 45.

Latched

Latched can be either Yes or No.

No: The output initially changes state when a user operates the output, but then changes state again after a set time. The time is fixed by the “On Time” option, below.

Yes: The output changes state every time a user operates the output. In addition, three new menu options appear that allow you to set an On time and Off time for any day of the week, see below.

On Time

If you select Latched = No, then use this option to key in the number of seconds the output should remain active. You can select any period between 1 and 999 seconds. Note that if you select an active time of zero seconds then the output will not operate.

On Time/Off Time/Days

If you select Latched = Yes, then use these three options to make a user defined output come on and go off in a regular pattern.

On Time: Key in the time on the 24 hour clock when you want the output to activate.

Off Time: Key in the time on the 24 hour clock when you want the output to deactivate.

Days: Select one or more days of the week when you want the output to operate.

The control unit will operate the output at the times selected. However, if a user activates the output while it is Off, then the output stays on until the control unit reaches the next Off time. If a user de-activates the output while it is On, then the output stays off until the control unit reaches the next On time.

If you do not key any values into On Time/Off Time/Days, then the output acts as a simple On/Off switch under control of the user.

“Setting Options” and “Partitions” Menus

Part Setting or Partitioned System?

When you first power-up a new i-on160EX (see *i-on160EX Installation Guide*), or if you restore an i-on160EX control unit to factory defaults (see page 67), you must choose between having a Part Setting system or a Partitioned system.

If you select a Part Setting system then the Installer Menu contains a “Setting Options” sub menu. If you select a partitioned system then the installer menu contains “Partitions” sub-menu instead.

Both of these menus contains the same options, but organised in slightly different ways:

The Setting Options sub-menu contains all the options to program entry, exit and alarm response for a single alarm system with a Full Set and **three** Part Set levels.

The Partitions sub-menu is divided into twenty partitions. Each partition behaves like a complete, independent, alarm system. However, each partition has only Full Set and **one** Part Set.

Table 2 on the next page shows the layout of both the Setting Options and the Partitions menus. Since so many of the options work in the same way in both of these menus, the table shows the page number where the description of each option can be found.

Table 2. Setting Option and Partition Menus

3 SETTING OPTIONS	PAGE	3 PARTITIONS	PAGE
Full Set		Partition 1...20	
Name	54	Name	54
Exit mode	54	Exit Mode	54
Settle time (see note 1)	54	Settle Time (see note 1)	54
Exit time (see note 2)	55	Exit Time (see note 2)	55
Entry time	55	Entry Time	55
Strobe on Set	55	Alarm Response	55
Strobe on Unset	55	Strobe on Set	55
Part Set B		Strobe on Unset	55
Name	54	Part Set Exit Mode	54
Exit Mode	54	Part Set Settle Time (see note 1)	54
Settle time (see note 1)	54	Part Set Exit Time (see note 2)	55
Exit time (see note 2)	55	Part Set Entry Time	55
Entry time	55	Part Set Alarm Response	55
Alarm Response	55	Part Set Final Exit	55
Part Set Final Exit	55	Part Set Entry Route	56
Part Set Entry Route	56	Part Set Strobe Set	56
Strobe on Set	55	Part Set Strobe Unset	55
Strobe on Unset	55		
Part C, D (Same as Part Set B)		Full Set Link	56
Calendar Set	56	Calendar Set	56

Notes:

1. Appears only if Exit Mode is "Final Door".
2. Appears only if Exit Mode is "Timed Exit" or "Silent Set".

Notes for Part Set Options

In a Part Setting System, for Part Set B to work you must have at least one zone with the attribute Part Set B = "Yes", see page 36

In the same way For Part Set C to work you must have at least one zone with the attribute Part Set C = "Yes". For Part Set D to work you must have at least one zone with the attribute Part Set D = "Yes".

In a Partitioned System, for part set to work within a partition you must assign the "Part Set" attribute to at least one zone belonging to the partition.

Options

Note: The default settings for these options are compliant with EN50131, see page 23. Changes to some of the defaults may render the system non-compliant.

Name

Use this option to give the Full Set, Part Set, or Partition a name. The control unit displays this name to the user during setting.

Exit Mode

The exit modes available are:

Timed Set Use this option to make the system set after a delay. Use the Exit Time menu (see page 55) to choose the delay.

Final Door Set Use this option to complete setting the system by closing a door fitted with a Final Exit zone detector. Note that the exit time is infinite in this option.

Note 1: If you wish to use Final Door Set exit mode when part setting then:

a) Make sure that you include a zone with the Final Exit type as one of the part set zones.

b) Make sure you select "Final Door" in Part Set Final Exit As (see page 55).

Note 2: If you wish to use Final Door Set exit mode for a Partition then make sure you include a zone with the type Final Exit in the Partition.

Note 3: Do not try to make a PIR zone act as a Final Exit. Radio PIR detectors have a "lock out" period after each activation in order to conserve battery power. When you set (or part set) the system a PIR may still be in lockout, during which it cannot send a signal to complete the setting process.

Instant Set The system sets immediately and without any setting tone. The keypad(s) give confirmation tone when the system is set.

Silent Set The system sets after the time programmed in the Entry/Exit Time menu but does not give any exit tones. When the system sets the keypad gives a double beep confirmation tone.

The keypad(s) give a double beep confirmation tone at the end of all setting modes.

Settle Time

This option allows you to define a time delay to allow detectors to settle

before the system sets. This may be needed if detectors are being set off by air movements caused by the final door being closed. During this period, the sounders stop and the system sets but the control unit ignores any alarms generated by the detectors.

Enter two digits to specify a time in seconds, from 01 to 30.

Note: This option is available for Final Door Set exit mode only.

Exit Time

The exit time can take any value between 10s and 120s.

Note: If you select Final Door Set or Instant Set for the exit mode then the Exit Time option does not appear in the menu.

Entry Time

The entry time can take any value between 10s and 120s. The entry time you select in this option applies to Full set and all Part Sets.

Strobe on Set (Part Set Strobe Set)

When set to ON this option causes the control unit to activate any output programmed as Strobe, plus the strobe on any 760ES wireless siren. The outputs/strobes are active for three seconds after the system sets. Strobe On Set applies to Full Set and all the Part Sets.

Strobe on Unset (Part Set Strobe on Set)

When set to ON this option causes the control unit to activate any output programmed as Strobe, plus the strobe on any 760ES wireless siren. The outputs/strobes are active for three seconds after the system unsets. Strobe On Unset applies to Full Set and all the Part Sets.

Alarm Response/Part Set Alarm Response

You can select one of the following:

Internal:	Keypads and loudspeakers.
Siren	Keypads, loudspeakers and siren.
Siren + Comms	Keypads, loudspeakers, siren and communication. Note that any Siren Delay (see page 69) applies to "Siren+Comms", but not "Internal" or "Siren" alarm responses.

Part Set Final Exit As

This option controls how the system will treat Final Exit zones in a part set.

Final Door	In a Part Setting system, any Final Exit zones with the Part Set B, C or D attributes will continue to act as Final Exit zones during part set. In a Partitioned system, any Final Exit zones, belonging to the partition, with the Part Set attribute will continue to act as Final Exit zones during part set.
Normal Alarm	In a Part Setting System any Final Exit zones with the Part Set B, C or D attributes will act

as Normal Alarm zones during part set.

In a Partitioned system, any Final Exit zones, belonging to the partition, with the Part Set attribute will act as Normal Alarm zones during part set.

Part Set Entry Route As

This option controls how the system treats Entry Route zones during part set.

Entry Route In a Part Setting system, all Entry Route zones with the Part Set B, C or D attributes will continue to act as Entry Routes during part set.

In a Partitioned system, all Entry Route zones, belonging to the partition, with the Part Set attribute will continue to act as Entry Routes during part set.

Final Exit In a Part Setting System, any Entry Route zones with the Part Set B, C or D attributes will act as Final Exit zones during part set.

In a Partitioned system, any Entry Route zones, belonging to the partition, with the part set attribute will act as Final Exit zones during part set.

Full Set Link

The Full Set Link option is available on Partitioned systems. Full Set Link allows you to set up a Common Area. See Appendix II for an example of how to use a Common Area.

Partition 1 is always the Common Area. You can link Partition 1 to any of the other partitions. When all of the linked partitions are set, then the control unit Full Sets Partition 1. In addition, the system takes on whatever Alarm Response you have allocated to Partition 1.

If you wish to link/unlink partition 1 to many partitions then you can use the "All Partitions" option (in between partition 2 and 20 on the menu) to either link or unlink partition 1 to all the other partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the linking as necessary.

Calendar Set

Using the calendar set option you can program the control unit to set or unset the alarm system (or parts of it) at fixed times of day on a seven day cycle. If the system is set up as a part setting system then you can use this option to Full Set or Part Set-B, -C or -D. If the system is set up as a Partitioned system then this option allows you to Full Set or Part Set any collection of partitions.

There are two basic elements that you can program within the calendar set option: the "event" and the "exception".

Each event specifies:

- A time on the 24 hour clock
- One or more days of the week
- An action (setting, part setting or unsetting).
- A 12 character name as a reminder of the purpose of the event.
- An exception (see below).

Each exception marks a time period when certain events do not apply. An exception has a start time and date, an end time and date, and a name. You link events to exceptions while programming events – see below.

The i-on160EX can store up to 20 events and 30 exceptions.

By using events and exceptions you can program the system to set in a regular pattern for each day of the week, except during significant holidays (or other events) that occur at known times during the year.

Hint: When you are programming calendar set options it is advisable to set up your exceptions first, and then add the events.

Calendar Set Options

Add Event

Use this option to create an event. When you select the option the control unit will guide you through the following series of steps to ensure that you add all the required information:

Event Name. Key in a 12 character name (or press ✓ to leave the default name).

Event Time. Use the 24 hour clock. Note that if you specify a start time that is less than 10 minutes from the current time shown by the control unit clock (less than the number of minutes held in the calendar set warning time) then the event will not take action until the following start day. Also, note that the time "00:00" is midnight, at the beginning of a new day.

Event Days. Press ▲ or ▼ to scroll through each day of the week. Press ◀ or ▶ to specify Yes (event occurs on that day) or No.

Event Actions. In a part setting press ◀ or ▶ to select one of: Full Set, Part Set B (or C or D) and Unset.

In a partitioned system the keypad display shows a list of partitions. Press ▲ or ▼ to scroll through each partition. Press ◀ or ▶ to select one of the actions: Full Set, Part Set or Unset. One event in a partitioned system can affect more than one partition.

Event Exceptions. Press ▲ or ▼ to scroll through the list of programmed exceptions. Press ◀ or ▶ to specify Yes (the exception applies to the event) or No (the exception does not apply to the event).

Edit Event

This option allows you to edit individual parts of an event if you need to change one after setting it up.

Delete Event

Use this option to delete an event.

Add Exception

Use this option to create an Exception. During the time specified by the exception none of the linked events will take place. When you add an exception, the control unit guides you through the following steps:

Name. Key in a 12 character name. Give the exception a meaningful name that will remind you of its purpose when you are linking events to exceptions.

Exception Start Time. Key in the start time in 24 hour format. (The time "00:00" is midnight, at the beginning of a new day.)

Exception Start Date. Key in the starting day and month in number format (for example 31/12 for 31st December).

Exception End Time. Key in the end time in 24 hour format. (The time "00:00" is midnight, at the beginning of a new day.)

Exception End Date. Key in the end day and month in numeric format (for example 02/01 for the 2nd January).

Edit Exception

This option allows you to edit individual parts of an exception if you need to change one after setting it up.

Delete Exception.

Use this option to delete an exception.

Calendar Set Example

As an example, a user wants their system to set every evening during the week at 19:00, and unset at 05:00 in the morning. During the weekend the system should unset on Saturday at 05:00 and set at 13:00. The system should then remain set until Monday 05:00.

At Christmas the system should remain set from 19:00 on 24 December until 05:00 2 January.

To accomplish this set up the following events and exception:

Event 1 Name: Unset AM. Time: 05:00. Action: Unset. Days: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday.

Event 2 Name: Set PM. Time: 19:00. Action: Full Set. Days: Monday, Tuesday, Wednesday, Thursday, Friday.

Event 3 Name: Set Saturday. Time: 13:00. Action: Full Set. Days: Saturday.

Exception 1 Name: Christmas, Start Time: 23:55. Start Date: 24 December. End Time: 00:05. End Date: 2 January.

Calendar Sets in Action

To describe what happens when the control unit reaches the time specified in an event, it is simpler to treat events as if they either set or unset the system. In reality, an event can do both things at the same time to different partitions.

Setting Events. When the control unit reaches a time 10 minutes before that programmed for a setting event, it starts the calendar set warning tone from the keypads and loudspeakers allocated to the partition(s) specified in the event. The control unit also activates any outputs with the type "Autoset Warning" (see page 51).

At the end of the calendar set warning time the control unit stops the warning tone, sets the affected partition(s) without any further delay, deactivates any "Autoset Warning" outputs and activates any "Set" outputs. The system logs a calendar set as "system auto set" along with the affected partition number.

Deferring Setting. During the calendar set warning time a user can interrupt or cancel the setting process. To do this they must key in their access code at a keypad (or present a prox tag) and select either "Defer" or "Cancel". Note that the user must belong to the partition that is due to be set.

If the calendar set warning timer has been deferred by a user, the control unit halts the warning timer, and defers any consequent setting event for 30 minutes. After 20 minutes the control unit starts counting down the warning timer again from 10 minutes. Users can defer a calendar set in this way a total of three times. After the third deferral the control unit will set the system.

If a user presses **x twice**. The first press will start the system setting, the second press will cancel the setting process and take the system back to the calendar set warning tone.

Note that deferring setting does NOT defer any unsetting events.

If the user cancels a calendar set, then the system waits until the next programmed event that calls for setting the system or any partitions.

If There Is a Setting Fault. If there is a fault that would normally prevent the system from setting then a calendar set event will also fail. Ten minutes before the time for a setting event the control unit will start the calendar set warning tone as usual, but at the setting time the control unit will not set the system. The control unit will log the failure as "set fail". At the same time the control unit will activate any output programmed as type "Set Fail".

Unsetting Events. When the control unit reaches the time programmed for an unsetting event the control unit unsets all partitions programmed to unset. There are no specific warning indications for partitions unset by a calendar event.

Manual Setting/Unsetting and Calendar Sets. If a user sets a partition that is due to be set by a Calendar event, then the partition remains set when the calendar event time is past. Likewise, if a user unsets a partition before a calendar event is due to unset the partition then the partition remains unset. Manually setting and unsetting partitions controlled by Calendar Sets will not alter the times programmed in Calendar events.

Restrictions on Calendar Sets

Please remember the following points when setting up events:

1. You cannot program an event to change the system/partition directly from one part set level to another. You must program an event to unset the system/partition first, and another event to set the system/partition to a different part set level. For example, if event A part sets the system (or a partition) then you cannot program event B to full set the system. You must program event B to unset the system and then use event C to full set the system.

2. If you are unsetting a partition and setting the same partition again then you must program the setting event to occur at least 10 minutes after the unsetting event.

System Options

This section of the Installer Menu contains a series of options that affect the working of the alarm system as a whole.

Note: The default settings for these options are compliant with EN50131, see page 23. Changes to some of the defaults may render the system non-compliant.

Wired Zone Type

Normally the control unit asks you to select the zone wiring type when you power up a new installation for the first time, or when you restore the control unit to factory defaults (see page 9). This sub-menu lets you change the zone wiring type for either the control unit or for the whole system. There are two options:

- | | |
|--------|--|
| Panel | This option lets you change the zone wiring type for the control unit. |
| System | This option lets you change the zone wiring type for the whole system. |

For both options the choices available are: 4-wire CC, 4k7/2k2, 1k0/1k0, 2k2/2k2, or 4k7/4k7.

If you select "4 Wire CC" then the control unit and/or expanders provide five wired zones, numbered 1 to 5.

There are several options of resistor values for FSL: the keypad display shows the alarm contact resistor/end of line resistor values for each option.

If you select any of the Panel - FSL options then the control unit provides 10 wired zones, numbered 0 to 9.

If you select any of the System – FSL options then all wired expanders provide 10 wired zones, number 0 to 9.

You can change the wiring type of each wired expander individually, see page 40.

Note: Make sure that all zones are wired correctly for the selected wiring type. See i-on160EX Installation Guide for wiring details.

User Access

To give users access to various system facilities select *System Options – User Access*. Press the ▲ or ▼ keys to scroll up or down the list on the display. To allow access press ► repeatedly until "Yes" appears next to the selected option. To deny access press ► until "No" appears next to the selected option. Press ✓ when you have finished.

PA Keys Active

This option allows users to start an alarm from the keypads by pressing both the Panic Alarm keys at the same time. This option applies to all keypads, both radio and wired, and is not affected by allocating keypads to specific partitions.

Yes The PA keys on all keypads are functional.

No The PA keys are disabled.

Quick Set

Note: If you enable the quick set keys the control unit no longer complies with EN50131.

This option controls the operation of the A, B, C or D keys.

Yes It is possible to set the alarm system by pressing A, B, C or D without entering an access code.

No The user must enter an access code (or present a tag) before pressing the A, B, C or D keys.

Quick Omit

This option allows users to omit a zone that is active (has it's alarm contacts open) while they are setting the system. The zone must have the Omittable attribute (see page 36).

Yes By pressing ✓ the user can set the system if there are zones with the Omit Allowed attribute active.

No The user must go to the Omit Menu to set the system if a zone is active.

User Code Required

Use this option to ensure that an installer or maintainer cannot gain access to program the system unless a user is present:

Yes After the installer/maintainer enters their access code, the system asks for a user access code before allowing access to the Installer Menu.

No The installer/maintainer can enter the Installer Menu by simply keying in their own code.

User Reset

This menu option determines under what circumstances a user or the installer can reset the system after an alarm.

Zone alarms

(Appears when if *System Options – DD243 – Confirmation* is set to "Off", see page 62.)

Yes The user can reset the system after an alarm triggered by a zone's alarm circuit.

No The installer must reset the system after an alarm triggered by a zone's alarm circuit. See also "Remote Reset" on page 97 .

Note: If a user unsets the system during an alarm, but before the Alarm Abort period has expired, then they can reset the system (see page 97).

Zone Tamper

- Yes The user can reset the system after an alarm caused by a zone's tamper circuits being triggered.
- No The installer must reset the system after an alarm caused by a zone's tamper circuits being triggered. The alarm abort period does not apply.

Note: This setting is required for INCERT approval.

System Tamper

- Yes The user can reset the system after an alarm caused by a system tamper, for example the control unit lid or a keypad being opened.
- No The installer must reset the system after a system tamper alarm. The alarm abort period does not apply.

Note: This setting is required for INCERT approval.

If something activates a tamper, either system or zone, when the system is set then the control unit classifies this as an unconfirmed or confirmed alarm. The reset follows the alarm reset option NOT the tamper.

DD243 (UK Only)

Note: This menu is visible only when System Options – Restore Defaults – Country defaults is set to "UK".

In order to program your requirements for DD243 select *System Options - DD243*. The options available are:

Confirmation

When set to 'On' this option enables the features designed to ensure the system complies with DD243:2004.

Note: When using Confirmation, and the system is programmed for Installer Reset after an alarm, the user cannot set the system after an alarm until the installer has carried out a reset.

Confirmation Time

This option determines the length of the confirmation time.

After Entry

- Never The control unit turns alarm confirmation off if the user enters by the entry door (used for DD243:2004 clauses 6.4.2 and 6.4.4).
- 1 zone The control unit starts a confirmed alarm if the intruder activates one or more zones, not on the entry route, after entering the premises through the final exit zone.
- 2 zones The control unit starts a confirmed alarm if an intruder activates two (or more) zones, not on the entry route, after entering the premises through the final exit zone (used for DD243:2004 clauses

6.4.5).

Entry Keypad Lock

This option determines whether the user can unset the system by entering an access code after opening the entry door.

- Off The user can enter an access code at the keypad after the entry door opens (used for DD243:2004 clause 6.4.4).
- On The user must unset the system by some means other than the keypad, for example prox tag, remote control or key-switch (used for DD243:2004 clause 6.4.5).

Note: This option functions when confirmation is ON and communications is enabled. If communications is disabled this option has no effect.

Sounder on

- Unconfirm When the system is set the control unit activates the internal sounders when an unconfirmed alarm occurs.
- Confirm When the system is set the control unit does not activate the internal sounders until a confirmed alarm occurs.

Note: The control unit will not allow you to select "Sounder on - Confirm" at the same time as "Siren on - Unconfirm".

Siren on

- Unconfirm the control unit operates the siren for all alarms (and overrides any Siren Delay).
- Confirm When the system is set the control unit does not activate the siren(s) until a confirmed alarm occurs.

Note: The control unit will not allow you to select "Siren on - Unconfirm" at the same time as "Sounder on - Confirm".

Siren Delay and DD243

The Sounder On and Siren On options are both affected by the Siren Time and Siren Delay, as follows:

Sounder On Unconfirm/Siren On Unconfirm

Unconfirmed alarm: internal sounders and sirens start immediately and run for the programmed siren time (see page 69).

Confirmed alarm: the control unit restarts the sirens and internal sounders, which run for the full programmed siren time (even if that had expired earlier).

Sounder On Unconfirm/Siren On Confirm

Unconfirmed alarm: the internal sounders start immediately and run for the programmed siren time.

Confirmed alarm: the control unit waits for any programmed siren delay (see page 69) and then starts both the internal sounders and the external sirens. These both run for the programmed siren time.

Sounder On Confirmed/Siren On Confirmed

Unconfirmed alarm: No sounders or sirens.

Confirmed alarm: Control unit waits for Siren Delay, and then starts both internal sounders and external sirens. Both sirens and sounders run for the full siren time.

Unconfirmed Reset

If you enable alarm confirmation then this option overrides *System Options - User Reset – Zone Alarms* (see page 61). You may then use the options below:

- | | |
|-----------|---|
| User | The user can reset after an unconfirmed alarm. |
| Installer | The user cannot reset after an unconfirmed alarm, the installer must do it. |

Note: If a user causes an alarm which would require Installer reset then they have 90s to abort the alarm, which they can then reset themselves.

Confirmed Reset

If you enable alarm confirmation then this option overrides *System Options - User Reset – Zone Alarms* (see page 61). You may then use the options below:

- | | |
|-----------|--|
| User | The user can reset after a confirmed alarm. |
| Installer | The user cannot reset after a confirmed alarm, the installer must do it. |

Note: If a user causes an alarm which would require Installer reset then they have 120s to abort the alarm, which they can then reset themselves.

Masking

This option allows you to control whether the system responds to masking or trouble events from those detectors that are capable of reporting them, are connected correctly to the system, and are programmed with the “masking” attribute. The options available are:

- | | |
|----------|--|
| Disabled | The system hides the “Masking” zone attribute, and the <i>System Options – Masking Override</i> menu. The control unit treats masking signals from FSL detectors as alarms or tampers depending on the resistance. |
| Enabled | The “Masking” zone attribute is available to assign to zones and the Masking Override menu option is visible. |

The detector must use 2k2/4k7 FSL wiring with just one pair of contacts, and report masking conditions as a nominal 9k1 resistance. Figure 9 shows the resistance range used for signalling “masking”, and how that range changes when Masking is enabled or disabled.




Figure 9. Resistance bands for FSL detectors

Note that an installer can wire resistors to the contacts of a closed circuit loop detector with a Fault (or Trouble) output in order to use FSL signalling (see *Fully Supervised Loop Connections* in the i-on160EX Installer Guide). The detector must signal masking by closing both the Alarm and Fault contacts together.

When masking is enabled the alarm response depends on whether the system is set or unset, and which resistance range the detector is signalling with.

When the system is **unset**:

Detector Response output

Mask (9k1) The control unit treats a masking event as a fault, activates any outputs programmed as General Fault or Masking, and generates an Alert on the keypads.

A user can reset the system once the masking is cleared.

Fault (4k4) The control unit treats a masking event as a fault, activates any outputs programmed as General Fault or Masking, and generates an Alert on the keypads.

On a Security Grade 3 system the Installer must reset the Alert.

On a Security Grade 2 system the ability to reset the alert is governed by the *System Options - User Reset - System Tamper* option, see page 62.

When the system is **set**:

Detector output Response

Mask (9k1)	<p>The control unit treats a masking event as an alarm condition. This will signal an unconfirmed alarm or will confirm an outstanding unconfirmed alarm. The unconfirmed and confirmed events must be from different detectors.</p> <p>The ability to reset the system after the alarm is governed by the <i>System Options - User Reset – Zone Alarms</i> option, see page 61.</p>
Fault (4k4)	<p>The control unit treats a masking event as a fault, activates any outputs programmed as General Fault or Masking, and generates an Alert on the keypads.</p> <p>On a Security Grade 3 system the Installer must reset the Alert. On a Security Grade 2 system the ability to reset the alert is governed by the <i>System Options - User Reset - System Tamper</i> option, see page 62.</p>

Mask Override

This option controls how the user can respond to a masking event once it is reported by the control unit. There are two options:

Mask Override	A User can override a masking fault to set the system
Mask Inhibit Set	A User is may not override a masking fault to set the system. The system will not set until the masking fault has cleared.

Language

The control unit can use one of several languages in its display. To change the language select *System Options – Language*.

Changing the language does not affect any stored names for full/part set, detectors, outputs or users, and does not change any defaults.

Restore Defaults

Country Defaults

Each country has different settings for PSTN communications and alarm reporting. You can use this option to select default settings for a given country.

Changing the country does not change the language used by the display.

Staged Defaults

This menu option allows you to default parts of the control unit's programming, without affecting the whole system. From within this menu you can choose to default one or more of the following:

Select this option:**The control unit deletes:**

User	All user access codes, their PAs, prox tags, and remote controls. User 01 access code changes to 1234, and installer access code to 7890 (123456 and 567890 in six digit access codes). This option has the same effect as restoring power to the control unit with the Code Reset pins shorted.
Zones	All information relating to zones: types, attributes and partitions. For radio zones the control unit retains the IDs of any detectors that the control unit has already learned.
Radio Devices	All IDs for all learned radio devices. This menu presents each type of radio device is sub-menu: Detectors: Delete radio detectors only. External Sirens: Delete external sirens only. Keypads: Delete all radio keypads only. WAMs: Delete all WAMs. Alternatively you can delete All Devices at once.
Outputs	All programming for outputs.
Setting Information	All programming for setting options.
System Options	All programming for system options.
Communications	All programming for communications.

Factory Defaults

If you wish to remove all programming from a control unit (perhaps to re-install it at another site) select this option.

Note that Factory Defaults erases all wireless devices, names and stored texts. However, selecting Factory Defaults does not erase the log, or delete any users

Installer Name

This field controls the user name employed by the login screen of the i-on160EX Web Server. When logging in to the Web Server you must key into the username field the same text as you have programmed into the Installer Name field. Note that the username field on the Web Server login is case sensitive.

Installer Code

The default Installer access code is 7890 (567890 with six-digit access codes). Cooper Security Ltd recommend that you change this code to some other number. To change the Installer access code select *System Options-Installer Code*.

The Installer code allows you to enter the Installer Menu, and carry out an Installer reset. However, the Installer code does not allow you to set or unset the system.

When logging into the i-on160EX Web Server you must key into the password field the same code as you have programmed into the Installer Code field.

Keypad Text

If required the installer can key in a text message that appears on the first line of the display in the standby screen. This could be, for example, the name of the installer's company. See page 12 for hints on editing text.

Remote needs Entry

Instead of using an entry timer triggered by a Final Exit zone to allow the user to gain access to the control unit and unset the system, the user can employ a remote control. To choose between either of these options select: *System Options – Remote needs Entry*. The options available are:

- | | |
|----------|--|
| Enabled | The user must first trigger an entry zone and start the entry timer before unsetting the system with a remote control. |
| Disabled | The user can unset the system using a remote control without first starting the entry timer. |

PA Response

During a PA alarm the control unit starts communications (provided you have a communication module fitted and enabled, or the communications outputs wired to an appropriate communicator and correctly programmed). This option controls the associated audible alarm.

- | | |
|-----------|--|
| Audible | As well as starting communications the control unit starts PA alarm tones from the keypads and loudspeakers, and activates any siren outputs. The sirens follow the Siren Time (see page 69). The loudspeakers operate until a user silences the alarm. |
| Silent | The control unit keeps the PA alarm silent: there are no alarm tones from keypads or loudspeakers and any siren outputs or PA outputs remain inactive. The control unit signals the PA using the communications device(s). |
| Displayed | All keypads display a PA alert message immediately (a user does not have to key in their access code to see the message). If more than one PA is active then the keypad display scrolls through the alert messages at roughly one second intervals.

The control unit also starts PA alarm tones, activates any siren outputs, and starts communications, as described for the "Audible" option. |

Note: All PAs are disabled when the system is in Installer Menu.

Auto Rearm

(Appears when if *System Options – DD243 – Confirmation* is set to "Off", see page 62.)

To change the number of times that the system will re-arm when the siren time expires select: *System Options-Auto Rearm*.

Select NEVER to make the system never re-arm (the system will go into alarm once only). Select one of the other options to make the system re-arm once,

twice, three, four or five times, or always. The system re-arms all closed zones, but not detectors that are still sending alarm signals. *(Note that this setting is required in order to comply with EN50131.)*

If the system has rearmed, then when a user enters the system through the Final Exit door the control unit will give an audible internal alarm in place of the normal entry tone.

Siren Delay

(For part setting systems only.) When the system is set and (for example) an intruder violates a zone, then the system waits for the programmed Siren Delay before operating the siren. The system then operates the siren for the programmed Siren Time.

Note: Siren Delay has no effect if the Alarm Response Mode does not require communications or if a line fault is detected.

Siren Time

(For part setting systems only.) This option changes the length of time that the system operates the siren during an alarm.

Note: The durations offered by the display apply to a siren wired directly to the control unit.

The 760ES radio siren has one of three fixed sounder durations in an alarm: 5seconds, 3mins or 15mins. These fixed durations are designed to preserve the battery life of the radio siren.

Panel Loudspeaker

Loudspeaker 1 (or 2)

This option allows you to control the volume and the partition assignment of each of the loudspeakers connected directly to the control unit.

Volume

Use this option to change the volume of notification tones from loudspeakers connected to loudspeaker terminals 1 or 2 on the control unit. Press ◀ to lower the volume or ▶ to raise the volume. The display shows the current volume setting by a row of stars (for example "*****"). This volume control does NOT change the volume of alarm tones.

Partitions

In a partitioned system you can assign the panel loudspeakers to any of the partitions. Any loudspeaker can belong to one or more partitions.

Once you have entered the Partitions option, press ▲ or ▼ to scroll through the list of partitions followed by ▶ or ◀ to allocate/deallocate the loudspeaker to each partition as necessary.

If you wish to allocate/deallocate the loudspeaker to many partitions you can use the "All Partitions" option (in between partition 1 and 20 on the menu) to either allocate or deallocate the loudspeaker to all partitions in one operation. Once you have carried out this operation you can then scroll through the partition list and change the allocation of the loudspeakers as necessary.

Entry Alarm Delay

Use this option to determine what the system will do if a user strays from an Entry Route zone during entry. (This option is available to provide compliance with EN 50131-1.)

Select “No” to make the system give an alarm immediately if the user strays from an entry route zone during entry. *Note: This is not compliant with EN50131.*

If you select “Yes” and the user strays from an entry route zone during entry then the system waits 30 seconds before raising a full alarm. The system also gives an internal alarm during the 30 second wait.

If the user enters an access code or presents a tag before the end of the 30 seconds internal alarm then the user can reset the system.

Supervision

If a wirefree detector loses contact for more than 20 minutes then the control unit logs the event as “RF Warning”. In addition, the control unit inhibits setting. If a user overrides the inhibition then the control unit logs the event as an RF warning override.

If a wirefree detector loses contact for more than two hours then the control unit raises an alarm. The options available for this alarm are:

Option:	With system SET, the control unit:	With system UNSET the control unit:
Disabled	Does nothing.	Does nothing.
Fault	Logs the event (but does NOT display any alert or fault tone).	Displays an Alert and sounds a fault tone and logs the event.

Jamming

The control unit can detect interfering (or "jamming") radio signals. To enable jamming detection select *System Options - Jamming*.

If the control unit detects jamming once you have enabled this option then the display shows an Alert message for the user.

Force Set

You may wish to allow a user with a remote control to set the alarm system when one or more of the detectors are not working or are open (active).

Note: If you enable "Force Set" then the system does not comply with EN50131.

There are three options available:

Off

The remote control user cannot force set the system, even if you have applied the force set zone attribute to any zones.

Confirm

The remote control user can force set the system. They must operate as follows: 1) the user presses the appropriate button to set the system, 2) the control unit does not start setting, 3) the user presses the same

remote control button to confirm that they wish to continue setting the system.

On

The user need only press the remote control button once to complete setting the system.

Note: The Confirm and On options will also allow a user with a remote control to set the system if a reset is required after an alarm.

If any user is attempting to reset the system from a wired keypad when a remote user tries to set the system, then the control unit will temporarily ignore the remote user.

Tamper Omit

If a user omits a zone, it may be necessary to also omit the tamper belonging to that zone. This option allows you to do that:

Enabled

The tamper is omitted when a user omits a zone.

Disabled

The tamper is still operational when a user omits a zone.

Anti-Code Reset

Anti-code reset allows an alarm company to control remotely whether a user can reset the system after an alarm. If the system is programmed for anti-code reset, then after an alarm a user can silence the sounders. However, the display tells the user the first zone to alarm, and then instructs them to call the ARC and quote a four digit code. This four digit code is called the "reset code".

If the ARC decides to allow the user to reset the system then they:

Key the reset code into a device or program that produces an "anti-code".

Tell the alarm system user the anti-code.

The alarm system user then keys the anti-code into their keypad and the alarm system resets.

If order for this procedure to work both the alarm system control unit and the ARC must have the same "CSID" code. This acts as a seed for computing both the reset code and its anti-code. The ARC usually generates the CSID code.

Use this option to program the control unit with the CSID required for anti-code reset. If you set the CSID to "0000" then the control unit will not use anti-code reset. If you sent the CSID to any number 0001 to 9999 then the control unit will use anti-code reset.

Silence Alerts

This option controls the length of time that the keypad gives the alert tone (a brief 'beep' every few minutes) when there is an alert. The options are:

User

The keypad gives the tone until a user keys in their access code to acknowledge the alert.

30, 60, 120 minutes

The keypad gives the alert tone for the selected time.

No Alert Tones

The keypad gives no alert tone. (The red LEDs around the navigation key glow to show that there is an alert.)

Mains Fail Delay

This option controls the length of time that the control unit waits until starting an alert if the mains supply fails. The values available are 0 to 10 minutes.

Note that when the value is set to 0 minutes, mains interruptions of less than 9 seconds will not start an alert.

Battery 2

This option can enable or disable alert reporting on the second backup battery. The options are:

Enabled

The control unit will start an alert if battery 2 is missing or low voltage.

Disabled

The control unit will ignore the presence or absence of battery 2.

Communications

Note: If you have connected a plug-by communicator then use the Outputs - Plug-by Outputs menu to program the communicator.

The Communications option in the Installer Menu contains all the options needed to program how the control unit will communicate alarms. Within the Communications option, the main menu items deal with the following areas:

ARC Reporting

Deals with reporting to a central station using either SIA, CID or Fast Format.

Speech Dialler

Deals with recording speech messages, selecting the alarm types that will trigger them, and selecting destinations for the messages. This sub-menu is visible only when the i-sd02 or i-gsm-2 modules are fitted.

SMS

Deals with setting up text messages, selecting the alarm types that will trigger them and selecting their destinations. This sub-menu is visible only when the i-sd02 or i-gsm-2 modules are fitted.

Line Fail Reporting

Allows you to select how the control unit reports a communications failure.

IP Network (Own)

The Web Server sub-menu deals with setting the control unit's own IP address and access to the built in web-pages.

The other sub-menus within IP Network (Own) menu allow you to set up the IP address and other parameters for any attached Ethernet or GPRS modules. *These sub-menus will not appear if the modules are not fitted.*

Downloading

Deals with setting up phone numbers, account numbers for the downloader, and controlling the type of connection you wish to allow.

Note: Apart from Downloading and IP Network (Own), the above menu items appear only if the appropriate module is fitted.

The control unit is designed to alert the user if it fails to complete a programmed communication. If alarm reporting fails then the keypad displays an alert by lighting the red LEDs around the navigation keys. Although the user may acknowledge the alert, the control unit will not remove the alert until communication is completed successfully.

If you wish to remove a communications module from a system, ensure that you first disable communications in the appropriate menus:

To remove a:	Disable:
i-sd02, i-gsm02	ARC Reporting, Speech Dialler, SMS
GPRS, Ethernet	ARC Reporting, IP Network

Otherwise the control unit will continually report a communications failure.

ARC Reporting

To program how the control unit will communicate with an ARC select *Communications - ARC Reporting*.

Call Mode

To choose the call mode for communicating with an ARC select: *Communications - ARC Reporting - Call Mode*. The call modes available are:

Disabled.

The control unit disables all ARC communications.

Note: If you have fitted an 8750 module to the control unit then the module will continue to send Poll calls to the ARC even if you set call mode to disabled. (The ARC will not receive alarm or test calls.) If you also disconnect the Ethernet cable from the 8750 module the control unit will not raise a Line Fail or Poll Fail alert, because you have set the call mode to disabled.

Single.

The control unit reports to the first telephone number in the Phone Book, using a single account number (see "Account Numbers" on page 74).

Operation: The control unit dials the number and attempts to connect with the ARC. If the call fails, the control unit ends the call and then re-attempts to connect up to a maximum of 15 times.

Alternate.

The control unit reports to one of the two telephone numbers in the Phone Book.

Operation: The control unit dials the first telephone number and attempts to connect to the ARC. If it fails, it will then close down and dial the second telephone number and attempt to connect to the ARC. If received and acknowledged on this attempt, the alarm transmission is complete. If the control unit fails to connect to the second telephone number, it will close down again and re-attempt to connect to the first telephone number. The control unit will continue to shuttle between the two numbers up to 15 times.

Phone Book

This option appears only when there is an i-sd02 or i-gsm02 module fitted. Use this menu to store two telephone numbers that the control unit uses to report alarms to the ARC. The control unit accepts one telephone number if you choose Single in the Call Mode menu, or two telephone numbers if you select Alternate in the Call Mode menu.

The control unit can store telephone numbers up to 31 digits long.

Use the ▲ and ▼ keys to move the cursor backwards and forwards through the number if you wish to edit it.

Press ◀ to delete the digit to left of the cursor.

Press * to add a 2 second pause, if required. The display shows this as a comma.

IP Network

This option appears if a GPRS or Ethernet module is fitted. Use it to program alarm receiving company destinations that the control unit must report to over the internet.

Note: Before programming the control unit to use the IP Network please make sure that:

1. *You understand basic IP terminology.*
2. *You have obtained the necessary information from your Internet Service Provider.*

Unit Name

Use this option to store a unique name for the unit.

Polling IP Address

Key in the IP address of the remote polling engine. If the ARC is not using a polling engine then leave this option blank.

ARC IP Address

Use this option for the ARC's main IP addresses. This option provides two entries for storing a primary and a secondary ARC IP address.

Account Numbers.

To store an ARC account number select *Communications – ARC Reporting – Account Numbers*.

If you are programming a partitioned system then the control unit gives you the opportunity to store an account number for each partition. If you are programming a Part Setting system then you can store one account number.

With CID reporting the system reports alarms using a four digit account code.

With Fast Format reporting you can use four-, five- or six-digit codes. The control unit pads five-digit codes to six digits using a leading zero. The control unit leaves four- and six-digit codes unchanged.

Note: If you need to add a letter to the account code press the numbers keys repeatedly until the letter you want appears on the display. See page 12.

Report Type

To choose the report type to send to the ARC select: *Communications – ARC Reporting – Report Type*.

The report types available are: Fast Format, Contact ID, SIA 1, SIA 2, Scancom SIA 3, Extended SIA 3.

Fast Format Channels

(See Appendix I for a brief description of Fast Format.)

If you selected Fast Format in Report Type then you can select *Communications - ARC Reporting - Fast Format Channels* to allocate one of the following events to each of eight channels (defaults in brackets):

1. Not used
2. Fire Alarm (default Channel 1)
3. Panic Alarm (default Channel 2)
4. Burglar Alarm (default Channel 3)
5. Open/Close (default Channel 4)
6. Alarm Abort (default Channel 6)
7. Technical Alarm (default Channel 8)
8. Confirmed Alarm (default Channel 7)
9. RF Low Battery
10. RF Supervision (see note 5)
11. RF Jamming (see note 5)
12. Mains Fail
13. Tamper
14. Open (see note 1)
15. Close (see note 1)
16. Zone Omitted - setting (default Channel 5. see note 2)
17. Zone Omitted - system (see note 4)
18. General Fault
19. Masking
20. Burg Partition 1 (partitioned system only)
- .. and so on up to:
39. Burg Partition 20 (partitioned system only)

Notes: 1. Open and Close provide the same functions as Open/Close, but on two separate channels.

2. Zone Omitted - the control unit sends this signal for five seconds when a user omits a zone.

3. The control unit delays reporting/logging either mains loss, or exiting Installer Menu with mains loss, by 15-18 min (chosen randomly). For Scandinavia the control unit waits at least 60 minutes before reporting.

4. Appears only when DD243 options enabled.

5. The control unit communicates Jamming, Supervision when the system is unset.

CID/SIA Events

(This menu appears only if you select "Contact ID" or any of the SIA versions in *Communications - Report Types*. See Appendix I for a description of the CID and SIA formats.)

To make programming easier, the i-on160EX groups CID/SIA telegrams together into Report Groups. Table 3 lists the telegrams included in each report group, and the relevant CID/SIA codes. When you enable a Report Group, then you are enabling the control unit to send any of the telegrams in that group.

CID/SIA alarm transmissions will take considerably more telephone time than Scancom Fast Format since the system transmits extended alarm data to the ARC.

Note: The control unit delays reporting/logging either mains loss, or leaving Installer Menu with mains loss, by 15-22 minutes (chosen randomly). The control unit delays reporting/logging either mains restore, or leaving Installer Menu with mains restored, by 60-90 sec (chosen randomly).

Table 3. CID/SIA Report Groups

		Code	
Report Group	Includes:	CID	SIA
Fire Alarm	Fire and fire restore	110	FA, FR
Panic Alarm	Zone PA and restore	120	PA, PR
	Keypad PA, Keypad PA restore	121	HA, HR
	RF PA, RF PA restore	-	PA, PR
	Radio keypad PA, radio keypad PA restore	-	HA, HR
Burglar Alarm	Burg and Burg restore	130	BA, BR
	Alarm confirmation	139	BV
	Masking fault and restore	380	BT, BJ
	Alarm Abort	406	BC
Technical Alarm	Technical alarm and restore	150	UA, UR
Masking	Mask Alarm	380	BT
	Mask Restore	380	BJ
	Detector 4k4 Fault	389	IA
	Detector 4k4 Restore	389	IR
Tamperers	Keypad tamper and restore	137	TA, TR
	Detector tamper and restore		
	Lid tamper and restore		
	Bell tamper and restore		
	Radio keypad tamper and restore		
	External siren tamper and restore		
	WAM tamper and restore		
	Missing bus device and restore	137	EJ, ES
	Tamper bus device and restore		
	User code tamper (excess keys)	461	JA
Set/Unset	System/Partition set and unset	401	CL, OP

	System/Partition keyswitch set and unset	409	CS, OS
	Calendar set deferred	-	CE
Part Set	System/Partition part set	401	CL
	System/Partition keyswitch part set	409	CS
Reset	System/Partition reset	305	OR
Exit Timeout	Exit timeout and restore	457	EA
Omit	User zone omit. System zone omit.	573	BB
RF Supervision	Zone supervision fail and restore Radio keypad supervision fail and restore External siren supervision, fail and restore* WAM supervision fail and restore	381	BZ
RF Jamming	Jamming fail and restore*	344	XQ,HQ
RF Battery/PSU	Smoke/WAM psu fail and restore	337	YP, YQ
	Zone low battery fail and restore	384	XT, XR
	Ext Siren/WAM low battery fail and restore	338	YT, YR
Panel Battery	Control unit battery low/fail and restore	302	YT, YR
	Control unit battery low/ missing and restore	311	YM, YR
Mains Fail	Mains fail and restore	301	AT, AR
Faults	Fail and restore for: Aux 12V, Aux 14.4V, Bell 12V, Bus 12V, System 12V	300	YP, YQ,
	System error	-	YW
	External battery fault and restore	311	YM, YR
	WAM trouble and restore	320	TA, TR
	Bus device aux fuse fault and restore	330	ET, ER
	Bus device low voltage fault and restore	337	ET, ER
	External PSU fault and restore via zone n	-	YP, YQ
	External PSU low volts via zone n	338	YT, YR
	External PSU AC fail and restore	342	AT, AR
	Comms line fault and restore	351	LR, LT
	Smoke fault and restore	373	FT, FJ
	4k4 Fault and restore on zone n	389	IA, IR
Installer Mode	Installer mode start keypad (web)	627	LB (RB)
	Installer mode end keypad (web)	628	LS (RS)
User Code Change	User a changed user b's code	-	JV
	User a deleted user b	-	JX
	User codes defaulted	-	RH
Time Date Reset	Time and date reset	625	JT
Downloading	Downloading successful	412	RS

Downloading failed	-	RU
*Notes: 1. The control unit communicates Jamming, Supervision when the system is unset.		

Restorals

When you enable a CID/SIA Report Group, the control unit sends the relevant telegram both when an event occurs, and when the condition causing the event stops. The second transmission of the telegram is also called a “restore”. You can enable or disable restoral reporting by selecting *Communications – ARC Reporting – Restorals*. The options available are:

- Disabled
- Restore off. The control unit does not communicate restores.
- Enabled.
- Restore on. The control unit does communicate restores.

Burg Comms Rearm

(This menu appears only if you select “Fast Format” in *Communications - Report Type*.) This menu option determines what the control unit does with the “Burg” Fast Format channel 3 at the end of the siren run time. There are two options:

- Disabled
- The channel stays active until an Installer or user resets the system.
- Enabled
- The system rearms Channel 3 once the siren timer has expired. Once the Channel is rearmed, the system is ready to report any new alarm. The system bypasses any detectors that are still triggered.

Notes:
If a Final Exit Zone is triggered, Channel 3 becomes active at the end of the Programmed Entry time.

21CN FF Ack Time

(This menu appears only if you select “Fast Format” in *Communications - Report Type*.)

A PSTN line connected to a BT21CN line (or equivalent) will take longer to acknowledge a Fast Format transmission. This option allows you to adjust the length of time that the control unit waits for the ARC acknowledgement. You can adjust the acknowledgement time from a minimum of 400ms up to a maximum of 1200ms in 100ms steps.

Send Tamper as Burg

When using CID reporting this option allows you to program the control unit to send tampers as alarm.

- If you select Disabled, (the default) then the control unit sends all CID messages as specified in *Communications – ARC Reporting – CID/SIA Events*.
- If you select Enabled then for full alarm response the control unit sends tampers as burglary (BA) and sends Contact ID 130 in place of Contact ID 137.

Dynamic Test Call

In dynamic testing the system makes a test call 24 hours after the last alarm communication. To enable dynamic testing select *Communications – ARC Reporting – Dynamic Test Call – Enabled*.

Static Test Call

In static testing the system makes a test call either on:

Every day at one particular time of day or

On the same day of every week, or

On one day every month.

To make test calls at a set time every day select *Communications – ARC Reporting – Static Test Call – Daily*. From the display select a number between 01 and 24 to choose the time of day for the call. For example, select 18 to program the control unit to make a static test call at 6:00pm every day.

To make test calls on the same day every week select *Communications – ARC Reporting – Static Test Call – Weekly*. From the display select the day of the week on which the call should take place. Next, key in the hour of the day (01 to 24) on which the test call should occur..

To make test calls on one day every month select *Communications – ARC Reporting – Static Test Call – Monthly*. From the display select a number between 1 and 31 to specify the day of the month on which the call should take place. Next, key in the hour of the day (01 to 24) on which the test call should occur.

For each of the three types of call, the control unit will add or subtract up to 16 minutes at random to the hour you specified. This is to make sure that the ARC is not overwhelmed with a flood of test calls from systems that have all been given the same time.

Select *Communications – ARC Reporting – Static Test Call – Disabled* to disable static test calls.

Speech Dialler

The i-sd02 has a built-in speech dialler. The module can record five speech messages using its internal microphone and replay them to a pre-programmed telephone number to report an alarm. One message is called the "Home message", and is always played at the beginning of a report. You should use this message to identify the control unit and it's location. The other four messages allow you to record some indication of the type of event causing an alarm, for example: "Fire" or "Panic Alarm". The control unit plays these messages after the home message.

The i-sd02 can record up to ten seconds of speech for the Home message, and up to five seconds of speech for each of the alarm messages.

While programming the speech dialler you link each message with the specific alarm type you wish to report. You then select a set of destinations for each message, where each destination corresponds to one of the telephone numbers you wish to call (see Figure 10).




Figure 10. Speech Dialler Programming.

If the control unit has Call Acknowledge enabled (see page 82), then the person receiving the speech messages can control the link by sending DTMF tones back to the control unit (usually by pressing buttons on the telephone key pad). The commands available are:

Function	Key
End this call	DTMF '5'
Play 'Home' and 'alarm' message	DTMF '3'
Clear down	DTMF '9'

Note that when the called party answers a speech dialler call there could be a six second delay before the control unit starts playing the home message.

Call Mode

This option enables or disables the speech dialler feature. To employ speech dialling set the call mode to "Enabled".

Messages

To record the speech messages you wish the speech dialler to use enter Installer Menu and select *Communications – Speech Dialler – Messages*.

There are five messages slots available: The Home Message and Messages 1 to 4. Within each message you can use one of the following options:

- Record Message** Press ► to start recording. The control unit starts recording from the i-sd02's built in microphone. The display shows a progress bar indicating how long you have left to record. Press ✕ to end recording.
- Play Message** Press ► to play back the message from the i-sd02's speaker.
- Delete Message** Press ► to delete the message. When the display asks

"Delete Message?" press ✓.

Use Lid Tamper This puts the control unit into a special mode where the tamper switch controls the recording and playback of the current message. Use this mode if the control unit is an inconvenient distance from the keypad.

1. Start with the control unit lid off and the tamper switch open.
2. At the keypad select *Use Lid Tamper* and press ✓.
3. At the control unit hold down the tamper switch. When the red LED on the I-SD02 glows recite your message.
4. Release the tamper switch.
5. Pulse the tamper switch briefly.
The i-sd02 plays back your recording.
6. Go back to the keypad and press ✕.
7. If required, replace the control unit lid. **DO NOT** replace the control unit lid until you have left the "Use Lid Tamper" mode.

Phone Book

To record the telephone numbers that you wish to use, select *Communications – Speech Dialler – Phone Book*. (See "Destinations" on page 82 for instructions how to link messages to phone numbers.)

Select one of the telephone numbers.

The display shows the current digits of the selected telephone number.

Key in the telephone number. Press * to add a two second pause, if required. The display shows this as a comma.

Press ✓ when you are happy that the number is correct.

The display then gives you a chance to key in a name for that number. The control unit will display this name in the phone book to help you remember what destination you wanted the message to go to. (See page 12 for hints on editing text.) Press ✓ when you are happy that the name is correct.

Note that once you have set the speech dialler call mode to "enabled" (see page 80) and assigned a report trigger a message, and a message to a telephone number (see below) then the control unit makes this number available in the User Menu. User 01 can enter a new telephone number in this slot at will. This allows the user to re-direct any speech message destined for this number. The user cannot disable the telephone number by entering a blank number; the fact that they have changed the number is logged.

Triggers

In the i-on160EX you can link up to five different trigger events to each speech message. A trigger event is one item selected from a list of alarm types.

To link specific trigger events to individual messages select *Communications – Speech Dialler – Triggers*.

The display shows a list of speech messages. (Note that the home message does not appear. The control unit always sends the home message at the

beginning of each transmission.) Select the message that you wish to program. The display then shows a list of five triggers.

Select a trigger and the display shows a list of available alarm events. Select one alarm event for that trigger. When you have selected an alarm event the display shows the list of triggers again. You may program one alarm event for each of the five triggers in the list.

When you finish selecting alarms for each trigger, you have now linked alarm events to triggers, and one or more triggers to a message.

Destinations

Once you have programmed telephone numbers, messages and triggers, you must then link specific messages to individual telephone numbers. To do this select *Communications – Speech Dialler – Destinations*.

Select a message from the list on the display. The control unit will show you a list of telephone numbers. If you gave a telephone number a name then the display shows the name instead of the digits of the number.

Highlight a telephone number and press ► until a “Yes” appears after the number. Press ✓ when you have finished. The control unit will send the selected speech message to every telephone number with a “Yes” next to it.

Note: There are a total of five voice messages available. The control unit always sends the Home Message at the beginning of every speech report. The control unit then sends messages 1, 2, 3 or 4 to the telephone numbers you selected.

Call Acknowledge

If the called party answers a speech dialler call, then they can end the call by sending back a DTMF '5'.

With Call Acknowledge **enabled** the control unit ends the call when it receives a DTMF '5' or '9'. If the control unit does not receive a DTMF '5' or '9' then it attempts to call again (up to three times).

Note that after receiving a DTMF '5' the control unit will go on to call any other programmed speech dialler numbers.

After receiving a DTMF '9' the control unit will cancel all further calls for the current alarm.

With Call Acknowledge **disabled** the control unit stops further call attempts to that number as soon as it detects a call being answered.

SMS

The control unit can send alarm reports by SMS message to any of four telephone numbers. Each alarm report is a single SMS message, comprising:

- A Home Message and a text message. You must program the control unit with the content of these messages.

- The text of the log entry that corresponds to the event causing the alarm.

- The time and date of the alarm.

- The zone name of the zone causing the alarm.

The control unit sends the text in the Home Message to every telephone number you have programmed for SMS messages. The control unit also sends message 1 to telephone number 1, message 2 to telephone number 2, message 3 to telephone number 3 and message 4 to telephone number 4.

When programming SMS you key in the text of each message, link the messages to specific groups of alarms, and then key in the telephone number you want each message to go to.




Figure 11. SMS Message programming

Call Mode

This option enables or disables SMS reporting. To employ SMS reporting set the call mode to "Enabled".

Messages

To set up the text of SMS messages select *Communications – SMS – Messages*.

The bottom line of the display shows the first item in a list of the messages you can program. Press ▲ and ▼ to scroll to the required message followed by ✓ to select it. Then key in the text and press ✓ to finish.

The Home Message provides space for 12 characters. Use this text to identify the control unit. Each of messages 1 to 4 provides space for 30 characters. Key in a message that relates to the type of alarm event you select as a trigger (See "Triggers" on page 84).

Phone Book

To program the telephone numbers that the control unit will use for SMS message select *Communications – SMS – Phone Book*. The bottom line of the display shows the first of a list of phone numbers. Press ▲ and ▼ to scroll to the required phone number followed by ✓ to select it. Key in the correct digits and then press ✓.

The display then allows you to give the telephone number a name. The control unit will display this name in the phone book to help you remember what destination you wanted the message to go to.

Triggers

You can link a set of alarm events to each message. To link an event select *Communications – SMS – Triggers*.

The bottom line of the screen shows the first message. (Note that the display does not show an entry for the Home Message. The control unit sends the text in the Home Message at the beginning of every SMS message.) Press ▲ or ▼ to scroll to the message you want to program and press ✓ to select it. The bottom line of the display shows the first item in the list of events that you can chose to trigger the message.

The display shows a "Yes" or "No" next to the event you have selected. Press ► to convert the "Yes" to an "No". You can select a "Yes" for more than one event in the list. Press ✓ when you have finished. The control unit will start sending an SMS message whenever it detects one of the events that you have marked with a "Yes".

PSTN SMS

If you do not have a GSM module fitted, but are sending SMS messages by way of the PSTN line, then you must program some extra information under this menu.

Select *Reporting – SMS – PSTN SMS*.

The display shows the following options:

- | | |
|-----------------------|---|
| Protocol | This option allows you to select the protocol used by the Service Centre. The options available are: TAP 8N1, TAP 7E1 and UCP. |
| Service Centre Tel No | The option allows you to store the Service Centre's telephone number. Consult the technical support department of the service provider that you wish to use. When asking for the service centre number ask which protocol they support. Press * to insert a two second pause, if required. The display shows this as a comma. |

Line Fail Response

This menu lets you program the system to respond with either audible or silent alarms when the control unit detects a fault on one of its communication lines. To program Line Fail Response select *Communications – Line Fail Response*.

The exact response depends on whether the system is set or unset, as follows:

Audible	<p>If the system is unset then the system logs the event. The keypads produce a short audible tone every minute. Entering a valid access code silences the sounders and the display indicates a telephone line fault. The system can be set again with the line fault present.</p> <p>If the system is set then the control unit logs the event but does not give any tone or display. The control unit cancels any programmed siren delay if the line is out of order when an alarm occurs.</p>
<i>Note: Cooper Security recommend audible response for line fault.</i>	
Silent	<p>If the system is unset then the display indicates a telephone line fault and the control unit logs the event. The system may be set again with the line fault present.</p> <p>If the system is set then the control unit does not give any indication or tone but does log the event. The control unit cancels any programmed siren delay if the line is out of order when an alarm occurs.</p>
Disabled	The control unit does not monitor the telephone line.

Line Fail Delay

This menu controls the length of time that the control unit waits until starting an alert if the communications line fails. The values available are 0 to 60 seconds.

IP Network (Own)

This menu allows you to:

- Give the control unit its own IP (Internet Protocol) address, used for the built in Web Server
- Give any GPRS or Ethernet module their own IP numbers ready for use with IP Alarm Reporting or IP Downloading.

If there is no GPRS or Ethernet module present then the IP Network (Own) menu contains the following options:

Web Server	<p>This sub-menu controls the availability of the control unit's built-in web server. There are two lower options:</p> <p>Status Set the Status to Enabled in order to make the web server available. Setting Status to Disabled halts the web server.</p> <p>Port Number This is the port that the control unit uses for the web server. The format is a group of digits up to five digits long. The default port is 80.</p>
IP Address	This is the control unit's own IP address. The IP address comprises four groups of digits. Each group is three digits long, and is separated from the next group by a "dot", for example "192.168.000.001". Press "*" to key in the dot.
Sub-Net Mask	If necessary, key in the sub-net mask, for example

"255.255.255.000". This number has the same format as the IP address.

Gateway Address This is the IP address of the router that connects the local network, to which the i-on160EX is connected, to rest of the Internet (or to a larger network). If necessary, key in the gateway IP address. This number has the same format as the IP address.

Notes:

1. If you leave IP Address, Sub-Net Mask and Gateway Address blank then the control unit will use DHCP (Dynamic Host Control Protocol) to obtain these values from a DHCP server.
2. Once you have entered the details described above, you can see what IP address you have given the control unit by selecting the About Panel - About Comms - IP Address option from the Installer menu. See page 150

If there is a Chiron, GPRS or Ethernet module fitted then the above items appear under a sub-menu titled "Panel Ethernet".

Chiron or Ethernet Module

If there is a Chiron or Ethernet module fitted then you will see the following additional options, designed to specify the IP details for the module itself:

IP Address This is the module's own IP address. The IP address comprises four groups of digits. Each group is three digits long, and is separated from the next group by a "dot", for example "192.168.000.001". Press "*" to key in the dot.

Sub-Net Mask If necessary, key in the sub-net mask, for example "255.255.255.000". This number has the same format as the IP address.

Gateway Address This is the IP address of the router that connects the local network, to which the module is connected, to rest of the Internet (or to a larger network). If necessary, key in the gateway IP address. This number has the same format as the IP address.

Note: If you leave IP Address, Sub-Net Mask and Gateway Address blank then the control unit will use DHCP (Dynamic Host Control Protocol) to obtain these values from a DHCP server.

Port Number This is the port that the module uses when connecting to Downloader.

Note: Once you have entered the details described above, you can see what IP address you have given the control unit by selecting the About Panel - About Comms - IP Address option from the Installer menu. See page 150

GPRS Module

If you have fitted a GPRS module you will also see the menu option "Module: GPRS". This menu has the following options:

IP Address	This is the module's own IP address. If you leave it blank the service provider will give the module an IP address using DHCP. (Cooper Security recommend that you leave this field blank.)
Port Number	If you wish to change the port number used by the module then key in the new port number here.
APN	Key in the GPRS Access Point Name here.
Username	Use this option to store the GPRS User ID.
Password	Use this option to store the GPRS password.
If you have fitted an Ethernet module you will see the menu option "Module: Ethernet". This menu has the following options:	
IP Address	This is the module's own IP address.
Sub-Net Mask	If necessary, key in the sub-net mask, for example "255.255.255.000". <i>Note: If you leave IP Address and Sub-Net Mask blank then the control unit will use DHCP (Dynamic Host Control Protocol) to obtain these values from a DHCP server.</i>
Gateway Address	This is the IP address of the router that connects the local network, to which the i-on160EX is connected, to rest of the Internet (or to a larger network). If necessary, key in the gateway IP address.

Downloading

The control unit can communicate with Downloader software running on a PC. Downloader connects with the control unit either locally over the USB (Universal Serial Bus) port or, if you have fitted a communications module, remotely over a telephone line.

While connected Downloader can inspect and/or change the control unit's programming configuration. If you do not wish to change the configuration you can simply monitor the state of the control unit and its zones from the PC.

In order to use Downloader software you must program following options:

Account

As part of ensuring the security of a connection, Downloader must use an account name and serial number for each control unit.

While the control unit is in Installer Menu you can change the account name and serial number from the keypad: Select *Communications - Downloading - Account*.

Account Name: This can be any string of alphabetic characters or numbers up to 16 characters long.

Serial Number: This must be an eight digit numerical string. If the number you wish to use has less than eight digits then insert leading zeroes.

Connection Type

To choose which physical connection you wish to use select *Downloading - Connection Type*. The options available are:

- Remote Automatically answer calls coming from a remote PC over the telephone network. You will also need to program "Rings to Answer" and/or "Answer on One Ring", see below. (Note that Secure Callback does not work with this option.)
- Local Connect the control unit to a PC (for example a laptop) using a local USB cable.

Note: The control unit will leave the Connection Type menu if Downloader does not make a call within 30 minutes.

See "Access Mode" on page 88 if you want the control unit to answer incoming calls from Downloader without an Installer being present.

Rings to Answer

(This option appears only when the i-sd02 or i-gsm02 module is fitted.)

Select *Downloading - Rings to Answer* to set the number of rings that the system waits before answering an incoming call from the remote PC.

Answer On One Ring

(Also known as Answer Phone Defeat, this option appears only when the i-sd02 i-gsm02 module is fitted.) Use this feature if the alarm system shares a line with other equipment. Select *Downloading - Answer on One Ring*.

When enabled, Downloader "warns" the control unit that a call is coming by ringing the control unit number, waiting for between one and two rings and then hanging up. The control unit now knows to expect a call within the next 10 to 90 seconds. Downloader then rings the control unit again, within 10 to 90 seconds. The control unit answers after the first ring.

Note: When using "Answer on One Ring" set the number of rings in "Rings to Answer" to a higher number than that used by the equipment sharing the telephone line with the control unit. If you do not, then the other equipment will never answer any incoming calls.

Access Mode

This function allows you to provide extra security when a remote PC is dialling into the system. Select *Downloading, Access Mode*.

Once Downloader is connected to the control unit then it has access to all system programming. If you wish to provide secure access then use either Call Out Only or Secure Callback. Please note that you cannot use Secure Callback with Local connection.

- Call Out Only. Someone must start a call to the remote PC manually from within User Menu (select *User Menu – System Config – Call to Dwnldr*).
- Secure Callback. When the remote PC calls, the system waits for the set number of rings (see "Rings to Answer") and then answers. The remote PC sends a control unit ID, the Downloader software version, and indicates which of the two Downloader Telephone Numbers to use (see "Phone Book" below). The system checks that the remote PC is sending the correct control unit ID, and is using the correct

Downloader software version. If these items don't match then the system hangs up. If the items do match then the system hangs up and, after a short delay, the system seizes the telephone line and calls the PC using the indicated Downloader Telephone Number.

Notes:

a) Secure Call Back must be Disabled until the first "attended" upload has been performed. This first upload can be carried out either from User Menu, or from Installer Menu.

b) Secure Call Back mode does not comply with EN50131.

Unattended.

The control unit answers as soon as the number of rings set in "Rings to Answer" or "Answer on One Ring" have elapsed.

Notes:

a) The Downloader operator can choose to use Secure Callback, even though the alarm system is programmed for Unattended Mode.

b) Unattended mode does not comply with EN50131.

Phone Book

(This option appears only when the i-sd02, i-dig02 or i-gsm02 module is fitted.)

Select *Downloading - Phone Book* to program two separate, 31-digit telephone numbers that the system will use during downloading. When the remote PC operator makes a connection they select one of these telephone numbers for the control unit to call back on (for example to the operator's home or office).

Press ▲ or ▼ keys to move the cursor backwards and forwards through the number if you wish to edit it.

Press ◀ to delete the digit to right of the cursor.

Press * to add a 2 second pause, if required. The display shows this as a comma.

IP Network

If you have fitted an Ethernet module (08750EUR-00) to the control unit then it is possible for Downloader to communicate with the control unit using the Internet Protocol. This menu allows you to store two IP addresses that the control unit can "call" in order to start a Downloading session. The user starts the call by selecting one of the IP address.

The options available are:

- | | |
|----------------|---|
| IP Address | This option presents two sub-menus where you can key primary and secondary IP Addresses used by Downloader. The IP address comprises four groups of digits. Each group is three digits long, and is separated from the next group by a "dot", for example "192.168.000.001". Press "*" to key in the dot. |
| IP Port Number | This option also presents another two sub-options where |

you can key in the port numbers that Downloader “listens” to on the remote PC for the primary and secondary IP addresses.

Secure Callback

(This option appears only when the i-sd02 or i-gsm02 module is fitted.)

Select *Downloading - Secure Callback* to allow Downloader to use a third callback number (independent of the telephone numbers in the *Downloading – Phone Book* option). Before making a Downloader connection, the remote PC operator keys in the third callback number. Once connected Downloader transmits the number to the control unit. The control unit then uses that number to call back to the remote PC.

Modem Baud Rate

(This option appears only when the i-sd02 or i-gsm02 module is fitted.)

Over some noisy telephone lines Downloader communicates more effectively using a slower Baud rate from the control unit. Select *Downloading – Modem Baud Rate* to change the baud rate to 300 baud.

Test

The i-on160EX provides three options within the Installer Menu to help in testing: the Test option itself, the View Log option to see what events have been recorded, and the About option so that you can check on the release level of the software.

If you think that part of the system is not working correctly then you can use the Test option to test various peripherals.

The Test option also lets you check the identity of Remote controls, Panic Alarms and Tags.

You can test each part listed in the Test menu as follows:

Sirens and Sounders

This option allows you to test all the warning devices connected to the control unit. The option is divided into sub-menus allowing you to test specific types of sounder, as shown in the table below:

Ext. Radio Sirens	This option presents a list of the learned-in radio sirens. Select a siren for testing by pressing ▲ or ▼. Note that both siren and strobe should operate.
Wired Sirens	This option allows you to operate all outputs programmed as “Siren” and “Strobe”. Either: Select “All Sirens” to operate all sirens at once. OR: Press ▲ or ▼ to select the sirens for an individual partition.
Loudspeakers	With this option you can test any loudspeakers connected to the system. Either: Select “All Loudspeakers” to operate all loudspeakers at once. OR: Press ▲ or ▼ to select the loudspeakers for an individual partition.

Wired Keypads Use this option to test the sounders on the wired keypads. Either: Select "All keypad sounders" to operate all wired keypad sounders on the system at once.
 OR: Press ▲ or ▼ to select the wired keypad sounders for an individual partition.

Note that options for radio sirens will not appear if the control unit has not learned any radio sirens.

Select the type of sounder you wish to test and press ✓. The sub-menu gives you the option to test all sounders in a category at once, or to select individual partitions and test the sounder(s) for that partition. (The display will only present those partitions that have zones allocated to them.)

Press ► to turn the sounder on. Press ► to turn the sounder off again. The display shows the word "On" when the sounder should be operating and "Off" when the sounder should be silent.

Wired Keypad

Use this menu option to test the keypad you are currently holding (you cannot test a keypad remotely). When you start the test the display shows the keypad name and bus address. All four LEDs should glow. The LEDs around the navigation should all glow red. Every time you press a navigation key the LEDs change colour. Press all the keys one by one. The display should show you the key you pressed. To test the PA keys press them both at the same time.

Note: While you are using the Test – Wired Keypad option activating a keypad PA will not cause a PA alarm.

Press ✕ to leave the test.

Radio Keypad

Please note that there is no Test menu option for the radio keypads.

If you suspect that radio keypad keys are not working then:

- a) Press the A, B, C, D and Unset keys one after the other. The transmit LED should flash for each key press. This verifies whether these five keys are working.
- b) Test all the other keys (including the two-button PA) by using valid access codes to set/unset the system, or to generate a PA while the system is unset.

Walk test

The walk test menu provides several different ways of organising a walk test. The options within Walk Test are:

Chime Use this option to turn a chime tone on or off. When the chime tone is on, the keypads and loudspeakers will sound a chime tone for each zone that triggers while you are performing a walk test.

System This option allows you to walk round the entire system and test all the zones.

Partitions	<p>Use this option to select one or more partitions, and test the zones only within those partitions.</p> <p>Use ▲ or ▼ to scroll up and down the list of partitions. Press ◀ or ▶ to display "Yes" at the end of the bottom line to mark the partition as one you want to test.</p>
Expanders	<p>Use this option to select an individual expander, and test the zones belonging to just that expander.</p>
Zones	<p>This option lets you select one or more individual zones, and test only those zones and no others.</p> <p>Use ▲ or ▼ to scroll up and down the list of zones. Press ◀ or ▶ to display "Yes" at the end of the bottom line to mark the zone as one you want to test.</p>

When you select a Walk Test option (apart from the Chime option), the display shows the first item in a list of the detectors available for test. Walk around the area you wish to test and trigger each detector. If the Chime option is set to "Yes" then every time you trigger a detector the keypads and loudspeakers give confirmation tone. The bottom right of the display shows an "A" if you trigger the Alarm input and a "T" if you trigger the Tamper.

The top of the display shows the number of zones left to test. The control unit decreases the number of zones every time you trigger an individual Alarm input.

The bottom line of the display shows the zone name. To see the zone number press ◀ or ▶ .

Press ✓ to end the test.

Note: Use the Walk Test option to test wired PA switches. While you are using the Walk Test option activating a wired PA switch will not cause a PA alarm.

If you wish to see which zones have not yet been tested then press the menu key. The bottom line of the display will show the first in a list of those zones remaining to test. As you test each zone it will disappear from the display. Press the menu key again to return to the full list of zones.

Zone Resistances

When you select Zone Resistance, the display shows the first of the available wired detectors. Press ▲ or ▼ to see the other detectors in the list.

The bottom line of the display shows the zone name. To see the zone number press ◀ or ▶ .

The end of the bottom line shows the resistance of the zone. The display alternates between the Alarm resistance ("A") and the Tamper resistance ("T").

"O/C" means Open Circuit.

"0k00" means zero resistance or closed circuit.

Signal Strengths

This option allows you check the received signal strength from all the radio transmitters belonging to the system.

The keypad display shows first: the strength of the most recent signal it has received from a transmitter, and second: (in brackets) the minimum strength signal it has received from the transmitter since the records were last reset. The control unit is always recording signal strengths, whether or not you are using the Signal Strength menu.

Note: If you have fitted a WAM to act as a repeater for weak detector signals then you will not see any change in the signal strength reported for those detectors. However, you should note the signal strength of the WAM, since that device is now passing on the information from the detectors whose signal you are trying to amplify.

To reset the signal strength records press "D" while you are in the *Tests – Signal Strength* menu. When you press "D" then the control unit resets the signal strength records for ALL transmitters.

You can also reset the signal strength record of individual transmitters. To do this press "#" while the display shows the signal strength of the transmitter you wish to reset.

There are four sections to the Signal Strength menu: *Detector Signals*, *Radio Sirens*, *Radio Keypads*, and *WAMs*. Press ▲ or ▼ followed by ► to select the section you want to test.

Detectors

The display shows the strength of the most recently received signal from each learned radio zone (zones 17 to 40). The bottom line of the display shows the zone name. To see the zone number press ◀ or ▶.

Radio Keypads

The display shows a list of the received signal strengths from each radio keypad.

External Sirens

The display shows a list of the received signal strengths from each 760ES siren.

WAM Signals

The display shows a list of the received signal strengths from each learned WAM.

Outputs

This option has three sections: *Radio Outputs*, *Wired Outputs* and *Plug-by Outputs*. Press ▲ or ▼ followed by ► to select the section you want to test.

Within each section the bottom line of the display shows one from a list of outputs belonging to the section. Press ▲ or ▼ to display the output you wish to test then press ► to activate the output. Press ✓ to finish the test.

When you complete testing the outputs check that they are in the state you wish to leave them in.

Remotes

The Test menu allows you to test user's remote control (you must have the remote control to carry out the test). From the Installer Menu select *Test-Remotes*.

The keypad display shows a message asking you to press any button on the remote you wish to test.

Press one of the remote's buttons.

The top line of the keypad display shows the remote's identity, the button you pressed and the remote's owner. The bottom line of the display shows the action assigned to that button and the signal strength.

Press all the other buttons on the remote to test them in the same way.

Note: To test the PA function on a remote use the Test – User Panic Alarms option in the Installer Menu. A remote's PA keys are not active in Test – Remotes option.

User Panic Alarms

The Test menu allows you to test user's PA transmitters. You must have the PA transmitter to carry out the test. From the Installer Menu select *Test – User Panic Alarms*.

The keypad display shows a message asking you to press the PA buttons.

Press the PA buttons, both at the same time. (The alarm system will not start a PA alarm as a result.)

The keypad display shows the PA's owner. The bottom line of the display shows the signal strength.

Note: To test wired PA buttons use the Test – Walk Test option. To test PA buttons on a keypad, use the Test – Wired Keypad option. If you attempt to test either of these functions while in User Panic Alarms you will start a genuine PA.)

Prox Tags

The Test menu allows you to test a user's proximity tag. (You must have the proximity tag in order to test it.) From the Installer Menu select *Test – Prox Tag*.

The keypad display shows a message asking you to present the tag to the keypad.

Hold the prox tag up to the keypad.

The keypad display shows the owner of the prox tag.

ARC Reporting

The Test menu allows you to send a test call to either of the two telephone numbers you have programmed to receive alarm information. The control unit must have a suitable communications module fitted. ARC reporting must be enabled (see page 73).

From the Installer Menu select *Test – ARC Reporting – Tel No 01* (or *Tel No 02*).

The control unit starts the test call as soon as you press Y. Press X to abandon the test call.

During the test call the keypad display will show a sequence of progress messages, for example:

Dialling...

Connected...

Negotiating...

Call Successful... (or Call Failed...).

If the call fails the keypad display will show a brief message giving the reason for failure.

Speech Dialler

The Test menu allows you to send a test speech call to any telephone number (not just the ones programmed to receive speech messages in the event of an alarm).

From the Installer Menu select *Test – Speech Dialler*.

The keypad display shows a message asking you to key in a telephone number.

Key in the telephone number of the phone that you wish to receive the test message and press ✓.

When you press ✓ the control unit starts the test call. The keypad display shows: "Dialling...".

When the person at the receiving end answers the call the display shows "Connected...".

The control unit will play the home message followed by each of the four alarm messages, and then repeat all five messages three more times. While the control unit is playing the messages the keypad display shows "Playing messages...".

The person receiving the messages call acknowledge (and end) the call by pressing "5" or "9" on their phone keypad.

If no-one acknowledges a test call the keypad display shows "No acknowledgement".

PSU Current

The Test menu allows you to check how much current the control unit is consuming. From the Installer menu select *Test – PSU Current*. The bottom line of the keypad display shows the current delivered by the PSU in the control unit.

Locate Bus Device

The Test menu allows you to list all the devices connected to the bus, and to find out where they are located by activating their sounder. From the Installer menu select *Test – Locate Bus Device*.

The control unit presents the first item in a list of all the devices connected to the bus. The keypad display shows the expander bus number, and any name that has been programmed for it.

Press ▲ or ▼ to scroll up or down the list.

Press ► to turn on the device's buzzer. (Press ◀ or ▶ to turn it off again.)

View Log

The control unit keeps a log of the last 1,000 events (for example, alarms and setting/unsetting). You can read the log when the system is completely unset.

Note: To comply with EN50131-1:2006 for Grade 2 systems the log is divided internally into two portions: mandatory events and non-mandatory events. The mandatory portion of the log can store up to 1,500 events, and the non-mandatory portion of the log can store up to 500 events. The entire log will store its records for at least 10 years without power.

When you view the log, the display initially shows users by their number (for example User01). Pressing ► displays any name programmed for the user.

There are some user numbers that have special meaning:

User 000 Installer (the word "Web" will appear in the log entry if the installer logged on using the web browser).

User 501 Quick Set User

User 502 Panel (Control Unit)

User 503 Keyswitch User

User 504 ARC Remote Reset

User 505 Downloader

User 506 Virtual keypad

About

The *About* option in the Installer Menu offers information on the version and status of the control unit.

If the control unit has a communications module fitted then the *About* option also provides information about the module, including IP addresses and port numbers for modules connected to the Internet.

Panel

This option the control unit model and its software revision.

Comms

The contents of this option depend on the plug-on communications module fitted to the control unit. When no module is present the Panel Ethernet option is the only one visible.

Panel Ethernet shows information about Internet Protocol (IP) settings used by the control unit itself. You will need this information when you set up an Ethernet connection from a PC to the control unit in order to use the built in web browser interface. To change the settings use the *Communications – IP Network (Own)* menu (see page 85).

IP Address	This is the IP address the control unit uses when linked by Ethernet to a PC.
Subnet Mask	This is the subnet mask currently in use by the control unit itself.
Gateway Address	This is the gateway address being used by the control unit.
MAC Address	This is the unique MAC address of the control unit pcb. Each control unit pcb will have an individual MAC address.
IP Link Status	This option shows the current status of the Ethernet link between a PC and the control unit. The display shows "Fail" when there is no link, and "OK" when the Ethernet link is established. Note that "OK" only shows that the link is established, it does not show that the PC is logged into the control unit.

Module: Shows the identity of the communications module currently fitted.

Zone Mapping

This option allows you to check which zones are currently allocated to detector connection points, or which detector connection points have zone numbers allocated. There are two options:

Zone Number

The display shows a list of zone numbers (with names), with detector connection points for each zone.

Zone address

The display shows a list of detector connection points, with zone numbers and names, where allocated.

Non-Programmable Functions

Alarm Abort

The i-on160EX contains a fixed Alarm Abort Delay period of 90 seconds. The control unit starts the Alarm Abort Delay timer whenever it starts an alarm. If a user silences the alarm within the Abort Delay period, the alarm will not require an engineer or remote reset.

If an alarm occurs and a user unsets the system **within** the Alarm Abort Delay period then the control unit activates any output of type Alarm Abort (page 46) and starts any Alarm Abort Fast Format communications programmed.

Remote Reset (RedCare Reset)

If the system is configured for installer reset only (you have programmed option *System Options – User Reset – Zone alarms* as "No" or *System Options - DD243 - Confirmation* is "On") then the control unit enables the Remote Reset input pin on the its plug by connector. After an alarm, the user can silence the sounders but must contact an Alarm Receiving Centre (ARC) to reset the system.

The ARC verifies the user's identity and (provided that the control unit is fitted with a suitable plug-by communicator) can send a +12v signal to the remote

reset input of the plug by pins. This allows the user to reset the system using their normal user access code.

If the ARC sends the 12v signal to enable the remote reset pin and reverts it back to 0v before the user resets the system, the panel will remember that the remote reset pin was enabled and will still allow the user to reset the system using their normal user access code.

Step By Step Programming Procedures

The detailed procedures shown in this section are here to help those who are not familiar with the Installer Menu. The procedures do not cover the whole of the Installer Menu. Cooper Security hope that after you have followed these detailed instructions then you will be familiar enough with the Installer Menu to carry out any other programming task.

Addressing Keypads and Expanders on the Bus

When commissioning an alarm system the Installer will have made the control unit give an address to all the devices connected to the bus at that time. If you need to make subsequent changes to the system then please read the following guidelines:

1. *When removing a device from the bus always delete the device from the Installer Menu first. This ensures that the deleted device has a default bus address, and that all the other system information for that device has been erased.*
2. *Always power down the system before connecting or disconnecting a device from the bus.*
3. *When adding a device to the bus make sure that it has a default bus address first.*

If you have a bus device taken from another system and you are not sure that its address has been defaulted correctly, then:

To Manually Default The Bus Address Of An Expander

1. Disconnect the device from the bus (if you have not already done so).
2. Open the lid (make sure that the tamper switch operates).
3. Hold down the "Request/Delete Address" button.
4. Apply 12Vdc power to the device (use the 0V and 12V terminals on the bus connector).

After a few seconds the device sounder gives the confirmation tone (two beeps) and the display shows "— -".

5. Release the "Request/Delete Address" button after you hear the confirmation beeps.

To Manually Default The Bus Address Of A Keypad

1. Open the keypad (make sure that the keypad tamper operates).

2. Apply 12Vdc power to the device (use the 0V and 12V terminals on the keypad connector).
3. Hold down keys D and ✕ at the same time. *See Note below.*

After a few seconds you should hear a confirmation tone and the navigation LEDs start flashing.

4. Release the D and ✕ keys.
5. Close the lid, making sure the tamper switch closes.

Note: DO NOT hold down D and ✕ to delete a keypad from a system while the keypad is still connected to the bus. Always delete keypads from a system first by using the Installer Menu, see page 102. If you have inadvertently erased a keypad's address by holding down D and ✕ then:

1. Make the control unit re-scan the bus by leaving the Installer Menu.
2. Press ✓ when the control unit displays "Accept all changes to bus?".
3. Add the keypad back to the system, as described below.

To Add An Expander Or Keypad To The Bus:

1. Make sure that the expander or keypad has the default bus address. (See page 99.)
2. Power down the system and connect the device to the bus.
3. Power up the system.
4. Enter Installer Menu.

5. Press ✓.

The display shows:

6. Press ▼ until the display shows

```

INSTALLER MENU
  Detectors/Devices >
DETECTORS/DEVICES
  Detectors >
DETECTORS/DEVICES
  Address Bus Device>

```

(The rest of these instructions assume you are adding a wired expander. The same instructions will also work for a radio expander or wired keypad.)

8. Press ✓.

The display shows a message telling you to press the address request buttons on the bus device.

```

Press addr button(s)
on bus devices

```

9. For Expanders:

Go to the expander. Remove the expander lid. Hold down the Request/Delete Address button

for at least three seconds.

After three seconds the expander gives a confirmation tone (two beeps) and its display shows the address allocated by the control unit, for example:

1— followed by 03

Note: DO NOT attempt to address two devices at the same time.

If you do not wish to accept this bus device number, hold down the Request/Delete Address button for at least three seconds again. The control unit will allocate the next free number, for example:

1— followed by 06

NOTE: If there are no more free bus addresses then the keypad display will display an error message. This may happen especially if you are trying to add an EXP-R30, and there are not three consecutive bus addresses available.

For Keypads:

Go to the keypad. Hold down keys A and ✓ for at least three seconds.

After three seconds the keypad gives a confirmation tone and its display shows the address allocated by the control unit, for example:

```
b1 d52
U02.0 26/07/10
```

Note: DO NOT attempt to address two keypads at the same time.

If you do not wish to accept this bus device number, hold down A and ✓ again and the control unit will allocate the next free number, for example:

```
b1 53
U02.0 26/07/10
```

At this point you can go to any other expander or keypad device that you wish to add to the bus and repeat step 9.

10. At the keypad you are using to program the system press ✕ when you have finished adding bus devices.

```
WIRED EXPANDER
Add Expander
```

(If you are adding a keypad the display will show:)

```
WIRED KEYPAD
Add keypad
```

11. Press **✕** until the keypad display shows:

```
Leave
installer mode?
```

12. Press **✓**.

```
Please wait...
```

After a short time (depending on the number of bus devices fitted to the system) the display shows:

```
i-on160EX
12:43 02/11/2010
```

The control unit has saved your changes, and left the Installer Menu.

To Delete A Keypad or Expander From The Bus:

1. Enter Installer Menu.

```
INSTALLER MENU
```

2. Press **✓**.

```
Detectors/Devices >
```

The display shows:

```
DETECTORS/DEVICES
```

3. Press **▼** until the display shows:

```
Detectors >
```

EITHER (if you are deleting a wired expander):

```
DETECTORS/DEVICES
```

```
Wired Expanders >
```

OR (if you are deleting a radio expander):

```
DETECTORS
```

```
Radio Expanders >
```

OR (if you are deleting a keypad):

```
DETECTORS/DEVICES
```

```
Wired Keypads
```

(The rest of these instructions assume you are deleting a wired expander. The instructions are similar but the displays are slightly different for a radio expander or a keypad.)

4. Press **✓**.

```
WIRED EXPANDERS
```

The display shows:

```
Address Bus Device >
```

5. Press **▼** until the display shows:

```
WIRED EXPANDERS
```

```
Delete Expander
```

6. Press **✓**.

The display shows the first in a list of the expanders that are currently connected to the bus.

```
DELETE EXPANDER
```

```
EXP. W1-02 (W10)>
```

7. Press **▲** or **▼** until the display shows the expander you wish to delete (in this example, expander W1-04):

```
DELETE EXPANDER
```

```
EXP. W1-04 (W10)>
```

8. Press ✓ .

The display asks you to confirm that you want to delete the selected device:

```
Delete Expander
Are you sure?
```

Notes: If you change your mind and do NOT wish to delete the device shown then press ✕.

9. Press ✓ .

The display shows a brief message to confirm the deletion:

```
W1-04 deleted!
```

...followed by the Delete Expander option.

The control unit deletes its record of the expander you selected in step 7, and also defaults the expander's own record of the bus address. If you wish to re-instate the expander you must add it as a new expander – see page 99).

```
WIRED EXPANDERS
Delete Expander >
```

10. Press ✕ until the display shows:

```
Leave
installer mode?
```

11. Press ✓.

The display shows:

```
Please wait...
```

After a short time (depending on the number of bus devices fitted to the system) the display shows the time and date:

```
i-on160EX
12:43 02/11/2010
```

12. Power down the system and disconnect the device from the bus.

13. Power up the system again.

Expanders

To Disable or Enable an Expander:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

The display shows:

```
DETECTORS/DEVICES
Detectors >
```

3. Press ▼ until the display shows:

EITHER (for a wired expander):

```
DETECTORS/DEVICES
Wired Expanders >
```

OR (for a radio expander):

```
DETECTORS
Radio Expanders >
```

(The rest of these instructions assume you are disabling a wired expander. The instructions are similar but the displays are slightly different for a radio expander.)

4. Press **✓** .

The display shows:

```
WIRED EXPANDERS
Address Bus Device >
```

5. Press **▼** until the display shows:

```
WIRED EXPANDERS
Enable Expander
```

6. Press **✓** .

The display shows the first in a list of the expanders that are currently connected to the bus.

```
ENABLE EXPANDER
Exp. W1-02      Yes
```

7. Press **▲** or **▼** until the display shows the expander you wish to enable or disable (in this example, expander W1-04):

```
ENABLE EXPANDER
Exp. W1-04      Yes
```

The right hand end of the bottom line shows the state of the expander: "Yes" for enable, "No" for disable.

8. Press **►** or **◄** until the end of the bottom line shows the state you want.

```
ENABLE EXPANDER
Exp. W1-04      No
```

This example shows the expander being disabled:

Notes:

*1. If you change your mind and do NOT wish to disable the device shown then press **►** or **◄** until the bottom line shows "Yes".*

9. Press **✓** .

The display shows the Enable Expander option.

```
WIRED EXPANDERS
Enable Expander >
```

The control unit disables the expander you selected in step 7. If you wish to enable the expander follow steps 6 to 8 again, but ensure that the bottom line of the display shows "Yes" for the selected expander.

10. Press **✕** until the display shows:

```
Leave
installer mode?
```

11. Press **✓** .

The display shows:

```
Please wait...
```

After a short time (depending on the number of bus devices fitted to the system) the display shows the time and date, for example:

```
i-on160EX
12:43 02/11/2010
```

The keypad navigation key LEDs will glow red

with an alert. When a user reads the alert it will show the address of the disabled expander.

To enable the expander again, repeat steps 1 to 11, but at step 8 press ► or ◀ until the end of the bottom line shows "Yes".

To Replace an Expander:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

The display shows:

```
DETECTORS/DEVICES
Detectors >
```

3. Press ▼ until the display shows:

EITHER (if you are replacing a wired expander):

```
DETECTORS/DEVICES
Wired Expanders >
```

OR (if you are replacing a radio expander):

```
DETECTORS/DEVICES
Radio Expanders >
```

(The rest of these instructions assume you are replacing a wired expander. The instructions are similar but the displays are slightly different for a radio expander.)

4. Press ✓.

The display shows:

```
WIRED EXPANDERS
Address Bus Device >
```

5. Press ▼ until the display shows:

```
WIRED EXPANDERS
Replace Expander
```

6. Press ✓.

The display shows the first in a list of the expanders that are currently connected to the bus.

```
REPLACE EXPANDER
Exp. W1-01 Remove
```

7. Press ▲ or ▼ until the display shows the expander you wish to replace (in this example, expander W1-04):

```
REPLACE EXPANDER
Exp. W1-04 Remove
```

8. Press ✓.

The display shows:

```
Exp. W1-04
Remove Expander?
```

Notes:

1. If you change your mind and do NOT wish to replace the expander then press ✕.

9. Press ✓.

The display shows for a few seconds:

```
W1-04 can be removed
```

Followed by:

The navigation keys on the keypad glow red.

```
REPLACE EXPANDER
Exp. W1-04      Add
```

- 10 a) Power down the system (both mains and battery).
- b) Remove the old expander.
- c) Connect the new expander.

Note: The new expander must be of the same type as the one you removed. Make sure that you replace an EXP-R30 with an EXP-R30.

d) Power up the system (connect the battery, close the control unit lid to ensure the tamper switch is closed, then apply mains power).

```
i-on160EX
12:43 02/11/2010
```

The keypad display shows:

The navigation key LEDs glow red to show that there is an alert for the disabled expander.

11. Re-enter Installer Men, and navigate back to *Detectors/Devices – Wired Expander – Replace Expander* (follow steps 1 to 6).

```
REPLACE EXPANDER
Exp. W1-04      Add
```

The display shows:

12. Press ✓ .

The display shows:

```
Press addr button(s)
on bus devices
```

13. Go to the expander. Remove the expander lid. Hold down the Request/Delete Address button for at least three seconds.

After three seconds the expander gives a confirmation tone (two beeps) and its display shows the address allocated by the control unit. In this example the address is 1-04; the control unit has allocated the address of the old expander.

```
1 – followed by 04
```

The keypad display shows for a few seconds:

```
W1-04 replaced
```

Followed by:

```
REPLACE EXPANDER
Exp. W1-04      Remove
```

14. Leave the Installer Menu.

The new expander now has the programming of the old expander.

Note: If you replace a wireless expander then you must teach the identity of the new wireless expander to any receivers or output modules that had previously learned the old wireless expander's identity. This includes any 762s, 768s or WAMs.

Naming Wired and Radio Expanders

1. Enter Installer Menu.

```
INSTALLER MENU
```

2. Press ✓.

```
Detectors/Devices >
```

3. Press ▼ until the display shows EITHER (if you are adding a wired expander):

```
DETECTORS/DEVICES
```

```
Detectors >
```

```
DETECTORS
```

```
Wired Expanders >
```

OR (if you are adding a radio expander):

```
DETECTORS
```

```
Radio Expanders >
```

4. Press ✓.

(The rest of these instructions assume you are naming a wired expander. The same instructions will also work for a radio expander.)

```
WIRED EXPANDERS
```

```
Address Bus Device >
```

5. Press ▼ until the display shows:

```
WIRED EXPANDERS
```

```
Edit Expander >
```

6. Press ✓.

```
EDIT EXPANDER
```

```
Exp. W1-03 (W10)>
```

7. Press ▲ or ▼ to select the expander that you wish to name. Then press ✓.

The bottom line of the display shows "Name".

```
Exp. W1-03
```

```
Name >
```

8. Press ✓.

The bottom line of the display shows the expander's current name. The cursor is on the first character on the left.

```
Exp. W1-03
```

```
Exp. W1-03
```

9. See page 12 for hints on how to edit names.

```
Exp. W1-03
```

```
Building 9
```

10. Press ✓ to save the text.

```
BUILDING 9
```

```
Name >
```

11. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Assigning Wired and Radio Expanders to Partitions

1. Enter Installer Menu.	INSTALLER MENU Detectors/Devices >
2. Press ✓.	DETECTORS/DEVICES Detectors >
3. Press ▼ until the display shows EITHER (if you are adding a wired expander):	DETECTORS/DEVICES Wired Expanders >
OR (if you are adding a radio expander):	DETECTORS/DEVICES Radio Expanders >
4. Press ✓ . (The rest of these instructions assume you are naming a wired expander. The same instructions will also work for a radio expander.)	WIRED EXPANDERS Address Bus Device >
5. Press ▼ until the display shows:	WIRED EXPANDERS Edit Expander >
6. Press ✓ .	EDIT EXPANDER Exp. W1-01 (W10)>
7. Press ▲ or ▼ to select the expander that you wish to name. Then press ✓. The bottom line of the display shows the option "Name".	Exp. W1-01 Name >
8. Press ▼ until the display shows:	Exp. W1-01 Partitions >
9. Press ✓ .	Exp. W1-03 Partition 01 Yes
10. To allocate an expander to a Partition press ► or ◀ until the end of the bottom line shows "Yes". To remove an expander from a Partition press ► or ◀ until the end of the bottom line shows "No". You can allocate and expander to more than one Partition. See page 52 for more information about partitions.	Exp. W1-03 Partition 1 No
To allocate (or remove) an expander to or from all Partitions in one go: Press ▲ or ▼ until the bottom line of the display shows "All Partitions". Press ► or ◀ until the end of the bottom line shows "Yes" or "No" as required.	Exp. W1-03 All Partitions No
11. Press ▼ to show other partitions.	Exp. W1-01

Press ► or ◀ to allocate or remove partitions as required.

Partition 2 Yes

12. Press ✓ to confirm your changes.

Exp. W1-01
Partitions >

13. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Changing the Wiring Type of Wired Expanders

1. Enter Installer Menu.

INSTALLER MENU
Detectors/Devices >

2. Press ✓.

DETECTORS/DEVICES
Detectors >

3. Press ▼ until the display shows:

DETECTORS
Wired Expanders >

4. Press ✓ .

WIRED EXPANDERS
Address Bus Device >

5. Press ▼ .

WIRED EXPANDERS
Edit Expander >

6. Press ✓ .

EDIT EXPANDER
Exp. W1-01 (W10)>

7. Press ▲ or ▼ to select the expander that you wish to edit. Then press ✓.

Exp. W1-01
Name >

The bottom line of the display shows "Name".

8. Press ▼ until the display shows:

Exp. W1-03
Wired zone type >

9. Press ✓ .

The bottom line of the display shows the current wiring type of the expander. A "*" at the beginning of the line acts as a reminder if you scroll away and back again See page 40 for an explanation of the wiring types.

Exp. W1-03
*4-wire CC

10. Press ▲ or ▼ to show the wiring type you wish to choose.

Exp. W1-03
2-wire FSL 2K2/4K7

11. Press ✓ .

The display asks you to confirm your choice:

Exp. W1-03
Are you sure?

12. Press ✓ to confirm your choice.

Exp. W1-03

(Press **X** if you wish to change your mind.)

```
Wired zone type >
```

13. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

Editing Zones

Learning radio detectors

Note: This example assumes that your radio expander device number is R1-03. The number may be different on the system you are working on. Make sure you use the correct expander device number.

1. Enter Installer Menu.

```
INSTALLER MENU  
Detectors/Devices >
```

2. Press **✓**.

```
DETECTORS/DEVICES  
Detectors >
```

3. Press **✓** .

```
DETECTORS  
Add/Del Detectors >
```

4. Press **✓** .

```
ADD/DEL DETECTORS  
Exp. R1-02 (R10)>
```

The bottom line of the display shows the first of the radio expanders.

5. Press **▲** or **▼** to show the expander you want and press **✓**.

```
ADD/DEL DETECTORS  
*Zone 020.
```

The bottom line of the display shows the first of the radio detector zones belonging to the selected expander.

The display shows an "*" next to zones where the control unit has already learned detectors.

6. Press **▲** or **▼** keys to show the zone you want and press **✓**.

```
ADD/DEL DETECTORS  
Zone 021
```

7. Press **✓** .

```
Activate  
detector tamper
```

The display instructs you to activate the radio detector tamper.

8. Open the radio detector and insert the battery.

```
Detector assigned to  
Zone 021 SS: 9
```

The act of inserting the battery causes the detector to send a tamper signal.

The display shows a message to confirm that you have learned the detector to the selected zone, together with the current signal strength of the transmitter.

The keypad also sounds a double "beep" when

the control unit successfully learns the detector.

9. **Either:** Press **X** to go back to the list of zones so that you can go on and learn other detectors.

```
ADD/DEL DETECTORS
*Zone 021
```

The control unit stores the identity of the radio detector, but sets the type to "Not Used".

OR: Press **✓** to carry on giving a name, type and attribute to the detector you have just learned (see page 33).

The control unit give the detector a zone type "Normal Alarm" and assigns it to Partition 1.

10. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

Deleting individual radio detectors

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press **✓**.

```
DETECTORS/DEVICES
Detectors >
```

3. Press **✓** .

```
DETECTORS
Add/Del Detectors >
```

4. Press **✓** .

```
ADD/DEL DETECTORS
Exp. R1-02 (R10)>
```

The bottom line of the display shows the first of the radio expanders.

5. Press **▲** or **▼** to show the expander you want and press **✓**.

```
ADD/DEL DETECTORS
*Zone 020 >
```

The bottom line of the display shows the first of the radio detector zones belonging to the selected expander.

The display shows an "*" next to zones where the control unit has already learned detectors.

6. Press ▲ or ▼ keys to show the zone you wish to delete.

```
ADD/DEL DETECTORS
*Zone 021      >
```

7. Press ✓.

The bottom line of the display shows the first of two options: deleting the detector ID or of defaulting the zone.

```
DELETE Zone 020
Delete Detector ID>
```

8. Press ▲ or ▼ to see each of these choices.

```
DELETE Zone 020
Default Zone    >
```

If you select "Delete Detector ID" then the control unit "forgets" the ID of the detector, but leaves any zone programming in place.

```
DELETE DETECTOR ID
Are you sure?
```

If you select "Default zone" then the control unit "forgets" the ID of the detector **and** sets all the zone programming back to default values: Type = Not Used, no attributes.

```
Delete detector and
clear all zone info?
```

Note: Either option acts as soon as you confirm it, and not when you leave Installer Mode.

9. Press ✓ to confirm your choice.

After a brief message confirming the action the control unit has taken the bottom line of the display shows the zone ready to learn in a new radio detector.

```
ADD/DEL DETECTORS
Zone 021      >
```

To reinstate the detector you must teach the control unit that detector's identity again (see page 110).

Deleting all radio detectors

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTORS/DEVICES
Detectors      >
```

3. Press ✓.

```
DETECTORS
Add/Del Detectors >
```

4. Press ✓.

The bottom line of the display shows the first of the radio expanders.

```
ADD/DEL DETECTORS
Exp. R1-02 (R10)>
```

5. Press ▲ until the bottom line of the display shows "Delete All".

```
ADD/DEL DETECTORS
Delete All      >
```

6. Press ✓.

The display shows a message asking you to confirm your choice. (Press ✕ if you want to change your mind.)

```
Delete ALL detectors
and zone data?
```

6. Press ✓.

The display shows a second message asking you to confirm your choice. (Press ✕ if you want to change your mind.)

```
Are you sure?
```

Note: The deletion will take place immediately, and not when you leave Installer Mode.

7. Press ✓ to confirm your choice.

After a short message confirming that the control unit has deleted all the radio detectors the display returns to the Delete All menu.

```
ADD/DEL DETECTORS
Delete All >
```

To reinstate the detectors you must teach the control unit each detector's identity again (see page 110).

Changing Zone Names, Type, Attributes and Partitions

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTORS/DEVICES
Detectors >
```

3. Press ✓ .

```
DETECTORS
Add/Del Detectors >
```

4. Press ▼ until the display shows:

```
DETECTORS
Program zones >
```

5. Press ✓ .

The bottom line of the display shows the first zone.

```
Z001 P0<00<00 NU
Zone 000 >
```

6. Press ▲ or ▼ to show the other zones.

```
Z002 P0<00<02 NU
Zone 002 >
```

(Hint: You can key in the zone number you wish to edit, for example:"012" for zone 12.)

The top line of the display shows the zone number, the detector connection point and the current zone type (NU = Not Used).

7. When you have found the zone you wish to edit press **✓**.

The bottom line of the display shows "Name".

8. Press **▲** or **▼** to see the Type, Attributes or Partition options for that zone. Press **✓** to select the option you wish to change.

Note: If a zone has the type "Not Used" then the Attributes and Partition options do not appear.

When changing the name, see page 12 for hints on how to edit names.

When changing zone types, you can allocate one type per zone. A "*" at the beginning of the bottom line shows the type currently allocated to the zone. See page 33 for a list of the available zone types.

```
Zone 041      NU
Name          >
```

```
ZONE 041 TYPE
* Panic Alarm
```

When changing zone attributes, you can select more than one attribute for a zone. Press **►** or **◄** until the end of the bottom line shows "Yes" to allocate an attribute. The number of zone attributes available depends on the zone's type. Some zone types (for example PA) do not allow any attributes. See page 36 for a list of attributes.

```
ZONE 041 ATTRIBUTES
Chime          Yes
```

When allocating zones to partitions you can select more than one Partition for each zone. Press **►** or **◄** until the end of the bottom line shows "Yes" to allocate a zone to a Partition. See page 51 for more information about partitions.

```
ZONE 041 PARTITIONS
Partition 1    Yes
```

If you want to allocate a zone to all partitions at once:

Press **▲** or **▼** until the bottom line shows "All Partitions".

Press **►** or **◄** until the end of the bottom line shows "Yes" to allocate the zone to all partitions or "No" to remove the zone from all partitions except partition 1.

```
ZONE 041 PARTITIONS
All Partitions Yes
```

Note: If you selected "Part set mode" during Initial Power-up then the display will not show the Partitions option (see System Options–Restore Defaults–Factory Defaults on page 67 if you want to change the system from Part Setting to Partitions).

9. Press ✓ to confirm your changes.
The bottom line of the display shows the zone you were editing, for example:
10. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```
Zone 041      NU
Name          >
```

Keypads

Naming a Wired Keypad

To name a wired keypad:

1. Enter Installer Menu.
2. Press ✓.
3. Press ▼ until the display shows:
4. Press ✓.
The bottom line of the display shows:
5. Press ▼ until the display shows:
6. Press ✓.
The bottom line of the display shows the first in a list of the available wired keypads.
5. Press ▲ or ▼ to select the keypad that you wish to name. Then press ✓.
The bottom line of the display shows:
6. Press ✓.
The bottom line of the display shows the keypad's current name. The cursor is on the first character on the left.
7. See page 12 for hints on how to edit names.
8. Press ✓ to save the completed name.
9. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```
INSTALLER MENU
Detectors/Devices >
```

```
DETECTOR DEVICES
Detectors        >
```

```
DETECTOR DEVICES
Wired Keypads    >
```

```
WIRED KEYPADS
Address Bus Device>
```

```
WIRED KEYPADS
Edit Keypad      >
```

```
EDIT WIRED KEYPADS
Keypad K1-51     >
```

```
Keypad K1-54
Name            >
```

```
Keypad K1-54
Keypad K1-54
```

```
Keypad K1-54
Bedroom K1-54
Bedroom
Name          >
```

Assigning a Wired keypad to Partitions

Note: If you selected "Part set mode" during Initial Power-up then you cannot assign a keypad to a partition (see System Options–Restore Defaults–Factory Defaults on page 67 if you want to change the system from Part Setting to Partitions).

1. Enter Installer Menu.
2. Press **✓**.
3. Press **▼** until the display shows:
4. Press **✓**.
The bottom line of the display shows:
5. Press **▼** until the display shows:
6. Press **✓**.
The bottom line of the display shows the first in a list of the available wired keypads.
7. Press **▲** or **▼** to select the keypad that you wish to assign. Then press **✓**.
The bottom line of the display shows:
8. Press **▼** until the display shows:
9. Press **✓**.
The bottom line of the display shows the first item in the list of partitions.
10. To allocate a keypad to a partition press **►** or **◄** until the end of the bottom line shows "Yes".
To remove a keypad from a partitions press **►** or **◄** until the end of the bottom line shows "No".
You can allocate a keypad to more than one Partition: press **▲** or **▼** to see the other partitions. See page 52 for more information about partitions.

If you want to allocate a keypad to all partitions at once:
Press **▲** or **▼** until the bottom line shows "All Partitions".
Press **►** or **◄** until the end of the bottom line shows "Yes" to allocate the keypad to all partitions or "No" to remove the keypad from all

```
INSTALLER MENU
Detectors/Devices >
```

```
DETECTOR DEVICES
Detectors >
```

```
DETECTOR DEVICES
Wired Keypads >
```

```
WIRED KEYPADS
Address Bus Device>
```

```
WIRED KEYPADS
Edit Keypad >
```

```
EDIT WIRED KEYPADS
Keypad K1-51 >
```

```
Keypad K1-53
Name >
```

```
Keypad K1-53
Partitions >
```

```
Keypad K1-53
Partition 01 Yes
```

```
Keypad K1-53
Partition 01 No
```

```
Keypad K1-53
All Partitions Yes
```

partitions except partition 1.

11. Press ✓ to confirm your changes.
12. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```
Keypad K1-53
Partitions      >
```

Adding a Radio Keypad

To make the control unit learn a Radio Keypad's identity.

1. Enter Installer Menu.
2. Press ✓.
3. Press ▼ until the display shows:
4. Press ✓.
5. Press ✓.
The bottom line of the display shows the first of the available radio expanders.
6. Press ▲ or ▼ to select the expander that you wish allocate the radio keypad to.

```
INSTALLER MENU
Detectors/Devices >
DETECTOR DEVICES
Detectors        >
DETECTOR DEVICES
Radio Keypads    >
RADIO KEYPADS
Add/Del Radio Kpd >
ADD/DEL RADIO KPD
Exp. R1-02      (R30)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

7. Press ✓.
The bottom line of the display shows the first of the device addresses used for radio keypads on the expander. (See page 18 for an explanation of radio keypad numbering.) If a radio keypad is already learned into the system at this address then the bottom line of the display shows a "*" on the left and displays the radio keypad's name.
8. Press ▲ or ▼ to select the device address that you wish use.
9. Press ✓.
The bottom line of the display instructs you to operate the keypad tamper.

```
ADD/DEL RADIO KPD
Exp. R1-05      (R10)>
```

```
ADD/DEL RADIO KPD
RKP R1-05-01    >
```

```
ADD/DEL RADIO KPD
RKP R1-05-02    >
Activate Radio
Keypad Tamper
```

10. Fit suitable batteries to the radio keypad.

When you fit the final battery the radio keypad transmits its identity to the control unit. When the control unit learns the identity it displays the radio keypad's signal strength.

```
ADD/DEL RADIO KPD
Keypad added SS: 9
```

11. Press ✓.

The bottom line of the display shows the keypad's default name. The "*" at the left of the display shows that the control unit has learned the radio keypad's identity.

```
ADD/DEL RADIO KPD
*Radio Kpd 01 >
```

12. Carry on with any other programming you need to do.

Deleting a Radio Keypad

To remove a Radio Keypad from the system:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTOR DEVICES
Detectors >
```

3. Press ▼ until the display shows:

```
DETECTOR DEVICES
Radio Keypads >
```

4. Press ✓.

```
RADIO KEYPADS
Add/Del Radio Kpd >
```

5. Press ✓.

The bottom line of the display shows the first of the available radio expanders.

```
ADD/DEL RADIO KPD
Exp. R1-02 (R30) >
```

6. Press ▲ or ▼ to select the expander that the radio keypad is allocated to.

```
ADD/DEL RADIO KPD
Exp. R1-05 (R10) >
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

7. Press ✓.

The bottom line of the display shows the first of the device addresses used for radio keypads on that expander. (See page 18 for an explanation of radio keypad numbering.) If a radio keypad is already learned into the system at that address then the bottom line of the display shows a "*" on the left and displays the radio keypad's name.

```
ADD/DEL RADIO KPD
*Radio Kpd 01 >
```

8. Press ▲ or ▼ to select the keypad that you wish delete.

```
ADD/DEL RADIO KPD
*Radio Kpd 02 >
```

9. Press ✓.

The bottom line of the display asks if you want to delete the selected radio keypad.

```
ADD/DEL RADIO KPD
Delete Radio Keypad?
```

10. Press ✓.

The bottom line of the display asks you to confirm that you want to delete the selected radio keypad.

```
ADD/DEL RADIO KPD
Are you sure?
```

11. Press ✓.

The bottom line of the display shows:

The control unit has deleted the radio keypad.

```
ADD/DEL RADIO KPD
RKP R1-05-02
```

12. Carry on with any other programming you need to do.

Naming a Radio Keypad

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTOR DEVICES
Detectors >
```

3. Press ▼ until the display shows:

```
DETECTOR DEVICES
Radio Keypads >
```

4. Press ✓.

```
RADIO KEYPADS
Add/Del Radio Kpd >
```

5. Press ▼.

```
RADIO KEYPADS
Edit Keypads >
```

6. Press ✓.

The bottom line of the display shows the first in a list of the radio keypads that have been learned by the control unit.

```
RKP01 R1-02-01
Radio Kpd 01 >
```

7. Press ▲ or ▼ to select the keypad that you wish to name.

```
RKP01 R1-03-02
Radio Kpd 02 >
```

8. Press ✓.

The bottom line of the display shows "Name".

```
Radio Kpd 02
Name >
```

9. Press ✓.

The bottom line of the display shows the keypad's current name. The cursor is on the first character on the left.

```
Radio Kpd 02
Radio Kpd 02
```

10. See page 12 for hints on how to edit names.

```
Radio Kpd 02
Bedroom
```

11. Press ✓ to save the text.
12. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

```
Bedroom
Name >
```

Assigning a Radio Keypad to Partitions

The i-on160EX allows you to assign radio keypads to one or more of the partitions.

Note: If you selected "Part set mode" during Initial Power-up then you cannot assign a radio keypad to a partition (see System Options–Restore Defaults–Factory Defaults on page 67 if you want to change the system from Part Setting to Partitions).

1. Enter Installer Menu.
2. Press ✓.
3. Press ▼ until the display shows:
4. Press ✓.
5. Press ▼.
6. Press ✓.
The bottom line of the display shows the first in a list of the radio keypads that have been learned by the control unit.
7. Press ▲ or ▼ to select the keypad that you wish to name.
8. Press ✓.
The bottom line of the display shows "Name".
9. Press ▼.
The bottom line of the display shows :
10. Press ✓.
11. To allocate a radio keypad to a partition press ► or ◀ until the end of the bottom line shows "Yes". To remove a radio keypad from a partition press ► or ◀ until the end of the bottom line shows "No". You can allocate a keypad to more

```
INSTALLER MENU
Detectors/Devices >
DETECTOR DEVICES
Detectors >
DETECTOR DEVICES
Radio Keypads >
RADIO KEYPADS
Add/Del Radio Kpd >
RADIO KEYPADS
Edit Keypads >
RKP01 R1-01-01
Radio Kp 01 >
```

```
EDIT RADIO KEYPADS
Radio Kpd 02 >
Radio Kpd 02
Name >
Radio Kpd 02
Partitions >
Radio Kpd 02
Partition 1 Yes
Radio Kpd 02
Partition 1 No
```

than one Partition. Press ▲ or ▼ to see the other partitions. See page 52 for more information about partitions.

If you want to allocate a keypad to all partitions at once:

Press ▲ or ▼ until the bottom line shows "All Partitions".

Press ► or ◀ until the end of the bottom line shows:

Either "Yes" to allocate the keypad to all partitions

Or "No" to remove the keypad from all partitions except partition 1.

```
Radio Kpd 02
All Partitions Yes
```

12. Press ✓ to confirm your changes.

```
Radio Kpd 02
Partitions >
```

13. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Naming and Programming Quick Set Keys

Note: This procedure applies equally to wired keypads or radio keypads. The examples shown are for wired keypads.

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTOR/DEVICES
Detectors >
```

3. EITHER:

Press ▼ until the display shows:

```
DETECTOR DEVICES
Wired Keypads >
```

4. Press ✓.

The display shows:

```
WIRED KEYPADS
Address Bus Device>
```

5. Press ▼ until the display shows:

```
WIRED KEYPADS
Edit Keypad >
```

6. Press ✓.

The bottom line of the display shows the first in a list of available wired keypads:

```
EDIT WIRED KEYPADS
Keypad K1-51 >
```

7. Press ▲ or ▼ to select the keypad that you wish to program. Then press ✓.

```
Keypad K1-51
Name >
```

8. Press ▼ until the bottom line of the display shows the key you wish to edit, for example:

```
Keypad K1-51
Key A >
```

9. Press ✓.

The display shows the Name option. (If you do not want to name the key go to step 13.)

```
Keypad K1-51 Key A
Name >
```

10. To name the key press ✓.

The bottom line of the display shows the key's current name. The cursor is on the first character on the left.

```
Keypad K1-51 Key A
Key A
```

11. See page 12 for hints on how to edit names.

```
Keypad K1-51 Key A
Front doo
```

12. Press ✓ to save the text.

```
Keypad K1-51 Key A
Name >
```

This example shows how to program keys to set partitions. The same instructions can be adapted to program keys to unset partitions.

13. Press ▼ until the bottom line of the display shows :

```
Keypad K1-51 Key A
Setting >
```

14. Press ✓.

The bottom line of the display shows the key's current use. "Not Used" means that the key does nothing. "Set" means that the key sets some combination of partitions, or a part set.

```
Keypad K1-51 Key A
*Not Used
```

15. Press ▼ until the bottom of the line shows "Set" and then press ✓.

The bottom line of the display shows the first item in a list of the partitions. The right hand end of the bottom line shows the setting state that you want the key to produce for that partition.

```
SET PARTITION
Partition 1 Full
```

16. Press ◀ or ▶ change the setting state. The options are: Full Set, Part Set, or None (no action).

```
SET PARTITION
Partition 1 Part
```

17. Press ▼ to show other partitions. Press ◀ or ▶ change the setting state as required, for example:

```
SET PARTITION
Partition 2 Full
```

18. Press ✓ to stop changing Key A's setting functions.

```
Keypad K1-51 Key A
Setting >
```

19. Press ✕ to stop editing Key A.

```
Keypad K1-51
Key A >
```


20. Repeat steps 8 to 19 for any other keys you wish to edit.
21. Press **✕** to stop editing the keypad.
22. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```
EDIT WIRED KEYPADS
```

```
Keypad K1-51      >
```

Sirens

Adding a Radio Siren

(Please read the installation guide for the radio siren.) To make the control unit learn the ID of a radio siren:

1. Enter Installer Menu.
 2. Press **✓**.
 3. Press **▼** until the bottom line of the display shows:
 4. Press **✓** .
 5. Press **✓**.
- The bottom line of the display shows the first of the available radio expanders.

```
INSTALLER MENU
```

```
Detectors/Devices >
```

```
DETECTORS/DEVICES
```

```
Detectors      >
```

```
DETECTORS/DEVICES
```

```
External Sirens >
```

```
EXTERNAL SIRENS
```

```
Add/Del Ext Siren >
```

```
ADD/DEL EXT SIREN
```

```
Exp. R1-02  (R30)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

6. If required press **▲** or **▼** to select the expander that you wish allocate the external siren to, for example:
7. Press **✓**.

```
ADD/DEL EXT SIREN
```

```
Exp. R1-05  (R10)>
```

```
ADD/DEL EXT SIREN
```

```
*Siren 01      >
```

The bottom line of the display shows the first of the device addresses used for radio sirens on that expander. (See page 18 for an explanation of radio siren numbering.) If a radio siren is already learned into that address then the bottom line of the display shows a "*" on the left, and the name of the siren.

8. Press ▲ or ▼ keys to show the device address that you want to use for the radio siren, for example:

```
ADD/DEL EXT SIREN
Siren R1-05-02 >
```

9. Press ✓.

```
Activate External
Siren Tamper
```

10. Insert the batteries in the external siren.

The display shows a message to confirm that the system has learned the radio siren, together with the current signal strength of the siren.

```
ADD/DEL EXT SIREN
Siren added SS: 9
```

The keypad also sounds a double "beep" when the control unit successfully learns the siren.

11. Press ✓ to go back to the list of sirens so that you can go on and learn other sirens. The bottom line of the display shows the default name of the external siren the control unit has just learned.
12. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

```
ADD/DEL EXT SIREN
*Siren 02 >
```

Allocating Sirens To Partitions

Note:

1. *This menu does not appear if you are using a Part Setting system. To change to a Partitioned system see System Options – Restore Defaults – Factory Defaults on page 67 .*
2. *By default all sirens are assigned to all partitions.*

To allocate a siren to a partition:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ✓.

```
DETECTORS/DEVICES
Detectors
```

3. Press ▼ until the bottom line of the display shows:

```
DETECTORS/DEVICES
External Sirens >
```

4. Press ✓ .

```
EXTERNAL SIRENS
Add/Del Ext Siren >
```

5. Press ▼ .

```
EXTERNAL SIRENS
Edit Ext Siren >
```

6. Press ✓ .

The bottom line of the display shows the first in a list of the radio sirens that have been learned

```
SRN01 R1-01-01
Siren 01 >
```

by the system

- 7. Press ▲ or ▼ keys to show the siren you want.
- 8. Press ✓.
- 9. Press ▼.
- 10. Press ✓.
- 11. To allocate a radio siren to a partition press ► or ◀ until the end of the bottom line shows "Yes". To remove a radio siren from a partition press ► or ◀ until the end of the bottom line shows "No". You can allocate the radio siren to more than one partition. Press ▲ or ▼ to see the other partitions. See page 52 for more information about partitions.

SRN02 R1-01-02	
Siren 02	>
Siren 02	
Name	>
Siren 02	
Partitions	>
Siren 02	
Partition 1	Yes
Siren 02	
Partition 1	No

Note: By default all sirens are assigned to all partitions.

If you want to allocate a radio sirens to all partitions at once:

Press ▲ or ▼ until the bottom line shows "All Partitions".

Press ► or ◀ until the end of the bottom line shows:

Either "Yes" to allocate the keypad to all partitions

Or "No" to remove the keypad from all partitions except partition 1.

Siren 02	
All partitions	Yes

- 12. Press ▼ to show other partitions.
Press ► or ◀ to allocate or remove partitions as required.

Siren 02	
Partition 2	No

- 13. Press ✓ to confirm your changes.

Siren 02	
Partitions	>

- 14. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Deleting a Radio Siren

To remove a radio siren from the system:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press **✓**.

```
DETECTORS/DEVICES
Detectors
```

3. Press **▼** until the bottom line of the display shows:

```
DETECTORS/DEVICES
External Sirens >
```

4. Press **✓**.

```
EXTERNAL SIRENS
Add/Del Ext Siren >
```

5. Press **✓**.

The bottom line of the display shows the first of the available radio expanders.

```
ADD/DEL EXT SIREN
Exp. R1-02 (R30) >
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

6. If required press **▲** or **▼** to select the expander that you wish allocate the radio keypad to.

```
ADD/DEL EXT SIREN
Exp. R1-05 (R10) >
```

7. Press **✓**.

The bottom line of the display shows the first in a list of device addresses used by radio sirens on that expander. If a radio siren has already been learned by the system then the bottom line of the display shows a "*" at the beginning of the line, and the siren name.

```
ADD/DEL EXT SIREN
Siren R1-05-01 >
```

8. Press **▲** or **▼** keys to show the siren you want to delete.

```
ADD/DEL EXT SIREN
*Siren 01 >
```

9. Press **✓**.

The display asks if you wish to delete this radio siren. (Press **✗** if you wish to leave the siren in place.)

```
ADD/DEL EXT SIREN
Delete Ext Siren?
```

10. Press **✓**.

The display asks you to confirm that you wish to delete this radio siren. (Press **✗** if you wish to leave the siren in place.)

```
ADD/DEL EXT SIREN
Are you sure?
```

11. Press **✓**.

The keypad also sounds a double "beep" when the control unit successfully deletes the siren. The display no longer shows "*" at the beginning of the bottom line, indicating that there is no siren learned at the displayed device address.

```
ADD/DEL EXT SIREN
Siren R1-05-02 >
```

WAMs

Please read the installation manual for the WAM. You must make sure that the WAM is programmed as Mode 1 BEFORE adding it to the system. The WAM must be powered up in order to make the control unit learn its identity.

Adding a WAM

To teach the control unit the WAM's identity:

1. Enter Installer Menu.

```
INSTALLER MENU
  Detectors/Devices >
```

2. Press ✓.

```
DETECTORS/DEVICES
  Detectors >
```

3. Press ▼ until the display shows:

```
DETECTORS/DEVICES
  WAMs >
```

4. Press ✓.

```
WAMS
  Add/Del WAM >
```

5. Press ✓.

```
ADD/DEL WAM
  Exp. R1-02 (R30)>
```

The bottom line of the display shows the first of the available radio expanders.

6. Press ▲ or ▼ to select the expander that you wish allocate the WAM to.

```
ADD/DEL WAM
  Exp. R1-05 (R10)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

7. Press ✓.

```
ADD/DEL WAM
  WAM R1-05-01 >
```

The display shows the first in a list of the available WAM device addresses on the selected expander. When a device address is occupied with a WAM then the bottom line shows a "*" at the beginning and the WAM name.

8. Press ▲ or ▼ to see other available WAM device addresses:

```
ADD/DEL WAM
  WAM R1-05-02 >
```

9. Press ✓ when the display shows the WAM device address you wish to use.

```
ADD/DEL WAM
  Activate WAM Tamper
```

10. Operate the WAM's tamper.

The WAM signals its identity to the i-on160EX control unit. When the control unit learns the WAM's identity the keypad gives a double beep.

```
ADD/DEL WAM
  WAM added SS: 9
```

11. Press ✓

The display shows that the control unit has learned the WAM's identity and given it a default

```
ADD/DEL WAM
  *WAM 01 >
```

name (WAM 01).

12. Don't forget to restore the tamper on the WAM you have just learned.

Naming a WAM

To give a WAM a meaningful name:

1. Enter Installer Menu.
2. Press ✓.
3. Press ▼ until the display shows:
4. Press ✓.
5. Press ▼ until the display shows:
6. Press ✓ .
The display shows the first in a list of the WAMs that the panel has learned:
7. Press ▲ or ▼ until the bottom line of the display shows the WAM that you wish to name:
8. Press ✓.
The bottom line of the display shows, for example:
9. Press ✓.
The bottom line of the display shows the WAM's current name. The cursor is on the first character on the left.
10. See page 12 for hints on how to edit names.
In the example, the WAM is being named for its location:
11. Press ✓ to save the text.
12. Press ✕
The display shows that the control unit is now ready to select another WAM.
13. Carry on with any other programming you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

```
INSTALLER MENU
  Detectors/Devices >
DETECTORS/DEVICES
  Detectors >
DETECTORS/DEVICES
  WAMs >
WAMS
  Add/Del WAM >
WAMS
  Edit WAM >
WAM01 R1-05-01
  WAM 01 >
WAM02 R1-05-02
  *WAM 02 >
WAM 02
  Name >
WAM 02
WAM 02
WAM 02
STAIRS_
STAIRS
  Name >
WAM02 R1-05-02
  STAIRS >
```

Deleting a WAM

To remove a WAM from service in the system:

1. Enter Installer Menu.

```
INSTALLER MENU
  Detectors/Devices >
```

2. Press **✓**.

```
DETECTORS/DEVICES
  Detectors >
```

3. Press **▼** until the display shows:

```
DETECTORS/DEVICES
  WAMs >
```

4. Press **✓**.

```
WAMs
  Add/Del WAM >
```

5. Press **✓**.

```
ADD/DEL WAM
  Exp. R1-02 (R30) >
```

The bottom line of the display shows the first of the available radio expanders.

6. Press **▲** or **▼** to select the radio expander allocated to the WAM you wish to delete.

```
ADD/DEL WAM
  Exp. R1-05 (R10) >
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

7. Press **✓**.

```
ADD/DEL WAM
  WAM R1-05-01 >
```

The display shows the first in a list of the available WAM device addresses on the selected expander.

8. Press **▲** or **▼** until you see the WAM you wish to remove:

```
ADD/DEL WAM
  *WAM 02 >
```

9. Press **✓**.

The bottom line of the display asks if you wish to delete the selected WAM.

```
ADD/DEL WAM
  Delete WAM?
```

10. Press **✓**.

The bottom line of the display asks you to confirm that you wish to delete the WAM.

```
ADD/DEL WAM
  Are you sure?
```

11. Press **✓**.

The control unit removes the identity of the WAM from that WAM device address (note that the "*" has gone from the beginning of the bottom line).

```
ADD/DEL WAM
  WAM R1-05-02 >
```

The display shows that the control unit is now ready to select another WAM.

Outputs

Adding Radio Outputs

To teach the control unit's identity to a 762r, 768r or 769r:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ▼ until the display shows:

```
INSTALLER MENU
Outputs >
```

3. Press ✓.

```
OUTPUTS
Radio Outputs >
```

4. Press ✓ .

```
RADIO OUTPUTS
Add Outputs >
```

5. Press ✓.

The bottom line of the display shows the first of the available radio expanders, for example:

```
ADD OUTPUTS
Exp. R1-02 (R30)>
```

6. Press ▲ or ▼ to select the expander that you wish allocate the radio keypad to.

```
ADD OUTPUTS
Exp. R1-05 (R10)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

7. Press ✓.

The top line of the display shows the first in a list of unused radio outputs, for example:

```
ADD OUTPUT R1>05>01
Not Used >
```

8. Press ▲ or ▼ until the display shows the output you wish to add, for example:

```
ADD OUTPUT R1>05>03
Not Used >
```

Note that if the bottom line of the display shows an output name this indicates that the output has been previously taught to a receiver.

9. Press ✓.

```
Is receiver in learn
mode?
```

10. Make sure that the receiver is in learn mode (see Appendix IV).

11. Press ✓.

The control unit transmits its identity to the receiver. When the receiver has successfully learned the identity of the control unit it beeps twice.

```
Did receiver beep
twice?
```

12. Press ✓.

The display shows the menu option that allows you to name the radio output.

```
EDIT O/P R1>05>03
Name >
```


13. EITHER:

Press ✓ to carry on and program the output name (see step 10 on page 132)

OR:

Press ✕ to carry on with other programming.

DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Giving a Radio Output a Type:

Note: Some output types can be assigned to zones or partitions. If you select those types then the keypad display will show a further menu allowing you to select the appropriate zones or partitions.

To give a radio output a type:

1. Enter Installer Menu.
2. Press ▼ until the display shows:
3. Press ✓.
4. Press ✓.
5. Press ▼ until the display shows:
6. Press ✓.

```
INSTALLER MENU
Detectors/Devices  >
INSTALLER MENU
Outputs            >
OUTPUTS
Radio Outputs      >
RADIO OUTPUTS
Add Outputs        >
RADIO OUTPUTS
Edit Outputs       >
EDIT OUTPUTS
Exp. R1-02        (R30)>
```

7. Press ▲ or ▼ to select the expander that you wish allocate the radio keypad to.

```
EDIT OUTPUTS
Exp. R1-05        (R10)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

8. Press ✓.

The display shows the first in a list of the radio outputs for the selected expander. The bottom line of the display shows the current name of the output.

```
EDIT O/P R1>05>01
O/P R1>05>01
```

9. Press ▲ or ▼ until the display shows the output you wish to edit, for example:

```
EDIT O/P R1>05>03
O/P R1>05>03 >
```

10. Press ✓.

If the bottom line of the display shows "Not Used" then the output does not currently have a type assigned to it. Go to step 11.

```
EDIT O/P R1>05>03
Not Used >
```

If the bottom line of the the display shows "Name" then the output already has a type assigned to it. Press ▼ until the bottom line shows "Type". Go to step 12.

11. Press ✓.

```
EDIT O/P R1>05>03
Type >
```

12. Press ✓.

The bottom line of the display shows the output's current type. A "*" at the beginning of the line is there to remind you of the current type if you scroll down the type list. .

```
O/P R1>05>03 TYPE
*Not Used
```

13. Press ▲ or ▼ to scroll through the type list.

You can select any of the types listed on page 45 onwards.

```
O/P R1>05>03 TYPE
Open/Close
```

You can select an output type quickly by keying the number shown in brackets after the type's name, for example:"04" to select Open/Close, "02" to select Panic Alarm, "19" to select General Fault. The number does not appear on the keypad display.

14. Press ✓ to confirm the change in type.

```
EDIT O/P R1>05>03
Type >
```

15. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Naming a Radio Output

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ▼ until the display shows:

```
INSTALLER MENU
Outputs >
```

3. Press ✓.

```
OUTPUTS
Radio Outputs >
```

4. Press ✓.

```
RADIO OUTPUTS
Add Outputs >
```

5. Press ▼ until the display shows:

```
RADIO OUTPUTS
Edit Outputs >
```

6. Press ✓.

The bottom line of the display shows the first of the available radio expanders.

```
EDIT OUTPUTS
Exp. R1-02 (R30)>
```

7. Press ▲ or ▼ to select the expander that you wish allocate the radio keypad to.

```
EDIT OUTPUTS
Exp. R1-05 (R10)>
```

Note: This example assumes that your radio expanders are bus devices 02 and 05. The numbers may be different on the system you are working on.

8. Press ✓.

The display shows the first in a list of the radio outputs for the select expander. The bottom line of the display shows the current name of the output.

```
EDIT O/P R1>05>01
O/P R1>05>01
```

9. Press ▲ or ▼ until the display shows the output you wish to edit, for example:

```
EDIT O/P R1>05>03
O/P R1>05>03 >
```

10. Press ✓.

Note: If the output has the type "Not Used" you will not be able to change its name. Go to page 131 to change the type of the output.

```
EDIT O/P R1>05>03
Name >
```

11. Press ✓.

The bottom line of the display shows the output's current name. The cursor is on the first character on the left.

```
EDIT O/P R1>05>03
O/P R1>05>03
```

12. See page 12 for hints on how to edit names.

```
EDIT O/P R1>05>03
Porch light
```

13. Press ✓ to save the text.

```
EDIT O/P R1>05>03
Name >
```

14. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Giving a Wired Output a Type:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ▼ until the display shows:

```
INSTALLER MENU
Outputs >
```

3. Press ✓.

```
OUTPUTS
```

4. Press ▼.

```
Radio Outputs >
OUTPUTS
Wired Outputs >
EDIT OUTPUTS
Panel >
```

5. Press ✓.

The display shows the first group of wired outputs available for editing: those on the panel.

6. If required, press ▲ or ▼ until the display shows the expander whose outputs you wish to edit.

```
EDIT OUTPUTS
Exp. W1-01 (W10)>
```

7. Press ✓.

The top line of the display shows the first in a list of the wired outputs on the expander, for example:

```
EDIT O/P W1>01>01
Not Used >
```

8. Press ▲ or ▼ until the display shows the output you wish to edit, for example:

```
EDIT O/P W1>01>03
O/P W1>01>03 >
EDIT O/P W1>01>03
Not Used >
```

9. Press ✓.

If the bottom line of the display shows "Not Used" then the output does not currently have a type assigned to it. Go to step 10.

If the bottom line of the display shows "Name" then the output already has a type assigned to it. Press ▼ until the bottom line shows "Type". Go to step 11.

10. Press ✓.

```
EDIT O/P W1>01>03
Type >
```

11. Press ✓.

The bottom line of the display shows the output's current type. A "*" at the beginning of the line is there to remind you of the current type if you scroll down the type list. .

```
O/P W1>01>03 TYPE
*Not Used
```

12. Press ▲ or ▼ to scroll through the type list.

You can select any of the types listed on page 45 onwards.

```
O/P W1>01>03 TYPE
Strobe
```

13. Press ✓ to confirm the change in type.

```
EDIT O/P W1>01>03
Type >
```

14. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

Note: Partitioned Systems

If you are programming a partitioned system then at this point, for some output types, the top line of the display shows "Partition?". The bottom line of the display shows "Partition 1 Yes". This means that the system is asking if you want to allocate the output to Partition 1.

You can remove the output from Partition 1 by pressing ◀ or ▶ to change the "Yes" to a "No".

Press ▲ or ▼ to scroll to other Partitions. Press ◀ or ▶ to assign the output to each Partition as required.

Press ✓ when you have finished assigning outputs to Partitions.

Naming a Wired Output

- 1. Enter Installer Menu.
- 2. Press ▼ until the display shows:
- 3. Press ✓.
- 4. Press ▼.
- 5. Press ✓.

```
INSTALLER MENU
Detectors/Devices  >
INSTALLER MENU
Outputs           >
OUTPUTS
Radio Outputs     >
OUTPUTS
Wired Outputs     >
EDIT OUTPUTS
Panel             >
```

- The display shows the first group of wired outputs available for editing: those on the panel.
- 6. If required, press ▲ or ▼ until the display shows the expander whose outputs you wish to edit.
 - 7. Press ✓.
 - The top line of the display shows the first in a list of the wired outputs for the group you selected in step 6. For example, if you selected an expander:
 - 8. Press ▲ or ▼ until the display shows the output you wish to edit, for example:
 - 9. Press ✓.

```
EDIT OUTPUTS
Exp. W1-01      (W10)>
EDIT O/P W1>01>01
Not Used       >
EDIT O/P W1>01>03
O/P W1>01>03   >
```

Note: If the output has the type "Not Used" you will not be able to change its name. Go to page 133 to change the type of the output.

```
EDIT O/P W1>01>03
Name           >
```

- 10. Press ✓.
- The bottom line of the display shows the output's current name. The cursor is on the first character on the left.

```
EDIT O/P W1>01>03
O/P W1>01>03
```

11. See page 12 for hints on how to edit names.
12. Press ✓ to save the text.
13. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

```
EDIT O/P W1>01>03
Porch light
EDIT O/P W1>01>03
Name >
```

Changing the Polarity of a Wired Output:

1. Enter Installer Menu.
2. Press ▼ until the display shows:
3. Press ✓.
4. Press ▼.
5. Press ✓.
The display shows the first group of wired outputs available for editing: those on the panel.
6. If required, press ▲ or ▼ until the display shows the expander whose outputs you wish to edit, for example:
7. Press ✓.
The display shows the first in a list of the wired outputs belonging to the group you selected in step 6, for example:
8. Press ▲ or ▼ until the display shows the output you wish to edit, for example:
9. Press ✓.
Note: If the output has the type "Not Used" you will not be able to change its polarity. Go to page 133 to change the type of the output.
10. Press ▼ until the display shows:
11. Press ✓.
The bottom line of the display shows the output's current polarity. A "*" at the beginning of the line is there to remind you of the current

```
INSTALLER MENU
Detectors/Devices >
INSTALLER MENU
Outputs >
OUTPUTS
Radio Outputs >
OUTPUTS
Wired Outputs >
EDIT OUTPUTS
Panel >
```

```
EDIT OUTPUTS
Exp. W1-01 (W10)>
```

```
EDIT O/P W1>01>01
O/P W1>01>01 >
```

```
EDIT O/P W1>01>03
O/P W1>01>03 >
EDIT O/P W1>01>03
Name >
```

```
EDIT O/P W1>01>03
Polarity >
O/P W1>01>03 POLAR.
*Normal
```

polarity if you scroll down the list. See page 45 for more information on output polarity.

- 12. Press ▲ or ▼ to change the polarity.
- 13. Press ✓ to confirm the change in polarity.
- 14. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

```
O/P W1>01>03 POLAR.  
Inverted  
EDIT O/P W1>01>03  
Polarity >
```

Calendar Set

The procedures shown for calendar setting refer to a partitioned system. If you are programming a part setting system look for the comments in brackets that show where the menus differ.

When programming calendar sets from the keypad it is better to add exceptions before adding events (since events refer to exceptions).

To add an exception:

- 1. Enter Installer Menu.
- 2. Press ▼ until the display shows:
(For a part set system the bottom line of the display shows "Setting Options".)
- 3. Press ✓.
(For a part set system the display shows "Setting Options Full Set".)
- 4. Press ▲ until the display shows:
(For a part set system the top line of the display shows "Setting Options".)
- 5. Press ✓.
- 6. Press ▼ until the display shows:
- 7. Press ✓.
The bottom line of the display shows the default name for the new exception, for example:
- 8. Key in a name to remind you of the exception, for example:
(See page 12 for hints on editing text.)

```
INSTALLER MENU  
Detectors/Devices >  
INSTALLER MENU  
Partitions >  
PARTITIONS  
Partition 1 >  
PARTITIONS  
Calendar Set >  
CALENDAR SET  
Add Event >  
CALENDAR SET  
Add Exception >  
EXCEPTION NAME  
Exception 01  
EXCEPTION NAME  
Bank Hol May
```

9. Press ✓.

The display shows:

```
EXCEPTION START TIME
00 : 00
```

10. Key in the start time of the exception.

For example, to start at one minute past midnight:

```
EXCEPTION START TIME
00.01
```

Note that midnight is "00:00" and represents the start of the day.

11. Press ✓.

The display shows:

```
EXCEPTION START DATE
01/01
```

12. Key in the start date.

For example, if the start date is 02/05 (2nd May), key in:

```
EXCEPTION START DATE
02/05
```

13. Press ✓.

The display shows:

```
EXCEPTION END TIME
00 : 00
```

14. Key in the end time of the exception.

For example if the exception ends at one minute before midnight.

```
EXCEPTION END TIME
23 : 59
```

15. Press ✓.

The display shows:

```
EXCEPTION END DATE
01/01
```

16. Key in the end date of the exception.

For example:.

```
EXCEPTION END DATE
02/05
```

17. Press ✓.

The display shows:

```
CALENDAR SET
Add Exception >
```

18. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

To add an event:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press ▼ until the display shows:

(For a part set system the bottom line of the display shows "Setting Options".)

```
INSTALLER MENU
Partitions >
```

3. Press ✓.

(For a part set system the display shows "Setting Options Full Set".)

```
PARTITIONS
Partition 1 >
```


4. Press ▲ until the display shows:

(For a part set system the top line of the display shows "Setting Options".)

```
PARTITIONS
Calendar Set >
```

5. Press ✓.

```
CALENDAR SET
Add event >
```

6. Press ✓.

The bottom line of the display shows a new event and its default name. The text cursor is on the first character.

```
EVENT NAME
Event 01
```

7. Key in a name for the event (if required).

For example:

```
EVENT NAME
Mon am unset
```

See page 12 for hints on how to edit names.

8. Press ✓ when you have finished editing the name.

```
EVENT TIME
00:00
```

The bottom line of the display shows the current time for the event.

Note that midnight is "00:00" and represents the start of the day.

9. Key in the start time of the event. Use the 24 hour clock.

```
EVENT TIME
07:30
```

10. Press ✓ to finish setting up the event time.

The bottom line of the display shows the first in a list of the seven days of the week. The end of the bottom line shows "Yes" if the event will happen on that day, or "No" if it will not.

```
EVENT DAYS
Sunday No
```

11. Press ► repeatedly to change the "Yes" to a "No" and back again, as required.

```
EVENT DAYS
Sunday No
```

12. Press ▲ or ▼ to see the other days of the week. Press ► to change their state as required.

```
EVENT DAYS
Monday Yes
```

13. Press ✓ to finish setting up the event day(s).

On a partitioned system the bottom line of the display shows the first in a list of the partitions. At the end of the bottom line is the current action for that partition.

```
EVENT ACTIONS
Partition 01 No
```

- a) Press ► repeatedly to cycle through the available actions for the partition.

```
EVENT ACTION
Partition 01 Full
```

Each time you press ► the right hand of the bottom line of the display changes to one of "Full", "Part", "Unset" or "No" (for no action).

b) Press ▲ or ▼ to see the other partitions in the list. Press ► to change their state as required.

EVENT ACTION	
Partition 02	No

On a part setting system the bottom line of the display shows the current action for the system, for example:

EVENT ACTIONS	
*Part Set D	

a) Press ▲ or ▼ to display the other actions available, for example:

EVENT ACTIONS	
Unset	

On a part setting system the actions available are "Full Set", "Part Set B", "Part Set C", "Part Set D", "Unset" and "No action".

14. Press ✓.

The display shows the first of any exceptions available. (See page 137). The end of the bottom line shows "Yes" if the exception applies to that event, or "No" if it does not.

EVENT EXCEPTIONS	
Exception 01	No

(Note that the exception description can be programmed, and may differ from that shown here.)

15. Press ► repeatedly to change the "Yes" to a "No" and back again, as required.

EVENT EXCEPTIONS	
Exception 01	Yes

16. Press ▲ or ▼ to see the other available exceptions. Press ► to change their state as required.

EVENT EXCEPTIONS	
Exception 03	No

17. Press ✓ when you have finished applying exceptions.

The display shows:

CALENDAR SET	
Add Event	>

18. Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

To edit an event:

1. Enter Installer Menu.

INSTALLER MENU	
Detectors/Devices	>

2. Press ▼ until the display shows:

(For a part set system the bottom line of the display shows "Setting Options".)

INSTALLER MENU	
Partitions	>

3. Press ✓.

(For a part set system the display shows "Setting Options Full Set".)

PARTITIONS	
Partition 1	>

4. Press ▲ until the display shows:
(For a part set system the display shows:
"Setting Options Calendar Set".)
5. Press ✓.
6. Press ▼ until the display shows:
7. Press ✓.
The display shows the first item in a list of the
available events.
8. Press ▲ or ▼ to see the other events.
9. Press ✓.
The bottom line of the display shows the first
option that you can edit for the selected event
(in this case "Name").
10. Either: press ✓ to select the Name option.

OR: press ▼ or ▲ repeatedly to see the rest of
the editing menu options:
Press ✓ to select an editing option.

Each of the options allows you to edit one of
the parts of the event. The displays appearing
while editing the event work in the same way
as the displays shown during adding the event
(see page 138).
11. Press ✓ to complete editing the selected part of
the event.
The display shows the event editing menu.
12. Carry on with any other programming that you
need to do. DON'T FORGET to leave the
Installer Menu in order to save the changes you
have made (see page 7).

PARTITIONS

Calendar Set >

CALENDAR SET

Add Event >

CALENDAR SET

Edit Event >

EDIT EVENT

Event 01 >

EDIT EVENT

Event 03 >

EVENT 03

Name >

EVENT 01 NAME

Event 01

EVENT 03

Time >

EVENT 03

Days >

EVENT 03

Actions

EVENT 03

Exceptions >

EVENT 03

Name >

To delete an event:

1. Enter Installer Menu.

INSTALLER MENU

Detectors/Devices >

2. Press ▼ until the display shows:
(For a part set system the bottom line of the display shows "Setting Options".)
3. Press ✓.
(For a part set system the display shows "Setting Options Full Set".)
4. Press ▲ until the display shows:
(For a part set system the top line of the display shows: "Setting Options".)
5. Press ✓.
6. Press ▼ until the display shows:
7. Press ✓.
The display shows the first item in a list of the available events.
8. Press ▲ or ▼ to see the other events.
9. Press ✓.
The bottom line of the display asks you to confirm that you want to delete the event.
10. Press ✓ to delete the event.
(Press ✕ if you wish to change your mind.)
The control unit deletes the event, and then displays the next event available for deletion.
11. Press ✕ to leave the Delete Event menu.
The display shows:
12. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```
INSTALLER MENU
Partitions >
```

```
PARTITIONS
Partition 1 >
```

```
PARTITIONS
Calendar Set >
```

```
CALENDAR SET
Add event >
```

```
CALENDAR SET
Delete event >
```

```
DELETE EVENT
Event 01 >
```

```
DELETE EVENT
Event 03 >
```

```
DELETE EVENT
Are you sure?
```

```
DELETE EVENT
Event 04
```

```
CALENDAR SET
Delete Event >
```

System Options

Programming Remote Code Reset

To install the CSID seed code:

1. Call the ARC and obtain the CSID seed code.
2. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

3. Press ▼ until the display shows:
4. Press ✓.
5. Press ▲ until the display shows:
6. Press ✓.
The display shows a blank CSID seed code.
7. Key in the CSID seed code (for example):
8. Press ✓.
9. Carry on with any other programming that you need to do. **DON'T FORGET** to leave the Installer Menu in order to save the changes you have made (see page 7).

```

INSTALLER MENU
  System Options  >
SYSTEM OPTIONS
  Wired zone type  >
SYSTEM OPTIONS
  CSID Code       >
CSID Code
0000
CSID Code
1234
SYSTEM OPTIONS
  CSID Code       >

```

Note: To disable this option key in "0000" over the existing code.

To ensure that users cannot reset the system after alarm unless they enter an anti-code:

1. Enter Installer Menu.
2. Press ▼ until the display shows:
3. Press ✓.
4. **EITHER** IF DD243 Confirmation is ON then:
 - a) Press ▼ until the display shows:
 - b) Press ✓.
 - c) Press ▼ until the display shows:
 - d) Press ✓.
 - e) Press ▼ until the display shows:
 - f) Press ✓.

```

INSTALLER MENU
  Detectors/Devices  >
INSTALLER MENU
  System Options     >
SYSTEM OPTIONS
  Wired zone type    >
SYSTEM OPTIONS
  DD243              >
DD243
  Confirmation       >
DD243
  Confirmed Reset    >
CONFIRMED RESET
*User
CONFIRMED RESET
  Installer
DD243
  Confirmed Reset    >

```

- g) Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

OR IF DD243 Confirmation is OFF then:

- a) Press ▼ until the display shows:
- b) Press ✓.
- c) Press ► until the display shows:
- d) Press ✓.
- e) Carry on with any other programming that you need to do. DON'T FORGET to leave the Installer Menu in order to save the changes you have made (see page 7).

SYSTEM OPTIONS	
User reset	>
USER RESET	
Zone alarms	Yes
USER RESET	
Zone alarms	No
SYSTEM OPTIONS	
User Reset	>

Testing

To start testing

1. Make sure the system is idle.
2. Enter Installer Menu.
3. Press ▲ until the display shows:
4. Press ✓.
5. Press ▼ until the display shows the part of the system that you wish to test.

i-on160EX	
13:25 16/3/2010	
INSTALLER MENU	
Detectors/Devices	>
INSTALLER MENU	
Test	>
TEST	
Sirens & Sounders	>

To walk test

To test every zone in the whole system:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" above).
2. Press ▼ until the display shows:
3. Press ✓.
The bottom line of the display gives you the opportunity to turn the chime feature on or off.

TEST	
Sirens & Sounders	>
TEST	
Walk Test	>
WALK TEST	
Chime	On

4. Press ◀ or ▶ to toggle between Chime On or Chime Off.

5. Press ▼.

The display shows:

6. Press ✓.

The display shows, for example:

7. Trigger the alarm and tamper of each zone.

As you trigger the zones the top line of the display shows the number of zones remaining to be tested. The bottom line of the display shows the first in a list of the zones you have selected to test.

Each zone that you test shows an "A" if you have tested the Alarm contacts and a "T" if you have tested the tamper.

The chime tone will sound for each zone you activate if you have enabled Chime.

Press ≡ if you wish to see a list of the zones not yet triggered.

8. Press ▲ or ▼ to scroll up or down the list of zones.

Press ✕ to finish the test.

To test the zones in one or more partitions:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).

2. Press ▼ until the display shows:

3. Press ✓.

The bottom line of the display gives you the opportunity to turn the chime feature on or off.

4. Press ◀ or ▶ to toggle between Chime On or Chime Off.

5. Press ▼ until the display shows:

6. Press ✓.

The display shows:

7. Press ◀ or ▶ to select a partition for testing.

Each time you press ◀ or ▶ the "Yes" toggles to a "No" and back again. When "Yes" appears the partition is selected.

```
WALK TEST
System >
```

```
24 Zone(s) to test
Zone 020
```

```
23 Zone(s) to test
Zone 020 TA
```

```
TEST
Sirens & Sounders >
```

```
TEST
Walk Test >
```

```
WALK TEST
Chime On
```

```
WALK TEST
Partitions >
```

```
WALK TEST PTNS
Partition 1 No
```

Press ▲ or ▼ to see other partitions.

8. Press ✓ to start the test.

The display shows for example:

9. Trigger the alarm and tamper of each zone.

As you trigger the zones the top line of the display shows the number of zones remaining to test. The bottom line shows the first in a list of zones that you have selected for testing.

Each zone that you test shows an "A" if you have tested the Alarm contacts and a "T" if you have tested the tamper.

The chime tone will sound for each zone you activate if you have enabled Chime.

Press ≡ if you wish to see a list of the zones not yet triggered.

10. Press ▲ or ▼ to scroll up or down the list of zones.

Press ✕ to finish the test.

To test the zones in an expander:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).

2. Press ▼ until the display shows:

```
24 Zone(s) to test
Zone 020
```

3. Press ✓.

The bottom line of the display gives you the opportunity to turn the chime feature on or off.

4. Press ◀ or ▶ to toggle between Chime On or Chime Off.

```
23 Zone(s) to test
Zone 020      TA
```

5. Press ▼ until the display shows:

```
TEST
Sirens & Sounders  >
TEST
Walk Test          >
WALK TEST
Chime              On
```

6. Press ✓.

The display shows:

7. Press ✓ to start the test.

The display shows for example:


```
WALK TEST
Expanders          >
WALK TEST EXPANDERS
W1-02 Wired Expandr>
24 Zone(s) to test
Zone 020
```





8. Trigger the alarm and tamper of each zone.

As you trigger the zones the top line of the display shows the number of zones remaining to be tested. The bottom line of the display shows the first in a list of the zones that you have selected for testing.

Each zone that you test shows an "A" if you have tested the Alarm contacts and a "T" if you have tested the tamper.


The chime tone will sound for each zone you activate if you have enabled Chime.

Press  if you wish to see a list of the zones not yet triggered.

9. Press  or  to scroll up or down the list of zones.
Press  to finish the test.

```
23 Zone(s) to test
Zone 020          TA
```

Testing a Remote Control:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).
2. Press  until the display shows:

```
TEST
Sirens & Sounders >
```

3. Press .

The display instructs you to press any button on the remote.

If the display shows "No Remotes Learnt" then there are no remotes learned into the system.

```
TEST
Remotes >
Press required
Remote button
```

4. Press one button on the remote.

```
RM01, B4: User 02
Unset All          SS9
```

The example display at right shows:


"RM01" = The name of the remote.

"B4" = The button you pressed.

"User 02" = The user who the remote is assigned to.

"Unset All" = The function of the button.

"SS9" = The radio signal strength of the remote.

5. Press any other buttons on the remote that you wish to test.
6. Press  to finish the test.

```
RM01, B3: User 02
Toggle on11       SS9
TEST
Remotes >
```

Testing a Radio Panic Alarm:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).
2. Press ▼ until the display shows:
3. Press ✓.
The display instructs you to press both PA buttons.
4. Press and hold down both buttons on the PA at the same time.

```
TEST
Sirens & Sounders  >
TEST
User Panic Alarms  >
Press both PA
Buttons
User: User 002
SS: 9
```

The display shows (for example):
"User 002" = The user who the remote is assigned to.
"SS9" = The radio signal strength of the remote.

5. Press ✕ to finish the test.

```
TEST
User Panic Alarms  >
```

Testing a Proximity Tag:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).
2. Press ✓.
3. Press ▼ until the display shows:
4. Press ✓.
The display instructs you to present the prox tag to the keypad.
5. Hold the prox tag against the front of the keypad.
The display shows the owner of the prox tag.
6. Press ✕ to finish the test.

```
TEST
Sirens & Sounders  >
TEST
Sirens & Sounders  >
TEST
Prox Tags          >
TESTING PROX TAGS
Present tag to panel
TESTING PROX TAGS
User: User 002
TEST
Prox Tags          >
```

Sending a Test Call to an ARC Number:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).
2. Press ▲ until the display shows:
3. Press ✓.

```
TEST
Sirens & Sounders  >
TEST
ARC Reporting      >
ARC REPORTING
```

The bottom line of the display shows "Number 1". There are two numbers to chose from.

4. Press ▲ or ▼ to select the number you wish to call.
5. Press ✓.

The keypad display shows the progress of the call: "Dialling", then "Connected", "Negotiating" followed by "Call Successful". Check with the receiving centre that the test call arrived. If the call fails the display will show "Call failed" followed by a reason.

Tel No 01 >

ARC REPORTING

Tel No 02 >

Test call started...

Dialling....

Connected...

Negotiating...

Call Successful

Sending a Test Call to a Speech Dialler Number:

1. Enter the installer menu and select Test (see steps 1 to 4 in "To start testing" on page 144).

TEST

Sirens & Sounders >

2. Press ▼ until the display shows:

TEST

Speech Dialler >

3. Press ✓.

The display instructs you to key in a telephone number that you wish to send the test message to.

Key in tel no:

4. Key in the telephone number the you wish to call.

Key in tel no:

12345

5. Press ✓.

The keypad display shows the progress of the call: "Dialling" while the speech dialler is dialling the telephone number, followed by "Connecting" when the called number is ringing. The display shows. "Connected" when the called number answers, followed by "Playing Messages" (after six seconds). If the called number presses 5 or 9 the display shows

Dialling....

Connecting...

Connected...

"Acknowledged".

Playing Messages...

Note: If you key in a valid user access code before the speech dialler connects to its first destination then the control unit will cancel the call.

Log

Viewing the Log

1. Enter Installer Menu.
2. Press ▲ until the display shows:
3. Press ✓.
The display shows you the most recent log event.
4. Press ▲ or ▼ to scroll through the log.
▼ shows earlier events.
▲ shows more recent events.
5. Press ► to see more details in the first line of the display.
6. Press ✕ when you have finished reading the Log.

INSTALLER MENU
Detectors/Devices >

INSTALLER MENU
View Log >

*U00 On Site
15:13:52 16/03/2010

Config Changed
15:05:34 16/03/2010

Installer
15:05:34 16/03/2010
INSTALLER MENU
View Log >

About

Finding The Current Panel Software and Language Version

1. Enter Installer Menu.
2. Press ▲ until the display shows:
3. Press ✓.
4. Press ✓.
The bottom line of the display shows the panel software version, for example:
5. Press ▼.
The bottom line of the display shows the version of the language text used on the

INSTALLER MENU
Detectors/Devices >

INSTALLER MENU
About >

ABOUT
Panel >

ABOUT PANEL
i-on160EX v1.00.00

ABOUT PANEL
English v1.00.00

display, for example:

6. Press **✕** when you have finished.

```
INSTALLER MENU
About >
```

Seeing Which Communications Module Is Currently Installed:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press **▲** until the display shows:

```
INSTALLER MENU
About >
```

3. Press **✓**.

```
ABOUT
Panel >
```

4. Press **▼** until the display shows:

```
ABOUT
Comms >
```

5. Press **✓**.

```
ABOUT COMMS
Module: 8750 >
```

The bottom line of the display shows the module type currently fitted (or the word "None" if no module is fitted).

If the communications module is an Ethernet or GPRS module:

6. Press **✓**.

The bottom line of the display shows "IP Address".

```
MODULE: ETHERNET
IP Address >
```

7. Press **✓**.

The bottom line of the display shows the IP address currently assigned to the plug-on Ethernet module. Note that this may have been assigned by DHCP.

```
IP ADDRESS
000.000.000.000.DHCP
```

8. Press **✕** then **▼**.

```
MODULE: ETHERNET
Subnet Mask >
```

9. Press **✓**.

The bottom line of the display shows the subnet mask currently assigned to the plug-on Ethernet module. Note that this may have been assigned by DHCP.

```
SUBNET MASK
000.000.000.000 DHCP
```

10. Press **✕** then **▼**.

```
MODULE: ETHERNET
Gateway Address >
```

11. Press **✓**.

The bottom line of the display shows the gateway address currently assigned to the plug-on Ethernet module. Note that this may have been assigned by DHCP, or this may be

```
GATEWAY ADDRESS
000.000.000.000 DHCP
```

blank if you are connecting a PC/laptop directly to the control unit.

12. Press **✕** then **▼**.

```
MODULE: ETHERNET
MAC Address >
```

13. Press **✓**.

The bottom line of the display shows the MAC address of the plug-on Ethernet module.

```
MAC ADDRESS
00-11-78-00-00-00
```

14. Press **✕** then **▼**.

```
MODULE: ETHERNET
IP Link Status >
```

15. Press **✓**.

The bottom line of the display shows "OK" if the control unit has successfully connected to a PC by way of an Ethernet cable.

```
IP LINK STATUS
OK
```

Finding IP Network Information For The Built-In Ethernet Port:

1. Enter Installer Menu.

```
INSTALLER MENU
Detectors/Devices >
```

2. Press **▲** until the display shows:

```
INSTALLER MENU
About >
```

3. Press **✓**.

```
ABOUT
Panel >
```

4. Press **▼** until the display shows:

```
ABOUT
Comms >
```

5. Press **✓**.

The bottom line of the display shows the plug-on module type currently fitted (or the word "None" if no module is fitted).

```
ABOUT COMMS
Module: 8750 >
```

6. Press **▼**.

```
ABOUT COMMS
Panel Ethernet >
```

7. Press **✓**.

```
PANEL ETHERNET
IP Address >
```

8. Press **✓**.

The bottom line of the display shows the IP address currently assigned to panel's webserver. Note that this may have been assigned by DHCP.

```
IP ADDRESS
192.168.000.100
```

9. Press **✕** then **▼**.

```
PANEL ETHERNET
Subnet Mask >
```

10. Press ✓.

The bottom line of the display shows the subnet mask currently assigned to the panel webserver. Note that this may have been assigned by DHCP.

```
SUBNET MASK
255.255.255.000
```

11. Press ✕ then ▼.

```
PANEL ETHERNET
Gateway Address  >
```

12. Press ✓.

The bottom line of the display shows the gateway address currently assigned to the plug-on Ethernet module. Note that this may have been assigned by DHCP, or this may be blank if you are connecting a PC/laptop directly to the control unit.

```
GATEWAY ADDRESS
000.000.000.000 DHCP
```

13. Press ✕ then ▼.

```
PANEL ETHERNET
MAC Address      >
```

14. Press ✓.

The bottom line of the display shows the MAC address control unit pcb

```
MAC ADDRESS
00-11-78-00-00-00
```

15. Press ✕ then ▼.

```
PANEL ETHERNET
IP Link Status   >
```

16. Press ✓.

The bottom line of the display shows "OK" if the control unit has successfully connected to a PC by way of an Ethernet cable.

```
IP LINK STATUS
OK
```

17. Press ✕ to leave the submenu.

```
PANEL ETHERNET
IP Link Status   >
```

Appendix I: ARC Communication Formats

Note: To comply with EN50131 you must fit a communications module.

Fast Format

Fast Format is the format most widely used in the UK. When using the Fast Format, each message transmitted to the ARC consists of the following:

A 4,5 or 6-digit account number.

8 channels of data. Each channel communicates the status of an output, as programmed using the "Fast Format Channels" option (see page 75). The value of the channel can be:

- 1 = new alarm and not previously reported
- 2 = status of output is open/unset
- 3 = alarm restored and not previously reported
- 4 = status of output is closed/set
- 5 = not in alarm
- 6 = in alarm but previously reported

A test signal.

Contact ID

The Contact ID format transmits data from the event log to the Alarm Receiving Centre (ARC). Examples of messages in the Contact ID format are:

Example 1 - 1234 18 1137 01 015 2

1234 is the account number, as specified in Account Numbers option (page 74).

18 is the message type used to identify the message as Contact ID.

1137 is the event qualifier for a new event (1), followed by the event code for a system tamper alarm (137).

01 is the partition number.

015 is the zone number.

2 is the checksum value, which the ARC needs to verify to confirm a valid message has been received.

Example 2 - 1234 18 3137 01 015 F

The only difference between this and the first example, is the event qualifier of 3 to indicate a restore of a system tamper alarm, and the checksum value.

SIA 1, SIA 2, SIA 3 and Extended SIA 3

When using the SIA formats the control unit transmits data from the event log to the ARC. The four SIA formats differ in the amount of data transmitted with each message:

Type	Format
SIA1:	#AAAAAA NCCcc
SIA2:	#AAAAAA Nidnnn/rinn/CCcc

SIA3: #AAAAAA|Ntihh:mm/idnnn/rinn/CCcc
 #AAAAAA|AS

Extended SIA 3: #AAAAAA|Ntihh:mm/idnnn/rinn/CCcc/AS

Where:

AAAAAA 6-digit programmable account code (e.g. 123456).
 "N" New Event (always N).
 "ti"hh:mm/ time (e.g. ti10:23/).
 "id"nnn/ user number, if applicable; otherwise not sent (e.g. id123/ or id6/).
 "ri"nn/ partition no. (e.g. ri12/ or ri3).
 CC event code (e.g. FA = Fire Alarm).
 cc zone or keypad number, if applicable; otherwise not sent (e.g. 23 or 5).
 "A"S text description of event, usually the log event description.

(The control unit sends those characters shown between " and " above literally as they appear in the text.)

For example, if there is a fire alarm on zone 2 of partition 4 at 10:15 (partition 4 account number is 10), the message would be:

SIA1: #000010|NFA2

SIA2: #000010|N/ri4/FA2

SIA3: #000010|Nti10:15/ri4/FA2 #000010|AFire
 Zone 2

Extended SIA3: #000010|Nti10:15/ri4/FA2/AFire Zone 2

Appendix II: Programming a Common Area

Some commercial premises include two or more separate areas linked by a common area. You can program the i-on160EX to allow users to set each area independently, and then set the common area automatically when the last occupant leaves the premises. The Full Set Link option in Installer Menu - Partitions provides this feature.

Figure 12 shows a typical example of a commercial building that could use the "Common Area".




Figure 12. Typical commercial building.

The business using the building is split into Factory and Office departments. These two sets of users work different hours. The manager wants each department to be able to set their own part of the alarm system separately. The common area including the Foyer, Kitchen and Toilet should only be armed when there is no one in the building. This will allow either the Factory or the Office staff to use those facilities when part of the alarm system is armed.

Installation and Programming

If the installer wishes to employ wired zones only they should use FSL wiring. The i-on160EX provides connections for 10 FSL zones on its pcb.

For best operation, there should be two keypads: one fitted in the Loading Bay and the other fitted in Reception.

When starting the control unit for the first time, select Partitioned system (not part setting system).

In the i-on160EX Partition 1 is always the common area. Use Partition 1 for the Foyer, Kitchen and Toilet. Partition 2 can be used for the Factory and Loading Bay. Partition 3 can be used for the Office and Reception. To make the common area (P1) follow the status of other partitions use the Partitions - Full Set Link option (see below).

To avoid false alarms make the alarm response of the common area (Partition 1) Siren + Comms and the other two Partitions Siren only.

Zone Programming

Location	Zone	Name	Zone Type	Partitions
Front Door	001	Front Door	Final Exit	P1
Foyer PIR	002	Foyer PIR	Entry Route	P1
Loading Bay Entrance	003	LB to Foyer	Final Exit	P2
Roller shutter	004	Rshutter	Normal Alarm	P2
Loading Bay PIR	005	LBay PIR	Entry Route	P2
Factory PIR	006	Factory PIR	Normal Alarm	P2
Factory Fire Door	007	Factory FD	24 Hour	P2
Kitchen PIR	008	Kitchen PIR	Normal Alarm	P1
Office Fire Door	009	Office FD	24 Hour	P3
Office PIR	010	Office PIR	Normal Alarm	P3
Reception PIR	011	Recpt PIR	Entry Route	P3
Reception Entrance	012	Rcept Door	Final Exit	P3

Partition and Other Programming

Menu	Sub Menu	Option
Add/delete	Detectors/Devices	External Radio Siren (if to be fitted)
Wired keypads	Keypad 01	Name = Office Partition 3
	Keypad 2	Name = Factory Partition 2
	Keypads 3 & 4 – not fitted	NA
Outputs	Panel Outputs	1 = Siren 2 = Strobe 3 & 4 = NU
Partitions	P1	Name = Foyer Exit Mode = Final Door Set Settle Time = 10s Entry Time = 45s Alarm Response = Siren + Comms (Full) Strobe on Set = Yes (If required) Strobe on Unset = Yes (if required)
	P2	Name = Offices Exit Mode = Timed Exit Time = 20s Entry Time = 45s Alarm Response = Siren (Local)
	P3	Name = Factory Exit Mode = Timed Exit Time = 20s Entry Time = 45s Alarm Response = Siren (Local)
	Full Set Link	P2 = Yes P3 = Yes

System Options	Wired Zone Type	Select FSL if using all wired detectors
	DD243 (for UK only)	Confirmation = On
	• <i>Confirmation Time</i>	30 mins
	• <i>After Entry</i>	2 zones
	• <i>Entry keypad Lock</i>	On
	• <i>Sounder on</i>	Unconfirmed
	• <i>Siren on</i>	Unconfirmed
	• <i>Unconfirmed reset</i>	User
	• <i>Confirmed Reset</i>	Installer
	Keypad Text	Enter Name of installer company
	Siren Delay	(default 0 mins)
	Siren Time	(default 15 mins)
	Force Set	Off
	CSID	Enter 4 digit ARC Scantronic reset code (if required)
	Silence Alerts	User

User Programming

User	Code	Type	Partitions
01	1234	Master User	Whole system – P2 + P3
02	2222	Partition user	P2 (Factory)
03	3333	Partition user	P3 (Office)

User Operation

To set:

Full System	User 01 enters code or Prox + ✓ (User 01 can select an individual Partition or full set the whole system.)
Factory only (Partition 2)	Partition 2 User enter Code or Prox in Keypad 2
Office only (Partition 3)	Partition 3 User enter Code or Prox in Keypad 1

To Unset:

First user to enter keys in their code or presents a Prox tag

If User 02 (a member of the Factory department) sets their Factory partition and the Office partition is already set, then the common foyer area will also start to set. When the user closes the Front Door (zone 1) the whole system sets and the alarm response is raised to Full alarm (Siren + Comms).

The same thing will happen if User 03 sets the Office partition when the Factory partition is already set.

If either User 02 or 03 opens the Front Door this starts the entry time and tone. The user enters their code or presents a Prox tag to the keypad in their department. The system then unsets their partition and the common area.

If the Master user opens the Front Door and enters their code or presents a Prox to a keypad then only P1, the common area, will unset. The keypad then gives the master user the option to unset either Factory or Office or both. This allows the manager to open only the area they want to enter, leaving the other area protected.

Appendix III: Using A WAM As A Repeater

Introduction

In mode 1 the WAM acts as a repeater for i-on alarm systems. The WAM receives signals from transmitters that are out of range of the radio expander. The WAM repeats these signals and, because the WAM is nearer the expander, the expander can now hear the signals and respond to them.

The WAM can learn up to eight detectors. You can also program the WAM to flash a separate blue LED for each transmitter.

Note that you cannot chain a series of WAMs to extend the transmitter range indefinitely. The system allows only one hop. However, each i-on160EX control unit can learn the identities of up to 20 WAMs.

To use the WAM as a repeater, you will need to:

- a) Teach the i-on160EX the identity of all the transmitters (see page 110).
- b) Teach the expander the identity of the WAM (see page 161)
- c) Teach the WAM the identity of those transmitters whose signals it is going to repeat (see page 163).

Before You Begin

1. Carry Out a Radio Site Survey

Cooper Security strongly recommend that you carry out a radio site survey to find the best position for the WAM. You must choose a position for the WAM so that a) the nearest radio expander can receive the signals from the WAM and b) the WAM can receive the signals from those distant transmitters that you wish to repeat.

2. Prepare the WAM:

1. Make sure power to the WAM is OFF, and open the WAM lid.
2. On the bank of 8 dipswitches:


Set dipswitches:

- | | | |
|---------|------------|-------------------------------------|
| 1 | ON (up) | Radio learning ON. |
| 2 | ON (up) | Jamming detection ON |
| 3 | ON (up) | Supervision ON |
| 8 | ON (UP) | (optional) LEDs show channel status |
| 4,5,6,7 | OFF (down) | Not applicable |


Note: You do NOT need to adjust the jumpers next to the tamper switch.

3. Set the WAM to the Mode 1 (Repeater)


1. Apply power to the WAM.
2. Enter programming mode as follows:
 - a) Make sure the tamper switch has opened.
The Red Trouble LED glows.
 - b). Press SELECT.
The blue LED 1 glows. The WAM is in menu 1.



3. Use menu 7 to go into mode selection as follows:
 - a) Press SELECT repeatedly until LED 7 glows.



- b) Press SET.
The blue LEDs show the current mode. When delivered from the factory the WAM is in mode 1 (LED 1 glowing).



4. If necessary, select mode 1 by pressing SELECT repeatedly until LED 1 lights up.
(Note that LED 6 does not light up.)

5. Press SET.
The sounder gives a double "beep" and the LED 7 glows again. The WAM is now back in menu 7.



6. Leave programming mode as follows:
 - a) Press ESC/DEL.
The blue LED goes dark. The sounder gives a regular beeping tone to remind you to replace the lid.
 - b) Replace the lid (or operate the tamper switch).
After a few seconds the red Trouble LED switches off and the sounder gives a double beep confirmation tone.

NOTE: You must leave programming mode in order to save the changes you have made.

Teach the Expander the Identity of the WAM

At The Control Unit:

1. Enter Installer Menu.

INSTALLER MENU

2. Press ✓.

3. Press ▼ until the display shows:

4. Press ✓.

5. Press ✓.

The display shows the first in a list of the available radio expanders.

6. Press ▲ or ▼ to see other expanders (if necessary).

7. Press ✓ to select the radio expander you that wish to learn the WAM.

The bottom line of the display shows the first of the two WAM memory slots available on the expander. When a slot is occupied with a WAM then the bottom line shows a "*" at the beginning.

8. Press ▲ or ▼ to see other available WAM slots:

9. Press ✓ when the display shows the WAM slot you wish to use.

```
Detectors/Devices  >
DETECTORS/DEVICES
Detectors          >
DETECTORS/DEVICES
WAMs               >
WAMS
Add/Del WAM       >
ADD/DEL WAM
Exp. R1-02        (R30)>
```

```
ADD/DEL WAM
Exp. R1-03        (R10)>
ADD/DEL WAM
WAM R1-03-01      >
```

```
ADD/DEL WAM
WAM R1-03-02      >
ADD/DEL WAM
Activate WAM Tamper
```

On the WAM:

1. Apply power to the WAM.
2. Make sure the tamper switch operates. You can do this by either opening the WAM lid (if it is currently closed) OR by leaving programming and closing the WAM lid.

The Red Trouble LED glows. The WAM starts transmitting its identity.

At the Control Unit

When the control unit learns the WAM's identity the keypad gives a double beep.

1. Press ✓

The display shows the default name for the newly learned WAM.

3. Leave the installer menu to save changes.

```
ADD/DEL WAM
WAM added         SS: 9
ADD/DEL WAM
*WAM 01           >
```


Teach the WAM the Identity of the Detectors

1. Enter programming mode as follows:

a) Open the tamper switch.

The Red Trouble LED glows.

b). Press SELECT.

The blue LED 1 glows. The WAM is in menu 1.




2. Press SET.

If any blue LEDs flash then those channels are already in use.



3. Activate tampers on all transmitters that the WAM needs to learn.


Each time the WAM learns a detector a blue LED glows to show the channel that detector is using.



4. Leave programming mode as follows:


a) Leave menu 1 by pressing ESC.

The blue LED 1 glows steadily.



b) Press ESC again.

The blue LED 1 goes dark. The sounder gives a regular beeping tone to remind you to replace the lid.



c) Close the lid tamper.

After a few seconds the WAM beeps twice and the red Trouble LED goes dark.

NOTE: You must leave programming mode in order to save the changes you have made.

5. Check that the control unit can receive signals from the transmitters learned by the WAM.

Deleting Devices

If you need to delete detectors from a WAM, perhaps in order to move them from one repeater to another, then:


1. Enter programming mode as follows:

a) Open the tamper switch.

The Red Trouble LED glows.


b). Press SELECT.

The blue LED 1 glows.



2. Press SELECT.


The blue LED 2 glows.



3. Press SET.

The WAM is in menu 2 – Delete Detectors.

If any blue LEDs flash then those channels are in use.



4. If necessary, press SELECT to select the detector you wish to delete. The blue LED of the selected detector flashes.

5. Press and hold ESC for at least four seconds.

The WAM sounder gives a double beep to confirm that the WAM has deleted the transmitter from that channel. The blue LEDs show menu 2.




6. Repeat steps 3 to 5 for the other detectors as necessary.

7. Leave programming mode as follows:

a) Leave menu 2 by pressing ESC. The sounder gives a regular beeping tone to remind you to replace the lid.

b) Close the lid tamper.

After a few seconds the WAM beeps twice and the red Trouble LED goes dark.



NOTE: You must leave programming mode in order to save the changes you have made.

Appendix IV: Programming a 762 or 768/769 as an Output Module

Introduction

Before You Begin



Carry out a radio site survey.

Set Up the 762 or 768

Enter Programming Mode

To enter programming for the first time (while installing a new unit):

1. Connect a suitable 12VDC power supply to the DC supply in connector.

The display shows the version number of the software as two  | 
alternating two-digit numbers, for example:

2. Press Select.

 L n

The display shows the first command in the menu: Manual
Learn.

To enter programming while the unit is operating:

1. Open the 762r case lid.

*Note: If the unit is connected to an alarm control panel the tamper
alarm may sound.*

The display is blank.

2. Press Select.

 L n

The display shows the first command in the menu: Manual
Learn.

Disable Infra-red learning

Enter programming mode if the 762r./768r is not already
there.



 L n

3. Press Select until the display shows the Infra Red Learn
command "IR":

 I r

4. Press Set.

 E

The display shows  if infra read learning is enabled, or  if
infra red learning is disabled (radio learning enabled).

5. Press Select until the display shows "disable".

 d

6. Press Set.

 I r

NOTE: If you disable infra-red learn then the receiver enables radio learn. If you enable infra-red learn then the receiver disables radio learn.

Set to manual learn

7. Press Select until the display shows the manual learn command "Ln".

Ln
8. Press Set.

The display shows the first available channel number, for example "C1":

[1

Select channel

9. Press Select repeatedly until the display shows the channel number you wish to use, for example:

[2

The display flashes if there are no other devices on that channel. The display is steady if there are already devices on the channel. The 762r will not show a channel number if it has already learned the maximum number of devices to that channel.
10. Press Set.

The display shows "C" and the channel number ("C2" in the example), followed by "d-" and then "S-" as the receiver scans for a new transmitter.

[C
[2
d-
S-

Teach the i-on160EX to the 762r

At the Control Unit:

1. Enter Installer Menu.

2. Press ▼ until the display shows:

3. Press ✓.

4. Press ✓ .

5. Press ✓.

The display shows the first in a list of the available radio expanders, for example:

6. Press ▲ or ▼ to see other radio expanders (if any).

The display shows, for example:

INSTALLER MENU	
Detectors/Devices	>
INSTALLER MENU	
Outputs	>
OUTPUTS	
Radio Outputs	>
RADIO OUTPUTS	
Add Outputs	>
ADD OUTPUTS	
Exp. R1-01	(R30)>
ADD OUTPUTS	
Exp. R1-03	(R10)>

7. Press ✓.

The display shows the first in a list of the radio outputs on that expander, for example:

```
ADD OUTPUT R1>03>01
Not Used >
```

The bottom line of the display shows the outputs current type.

8. Press ▲ or ▼ until the display shows the output you wish to add, for example:

```
ADD OUTPUT R1>03>02
Not Used >
```

9. Press ✓.

The display prompts you to make sure that the receiver is in learn mode:

```
Is the receiver in
learn mode?
```

10. Press ✓.

The control unit transmits its identity to the receiver. When the receiver has successfully learned the identity of the control unit it beeps twice.

```
Did the receiver beep
twice?
```

At the 762r

The 762 gives a double "beep" and the display shows the device number allocated to the transmitter. If you are using radio learn the display alternates with the transmitter's signal strength, for example: `d2 57`

(If you are using Infra-red learn the display shows a signal strength reading of zero.)

Note: If the display shows "--" and you hear a low tone from the sounder, then the 762r has already learned that transmitter.

If you hear a double beep followed by a low tone then the 762 has insufficient channels available for all the channels transmitted, but has allocated to the transmitter those that are available.

1. Press Esc/Del to go back to the command menu.

The display shows: `L n`

2. Press Select until the display shows the command "GO".

You should see: `GO GO`

3. Press Set.

The display shows: `L L`

You should hear a single beep repeated slowly.

4. Close the lid.

The unit is now out of programming mode.

Note: There is a deliberate delay of four seconds before the receiver leaves programming mode. This is to make sure that you have time to close the lid properly and screw it down firmly.

At the Control Unit

3. Press ✓.

The display shows:

```
EDIT OUTPUT R1>03>02
Name >
```

4. Press ✓ .

```
RADIO OUTPUTS
Add Outputs >
```

5. Press ✓.

The display shows the first in a list of the available radio expanders, for example:

```
ADD OUTPUTS
Exp. R1-01 (R30)>
```

6. Press ▲ or ▼ to see other radio expanders (if any).

```
ADD OUTPUTS
Exp. R1-03 (R10)>
```

The display shows, for example:

7. Press ✓.

The display shows the first in a list of the radio outputs on that expander, for example:

```
ADD OUTPUT R1>03>01
Not Used >
```

The bottom line of the display shows the outputs current type.

8. Press ▲ or ▼ until the display shows the output you wish to add, for example:

```
ADD OUTPUT R1>03>02
Not Used >
```

9. Press ✓.

The display prompts you to make sure that the receiver is in learn mode:

```
Is the receiver in
learn mode?
```

10. Press ✓.

The control unit transmits its identity to the receiver. When the receiver has successfully learned the identity of the control unit it beeps twice.

```
Did the receiver beep
twice?
```

Index

24 hour alarm		run time	69
output type	50	Burg comms rearm	78
zone type	34	Burglar alarm	
762r	130	fast format	75
768r	130	output type	46
769r	130	Calendar set	56
770r	44	Call acknowledge	82
Abort Delay	97	Call mode	
AC Fail		speech messages	80
external PSU zone type...	35	Call out only	88
fast format	75	Chime	37
output type	47	Common Area	156
Access code		Comms channels	
defaults	6	fast format	75
installer	67	Comms module	73
user	6	removing	73
Account name		speech dialler	79
Downloader	87	Communication	
Account number		SIA	154
ARC reporting	74	Communications	4
Alarm abort		menu	72
output type	46	module	4
Alarm Abort	97	Confirmation	62
Alert		After entry	62
tones silencing	71	Timer	62
Alternative reporting	73	Confirmed alarm	
Answer on one ring	88	output type	46
ARC reporting	72, 73	Confirmed reset	64
account number	74	Contact ID	74
call mode	73	account code	74
IP address	74	codes	76
IP network	74	report groups	75
phone book	73	reports	75
report type	74	restorals	77
testing	94	DD243	62
Armed lamp	49	Default	
Assign comms channels	75	access codes	11
ATS Test		country	66
output type	49	factory	67
Auto rearm	68	restoring	66
Autoset warning		Destinations	
output type	51	speech messages	82
Battery		Detectors	
fault output type	48	deleting	32
Bell	49	editing	33
delay	69	learning	32
delay and DD243	63	signal strengths	93

Double knock	37	Fast format	75
Downloading	72, 87	account code.....	74
access mode	88	Final door	
connection type	87	in part set (partitions)	55
IP address	89	Final door set	
mode baud rate	90	Part setting	54
port number.....	89	Final exit.....	34
telephone number.....	89	in part set (partitions)	56
Dynamic test call	78	Final Exit	
EN50131-1		settling time.....	54
8.8.3.....	22	Fire	
EN50131-3		fast format.....	75
9.1 bb	37	output type	46
9.1 cc.....	69	SIA messages.....	155
9.1 gg	32	zone type.....	33
9.1 hh	32	Force set.....	70
9.1 m.....	32	Force set omit	38
9.1 o	64	Full set	
9.1 p	22	exit mode (Part setting) ..	54
9.1 x	59	name (Part setting)	54
EN5131-3		output type	50
9.1 jj.....	23	Full Set Link	56, 156
Entry code lockout	63	Full set ready.....	50
Entry route.....	34	Gateway address	
in part set (Part setting) .	56	Ethernet module	87
in part set (partitions)	56	web server.....	86
stray on entry delay	70	General fault	
Entry time		output type	49
for remote control.....	68	GPRS	
Part setting	55	access point name	87
Entry/exit follow	49	password (ARC reporting)	87
Event	57	user id (ARC reporting)...	87
Event log		Infra red learn	45
Contact ID transm. format	154	Installer code	
SIA transmission format	154	changing.....	67
Exception.....	57	Installer text	68
Exit mode		Instant set	
Part setting	54	Part setting	54
Exit time		IP address	
Part setting	55	downloading.....	89
Expander		Ethernet module	87
testing.....	95	GPRS module	87
External PSU		polling (for arc)	74
AC Fail zone type	35	port number.....	87
battery fault zone type ...	35	web server.....	85, 86
fault output type.....	48	IP Network	72
fault zone type	35	ARC reporting.....	74
low volts output type.....	48	downloading.....	89
Low volts zone type	35		

Key switch	
latched	34
momentary	34
Keypad	
naming	40
PA keys enable	61
partitions	41
quick set keys	41
radio	42
radio-deleting	43, 118
radio-learning	42, 117
radio-naming	119
radio-partitions	43, 120
testing	91
Language	66
Line Fail	See Line Fault
Line Fault	
audible displayed alarm ..	85
reporting	72, 84
silent	85
tamper	85
Log	
erasing	10
viewing	96
Log only	
zone type	36
Loudspeakers	
partitions	69
volume	69
Mains power supply	
Mains fail - fast format ...	75
Masking	
output type	51
zone type	36
Modem baud rate	90
Module	151
Name	
account	87
editing	12
erasing all	67
full set (Part setting)	54
installer text	68
IP network unit	74
keying in	12
plug-by outputs	45
radio keypad	119
radio output	132
telephone number	81, 84
wired keypad	115
zones	33
Normal alarm	34
in part set (partitions)	55
Omit allowed attribute	37
Open/Close	46
fast format	75
Output	
Digi On Board output	154
Outputs	
plug-by	45
radio	45
Radio-learning	130
radio-name	132
radio-type	131
testing	93
type	46
wired	45
wired-partitions	135
wired-type	133
PA keys enable	61
PA silent	68
Panic alarm	
fast format	75
output type	46
testing	94
zone type	33
Part set	
B options (part setting) ..	53
B output type	50
B zone attribute	37
C output type	50
C zone attribute	37
D output type	51
D zone attribute	37
definition	4
entry route as (part setting)	56
final exit as (part setting)	55
output type	50
zone attribute for partitions	37
Part setting	52
definition	4
part set B options	53
Partitioned system	52
Partitions	
definition	5
keypad	41
Loudspeakers	69
siren	124
zones	36, 43

Phone book		RF low battery	
ARC reporting.....	73	fast format.....	75
downloading.....	89	output type	47
SMS	84	RF supervision	
speech dialler	81	enabling/disabling	70
PIR set latch.....	50	fast format.....	75
Plug-by outputs	45	output type	47
Polarity		Rings to answer	88, 89, 90
wired output	136	SD02	79
Polling IP address.....	74	Secure callback.....	88
Port number		Send tamper as burg	78
web server.....	85, 86	Set fail.....	51
Proximity tag		Setting complete.....	50
for entry code lockout	63	Settling time for Final Exit ..	54
testing.....	94	Shock sensor reset.....	50
PSU current		SIA	74, 154
testing.....	95	Signal strength	
Quick set keys		testing.....	93
enable	61	Silent PA	68
naming.....	41	Silent set	
programming	41	Part setting	54
Radio keypad.....	42	Single reporting	73
deleting	43, 118	Siren	49
learning.....	42, 117	confirmed/unconfirmed...	63
naming.....	119	delay.....	69
partitions	43, 120	delay and DD243	63
Radio outputs	45	deleting	125
learning.....	130	partitions	124
naming.....	132	radio	43
type	131	run time	69
Radio zone		testing.....	91
adding	32	Smoke sensor reset.....	50
delete all	32	SMS	72, 82
delete from expander	32	call mode.....	83
delete one.....	32	messages	83
RedCare reset.....	97	pstn	84
Remote controls		telephone numbers	84
for outputs.....	51	text messages	82
force set	70	triggers	84
needs entry timer	68	Soak Test.....	37
testing.....	90, 94	Sounder	
Remote reset.....	97	confirmed/unconfirmed...	63
Report mode		Speech dialler.....	72, 79
fast format.....	75	testing.....	95
Restorals.....	77	Speech messages.....	79
RF fault.....	47	call acknowledge.....	82
RF jamming.....	47	call mode.....	80
enabling/disabling detection of ..	70	destinations	82
fast format.....	75	recording	80

triggers	81
Static test call.....	78
Status	
web server.....	85
Stray on entry delay	70
Strobe	49
Strobe on set	
Part setting	55
Strobe on unset	
Part setting	55
Subnet mask	
Ethernet module	87
web server.....	85, 86
System options	60
Tamper	
allow omit.....	71
fast format.....	75
output type	48
send as burg	78
zone type.....	35
Technical alarm	
fast format.....	75
output type	46
zone type.....	34
Telephone number	
ARC reporting.....	73
downloading.....	89
SMS	84
Speech dialler.....	81
Test call	
dynamic	78
static.....	78
Text editing	12
Text messages	
SMS	82
Timed set	
Part setting	54

Triggers	
speech messages.....	81
Unattended mode.....	89
Unconfirmed reset.....	64
Unset complete.....	50
USB.....	87
User access	60
User code	
default.....	11
required for engineer access	61
User defined	
output type	51
WAM	44
deleting	129
viewing.....	128
Web server.....	72, 85
Wired outputs.....	45
partitions	135
type	133
Wired zone type.....	60
Zone	
alarm output type	51
attributes.....	36
editing.....	33
follow output type.....	51
force set	70
names	33
number of.....	60
omit (system) output type	49
omit (user) output type ..	48
omitted-fast format.....	75
partitions	36, 43
resistances.....	92
types.....	34
wiring not used.....	33

www.coopersecurity.co.uk

Product Support (UK) Tel: +44 (0) 1594 541979

Available between:

08:15 to 12:30 and 13:00 to 17:00 Monday to Friday.

Product Support Fax: (01594) 545401

email: techsupport@coopersecurity.co.uk

Part Number 12019970

5/11/2010