



PMC-CGM

Installation and Use

6806800D53C

March 2008

© Copyright 2008 Emerson

All rights reserved.

Trademarks

Emerson is a trademark registered in the U.S. Patent and Trademark Office. All other product or service names are the property of their respective owners.

Intel® is a trademark or registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Java™ and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Microsoft®, Windows® and Windows Me® are registered trademarks of Microsoft Corporation; and Windows XP™ is a trademark of Microsoft Corporation.

PICMG®, CompactPCI®, AdvancedTCA™ and the PICMG, CompactPCI and AdvancedTCA logos are registered trademarks of the PCI Industrial Computer Manufacturers Group.

UNIX® is a registered trademark of The Open Group in the United States and other countries.

Notice

While reasonable efforts have been made to assure the accuracy of this document, Emerson assumes no liability resulting from any omissions in this document, or from the use of the information obtained therein. Emerson reserves the right to revise this document and to make changes from time to time in the content hereof without obligation of Emerson to notify any person of such revision or changes.

Electronic versions of this material may be read online, downloaded for personal use, or referenced in another document as a URL to an Emerson website. The text itself may not be published commercially in print or electronic form, edited, translated, or otherwise altered without the permission of Emerson,

It is possible that this publication may contain reference to or information about Emerson products (machines and programs), programming, or services that are not available in your country. Such references or information must not be construed to mean that Emerson intends to announce such Emerson products, programming, or services in your country.

Limited and Restricted Rights Legend

If the documentation contained herein is supplied, directly or indirectly, to the U.S. Government, the following notice shall apply unless otherwise agreed to in writing by Emerson.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data clause at DFARS 252.227-7013 (Nov. 1995) and of the Rights in Noncommercial Computer Software and Documentation clause at DFARS 252.227-7014 (Jun. 1995).

Contact Address

Emerson Network Power - Embedded Computing GmbH

Lilienthalstr. 15

85579 Neubiberg-Munich/Germany

Contents

| | |
|--|-----------|
| About this Manual | 9 |
| Safety Notes | 13 |
| Sicherheitshinweise | 17 |
| 1 Introduction | 21 |
| 1.1 Features | 21 |
| 1.2 Standard Compliances | 22 |
| 1.3 Ordering Information | 23 |
| 2 Hardware Preparation and Installation | 25 |
| 2.1 Overview | 25 |
| 2.2 Before Installation | 25 |
| 2.2.1 Unpacking and Inspecting the Module | 25 |
| 2.2.2 Requirements | 26 |
| 2.2.2.1 Environmental Requirements | 26 |
| 2.2.2.2 Power Requirements | 27 |
| 2.3 Configuring the Module | 28 |
| 2.4 Installing and Removing the Module | 29 |
| 2.5 Hardware Upgrades and Accessories | 30 |
| 3 Controls, LEDs and Connectors | 31 |
| 3.1 Overview | 31 |
| 3.2 Layout | 31 |
| 3.3 Front Panel Connectors and LEDs | 31 |
| 3.3.1 BITS Interface Connectors | 32 |
| 3.3.2 LEDs | 33 |
| 4 Access and Configuration | 35 |
| 4.1 Overview | 35 |
| 4.2 Accessing the PMC-CGM | 35 |
| 4.2.1 Cabling | 36 |
| 4.2.2 Access | 36 |
| 4.3 Using a MIB Browser | 37 |

| | | |
|--------------|--|-----------|
| 4.4 | Configuring the PMC-CGM | 37 |
| 4.4.1 | Define IP Address of the Protection Partner Module | 38 |
| 4.4.2 | Define SNMP Trap Destinations | 38 |
| 4.4.3 | Configure the Interface Mode | 39 |
| 4.4.4 | Configure the BITS Interface | 39 |
| 4.4.5 | Configure Initial Master/Slave Role | 40 |
| 4.4.6 | Setup Multi-Shelf Configuration | 40 |
| 4.4.7 | Configure the Reference Clock | 41 |
| 4.4.8 | Perform Firmware/Software Upgrade | 42 |
| 4.4.9 | Reset the PMC-CGM | 43 |
| 4.4.10 | Configure Parameters for Event Handling | 44 |
| 5 | MIB Description | 47 |
| 5.1 | Overview | 47 |
| 5.2 | cgmControl | 47 |
| 5.3 | cgmSys | 55 |
| 5.4 | cgmClkDist | 60 |
| A | Related Documentation | 63 |
| A.1 | Emerson Network Power - Embedded Computing Documents | 63 |
| A.2 | Related Specifications | 63 |
| Index | | 65 |

List of Tables

| | | |
|-----------|---|----|
| Table 1-1 | Standard Compliances and Clocking Standards | 22 |
| Table 1-2 | Available Board Variants | 23 |
| Table 2-1 | Environmental Requirements | 27 |
| Table 2-2 | DC Module Power Requirements | 27 |
| Table 2-3 | Switch Settings | 29 |
| Table 3-1 | LED Description | 34 |
| Table 4-1 | MIB Browser Settings | 37 |
| Table 4-2 | Interface Modes | 39 |
| Table 5-1 | MIB Structure | 47 |
| Table 5-2 | cgmInputTable | 47 |
| Table 5-3 | Input Assignments | 48 |
| Table 5-4 | cgmBitsTable | 49 |
| Table 5-5 | cgmControl Elements | 53 |
| Table 5-6 | cgmEventTable | 55 |
| Table 5-7 | Event Codes and Severity | 56 |
| Table 5-8 | cgmSys Objects | 58 |
| Table 5-9 | cgmClkDist Objects | 61 |
| Table A-1 | Emerson Network Power - Embedded Computing Publications | 63 |

List of Figures

| | | |
|------------|---|----|
| Figure 1-1 | PMC-CGM | 22 |
| Figure 2-1 | Switch Location | 28 |
| Figure 2-2 | Location of PMC Slot on ATCA-F103 | 29 |
| Figure 3-1 | Module Layout | 31 |
| Figure 3-2 | Front Panel | 32 |
| Figure 3-4 | BITS Connector Pin Assignment | 33 |
| Figure 3-3 | BITS Connector Location | 33 |
| Figure 3-5 | LED Location | 33 |
| Figure 4-1 | Connecting the ARTM-F103-STX Ethernet Ports | 36 |

About this Manual

Overview of Contents

This manual is divided into the following chapters and appendices.

- [Safety Notes on page 13](#) provides safety relevant information when handling the product.
- [Sicherheitshinweise on page 17](#) provides a German translation of the Safety Notes section.
- [Introduction on page 21](#) provides a basic overview of the features of the product.
- [Hardware Preparation and Installation on page 25](#) outlines the installation requirements, switch settings, installation and removal procedures.
- [Controls, LEDs and Connectors on page 31](#) describes the LEDs, key, and connectors of the product.
- [Access and Configuration on page 35](#) provides procedures that necessary when handling the product.
- [MIB Description on page 47](#) gives an overview on the Private Emerson CGM-CONTROL-MIB and describes the implemented MIB objects.
- [Appendix A, Related Documentation, on page 63](#) lists related documentation and specifications.

Abbreviations

This document uses the following abbreviations:

| Abbreviation | Definition |
|--------------|--|
| AdvancedTCA | Advanced Telecom Computing Architecture |
| AIS | Alarm Indication Signal |
| AMC | Alarm Management Controller |
| ANSI | American National Standards Institute |
| BITS | Building Integrated Timing Source |
| CD-ROM | Compact-Disk Read-Only Memory |
| CGM | Clock Generator Module |
| CISPR | Comité Internationale Spécial des Perturbations Radioelectrotechnique (International Special Committee on Radio Interference, IEC) |
| DC | Direct Current |
| DHCP | Dynamic Host Configuration Protocol |
| DPLL | Digital Phase-Locked Loop |

| Abbreviation | Definition |
|---------------------|--|
| EMC | Electromagnetic Compatibility |
| EN | European Norm |
| ESF | Extended Super Frame |
| ETSI | European Telecommunications Standards Institute |
| FCC | Federal Communications Commission |
| FDL | Facility Data Link |
| FPGA | Field Programmable Gate-Array |
| FPS | Frames Per Second |
| FW | Firmware |
| GmbH | Gesellschaft mit begrenzter Haftung |
| IEC | International Electrotechnical Commission |
| IP | Internet Protocol |
| IPMI | Intelligent Platform Management Interface |
| IS | In Service |
| KHz | Kilohertz |
| LED | Light Emitting Diode |
| MHz | Megahertz |
| MIB | Management Information Base |
| NEBS | Network Equipment Building Standards |
| NVRAM | Non-Volatile Random Access Memory |
| OID | Object Identifier |
| OOS | Out of Service |
| PCB | Printed Circuit Board |
| PCI | Peripheral Component Interconnect |
| PICMG | PCI Industrial Computer Manufacturers Group |
| PLL | Phase-Locked Loop |
| PMC | PCI Mezzanine Card |
| RTM | Rear Transmission Module |
| RoHS | Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment |
| SELV | Safety Extra Low Voltage |
| SGA | Shelf Geographical Address |
| SNMP | Simple Network Management Protocol |
| TFTP | Trivial File Transfer Protocol |
| TNV | Telecommunication Network Voltage |

| Abbreviation | Definition |
|--------------|--|
| TPE | Twisted-Pair Ethernet |
| UL | Underwriters Laboratories Incorporated |
| VCCI | Voluntary Control Council for Interference |
| VLAN | Virtual Local Area Network |

Conventions

The following table describes the conventions used throughout this manual.

| Notation | Description |
|-----------------------|---|
| 0x00000000 | Typical notation for hexadecimal numbers (digits are 0 through F), for example used for addresses and offsets |
| 0b0000 | Same for binary numbers (digits are 0 and 1) |
| bold | Used to emphasize a word |
| Screen | Used for on-screen output and code related elements or commands in body text |
| Courier + Bold | Used to characterize user input and to separate it from system output |
| <i>Reference</i> | Used for references and for table and figure descriptions |
| File > Exit | Notation for selecting a submenu |
| <text> | Notation for variables and keys |
| [text] | Notation for software buttons to click on the screen and parameter description |
| ... | Repeated item for example node 1, node 2, ..., node 12 |
| . . . | Omission of information from example/command that is not necessary at the time being |
| .. | Ranges, for example: 0..4 means one of the integers 0,1,2,3, and 4 (used in registers) |
| | Logical OR |

Safety Notes

This section provides warnings that precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed during all phases of operation, service, and repair of this equipment. You should also employ all other safety precautions necessary for the operation of the equipment in your operating environment. Failure to comply with these precautions or with specific warnings elsewhere in this manual could result in personal injury or damage to the equipment.

Emerson intends to provide all necessary information to install and handle the product in this manual. Because of the complexity of this product and its various uses, we do not guarantee that the given information is complete. If you need additional information, ask your Emerson representative.

The product has been designed to meet the standard industrial safety requirements. It must not be used except in its specific area of office telecommunication industry and industrial control.

Only personnel trained by Emerson or persons qualified in electronics or electrical engineering are authorized to install, remove or maintain the product.

The information given in this manual is meant to complete the knowledge of a specialist and must not be used as replacement for qualified personnel.

Keep away from live circuits inside the equipment. Operating personnel must not remove equipment covers. Only factory authorized service personnel or other qualified service personnel may remove equipment covers for internal subassembly or component replacement or any internal adjustment.

Do not install substitute parts or perform any unauthorized modification of the equipment or the warranty may be voided. Contact your local Emerson representative for service and repair to make sure that all safety features are maintained.

Electrical Interference

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes or modifications not expressly approved by Emerson could void the user's authority to operate the equipment. A proper installation in a compliant system will maintain the required performance. Use only shielded cables when connecting peripherals to assure that appropriate radio frequency emissions compliance is maintained.

Operation

Product Damage

Surface

High humidity and condensation on the product surface causes short circuits. Do not operate the product outside the specified environmental limits. Make sure the product is completely dry and there is no moisture on any surface before applying power.

Overheating and Product Damage

Operating the product without forced air cooling may lead to overheating and thus damage of the product.

When operating the product, make sure that forced air cooling is available in the shelf.

Installation

Damage of Circuits

Electrostatic discharge and incorrect installation and removal of the product can damage circuits or shorten their life.

Before touching the product or electronic components, make sure that you are working in an ESD-safe environment.

Product Damage

Incorrect installation of the product can cause damage of the product.

Only use handles when installing/removing the product to avoid damage/deformation to the face plate and/or PCB.

Damage to Product/Backplane or System Components

Bent pins or loose components can cause damage to the product, the backplane, or other system components.

Therefore, carefully inspect the product and the backplane for both pin and component integrity before installation.

Emerson and our suppliers take significant steps to ensure there are no bent pins on the backplane or connector damage to the boards prior to leaving the factory. Bent pins caused by improper installation or by inserting boards with damaged connectors could void the Emerson warranty for the backplane or boards.

Configuration Switches

Malfunction of the Product

Switches marked as "Reserved" might carry production-related functions and can cause the product to malfunction if their setting is changed.

Therefore, do not change settings of switches marked as "reserved".

Damage of the Product

Setting/resetting the switches during operation can cause damage of the product.

Therefore, check and change switch settings before you install the product.

Cabling and Connectors

Product Damage

The RJ-45 connector(s) on the face plate are BITS interfaces. Connecting a telephone to such a connector may destroy your telephone as well as the product.

Make sure that BITS connectors near your working area are clearly marked as network connectors. In addition, observe the following safety notes:

- Verify that the length of an electric cable connected to a BITS bushing does not exceed 100 m.
- Make sure the BITS bushing of the system is connected only to Telecommunication Network Voltage level 1 (TNV-1) circuits.

If in doubt, ask your system administrator.

Environment

Always dispose of used modules, system components and RTMs according to your country's legislation and manufacturer's instructions.

Sicherheitshinweise

Dieses Kapitel enthält Hinweise, die potentiell gefährlichen Prozeduren innerhalb dieses Handbuchs vorrangestellt sind. Beachten Sie unbedingt in allen Phasen des Betriebs, der Wartung und der Reparatur des Systems die Anweisungen, die diesen Hinweisen enthalten sind. Sie sollten außerdem alle anderen Vorsichtsmaßnahmen treffen, die für den Betrieb des Produktes innerhalb Ihrer Betriebsumgebung notwendig sind. Wenn Sie diese Vorsichtsmaßnahmen oder Sicherheitshinweise, die an anderer Stelle dieses Handbuchs enthalten sind, nicht beachten, kann das Verletzungen oder Schäden am Produkt zur Folge haben.

Emerson ist darauf bedacht, alle notwendigen Informationen zum Einbau und zum Umgang mit dem Produkt in diesem Handbuch bereit zu stellen. Da es sich jedoch um ein komplexes Produkt mit vielfältigen Einsatzmöglichkeiten handelt, können wir die Vollständigkeit der im Handbuch enthaltenen Informationen nicht garantieren. Falls Sie weitere Informationen benötigen sollten, wenden Sie sich bitte an die für Sie zuständige Geschäftsstelle von Emerson.

Das System erfüllt die für die Industrie geforderten Sicherheitsvorschriften und darf ausschließlich für Anwendungen in der Telekommunikationsindustrie und im Zusammenhang mit Industriesteuerungen verwendet werden.

Einbau, Wartung und Betrieb dürfen nur von durch Emerson ausgebildetem oder im Bereich Elektronik oder Elektrotechnik qualifiziertem Personal durchgeführt werden. Die in diesem Handbuch enthaltenen Informationen dienen ausschließlich dazu, das Wissen von Fachpersonal zu ergänzen, können dieses jedoch nicht ersetzen.

Halten Sie sich von stromführenden Leitungen innerhalb des Produktes fern. Entfernen Sie auf keinen Fall Abdeckungen am Produkt. Nur werksseitig zugelassenes Wartungspersonal oder anderweitig qualifiziertes Wartungspersonal darf Abdeckungen entfernen, um Komponenten zu ersetzen oder andere Anpassungen vorzunehmen.

Installieren Sie keine Ersatzteile oder führen Sie keine unerlaubten Veränderungen am Produkt durch, sonst verfällt die Garantie. Wenden Sie sich für Wartung oder Reparatur bitte an die für Sie zuständige Geschäftsstelle von Emerson. So stellen Sie sicher, dass alle sicherheitsrelevanten Aspekte beachtet werden.

EMV

Das Produkt wurde in einem Emerson Standardsystem getestet. Es erfüllt die für digitale Geräte der Klasse A gültigen Grenzwerte in einem solchen System gemäß den FCC-Richtlinien Abschnitt 15 bzw. EN 55022 Klasse A. Diese Grenzwerte sollen einen angemessenen Schutz vor Störstrahlung beim Betrieb des Produktes in Gewerbe- sowie Industriegebieten gewährleisten.

Das Produkt arbeitet im Hochfrequenzbereich und erzeugt Störstrahlung. Bei unsachgemäßem Einbau und anderem als in diesem Handbuch beschriebenen Betrieb können Störungen im Hochfrequenzbereich auftreten.

Warnung! Dies ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funkstörungen verursachen. In diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen durchzuführen.

Operation

Beschädigung des Produktes

Hohe Luftfeuchtigkeit und Kondensat auf der Oberfläche des Blades können zu Kurzschlüssen führen.

Betreiben Sie das Produkt nur innerhalb der angegebenen Grenzwerte für die relative Luftfeuchtigkeit und Temperatur. Stellen Sie vor dem Einschalten des Stroms sicher, dass sich auf dem Produkt kein Kondensat befindet.

Überhitzung und Beschädigung des Blades

Betreiben Sie das Blade ohne Zwangsbelüftung, kann das Blade überhitzt und schließlich beschädigt werden.

Bevor Sie das Blade betreiben, müssen Sie sicher stellen, dass das Shelf über eine Zwangskühlung verfügt.

Installation

Beschädigung von Schaltkreisen

Elektrostatische Entladung und unsachgemäßer Ein- und Ausbau von Blades kann Schaltkreise beschädigen oder ihre Lebensdauer verkürzen.

Bevor Sie Blades oder elektronische Komponenten berühren, vergewissern Sie sich, dass Sie in einem ESD-geschützten Bereich arbeiten.

Beschädigung des Produktes

Fehlerhafte Installation des Produktes kann zu einer Beschädigung des Produktes führen.

Verwenden Sie die Handles, um das Produkt zu installieren/deinstallieren. Auf diese Weise vermeiden Sie, dass das Front Panel oder die Platine deformiert oder zerstört wird.

Beschädigung des Produktes, der Backplane oder von System Komponenten

Verbogene Pins oder lose Komponenten können zu einer Beschädigung des Produktes, der Backplane oder von Systemkomponenten führen.

Überprüfen Sie daher das Produkt sowie die Backplane vor der Installation sorgfältig und stellen Sie sicher, dass sich beide in einwandfreien Zustand befinden und keine Pins verbogen sind.

Emerson und unsere Zulieferer unternehmen größte Anstrengungen um sicherzustellen, dass sich Pins und Stecker von Boards vor dem Verlassung der Produktionsstätte in einwandfreiem Zustand befinden. Verbogene Pins, verursacht durch fehlerhafte Installation oder durch Installation von Boards mit beschädigten Steckern kann die durch Emerson gewährte Garantie für Boards und Backplanes erlöschen lassen.

Schaltereinstellungen

Fehlfunktion des Produktes

Schalter, die mit 'Reserved' gekennzeichnet sind, können mit produktionsrelevanten Funktionen belegt sein. Das Ändern dieser Schalter kann im normalen Betrieb Störungen auslösen.

Verstellen Sie nur solche Schalter, die nicht mit 'Reserved' gekennzeichnet sind. Prüfen und ggf. ändern Sie die Einstellungen der nicht mit 'Reserved' gekennzeichneten Schalter, bevor Sie das Produkt installieren.

Beschädigung des Produktes

Das Verstellen von Schaltern während des laufenden Betriebes kann zur Beschädigung des Produktes führen.

Prüfen und ändern Sie die Schaltereinstellungen, bevor Sie das Produkt installieren.

Kabel und Stecker

Beschädigung des Produktes

Die RJ-45-Stecker an der Frontblende sind BITS-Schnittstellen. Der Anschluss eines Telefones an die RJ-45-Stecker kann sowohl das Telefon als auch das Produkt zerstören.

Stellen Sie daher sicher, dass BITS-Stecker an Ihrem Arbeitsplatz eindeutig als Netzwerkstecker gekennzeichnet sind. Beachten Sie ferner die folgenden Sicherheitsweise:

- Stellen Sie sicher, dass die Länge eines Kabels, welches an den BITS-Stecker angeschlossen ist, 100 m nicht überschreitet.
- Stellen Sie sicher, dass der BITS-Stecker ausschließlich mit einem TNV-1 Stromkreis verbunden ist.
- Wenden Sie sich bei Fragen an ihren Systemadministrator.

Umweltschutz

Entsorgen Sie alte Batterien und/oder Blades/Systemkomponenten/RTMs stets gemäß der in Ihrem Land gültigen Gesetzgebung und den Empfehlungen des Herstellers.

1.1 Features

The Clock Generator Module (PMC-CGM) is a PMC module which is either available together with the Emerson ATCA-F103 switch or as part of an accessory kit. It can only be used in conjunction with the ARTM-F103-STX.

The PMC-CGM is delivered with payload software which lets you configure and monitor the clock synchronization via SNMPv2 and Management Information Bases (MIBs). You may use the software as an interface to write a higher-level clock manager software.

The PMC-CGM serves the following purposes:

- Synchronizes to a reference clock (line card clock CLK3, aka. REFA/REFB or external E1/T1 clock) and provides a system clock (CLK1/CLK2) in an AdvancedTCA chassis and to up to two extension shelves.
- Acts as temporary stand-alone clock source if all reference clocks failed while maintaining clock phase and frequency as long as possible ("holdover mode").
This is accomplished by measuring the reference clock against a high-precision oscillator and calculating the frequency/phase offset to be applied when the reference clock fails.

The hardware/firmware is designed so that two clock modules form a protection (master/slave) pair. If the master module fails, the slave module takes over seamlessly without disturbing the system clocks.


For a PMC-CGM support on the ATCA-F103, the following software versions (or higher) are required on the ATCA-F103:

- Application: 4.0.629
- IPMI firmware: 1.03.082
- Bootloader: 4.0.629

For more details on the clocking concept used in your system refer to the *Centellis CO 31kX Installation and Use* manual.

The following graphic shows the PMC-CGM.

Figure 1-1 PMC-CGM



1.2 Standard Compliances

The PMC-CGM, when installed in a compliant chassis, meets the following standards:

Table 1-1 Standard Compliances and Clocking Standards

| Standard | Description |
|--|---|
| UL 60950-1, EN 60950-1, IEC 60950-1 CAN/CSA C22.2 No 60950-1 | Legal safety requirements |
| CISPR 22 CISPR 24 EN 55022 EN 55024 FCC Part 15 Industry Canada ICES-003 VCCI Japan AS/NZS CISPR 22 EN 300 386 NEBS Standard GR-1089 CORE | Legal EMC requirements on system level (predefined Emerson system) |

Table 1-1 Standard Compliances and Clocking Standards (continued)

| Standard | Description |
|---|---|
| G.703 | BITS interface |
| G.813 TR-1244 | Clock quality |
| ANSI/IPC-A610 Rev.C Class 2 ANSI/IPC-7711 ANSI/IPC-7721 ANSI-J-001...003 | Manufacturing requirements |
| NEBS Standard GR-63-CORE ETSI EN 300 019 series | Environmental requirements |
| PICMG 3.0 R1.0 | Defines mechanics, blade dimensions, power distribution, power and data connectors, and system management |



The product has been designed to meet the directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) Directive 2002/95/EC.

1.3 Ordering Information

As of the printing date of this manual, this guide supports the boards model listed below.

Table 1-2 Available Board Variants

| Order Number | Description |
|--------------|---|
| PMC-CGM2 | TELECOM CLOCK GENERATOR MODULE FOR ATCA-F103 (RoHS 6/6) |

2.1 Overview

In this section, you can find information on the following topics:

- Things to observe before the installation
- Installation procedure
- Available accessories

2.2 Before Installation

This section provides the following information:

- Unpacking and inspecting the module
- Requirements

2.2.1 Unpacking and Inspecting the Module

NOTICE

Damage of Circuits

Electrostatic discharge and incorrect module installation and removal can damage circuits or shorten their life.

Before touching the module or electronic components, make sure that you are working in an ESD-safe environment.

Shipment Inspection

To inspect the shipment, perform the following steps.

1. Verify that you have received all items of your shipment:
 - Printed user manual
 - PMC-CGM module
 - Any optional items ordered

2. Check for damage and report any damage or differences to the customer service.
3. Remove the desiccant bag shipped together with the module and dispose of it according to your country's legislation.



The product is thoroughly inspected before shipment. If any damage occurred during transportation or any items are missing, please contact our customer's service immediately.

2.2.2 Requirements

Before you power up the module, calculate the power needed according to your system configuration.

2.2.2.1 Environmental Requirements

You must make sure that the board, when operated in your particular system configuration, meets the environmental requirements specified below.



Operating temperatures refer to the temperature of the air circulating around the board and not to the component temperature.

NOTICE

Board Damage

High humidity and condensation on the board surface causes short circuits. Do not operate the board outside the specified environmental limits. Make sure the board is completely dry and there is no moisture on any surface before applying power.

Table 2-1 Environmental Requirements

| Feature | Operating | Non-Operating (packed state) |
|--|---|---|
| Temperature | +5°C (+41°F) to +40°C (+104°F) (normal operation) according to NEBS Standard GR-63-CORE -5°C (+23°F) to +55°C (+131°F) (exceptional operation) according to NEBS Standard GR-63-CORE | -40°C (-40°F) to +85°C (+185°F) |
| Temp. change | +/- 0.25°C/min according to NEBS Standard GR-63-CORE | +/- 0.25°C/min |
| Relative humidity | 5% to 90% non-condensing according to Emerson-internal environmental requirements | 5% to 95% non-condensing according to Emerson-internal environmental requirements |
| Vibration (tested in target platform) | 0.1 g from 5 to 100 Hz and back to 5 Hz at a rate of 0.1 octave/minute. | 5-20 Hz at 0.01 g ² /Hz 20-200 Hz at -3.0 dB/octave Random 5-20 Hz at 1 m ² /Sec ³ Random 20-200 Hz at -3 dB/octave |
| Shock | Half-sine, 11 mSec, 30 m/Sec ² | Blade level packaging Half-sine, 6 mSec at 180 m/Sec ² |
| Free fall | - | 200 mm/all edges and corners 1.0 m (packaged) per ETSI 300 019-2-2 (Blade level packaging) 100 mm (unpackaged) per GR-63- CORE |

2.2.2.2 Power Requirements

Make sure that the module is only used on an ATCA-F103 blade in an AdvancedTCA shelf connected to -48VDC up to -60VDC (rated voltage), according to Telecommunication Network Voltage (TNV-2).

A TNV-2 circuit is a circuit whose normal operating voltages exceed the limits for a safety-extra-low-voltage (SELV) under normal operating conditions, and which is not subject to overvoltages from telecommunication networks.


Table 2-2 DC Module Power Requirements

| Feature | Value |
|---------------------------|------------|
| Rated Voltage | 3.3V |
| Operating Voltage | 3.3V +/-3% |
| Input current | 1.5A |
| PMC-CGM power dissipation | 5W (max.) |

2.3 Configuring the Module

The module provides the configuration switch SW1 as shown in the following figure. The switch settings shown in the figure correspond to the default settings. The switches are displayed as the small white squares.

Figure 2-1 Switch Location



NOTICE

Product Malfunction

Switches marked as 'reserved' might carry production-related functions and can cause the product to malfunction if their setting is changed. Therefore, do not change settings of switches marked as 'reserved'. The setting of switches which are not marked as 'reserved' has to be checked and changed before product installation.

Product Damage

Setting/resetting the switches during operation can cause product damage. Therefore, check and change switch settings before you install the product.


Table 2-3 Switch Settings

| Switch | Description |
|--------|---|
| SW1-1 | Reserved (OFF: default value) |
| SW1-2 | Reserved (OFF: default value) |
| SW1-3 | Restores default static IP addresses OFF: Dynamic IP addresses are assigned by the ATCA-M100, for details refer to Table "MIB Browser Settings" on page 37 (default) ON: Static IP addresses are assigned 192.168.21.40: acces via ETHA on ARTM-F103-STX 192.168.22.40: acces via ETHB on ARTM-F103-STX |
| SW1-4 | Reserved (OFF: default value) |

2.4 Installing and Removing the Module

The PMC-CGM can be installed on the PMC slot of the AdvancedTCA ATCA-F103 blade.

Figure 2-2 Location of PMC Slot on ATCA-F103



Before installing an PMC module observe the following notes.



- **To ensure proper EMC shielding, either operate the blade with the PMC-CGM module installed or with a blind panel.**
- **If the blade is upgraded with a PMC module, ensure that the blind panel is stored in a safe place in order to be reused again when removing the PMC module.**

Installation Procedure

To install the PMC module, proceed as follows:

1. Remove the blind panel from the PMC slot of the ATCA-F103.
2. Store the blind panel in a safe place.
3. Connect the PMC module carefully to the PMC slot.
4. Make sure that standoffs of the PMC module cover the mounting holes of the blade.
5. Place the screws delivered with the PMC module into the mounting holes of the blade (from the back side of the blade).
6. Fasten screws.
7. Connect interface cables as required - for more information refer to the *ARTM-F103-STX Installation and Use* manual.

Removal Procedure

To remove a PMC module, proceed as follows:

1. Remove interface cables, if applicable.
2. Remove screws from back side of the blade's PMC slot.
3. Disconnect PMC module carefully from the PMC slot.
4. Install the blind panel.

2.5 Hardware Upgrades and Accessories

In multi-shelf configurations, you need a clock distribution cable. Emerson offers an accessory kit which contains a category 5 cable of 10 m length. For more information refer to the *CABLE-CGM2-CLK Installation and Use* manual.

3.1 Overview


This chapter describes:

- Layout
- Front panel connectors and LEDs

3.2 Layout

The following figure shows the main components of the PMC-CGM.

Figure 3-1 Module Layout




3.3 Front Panel Connectors and LEDs

At the front panel of the PMC-CGM, there are the two RJ-45 connectors for the Building Integrated Timing Source (BITS) interfaces and six LEDs.

The Ethernet ports for the PMC-CGM are located on the ARTM-F103.

Figure 3-2 Front Panel



3.3.1 BITS Interface Connectors

The module provides two RJ-45 BITS front panel connectors.

NOTICE


Product Damage

The RJ-45 connector(s) on the face plate are BITS interfaces. Connecting a telephone to such a connector may destroy your telephone as well as the product.

Make sure that BITS connectors near your working area are clearly marked as network connectors. In addition, observe the following safety notes:


- Verify that the length of an electric cable connected to a BITS bushing does not exceed 100 m.
- Make sure the BITS bushing of the system is connected only to Telecommunication Network Voltage level 1 (TNV-1) circuits. If in doubt, ask your system administrator.

Figure 3-3 BITS Connector Location



You can find the signal description of the the BITS connectors in the following figure where x is the number of the BITS connector.


Figure 3-4 BITS Connector Pin Assignment



3.3.2 LEDs

The product provides the following LEDs.

Figure 3-5 LED Location



You can find a description of the LEDs in the following table.

Table 3-1 LED Description

| Name | Description |
|------|---|
| B1 | BITS Interface 1 Status Green: BITS interface 1 is in use and status is okay Orange: BITS interface 1 is in use and status is not okay Red: : BITS interface 1 is out-of-service OFF: Not defined |
| B2 | BITS Interface 2 Status Green: BITS interface 2 is in use and status is okay Orange: BITS interface 2 is in use and status is not okay Red: : BITS interface 2 is out-of-service OFF: Not defined |
| M/S | Master/Slave Operation Green: PMC-CGM operates as Master Amber: Not defined Yellow: PMC-CGM operates as Slave OFF: PMC-CGM is non-operational (by application) |
| Mode | Mode Green: PMC-CGM operates in locked mode Amber: PMC-CGM operates in holdover mode Yellow: PMC-CGM operates in free-run mode OFF: not defined |
| OOS | Out-Of-Service Red: PMC-CGM is out-of-service Off: Not defined |
| IS | In Service Green: PMC-CGM is in service Off: Not defined |

4.1 Overview

In this chapter, you can find information on the following topics:

- How to access the module.
- What to observe when using a MIB browser.
- How to configure the module.

4.2 Accessing the PMC-CGM


To access the module you have to provide the necessary cabling and then use IPMI or a MIB browser to access to the module, for details refer to the following sections.

4.2.1 Cabling

To access the PMC-CGM, you have to attach an Ethernet cable to the ARTM-F103-STX as shown in the following graphic.

It is mandatory that you connect port ETH7 with ETHA on the same ARTM-F103-STX and that you cross-connect ETH8 with ETHB on the peer ARTM-F103-STX as indicated below.

Figure 4-1 Connecting the ARTM-F103-STX Ethernet Ports



4.2.2 Access

To access the module you can either use IPMI or a MIB browser.

For details on how to access the module via IPMI refer to the *PMC-CGM: Control via IPMI Programmer's Reference*.

When using a MIB browser, you have to specify the settings described in [Using a MIB Browser on page 37](#).

4.3 Using a MIB Browser

When you are using a MIB browser to configure the PMC-CGM, you have to use the following settings.

Table 4-1 MIB Browser Settings

| Setting | Value |
|--|---|
| Read community | Public |
| Write community | Public |
| Dynamic IP addresses assigned by ATCA-M100 | 172.17.<SGA>.18: acces via ETHA on left ARTM-F103-STX 172.18.<SGA>.18: acces via ETHB on left ARTM-F103-STX 172.17.<SGA>.28: acces via ETHB on right ARTM-F103-STX 172.18.<SGA>.28: acces via ETHA on right ARTM-F103-STX The first three octets of the IP addresses correspond to the first three octets of the shelf manager IP connection record (SMICR) which is part of the chassis FRU. It can be extracted by the ShM of your system. For details of the SMICR refer to the <i>PICMG 3.0 Rev. 1.0 AdvancedTCA Base Specification</i> . |



All changes that you apply via the MIB browser are volatile, that means they are lost when the module is rebooted. The only exception is the `cgmBootString` (OID:.1.3.6.1.4.1.3656.8152.1.3.33) object, which is stored in the NVRAM.

4.4 Configuring the PMC-CGM

To configure the PMC-CGM, you can perform the following tasks which are described in detail in the following sections.

- Define the IP address of the protection partner module
- Define SNMP trap destinations
- Configure the interface mode - SDH/E1 versus SONET/T1
- Configure the BITS interface
- Configure the initial master/slave role
- Setup a multishelf configuration
- Configure the reference clock
- Upgrade the firmware/software
- Reset the PMC-CGM
- Configure parameters for event handling

You can perform these tasks independently from each other.

4.4.1 Define IP Address of the Protection Partner Module

The PMC-CGM modules usually work in a master/slave configuration. The protection partner is the other PMC-CGM module, regardless of the master/slave role. The default partner address is configured according to the IP address configuration described in [Table "MIB Browser Settings" on page 37](#).

Defining the IP address of the protection partner module

To define the IP address via the MIB, process as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. In object `cgmProtectionPartnerAddress` OID: `.1.3.6.1.4.1.3656.8152.1.1.22.0` set the IP address of the partner PMC-CGM module.

4.4.2 Define SNMP Trap Destinations

The PMC-CGM firmware keeps an event log which captures errors, warnings and informative messages in a RAM buffer. The event log can always be accessed via SNMP. Additionally, it is possible to configure the firmware so that each entry up to a certain severity level is posted as an SNMP trap to a specified destination.

Defining SNMP Trap Destinations

To define SNMP trap destinations, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to object `cgmBootString` OID: `.1.3.6.1.4.1.3656.8152.1.3.33`.
4. Enter IP address to which the SNMP traps have to be sent in the `h|host|trapDest` parameter.
This setting is stored persistently in the NVRAM of the module and is applied after the next reboot.
5. Go to object `cgmTrapDestination` OID: `.1.3.6.1.4.1.3656.8152.1.3.32.0`.
6. Enter IP address to which the SNMP traps have to be sent.
This setting is only valid until the next reboot. After the reboot, the default IP address defined via the `cgmBootString` object is applied.

4.4.3 Configure the Interface Mode

You can choose between SONET/T1 and SDH/E1 mode via the MIB object `cgmlInterfaceMode` OID: `.1.3.6.1.4.1.3656.8152.1.1.10.0`. The modes are used in different regions.

Table 4-2 Interface Modes

| Mode Type | MIB Value | Purpose |
|-----------|-------------|-------------|
| SONET/T1 | 0 | USA |
| SDH/E1 | 1 (default) | Europe/Asia |

This entry determines whether an input frequency of 1544KHz (Sonet/T1) or 2048KHz (SDH/E1) can be selected for the `cgmlInputFrequency` object (OID: `.1.3.6.1.4.1.3656.8152.1.1.1.1.3`).

Configuring the interface mode

To configure the interface mode of the PMC-CGM, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to object `cgmlInterfaceMode` OID: `.1.3.6.1.4.1.3656.8152.1.1.10.0`.
4. Check whether the default value meets your requirements. Otherwise, change the value as required.

4.4.4 Configure the BITS Interface

The interface mode determines whether the BITS interface operates in E1 (default value) or T1 mode.

Configuring the BITS interface

To set the line type and line code of the BITS interface, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. In `cgmlBitsTable` OID: `.1.3.6.1.4.1.3656.8152.1.1.2` go to object `dsx1LineCode` OID: `.1.3.6.1.4.1.3656.8152.1.1.2.1.5` and select desired line code value.
For details on the available values refer to [Table "cgmlBitsTable" on page 49](#).
4. In `cgmlBitsTable` OID: `.1.3.6.1.4.1.3656.8152.1.1.2` go to object `dsx1LineType` OID: `.1.3.6.1.4.1.3656.8152.1.1.2.1.4` and select desired line type value.
For details on the available values refer to [Table "cgmlBitsTable" on page 49](#).

4.4.5 Configure Initial Master/Slave Role

After the initial configuration, the master/slave roles are handled by the DPLL software that runs on the processor of the PMC-CGM.

Configuring the initial master/slave roles

To configure the initial master/slave roles, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Check the master/slave role of the current PMC-CGM module in the `cgmProtectionState` object OID: 1.3.6.1.4.1.3656.8152.1.1.19.0.
The following values are possible: 0 (standaloneMaster: Communication with the partner is not possible and the module is running in master mode.), 1 (slave), 2 (master).
4. Adapt the master/slave role of the current PMC-CGM module, if necessary, in the `cgmProtectionCmd` object OID: 1.3.6.1.4.1.3656.8152.1.1.20.0.
The following values are possible:
0 - Attempt to become master. This is only possible if a valid clock input is present.
1 - Give up mastership to the protection partner. This is only possible if the partner (slave) has a valid input other than MS_SYNC.
5. Check whether the role change was successful in the `cgmProtectionState` object OID: 1.3.6.1.4.1.3656.8152.1.1.19.0.

4.4.6 Setup Multi-Shelf Configuration

You have to define the number of extension shelves, up to two extension shelves are possible.

Setting up a multi-shelf configuration

To set up a multi-shelf configuration, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to `cgmExtChConnection` object OID: 1.3.6.1.4.1.3656.8152.1.4.11.0.
4. Select the properties of the connections to extension chassis 2 and 3.
The following values are possible:
Single Chassis (0) - default value
Chassis 2 in extension mode (1)
Chassis 3 in extension mode (3)
Chassis 2&3 in extension mode (5)

4.4.7 Configure the Reference Clock

You can define the reference clock source, the frequency and the priority of the reference clock inputs. For a description of the respective MIB objects refer to [Table "cgmInputTable" on page 47](#).

Reference clock sources are:

- BITS interface 1 (input 3, frequency automatically configured via interface mode)
- BITS interface 2 (input 4, frequency automatically configured via interface mode)
- Linecard reference clock A (input 7)
- Linecard reference clock B (input 12)

For the slave, the reference clock is always the Master/Slave synchronization clock. This is automatically configured.

When you initially assign priorities, we recommend to start with the highest priority input. Otherwise, the PLL may switch inputs unnecessarily or end up locked on a low-priority input while a higher priority input is also valid.

If you want to change the selected PLL input by changing the priority, you have to change to revertive mode first (cgmProtectionRevertiveModeState OID:.1.3.6.1.4.1.3656.8152.1.1.18.0).

Configuring the reference clock source for the T0/T4 path

To configure the reference clock, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to cgmInputFrequency object OID:.1.3.6.1.4.1.3656.8152.1.1.1.1.3.<instance number which is equal to input number -1>.
4. Select the desired input frequency.
The following values are possible:
 - 0: 8 KHz
 - 1: 1544 KHz / 2048 KHz, depending on E1/T1 operation.
 - 3: 19.44 MHz
5. Go to cgmT0InputPriority object OID:.1.3.6.1.4.1.3656.8152.1.1.1.1.4.<instance number which is equal to input number -1>.
6. Select the desired input priority.
A priority value from 2 to 15 is used by the T0 PLL to select an input. A lower numerical value means a higher priority. A value of 0 disables the input, that means it will not be selected as reference clock. A value of 1 cannot be set as it is used for the master/slave synchronization clock.
Default value is 0.
This setting is applied to the protection partner as well.

7. For the T4 path, repeat steps 5 and 6 with the cgmT4InputPriority object
OID: 1.3.6.1.4.1.3656.8152.1.1.1.1.5.<instance number which is equal to input
number -1>.
8. Go to cgmlnputRefASource object OID: 1.3.6.1.4.1.3656.8152.1.4.16.0.
9. Select the source (chassis) of the primary linecard derived reference clock.
The following values are possible:
local reference A (0) - default value
local reference B (1)
Chassis 2 reference A (2)
Chassis 2 reference B (3)
Chassis 3 reference A (4)
Chassis 3 reference B (5)
10. Go to cgmlnputRefBSource object OID: 1.3.6.1.4.1.3656.8152.1.4.18.0.
11. Select the source of the "secondary" linecard derived reference clock (REFB input
to PLL). Not relevant for distributed mode.
local reference A (0)
local reference B (1) - default value
Chassis 2 reference A (2)
Chassis 2 reference B (3)
Chassis 3 reference A (4)
Chassis 3 reference B (5)

4.4.8 Perform Firmware/Software Upgrade

You can upgrade the firmware/software of the PMC-CGM via the MIB. The firmware/software upgrade is done by downloading an image from a TFTP server and programming it into the inactive partition of the boot flash (that means not the one which is currently running) which is split into two partitions of 32MB each. By default, only one of the two partitions (the active partition) is accessible.

Upgrading the firmware/software

To upgrade the firmware/software, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to object cgmFwUpdateHost OID: 1.3.6.1.4.1.3656.8152.1.3.26.0.
4. Enter the IP address of the TFTP server that contains the new image.
5. Go to object cgmFwUpdateFile OID: 1.3.6.1.4.1.3656.8152.1.3.27.0.
6. Enter the file that contains the new image.
7. Go to object cgmFwUpdateMd5 OID: 1.3.6.1.4.1.3656.8152.1.3.28.0.

8. Enter the checksum (hexadecimal format) of the new image which is contained in the .md5 file delivered together with the new image.
This checksum is verified after downloading the TFTP image and after programming it into the boot flash.
9. Go to the object `cgmFwUpdateOption` OID: 1.3.6.1.4.1.3656.8152.1.3.29.0.
10. Select how to handle revision numbers of the old and the new image.
The following values are possible:
"newer" (0): only images with a version number higher than the current one can be programmed.
"newerOrSame" (1): images with the same or a higher version number can be programmed.
"allowDowngrade" (2): downgrade is possible.
"noVersionCheck" (3): no version check is performed at all. This allows installing images which do not contain version information.
11. Go to the object `cgmFwUpdateStart` OID: 1.3.6.1.4.1.3656.8152.1.3.30.0.
12. Start the upgrade by setting the value `start` (1).
The upgrade takes about 3-4 minutes.
13. Check the progress of the upgrade by performing a walk on the `cgmEventDescr` object OID: 1.3.6.1.4.1.3656.8152.1.3.1.1.6.
14. Wait until the message "Firmware update successful" is displayed.
15. Reset the PMC-CGM to apply/boot the new image.
16. Optionally, you can now upgrade the backup partition as well by repeating this procedure.

4.4.9 Reset the PMC-CGM

You can reset the PMC-CGM module via IPMI or SNMP, both methods have the same reset level.

To reset the PMC-CGM via IPMI, the shelf manager issues the IPMI command "Cold Reset". Graceful Shutdown functionality is not implemented for the PMC-CGM.

Resetting the PMC-CGM via SNMP

To reset the module via SNMP, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to object `cgmRestartCmd` OID: 1.3.6.1.4.1.3656.8152.1.3.25.0.

4. Set object to restart (1).



While resetting the PMC-CGM, the clocks driven by the module are in an undefined state.

4.4.10 Configure Parameters for Event Handling

You can use the following elements as parameters to define how events are handled in your system.

- cgmSysEventLogSize
- cgmSysEventLogCount
- cgmSysEventLogClear
- cgmSysEventLogLevel
- cgmSysEventTrapLevel

You can find a detailed description of these elements in [Table "cgmSys Objects" on page 58](#).

Configuring event handling parameters

To configure the event handling, proceed as follows:

1. Start SNMP manager or MIB browser.
2. Connect to the PMC-CGM using one of its IP addresses.
3. Go to cgmSysEventLogSize object OID: 1.3.6.1.4.1.3656.8152.1.3.10.0.
It contains the maximum number of events the event log can hold.
4. Go to cgmSysEventLogCount object OID: 1.3.6.1.4.1.3656.8152.1.3.11.0.
It contains the current number of events present in the event log.
5. Go to cgmSysEventLogClear object OID: 1.3.6.1.4.1.3656.8152.1.3.12.0.
You can use this element to clear the event log.
When set to 0, events which have not been accessed will be cleared (an event is marked as "accessed" if its timestamp cgmEventTime is read).
If set to 1, all events are cleared regardless whether they have been accessed or not. This is not recommended since it may cause events to get lost while the log is about to be cleared.
6. Go to cgmSysEventLogLevel object OID: 1.3.6.1.4.1.3656.8152.1.3.13.0.
Specifies up to which severity events shall be placed into the event log:
0 - No events are logged
1 - Only critical events are logged

- 2 - Critical events and warnings are logged
 - 3 - Critical events, warning and events are logged
 - 4 - Everything is logged
- Default value is (3).

7. Check the default value and adapt it if necessary.
8. Go to cgmSysEventTrapLevel object OID:.1.3.6.1.4.1.3656.8152.1.3.14.0.
Specifies up to which severity new event log entries are posted as a trap (using the cgmLogEvent object).
 - 0 - No events are posted
 - 1 - Only critical events are posted
 - 2 - Critical events and warnings are posted
 - 3 - Critical events, warning and events are posted
 - 4 - Everything is posted

Default value is (3).
9. Check the default value and adapt it if necessary.

5.1 Overview

You can use the CGM-CONTROL-MIB to access and control the clock generator module PMC-CGM that is used in your AdvancedTCA system.

It is located at

.iso.org.dod.internet.private.enterprises.forceComputers.cgmControlMIB.motCgm (OID: .1.3.6.1.4.1.3656.8152.1).

The CGM-CONTROL-MIB contains the following three main branches.

Table 5-1 MIB Structure

| Branch | Used for... |
|------------|---|
| cgmControl | Controlling and configuring the BITS interfaces and the PLL |
| cgmSys | Maintianing the PMC-CGM (FW/SW upgrade, event log) |
| cgmClkDist | Distributing clocks in the chassis |

5.2 cgmControl

The cgmControl branch contains the following information:

- cgmInputTable - for details refer to [Table 5-2 on page 47](#).
For details on how to use these MIB objects refer to [Configure the Reference Clock on page 41](#).
- cgmBitsTable - for details refer to [Table 5-4 on page 49](#).
For details on how to use these MIB objects refer to [Configure the BITS Interface on page 39](#).
- Various MIB objects that are described in [Table 5-5 on page 53](#).
For details on how to use these MIB objects refer to [Configure the Interface Mode on page 39](#), [Configure Initial Master/Slave Role on page 40](#).

The cgmInputTable (OID: .1.3.6.1.4.1.3656.8152.1.1.1) uses the instance number as defined in [Table "Input Assignments" on page 48](#) as index.

Table 5-2 cgmInputTable

| OID | MIB Object | Description | Access |
|------------|--------------|---|--------|
| .1.1.1.1.2 | cgmInputName | Named source for this input. If the string is empty the input is not connected. | r |

Table 5-2 cgmInputTable (continued)

| OID | MIB Object | Description | Access |
|------------|------------------------------|---|--------|
| .1.1.1.1.3 | cgmInputFrequency | Configures the input frequency: 0: 8 KHz 1: 1544 KHz / 2048 KHz, depending on E1/T1 operation. 3: 19.44 MHz | r/w |
| .1.1.1.1.4 | cgmT0InputPriority | This setting is applied to the protection partner as well. A priority value from 2 to 15 used by the T0 PLL to select an input. A lower numerical value means a higher priority. A value of 0 disables the input, that means it will not be selected as reference clock. A value of 1 cannot be set as it is used for the master/slave synchronization clock. Default value is 0. | r/w |
| .1.1.1.1.5 | cgmT4InputPriority | Priority of frequency monitor (T4 Path). Lower numerical values represent a higher priority than greater values. A value of 0 means that the input will never be selected as active input. Default value is 0. | r/w |
| .1.1.1.1.6 | cgmInputState | Indicates whether the input receives a valid clock or not. | r/w |
| .1.1.1.1.7 | cgmInputActivityMonitorEna | Controls whether the activity monitor for this input is enabled. | r/w |
| .1.1.1.1.8 | cgmInputActivityMonitorState | Reports the state of the activity monitor for this input. | r |

Table 5-3 Input Assignments

| Instance | cgmInputNumber | cgmInputName | Default cgmInputFrequency |
|----------|----------------|--------------|---------------------------|
| 2 | 3 | BITS1 | freqE1T1 (1) |
| 3 | 4 | BITS2 | freqE1T1 (1) |
| 6 | 7 | REFA | freq8K (0) |
| 10 | 11 | MS_SYNC | freq8K (0) |
| 11 | 12 | REFB | freq8K (0) |

The cgmBitsTable (OID: .1.3.6.1.4.1.3656.8152.1.1.2) uses bitsInterfaceNumber as index.

Table 5-4 cgmBitsTable

| OID | MIB Object | Description | Access |
|------------|---------------------|---|--------|
| .1.1.2.1.1 | bitsInterfaceNumber | 0 for BITS interface 1 1 for BITS interface 2 | r |
| .1.1.2.1.2 | bitsEnable | Enables (0) or disables (1) a BITS interface. Enabling the interface also applies various default parameters, depending on the operation mode defined in <cgmInterfaceMode>: E1/SDH Mode: - <dsx1LineType> is <dsx1E1> - <dsx1LineCode> is <dsx1HDB3> -< bitsLiuE1Lbo> is <o120> T1/Sonet Mode: - <dsx1LineType> is <dsx1D4> - <dsx1LineCode> is <dsx1B8ZS> - <bitsLiuT1Lbo> is <ft0to133> Default value is enabled (0). | r/w |
| .1.1.2.1.3 | bitsTxEnable | Enables/disables the line interface transmitter. Default value is enabled (1). | r/w |
| .1.1.2.1.4 | dsx1LineType | Line type configuration. The allowed settings depend on the module's interface mode: Applicable for E1: - dsx1E1 (value 4, default) - dsx1E1CRCMF (value 7) - dsx1E1G703 (value 12) - dsx1E1UnframedAll1 (value 9) (Setting this line type is equivalent to Transmit AIS in E1 mode.) - dsx1E1UnframedAlt (value 11, 0101... pattern) Applicable for T1: - dsx1D4 (value 3, default) - dsx1ESF (value 2) - dsx1UnframedAll1 (value 8) - dsx1UnframedAlt (value 10, 0101.. pattern) | r/w |
| .1.1.2.1.5 | dsx1LineCode | E1/T1 Line code. Applicable for E1: - dsx1HDB3 (default) - dsx1AMI Applicable for T1: - dsx1B8ZS (default) - dsx1AMI | r/w |

Table 5-4 cgmBitsTable (continued)

| OID | MIB Object | Description | Access |
|-------------|--------------------|--|--------|
| .1.1.2.1.6 | dsx1LoopbackConfig | Loopback mode Loopback mode disabled (1) local (payload) loopback - Tx to Rx (2) line loopback - Rx to Tx (3) Default value is disabled (1). | r/w |
| .1.1.2.1.7 | dsx1LineStatus | Current line status. This is a bit mask encoding the following states: -Bit 0 (value 0x01): Yellow alarm condition -Bit 3 (value 0x08): Alarm condition -Bit 5 (value 0x20): Loss of Frame condition -Bit 6 (value 0x40): Loss of Signal condition | r |
| .1.1.2.1.10 | bitsCurSsm | The last received synchronization status message Not yet supported | r |
| .1.1.2.1.11 | bitsSsmE1SaSelect | Selects on which Sa bit the E1 synchronization status message is expected. Default value is (4). Not yet supported | r/w |
| .1.1.2.1.13 | bitsLiuJaEn | Enable jitter attenuator Default value is disabled (0). | r/w |
| .1.1.2.1.14 | bitsLiuJaDs | Jitter attenuator depth (32 or 128 bits) Default value is 128 bits (0). | r/w |
| .1.1.2.1.16 | bitsLiuEgl | Receive equalizer gain limit for T1 (-36/-15dB) and E1 (-43/-12dB) Default value is (0). | r/w |
| .1.1.2.1.18 | bitsLiuE1Lbo | E1 line build-out select in Ohm (without and with high return loss) 120 Ohm (1) 120 Ohm with high return loss (3) Default value is (1). | r/w |
| .1.1.2.1.19 | bitsLiuT1Lbo | T1 line build-out select for DSX-1 application in feet. 0 to 133 ft (0) 133 to 266 (1) 266 to 399 (2) 399 to 533 (3) 533 to 655 (4) Default value is (0). | r/w |

Table 5-4 cgmBitsTable (continued)

| OID | MIB Object | Description | Access |
|-------------|----------------|---|--------|
| .1.1.2.1.35 | bitsLiuRxLevel | Receive level in dB 2.5 (0) 5.0 (1) 7.5 (2) 10.0 (3) 12.5 (4) 15.0 (5) 17.5 (6) 20.0 (7) 22.5 (8) 25.0 (9) 27.5 (10) 30.0 (11) 32.5 (12) 35.0 (13) 37.5 (14) 40.0 (15) | r |
| .1.1.2.1.63 | bitsT1RxSync | Resynchronization criteria. In D4 framing mode: - opt1 (0): search for Ft pattern, then search for Fs pattern opt2 (1): cross couple Ft and Fs pattern In ESF Framing mode: opt1 (0): search for FPS pattern only opt2 (1): search for FPS and verify with CRC6. Default value is (0). | r/w |
| .1.1.2.1.69 | bitsT1TxYel | Setting this object to on (1), causes the yellow alarm to be transmitted. Default value is (0). | r/w |
| .1.1.2.1.73 | bitsT1TxB7zs | Transmit-side bit 7 zero-suppression enable (bit 7 forced to a 1 in channels with all 0s) Default value is (0). | r/w |
| .1.1.2.1.75 | bitsT1TxFbCT1 | Causes the next three consecutive Ft (D4 framing mode) or FPS (ESF framing mode) bits to be corrupted causing the remote end to experience a loss of frame (loss of synchronization) Default value is (0). | r/w |
| .1.1.2.1.80 | bitsT1TaisCi | Transmit AIS-CI Setting this causes the AIS-CI code to be transmitted, as defined in ANSI T1.403 Default value is (0). | r/w |

Table 5-4 cgmBitsTable (continued)

| OID | MIB Object | Description | Access |
|--------------|-----------------------|---|--------|
| .1.1.2.1.81 | bitsT1TraiCi | Transmit RAI-CI Setting this bit causes the ESF RAI-CI code to be transmitted in the FDL bit position. Default value is (0). | r/w |
| .1.1.2.1.91 | bitsE1RxSyncC | Frame resynchronization criteria Default value is (0). | r/w |
| .1.1.2.1.112 | bitsT3ClkForce | When set to (1), it, forces the T3 clock output from the framer to be output to the PLL even if no signal is present. This should only be set for test purposes since the framer will generate a free-running clock in the absence of a valid input. Default value is (0). | r/w |
| .1.1.2.1.113 | bitsT3ClkSquelch | When set to disabled (1), it forces the T3 output to the PLL to be active even if a loss of frame or an alarm condition exists. This would typically be disabled for normal operation and only be set for unframed operation. Default value is (0). | r/w |
| .1.1.2.1.114 | bitsTestPattern | An 8- or 16-bit test pattern that will be serialized and repeatedly output on T1E1 port when the test output is enabled. Applies to the following line-type settings: dsx1ESF dsx1D4 dsx1E1 dsx1E1CRCMF dsx1E1unframed Default value is (0). | r/w |
| .1.1.2.1.115 | bitsTestPatternLength | Determines whether a 8 bit (0) or 16 bit (1) test pattern is generated. Applies to the following line-type settings: dsx1ESF dsx1D4 dsx1E1 dsx1E1CRCMF dsx1E1unframed Default value is (0). | r/w |

Table 5-4 cgmBitsTable (continued)

| OID | MIB Object | Description | Access |
|--------------|---------------------|--|--------|
| .1.1.2.1.116 | bitsTestPatternType | <p>Determines the type of the generated test pattern. fixed(0) to use a pattern as defined in bitsTestPattern / bitsTestPatternLength.</p> <p>prbs11 (1) prbs15 (2) qrss20 (3)</p> <p>Default value is (1).</p> <p>Applies to the following line-type settings: dsx1ESF dsx1D4 dsx1E1 dsx1E1CRCMF dsx1E1unframed</p> | r/w |

The following table describes the elements of the cgmControl MIB branch (OID:.1.3.6.1.4.1.3656.8152.1.1).

Table 5-5 cgmControl Elements

| OID | MIB Object | Description | Access |
|---------|---------------------------------|---|--------|
| .1.1.10 | cgmInterfaceMode | <p>Defines Sonet/T1 (0) or SDH/E1 (1) operation mode for both BITS interfaces. Affects whether an input frequency of 1544KHz (Sonet/T1) or 2048KHz (SDH/E1) can be selected for the cgmInputFrequency object.</p> <p>Default value is (1).</p> | r/w |
| .1.1.15 | cgmMasterSlaveShelfCombination | <p>Defines whether the master/slave combination is on the same shelf (0) or on different shelves (1).</p> <p>Note: only "same shelf" is supported.</p> <p>Default value is (0).</p> | r/w |
| .1.1.16 | cgmMasterSlaveSync | <p>Defines the communication path to the protection partner.</p> <p>Default value is backplane (0).</p> | r/w |
| .1.1.18 | cgmProtectionRevertiveModeState | <p>When a clock module is in revertive operation (0), it will always choose the highest priority valid input.</p> <p>When in nonrevertive operation (1), a selected input will remain selected until it fails. The highest priority valid input will be chosen at that point and remain selected until it fails as well.</p> <p>Default value is (1).</p> | r/w |

Table 5-5 cgmControl Elements (continued)

| OID | MIB Object | Description | Access |
|---------|--------------------------------------|---|--------|
| .1.1.19 | cgmProtectionState | Indicates whether this module is the master or slave of a protection pair: 0 - standaloneMaster: Communication with the partner is not possible and the module is running in master mode. 1 - slave 2 - master | r |
| .1.1.20 | cgmProtectionCmd | Can be used to manually change the state of the module. 0 - Attempt to become master. This is only possible if a valid clock input is present. 1 - Give up mastership to the protection partner. This is only possible if the partner (slave) has a valid input other than MS_SYNC. Whether the operation failed or succeeded can be seen in the cgmProtectionState element. | r/w |
| .1.1.21 | cgmProtectionMasterToSlaveTrackDelay | The tracking delay for the master/slave synchronization signal in ns units. Default value is automatically configured. | r/w |
| .1.1.22 | cgmProtectionPartnerAddress | The IP address of the protection partner. Default value depends on your configuration. | r/w |
| .1.1.30 | cgmPathStateT0 | The current state of the T0 PLL: 0 - freerun 1 - locked 2 - holdover 3 - preLocked 4 - preLocked2 5 - phaseLost 6 - forcedFreerun 7 - forcedHoldover | r |
| .1.1.32 | cgmPathInputT0 | The input currently selected for the T0 PLL. The value 255 indicates that no input is selected. | r |
| .1.1.34 | cgmPathInputT4 | The input currently selected for the T4 PLL. The value 255 indicates that no input is selected. Other values reflect the cgmInputNumber element in the cgmInputTable table, for details refer to Table "Input Assignments" on page 48 . | r |
| .1.1.40 | cgmCLK1OutputFrequency | The output frequency of CLK1: 0 - CLK1 output disabled 1 - 8 KHz Default value is (1). | r/w |

Table 5-5 cgmControl Elements (continued)

| OID | MIB Object | Description | Access |
|---------|-------------------------|--|--------|
| .1.1.41 | cgmCLK2OutputFrequency | The output frequency of CLK2: 0 - CLK2 output disabled 1 - 19.44 MHz Default value is (1). | r/w |
| .1.1.42 | cgmCLK3OutputFrequency | Not supported on PMC-CGM | r/w |
| .1.1.43 | cgmCLK1OutputFramePulse | The output frame pulse of the T1 clock: 0 - Not inverted, not pulsed 1 - Not inverted, pulsed 2 - Inverted, not pulsed 3 - Inverted, pulsed Default value is (0). | r/w |
| .1.1.44 | cgmT4ClkSquelch | When set to 0 (enable) the output of the T4 PLL is squelched if no valid input is selected. If set to 1 (disable) an output is provided in any case. | |

5.3 cgmSys

The cgmSys branch contains the following information:

- cgmEventTable - for details refer to [Table 5-6 on page 55](#).
- Various MIB objects that are described in [Table 5-8 on page 58](#).
For a description on how to use these objects refer to [Configure Parameters for Event Handling on page 44](#), [Perform Firmware/Software Upgrade on page 42](#).

The cgmEventTable (OID:.1.3.6.1.4.1.3656.8152.1.3.1) uses cgmEventNumber as index. The elements of the trap definition cgmLogEvent (OID:.1.3.6.1.4.1.3656.8152.1.2.0.1) is identical to the elements defined in cgmEventTable.

Table 5-6 cgmEventTable

| OID | MIB Object | Description | Access |
|------------|------------------|---|--------|
| .1.3.1.1.2 | cgmEventTime | System time stamp when event occurred (this is the module's run-time since power-up). | r |
| .1.3.1.1.3 | cgmEventSeverity | The event's severity level 1. Critical (0): An error has occurred which needs immediate attention. 2. Warnings (1): An error has occurred which may affect board operation but does not require immediate attention. 3. Events (2): An event occurred in a board subsystem which may need attention (e.g. the PLL gained lock). 4. Information (3): Various information messages helpful for troubleshooting or monitoring the state of the CGM module. | r |

Table 5-6 cgmEventTable (continued)

| OID | MIB Object | Description | Access |
|------------|---------------|--|--------|
| .1.3.1.1.4 | cgmEventCode | A pre-defined event code - for details refer to Table 5-7 on page 56 . | r |
| .1.3.1.1.5 | cgmEventData | Event specific data | r |
| .1.3.1.1.6 | cgmEventDescr | Textual event description | r |

The following table lists all event codes and their severity. Events which cause the module to give up mastership are marked with an asterisk in the "severity" column.

Table 5-7 Event Codes and Severity

| Code | Severity | Description |
|--------------------------|----------|--|
| inputChanged (1) | Event | The selected PLL input has changed. |
| lostLock (2) | Event | The T0 PLL lost lock and enters holdover mode. |
| gainedLock (3) | Event | The PLL gained lock. |
| nowMaster (4) | Event | The module has acquired mastership. |
| nowSlave (5) | Event | The module has entered slave mode. |
| validInputsChanged (6) | Event | The validity or more of the PLL inputs has changed . |
| selectedInputFailed (7) | Event | The selected clock input has failed. |
| dppllInitError (10) | Warning | Error while initializing the DPLL. |
| freqValidationError(11) | Warning | One of the clock sources measured in the FPGA is out of range. |
| inputStateChange (12) | Event | Reported when a state change is detected by the activity monitor. EventData: Upper 16 bits encode the new state, lower 16 bits encode the input number. State can be 0 (working) 1 (failing) 2 (failed) 3 (recovering) 4 (unknown) This is the same information as presented in the cgmInputActivityMonitor element. |
| lineCardClkError (20) | Warning | Not applicable for PMC-CGM. |
| lineCardClkSelected (21) | Event | Not applicable for PMC-CGM. |
| bitsRlof/c (30/34) | Event | "Loss of frame" / "Loss of frame cleared" event detected on a BITS interface. EventData: The BITS interface on which the event has been detected (0 or 1). |

Table 5-7 Event Codes and Severity (continued)

| Code | Severity | Description |
|------------------------------|-----------|--|
| bitsRlos/c (31/35) | Event | "Loss of signal" / "loss of signal cleared" event detected on a BITS interface. EventData: The BITS interface on which the event has been detected (0 or 1). |
| bitsRais/c (32/36) | Event | "Alarm indication" / "Alarm indication cleared" event detected on a BITS interface. EventData: The BITS interface on which the event has been detected (0 or 1). |
| bitsRyel/c (33/37) | Event | "Yellow alarm" / "Yellow alarm cleared" event detected on a BITS interface. EventData: The BITS interface on which the event has been detected (0 or 1). |
| bitsRxSsmChange (38) | Event | A new synchronization status message has been received. EventData: The new SSM message received. |
| memoryLeak (100) | *Warning | The task checker has detected that the amount of available memory has dropped below the critical threshold. |
| memAllocError (101) | *Warning | Required memory could not be allocated. EventData: The amount of memory which was attempted to be allocated. |
| tftpError(102) | Event | A TFTP error occurred (firmware update). |
| firmwareUpdateFailedNc (103) | Warning | The firmware update failed before accessing the boot flash device. |
| firmwareUpdateFailedC (104) | *Critical | The firmware update failed possible corruption of the boot flash device. The standby boot flash image has not been made active. |
| firmwareUpdateSuccess(105) | Event | The firmware update completed successfully. |
| firmwareUpdateProgress (106) | Event | A firmware update progress message. |
| abnormalReset(110) | Warning | The last reset resulted from a fatal error condition (checkstop or watchdog). EventData: A bit mask with the following values: 0x10000000: Indicates watchdog reset 0x08000000: Indicates checkstop reset |
| linkFailure (120) | Warning | The active network connection failed, the firmware switched to the inactive link. EventData: either 0 or 1, indicating the link which failed. |
| linkSwitch (121) | Event | The active network link was switched. EventData: The new active link (0 or 1) |
| info (200) | Info | General system information. For debugging only. |

Table 5-7 Event Codes and Severity (continued)

| Code | Severity | Description |
|--------------------------|-----------|---|
| genSysError (1000) | Warning | A general system error. For debugging only. |
| genSysErrorC (1001) | *Critical | A general critical system error. For debugging only. |
| startupComplete (130) | Event | Indicates that the clock module has started and is ready for operation. |
| resetRequest (131) | Event | Indication that the module is being resetted. |
| invalidBootOptions (140) | Warning | Invalid parameters were given for the cgmBootString. |

The following table describes the elements of the cgmSys MIB branch (OID: 1.3.6.1.4.1.3656.8152.1.3). They provide general control and status operations for the event log.

Table 5-8 cgmSys Objects

| OID | MIB Object | Description | Access |
|---------|----------------------|---|--------|
| .1.3.10 | cgmSysEventLogSize | The maximum number of events the event log can hold (about 80000). | r |
| .1.3.11 | cgmSysEventLogCount | The current number of events present in the event log. | r |
| .1.3.12 | cgmSysEventLogClear | Clears the event log. When set to 0, events which have not been accessed will be cleared (an event is marked as "accessed" if its timestamp cgmEventTime is read). If set to 1, all events are cleared regardless whether they have been accessed or not. This is not recommended since it may cause events to get lost while the log is about to be cleared. | r/w |
| .1.3.13 | cgmSysEventLogLevel | Specifies up to which severity events shall be placed into the event log: 0 - No events are logged 1 - Only critical events are logged 2 - Critical events and warnings are logged 3 - Critical events, warning and events are logged 4 - Everything is logged Default value is (3). | r/w |
| .1.3.14 | cgmSysEventTrapLevel | Specifies up to which severity new event log entries are posted as a trap (using the cgmLogEvent object). 0 - No events are posted 1 - Only critical events are posted 2 - Critical events and warnings are posted 3 - Critical events, warning and events are posted 4 - Everything is posted Default value is (3). | r/w |

Table 5-8 cgmSys Objects (continued)

| OID | MIB Object | Description | Access |
|---------|--------------------|--|--------|
| .1.3.23 | cgmSysHwVersion | The hardware revision of the PMC-CGM. | r |
| .1.3.24 | cgmSysSwVersion | The firmware revision of the board in the format "x.y.z" which corresponds to "<major revision>.<minor revision>.<build count>". | r |
| .1.3.25 | cgmRestartCmd | Restarts the module when set to 1. The operation is ignored while a firmware update is ongoing. After a successful firmware update this will start the new firmware. | r/w |
| .1.3.26 | cgmFwUpdateHost | The IP address of the TFTP server where the new firmware image is located. | r/w |
| .1.3.27 | cgmFwUpdateFile | The name of the firmware update image to be downloaded from the TFTP server. | r/w |
| .1.3.28 | cgmFwUpdateMd5 | The MD5 checksum of the firmware image. This checksum is verified after downloading the TFTP image and after programming it into the boot flash. | r/w |
| .1.3.29 | cgmFwUpdateOption | Controls how to handle revision numbers of the old and the new firmware image: If "newer" (0) only images with a version number higher than the current one can be programmed. If "newerOrSame" (1), images with the same or a higher version number can be programmed. If "allowDowngrade" (2), firmware downgrade is possible. If "noVersionCheck" (3), no version check is performed at all. This allows installing images which do not contain version information. Default value is (0). | r/w |
| .1.3.30 | cgmFwUpdateStart | A value of 1 initiates the firmware update. The value remains 1 as long as the update is ongoing. | r/w |
| .1.3.31 | cgmSysTelnetEnable | Enables(1) / disables (0) a telnet server on the module. Used only for debugging purposes. Default value is (1). | r/w |
| .1.3.32 | cgmTrapDestination | IP address where to send traps to. Default value is the host address specified in the boot parameters of the PMC-CGM. | r/w |

Table 5-8 cgmSys Objects (continued)

| OID | MIB Object | Description | Access |
|---------|---------------|---|--------|
| .1.3.33 | cgmBootString | <p>The boot configuration data consists of a list of parameter=value pairs separated by spaces. The following parameters/values are defined:</p> <p>(e ethaddr)=<ip-address>[:netmask] Defines the module's IP address/netmask. This is overwritten by dynamic configuration options (see below). Default netmask is fffff00.</p> <p>(h host trapDest)=<ip-address> Defines the default address for the cgmTrapDestination element.</p> <p>(g gatewayip)=<ip-address> Defines the default gateway address.</p> <p>(m mode)=<flag>[,<flag>[,...]] Defines various configuration flags. <flag> may be one of</p> <ul style="list-style-type: none"> -ipmi: Obtain IP/gateway address via IPMI (from shelf manager). -dhcp: Configure network interfaces via DHCP. -static: Use static network setup as defined here. <p>When obtaining network address via IPMI or DHCP, and the host address (h=statement) is on the same subnet as the statically configured IP address (e=statement), the network part of the host address is adjusted according to the dynamically obtained IP address.</p> <p>Setting this element has no immediate effect, modifications are applied at the next reboot.</p> | r/w |

5.4 cgmClkDist

The cgmClkDist branch contains the following information which is used for controlling clock distribution and measurement:

- cgmDmClkTable - not supported for the PMC-CGM.
- cgmFrqMonTable - not supported for the PMC-CGM.
- Various MIB objects that are described in [Table 5-5 on page 53](#).
For details on how to use these MIB objects refer to [Configure the Reference Clock on page 41](#).

The following table describes the elements of the cgmClkDist MIB branch (OID:.1.3.6.1.4.1.3656.8152.1.4).

Table 5-9 cgmClkDist Objects

| OID | MIB Object | Description | Access |
|---------|--------------------|--|--------|
| .1.4.10 | cgmClkDistMode | <p>The clock distribution mode of the module. There are four main modes a module can be operated in:</p> <ul style="list-style-type: none"> ● Distributed Mode (0) For each clock domain (CLK1/2/3), the module selects a payload card in the shelf and replicates it to the other payload cards. The selection can be done manually or automatically. Not applicable for PMC-CGM. ● Extension Mode (1) The module receives CLK1/2 from the main shelf and distributes them to the local payloads. Reference clocks (CLK3) can be routed to the main shelf. Not applicable for PMC-CGM. ● Buffer Mode (2) The module receives CLK1/2/3 from the main shelf and distributes them to the local payloads. Not applicable for PMC-CGM. ● Centralized Mode (3) The module generates the T0 clocks based on internal or external references. In centralized mode there may be up to two shelves connected, operating in either extension or distribution mode. ● Extended Centralized Mode (4) Like centralized mode, except that CLK3 is routed to the main shelf via the front-panel connector (i.e. REF A/B can not be selected as input). Not applicable for PMC-CGM. <p>Default value is centralized mode (3).</p> | r/w |
| .1.4.11 | cgmExtChConnection | <p>In centralized mode, selects the properties of the connections to extension chassis 2 and 3 (not connected, extended mode or buffered mode):</p> <p>Single Chassis (0) Chassis 2 in extension mode (1) Chassis 3 in extension mode (3) Chassis 2 and 3 in extension mode (5) Default value is (0).</p> | r/w |

Table 5-9 cgmClkDist Objects (continued)

| OID | MIB Object | Description | Access |
|---------|-----------------------------|---|--------|
| .1.4.16 | cgmlInputRefASource | Determines the source of the "primary" linecard derived reference clock (REFA input to PLL). local reference A (0) local reference B (1) Chassis 2 reference A (2) Chassis 2 reference B (3) Chassis 3 reference A (4) Chassis 3 reference B (5) Default value is (0). | r/w |
| .1.4.17 | cgmlInputRefASourceLinecard | Determines the source (linecard) of the primary linecard derived reference clock. Not applicable for PMC-CGM. | r/w |
| .1.4.18 | cgmlInputRefBSource | Determines the source of the "secondary" linecard derived reference clock (REFB input to PLL). local reference A (0) local reference B (1) Chassis 2 reference A (2) Chassis 2 reference B (3) Chassis 3 reference A (4) Chassis 3 reference B (5) Default value is (1). | r/w |
| .1.4.19 | cgmlInputRefBSourceLinecard | Determines the source (linecard) of the secondary linecard derived reference clock. Not applicable for PMC-CGM. | r/w |



A.1 Emerson Network Power - Embedded Computing Documents

The Emerson Network Power - Embedded Computing publications listed below are referenced in this manual. You can obtain electronic copies of Emerson Network Power - Embedded Computing publications by contacting your local Emerson sales office. For documentation of final released (GA) products, you can also visit the following website:

<http://www.emersonnetworkpowerembeddedcomputing.com> > Resource Center > Technical Documentation Search. This site provides the most up-to-date copies of Emerson Network Power - Embedded Computing product documentation.

Table A-1 Emerson Network Power - Embedded Computing Publications

| Document Title | Publication Number |
|--|--------------------|
| Centellis CO 31kX Installation and Use | 6806800A99 |
| ATCA-F103 Installation and Use | 6806800D97 |
| ARTM-F103-STX Installation and Use | 6806800D79 |
| PMC-CGM: Control via IPMI Programmer's Reference | 6806800D54 |
| CABLE-CGM2-CLK Installation and Use | 6806800F47 |

A.2 Related Specifications

For additional information, refer to the following table for related specifications. As an additional help, a source for the listed document is provided. Please note that, while these sources have been verified, the information is subject to change without notice.

| Company/Org. | Documents |
|--|--|
| PICMG can be ordered via www.picmg.org | PICMG 3.0 AdvancedTCA Base Specification |

A

- Abbreviations 9
- Access 35
 - Cabling 36
 - IP addresses 37
 - Via IPMI 36
 - Via MIB browser 37
- ATCA-F103 21
 - PMC slot on 29
 - PMC-CGM support on 21

B

- BITS interface 32
 - Configuration 39
 - Connector 33
 - LEDs 34
 - MIB objects 49
- Blind panel 30

C

- Clock distribution cable 30
- Clocking concept 21
- Clocking standards 22
- Compliances 22
- Contact information 12
- Content overview 9
- Conventions 11

E

- E1 39
- Environmental requirements 27
- Event codes 56
- Event handling 44
 - MIB objects 58
 - Procedure 44

F

- Features 21
- Feedback 12
- Firmware upgrade
 - MIB objects 58
 - Procedure 42
- Free-run mode 34
- Front panel 32
 - BITS interface 32
 - LEDs 33

H

- Holdover mode 34

I

- Interface mode
 - Configuration 39
 - MIB objects 53
- IP addresses 29
 - Dynamic 29, 37
 - Static 29

L

- LEDs 33
- List of abbreviations 9
- Locked mode 34

M

- Master/slave 21, 40
 - Configuration 40
 - LED 34
 - MIB objects 53
- MIB 47
- MIB browser 37
 - Changes 37
 - Read community 37
 - Write community 37
- Module layout 31
- Multi-shelf support 40
 - Configuration 40

O

- Operating modes 34
 - Free-run 34
 - Holdover 34
 - Locked 34
- Operating temperature 27
- Order numbers 23

P

- PMC slot on ATCA-F103 29
- PMC-CGM support 21
- Power requirements 27
- Procedures
 - Configuring BITS interface 39
 - Configuring event handling 44
 - Configuring master/slave role 40
 - Configuring multi-shelf support 40
 - Configuring the reference clock 41
 - Defining interface mode 39
 - Defining IP address of protection partner 38
 - Defining SNMP trap destinations 38
 - Installing the module 30
 - Removing the module 30
 - Resetting the PMC-CGM 43

Unpacking the module [25](#)
Upgrading the firmware [42](#)
Protection partner [21, 38](#)

R

Reference clock [41](#)
 Configuration [41](#)
 MIB objects [47, 61](#)
Requirements [26](#)
 Environmental [27](#)
 Power [27](#)
Reset [43](#)
 Via IPMI [43](#)
 Via SNMP [43](#)

RoHS [23](#)

S

Safety notes [13](#)
SDH [39](#)
SONET [39](#)
Standard compliances [22](#)
SW1 [28](#)
Switch settings [28](#)

T

T1 [39](#)
TNV-2 [27](#)
Trap destinations [38](#)