

Say What?!™ Wireless Chime

This package includes (Style of push button and chime may vary from illustration):

- Wireless chime
- Wireless push button with demonstration batteries
- Hardware pack
- Audio cable (Model 1204 Only)


This chime requires 3 “C” alkaline batteries for the chime and 4 “AA” alkaline batteries for the transmitter (Not Included). In typical use, alkaline batteries will last up to six months.

1. Install 4 type “AA” alkaline batteries in push button.

Open back of push button by removing screw at top of battery cover with small philips-head screwdriver. Slide cover up and pull bottom of cover out to remove. Remove demonstration batteries. Insert batteries according to markings inside push button. Reverse above procedures to reattach battery cover.

2. Install 3 type “C” alkaline batteries in chime.

Open back of case by removing 2 screws at bottom of battery cover with small philips-head screwdriver. Press in catch on bottom of chime and remove cover. Insert batteries according to markings inside the chime. Reverse above procedures to reattach battery cover.



Model 1204 Shown

3. Test functions.

Temporarily position chime and push button where you want them mounted. Press push button to verify chime and push button work properly. If chime does not sound, see *Troubleshooting*.

4. Adjust volume.

The chime is equipped with a High/Low switch located on the left side. Slide the switch to either High or Low to adjust volume.

5. Mount push button and chime.

Use either a screw or double sided tape to mount push button.

To mount with screw, determine where push button will be located. Using 3/16" drill bit, drill tap hole. If screw is not mounted directly into wood stud or trim molding, use drywall anchor. Insert screw leaving approximately 1/8" gap between head of screw and wall. Place keyhole slot on rear of push button over the screw's head and slide down firmly.

When attaching push button using double sided tape, make sure the surface is clean.

Chime can be mounted by using 1 screw with keyhole (see illustration on page 1) or placed on top of a desk or table. Follow steps under mounting push button with screw to mount chime.



Before returning product to store, please see *Troubleshooting* section or call Technical Service toll free: **1-800-858-8501**.

Code and Tune Settings


Code Settings

Note: Most installations will not require you to change any jumpers on your chime and push button.

This manual includes operating instructions for different types of chimes. All chimes work on the same principle and use the same channel setting information. Please read all instructional information and note any specific information pertaining to your particular chime.

The push button and chime communicate by using a code that can be changed by removing and/or adding jumpers on both the push button and chime. The code is factory set; however, there are selectable codes that allow you to expand your system and prevent outside interference (Models 1200/1201-8 selectable codes; Model 1204-128 selectable codes). Other wireless products may cause interference and the system may not function properly. Follow the instructions below for setting a new code.

1. To access the jumpers, remove the battery covers and locate the jumpers on both the push button and chime (See illustration on page 3). *Note:* To access the jumpers on the push button, the batteries must be removed.
2. The push button and chime both have multiple jumpers (either 3 or 7 depending on model). The jumpers are used for setting the code.
3. To change the code, add and/or remove jumpers as needed. It is recommended to only change one jumper at a time and then check to see if system is functioning properly. *Note:* Jumpers must be exactly the same for both the push button and chime for this system to function.



Chime Tune Settings

Your wireless chime has different selectable tune modes: 4 prerecorded sounds and 1 setting that cycles through the 4 prerecorded sounds (model 1204 adds the ability to record up to 10 seconds of audio via the audio cable or built-in microphone, see instructions below).

To select different tune modes, slide switch located on right side of chime to numbers 1 through 4 to select the prerecorded sound desired. Select "All" to allow chime to cycle through the 4 prerecorded sounds each time the chime sounds.

Model 1204: To record up to 10 seconds of audio using the audio cable, plug one end of the audio cable into the 3 1/2 mm headphone or audio out jack on your sound source. Plug other end of audio cable into 3 1/2 mm audio jack located on back of chime near the top. Slide tune setting switch to position number 5. Push down and hold "Rec" button (located near audio jack) while playing audio from your sound source. Release "Rec" button when completed.

To record up to 10 seconds of audio using built-in microphone, press down and hold the "Rec" button located on the back of the chime near the top while speaking or playing the audio from your sound source. Release the "Rec" button when completed. *Note:* The microphone is located on front of chime. For best results, do not hold the microphone closer than 2" to the sound source.

Recording Push Button Audio

Your push button has the capability to record up to 10 seconds of audio for personalized messages and sounds.

All Models: To record up to 10 seconds of audio, press down and hold "Rec" button located on back of push button near bottom while speaking or playing audio from your sound source. Release "Rec" button when completed. *Note:* The microphone is located on front of push button. For best results, do not hold the microphone closer than 2" to the sound source.

Model 1204: To record up to 10 seconds of audio, plug one end of the audio cable into the 3 1/2 mm headphone or audio out jack on your sound source. Plug other end of audio cable into 3 1/2 mm audio jack located on back of push button near the bottom. Push down and hold "Rec" button (located near audio jack) while playing audio from your sound source. Release "Rec" button when completed.



Before returning product to store, please see *Troubleshooting* section or call Technical Service toll free: **1-800-858-8501**.

Troubleshooting

Chime does not sound:

- Make sure push button and chime codes are the same (See page 3).
- Check orientation of push button and chime batteries (See markings inside push button and chime).
- Check charge of push button and chime batteries, replace if necessary.
- Verify push button and chime are within 50 feet of each other.

Batteries seem OK, but the chime does not work when installed:

- Do not mount chime or push button on metal or near metal studs. This reduces the transmitter range. Use 1/4" to 1/2" (6 to 13 mm) wood shims to move chime or push button off metal surface.
- Concrete floors may reduce range. Move chime away from floor.
- Try locating chime closer to push button.

The range of the wireless chime can vary with location, temperature and battery condition.

Regulatory Information

This device (1200RX, 1201RX, 1204RX, 1210TX, 1214TX) complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The user is cautioned that changes or modifications not expressly approved by the party responsible for regulatory compliance could void the user's authority to operate the equipment.

This product complies with ASTM F963-96a.

Age grading information:

- Models 1200/1201 - "Ages 8 & Up"
- Model 1204 - "Ages 14 & Up"

Technical Service (Do Not Send Products)

If you experience a problem, follow this guide. You may also want to visit our Web site at: www.desatech.com. If the problem persists, call* for assistance at **1-800-858-8501**, 7:30 AM to 4:30 PM CST (M-F). You may also write* to:

DESA Specialty Products™

P.O. Box 90004, Bowling Green, KY 42102-9004

* If contacting Technical Service, please have the following information available: Model Number, Date of Purchase, and Place of Purchase.

NO SERVICE PARTS AVAILABLE FOR THESE PRODUCTS

ONE YEAR LIMITED WARRANTY

This is a "Limited Warranty" which gives you specific legal rights. You may also have other rights which vary from state to state or province to province. For a period of one year from the date of purchase, any malfunction caused by factory defective parts or workmanship will be corrected at no charge to you. **Batteries are not covered.** To obtain a refund or a replacement, return the product to the place of purchase.

Not Covered - Repair service, adjustment and calibration due to misuse, abuse or negligence, light bulbs and other expendable items are not covered by this warranty. Unauthorized service or modification of the product or of any furnished component will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use, or unauthorized service.

This warranty covers only DESA Specialty Products™ assembled products and is not extended to other equipment and components that a customer uses in conjunction with our products.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY, REPRESENTATION OR CONDITION OF MERCHANT ABILITY OR THAT THE PRODUCTS ARE FIT FOR ANY PARTICULAR PURPOSE OR USE, AND SPECIFICALLY IN LIEU OF ALL SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

REPAIR OR REPLACEMENT SHALL BE THE SOLE REMEDY OF THE CUSTOMER AND THERE SHALL BE NO LIABILITY ON THE PART OF DESA SPECIALTY PRODUCTS™ FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO ANY LOSS OF BUSINESS OR PROFITS, WHETHER OR NOT FORESEEABLE. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Retain receipt for warranty claims.

DESA Specialty Products™ reserves the right to discontinue and to change specifications at any time without notice without incurring any obligation to incorporate new features in previously sold products.