



SMOOTH 9.6P

OWNER'S MANUAL

treadmillbynet.com
advancedfitness.com
The Fitness Superstore

SALES: (888) 9TREADS
(888) 987-3237

SERVICE: (888) 800-1167 ext. 103

SMOOTH is a registered trademark of
Internetfitness.com
Mt. Laurel, NJ

Important Safety Instructions

WARNING!

Read all instructions before using this appliance.

DANGER - To reduce the risk of electric shock disconnect your treadmill from the electrical outlet prior to cleaning and/or service work.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons, install the treadmill on a flat level surface with access to a 120-volt, 20-amp grounded outlet. DO NOT USE AN EXTENSION CORD: DO NOT ATTEMPT TO DISABLE THE GROUNDED PLUG BY USING IMPROPER ADAPTERS, OR IN ANY WAY MODIFY THE CORD SET. A serious shock or fire hazard may result along with computer malfunctions. See Grounding Instructions, page 2.

- Do not operate treadmill on deeply padded, plush or shag carpet. Damage to both carpet and treadmill may result.
- Do not block the rear of the treadmill. Provide a minimum of 3 1/2 feet clearance between the rear of the treadmill and any fixed object.
- Keep children away from the treadmill. There are obvious pinch points and other caution areas that can cause harm.
- Keep hands away from all moving parts.
- Never operate the treadmill if it has a damaged cord or plug. If it is not working properly, call your dealer.
- Keep the cord away from heated surfaces.
- Do not operate where aerosol spray products are being used or where oxygen is being administered.
- Never operate the treadmill with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- Never drop or insert any object into any openings.
- Do not use outdoors.
- To disconnect, turn all controls to the off position, remove tether cord, then remove plug from outlet.
- Do not attempt to use your treadmill for any purpose other than for the purpose it is intended.
- Use handrails provided; they are for your safety.
- Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable to be used on your treadmill. Quality athletic shoes are recommended to avoid leg fatigue.

**Remove tether cord after use to prevent unauthorized treadmill operation.
SAVE THESE INSTRUCTIONS - THINK SAFETY!**

Important Electrical Information

WARNING!


- **NEVER** use a ground fault circuit interrupt (GFCI) wall outlet with this treadmill.
- Route the power cord away from any moving part of the treadmill including the elevation mechanism and transport wheels.
- **NEVER** remove any cover without first disconnecting AC power.
- If voltage varies by ten percent (10%) or more, the performance of your treadmill may be affected. **Such conditions are not covered under your warranty.** If you suspect your voltage is low, contact your local power company or a licensed electrician for testing. See Diagnosis Guide, page 13.
- **NEVER** expose this treadmill to rain or moisture. This product is **NOT** designed for use outdoors, near a pool or spa, or in any other high humidity environment.

Grounding Instructions

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in sketch A. A temporary adapter that looks like the adapter illustrated in sketches B and C may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw.



Treadmill Assembly

Attention!

The following instructions are included only as information so that you, the consumer, understand basically how the treadmill is assembled.

STEP 1: Remove treadmill from carton. You may pick the rear of the treadmill up and roll it off the packaging. Remove foam padding, wrap, etc. **Observe for possible freight damage.**

Note: You will need a phillips screw driver and 1/2" wrench to complete assembly.

STEP 2: This owners manual packet contains (2) Allen wrenches and (4) black plugs. When practical, assembly hardware is mounted in appropriate locations that require removal and replacement. The computer head is loose. Set aside for step 6.

STEP 3: An unpainted steel channel connects the console uprights to the base. With phillips screwdriver and Allen wrench (provided) unbolt the console uprights from base. Discard plastic washers (4) and steel channels. The 5/16" x 1" Allen bolts and "gold" special nut/washers will be used in step 5. The black phillips head screws will be used in step 8.

STEP 4: Raise the console upright assembly and place upright console assembly into front grill area. Be careful of the two cables. A bottom and rear 3/8" pin will help locate into proper position to allow hardware installation. Locate the (4) 5/16" x 1" black Allen bolts and "gold" special 5/16" washer/nuts removed in step 4. Place one bolt on the end of the Allen wrench (provided) and insert thru any one of (4) round frame holes. Bolt should go thru console hole to allow "gold" 5/16" hex nut/washer to be started. Hand "run" the nut against the console so that it will not turn during tightening with Allen wrench. Do not tighten with Allen wrench until all (4) nut/bolt assemblies are inserted and started. Tighten all bolts. Nuts should "hold" without a wrench. If they do not hold use an open end wrench from the bottom. Insert the (4) black plugs into the access holes.

Note: For heavy use units it is advisable to use a wrench on the nuts and add additional torque to nut / bolt.

STEP 5: Handles will install thru access holes in console upright. Remove both 5/16" Allen bolts in each handle with included wrench that is located in parts bag. Slide handle (flair to outside) thru access holes in console upright. **Use caution to avoid data cables in left hand side console upright.** You may observe data cable clearance from top of open console upright. Start both bolts into hand rail thru console upright. Repeat procedure for opposite hand rail. **Tighten all bolts.**

STEP 6: Place the treadmill in operating position. Make certain cables from upper computer do not come in contact with motor fan. Apply AC power. Start the unit and observe belt tracking. Unit must be reasonably level for proper tracking. Test treadmill basic operation. This includes noise, motor performance, etc.

STEP 7: Install motor hood and secure with (2) black phillips head screws removed in step 4. Front of motor hood is not secured.

The dealer must provide the following (minimum):

- n Follow the belt tracking instructions closely in order to ensure proper belt tension and path.
- n Walk on the belt at slow speeds under 2.5 mph for a few minutes in order to break in the belt/deck lubricant.
- n Make certain treadmill is electrically grounded.

Contact Smooth

Service 1-888-800-1167, ext. 103
Sales 1-800-TREADMILL

Important Operation Instructions


- 1 **NEVER** operate this treadmill without reading and completely understanding the results of any operational change you request from the computer.
- 1 Understand that changes in speed and incline do not occur immediately. Set your desired speed on the computer console and release the adjustment key. The computer will obey the command gradually.
- 1 **NEVER** use your treadmill during an electrical storm. Surges may occur in your household power supply that could damage treadmill components. Removing safety cord will protect the unit.
- 1 Use caution while participating in other activities while walking on your treadmill; such as watching television, reading, etc. These distractions may cause you to lose balance or stray from walking in the center of the belt; which may result in serious injury.
- 1 **NEVER** mount or dismount the treadmill while the belt is moving. Smooth treadmills start with zero speed and it is unnecessary to straddle the belt during start up. Simply standing on the belt during slow acceleration is proper after you have learned to operate the unit.
- 1 Always hold on to a handrail or grab bar while making control changes (incline, speed, etc.). Do not use excessive pressure on console control overlays. They are precision set to function properly with little finger pressure. Pushing harder is not going to make the unit go faster or slower. If you feel the buttons are not functioning properly with normal pressure contact your Smooth dealer; adjustments can be made. All buttons should operate and control treadmill functions without excessive finger effort. Damage to overlay will result if excessive control pressure continues.

Safety Tether Cord

A safety tether cord is provided with this unit. It is a simple magnetic design that should be used at all times. It is for your safety should you fall or move too far back on the treadbelt. Pulling this safety tether cord will stop treadbelt movement.

To Use:

1. Place magnet into position on the console control head. Your treadmill will not start and operate without this. Removing the magnet also secures the treadmill from unauthorized use.
2. Fasten the black plastic clip onto your clothing securely to assure good holding power. **Note:** The magnet has strong enough power to minimize accidental, unexpected stopping and the clip should be attached securely to make certain it does not come off. Be familiar with its function and limitations. Use the adjustment system to assure proper length of cord.



The treadmill will stop, depending on speed, with a two to three step coast anytime the magnet is pulled off the console. Use the red **STOP/PAUSE** switch in normal operation.

Operation of Your New Treadmill

DO NOT STAND ON THE WALKING BELT WHILE LEARNING TO OPERATE YOUR NEW TREADMILL!!!

Basic Treadmill Operation:

Step 1: Press and release **DISPLAY ON/FAST** key. Display will light.

Step 2: For calorie computation if desired;

(A) **Calorie** window will display **LBS**.

(B) Use blue **INCLINE** keys to enter users weight.

Note: If no weight is entered calories do not calculate and calorie window will not light.

Step 3: For an elapsed (countdown) time press **ENTER** key. The **Time/Pace** window will indicate 20:00 (minutes). Adjust to desired time with blue **INCLINE** keys.

Note: The above steps 2 & 3 are not required for operation of the treadmill.

Step 4: Adjust to desired speed with **FAST_s/SLOW_t** keys.

Step 5: Incline may be adjusted anytime with blue **Up + / Down -** incline keys.

Step 6: Press **START BELT** key to begin belt movement. Clock will begin.

Speed / Incline Repeat Feature:

The computer will retain the speed/incline value you've just selected as a **repeater** feature. This means the next time the unit "wakes"/lights up, your desired start speed/incline will repeat itself. Anytime, before **belt movement is begun**, the speed or incline start value can be changed and held in memory.

Pause Feature:

Step 1: When operating the treadbelt, the pause feature may be utilized by pressing the red **STOP/PAUSE** switch. This will slowly decelerate the treadbelt to zero. **TIME** and **DISTANCE** will hold while unit is in the pause mode.

Step 2: To resume previously set speed, press **START BELT** key. Unit will slowly return to the speed displayed.

Pace Feature:

Pace is the amount of time that it will take to walk or jog a mile. Press **SELECT** key after treadbelt movement for pace function. Press **SELECT** key again to exit pace mode. Pace will scan with Time/Calorie and adjust up or down as speed is changed.

Track Feature: *Refer to page 9 (Programmable Operation)*

- Before going into P1 (preset) program is the 1/4 mile **Track** display. Select this feature as you would any other program. Once displayed press **START BELT** key to begin exercise. A dot will travel around the track indicating your position. The **Segment Time** window will indicate the number of laps.

Panel Dim Feature:

- After belt movement you may press and release the **DIM** key. This will blank out the display. Any key (Speed/Incline for example) will light the display back up for a few seconds. Press and release the **DIM** key to exit this mode. The computer display is still running, but simply not displaying the information.

To Turn Treadmill Off:

- Two methods accomplish this:
 - (1) Press and release red **STOP/PAUSE** switch while in pause mode. Display will blank out. Use this method when possible.
 - (2) Pull tether cord. **Should be used only in panic situation.**

Hour Meter Feature:

When the tether cord is initially placed in operational position the **Distance** window will display total **hours**.

The **Speed** window indicates upper computer software version. This is a service issue to refer to computer software design.

Dot Matrix Display

- This display illustrates in programmable modes the workout effort. Twenty rows of “dots” (7 high) indicate each segment of a workout. When all the “dots” of a row are lit, this indicates 100% of the program level. For example: if a program maximum speed is 3.5 mph, all dots lit mean 3.5 mph. The dots are only to show an approximate level (speed/incline) of effort. They do not necessarily indicate a specific value - only an approximate percent to compare levels of intensity.

Program Descriptions

NOTE: Refer to the section entitled "Operating Your New Treadmill" for program operation instructions.

Speed and Incline Programs

All Smooth Programmable treadmills are equipped with eight different programs to add variety to your workout. Each program is evenly divided into 10 equal segments. The workout computer will automatically divide any selected workout time by 10 to give you equal segment lengths. We provide you with four different program examples, from which you can develop and program your own workouts in the computer's memory. All Factory Defined programs come pre-packaged with warm up and cool down periods at the beginning and end of each program to help you exercise properly.

Factory Defined Exercise Programs

Programs P1 through P4 are generalized programs that are provided as simple examples of workouts and the results that may occur as a result of these workouts. *Consult your physician before beginning any exercise program and do not exceed their guidelines.*

WARNING! Factory Defined selections are characterized by programs that are pre-determined by our team of exercise experts. If you make any changes before you begin exercising or during exercise, the changes will be erased once the machine has been turned off at the end of your program and will return to the original factory program.

Definition of the Factory Defined Programs

P1- Interval Trainer - This program is designed to increase your endurance and build your lung power through periods of work load and rest. This is an extremely popular form of training for athletes that experience periods of work load and rest during performance.

P2- Thigh Burner - This program is designed to gradually increase the work load using incline while maintaining a somewhat constant speed. This hill profile is designed to burn away fat in the thigh area by concentrating the intense workout on the thighs.

P3- Cardio Conditioner - For the majority of people, work loads indicated in this program are similar to those experienced while using Heart Rate Control. Through this process, the cardiovascular system is strengthened.

P4- Weight Manager - By using varying work loads, this program creates interest and helps you stick with your workout. Through this process, it gives you the opportunity to improve your fitness while gradually replacing fat with muscle.

Programmable Operation of Your Treadmill

Note: Refer to instructions on countdown elapsed time feature. All programs have the workout pre-set at 20 minutes. You may change to another (10 minutes is minimum) if desired by following instructions pertaining to countdown time. This must be done before **DISPLAY ON/FAST_s** key is pressed.

To Select a Program:

Step 1: Press and release the **DISPLAY ON/FAST_s** key. Display will light.

Step 2: Press and release the **SELECT** key. **Time/Calorie/Pace** window will display elapsed time. Segment Time window will display a particular program.

Speed window will display the maximum **speed** that this program will achieve. **Incline** window will display the maximum **incline** of this program.

Step 3: When a preset program (P1-P4) is selected the **Distance** window will show L-3 (which means Level 3). You may choose 5 different effort levels of any preset program. Use the **FAST_sSLOW_t** keys to make a selection. The **Incline** and **Speed** windows will change accordingly indicating the maximum amount that speed/incline will achieve.

Note: See below *To Review/Change a Program*.

Step 4: After selecting a program press and release **START BELT** key. Treadmill will begin to move and workout has begun.

Note: The segment time will always be 1/20th of the session time. Within 5 seconds of the **end** of a segment run, **Incline** and **Speed** displays will flash with a chime to alert a change. This statement applies to both pre-set and user programs.

To Review/Change a Program:

Step 1: Refer to above. Repeat Step 1 & 2 (*To Select a Program*).

Step 2: Press and release the **ENTER** key when the desired program is displayed. **Incline** window will display the **incline** of that **segment**. Make desired incline adjustments with the blue **Up + / Down -** keys. Shown in the Speed window is the **speed** that **segment** will achieve. You may adjust displayed speed with the **FAST_sSLOW_t** keys. All pre-set programs will return to their original format once the treadmill is shut down.

Step 3: Press and release the **SHIFT^u** key to **advance** the display to the next segment. Use **SHIFT_o** key to go **back** to a previous segment.

STEP 4: After reviewing/changing the program, press and release the **START BELT** key to begin belt movement.

Note: You may adjust speed or incline anytime during a workout. These values will not be held in memory.

To Custom Program User (U1 thru U4):

- Step 1:** Refer to *Select a Program*. Repeat Step 1 & 2. Press and release the **SELECT** key past P4 to user U1. There are 4 available.
- Step 2:** Use the **FAST**_s**SLOW**_t speed keys to make a speed entry. Display will show desired speed and U1-1. Use the blue incline **Up + / Down -** keys to make an incline entry.
- Step 3:** Press and release the **Shift**[∅] key to advance to **segment 2**. Display will show U1-2. Use **FAST**_s**SLOW**_t keys to adjust to desired speed for that **segment**. Use the blue incline **Up + / Down -** keys to make an incline entry.
- Step 4:** Repeat above procedures until all 10 segments are programmed.
- Step 5:** Press and release the **START BELT** key to begin exercise. Exercise is now held in memory unless changed or erased.
- Note:** You may adjust speed and or incline anytime during a workout. These values will not be held in memory.

To Review / Change a User Program:

Follow instructions on page 9 *To Review/Change a Program*. Any speed and or incline change **before** belt movement is held in memory.

To Erase a User Defined Program:

- STEP 1:** Choose the user program to be erased. U1 for example.
- STEP 2:** Press both [∅]Shift [∅] keys at the same time for 3 seconds. Speed and incline values will be cleared and cannot be recovered.

General Maintenance

Belt and Bed - Your treadmill uses a very high-efficient low-friction bed. Performance is maximized when the bed is kept as clean as possible. Use a soft, damp cloth or paper towel to wipe the edge of the belt and the area between the belt edge and frame. Also reach as far as practical directly under the belt edge. This should be done once a month to extend belt and bed life. Use water only - no cleaners or abrasives. A mild soap and water solution along with a nylon scrub brush will clean the top of the textured belt. **Allow to dry before using.**


Belt Dust - This occurs during normal break-in or until the belt stabilizes. Wiping excess off with a damp cloth will minimize buildup.

General Cleaning - Dirt, dust, and pet hair can block air inlets and accumulate on the running belt. On a monthly basis, vacuum underneath your treadmill to prevent buildup. Once a year, you should remove the black motor hood and vacuum out dirt that may accumulate. **UNPLUG POWER CORD BEFORE THIS TASK.**

BELT ADJUSTMENTS:

Treadbelt Tension Adjustment - Belt tension is not critical for most users. It is very important for joggers and runners in order to provide a smooth, steady running surface.

Adjustment must be made from the right side of the rear roller in order to adjust tension with the 1/4" allen wrench provided in the parts package. The adjustment bolt is located at the end of the right side rail as noted in diagram below.



Tighten the rear roller only enough to prevent slippage at the front roller. Turn the treadbelt tension adjusting bolt in increments of 1/4 turn and inspect for proper tension. **When an adjustment is made to the belt tension, you must also make a tracking adjustment to compensate for the change in belt tension.** This is accomplished by turning both the tension and tracking allen bolts an equal amount. This adjustment should be made by turning both bolts clockwise by no more than a 1/4 turn at a time.

DO NOT OVERTIGHTEN - Overtightening will cause belt damage and premature bearing failure.

TREADBELT TRACKING ADJUSTMENT:

The performance of your treadmill is dependent on the frame running on a reasonably level surface. If the frame is not level, the front and back roller cannot run parallel, and constant belt adjustment may be necessary.


The treadmill is designed to keep the treadbelt reasonably centered while in use. It is normal for some belts to vary near a side while the belt is running with no one on it. After a few minutes of use, the treadbelt should have a tendency to center itself. If, during use, the belt continues to move toward one side, adjustments are necessary.

TO SET TREADBELT TRACKING:

A 1/4" allen wrench is provided to adjust the rear roller. Make tracking adjustments from the **left** side only. Set belt speed at approximately 2 to 3 mph. A small adjustment can make a dramatic difference. Turn the bolt only a 1/4 turn and wait a few minutes for the belt to adjust itself. Continue to make 1/4 turns until the belt stabilizes in the center of the running deck.

The belt may require periodic tracking adjustment depending on use and walking/running characteristics. Some users will affect tracking differently. Expect to make adjustments as required to center the treadbelt. Adjustments will become less of a maintenance concern as the belt is used. Proper belt tracking is an owner responsibility common with all treadmills.

CAUTION - KEEP HANDS CLEAR OF MOVING REAR PULLEY!



Belt will move in direction of allen wrench.

ATTENTION:

DAMAGE TO THE RUNNING BELT RESULTING FROM IMPROPER TRACKING / TENSION ADJUSTMENTS IS NOT COVERED UNDER THE SPIRIT WARRANTY.

LUBRICATION:

Do not relube with other than Smooth lubricant. See your Smooth dealer for purchase. The use of some other lubricants may destroy the deck surface or belt and will void warranty. If the treadmill belt/deck is kept reasonably clean it is possible to expect over 1000 hours before relubing is necessary.

Service Checklist - Diagnosis Guide

Before contacting your dealer for aid, please review the following information. It may save you both time and expense. This list includes common problems that may not be covered under the treadmill's warranty.

PROBLEM	SOLUTION/CAUSE
Display does not light	Tether cord not in position.
	Circuit breaker on front grill tripped. Push circuit breaker in until it locks.
	Plug is disconnected. Make sure plug is firmly pushed into AC household wall outlet.
	Household circuit breaker may be tripped.
Treadbelt does not stay centered	Treadmill defect. Contact your Smooth dealer.
	See General Maintenance section under Belt Tracking.
Treadmill belt hesitates when walked/run on	A user may be walking while favoring or putting more weight on either the left or right foot. If this walking pattern is natural, track the belt slightly off-center to the side opposite from the belt movement.
	See Maintenance section on Treadbelt Tension. Adjust as necessary.
Motor is not responsive / Display is lit	Make certain clock is running. This indicates motor should be receiving power to operate. Contact your Smooth dealer.
	Possible treadmill defect. Contact your Smooth dealer. Diagnostics will indicate if warrantable.
Motor "surges", speed fluctuates	Lower electronics require adjustment. Contact your Smooth dealer.
Treadmill will only achieve approximately 7 mph but shows higher speed on display	Low AC voltage to treadmill. Do not use an extension cord. If an extension cord is required it should be as short as possible and heavy duty 16 gauge minimum.
	Low household voltage. Contact an electrician or your Smooth dealer. A minimum of 110 volt AC current is required.
Treadbelt stops quickly/suddenly when tether cord is pulled	High belt/deck friction. See General Maintenance section on lubrication.
Treadmill trips on board 10 amp circuit breaker when running/walking	High belt/deck friction. See General Maintenance section on lubrication.
Computer shuts off when console is touched (on a cold day) while walking/running	Treadmill is not grounded. Static electricity is "crashing" the computer. Refer to Grounding Instructions on page 2.

Smooth Treadmills - LIMITED WARRANTY



CONSULT YOUR PHYSICIAN BEFORE USING THIS PRODUCT.

This Limited Warranty applies in the United States to products manufactured or distributed by Smooth Fitness ("Smooth") under the SMOOTH brand name. The warranty period to the original purchaser for home use only is (lifetime) on the frame, (10) years on motor, (10) years on hush deck, (5) years on slick deck, (5) years on belt, and rollers (3) years on all other parts, and (1) year labor. The warranty for a light commercial setting (under 4 hours use daily) is (lifetime) on the frame, (2) years all parts, and (1) year on labor. This warranty does not cover wear and tear, only manufacturer defects for the periods specified.

Smooth warrants that the Product you have purchased for non-commercial, personal, family or household use from Smooth or from an authorized Smooth reseller is free from defects in materials or workmanship under normal use during the warranty period. Your sales receipt, showing the date of purchase of the Product is your proof of the date of purchase. This warranty only extends to you, the original purchaser. It is not transferable to anyone who subsequently purchases the Product from you. It excludes expendable parts.

During the warranty period Smooth will at no additional charge, repair or replace (at Smooth's option) the part or product if it becomes defective, malfunctions, or otherwise fails to conform with this Limited Warranty under normal non-commercial, personal, family or household use. In repairing the Product, Smooth may replace defective parts, or at the option of Smooth, serviceable used parts that are equivalent to new parts in performance. All exchanged parts and Products replaced under this warranty will become the property of Smooth. Smooth reserves the right to change manufacturers of any part to cover any existing warranty.

To obtain warranty service, you must contact a Smooth authorized service technician or Smooth Fitness at our phone numbers located in this manual. Any parts determined to be defective must be returned to Smooth to obtain warranty service. You must prepay any shipping charges, export taxes, custom duties and taxes, or any other charges associated with transportation of the parts or Product. In addition, you are responsible for insuring any parts or Product shipped or returned. You assume the risk of loss during shipment. You must present Smooth with proof-of-purchase documents (including the date of purchase). Any evidence of alteration, erasing or forgery of proof-of-purchase documents will be cause to void this Limited Warranty.

This warranty does not extend to any product not purchased from Smooth or from an authorized Smooth reseller. This Limited Warranty does not extend to any Product that has been damaged or rendered defective: (a) as a result of accident, misuse, or abuse; (b) by the use of parts not manufactured or sold by Smooth; (c) by modification of the Product or normal wear and tear; (d) operation on incorrect power supplies; or (e) as a result of service by anyone other than Smooth, or an authorized Smooth warranty service provider. Product on which the serial number has been defaced or removed is not eligible for warranty service. Should any Product be submitted for warranty service be found ineligible therefore, an estimate of repair cost will be furnished and the repair will be made if requested by you upon Smooth's receipt of payment or acceptable arrangements for payment.

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY, SMOOTH MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMOOTH EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS LIMITED WARRANTY. NEITHER SMOOTH NOR ANY OF ITS AFFILIATES SHALL BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. This Limited Warranty gives you specific legal rights and you may also have other rights that may vary from state to state. This is the only express warranty applicable to Smooth-branded products. Smooth neither assumes nor authorizes anyone to assume for it any other express warranty.

PLEASE SEND IN THE ATTACHED WARRANTY CARD WITHIN TEN (10) DAYS OF PURCHASE TO REGISTER YOUR TREADMILL WITH SMOOTH FITNESS PRODUCTS. MADE IN THE USA. **Thank you for your business! PLEASE MAIL WARRANTY CARD TO: SMOOTH FITNESS, 717 FELLOW-SHIP RD., SUITE C, MT. LAUREL, NJ 08054**

SMOOTH TREADMILL WARRANTY REGISTRATION			TELEPHONE
FIRST	M.I.	LAST	
ADDRESS			APT. NO.
CITY		STATE	ZIP
____ / ____ / ____			
DATE OF PURCHASE	MODEL NO.	SERIAL NO.	
Name of store or company where purchased:	Where did you learn about treadmills? TV ___ Radio ___ Friend ___ In Store Display ___ Salesperson ___ Print ad/flyer ___ Internet ___	How import are each feature? Least Most Unique Features <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Horsepower <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Warranty <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Price <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Look/Design <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Folding Feature <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	Other Comments: _____ _____ _____ _____
How do you plan to use the treadmill? Walk ___ Run ___ Both ___	Why did you purchase a treadmill? Dr.'s Orders ___ Lose Weight ___ In-home convenience ___ Improve Cardiovascular Fitness ___ Safety from outdoors ___ Other _____	Smooth Fitness respects the rights of your privacy. Our company will not sell or distribute to others the information above. This information is used to track our product quality and to contact you in the event of a product safety concern. It may be used to offer you future product offerings only from Smooth. Please check here if you wish not to receive any additional information on Smooth products <input type="checkbox"/>	
Who will use the treadmill? Male ___ Female ___ Both ___ How many family members? ____		AGE: 15-24 ___ 25-34 ___ 35-44 ___ 45-54 ___ 55-64 ___ 65 + ___	



SMOOTH TREADMILLS – LIMITED WARRANTY

TREADMILL DRIVE MOTOR 10 YEAR WARRANTY ADDENDUM

EFFECTIVE MARCH 1, 2001

FOR THE FOLLOWING SMOOTH TREADMILL MODELS ONLY:

SM5.0P (includes version 2 PV2)
SM5.3P
SM5.1HR
SM9.1P
SM9.1HRC
SM9.2P
SM9.2HR
SM9.2AB (aeropedic belt)
SM9.6P
SM9.6HRC

This Limited Warranty amends the previous drive motor warranty in the treadmill owner's manuals listed above and applies in the United States to products distributed by Internet Fitness.com under the Smooth brand name. The warranty period to the original purchaser for the DRIVE MOTOR is ten (10) years from date of purchase, effective on or after March 1, 2001.

FOR THE CONSUMER: Please retain this page as proof of your new Drive Motor Warranty for future reference.

This Limited Warranty applies in the United States to products manufactured or distributed by Internet Fitness.com under the SMOOTH brand name. The warranty period to the original purchaser is ten (10) years on the drive motor from date of purchase. This Warranty applies only to home use.