

END OF LIFE

TR-5500HRS TREADMILL


GK36-00006-XXXX
SN: HTE266037-HTE273953

Display Console

AK36-00049-0001(R) Eng/Eng - R&R only
AK36-00049-0002(R) Ger/Met - R&R only
AK36-00049-0004(R) Frn/Met - R&R only
AK36-00049-0005(R) Spn/Met - R&R only
AK36-00049-0006(R) Itl/Met - R&R only
AK36-00049-0007(R) Jap/Met - R&R only
AK36-00049-0009(R) Dut/Met - R&R only


Overlay Bezel

AK36-00050-0001 Eng/Eng
AK36-00050-0002 Ger/Met - NLA
AK36-00050-0004 Frn/Met - NLA
AK36-00050-0005 Spn/Met - NLA
AK36-00050-0006 Itl/Met - NLA
AK36-00050-0007 Jap/Met - NLA
AK36-00050-0009 Dut/Met - NLA



TR-5500HRS
TREADMILL

GK36-00006-XXXX
SN: HTE 266037-HTE 273953




TR-5500HRS
TREADMILL

GK36-00006-XXXX
SN: HTE 266037-HTE 273953

Lift Actuator
120v/60Hz
OK36-01012-0004
220v
OK36-01012-0003
Lift Pin Kit
GK45-00002-0009

Heatsink
SK36-00061-0000(R)
120v/60Hz
AK36-00061-0001
220v

Not Shown:
Home Switch
0017-00032-0178
Home Switch Cable
AK36-00025-0000



On/Off Switch
AK40-00052-0000

Line Cord
AK36-00013-0000
Foreign
AK36-00013-0001
220v/60Hz
AK36-00042-0000

Front Panel
OK36-01013-0001