



Cat. KFE2S5



This user's manual contains important information about your fire extin guisher's operation. If you are installing this fire extinguisher for use by others, you must leave this manual—or a copy of it—with the end user

IMPORTANT! Please read carefully and save.

Read extinguisher label and the entire user's manual carefully before installing or using the unit. Make sure everyone in your household is completely familiar with the operation of the extinguisher, and review the instructions regularly. In an emergency, you will not have time to read instructions

TABLE OF CONTENTS

Important Information About Fire Extinguishers
Read Before Installing or Using This Fire Extinguisher
Where to Install This Extinguisher
How to Install This Extinguisher
Checking and Inspecting the Fire Extinguisher
How to Operate Your Fire Extinguisher in a Fire Emergency
After the Fire is Extinguished
If Your Fire Extinguisher Needs Service
Disposing of a Used Extinguisher
5 Year Limited Warranty


IMPORTANT INFORMATION ABOUT FIRE EXTINGUISHERS

NOTE: Be sure the extinguisher is rated to fight the type of fire most likely to occur in the area you choose to install it. Since household fires commonly start in the kitchen, you should always install an extinguisher in the kitchen. For added security, you should also install additional extinguishers in utility areas, and other living areas in your household. your household.

Fire extinguishers are classified by fire type. The A, B and C rating system defines the kinds of burning materials each fire extinguisher is designed to fight. The numbers in front of the A, B, or C indicate the rating for size of the fire the unit can extinguish. Using the wrong type of fire extinguisher can do more harm than good. Make sure you understand which fire extinguisher to use on each class of fire!



Class A rating: The agent/powder is suitable for fighting small fires involving wood, paper, cloth, rubber, and some plastics.



Class C rating: The agent/powder is suitable for fighting small fires in "live" electrical equipment.

READ BEFORE INSTALLING OR USING THIS FIRE EXTINGUISHER!

Model KFE2S5 is rated 5-B:C. This unit is NOT rated to fight Class A fires.

- This extinguisher is designed for use against small fires that have just started and are small enough to fight safely. It is not designed to fight large fires that are burning out of control. If the fire is too hot or smoky for you to get within 6 feet (2 meters) of it, do not try to fight it yourself. Warn everyone, evacuate the premises, and have someone call the Fire Department from outside the building. Trying to fight a large fire yourself can result in injury or death.
- Do not puncture or burn any fire extinguisher. The contents are under pressure, and the extinguisher could explode.
- Never locate this extinguisher close to an engine, stove or other source of heat. It is pressurized and could rupture or explode if exposed to temperatures over 150°F (66°C).

This extinguisher contains a dry powder extinguishing agent. The agent/powder is not toxic, but can irritate skin. When using this unit, avoid breathing the powder. Always ventilate the area

WHERE TO INSTALL THIS EXTINGUISHER

A Fire Extinguisher Should Be Mounted

- In the vicinity of (but not on or in) a potential source of heat and/or fire. like an oven or stove.
- Where it is easy to reach, near an exit or an escape route from
- In a location that is convenient, in plain sight, and 3-1/2 to 5 feet above the floor.
- Store the extinguisher high enough to keep it out of the reach
- On a clean, dry surface where the temperature does not go above 120° F (49° C) or below –40° F (-40°C).

HOW TO INSTALL THIS EXTINGUISHER

ACAUTION!

- Do not mount the extinguisher on drywall or plaster without adequate support. Use strong screws or bolts to mount the bracket securely into solid wood or metal that can support it, like a wooden partition stud. Secure mounting is needed so you can remove the extinguisher quickly and easily in an emer gency. Also, if the extinguisher is not held securely, it could drop to the floor and injure people or damage the extinguisher
- Do not break the safety seal! This seal prevents accidental discharge of the fire extinguisher. Break the seal only in an emergency before using the fire extinguisher.


NOTE: Since wall surface types vary, mounting screws are not included. Purchase screws or bolts specifically designed for the surface on which you will mount the fire extinguisher. The fire extinguisher label lists its maximum weight

The plastic cap on this extinguisher serves as a quick-release wall mounting bracket.

If you do not mount the fire extinguisher on the wall, you must remove the cap and store it separately. Failure to remove the cap from a free-standing extinguisher may prevent it from working properly in an emergency

REMOVE THE MOUNTING BRACKET/CAP


- Hold the extinguisher with the back (mounting surface) of the cap facing you. Make sure to hold the metal canister, not the plastic cap.
- Grasp the rectangular release handle on the back of the cap. Pull the handle up to remove the cap/bracket from the extinguish-



MOUNT THE BRACKET/CAP ON A WALL


Remember--Do not mount the extinguisher on drywall or plaster without adequate support (see 'Caution' above.)

Install the mounting bracket on a wooden stud or other solid surface that will support the weight of the extinguisher. Use 1-1/4" long #8 pan or round screws with a #8 washer as shown. Choose at least two of the six holes provided on the Mounting Bracket/Cap. Using two holes that are opposite each other (i.e. the top and bottom center holes) is recommended Mounting screws are not included (see



SECURE EXTINGUISHER TO BRACKET/CAP

After installing the mounting bracket, replace the extinguisher on the bracket with the label facing outward, so the label can be easily read.



CHECKING AND INSPECTING THE FIRE EXTINGUISHER

AWARNING!

Do not check the pressure or test the fire extinguisher by spray ing it, even briefly. Once used it will gradually lose pressure and will not be fully charged for use in an emergency.

Inspect and test the extinguisher once a week. Start by removing the extinguisher from the mounting bracket/cap.

- Review the manual and instruction label with everyone in your home. Everyone should know how to use the extinguisher in
- Check the extinguisher pressure by pressing the green button on top of the cap as shown in "Checking the Pressure." If the button pops back up, the extinguisher is properly pressurized and ready to use. If the button stays down, the extinguisher has lost pressure and must be replaced. If the unit is still under warranty, return it to BRK Brands, Inc. immediately. If the warranty has expired, take the unit outside and discharge the contents completely. Discard the old extinguisher and replace it immediately.





While the extinguisher is off the mounting bracket, check for any signs of damage or misuse. Make sure you can still read all the text on the label.

- Carefully examine the surface of the extinguisher for corrosion. You can help prevent corrosion by cleaning the extinguisher if it gets wet or dirty. If you notice corrosion during the warranty period, return the unit to BRK Brands, Inc. (see warranty information at the end of this manual).
- Make sure the tamper indicator ("safety seal") is still intact as shown in "Location Of The 'Safety Seal'" Make sure the nozzle s clean and unobstructed.
- When you finish inspecting the extinguisher, put it back securely into the mounting bracket.



IMPORTANT!

For more information about fire extinguishers, consult the NFPA Standard #10, "Portable Fire Extinguishers," available from the National Fire Protection Association, Inc., Batterymarch Park, Quincy, MA 02169, USA

HOW TO OPERATE YOUR FIRE EXTINGUISHER IN A FIRE EMERGENCY

ADANGER!

Make sure your extinguisher may be safely and effectively used on the small fire you want to fight. Always use extreme caution when fighting any fire. Fight a fire only where there is a clear escape path to allow you to get out safely if the fire

AWARNING!

Avoid breathing smoke and heated fumes; stay low if necessary. Burning materials will release toxic fumes. Inhaling these fumes may cause injury or death.

ACAUTION!

- Always stand back far enough away from the fire—near an exit—and make sure nothing is between you and your escape route. If you get too close to a fire, you risk getting burned or hit by splattering material like grease. If the fire is too hot or smoky for you to get within 6 feet (2 meters), DO NOT try to fight the fire yourself. Evacuate immediately and sell the Fire Popurhment. call the Fire Department.
- For fires on a kitchen stove, turn oven or burners off immediately if possible. If you can't reach the oven or burner controls safely, extinguish the fire first, then turn them off
- Fight the fire from an upwind direction with your back to any strong air current. Trying to fight a fire with currents blowing towards you can result in serious injury.

TO FIGHT THE FIRE

AWARNING!

This unit will not operate with mounting bracket attached. The extinguisher must be removed from the mounting bracket or it cannot discharge its contents to fight a fire.







Remove Extinguisher from Bracket/Cap

Press Lever To Discharge Powder

1. Remove the extinguisher from the mounting bracket.

- Hold the unit firmly with the nozzle facing away from you. Pull out the pin to break the "Safety Seal". You won't be able to squeeze the trigger until the safety seal is removed.
- Stand back 6 feet (2 meters) from the fire and make sure the fire is not between you and your exit.
- Hold the extinguisher upright and aim the nozzle at the base
- Press the lever to discharge the powder.
- Sweep the spray at the base of the burning material, using quick side-to-side motions. (If the spray scatters the fire, move back.)
- Move slowly towards the fire as the extinguisher spray pushes the fire back. Maintain a 6-foot (2 meter) distance between you and the front of the fire at all times.
- Completely discharge the contents of the extinguisher and make sure the fire is completely out. Flashbacks are common with fires.

AFTER THE FIRE IS EXTINGUISHED

After any fire it is advisable to have the area inspected by the Fire Department. The powder spray from the extinguisher may spread over a wide area, and may soil upholstery, carpets and walls. You should clean up the powder as soon as possible

ADANGER!

Do not turn the electrical power back on or plug in any appliances until the area has been cleaned up completely. It is very important to remove the powder from electrical equipment after a fire. If the powder gets wet, it can conduct electricity. (Using a dry chemical extinguisher on wet electrical equipment may be hazardous for this reason.) This may worsen an electrical leakage problem, impair the equipment's insulation, or create an electrical shock hazard.

If the fire was on a kitchen stove

- Make sure the oven and all burners are turned off
- Clean up the powder completely before using the stove or oven-this is especially important for self-cleaning ovens. Ventilate the area thoroughly.

If you think the fire had an electrical origin:

- Shut off the electrical power, if possible--do not touch any electrical wires or appliances
- Leave the building and close all doors behind you. Call the Fire Department and have them inspect the entire house As soon as they say it's safe to return, ventilate the area thoroughly.
- Have a licensed electrician inspect your electrical system. Do not turn the power back on or plug in any electrical equipment until the inspection has been completed.

IF YOUR EXTINGUISHER NEEDS SERVICE

This fire extinguisher is a disposable device that is NOT rechargeable

ACAUTION!

Do not try to service or repair this fire extinguisher under any circumstances. Do not try to remove the nozzle or valve assembly. This is a pressurized device that can cause serious injury if

If there is a problem and it is still under warranty, return it, shipping prepaid to BRK Brands, Inc.: Consumer Affairs, 3920 Enterprise Court, Aurora IL 60504-8132.

DISPOSING OF A USED EXTINGUISHER

Completely discharge the extinguisher outdoors, dispose of the unit properly, and replace it with a new fire extinguisher.

ADANGER!

Never puncture, burn or expose this fire extinguisher to temperatures over 150° F (66° C) even if it is fully discharged. The contents are under pressure and it could explode.

5 YEAR LIMITED WARRANTY

Coverage: BRK Brands, Inc. ("BRK") the maker of First Alert® brand products, warrants that for a period of five years from the date of purchase, this product will be free from defects in material and workman-ship. BRK, at its option, will repair or replace this product or any com-ponent of the product found to be defective during the warranty peri-od. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. BRK dealers, service centers, or retail stores selling BRK products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than BRK or an authorized service center. Further, the warranty does not cover acts of God, such as fire, flood, hurricanes and tornadoes or any batteries that are included with this unit.

BRK shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces, or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This war-ranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province.

How to Obtain Warranty Service:

Service: If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Consumer Affairs Division at 1-800-323-9005, 7:30 AM to 5:00 PM, Central Standard Time, Monday through Friday. To assist in serving you, please have the model number and date of purchase available when calling. 3920 Enterprise Court, Aurora, IL 60504-8132.

All Rights Reserved. © 2002 BRK Brands, Inc. First Alert*, 3901 Liberty Street Road, Aurora, IL 60504-8122 Consumer Affairs: (800) 323-9005 • www.firstalert.com

First Alert® is a registered trademark of the First Alert Trust.

M06-3008-00X M 04/02