



**NOW WE'RE
COOKING**

KitchenAid[®]

USE & CARE GUIDE


**33" BUILT-IN
ELECTRIC COOKTOP
MODEL
KECS-1340**

CONTENTS

	Page No.
SAFETY INSTRUCTIONS	3
OWNERSHIP REGISTRATION	4
FEATURES	5
Types of Elements	5
Control Knobs	6
How to Operate	6
Control Knob Settings	6
CARE OF YOUR NEW COOKTOP	7
Surface Elements	7
To Remove Elements	7
To Replace Elements	7
Cautions	7
CLEANING OF YOUR NEW COOKTOP	8
Cooktop Elements	8
Control Knobs	8
Chrome-Plated Drip Pans	8
Under Cooktop	8
Outside Finishes	8
WHEN YOU NEED SERVICE	9
DISTRIBUTOR LISTING	10-11
WARRANTY	12

IMPORTANT SAFETY INSTRUCTIONS

1. Proper Installation — Be sure your cooktop is properly installed and grounded by a qualified technician.
2. Never Use Your Cooktop for Warming or Heating the Room.
3. Do Not Leave Children Alone — Children should not be left alone or unattended in area where cooktop is in use. They should never be allowed to sit or stand on any part of the cooktop.
4. Wear Proper Apparel — Loose fitting or hanging garments should never be worn while using the cooktop.
5. User Servicing — Do not repair or replace any part of the cooktop unless specifically recommended in the manual. All other servicing should be referred to a qualified technician.
6. Storage In or On Cooktop — Flammable materials should not be stored in or near cooktop.
7. Do Not Use Water on Grease Fires. Never Pick Up a Flaming Pan — Smother flaming pan on cooktop by covering pan completely with well fitting lid, cookie sheet or flat tray. Flaming grease outside pan can be extinguished by baking soda or, if available, a multipurpose dry chemical or foam type extinguisher.
8. Use Only Dry Pot Holders — Moist or damp pot holders on hot surfaces may result in burns from steam. Do not let pot holder touch hot heating elements. Do not use a towel or other bulky cloth.
9. Use Proper Pan Size — This cooktop is equipped with one or more elements of different size. Select utensils having flat bottoms large enough to cover the element. The use of undersized utensils will expose a portion of the element to direct contact and may result in ignition of clothing. Proper relationship of utensil to element will also improve efficiency.
10. Never Leave Elements Unattended at High Heat Settings — Boil over causes smoking and greasy spillovers that may ignite.
11. Make Sure Drip Pans are in Place — Absence of these pans during cooking may subject wiring or components underneath to damage.
12. Protective Liners — Do not use aluminum foil or line cooktop drip pans, except as suggested in the manual. Improper installation of these pans may result in a risk of electric shock or fire.
13. Glazed Cooking Utensils — Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for range top service without breaking due to the sudden change in temperature.
14. Utensil Handles Should be Turned Inward and Not Extended Over Adjacent Elements — To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil, the handle of a utensil should be positioned so that it is turned inward, and does not extend over adjacent elements.
15. Do Not Immerse or Soak Removable Heating Elements — Heating elements should never be immersed in water.



OWNERSHIP REGISTRATION CARD

Take a minute...

Before you use your cooktop, please fill out and mail your ownership registration card. This card will enable us to contact you in the unlikely event of a product safety notification and assist us in complying with the provisions of the Consumer Product Safety Act. THIS CARD DOES NOT VERIFY YOUR WARRANTY.

Keep a copy of the bill of sale showing the date of purchase and/or date of installation of your cooktop. PROOF OF PURCHASE WILL INSURE YOU OF IN-WARRANTY SERVICE.

Write down the following information. You will need it if your cooktop ever requires service.

MODEL NUMBER* _____ SERIAL NUMBER* _____

DATE PURCHASED _____ DATE INSTALLED _____

DEALER'S NAME _____

ADDRESS _____

PHONE _____

* Model Number and Serial Number are found on a nameplate attached to the inside right rear corner of the burner box bottom.

KITCHENAID ELECTRIC COOKTOP

Your new KitchenAid cooktop is equipped with surface elements which have been specifically designed to provide you with an infinite number of cooking temperatures to meet your cooking needs.


Your cooktop is equipped with three "types" of elements:

Two 6-inch, 1250 watt elements for small cooking utensils (6-inch skillet, 2 to 2½-quart saucepan).

One 8-inch, 2100 watt element for large pots and pans (8-inch to 10-inch skillet, 3 to 6-quart saucepan).

and

One 8-inch, 2650 watt POWER™ BURNER powered to handle large cooking utensils and very large cooking loads (8 to 10-quart stockpot, woks). The POWER BURNER is located on the right front.



The control knobs for each element have infinite positions ranging from "HI" for highest level of heat available to "LO" for simmer or the lowest heat. There are no fixed positions between "HI" and "LO". You may turn the control knobs in any direction, to any of the settings indicated, or to any position in between.

The diagram below each knob indicates which element that particular knob controls.

To operate, grasp the control knob, push down and turn in either direction. The indicator light will glow as long as one or more elements are on.

CONTROL KNOB SETTINGS

The following are suggested heat settings to be used as a guide when cooking:


HI To start foods cooking and to bring foods to boiling.

MED-HI (6-5) For very fast frying, rapid boiling or for boiling large amounts of water.

MED (5-3) To continue frying after starting on HI. For foods cooked in a double boiler.

MED-LOW (3-2) To continue boiling or cooking medium to large amounts of food.

LO To keep smaller amounts of food at the boiling point and for gently simmering foods, melting butter, chocolate, etc.




Remember, the size and type of utensil used and the amount and type of food being cooked will influence the setting needed. For best cooking results, always use cooking utensils with flat bottoms, straight sides and tight fitting covers.

Use only the correct size utensils. Reflected heat from utensils much larger than outside edge of the heating element may result in damage to the cooktop or drip pans. Utensils smaller than the heating element expose a portion of the element, causing possible exposure of the heated element and loss of energy.

COOKTOP ELEMENTS

Clean area under chrome-plated drip pan frequently. Accumulated soils, especially grease, may catch fire.



TO REMOVE ELEMENTS:

- Always be certain that the control for that element is at OFF position and the coils are cool before attempting to remove the element.
- Raise the element, at point opposite receptacle, about 1 inch above the drip pan and pull it away from the receptacle.
- Carefully pull the element terminals through the opening in the drip pan. After removing the element, remove the drip pan to clean under the unit.
- Wipe around edges of the opening in the cooktop and rinse with damp cloth or sponge.

TO REPLACE ELEMENTS:

- Place chrome-plated drip pan into the opening in the cooktop so the receptacle can be seen through opening in pan.
- Insert terminals of elements through opening in drip pan and into receptacle.
- Guide the element into place so it fits evenly. To make sure element sits flat, place palm of hand flat on top of element to exert a slight downward force. Push element all the way toward the receptacle.

CAUTIONS:

- DO NOT put elements in your dishwasher or immerse them in liquid of any kind. See cleaning tip for cleaning surface elements.
- DO NOT attempt to clean the elements or chrome-plated drip pans in a self-cleaning oven.
- DO NOT cover drip pans with aluminum foil.
- DO NOT let the two electrical ends of the elements get damaged or bent. The terminals are sturdy and will not be damaged if handled with reasonable care. The element terminals and receptacle are designed to line up automatically when plugged together. If the terminals are badly bent and cannot be plugged into the receptacle, the element should be taken to a service center for replacement.
- DO NOT attempt to clean, adjust or in any way repair the element receptacle. If any abundance of liquid should accidentally spill and collect inside the receptacle, call for service.

NOTE: Be certain all cooktop parts are cool before cleaning.

COOKTOP ELEMENTS

Spatters and spills burn away when elements are heated. At end of meal, heat soiled elements on "HI". Let soil burn off "about a minute", then turn element to "OFF".

Avoid getting cleaning materials on elements. Wipe off any cleaning materials with damp paper towel before heating unit.

Always let elements cool completely before handling.

CONTROL KNOBS

The control knobs can be removed by pulling them off the switch stem and washing with warm, soapy water. Dry and return knobs to cooktop matching flat area on knob and shaft.

CAUTION:

When cleaning control panel with control knobs removed, do not allow water to run down inside.

CHROME-PLATED DRIP PANS

Wipe any spills as soon as possible to prevent "baked-on" spatters. Clean in dishwasher or warm, soapy water, rinse and wipe dry.

"Baked-on" soil may be removed using a stiff-bristled brush and warm, soapy water or rubbing lightly with a soap filled scouring pad.

UNDER COOKTOP

To clean inside cooktop, check all control knobs to be sure they are in the OFF position. Then raise cooktop and put the support rod in position to hold cooktop up. Clean with warm, soapy water. Dry thoroughly.

OUTSIDE FINISHES

Porcelain Enamel

The porcelain enamel used on your cooktop is acid resistant, but not acid proof. Therefore, if acid foods such as citrus juices, tomatoes, rhubarb or vinegar, as well as alcohol or milk, are spilled on the porcelain enamel, they should be wiped up immediately and not permitted to remain on the surface as they may effect the finish. Use a paper towel or dry cloth on warm surfaces. After the porcelain enamel has cooled, you may wash it with warm, soapy water, rinse and dry.

Avoid cleansing powders or harsh abrasives which may cause scratching.

Brushed Chrome

Wash with warm, soapy water and rinse. Dry with soft cloth. Never use steel wool, abrasives, ammonia, acids or commercial oven cleaners which may damage finish.

WHEN YOU NEED SERVICE

FOLLOW THESE STEPS

1. If your cooktop should fail to operate, review the following list before calling your dealer. You could save the cost of a service call.

- Has a fuse blown, or is the circuit breaker open?
- Are heating elements properly seated in receptacles?

2. If the problem is not due to one of the above items, see "Who to Call for Service" listed in the Warranty Statement.

3. If you are not satisfied with the action taken, contact the Major Appliance Consumer Action Panel (MACAP). MACAP is a group of independent consumer experts that voices consumer views at the highest levels of the major appliance industry. Contact them only when the dealer, authorized servicing outlet, wholesale distributor, and Hobart Corporation have failed to resolve your problem.

Major Appliance Consumer Action Panel
20 North Wacker Drive
Chicago, IL 60606

MACAP will in turn inform us of your action.

In all correspondence about your cooktop, please include:

- Date
- Your Name, Address, and Telephone Number
- Type of Appliance
- Brand
- Model Number
- Serial Number
- Date Purchased
- Dealer from Which Purchased (include address)
- Servicing Agent (include name and address if different from dealers)
- Location of Appliance
- A Clear Description of the Problem and the Service Required

ALABAMA

Birmingham 35201
Bellows-Evans, Inc.
P.O. Box 1537
(205) 791-0890

ALASKA

Anchorage 99501
North by Northwest, Inc.
1000 E. 4th Avenue
(907) 278-3595

ARIZONA

Phoenix 85043
National Brands, Inc.
4633 W. Polk Street
(602) 269-3201

ARKANSAS

Little Rock 72209
Arkansas Appliance Dist. Co.
5500 Patterson Rd.
(501) 568-4310

CALIFORNIA

Burlingame 94010
R & K Distributors, Inc.
1701 Rollins Rd.
P.O. Box 4348
(415) 692-3062
Commerce 90040
Sues, Young & Brown, Inc.
2200 Saybrook Ave.
P.O. Box 22171
(213) 724-2400
Fresno 93715
Devlin-Drew Co.
165 Broadway
P.O. Box 1326
(209) 233-8811
San Diego 92126
Sues, Young & Brown, Inc.
9586 Dist. Ave.
Suite "H" (619) 693-8839

COLORADO

Denver 80239
McNair Distributing Co.
5015 Paris Street
P.O. Box 39921
(303) 371-2780

CONNECTICUT

North Haven 06473
The Boyd Corporation
450 Sackett Point Rd.
P.O. Box 476
(203) 288-3821

FLORIDA

Jacksonville 32203
Cain & Bultman, Inc.
2145 Dennis St.
P.O. Box 2815
(904) 356-4812
Miami 33169
Cain & Bultman, Inc.
1111 N.W. 165th Street
(305) 625-0461
Tampa 33602
Cain & Bultman, Inc.
202 N. 11th Street
(813) 229-6571

GEORGIA

Atlanta 30325
W. D. Alexander Co.
Division of Cain & Bultman, Inc.
P.O. Box 19818
(404) 351-8200

HAWAII

Aiea 96701
Hobart Corporation
99-950 Iwaena St.
(808) 487-8910

ILLINOIS

Oak Brook 60521
Remco-Federal, Inc.
620 Enterprise Dr.
(312) 654-2111
Peoria 61615
Remco-Federal, Inc.
8635 N. Industrial Rd.
(309) 692-4521

INDIANA

Indianapolis 46219
Rodefeld Co., Inc.
8641 E. 30th St.
P.O. Box 19326
(317) 898-0670
South Bend 46625
Mid West Sales and Ser., Inc.
917 S. Chapin St.
(219) 287-3365

IOWA

Davenport 52807
Remco-Federal, Inc.
3707 Mississippi Ave.
(319) 386-3040
Des Moines 50309
H. E. Sorenson Co.
100 S.W. First St.
(515) 244-6267

KANSAS

Wichita 67202
Liberty Distributors, Inc.
149 N. Rock Island
(316) 264-7393
Lenexa 66215
Zenith Distributing Corp. of Kansas
12600 W. 93rd St.
(913) 888-4800

KENTUCKY

Louisville 40201
Roth Dist. Co., Inc.
3001 Crittenden Dr.
P.O. Box 2161
(502) 634-4701

LOUISIANA

New Orleans 70183
Geo. H. Lehleitner & Co., Inc.
P.O. Box 23707
(504) 734-0530
Shreveport 71166
Tri-States Distributing Co., Inc.
P.O. Box 1740
(318) 221-0553

MAINE

Portland 04106
The Boyd Corporation
75 Darling Ave.
(207) 774-0326

MARYLAND

Baltimore 21223
The Zamowski Co.
1101 DeSoto Rd.
(301) 644-2900

MASSACHUSETTS

Woburn 01801
The Boyd Corporation
112 Commerce Way
(617) 935-9165

MICHIGAN

Lansing 48901
Geo. Worthington Co.
1611-35 N. Grand River Ave.
(517) 487-3701
Alma 48801
Fischer-Flack, Inc.
6585 N. Jerome
(517) 463-6104
Taylor 48180
Radio Distributing Co.
27015 Trolley Dr.
(313) 295-4500
Wyoming 49508
Radio Distributing Co.
425 36th Street S.W.
(616) 531-2310

MINNESOTA

Eden Prairie 55344
Roth Distributing Co., Inc.
7640 Commerce Way
(612) 937-9540

MISSISSIPPI

Jackson 39209
McKee and McRae, Inc.
845 Boling St.
(601) 969-3002

MISSOURI

St. Louis 63146
Roth Distributing Co., Inc.
2392 Grissom Dr.
(314) 567-4100

MONTANA

Billings 59107
Taylor Distributing Co.
4148 First Ave. South
P.O. Box 30237
(406) 245-3055

NEBRASKA

Omaha 68127
The Mark Anthony Co.
9767 "I" St.
(402) 339-5410

NEW JERSEY

Newark 07102
Igoe Appliance Corp.
35 Halsey St.
(201) 624-2000

NEW MEXICO

Albuquerque 87197
Consolidated Dist. Co., Inc.
Sun City Warehouse
1421 Broadway, N.E.
P.O. Box 6364 Station "B"
(505) 247-0137

NEW YORK

Buffalo 14203
Lee Distributing Co., Inc.
845 Washington St.
(716) 856-7921
Latham 12110
Empire State Wholesalers, Inc.
5 Avis Dr.
P.O. Box 759
(518) 783-5511
Syracuse 13211
Lee Distributing Co., Inc.
6671 Commerce Blvd.
(315) 437-6544
Woodbury 11797
Leck Industries, Ltd.
135 Crossways Park Dr.
(516) 921-8000

NORTH CAROLINA

Charlotte 28208
Southern Radio Corp.
1625 W. Morehead St.
P.O. Box 668309
(704) 376-4461
Raleigh 27611
Warren Distributing Corp.
226 Glenwood Ave.
P.O. Box 26628
(919) 828-9100

NORTH DAKOTA

Fargo 58102
Northern Plains Dist., Inc.
4014-15th Ave. North
(701) 282-7500

OHIO

Cincinnati 45227
The Tracy-Wells Co.
5660 Wooster Pike
(513) 271-1813
Columbus 43214
The Tracy-Wells Co.
3568 Indianola Ave.
P.O. Box 14333
(614) 261-0331
Dayton 45401
V. J. McGranahan, Inc.
1415 Stanley Ave.
P.O. Box 922
(513) 222-9911
Solon 44139
Midland Dist. Inc.
5100 Naiman Parkway
(216) 248-8040
Holland 43528
McKimmy & Elliott Dist. Co.
6509-25 Angola Rd.
P.O. Box 367
(419) 865-5377

OKLAHOMA

Oklahoma City 73105
Modern Distributors, Inc.
200 E. Hill
(405) 528-4537

OREGON

Portland 97214
Dean Distributing Co., Inc.
139 S.E. Taylor St.
P.O. Box 14039
(503) 238-0558

PENNSYLVANIA

Duncansville 16635
Good Distributors, Inc.
Corner Routes 22 & 220
P.O. Box 306
(814) 696-0246
Kingston 18704
Arrow Appliances &
Electronics Dist. Co.
936 Rutter Ave.
P.O. Box 1428
(717) 287-2188
Philadelphia 19116
S. S. Fretz, Jr., Inc.
2001 Woodhaven Rd.
(215) 671-8300
Pittsburgh 15221
Houston-Starr Co.
300 Brushton Ave.
(412) 242-6000
York 17405
Raub Supply Co.
3001 W. Market St.
(717) 792-9711

RHODE ISLAND

Providence 02914
The Boyd Corporation
315 Harris Ave.
(401) 421-9005

SOUTH CAROLINA

Columbia 29201
Southern Radio Corp.
Stadium Road
P.O. Box 467
(803) 799-6143

SOUTH DAKOTA

Sioux Falls 57103
Max Pasley, Inc.
506 S. Cliff
(605) 336-3760

TENNESSEE

Chattanooga 37421
153 Warehouse Mart
(615) 899-1290
Knoxville 37919
Creswell & Co., Inc.
3910 Papermill Rd.
(615) 584-9171
Memphis 38114
King Kitchens, Inc.
2449 Scaper St.
(901) 743-9821
Nashville 37202
Hermitage Electric Sup. Corp.
531 Lafayette St.
P.O. Box 24990
(615) 244-4167

TEXAS

Amarillo 79105
Consolidated Dist. Co., Inc.
2300 North Western
P.O. Box 149
(806) 372-1246
Dallas 75243
The Stewart Co.
11000 N. Central Expressway
(214) 691-5555

El Paso 79901
Consolidated Dist. Co., Inc.
1830 Mills Ave.
(915) 533-4464
Houston 77043
Earl McMillan Sales, Inc.
1100 W. Belt Dr., North
(713) 467-1751
San Antonio 78294
Central Distributing Co.,
1201 E. Houston Street
P.O. Box 1229
(512) 225-1541

UTAH

Salt Lake City 84125
Wells Dist. Co.
2620 S. 900 West
P.O. Box 25008
(801) 972-8700

VERMONT

Burlington 05402
Vermont Appliance Co.
44 Lakeside Ave.
(802) 864-9831

VIRGINIA

Richmond 23223
Bluefield Distributing Co.
2400 Magnolia Court
(804) 649-7521
Roanoke 24015
Dixie Appliance Co.
P.O. Box 4009
(703) 342-6000

WASHINGTON

Tukwila 98188
F.B. Connelly Co.
720 Andover Park E.
P.O. Box 88407
(206) 575-0410
Seattle 98134
North by Northwest, Inc.
270 S. Hanford Street
(206) 447-1800
Spokane 99220
Taylor Distributing Co., Inc.
East 124 Sinto
P.O. Box 3435 TA
(509) 328-8110

WEST VIRGINIA

Charleston 25326
Eskew, Smith & Cannon
1206 Smith St.
P.O. Box 1626
(304) 344-3411

WISCONSIN

Milwaukee 53225
Roth Distributing Co., Inc.
11925 W. Carmen Ave.
(414) 353-9000

KitchenAid

COOKING EQUIPMENT

WARRANTY

LENGTH OF WARRANTY:

ONE YEAR FULL WARRANTY FROM DATE OF INSTALLATION

FIVE YEAR LIMITED WARRANTY ONE YEAR FULL PLUS SECOND THROUGH FIFTH YEAR LIMITED FROM DATE OF INSTALLATION

KITCHENAID WILL PAY FOR:

Replacement parts and repair labor to correct defects in materials or workmanship. Service must be provided by a KitchenAid wholesale distributor or by one of their authorized KitchenAid servicing outlets.

Replacement parts (labor costs not included) for any electric element on electric models or any burner on gas models if defective in materials or workmanship.

Replacement part (labor costs not included) for the magnetron tube in the combination microwave/single wall oven if defective in materials or workmanship.

KITCHENAID WILL NOT PAY FOR:

- A. Service calls to:
1. Correct the installation of the cooking equipment.
 2. Instruct you how to use the cooking equipment.
 3. Replace house fuses or correct house wiring.
- B. Repairs when cooking equipment is used in other than normal home use.
- C. Damage resulting from accident, alteration, misuse, abuse, improper installation or installation not in accordance with local electrical codes.
- D. Any labor costs during limited warranty.

HOBART CORPORATION DOES NOT ASSUME ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion or limitation may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

HOW TO ARRANGE FOR SERVICE

- First call your dealer or repair service he recommends.
- If you are unable to obtain satisfactory service, contact the KitchenAid wholesale distributor in your area. A complete distributor listing is printed in the Use and Care Guide furnished with the product.
- All service should be handled locally by the dealer from whom you purchased the unit or an authorized KitchenAid servicing outlet or wholesale distributor. If your local service is not satisfactory, contact the Customer Relations Department, KitchenAid Inc.

KITCHENAID, INC.