



imagination at work

GE Digital Camera

J Series : J1470S



User Manual

Preparations

Basic operation

Camera function controls

Playback

Using the Menu

Camera connectivity

Appendix

WARNING

Do not expose the camera battery pack or other accessories to rain or humidity to prevent fire hazard or electric shock.

For customers in the U.S.A.

Tested To Comply With FCC Standards FOR HOME OR OFFICE USE

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For customers in Europe



"CE" mark indicates that this product complies with the European requirements for safety, health, environment and customer protection. "CE" marked cameras are intended for sales in Europe.



This symbol [crossed-out wheeled bin WEEE Annex IV] indicates separate collection of waste electrical and electronic equipment in the European countries. Please do not throw the equipment into the domestic refuse. Please use the return and collection systems available in your country for the disposal of this product.

Declaration of Conformity

Model Name: J1470S

Trade Name: GE

Responsible Party: General Imaging Co.

Address: 1411 W. 190th Street, Suite 550, Gardena,
CA 90248, U.S.A.

Customer Service Telephone Number:
+1-800-730-6597

(Outside U.S. & Canada: +1-310-755-6857)

Conforms to the following Standards:

EMC: EN 55022:1998/A1:2000/A2:2003 Class B
EN 55024:1998/A1:2001/A2:2003
EN 61000-3-2:2000/A1:2001
EN 61000-3-3:1995/A1:2001

following the provision of the EMC Directive (89/336/
EEC,2004/108/EEC)

SAFETY PRECAUTIONS

Camera notes:

- ❗ Do not store or use the camera in the following types of locations:
 - In the rain, very humid and dusty places.
 - In a place where the camera can be exposed directly to the sunlight or subject to high temperature, e.g. Inside a closed car in summer.
 - In a place where the camera is subject to a high magnetic field, e.g. near motors, transformers or magnets.
- ❗ Do not place the camera on a wet surface or places where dripping water or sand may come in contact with the camera, which may cause irreparable faults.
- ❗ If the camera will not be used for a long period of time, we suggest you remove the battery and the memory card from the camera and keep them in dry environment.
- ❗ If you carry the camera suddenly from a cold location to a warm place, moisture may condense inside the camera. We suggest you wait for a while before turning on the camera.
- ❗ No compensation for loss of recordings. Loss of recordings cannot be compensated for if a malfunction of your camera or recording media, etc, makes the playback of recordings not possible.

Battery notes:

- ❗ Incorrect use of the batteries may cause them to leak, become hot, ignite or burst. Always observe the precautions given below.

- Do not expose the batteries to water, and take particular care to keep the terminals dry.
- Do not heat the batteries or throw them into a fire.
- Do not attempt to deform, disassemble or modify the batteries.

- ❗ Keep the batteries out of reach of babies and small children.
- ❗ In cold locations, battery performance deteriorates and the time for which they can be used shortens markedly.

Memory card notes:

- ❗ When using a new memory card, or a memory card has been initialized by a PC, be sure to format the card with your digital camera before using it.
- ❗ To edit image data, copy the image data to the PC's hard disk first.
- ❗ Do not change or delete the folder names or file names in the memory card from your PC, as this may make it impossible to recognize or misinterpret the original folder or file in your camera.
- ❗ The photos taken by this camera are stored in the auto-generated folder in SD card. Please do not store photos that are not taken by this model of camera, as this may make it impossible to recognize the picture when the camera is in playback mode. Please do not expose the camera to harsh environments such as moisture or extreme temperatures, which may shorten the life of your camera or damage the batteries.

BEFORE YOU START

Preface

Thank you for purchasing this GE digital camera. Please read this manual carefully and keep it in a safe place for future reference.

Copyright

© Copyright 2011 General Imaging Company All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, by any means, without the prior written permission of General Imaging Company.

Trademarks

All trademarks mentioned in this manual are used for identification purposes only and are properties of their respective owners.

Safety information

Please read the following important information carefully before using the product.

- Do not take apart or attempt to service the camera yourself.
- Do not drop or knock the camera. Improper handling may damage the product.
- Turn off the camera before inserting or removing the battery and memory card.
- Use only the type of battery that come with the camera. Using other types of batteries may damage the camera and invalidate the warranty.
- Do not touch the camera lens.
- Please not expose the camera to harsh environments such as moisture, or extreme temperatures, which may shorten the life of your camera or damage the batteries.
- Do not use or store the camera in dusty, dirty, or sandy areas, as its components may be damaged.

- Do not expose the lens to direct sunlight for extended periods.
- Download all pictures and remove the batteries from the camera if you are going to store the camera for long periods of time.
- Do not use abrasive cleansers, alcohol-based, or solvent-based cleaners to clean the camera. To clean, wipe the camera with a slightly damp soft cloth.

About this manual

This manual provides you with instructions on how to use your GE digital camera. Every effort has been made to ensure that the contents of this manual are accurate, however General Imaging Company reserves the right to make changes without notice.

Symbols used in this manual

Throughout this manual, the following symbols are used to help you locate information quickly and easily:



Indicates the useful information to know.



Indicates precautions to be taken while operating the camera.

CONTENTS

WARNING	i	Setting Date/Time and Language	15
SAFETY PRECAUTIONS	ii	Setting the Language	15
BEFORE YOU START	1	Setting the Date and Time	16
Preface	1	About the LCD Screen	17
Copyright	1	BASIC OPERATION	18
Trademarks	1	Shooting in Auto Mode	18
Safety information	1	Using the Zoom Function	18
About this manual	2	Flash	19
Symbols used in this manual	2	Self-timer	19
CONTENTS	3	Macro Mode	20
GETTING READY	7	i button function	20
Unpacking	7	Face Detection.....	21
Camera Views.....	8	Smile Detection.....	21
Charging the Battery.....	10	Blink Detection.....	22
Insert the Battery and SD/SDHC Card (Not included)	11	Advanced Functions Menu	23
Turning On and Off	13	WB (White Balance)	24
Mode Button Operation	14	ISO	24
		Quality	25

Size	25	Sport	34
Color	26	Indoor	34
Exposure Compensation	26	Snow	34
USING THE MODES	27	Fireworks	34
LCD Screen Display	27	Museum	34
Still Picture Mode Display	27	Night Landscape	34
Video Shooting Mode Display	29	Children	34
Playback Mode Display	30	Leaf	35
ASCN mode	31	Sunset	35
Landscape	31	Glass	35
Portrait	31	Landscape	35
Night Portrait	32	Night Portrait	35
Backlit Portrait	32	Beach.....	35
Night Landscape	32	Text.....	35
Macro	32	Gathering.....	35
Auto	32	ID	35
Panorama mode	32	Fish eye	35
Scene mode	33	Travel shooting.....	35
		Photo frame	35

Sketch	35	Digital Zoom	47
Stabilization mode	36	Slow Shutter	48
PLAYBACK	37	Movie Menu	48
Viewing Photos and Videos	37	Continuous AF	49
Thumbnail View	38	Expo Metering (Exposure Metering)	50
i button playback function	39	DIS	50
Using Zoom on Playback (for still pictures only)	41	Playback Menu	51
Using the Delete Button	42	Protect	51
USING THE MENUS	43	Delete	52
Still Picture Menu	43	DPOF (Digital Print Order Format)	53
AF Mode (Auto-Focus mode)	44	Trim	54
AF-assist Beam	44	HDR-High Dynamic Range.....	54
Continuous AF	45	Resize	55
Expo Metering (Exposure Metering)	45	Rotate	55
Continuous Shot	46	Red-eye Reduction	56
Date Imprint	46	Display Setup	56
Quick Review	47	Slideshow	57
		Wallpaper Settings	57

Setup Menu	60	Setting the USB Mode	68
Beep	61	Connecting the Camera and Printer	69
LCD Brightness	61	Using the PictBridge Menu	70
Power Saver	62	Print with Date	70
Zone	62	Print without Date	71
Date/Time	63	Print Index	72
Language	63	Print DPOF	73
File and Software	63	Exit	73
File Numbering	64	APPENDICES	74
Copy to Card (Copy internal memory to memory card)	64	Specifications	74
Reset Settings	65	Error Messages	78
FW Version (Firmware version)	65	Troubleshooting	80
Transmission.....	66		
Connecting to a PC	66		
Setting the USB Mode	66		
Transferring Files to your PC	66		
Connecting to a PictBridge Compatible Printer	68		


GETTING READY

Unpacking

Your package should contain the camera model you purchased along with the following items. If anything is missing or appears to be damaged, please contact your vendor.




Warranty Card



CD-ROM




Wrist Strap



USB Cable




Rechargeable
lithium-ion battery




Power Adapter

Camera Views



Front View




Back View




Right View




Top View



Bottom View




Left View



1	Flash Lamp	14	Delete button/Self-timer button/Down button
2	AF Assist/Timer Indicator	15	Face Detection/Left button
3	Lens	16	Function/OK Button
4	Speaker	17	Wrist Strap
5	Microphone	18	USB interface switch
6	LCD Screen	19	USB interface
7	i key Status Indicator	20	Power Button
8	Mode button	21	Movie button
9	Status Indicator	22	Shutter Button
10	Playback Button	23	Zoom Wheel
11	Menu Button	24	Tripod Socket
12	Disp/Up Button	25	Card Slot/Battery Compartment
13	Flash Mode/Right Button	26	Memory card/Battery slot switch

Charging the Battery

1. Put the battery into the camera.
2. Use USB cable to connect the camera with power adapter.
3. Insert power adapter to power socket.





 When charging, if the camera indicator is red the camera is still charging. When the camera completes charging, the light will turn green. To optimize battery life, please charge the battery for at least 4 hours before using it for the first time.


 The charger is for indoor use only.

Insert the Battery and SD/SDHC Card (Not included)


1. Open the battery compartment.




2. Insert the battery into the battery slot in the correct position as shown in the following diagram.



3. Insert an SD/SDHC card (not included) into the memory card slot as shown.



4. Close the battery compartment.



 Optional SD/SDHC cards are not included. The use of 64 MB to 16 GB memory cards from recognized manufacturers such as SanDisk, Panasonic and Toshiba is recommended for reliable data storage.


 To remove the SD/SDHC card, open the battery compartment and gently push the card to release it. Pull the card out carefully.

 When selecting Full size (1280X720) to record video, please use High Speed Card (above Class 4).

 When taking video, if "Memory card accessing is slow" on the LCD screen, please select High Speed Card or format this card, then take video

Turning On and Off

Press the Power button to turn the camera on. To turn off the camera, press the Power button again.



When the camera is turned on, it will be at the same shooting mode based on the last use. You can turn the Mode Dial on the top to select. When using the camera for the first-time, the language setting page will appear.

Mode Button Operation

The GE camera features a convenient mode button that allows for easy mode selection. All available modes are listed as follows:

Mode Name	Icon	Description
Auto mode		Switch to take still pictures in automatic mode.
Manual mode		Many of the camera settings can be configured manually in this mode.
Panorama mode		In this mode, up to 3 frames can be stitched together to create panoramic photo.
Stabilization mode		Switch to take still pictures by reducing the blurs caused by hand shake, under low luminance, or slow shutter speed.
Scene mode	SCN	Choose from 20 different scene types and effects for your photos.
Movie mode		Switch to record videos.
ASCN mode		Switch to have the camera automatically select the best scene type for still pictures.
Portrait		Switch to take portrait pictures under normal condition.

Setting Date/Time and Language

 The Date/Time and Language setup will automatically appear when the camera is turned on the first time.

To set the display language, date, and time, go to the following setup options in the General Setup menu.

- Language
- Date / Time

To access the **Setup** menu, do the following:

1. Press **Power** to turn the camera on.
2. Press the **menu** button, navigate through the camera menus by using the Left/Right button to select the General Setup menu.

Setting the Language

1. Select language with the Up/Down button, press  or right button to enter setting.
2. Use the Up/Down/Left/Right buttons to select the desired language.
3. Press the  button to confirm the setting.



Setting the Date and Time

1. Select Date/Time with the Up/Down button, then press  or right button to enter setting.
2. Use the Left/Right button to select date or time field, then press Up/Down buttons to adjust values.
3. Press the  button to confirm the setting.



About the LCD Screen

When you turn the camera on, various icons are shown on the LCD screen to indicate the current camera settings and status. To learn more about the displayed icons, see “LCD Screen display” on page 27.

LCD Screen notes:

Extremely high-precision technology had been used to manufacture the LCD screen so that most of the pixels are operational for use. However, there may be some minute points (black, white, red, blue or green) that constantly appear on the LCD screen. These points are normal in the manufacturing process and the recording is not affected in any way.



Avoid exposing the LCD screen to water; please remove any moisture on the LCD screen with dry and soft cleaning cloth.



If the LCD monitor is damaged, take particular care with the liquid crystal in the monitor. If any of the following situations arise, take the recommended immediate action indicated below:

- If liquid crystal comes in contact with your skin, wipe the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal flows into the eyes inadvertently, please rinse with water immediately and seek medical assistance.
- If liquid crystal is swallowed, flush your mouth thoroughly with water. Drink large quantities of water and induce vomiting. Then seek medical assistance immediately.

BASIC OPERATION

Shooting in Auto Mode

Auto mode is the easiest mode to take photos. While operating in this mode, the camera automatically optimizes your photos for best results.

To start shooting, do the following:

1. Press **Power** to turn the camera on.
2. Press the Mode button to select Automatic mode ().
3. Compose your picture on the LCD screen and press the Shutter button halfway to focus on the subject.
4. The LCD screen will show green focus frame after the subject is in focus.
5. Press **Shutter** fully to capture the image.

Using the Zoom Function

There are two built-in zoom functions: optical zoom and digital zoom. When taking photos, you can zoom in or out on an object using the zoom wheel.



Optical zoom is initially used until it reaches the maximal threshold. Thereafter, it will switch over from optical to digital zoom. After adjusting, the zoom axis display will be hidden, only **T**  will be displayed to indicate the current zoom status.

Flash

Press Right/Flash button to enter the flash interface, then press Left/Right button to switch among six different flash modes:

-  **Flash: Auto**
Camera flash goes on automatically based on existing light conditions.
-  **Flash: Red-eye reduction**
The camera exposes a brief flash before the picture is taken to reduce red-eye effects.
-  **Flash: Forced flash**
Make forced flash at the moment of shooting.
-  **Flash: Forced off**
Flash is turned off.
-  **Flash: Slow Synchro**
This allows you to take pictures of people at night that clearly show both your subjects and the night time backdrop.
-  **Flash:Red-Eye+Slow Synchro**
Using this mode for slow synchro shots with red-eye reduction.

Self-timer

To enable self-timer function, press Down/Self-timer button to enter the self-timer selection interface, press Left/Right button to switch among three self-timer modes:

-  **Self-timer : 2 Sec**
A single picture is taken 2 seconds after the Shutter button is pressed.
-  **Self-timer : 10 Sec**
A single picture is taken 10 seconds after the Shutter button is pressed.
-  **Self-timer : Off**
Disable the self-timer.

Macro Mode

Press the Left/Macro button to enter the close-up photo selection interface, press the Left/Right button to switch between two close-up shooting modes:

-  Macro : On
Select this to focus on subjects 5cm from the lens.
-  Macro : Off
Select this option to disable Macro.

i button function

In Shooting mode, pressing  key can select the functions of face detection and smile shooting.

1. Press  key to enter function menu.



2. Press Left/Right button to select the function that you need to set.
3. Press  button to enable this function and quit the menu.




For face and smile detection, only one option can be activated at a time.

Face Detection

This function automatically detects facial features and directs the camera to focus on them.

In face detection mode, when you slightly hold the shutter button halfway, the camera will automatically detect faces and display a rectangular focus frame around them. The focus frame will turn green to indicate that the face or faces are in focus. Press the shutter button the rest of the way to take the picture.



Smile Detection

When this feature is activated, the camera will automatically detect smiling faces and capture them.

After enabling the Smile Detection mode press the shutter button all the way down and the following icons will appear:



The camera will automatically take a photo each time a smile is detected until the Smile Detection mode is disabled. To disable Smile Detection, press the  button.

Blink Detection

The blink detection feature is on by default. After taking each photo, if a face is detected with their eyes closed, the blink detected icon () will display on the screen.



Advanced Functions Menu

The Advanced Functions menu of the camera includes image size, image quality, white balance, image color, ISO and EV value. These customized settings will allow you to capture pictures and videos with optimal results.

Set the advanced functions with the following steps:

1. Pull up the Advanced Function Menus by pressing  button.



2. Press the Down button to enter the advanced functions selection screen, press Left/Right button to select the function that you want to set.
3. Press the Up button to enter the advanced functions setting interface.



4. Use the Left/Right buttons to change the settings and then press  to confirm the new settings and close this Advanced Function Menu.

WB (White Balance)

The White Balance allows you to adjust the color temperature under different light source to ensure correct color reproduction. (The WB setting is only available when the camera is in the **M** Manual mode).



The options of White Balance include:

- **A** WB : Auto
-  WB : Daylight
-  WB : Cloudy
-  WB : Fluorescent
-  WB : Fluorescent CWF
-  WB : Incandescent
-  WB : Manual (Press the shutter button to set WB)

ISO

The ISO function allows you to set the sensitivity of the camera sensor based on the brightness of the scene. To improve the performance in darker environments, a higher ISO value is required. On the other hand, a lower ISO value is needed when in bright conditions. (The ISO setting is only available when the camera is in the **M** Manual mode).

Pictures at higher ISO will naturally have more noise than those at lower ISO.



The options of ISO include automatic, 64, 100, 200, 400, 800 and 1600.

Quality

The quality setting adjusts the compression ratio of the images. Higher quality settings give better photos, but will take up more memory space.



The picture quality of image has three options:

-  Quality : Best
-  Quality : Fine
-  Quality : Normal

Size

The size setting refers to the image resolution in pixels. A higher image resolution allows you to print that image in larger sizes without degrading the image quality.



The larger the number of pixels, the better the image quality. However, it will take up more space. The opposite will be true also.

Color

The color setting allows you to add artistic effects directly when taking pictures. You can try different color tones to alter the mood of your pictures. (The Color setting is only available when the camera is in the **M** Manual mode).



The color options include:

- **OFF** Color : Auto
- **BW** Color : Black & White
- **SE** Color : Sepia
- **VI** Color : Vivid

Exposure Compensation

The exposure compensation allows you to adjust the light exposure value to optimize photo.




The adjustable range of exposure value is from EV -2.0 to EV+2.0.

USING THE MODES

LCD Screen Display

Still Picture Mode Display

Mode:       



1 Shooting Mode Icons

- | | | | |
|---|--------------------|---|-------------|
|  | Auto mode |  | Manual mode |
|  | ASCN mode |  | Scene mode |
|  | Stabilization mode |  | Portrait |
|  | Panorama mode | | |

2 AF Mode

-  Single-AF
-  Multi-AF

3 Expo Metering

-  Spot
-  Center
-  AiAE

4 Image Size

5 Image Quality

- 6 Remaining number of pictures
- 7 Memory card/built-in memory
- 8 Battery Status
- 9 WT Ratio (Displayed only when zoom is activated)
- 10 Zoom
- 11 Exposure
- 12 ISO Value (Adjustable only in  Manual Mode)
- 13 Histogram
- 14 Focus Frame
- 15 Continuous Shot
- 16 Face Detection
- 17 Picture Color (Adjustable only in  Manual Mode)
- 18 White Balance (Adjustable only in  Manual Mode)
- 19 Macro Mode
- 20 Self-timer

 Self-time : 2-sec

 Self-time : 10-sec

21 Flash Mode

 Flash : Auto

 Flash : Red-eye reduction

 Flash : Forced flash


 Flash : Forced off

 Flash : Slow Synchro

 Flash : Red-Eye + Slow Synchro

Video Shooting Mode Display

Mode : 



- 1 Video Mode icon
- 2 Continuous AF
- 3 Metering
 -  Spot
 -  Center
 -  AiAE
- 4 Video Quality
- 5 Macro Mode

6 Self-timer

 Self-time : 10-sec

7 Remaining Time for Video Recording

8 Memory Card/Built-in Memory

9 Battery Status

10 WT Ratio (Displayed only when zoom is activated)

11 Zoom

12 Exposure

13 Recording Status Icon

 Recording standby

 Recording


 For optimal video shooting, it is recommended that an SD card be used. Recording videos with the internal memory jitter and noise may appear on the image.

 HD recording time limited to below 29min.

 During video recording the 7x optical zoom and 6x digital zoom are available.

Playback mode display

Mode: ▶




1. Play Mode icon
2. Picture File
3. File protection
4. Picture Number
5. Memory Card/Built-in Memory
6. Battery Status
7. Image Zoom
8. Zoom Magnification Area Indicator
9. Total Image Area
10. Memory Space (this picture/Total number of pictures)
11. Recording Date and Time
12. OK:PLAY
13. DPOF file

ASCN mode

In the "ASCN" mode, different recording conditions are detected automatically and the most suitable settings will be selected. With "ASCN" you can always take good pictures easily.

To use "ASCN":

1. Press mode selection button to select ASCN mode, press  button to enter ASCN mode, LCD screen will display the detection scene icon shown as following figure:



2. Hold the camera steadily and aim at the subject. The optimum scene mode will be identified automatically.
3. Press the Shutter button halfway down to focus.
4. Press the Shutter button all the way down to take the picture.

Icon	Mode name	Icon	Mode name
	Landscape Mode		Night Landscape Mode
	Portrait Mode		Macro Mode
	Night Portrait		Auto Mode
	Backlit Portrait		

Landscape Mode

For landscapes, ASCN will automatically adjust the exposure to match the background.

Portrait Mode

For portraits, ASCN will automatically adjust the exposure and skin tones to give clear pictures.

Night Portrait

When you shoot portraits at night, or in low light conditions, ASCN will automatically adjust the exposure for people and night scenes.

Backlit Portrait

When the sun or any other light source is behind you, ASCN will automatically adjust the foreground exposure to produce good pictures.

Night Landscape Mode

For night scenes, ASCN will automatically increase the ISO value to compensate for low light.

Macro Mode

To capture object detail for close-ups, ASCN will automatically adjust the focus.

Auto Mode

The camera will automatically adjust the exposure and focus to ensure good pictures.

Panorama mode

Panorama Mode allows you to create a panoramic picture. The camera will automatically compose a panoramic picture using the individual shots that you take.

Follow these steps to create a panoramic picture:

1. Press Mode button, use Left/Right button to select Panorama mode, then press  button to enter Panorama mode for shooting.
2. Use Left/Right button to select the direction for starting to shoot, press  button to enter Shooting mode; if no selection is made after 2 seconds, the camera will default to left to right.
3. After the first shot is taken, two target icons will appear on the left and right side of the LCD screen. Pan the camera and the circle icon on the screen will move towards the square frame icon. When the circle icon and square frame connects, it will turn green and the camera will take the picture automatically. Repeat the same step for the third picture to finish the stitching.



The camera will then stitch the pictures into a panorama automatically. Press the playback button to enter Playback mode and review the panorama result.

- 
 After selecting Panorama mode, Flash, Self-timer, Macro mode and Exposure Compensation can't be adjusted.
- 
 While in panoramic mode, press the Delete button to cancel shooting.
- 
 Panorama Mode can stitch 2 or 3 maximum pictures.

Scene mode

In **Manual Scene** mode, you can select from a total of 20 scene types to match your needs. The camera will adjust the optimal settings for that scene type.

Press Mode button, use Left/Right button to enter Scene Selection mode menu, press  button to enter Scene Selection mode, the following figure will display on LCD screen:



Select a scene using the Up/Down/Left/Right button and press the  button.

Icon	Mode Name	Icon	Mode Name
	Sport		Indoor
	Snow		Fireworks
	Museum		Night Landscape
	Children		Leaf/Foilage
	Sunset		Glass
	Landscape		Night Portrait
	Beach		Text
	Gathering		ID
	Fish eye		Travel shooting
	Photo frame		Sketch

Sport

For shooting fast-moving objects. Bring lively pictures to life.

Indoor

For shooting people indoors. Clearly show background and atmosphere.

Snow

Suitable for snowy landscape. Camera automatically adjusts and corrects exposure value (EV).

Fireworks

For shooting at night and fireworks. Shutter speed is slower than normal. (Use of tripod is recommended)

Museum

For shooting in museums or places where flash is not allowed.

Night landscape

For shooting night scenes. Use of tripod is recommended.

Children

Suitable for photographing children and pets. The flash shuts off automatically in order not to disturb the subject being photographed.

Leaf/Foliage

For shooting plants. Vivid reproduction of green.

Sunset

For shooting sunsets. Vivid reproduction of red and yellow.

Glass

Suitable for photographing objects behind glass or window.

Landscape

For shooting landscapes. Vivid reproduction of green and blue.

Night portrait

For shooting portraits with night scenes as background.

Beach

For taking pictures in areas with strong sunlight.

Text

For taking pictures of text, documents or white boards.

Gathering

For taking pictures of large groups or in areas with uneven lighting.

ID

Ideal to take pictures of documents such as IDs.

Fish eye

Creates a fish-eye effect, by distorting the center of the image.

Travel shooting

Produces background image blur that emphasizes the motion of the main subject.

Photo frame

For adding interesting frame effects to the photo.

Sketch

For taking photos with pencil sketch effect.



1. After selecting the scene type, press the  button to activate.
2. After setting the option, press  button to confirm the setting and enter the selected Scene Selection mode for shooting.

The main function menu also allows you to adjust the image quality and image size. Please refer to the **"Advanced Functions Menu"** section on page 23 for detailed instructions.

Stabilization mode

This mode can help reduce photo blur caused by hand shake, low light and slow shutter speed



-  Use stabilization mode in dark environments or when in slow shutter speed .
-  Shooting in a windy or unstable environment (such as a moving vehicle) may cause blurred images.



PLAYBACK

Viewing Photos and Videos

To view the captured photos and video clips on the LCD screen:

1. Press **[▶]** button to go to the **Playback** mode. The last recorded photo or video clip is displayed.
2. Use the **Left/Right** navigation buttons to scroll through the photos or video clips stored in the internal memory or memory card.
3. To play a selected video clip, press the **[func/ok]** button to enter the movie playback mode.

During video playback, the operating instructions will appear on the screen. Press the Left/Right button, and press the **[func/ok]** button for confirmation.



The operating instruction icons are as follows.

- | | | | |
|---|------------------------------------|---|---------------------------|
| 1 | Return to the first frame and play | 4 | Return to the first frame |
| 2 | Play | 5 | Rewind |
| 3 | Fast Forward | 6 | Pause |



When playing a stored video, press the Up/Down arrow button to adjust the playback volume ; or to mute the volume



Thumbnail View

In the playback mode, slide the zoom lever to  W , the photos and video thumbnails will display on the screen.

1. Slide the zoom lever to switch between 3x3 and 4x4 thumbnails.



2. When displaying 3x3 and 4x4 thumbnails, press the Up/Down/Left/Right button to select a picture or video clip to view.



When the  icon appears on the LCD screen, a movie file is currently being displayed.



Press the  button to restore a preview icon to its original image size.

i button playback function

In the playback mode, press the **[i]** button for full screen playback or date folder selection.

1. Press **[i]** key to enter function menu.



2. Press Up/Down button to select from the following two functions:
 - Full Screen Playback
 - Date Folder View
3. Press the **[func ok]** button to enter the corresponding interfaces.

Full Screen Playback

After entering the Full Screen Playback menu, press the Left/Right button to display the next photo.

Date Folder View

4. Select the Date Folder View, press the **[func ok]** button to enter the following screen:



5. Press the Up/Down to select Date Folder.
6. Press the **[func ok]** button to enter the Date Folder, press the Left/Right button to select the photos in the date folder.

When selecting a date in the date folder, sliding the zoom lever to **T**  will zoom in the picture; sliding the zoom lever to  **W** will first zoom out the picture then enter into the date folder index. Press the  button to return to the original scale.



 If it is a video, **OK:PLAY** will display on the screen.

Using Zoom Playback (for still pictures only)

In playback mode, the zoom wheel can be used to zoom in 2x to 8x.

1. Press  button to go to the **Playback** mode.
2. Use the **Left/Right** navigation buttons to select a photo to magnify.
3. Slide the zoom wheel to  to zoom in the picture.
4. While zooming, the zoom indicator and photo frame icon will display on screen.



5. Use the navigation buttons to pan across the image.
6. Press the  button to return the image to its original scale.



Movie images cannot be magnified.

Using the Delete Button

In Playback mode, press Down/Delete/Self-timer button to delete photos and movies.

To delete pictures or videos:

1. Press  button to go to the Playback Mode.
2. Select a picture or video clip you want to delete with the Left/Right button.
3. Press the Down/Delete button and the delete screen appears.



4. Select Yes or Cancel with Up/Down button and press the  button for confirmation.



Erased photos/video clips cannot be recovered.



Please refer to page 52 for instructions on the Delete Menu options.

USING THE MENUS

Still Menu

Mode:     

In any of the above Still Picture Modes, press the **menu** button to go to the Still Picture menu.

To adjust each setting:

1. In the Still Picture Menu, press Left/Right buttons to switch between different Photo and Camera Setup pages.



2. Press the Up/Down buttons to select the function.
3. Press  or Right button to enter the submenu.



4. Press Up/Down button to select an option or press the Left or **menu** button to return to the menu.
5. Press  button to confirm the setting and return to the previous layer.

 After selecting a function, you can press the Up button to return to the Still Picture menu for other Photo Setup or Camera Setup pages. Or you can press the Down button several times to move to the next setup menu page.

Refer to the following pages for more details about each setting.

AF Mode (Auto-Focus mode)

Use this setting to control the auto-focus mechanism while taking pictures.



Two options are available:

- **Single-AF:** The focus frame appears on the center of the LCD screen to focus on the subject.
- **Multi-AF:** The camera shall focus correctly for multiple parts of the object.

AF-assist Beam

This option can turn the AF assist lamp on or off. In dark conditions, the AF assist lamp can strengthen the focus on the image.



Continuous AF

After Continuous AF is turned on, the camera will adjust focus automatically in response to any camera or subject movement.



Expo Metering (Exposure Metering)

Use this setting to select an area for the exposure to be obtained.



Three options are available:

- Spot
- Center-Weight
- AiAE (Artificial Intelligence AE)

Continuous Shot

Use this setting to perform continuous shooting. After entering this mode, you can shoot multiple images through operating the shutter button.



There are five available options:

- **OFF:** Turn off Continuous Shot function.
- **Unlimited:** Press and hold the shutter to shoot continuously until you release the shutter or when the memory card has run out of space.
- **3 shot:** Capture up to 3 consecutive pictures.
- **3 shots (Last):** Capture pictures continuously until the Shutter button is released but only the last 3 shots are recorded.
- **Time-Lapse:** Automatically capture pictures in a pre-defined interval.



The flash is designed not to work in this mode in order to enable quick succession of shots.

Date Imprint

Include a Date/Time stamp in the photo image.



- **Off**
- **Date**
- **Date and Time**


Quick Review

This setting refers to the quick photo review immediately after taking a picture. The picture stays on the LCD screen for an adjustable period of time.



Digital Zoom

Use this setting to enable or disable the digital zoom function. When disabled, only the optical zoom is enabled.



Four options are available:

- Off
- 1 sec
- 2 sec
- 3 sec

Slow Shutter ("B" or Bulb Mode)

In Slow Shutter (B) mode, the shutter will remain open as long as the Shutter button is pressed. This gives you complete control over the duration of the exposure. (The slow shutter mode is available only in  manual mode.)



- **Manual** : To set a long exposure time between 2~30 sec.



The use of tripod is recommended for prolonged exposure.

Movie Menu

Mode :        

In the Movie Mode, press the menu button to access the Movie Setup menu.

To configure each setting:

1. In the Menu screen, switch between the Movie Setup or different Camera Setup pages using the Left/Right button, select the page with the function you want to adjust and press the Down button.



2. Press the  to enter the selection.



3. Press the Up/Down button to select an option or the Left or menu button to return to the menu.
4. Press  button to confirm the setting and return to the previous layer.

Refer to the following pages for more details about each setting.

Continuous AF

After Continuous AF is turned on, the camera will adjust focus automatically in response to any camera or subject movement.



Expo Metering (Exposure Metering)

Set metering mode for various lighting conditions.



DIS

Using this function can ensure the maximum stability of the screen when recording video.



Three options are available:

- Spot
- Center
- AiAE (Artificial Intelligence AE)

Playback Menu

Mode : 

In Playback mode, press the **menu** button to enter the **Playback** menu.



Please refer to the following sections for detailed instructions on the various menu options.

Protect

To prevent any pictures or videos from being accidentally erased, use this setting to lock one or all of the files.



To protect/unprotect pictures or videos, press the **MENU** button while in playback.

1. Use Up/Down arrow button to select Protection, press  or Right button to enter the submenu.

- Use the Up/Down button to select One picture/video to protect or select ALL to protect all photos and movies stored on the active memory (memory card or internal memory - when memory card is inserted, the memory card is the active memory. Without the memory card, the internal memory is the active memory). Press  button to confirm and enter photo/movie protection interface.
- Press the  button to select Yes to lock. For locked picture/video, use Unlock option to unlock it.
- A key () icon will appear on the top of the screen to indicate that the picture/video is protected.



If you Reset the Settings in the menu option, all protection settings on pictures/videos will be cancelled.

Delete

There are three ways to delete files.



• Delete One:

- In the Delete Option, select One and then press  button.
- Press the Left/Right button to locate the photo or video to be deleted. Press the Up/Down button to select item (Yes: to delete the file, Back: to return to previous menu) and then press  to confirm.

• Delete All:

1. In the Delete option, select All and then press  button.
2. Use Up/Down button to select Yes to delete all files, or select Back to return to the menu.

• Delete Date Folder:

1. In the Delete Folder, press  or button after selecting date folder.
2. Use the Up/Down button to select Date Folder to be deleted, press  to confirm, press the Up/Down button to select item (Yes: to delete the file, Back: to return to the menu) and then press  to confirm.



The “” indicator means a file is protected. File protection must be removed first before a file can be deleted.



Deleting files will cause DPOF settings to be reset.

DPOF (Digital Print Order Format)

DPOF allows you to record your selection of pictures that you would like to print, and will save your selection in the memory card, so that you can simply hand your memory card to a photo kiosk without having to tell them in person which photos you would like to print.



Trim

The Trim setting allows you select an area of the photo you want to keep and then save it as a new photo.

To trim a picture:

1. Select the **Trim** setting from the  menu.
2. Using the **Left/Right** buttons, locate the photo that you want to crop and have it displayed on the LCD.
3. Select "Yes" to confirm cutting, use the zoom lever and direction key to select the part to be cut, then cut the photo you need.



4. Press  button and a 'Save Changes?' prompt will display. Select "O" to confirm changes and save it as a new image, or select "X" to cancel changes and return to the previous menu.




The image can not be clipped again when it is clipped to 640X480.

HDR-High Dynamic Range

With the HDR function, pictures that may be overexposed may be corrected to optimize the highlights and lowlights captured to more accurately represent the real scene.

1. Select HDR setting in  menu by pressing Menu while in Playback.
2. Press Left and Right button to find picture you want to optimize and then select Confirm to perform HDR optimization or select Return to go back to Playback menu.



3. After HDR optimizing, the image will be saved as another file with the  icon appearing as a prompt, the original file still remains in the memory.

Resize

This setting allows you to resize a picture to a specified resolution, and saves it as a new picture.

1. Select the **Resize** setting from the **Playback** menu as described previously.



2. Use the **Left/Right** navigation buttons to select a picture to resize.
3. Use the **Up/Down** navigation buttons to select a resolution (**1024X768** or **640X480**) to resize the image or **Back** to cancel and return to the **Playback** menu.
4. Press the  button to confirm the setting.



Resizing an image creates a new file that contains the image in the size you select. The file with the original image also remains in memory.

Rotate

You can use this setting to change the picture orientation of the picture.

1. Select the **Rotate** setting from the **Playback** menu as described previously.
2. Use the **Left/Right** navigation buttons to select a picture to rotate.
3. Use the **Up/Down** navigation buttons to select the direction for rotation or **Back** to cancel and return to the **Playback** menu.



4. Press the  button to confirm the setting.
-  The panorama picture and video cannot be rotated.
-  Revolved file will replace the original one.

Red-eye Reduction

Use this setting to remove red-eyes in your photos.

1. Select the **Red-eye Reduction** in **Playback** menu as described previously.
2. Use the **Left/Right** button to select the picture from which the red-eye needs to be removed.
3. Use the **Up/Down** navigation buttons to select **Yes** to fix the selected image or **Back** to cancel and return to the **Playback** menu.



4. Press the  button to confirm the setting.



For best results, the face of the subject should be relatively large on the LCD screen, the subject should be facing the camera as front on as possible, and the red eyes should be as large as possible.



If there is no red eyes in the image, press  button after selecting "Yes", such prompt will appear on the screen: red eye is not detected!

Display Setup

Mode: 

Press **menu** button in **Playback** mode to enter **Display Setup** menu.



Refer to the following sections for details of every setting.

Slideshow

This setting allows you to view all the stored pictures as a slideshow.

1. Select Slide Show menu, press  or Right button to enter the slide show setup interface.
2. Press Up/Down button to select effect, interval, repeat or music, and press  or Right button to enter and adjust settings. Press  button to confirm settings.



3. Use the **Up/Down** navigation buttons to select **Start** to run the slideshow or **Cancel** to return to the **Playback** menu.
4. Press the  button to confirm the setting.

Wallpaper Settings

Use this setting to select your favorite picture to use as a background on the LCD screen.

1. Press Down button to select the Wallpaper Setting menu.



2. Press the  or Right button to enter the background setup interface.



Menu Wallpaper:

Use Up/Down button to select the Menu Wallpaper option, press  button to confirm or press Left button to return to last page, and press **menu** to exit the menu.



- User
- Nature
- Sparkling

Startup Screen:


Use Up/Down button to select the Startup Screen option, press  to confirm or press Left button to return to last page, and press **menu** to exit the menu.



- User
- GE logo

Set back to default:

Use Up/Down button to select Back To Default, press  to confirm or press Left button to return to last page, and press  to exit the menu.



- Yes
- No

Setup Menu

Mode :        


The Setup menu for the camera is available in all modes. Each menu page can be selected by pressing the menu button and switching between menus with the Left/Right button.



To adjust the settings:

1. Select the menu page with the function you want to adjust and press the Down button.

2. Switch between different functions with the Up/Down button.
3. Press the  or the Right button to enter the submenu.

 After selecting a function option, you can press the Up button to return to the menu for other Camera Setup pages. Or you can press the Down button to switch to the next menu page.

Refer to the following pages for more details about each setting.

Beep

Use this setting to adjust the volume of beep when buttons are pressed and change the tones for Shutter button, self-timer, and power-on/power-off.

To change this setting:

1. Select the **Beep** setting from the **Setup** menu as described previously.
2. Use the **Up/Down** navigation buttons to switch between volume, shutter, key, self-timer, and power fields.



3. Press the  or the Right button to enter, and Press the Up/Down button to adjust volume and change various sounds, then Press the  button to confirm the setting

LCD Brightness

Use this setting to adjust the brightness of your LCD screen.

1. Select the **LCD Brightness** setting from the **Setup** menu as described previously.
2. Select auto or adjust the brightness level using the Left/Right button, and press the  button to confirm the setting.



Power Saver

This setting allows you to save power and get the maximum possible running time for your battery. Follow the steps below to turn off the LCD screen and camera automatically after a period of inactivity.

1. Select the **Power Save** setting from the **Setup** menu as described previously.
2. Press the Up/Down button to select screen power and camera power, then Press the  or the Right button to enter.



3. Press the Up/Down button to adjust the selected item. Both items have the following options:

- LCD Off :
ON, 30 sec, 1 min, 2 min.
 - Camera Off :
ON, 3 min, 5 min, 10 min.
4. Press the  button to confirm.

Zone

The Zone setting is a useful function on your overseas trips. This feature enables you to display the local time on the LCD screen while you are overseas.

1. Select the **Zone** setting from the **Setup** menu as described previously. The world time screen appears.
2. Use the **Up/Down** navigation buttons to switch between the hometown () and travel destination () fields.
3. Use the **Left/Right** navigation buttons to select a city close to the desired time zone. Then press the  button to confirm.



Date/Time

See “Setting the Date and Time” section on page 16.

Language

See “Setting the Language” section on page 15.

File and Software

Format Memory

Please note: formatting enables you to delete all contents in the memory card and built-in memory, including protected photo and movie files.

To use this setting:

1. Select the Format in File and Software menu.
2. Use the **Up/Down** navigation buttons to select **Yes** or **No**. Then press the **func/ok** button to confirm.




3. Select **Yes**, the camera will format the selected media.
4. Please note that when you perform the Format Memory function, it only formats the active memory. If a memory card is inserted, the memory card is active and will be formatted. If there is no memory card, the internal memory is active and the internal memory will be formatted. Formatting the memory card will not automatically format the internal memory.

File Numbering

After you take a picture or video clip, the camera will save it in a sequential number. You can use this to reset the file numbering to 1. (When more than 999 images are on the memory card, the use of this features will have no effect.)

1. Select the File Name in File and Software menu.
2. Select the option with the Up/Down button and press the  button for confirmation.



Copy to Card (Copy internal memory to memory card)

Use this setting to copy the files stored in the internal memory to the memory card.

1. Select the Copy to memory card in File and Software menu.
2. Use the Up/Down navigation buttons to select Yes or No. Then press the  button to confirm.



Reset Settings

Use this setting to restore the camera to its default settings.

1. Select the **Reset** setting in File and Software menu.
2. Use the **Up/Down** navigation buttons to select **Yes** or **No**. Then press the  button to confirm.



FW Version (Firmware Version)

Use this setting to view and update the current camera firmware version.

1. Select the **FW Version** in File and Software menu.
2. The screen will show the current firmware version. If there is a memory card with a firmware file, the camera will detect it and ask if you want to update the firmware.



To update to the latest firmware version, you can go to the following website: www.ge.com/digitalcameras and look under Support.

Connecting to a PC

You can connect to the PC by using the USB interface on the camera or the USB cable. Once connected you can manually transfer the files or use software such as Arcsoft (included on disc).

Setting the USB mode

Since the camera's USB port can be set to connect with either a PC or a Printer, the following steps will allow you to ensure that the camera is correctly configured to connect with a PC.

1. Enter the camera setup menu and select USB Mode with the UP/Down button, then press the  or the Right button to enter.
2. Use the Up/Down navigation buttons to select PC.
3. Press the  button to confirm the setting.




Transferring files to your PC

The computer will automatically detect the camera as a removable drive. Double click on My Computer (or Computer) to access your computer drives. Locate the removable drive, browse the directory to locate your files and copy the folders/files as you normally do on a computer.

To use the Arcsoft software to transfer files to your computer, please connect the camera to the computer and follow these steps:

1. Start a computer to which ArcSoft software has been installed.
2. Make sure both the camera and PC are turned on.
3. Connect the camera with PC:
 - Connect USB interface of the camera with PC;
 - connect one end of attached USB cable with the camera, and connect another end with PC.



4. Please unplug USB after transmitting.

If USB connection item is set as [Computer]:

First remove the camera from the system as indicated below, then turn off and remove USB.

If USB connection item is set as [Computer (PTP)]:

Please operate according to the following steps: remove the camera from the system firstly, then turn off and remove USB.

Windows operating system (Windows 2000, Windows XP, Windows Vista, Windows 7.)

Click [Remove hardware safely] icon in the taskbar, and remove USB according to the displayed menu.



Macintosh

Drag the untitled icon to the Trash. ("Untitled")



Connecting to a PictBridge Compatible Printer



PictBridge allows printing images from a memory card in a digital camera directly to a printer, regardless of brand. To find out if a printer is PictBridge compatible, simply look for the PictBridge logo on the packaging or check

the manual for specifications. With the PictBridge function on your camera, you can print the captured photos directly with a PictBridge compatible printer using the supplied USB cable, without the need for a PC.

Setting the USB mode

Since the camera's USB port can be set to connect with either a PC or a Printer, the following steps will ensure that the camera is correctly configured to connect with a Printer.

1. Enter the camera setup menu and select USB cable with the Up/Down button, then press the  or Right button to enter.
2. Use the Up/Down button to select Printer.


3. Press the  button to confirm the setting.




-  After the camera is reset, it will switch to PC mode automatically from USB mode.

Connecting the camera and printer.

1. Make sure both the camera and printer are turned on.
2. Connect one end of the supplied USB cable to the USB port on your camera.
3. Connect the other end of the cable to the USB port on the printer.



If the camera is not connected to a PictBridge compatible printer, the following error message will appear on the LCD screen.



-  The above error message will also appear if the USB mode were set incorrectly, in which case you should disconnect the USB cable, check the USB mode settings, ensure that the Printer is turned on, and then try connecting the USB cable again.

Using the PictBridge Menu

After setting the USB mode to Printer, the **PictBridge** menu will appear:



Press the Up/Down button to select a menu item, then Press the  or Right button to enter this item.

Refer to the following sections for more detailed information on each setting.

Print with date

If you have set the date and time of your camera, the date and time will be recorded and saved with each photo you take.

1. Select **Print with date** from the **PictBridge** menu. The following screen will appear:



2. Use the **Left/Right** navigation buttons to scroll through the photos.

3. Use the **Up/Down** navigation buttons to select the number of prints for the current displayed photo.
4. Press the  button and the following screen will appear:



5. Select **Yes** to confirm the printing, or **Cancel**. Then press the  button.

Print without date

Use this setting to print the photos without dates on them.

1. Select **Print without date** from the PictBridge menu. The following screen will appear:



2. Use the **Left/Right** navigation buttons to scroll through the images.
3. Use the **Up/Down** navigation buttons to select the number of prints for the current displayed image.
4. Press the  button and the following screen will appear:



5. Select **Yes** to confirm the printing, or **Cancel**. Then press the  button.

2. Select **Yes** to confirm the printing, or **Cancel**. Then press the  button.

Print index


You can use this setting to print all indexes to show all the photos currently in your camera.

1. Select **Print index** from the **PictBridge** menu. The following screen will appear:

Print DPOF (Digital Print Order Format)

To use DPOF printing, you must select the photos for printing using the DPOF settings before hand. see the "DPOF" section on page 53.

1. Select **Print DPOF** from the **PictBridge** menu. The following screen will appear:



2. Select **Yes** to confirm the printing, or **Cancel**. Then press the  button.

Exit

To exit the **PictBridge** menu, select **Exit**. The "Remove USB cable" message will be displayed.



Disconnect the USB cable from the camera and printer.

Specifications



Design and specifications are subject to change without notice.

Effective Image Sensor Pixels		14.1 Megapixels
Image Sensor		14.48 Megapixels [1/2.3" (CCD)]
Lens	Focal Length F =	5.9mm (Wide) ~ 41.3mm (Tele)
	35mm film equivalent	32.9mm (Wide) ~ 230.3mm (Tele)
	F number	F3.4 (Wide) ~ F5.7 (Tele)
	Construction	9 elements in 7 groups
	Optical Zoom	7X
	Focusing Range	Normal: (Wide) 60cm ~ ∞, (Tele) 80cm ~ ∞; Macro: (Wide) 5cm ~ ∞
Anti-Handshake		Electronic Image Stabilization
Digital Zoom		6X digital zoom (Combined Zoom: 42X)

Number of Recording Pixels	Still Image	14MP, 12MP(3:2), 10MP(16:9), 8MP, 5MP, 3MP, 0.3MP
	Movie	1280x720pixels: 30fps/15fps, 640x480pixels: 30fps/15fps, 320x240pixels: 30fps/15fps
Image Compression		Best, Fine, Normal
DCF, DPOF (Ver1.1) Support		Yes
File Format	Still Image	Exif 2.2 (JPEG)
	Movie	Quick Time Motion JPEG, Audio: G.711 [Monaural])
Shooting Modes		Auto mode, Manual mode, ASCN mode, Scene mode, Stabilization mode, Portrait, Panorama mode, Video mode
Smile Detection		Yes
Blink Detection		Yes
Face-Detection		Yes
Red-eye Removal		Yes

Pan-Capture Panorama	Yes
LCD Display	3.0 inch (230,400 pixels) LTPS (low-temperature polycrystalline silicon) TFT color LCD
ISO Sensitivity	Auto, ISO 64/100/200/400/800/1600
AF Method	Single AF, Multi-AF (TTL 9-point), AF Assist Light (On/Off)
Light Metering Method	Artificial Intelligence AE (AiAE), Center-weighted Average, Spot (Fixed to center of frame)
Exposure Control Method	ProgramAE (AE-lock available)
Exposure Compensation	±2 EV in 1/3 Step increments
Shutter Speed	4 ~ 1/2000 second (Manual 30 s)
Continuous Shooting	Approx. 1.39 fps (Large/Fine mode)
Playback Modes	Single Photo, Index (9/16 thumbnails), Slide Show, Movie (Slow-Motion possible), Zoom (Approx. 2X~8X), Audio, Histogram Display
White Balance Control	Auto (AWB), Daylight, Cloudy, Fluorescent , Fluorescent CWF, Incandescent, Manual

Internal Flash (Shooting Range)	Auto/Red-Eye Reduction/Forced Flash/No Flash/Slow Synchro/Red-Eye Reduction+Slow Synchro
	Shooting Range Wide: Approx. 0.6m~4.5m / Tele: Approx. 0.8m ~ 2.7m
Recording Media	Internal Memory: 50 MB
	SD Card/SDHC Card (Up to 32 GB support)
Other Features	PictBridge, ExifPrint Support, Multi-language Support
Jacks	USB2.0
Power	Rechargeable Lithium-ion Battery GB-50 , 3.7V 880mAh
Shooting Capability (Battery Performance)	Approx. 300 shots (based on CIPA Standards)
Operation Environment	Temperature: 0~40°C, Humidity: 0~90%
Dimensions (W x H x D)	99.5mm x 56.9mm x (21.23~23.95) mm
Mass	Approx. 129g (Body only)

Error messages

Messages	Explanation
Card error	<ul style="list-style-type: none">• The memory card is not formatted.
Card full	<ul style="list-style-type: none">• The memory card is full and cannot store any new images.
Write protect	<ul style="list-style-type: none">• The memory card is write-protected.
Picture error	<ul style="list-style-type: none">• The picture was not captured correctly.• The picture is damaged.
No picture	<ul style="list-style-type: none">• There are no images in the memory card or in the internal memory.
Lens error	<ul style="list-style-type: none">• The lens is probably stuck and the camera will power off automatically.
System error	<ul style="list-style-type: none">• Unexpected error encountered.
Image cannot be saved	<ul style="list-style-type: none">• The write protection switch in the memory card is set to the "LOCK" position.
Write Protect	<ul style="list-style-type: none">• When pictures were taken in Panorama mode, the direction of movement was incorrect or the angle was outside the range of the internal settings.

Messages	Explanation
Card is not formatted, format?	<ul style="list-style-type: none">• Confirm whether the memory card should be formatted.
Cannot record movie	<ul style="list-style-type: none">• The write protection switch in the memory card is set to the "LOCK" position.
Warning!! Camera recording, please wait.	<ul style="list-style-type: none">• No other actions allowed to perform during video/audio recording.
Warning!! Battery exhausted.	<ul style="list-style-type: none">• The battery is out of charge.
This file cannot be played back	<ul style="list-style-type: none">• The picture format cannot be recognized by the camera.
No connection	<ul style="list-style-type: none">• The camera is not connected to the printer correctly.
Print error	<ul style="list-style-type: none">• There is a problem with camera or printer.
Cannot print	<ul style="list-style-type: none">• Check that the printer is out of paper or out of ink.• Check if the printer has a paper jam.

Troubleshooting

Problem	Possible causes	Solution
Camera does not turn on.	<ul style="list-style-type: none">• The battery has run out.• The battery is not inserted correctly.	<ul style="list-style-type: none">• Replace with a fully charged battery.
Camera turns off suddenly during operation.	<ul style="list-style-type: none">• The battery has run out.	<ul style="list-style-type: none">• Replace with a fully charged battery.
The picture is blurred.	<ul style="list-style-type: none">• The lens is dirty.•  appears when taking pictures.	<ul style="list-style-type: none">• Use a soft cloth to clean the lens on your camera• Use the Image Stabilization mode.
Images and video files cannot be saved.	<ul style="list-style-type: none">• The memory card is full.	<ul style="list-style-type: none">• Replace the memory card with a new one.• Delete unwanted images from the memory card.• Unlock the memory card.
No picture is taken when pressing the Shutter button.	<ul style="list-style-type: none">• The memory card is full.• There is no available space to store the files.• The mode dial is in Playback mode.	<ul style="list-style-type: none">• Replace the memory card with a new one or clean off current memory card.• Delete unwanted images.• The memory card is locked.• Change to Shooting mode.

Problem	Possible causes	Solution
Images cannot print from the connected printer.	<ul style="list-style-type: none"> • The camera is not connected to the printer correctly. • The printer is not PictBridge compatible. • The printer is out of paper or out of ink. • The paper is jammed. 	<ul style="list-style-type: none"> • Check the connection between the camera and printer. • Use a PictBridge compatible printer. • Load some paper in the printer. • Replace the ink cartridge in the printer. • Remove the jammed paper.
Write to memory card slowly	<ul style="list-style-type: none"> • When movie above HD is recorded into the memory card below Class 4, perhaps it is too slow to continue recording. 	<ul style="list-style-type: none"> • Please select HCSD or shoot after formatting this card.
Cannot write to the memory card	<ul style="list-style-type: none"> • When you shoot or record, the memory card interrupts and can't continue shooting or recording. 	<ul style="list-style-type: none"> • Please replace a memory card.
Too many movies to process	<ul style="list-style-type: none"> • When you select Date Playback, if the movie exceeds the specifications, you can't enter Date Playback. 	<ul style="list-style-type: none"> • Delete needless files. • Transfer the files in the memory card to other area.
Exceed maximum folder number in the memory card	<ul style="list-style-type: none"> • If there are too many data (folders) in the memory card, too long time will be spent on reading memory card when turning on the camera. 	<ul style="list-style-type: none"> • Delete needless files. • Transfer the files in the memory card to other area.

<http://www.ge.com/digitalcameras>

