

## FCC Statement

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

- Moving your radio from the receiver
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using the radio.

**RadioShack**  
A Division of Tandy Corporation  
Fort Worth, TX 76102

3A8

Printed in the Philippines

# OPTIMUS®

# AM/FM Shower Radio

n Water-Resistant

n Built-In Washcloth Hanger

n Hanging Strap

n Non-slip Controls

## Owner's Manual

Cat. No. 12-796

### Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period. *(continued)*

*(continued)* This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper installation or maintenance, alteration, lighting or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W,  
100 Throckmorton St., Suite 600, Fort Worth, TX 76102

*We Service What We Sell* 3/97

### Caring for Your Radio

To enjoy your radio for a long time:

- Handle it gently.
- Keep it away from dust and temperature extremes.
- Clean it with a damp cloth. Do not use harsh chemicals.
- Do not take it apart. If something is wrong with the radio, take it to your local RadioShack store for assistance.

## INSTALLING BATTERIES

Use a flat-head screwdriver to loosen the screw in the battery compartment cover, then lift open the cover.

**Screw**

**2 AA Batteries**  
**Cat. No. 23-552**

### Cautions:

- Match the polarity symbols (+ and -) marked inside.
- Always use fresh batteries of the required size.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

## USING THE RADIO

**Note:** The radio is water resistant, not waterproof. Do not hang it where water can wash over it.

**VOLUME** — rotate to adjust the volume

**Hanging Strap** — lets you hang the radio in a convenient place, such as over the shower head

**Tuning** — rotate to select your favorite station

**AM/FM** — switch to select the desired band

**Built-In Stand/Washcloth Hanger** — behind the radio; stand it on a firm surface or swing it down to hold a washcloth

## SPECIFICATIONS

Frequency Range ... AM: 530–1710 KHz  
FM: 88–108 MHz

Power Source ..... 3 V DC

Dimensions ..... 5<sup>1</sup>/<sub>8</sub> × 4<sup>3</sup>/<sub>8</sub> × 2<sup>1</sup>/<sub>16</sub> Inches  
(130 × 111 × 53 mm)

Weight ..... 10.6 oz  
(300 g)

Output Power ..... 180 mW

Speaker ..... 4 Ohms

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

© 1997, 1998 Tandy Corporation.  
All Rights Reserved.

Optimus and RadioShack are registered trademarks used by Tandy Corporation.