




**DUAL ZONE WINE CHILLER / VINERA CON 2 ZONAS  
INSTRUCTION MANUAL / MANUAL DE INSTRUCCIONES**

**Model Number / No. de Modelo: WC8302DZD**



**BEFORE USE, PLEASE READ AND FOLLOW ALL SAFETY RULES AND OPERATING INSTRUCTIONS.**

La sección en español empieza en la página 16.

Avanti has a policy of continuous improvement on its products and reserves the right to change materials and specifications without notice.

---

**Avanti Products, A Division of the Mackle Co., Inc.**

**P.O. Box 520604- Miami, Florida 33152**

**[www.avantiproductions.com](http://www.avantiproductions.com)**

---

## APPLIANCE SAFETY

**Your safety and the safety of others are very important.**

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the Safety Alert Symbol. This symbol alerts you to potential hazards that can kill or injure you and others. All safety messages will follow the Safety Alert Symbol and either the words "DANGER", "WARNING" or "CAUTION".



Danger means that failure to heed this safety statement may result in severe personal injury or death.



Warning means that failure to heed this safety statement may result in extensive product damage, serious personal injury, or death.



Caution means that failure to heed this safety statement may result in minor or moderate personal injury, or property or equipment damage.

All safety messages will alert you to what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed.

## IMPORTANT SAFEGUIDES



Before the appliance is used, it must be properly positioned and installed as described in this manual, so read the manual carefully. To reduce the risk of fire, electrical shock or injury when using the appliance, follow basic precaution, including the following:

### DANGER

- ? Plug into a grounded 3 -prong outlet, do not remove grounding prong, do not use an adapter, and do not use an extension cord.
- ? Replace all panels before operating.
- ? It is recommended that a separate circuit, serving only your appliance be provided. Use receptacles that cannot be turned off by a switch or pull chain.
- ? Never clean appliance parts with flammable fluids. These fumes can create a fire hazard or explosion. And do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.
- ? Before proceeding with cleaning and maintenance operations, make sure the power line of the unit is disconnected.
- ? Do not connect or disconnect the electric plug when your hands are wet.
- ? Unplug the appliance or disconnect power before cleaning or servicing. Failure to do so can result in electrical shock or death.
- ? Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this material. All other servicing should be referred to a qualified technician.

### WARNING

- ? Use two or more people to move and install appliance. Failure to do so can result in back or other injury.
- ? To ensure proper ventilation for your appliance, the front of the unit must be completely unobstructed. Choose a well-ventilated area with temperatures above 55<sup>0</sup>F (13<sup>0</sup>C) and below 90<sup>0</sup>F (32<sup>0</sup>C). This unit must be installed in an area protected from the element, such as wind, rain, water spray or drips.
- ? The appliance should not be located next to ovens, grills or other sources of high heat.
- ? The appliance must be installed with all electrical, water and drain connections in accordance with state and local codes. A standard electrical supply (115 V AC only, 60 Hz), properly grounded in accordance with the National Electrical Code and local codes and ordinances is required.
- ? Do not kink or pinch the power supply cord of appliance.
- ? The fuse (or circuit breaker) size should be 15 amperes.
- ? It is important for the appliance to be leveled in order to work properly. You may need to make several adjustments to level it.
- ? All installation must be in accordance with local plumbing code requirements.
- ? Make certain that the pipes are not pinched or kinked or damaged during installations.
- ? Check for leaks after connection.
- ? Never allow children to operate, play with or crawl inside the refrigerator.
- ? Although the unit has been tested at the factory, due to long-term transit and storage, the first batch of cubes must be discarded.
- ? Do not use solvent-based cleaning agents or abrasives on the interior. These cleaners may damage or discolor the interior.
- ? Do not use this apparatus for other than its intended purpose.

## REGISTRATION INFORMATION

Thank you for purchasing this fine Avanti product. Please fill out this card and return it within 100 days of purchase and receive these important benefits to the following address:

**Avanti Products, A Division of The Mackle Co., Inc.  
P.O.Box 520604 – Miami, Florida 33152**

✂ **Protect your product:**

We will keep the model number and date of purchase of your new Avanti product on file to help you refer to this information in the event of an insurance claim such as fire or theft.

✂ **Promote better products:**

We value your input. Your responses will help us develop products designed to best meet your future needs.

------(detach here)-----

### Avanti Registration Card

Name	Model #	Serial #
Address	Date Purchased	Store/Dealer Name
City	State	Zip
Area Code	Occupation	
Phone Number	<b><u>As Your Primary Residence, Do You:</u></b>	
<input type="checkbox"/> Extended	<input type="checkbox"/> Own <input type="checkbox"/> Rent	
<input type="checkbox"/> Food Loss	<b><u>Your Age:</u></b>	
<input type="checkbox"/> None	<input type="checkbox"/> under 18 <input type="checkbox"/> 18-25 <input type="checkbox"/> 26-30	
<b><u>Reason For Choosing This Avanti Product:</u></b>	<input type="checkbox"/> 31-35 <input type="checkbox"/> 36-50 <input type="checkbox"/> over 50	
Please indicate the most important factors that influenced your decision to purchase this product.	<b><u>Marital Status:</u></b>	
<input type="checkbox"/> Price	<input type="checkbox"/> Married <input type="checkbox"/> Single	
<input type="checkbox"/> Product Features	<b><u>Is This Product Used In The:</u></b>	
<input type="checkbox"/> Avanti Reputation	<input type="checkbox"/> Home <input type="checkbox"/> Business	
<input type="checkbox"/> Product Quality	<b><u>How Did You Learn About This Product:</u></b>	
<input type="checkbox"/> Salesperson Recommendation	<input type="checkbox"/> Advertising	
<input type="checkbox"/> Friend/Relative Recommendation	<input type="checkbox"/> In Store Demo <input type="checkbox"/> Personal Demo	
<input type="checkbox"/> Warranty	<input type="checkbox"/> Other _____	
<input type="checkbox"/> Other _____	Comments _____	
	_____	
	_____	

---

## HELP US HELP YOU...

### Read this guide carefully.

It is intended to help you operate and maintain your new appliance properly.

Keep it handy to answer your questions. If you don't understand something or you need more assistance, please call:

**Avanti Customer Service  
800-220-5570**

Keep proof of original purchase date (such as your sales slip) with this guide to establish the warranty period.

### **CAUTION:**

**THIS APPLIANCE IS NOT  
DESIGNED FOR THE STORAGE  
OF MEDICINE OR OTHER  
MEDICAL PRODUCTS.**

### Write down the model and serial numbers.

You'll find them on a plate located on the rear outside wall of the appliance.

Please write these numbers here:

\_\_\_\_\_

Date of Purchase

\_\_\_\_\_

Model Number

\_\_\_\_\_

Serial Number

Use these numbers in any correspondence or service calls concerning your appliance.

If you received a damaged appliance, immediately contact the dealer (or builder) that sold you the appliance.

Save time and money. Before you call for service, check the Troubleshooting Guide. It lists causes of minor operating problems that you can correct yourself.

---

## IF YOU NEED SERVICE


We're proud of our service and want you to be pleased. If for some reason you are not happy with the service you receive, here are some steps to follow for assistance.

FIRST, contact the people who serviced your appliance. Explain why you are not pleased. In most cases, this will solve the problem.

NEXT, if you are still not pleased, write all the details, including your telephone number, and send it to:

**Customer Service  
Avanti Products  
10880 NW 30 Street  
Miami, FL 33172 USA**

## PARTS & FEATURES



1. Digital Readout
2. Chrome Shelves Upper Zone
3. Chrome Shelves Lower Zone
4. Interior Light Upper Zone
5. Interior Light Lower Zone
6. Single Wine Rack Upper Zone
7. Double Wine Rack Lower Zone
8. Leveling Leg
9. Glass Door

## TABLE OF CONTENTS

APPLIANCE SAFETY	2
IMPORTANT SAFEGUIDES	3
REGISTRATION INFORMATION	4
HELP US HELP YOU ...	5
PARTS AND FEATURES	6
IMPORTANT SAFETY INSTRUCTIONS	8
INSTALLATION INSTRUCTIONS	8
BEFORE USING YOUR APPLIANCE	8
INSTALLING YOUR APPLIANCE	8
ELECTRICAL CONNECTION	9
EXTENSION CORD	9
REVERSING THE DOOR SWING OF YOUR APPLIANCE	9
OPERATING YOUR APPLIANCE	9
SETTING THE TEMPERATURE CONTROL	9
SHUTTING DOWN ONE COMPARTMENT	10
INTERIOR LIGHT	11
CARE AND MAINTENANCE	11
REPLACING YOUR LIGHT BULB	11
CLEANING YOUR APPLIANCE	11
POWER FAILURE	11
VACATION TIME	11
MOVING YOUR APPLIANCE	11
ENERGY SAVING TIPS	12
TROUBLESHOOTING GUIDE	12
SERVICE FOR YOUR APPLIANCE	13
YOUR AVANTI PRODUCTS WARRANTY	14
WIRING DIAGRAM	15
INSTRUCCIONES EN ESPAÑOL	16—17

## IMPORTANT SAFETY INSTRUCTIONS

 <b>WARNING</b>	To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:
<ul style="list-style-type: none"><li>? Read all instructions before using the appliance.</li><li>? <b>DANGER or WARNING:</b> Risk of child entrapment. Child entrapment and suffocation are not problems of the past. Junked or abandoned appliances are still dangerous. . . even if they will “just sit in the garage a few days.”</li><li>? <b>Before you throw away your old appliance:</b> Take off the doors. Leave the shelves in place so that children may not easily climb inside.</li><li>? Never allow children to operate, play with, or crawl inside the appliance.</li><li>? Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.</li><li>? Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.</li></ul> <p style="text-align: center;">-Save these instructions-</p>	

## INSTALLATION INSTRUCTIONS

### **BEFORE USING YOUR APPLIANCE**

- ? Remove the exterior and interior packing.
- ? Check to be sure you have all of the following parts:
  - ? 8 Contoured Shelves
  - ? 1 Single Flat Rack
  - ? 1 Double Flat Rack
  - ? 1 Instruction Manual
- ? Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- ? Clean the interior surface with lukewarm water using a soft cloth.

### **INSTALLING YOUR APPLIANCE**

- ? This appliance is designed to be free standing only, and should not be recessed or built-in.
- ? Place your appliance on a floor that is strong enough to support the appliance when it is fully loaded. To level your appliance, adjust the front leveling leg at the bottom of the appliance.
- ? Allow 5 inches of space between the back and sides of the appliance, which allows the proper air circulation to cool the compressor.
- ? Locate the appliance away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extreme cold ambient temperatures may also cause the appliance not to perform properly.
- ? Avoid locating the appliance in moist areas.
- ? Plug the appliance into an exclusive, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorized Avanti Products service center.

## **ELECTRICAL CONNECTION**

### **Warning**

Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by an authorized Avanti Products service center.

This appliance should be properly grounded for your safety. The power cord of this appliance is equipped with a three-prong plug which mates with standard three prong wall outlets to minimize the possibility of electrical shock.

Do not under any circumstances cut or remove the third ground prong from the power cord supplied. For personal safety, this appliance must be properly grounded.

This appliance requires a standard 115/120 Volt AC ~/60Hz electrical outlet with three-prong ground. Have the wall outlet and circuit checked by a qualified electrician to make sure the outlet is properly grounded. When a standard 2-prong wall outlet is encountered, it is your responsibility and obligation to have it replaced with a properly grounded 3-prong wall outlet.

The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury.

The appliance should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the appliance. This provides the best performance and also prevent overloading house wiring circuits that could cause a fire hazard from overheated. Never unplug the appliance by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle. Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end. When moving the appliance, be careful not to damage the power cord.

## **EXTENSION CORD**

Because of potential safety hazards under certain conditions, it is strongly recommended that you do not use an extension cord with this appliance. However, if you must use an extension cord it is absolutely necessary that it be a UL/CUL-Listed, 3-wire grounding type appliance extension cord having a grounding type plug and outlet and that the electrical rating of the cord be 115 volts and at least 10 amperes.

## **REVERSING THE DOOR SWING OF YOUR APPLIANCE**

This appliance has the capability of the door opening from either the left or right side. The unit is delivered to you with the door opening from the left side. Should you desire to reverse the opening direction, please call customer service for reversal instructions.

## **OPERATING YOUR APPLIANCE**

NOTE: The preset temperature at the factory is 50°F and it will show on the display when you press the UP and DOWN buttons for the first time.

## **SETTING THE TEMPERATURE CONTROL FOR EACH ZONE**

You can press **SET** button to control the internal temperature for each zone.

The degrees indicator will appear in the display marked upper (top zone) and lower (bottom zone).

- ? Press the SET button once.  
The LED indicator on the upper display will flash. Then press the **UP** or **DOWN** buttons to get the desired temperature.
- ? When you press the SET button again, the LED indicator on the lower display will flash. Then proceed to press the UP or DOWN buttons to get the desired temperature in the lower section.
- ? The temperature that you desire to set will increase 1°F or 1°C if you push the **UP** button once, on the contrary the temperature will decrease 1°F or 1°C if you push the **DOWN** button once.
- ? When you store mostly red wines, the temperature which you control by pushing the above two buttons need to be set at between 58 to 65°F and the LED lamp near “RED” will be lit.
- ? When you store mostly white wines, the temperature needs to be set at between 48 to 57°F and the LED lamp near “WHITE” will be lit.
- ? When you store mostly sparkling wines, the temperature needs to be set at between 40 to 47°F and the LED lamp near “SPARKL” will be lit.
- ? You can select temperature display setting from Fahrenheit to Celsius degree by pushing the **C** button.
- ? You can select temperature display setting from Celsius to Fahrenheit degree by pushing the **F** button.
- ? Fahrenheit and Celsius degrees indicator will appear on either the upper or lower displays.



Note: Once the unit is plugged in, the upper compartment will be cooled down first, only after the temperature in the upper compartment reaches the set degrees, the cooling of the lower compartment will begin.

**SHUTTING DOWN ONE COMPARTMENT**

When you do not have many bottles to store and you wish to shut down one of the compartments, you can do the following:

- ✍ Press **SET** button and the temperature in the UPPER window flashes, then press **UP** button and hold for 3 seconds, there will be an “OFF” displayed on the window. The upper compartment is shut down.
- ✍ To re-start, press **SET** button till the “OFF” flashes, press **UP** button and hold for 3 seconds, the upper compartment starts to cool again.

**STORAGE**

Many bottles may differ in size and dimensions. As such the actual number of bottles you may be able to store may vary.

**NOTE:** You can place 33 standard bottles in the upper zone and 47 standard bottles in the lower zone.

Most contoured shelves hold 7 standard bottles.

### **INTERIOR LIGHT**

- ? Interior lights are available in both upper and lower zones.
- ? You can turn the interior light on in each zone by pushing the LIGHT ON/OFF button.
- ? The lights will turn off automatically if it remains ON for 10 minutes or more.

## **CARE AND MAINTENANCE**

### **REPLACING YOUR LIGHT BULB FOR EACH ZONE**

#### **NOTE:**

All parts removed must be saved to do the replacement of the light bulb.

Before removing the light bulb, either unplug the appliance or disconnect the electricity leading into the appliance at the main power supply. Failure to do so could result in electrical shock or personal injury.

- ? Press the light switch to the "OFF" position.
- ? Hold firmly the light house cover on the ceiling of the inner cabinet, and slide it out.
- ? Replace with a 5-watt bulb that is the same shape and size.
- ? Hold and insert the light house cover to its original position.



1 – Bulb  
2 – LightHouse Cover

### **CLEANING YOUR APPLIANCE**

- ? Unplug the appliance, and remove shelves.
- ? Wash the inside surfaces with a warm water and baking soda solution. The solution should be about 2 tablespoons of baking soda to a quart of water.
- ? Wash the shelves with a mild detergent solution.
- ? The outside of the appliance should be cleaned with mild detergent and warm water.
- ? Wring excess water out of the sponge or cloth before cleaning the area of the controls, or any electrical parts.
- ? Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth.

#### **CAUTION:**

Failure to unplug the appliance could result in electrical shock or personal injury.

### **POWER FAILURE**

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened. If the power is going to be off for a longer period of time, you need to take the proper steps to protect your wine bottles.

#### **NOTE:**

- ✗ If the unit is unplugged, has lost power, or is turned off; you must wait 3 to 5 minutes before restarting the unit. If you attempt to restart before this time delay, the appliance will not start.

### **VACATION TIME**

- ? **Short vacations:** Leave the appliance operating during vacations of less than three weeks.
- ? **Long vacations:** If the appliance will not be used for several months, remove all items and unplug the power cord. Clean and dry the interior thoroughly. To prevent odor and mold growth, leave the door open slightly: blocking it open if necessary.

### **MOVING YOUR APPLIANCE**

- ? Securely tape down all loose items inside your appliance.
- ? Turn the leveling screw up to the base to avoid damage.
- ? Tape the door shut.
- ? Be sure the appliance stays secure in the upright position during transportation. Also protect the outside of appliance with a blanket, or similar item.

### **ENERGY SAVING TIPS**

- ? The appliance should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.

### **PROBLEMS WITH YOUR APPLIANCE**

You can solve many common appliance problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

### **TROUBLESHOOTING GUIDE**

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>
Appliance does not operate.	Not plugged in. The circuit breaker tripped or a blown fuse.
Appliance is not cold enough.	Check the temperature control setting. External environment may require a higher setting. The door is opened too often. The door is not closed completely. The door gasket does not seal properly.
Turns on and off frequently.	The room temperature is hotter than normal. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly.
The lights do not work.	Not plugged in. The circuit breaker tripped or a blown fuse. The bulbs have burned out. The switch is in the "OFF" position.
Vibrations.	Check to assure that the appliance is level.
The appliance seems to make too much noise.	The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your appliance. Contraction and expansion of the inside walls may cause popping and crackling noises. The appliance is not level.
The door will not close properly.	The appliance is not level. The door was reversed and not properly installed. The gasket is dirty. The shelves are out of position.

## SERVICE FOR YOUR APPLIANCE

We are proud of our customer service organization and the network of professional service technicians that provide service on your Avanti refrigerators. With the purchase of your Avanti appliance, you can be confident that if you ever need additional information or assistance, the Avanti Products Customer Service team will be here for you. Just call us toll-free.

### AVANTI PRODUCTS CUSTOMER SERVICES

Product Information 800-323-5029	Whatever your questions are about our products, help is available.
Part Orders 800-220-5570	You may order parts and accessories that will be delivered directly to your home, by personal check, money order, Master Card, or Visa.
In-Home Repair Service 800-220-5570	An Avanti Products authorized service center will provide expert repair service, scheduled at a time that is convenient for you. Our trained servicers know your refrigerator inside and out.

**YOUR Avanti Products WARRANTY**

**Staple your sales receipt here. Proof of original purchase date is needed to obtain service under warranty.**

**WHAT IS COVERED****LIMITED ONE-YEAR WARRANTY**

For one year from the date of purchase by the original owner, Avanti Products will, at its option, repair or replace any part of the appliance, which proves to be defective in material or workmanship under normal use.

During this period Avanti Products will provide all parts and labor necessary to correct such defects free of charge, so long as the appliance has been installed and operated in accordance with the written instructions in this manual. In rental or commercial use, the warranty period is 90 days. All Avanti appliances of 3.5 cubic feet capacity or less must be brought/sent to the appliance service shop for repair.

**LIMITED SECOND THROUGH FIFTH YEAR WARRANTY**


For the second through the fifth year from date of original purchase, Avanti Products will provide a replacement compressor free of charge due to a failure. You are responsible for the service labor and freight charges. In rental or commercial use, the limited compressor warranty is one year and nine months. Cost to move the appliance to the servicers' shop and back to the user's home, as may be required, are the user's responsibility.

---

**WHAT IS NOT COVERED**

- ? Content losses of food due to spoilage.
- ? Incidental or consequential damages.
- ? Parts and labor costs for the following will not be considered as warranty:
  - ? Evaporator doors, door springs, and/or frames.
  - ? Inner door panels, door shelves, door rails, and/or door supports.
  - ? Chest refrigerator lid liners.
  - ? Vegetable crispers.
  - ? Light bulbs and/or plastic housing.
  - ? Plastic cabinet liners.
  - ? Punctured evaporator that voids the warranty on the complete sealed system.
- ? Repairs performed by unauthorized servicers.
- ? Service calls that do not involve defects in material or workmanship such as customer education, door reversal, or proper installation.
- ? Service calls that are related to external problems, such as abuse, misuse, inadequate electrical power, accidents, fire, floods, or acts of God.
- ? Replacement of house fuses or resetting circuit breakers.
- ? Failure of the product if it is used for other than its intended purpose.
- ? This warranty does not apply outside the Continental USA.

## WIRING DIAGRAM



- A. READOUT PCB
- B. MAIN CONTROL PCB
- C. LOWER INDUCTOR
- D. UPPER INDUCTOR
- E. UPPER LAMP
- F. LOWER LAMP
- G. POWER PLUG
- H. SOLENOID VALVE
- I. OVERLOAD PROTECTOR
- J. PTC STARTING RELAY
- K. COMPRESSOR

## INSTRUCCIONES EN ESPAÑOL

### INSTALACION

Retire los accesorios de empaque (plásticos protectores, cartón y tiras engomadas). Limpie el exterior con un trapo suave y seco, y el interior con un trapo húmedo y tibio.

### UBICACION

1. Seleccione un lugar con un piso firme y nivelado.
2. Su vinera requiere ventilación. Deje un espacio mínimo de 5" hacia arriba y espacio suficiente en el respaldo para permitir la circulación de aire.
3. Evite luz directa del sol o calor. La luz directa del sol puede afectar la capa de pintura. Las fuentes de calor en su proximidad causarán un consumo mayor de electricidad.
4. Para un mejor desempeño, nivele la vinera utilizando las patas ajustables o tornillos niveladores. Para verificar el nivel, abra la puerta hasta la mitad, debe regresar sola.

### INSTRUCCIONES PARA LA CONEXION A TIERRA

Este aparato electrodoméstico debe estar conectado a tierra. En caso de un cortocircuito eléctrico, la conexión a tierra reduce el riesgo de choque eléctrico proporcionando un cable de escape para la corriente eléctrica. Este aparato viene equipado con un cordón que posee un cable a tierra con un enchufe de conexión a tierra. Este enchufe debe estar conectado en un tomacorriente instalado correctamente y conectado a tierra.

### ADVERTENCIA

El uso inadecuado del enchufe de conexión a tierra puede resultar en un riesgo de choque eléctrico. Consulte con un electricista si no comprende bien las instrucciones de conexión a tierra o si existe alguna duda sobre si el aparato está conectado a tierra correctamente.

### NO USE UN CORDON DE EXTENSION ELECTRICA

Use un tomacorriente de pared exclusivo. No conecte su vinera a cordones de prolongación eléctrica o junto a cualquier otro electrodoméstico en el mismo tomacorriente de pared.

### ADVERTENCIA IMPORTANTE:

Un electrodoméstico vacío es una atracción muy peligrosa para los niños. Quite los sellos magnéticos, puertas o cerraduras de todo electrodoméstico que no esté en uso, es también aconsejable remover o quitar ambas puertas al momento de desechar su vinera.

**NOTA:** La vinera de fábrica y enseñará 50°F (10°C) en la pantalla cuando usted oprima los botones marcados ? o ? por primera vez.

### OPERACION

COMO PROGRAMAR EL CONTROL DE TEMPERATURA PARA CADA ZONA.

- ? Oprima el botón marcado SET una vez, el indicador en la pantalla marcada UPPER (zona superior) se alumbrará de forma intermitente.
- ? Oprima los botones ? (abajo) y ? (arriba) para obtener la temperatura deseada.
- ? Cuando Ud oprime el botón marcado SET de nuevo, el indicador en la pantalla marcado LOWER (zona inferior) se alumbrará de forma intermitente.
- ? Oprima los botones ? (abajo) y ? (arriba) para obtener la temperatura deseada.
- ? Si en su mayoría Usted solamente guarda vinos blancos, presione el botón designado "white" o blanco y la vinera mantendrá una temperatura entre 10° y 11° C. La pantalla digital se alumbrará en color verde.
- ? Al presionar el botón marcado "red" o rojo, la vinera mantendrá una temperatura entre 14° y 16° C. La pantalla digital se alumbrará en color rojo.
- ? Presione el botón marcado "sparkling" o espumante y la vinera mantendrá una temperatura entre 7° y 9° C. El indicador (pantalla digital) se alumbrará en color amarillo.
- ? Al conectar su vinera por primera vez, puede haber una variante de varios grados entre la temperatura seleccionada y la indicada en la pantalla digital. Esto es normal y es debido al largo

periodo de activación y desactivación. Si usted ha programado la vinera a 15° por ejemplo, podría aumentarlo oprimiendo el botón marcado ? sucesivamente o podría bajarlo oprimiendo el botón marcado ? .

- ? También puede cambiar de grados centígrados a Fahrenheit, oprimiendo el botón marcado C/F°. F° aparecerá en la pantalla de color rojo, C° aparecerá en la pantalla de color amarillo.

### **ALMACENAJE**

Muchas botellas se diferencian en tamaño y diámetro. Como tal el número de botellas que usted puede almacenar puede variar. (mire las páginas 6 y 10)

### **LUZ INTERNA**

La luz interna está disponible en las dos zonas.

Usted puede automáticamente controlar la operación de iluminación oprimiendo el botón marcado LIGHT ON/OFF. La luz se apagará automáticamente después de 10 minutos.

### **CUIDADOS EN LOS PERIODOS DE AUSENCIA**

- ? Para cortos periodos de ausencia (menos de 21 días) el congelador podrá quedar funcionando. Coloque el botón de control de temperaturas en la posición mínima.
- ? En periodos de ausencia más largos, se aconseja dejar la vinera limpia y desconectada.
- ≠ Saque todo lo que tenga adentro de la vinera y haga el deshielo y la limpieza general.
- ? Deje la puerta entreabierta para que penetre el aire y así evitar la formación de olores.

### **ECONOMIA DE ENERGIA**

- ? Evite dejar por mucho tiempo las puertas abierta.
- ? Evite aperturas frecuentes de las puertas.
- ? Nunca coloque alimentos calientes dentro del refrigerador. Espere que estén a una temperatura ambiental.
- ? Coloque el botón de control de temperaturas en la posición adecuada.

### **SI USTED SE VA DE VACACIONES POR UN PERIODO DE 30 DIAS O MAS**

- ≠ Saque todos los artículos de la vinera.
- ? Desconecte la vinera del tomacorriente y limpie la vinera bien.
- ? Deje las puertas abierta para evitar la formación de olores, condensación o moho.

### **SI USTED SE MUDA**

- ? Desconecte la vinera del tomacorriente y limpie la vinera bien.
- ? Saque todas las partes movibles y empaquételas para que no se muevan durante la transportación.
- ? Cierre la puerta del refrigerador y séllela con cinta adhesiva.
- ? Asegúrese que el refrigerador va parado durante el viaje y cúbralo con una frazada.

**PRINTED IN CHINA**