

Operating Manual for the Sonic Frontiers Power 2 Stereo Amplifier




Operating Manual for the Sonic Frontiers Power 2 Stereo Amplifier


We at Sonic Frontiers hope you will derive many years of listening pleasure with your new Power 2 Amplifier. This Operating Manual contains important information regarding the operation and care of this Amplifier. Be sure to read this manual carefully and follow these instructions in order to keep them performing and sounding their best. Please contact Sonic Frontiers if you have any questions - a Customer Service Representative will be pleased to assist you.

Contents

Unpacking.....	1
Quick Setup.....	2
Reference Diagrams	3
Installing the Tubes	5
Biasing of the Power Tubes.....	7
Controls, Functions and Connections.....	8
Adjustment for Load Impedance.....	10
Care and Maintenance.....	12
Troubleshooting.....	13
Warranty.....	14
Specifications.....	15



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Sonic Frontiers Inc. can be reached at:
2790 Brighton Road, Oakville, Ontario, Canada L6H 5T4
Tel: (905) 829-3838 Fax: (905) 829-3033
E-Mail: SFI@sonicfrontiers.com WWW: <http://www.sonicfrontiers.com>

Unpacking

At this point we can assume that you have successfully opened the box flaps and found this manual. The box was designed to ensure the safe transport of the amplifier, Sonic Frontiers strongly recommends the storage of the Power 2 box in a safe, dry place. In the event that the amplifier may have to be shipped in the future, the original box is the best means for the protection and safety of the Power 2 during transportation.

You may want to enlist a friend's help to remove the amplifier from the box, the weight can make this awkward (hint: the back of the chassis is the heavy end). Here is a chart listing what you will find in the box:

	Packaged Items
Tube Complement:	8-6550C or KT88 6-6922 2-5687
Slot Screwdriver	1
Phillips Screwdriver	1
Biasing Tool	1
Power Cord	1
Pearl Tube Coolers (with O rings)	2
Cotton Gloves	1 pair
Extra Fuse	2
Amplifier	1
Tube Cover	1
Warranty Card	1
Operating Manual	1

If after your inspection of the contents there is a discrepancy, contact your dealer or Sonic Frontiers immediately.

Quick Setup

At this point we urge you to read and understand this manual in its entirety. But if you desire immediate action and have skill and/or past experience with tube hardware, follow these steps.



1. Place the amp on a hard flat surface that will not impede airflow under the amplifier's chassis (carpeting or area rugs are NOT acceptable as hard surfaces).

2. Ensure the Power 2 is in Mute mode (these selector switches are on the rear of the chassis). When disconnecting and connecting cable, placing the amplifier in Mute is an excellent practice.

3. Tube bias was set at the factory prior to shipment. Tubes are also marked for their corresponding socket location. Carefully inspect each and install appropriately. Check *Installing the Tubes and Biasing of the Power Tubes* (a must read) for further clarification.

4. Connect your preamplifier's left and right balanced or single-ended outputs to the left and right inputs of the amplifier.




5. Connect the speakers to the positive (+) red and negative (-) black output binding post. Note: It is not recommended to operate any tube amplifier without its speaker load connected.

6. Select the input for use via the selector switch: XLR-Balanced, Single-Ended Non-Inverting, Single-Ended Inverting .

7. Power up your system turning the power amplifier on last ensuring that both green LEDs are on (no Standby or Mute activation). Allow 5 minutes of warm up before operation.

Reference Diagrams



This drawing is referred to as the "Tube Top" within the instructional text.


Tube locations V1 to V3 and LV1 to LV3 indicate placement for the six 6922 tubes.

Tube locations V4 and LV4 indicate placement for the two 5687 tubes.


Locations V5 to V8 and LV5 to LV8 indicate placement for the 6550C/KT88 power tubes.

- A Holes on the Tube Top labeled "A" are LED indicators for the bias of the power tubes situated nearest.
- B Holes labeled "B" are the location of the bias controls. The bias controls adjust the bias of the tube which they are joined to by the lines. Direction arrows around the controls indicate the rotation of the control to INCREASE the bias of the power tubes.

This drawing is referred to as the "Front Panel" within the instructional text.



This drawing is referred to as the "Rear Panel" within the instructional text.



- C Power Switch
- D Standby Switch
- E Power LED (Green - Power; Red - Mute; Orange (Red + Green) - One Channel in Mute)
- F Standby LED (Green - Operate; Red - Standby)
- G Detachable IEC Power Cord Socket
- H Fuse Location
- I Left and Right Channel Input Selector Switches
- J Left and Right Channel Balanced XLR Inputs
- K Left and Right Channel Single-Ended RCA Inverting Inputs
- L Left and Right Channel Single-Ended RCA Non-Inverting Inputs
- M Left and Right Channel Ground Posts
- N Left and Right Channel Loudspeaker Binding Posts

Installing the Tubes




Be sure the amplifier is OFF (Power Switch Out) before installing any tubes or when any of the tube sockets are empty.

Wearing the cotton gloves provided with the amplifier when handling tubes will prevent skin oils from depositing on the glass surface of the tubes. The oils could cause the tubes to become "gassy" and fail prematurely.

Inspecting the tube boxes that come with the amplifier, you will notice that the boxes and power tubes themselves are labeled to corresponding sockets also labeled on the tube top surface. See Reference Diagrams for further clarification. Insert each tube in the corresponding socket.

Starting with the 9 pin small signal tubes (the 6922s and 5687s), pay extra attention to the tube pins and socket holes for these tubes. You will notice an open space where an imaginary tenth pin or hole would be. This is for proper tube alignment. Be sure pins are in line with holes when installing tubes. Gently rock the tube into the socket until the tube is firmly seated. The 6922 tubes are inserted into sockets designated V1 to V3 and LV1 to LV3. The 5687 tubes are inserted into sockets V4 and LV4.


Note the larger space between two of the pins and holes for proper alignment of tube and socket.



DO NOT PLACE 6922 TUBES IN A 5687 SOCKET OR A 5687 TUBE IN A SOCKET DESIGNATED FOR A 6922 TUBE. THIS COULD RESULT IN DAMAGE TO THE TUBE, AMPLIFIER (OR BOTH) THAT WOULD NOT BE COVERED UNDER WARRANTY.

The 5687 tube is designed to run very hot. In its implementation in the Power 2, it is being used at 1/3 its ratings. Even at this rating, the 5687 still gets hot and therefore, the 2Pearl™ Tube coolers should be installed over the 5687 tubes. The chassis has been designed with larger holes to accommodate these essential devices to keep these tubes "comfortable" and allow efficient operation. Just slide the coolers over the already installed tubes and add the rubber O rings around the coolers to clamp them in place. Hint: Add O rings before tube cooler is slid down fully.

When installing the 6550C or KT88 power tubes, match the numbers designated on the metal base of the tube or the tube boxes to the corresponding markings printed on the tube top (V5 through V8 and LV5 through LV8) and be sure the center pin key locator is in alignment with the slot in the center of the socket. Again push down the tube, rocking gently until it is firmly seated.



Note the locating center key and notch for proper alignment of tube and socket.

Biasing of the Power Tubes

Bias voltage applied to the grids of the power tubes in the output stage should be checked from time to time (once a month) to keep these tubes operating at the optimum operating point. A properly biased power tube will have a longer, happier life.


To check the bias of the 6550C/KT88 tubes, place the amplifier in mute with the power on and the amplifier in operate mode (STANDBY LED Green; Power LED Red-for MUTE). Looking at the tube top, take note of the power tube location and the bias LED below the surface of the chassis next to each tube. Also note the printed line that leads to each power tube. At the opposite end of this line is the bias adjustment for each power tube, a small slotted metal shaft, again located below the chassis surface. See reference diagrams for further clarification.

If a bias LED is glowing red the tube is overbiased; if a bias LED is glowing green the tube is underbiased, both conditions cause undue wear and/or are not optimal for the tube. The LED should not be glowing at all for the proper operating bias.

To properly bias the tubes is a simple procedure. For the power tubes on the left (LV5 to LV8) insert the biasing driver into the slot head of the bias adjustment control and turn the driver to adjust the control counterclockwise so the LED is green. Turn the adjustment back clockwise until the LED begins to dim. At this point; through careful adjustment, continue slowly turning the bias control, stopping the moment the LED goes out. No light from the LED indicates a properly biased tube. For the most accurate biasing, the biasing controls should always be rotated from the LED emitting green to the LED emitting no light, stopping immediately, as soon as the LED emits no light. Repeat procedure on the next tube until all tubes are properly biased.

For tubes on the right side of the amplifier (V5 to V8) the biasing controls are opposite. Turn the biasing controls clockwise initially to decrease bias so the LED is green and counterclockwise until the LED goes out. Refer to the Tube Top diagram for direction.

A cutaway of the tube top showing the location of the biasing controls below the tube top surface and the biasing driver.



Controls, Functions and Connections

Front Panel

Refer to Reference Diagrams.

C Power Switch

This switch provides control over the AC power from your wall outlet. When OFF (out position) nothing on the amplifier is functional. When ON (depressed) the amplifier will operate normally (green power LED indicates ON; Red Power LED indicates ON but in MUTE mode).

D Standby Switch

This switch when OFF (out position) will allow normal operation of the amplifier (indicated by the green Standby LED, assuming Power ON). When depressed ON the amplifier will be placed in STANDBY mode and will not be operational (indicated by the red standby LED, assuming Power ON). In this mode, a small amount of current will remain flowing through the tubes, this reduces power consumption and extends tube life during periodic short term non-use periods (i.e. during a listening session when interruptions occur, or a short time prior to a listening session so the amplifier is warm and ready). This mode also will keep optimal warm up times of the tubes shorter. For periods between listening sessions extending over a 12 hour period, it is recommended that the Power 2 is turned off via the Power Switch.

E Power LED

When this LED is off, so is the amplifier. When the LED is glowing red, both channels are Muted, controlled by the Input Selector Switches (I). When the LED is green, the amplifier is receiving power and both inputs are selected, the amplifier is ready for operation. (Green Power LED indicates ON; Red Power LED indicates ON but in MUTE mode; Green + Red (Orange) indicates one channel is in MUTE and one channel is selected).

F Standby LED


When this LED is off, so is the amplifier. When the LED is glowing red, this indicates the amplifier is in Standby mode, controlled by the Standby Switch. When the LED is green the amplifier is in operate mode.

Rear Panel

Refer to Reference Diagrams.

G Detachable Power Cord Socket

Plug the detachable Power Cord into this socket. The Power 2 amplifier is configured for the operating voltages in which they are sold. See shipping box or Voltage/ Impedance sticker on rear of the chassis for voltage settings. If a different operating voltage is required, please contact an authorized Sonic Frontiers dealer or the factory directly.



H Fuse Location

rated between 110-120V or a 3.5 amp slo-blo fuse for countries operating on a 220-240V supply.



REPLACEMENT FUSES MUST BE RATED WITH THE SAME SPECIFICATIONS AS THE ORIGINAL FUSE.

Damage due to bypassing the fuse or due to replacement of a fuse of higher ratings will not be covered under the warranty. To access the fuse, insert the slotted screwdriver, pushing to compress the internal spring and turn counterclockwise to unlock the housing. The spring will then eject the fuse and the housing.


I Left and Right Channel Input Selector Switches

These switches must both be rotated to the desired position to select the desired input, XLR Balanced, RCA Single-Ended Non-Inverting (+) or Inverting (-) for normal operation. In the MUTE position, this control allows for BIASING CONTROL of the power tubes and for safe cable swapping without shutting down the amplifier. When both switches are in the MUTE position the front panel Power LED will turn RED. Note: This position is purposefully positioned at 12 o'clock so it can be easily determined when access is obscured. The front panel Power LED will also turn red if this switch has selected an input which has no connection. If any input selector switch is in MUTE and the other is not, the Power LED will be a Red & Green colour at the same time.

J Left and Right Channel Balanced XLR Inputs

These inputs accept an XLR balanced connection from the preamp's left and right balanced outputs. Connections should be made left channel to left channel right channel to right. Note: The XLR pin configurations are as follows:

- Pin#1- Ground
- Pin#2- Positive
- Pin#3- Negative



View from front of connector.

K Left and Right Channel Single-Ended RCA Inverting Inputs

These inputs accept an input signal from a single-ended output of a preamp or source that is 180° out of phase relative to the original signal and correction for this configuration is desired. The input on the Power 2 does invert the phase of the output signal, relative to the input signal. Connections should be made left channel to left channel right channel to right.

L Left and Right Channel Single-Ended RCA Non-Inverting Inputs

These inputs accept an input signal from a single-ended output of a preamp or source that is inabsolute phase or are used if it is desired to maintain the phase of the signal from the preamp. Simply explained, this input does not invert the phase of the output signal relative to its input. Connections should be made left channel to left channel right channel to right.

M Left and Right Channel Ground Posts

This post is offered for use when a ground connection is required (i.e. when amplifier's function is being tested by a technician). It has no use for day-to-day audio related operation.

N Left and Right Channel Loudspeaker Binding Posts

These posts are used to connect the amplifiers to the speakers; positive terminal to positive terminal, negative terminal to negative terminal, from the right posts to the right speaker and left posts to the left speaker.



WARNING: AMPLIFIER OUTPUT IS BALANCED.
 CARE MUST BE TAKEN TO ENSURE THE AMPLIFIER IS NOT CONNECTED TO LOUDSPEAKERS (CERTAIN SUBWOOFERS) OR LOUDSPEAKER SWITCHBOXES THAT HAVE A COMMON GROUND. CONSULT YOUR DEALER OR SONIC FRONTIERS DIRECTLY FOR FURTHER CLARIFICATION REGARDING CONNECTIONS TO ITEMS IN THESE UNIQUE CASES. DAMAGE TO THE AMPLIFIER OR CONNECTED EQUIPMENT WILL NOT BE COVERED UNDER WARRANTY IF THESE WARNINGS ARE IGNORED.

Adjustment for Load Impedance



Note: Adjustment for load impedance should only be done by an authorized Sonic Frontiers dealer, distributor or service technician. Any damage to the amplifier as a result of a person(s) not authorized by Sonic Frontiers will not be covered under warranty.




Warning: Dangerous voltages exist within this amplifier.

The nominal speaker load of the amplifier was factory set to the impedance designated on the Voltage/Impedance sticker on the back of the chassis and shipping carton. In the event that you should require different impedance operation, the amplifier can be set to handle 2, 4 or 8 ohm loads. Some experimenting of this setting may be required for speakers which vary considerable in impedance across a frequency range. To change the output setting have your Sonic Frontiers' dealer follow these steps:




1. Unplug all connections to the power amplifier, namely the AC power supply cord and wait a minimum of 20 minutes for all power supplies to discharge.

2. Place the amplifier on the rear handles so it is upright and the underside is exposed. Using the Phillips screwdriver provided unscrew the bottom panel and remove.




3. Look for the terminal blocks under the transformer housings which looks like this:




4. Using the slot screwdriver provided with the amp, deal with one connection at a time, loosening off the tap screws of the first spade lug connection and tightening to the desired tap. The final connections should resemble these renderings:


8 Ohm Impedance Connections



4 Ohm Impedance Connections



2 Ohm Impedance Connection



5. Repeat for each channel.

6. Ensure all 12 screws per terminal block are tightened so there is no chance of them vibrating loose.

7. Replace the bottom cover and all external connections.

Care and Maintenance


Placement

The amplifier must be placed on a hard flat surface with plenty of unobstructed space around the Power 2 to allow for free movement of air for proper cooling. If the amplifier is to be placed on a carpeted floor, a Wood, Ceramic, Concrete, Marble... tile or slab 18" x 22" (or larger) must be placed under the Power 2 Amplifier.

If the amplifier is left unattended or is exposed near small children or pets, it is recommended that the tube cover be used. Cooling of the tubes is not as effective with the cover on, although it does allow for adequate operating temperatures.

To add the cover, simply place the cage over the tube top. The cover is locked through the tightening of the large screw heads on the sides located between the tube top and transformer case.

The location of the screw which locks the tube cover in place.



To remove the cover, loosen screws that were indicated for fastening. The Power 2's fastening screw is spring loaded for release after it is loosened. Then while applying a small amount of outward tension at the screw locations, lift the cover straight up and away from the tubes.

If the tube cover is not used, it is recommended that the tubes, namely the 6550C/KT88s are protected from settling dust in NON-USE periods. Dust settling on the tubes can cause heat impairment of the tubes. Therefore, when the amplifier is NOT IN USE, a cloth or dust cover should be used.

How do I know when to replace the tubes?

If the tubes lack power to drive your speakers, are hard to bias or won't hold bias, it could be time for replacements. Power tubes generally wear faster than small signal tubes, but how much faster depends on how often you run your system. If you need help determining these factors or sourcing replacement tubes, contact your Sonic Frontiers dealer, Sonic Frontiers or The Parts Connection (a division of Sonic Frontiers, 1-800-769-0747 in the U.S. or Canada, (905) 829-5858 for elsewhere) for further assistance.



Cleaning

Sonic Frontiers recommends only a dry cloth be used to clean the Power 2 Amplifier. Sonic Frontiers does not warranty damage done through liquids spilled on circuitry.

Troubleshooting

If at any time the amplifier should fail to work, follow these steps:

1. Check that all tubes are fully seated in correct sockets and all tube filaments are lit.
2. Check all connections at the rear panel.
3. Check that the amplifier is not in MUTE mode.
4. Check that the proper input is selected via the Selector Switch.
5. Check that the amplifier is in POWER ON mode and NOT in STANDBY mode.
6. Check other equipment and connections to that equipment in your system, from speakers to source.
7. Check that no fuses are blown in all equipment and/or breaker switches in the home.

If this checklist fails to be fruitful, contact your dealer or Sonic Frontiers directly.

Servicing

If the amplifier ever requires servicing in or outside of the warranty limitations, contact your Sonic Frontiers dealer or Sonic Frontiers directly.

Break-in Time

As with all audio electronic products, the ultimate sonic character of the Power 2 will not be realized until and unless the unit receives a minimum of approximately 70 hours of signal break-in time (i.e. the Power 2 is on and outputting a signal).

Safety Instructions

1. Water and Moisture - This product should not be used near water. To prevent fire or shock hazard, do not expose this product to rain or moisture.
2. Heat - This product should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances which produce heat.
3. Power Sources - This product should be connected to an AC power source of the proper rated voltage. The original shipping container will stipulate the AC voltage this unit can operate with correctly.
4. Servicing - Do not open this product for any reason. No user serviceable parts inside. Refer servicing to an authorized service technician.
5. Non-Use Periods - The power cord of this product should be unplugged from the outlet when left unused for an extended period of time.
6. Do not remove the top or bottom covers while the unit is "on", or connected to an AC power source. Cover screws could fall through the ventilation slots and cause electrical damage to the amplifier.

Warranty

Disclaimer of Liability

Under no circumstances does Sonic Frontiers, Inc. assume liability or responsibility for injury or damages sustained in the use or operation of this equipment or for damages to any other equipment connected to it. Sonic Frontiers, Inc. reserves the right to make design changes or improvements without the obligation to revise prior versions. All specifications are subject to change without notice.

Limited Five Year Warranty

Sonic Frontiers, Inc. warrants to the purchaser that each amplifier is free of manufacturing defects for a period of five (5) years from the date of purchase. This five (5) year limited non-transferable warranty excludes all vacuum tubes, which we warrant for a period of twelve (12) months. To receive this warranty, the original purchaser must complete and mail to Sonic Frontiers, within thirty (30) days from the date of purchase, the enclosed Warranty Registration Card. Sonic Frontiers, Inc. will then validate the warranty to the original purchaser. This warranty is subject to the following conditions and limitations:

1. Warranty applies only to the original purchaser.
2. This warranty is void and inapplicable if the product has been handled other than in accordance with the instructions in this Owner's Manual, abused or misused, damaged by accident or neglect or in being transported, or the defect is due to the product being tampered with, modified or repaired by anyone other than Sonic Frontiers, Inc. or an authorized Sonic Frontiers repair depot.
3. Warranty does not cover normal maintenance.
4. Sonic Frontiers, Inc. shall not be responsible in any way for consequential or indirect damages or liabilities resulting from the use and operation of the product covered herein or resulting from any breach of this warranty or any implied warranty relating to said product.

During this period, Sonic Frontiers, Inc. will repair or replace any defective components free of charge. A Return Authorization Number (RA Number) is required before any product is returned to our factory for any reason. This number must be visible on the exterior of the shipping containers for Sonic Frontiers to accept the return.

Units shipped to us without a Return Authorization Number or without a visible RA Number on the exterior of the shipping containers will be returned to the sender, freight collect.

Units to be repaired by Sonic Frontiers, Inc. must be sent shipping and insurance prepaid by the original purchaser in the original packing material. A returned product should be accompanied by a written description of the defect. Repaired units will be returned by Sonic Frontiers, Inc. shipping and insurance prepaid.

All other warranties or conditions either written or implied are void.

Note: In foreign markets (anywhere outside of Canada and the USA), the warranty is supplied by the authorized International Distributor. Exact terms and conditions may vary.

Specifications

Note: Power ratings based on a nominal power line input. All specifications are made on the 8 ohm taps, utilizing an 8 ohm load unless otherwise specified.

Power Output:	110 watts continuous at 8, 4 and 2 ohms from 20 Hz to 20 kHz with less than 1% total harmonic distortion terminated with rated load (typically <0.5% @ 110 watts 1 kHz) both channels driven. Actual power output available at clipping (defined as <1% THD) approximately 120 watts RMS
SMPTE Intermodulation Distortion:	<1% 20 Hz to 20 kHz @ 110 watts output
Power Bandwidth: (110 watt output)	15 Hz to 90 kHz (-0.5 dB points) 5 Hz to 110 kHz (-3 dB points)
Frequency Response:	5 Hz to 40 kHz @ 1 watt (-0.5 dB points) 2 Hz to 120 kHz @ 1 watt (-3 dB points)
Input Sensitivity (for 110 watt output):	1.25V RMS balanced for 110 watts output 1.25V RMS single-ended (inverting or non-inverting)
Input Impedance:	200K ohms balanced 100K ohms single-ended (inverting or non-inverting)
Damping Factor:	>50 (determined using the IHF method from RS-490)
Output Impedance:	0.30 ohms at 1 kHz
Negative Voltage Feedback:	16 dB
Hum and Noise:	approximately 400 microvolts of wideband, unweighted noise @ the 8 ohm taps, input muted; -110 dB below a 110 watt output
Rise Time:	3.0 microseconds
Slew Rate:	16 volts/microsecond
Power Requirements:	110-120 VAC 60 Hz (220-240 VAC); 580VA at rated output, 650VA maximum and 375VA with no signal input
Tube Complement:	8 (4 matched pair) x 6550C/KT88 - power output; 6 x 6922 - input/driver; 2 x 5687 - high voltage driver
Dimensions:	18" (46 cm) W x 22" (56 cm) D x 9" (23 cm) H
Weight (approx.):	110 lbs (50 kg) net each (unpacked)

Sonic Frontiers continually strives to improve their products; specifications are subject to change without notice.