



Please keep this instruction sheet for future reference, as it contains important information.

Requires three "AA" batteries (included).

Adult assembly is required for battery replacement.

Tool required for battery replacement:


Phillips screwdriver (not included).



[www.fisher-price.com](http://www.fisher-price.com)

# First Words Activity Book

# Battery Replacement



**For best performance, we recommend replacing the batteries that came with this toy with three new “AA” (LR6) alkaline batteries.**

- Locate the battery compartment on the bottom of the toy.
- Loosen the screw in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door.
- Insert three “AA” (LR6) **alkaline** batteries, as indicated inside the battery compartment.

**Hint:** We recommend using **alkaline** batteries for longer battery life.


- Replace the battery compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten.
- When sounds or lights from this toy become faint or stop, it's time for an adult to change the batteries!

## Battery Safety Information

Batteries may leak fluids that can cause a chemical burn injury or ruin your toy. To avoid battery leakage:


- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the toy. Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

# Learning Fun for Baby!



- To change modes, slide the mode switch to one of the three positions: learning 😊 ; off ○ or musical fun 🎵 .
  - Set the volume switch on the bottom of the toy to low 🔊 or high 🔊 volume.
- Hint:** If your child is not actively playing with this toy, it turns off automatically (sleep mode).
- When your child is finished playing with this toy, slide the mode switch to the off position ○ .

## Learning Fun




- Slide the mode switch to **Learning Fun** 😊 .
- When a page is turned, your child receives a greeting from the friendly character and is invited to learn about the pictures. Turn the pages to learn about animals, vehicles, nature or foods.
- When your child turn the last page, a surprise bookmark pops up.

**Hint:** To reset the bookmark, turn back the pages, then press the bookmark back into the book.

- When your child moves the toggle, spinner, rollers or slider, the character identifies the nearest picture along with a fun sound effect and flashing lights. **3**

## Music Fun



- Slide the mode switch to **Music Fun** 🎵 .
- When a page is turned, your child receives a greeting from the friendly character and is invited to learn about the pictures. Turn the pages to hear tunes about animals, vehicles, nature or foods.
- When your child turn the last page, a surprise bookmark pops up.

**Hint:** To reset the bookmark, turn back the pages, then press the bookmark back into the book.

- When your child moves the toggle, spinner, rollers or slider, a fun tune plays as lights flash in time to the music. Try again and hear a fun sound effect.

## Care

- Wipe the toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse the toy.

## FCC Note (United States Only)

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

## Consumer Information

### Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-5437**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TTD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For other countries outside the United States:

#### **CANADA**

**Questions? 1-800-567-7724.** Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

#### **GREAT BRITAIN**

Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB, Helpline: 01628 500302.

#### **AUSTRALIA**

Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

#### **NEW ZEALAND**

16-18 William Pickering Drive, Albany 1331, Auckland.

#### **ASIA**

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.