



RadioShack®

www.radioshack.comSM

ET-3504 900 MHz Cordless Phone

with Caller ID/Call Waiting





Owner's Manual
Please read before using this equipment.

Read This Before Installation

Your phone is ETL listed to UL standards and meets all applicable FCC standards.

WARNING: To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICE-ABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.		



This symbol is intended to alert you to the presence of uninsulated dangerous voltage within the product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.



This symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.

Each device that you connect to the phone line draws power from the phone line. We refer to this power draw as the device's ringer equivalence number, or REN. The REN is on the bottom of the base.

If you are using more than one phone or other device on the line, add up all the RENs. If the total is more than five (three in rural areas), your phone might not ring. If ringer operation is impaired, remove a device from the line.

FCC STATEMENT

This telephone complies with Part 68 of *FCC Rules*. You must, upon request, provide the FCC registration number and the REN to your phone company. These numbers are on the bottom of the base.

Note: You must not connect your phone to any of the following:

- coin-operated systems
- party-line systems
- most electronic key phone systems

THE FCC WANTS YOU TO KNOW

In the unlikely event that your phone causes problems on the phone line, the phone company can temporarily discontinue your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this telephone. The telephone company notifies you of these changes in advances, so you can take the necessary steps to prevent interruption of your telephone service.

This equipment complies with the limits for a Class B digital device as specified in Part 15 of *FCC Rules*. These limits provide reasonable protection against radio and TV interference in a residential area. However, your

© 2001 RadioShack Corporation.
All Rights Reserved.

RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

equipment might cause TV or radio interference even when it is operating properly. To eliminate interference, you can try one or more of the following corrective measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the radio or TV.
- Use outlets on different electrical circuits for the equipment and the radio or TV. Consult your local RadioShack store if the problem still exists.

LIGHTNING

Your telephone has built-in lightning protection to reduce the risk of damage from surges in telephone line and power line current. This lightning protection meets or exceeds FCC requirements. However, lightning striking the telephone or power lines can damage your telephone.

Lightning damage is not common. Nevertheless, if you live in an area that has severe electrical storms, we suggest that you unplug your phone when storms approach to reduce the possibility of damage.

IMPORTANT CALLER ID INFORMATION

To use the phone's Caller ID and Call Waiting features, you must be in an area where Caller ID and Call Waiting services are available and you must subscribe to the services.

Where Caller ID is offered, one or more of the following options are generally available:

- caller's number only
- caller's name only
- caller's name and number

For the phone's Caller ID memory dial feature to operate, you must receive the caller's number.

Important: Cordless phones generally require AC power to operate. You should also have a corded phone that does not require AC power to operate so you can still make and receive calls if there is an AC power failure.

Your telephone operates on standard radio frequencies as allocated by the FCC. Even though the access protection code prevents unauthorized use of your phone line, it is possible for other radio units operating on similar frequencies within a certain area to unintentionally intercept your conversations or cause interference. This lack of privacy can occur with any cordless phone.

CARE

Keep the phone dry; if it gets wet, wipe it dry immediately. Use and store the phone only in normal temperature environments. Handle the phone carefully; do not drop it. Keep the phone away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

Modifying or tampering with the phone's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your phone is not performing as it should, take it to your local RadioShack store for assistance. If the trouble is affecting the telephone lines, the phone company can ask you to disconnect your phone until you have resolved the problem.

Contents

Features	5
Installation	6
Mounting the Phone	6
On a Desk	6
On a Wall Plate	6
Directly On a Wall	7
Connecting, Charging, and Replacing the Battery Pack	7
Operation	9
A Quick Look at the Handset	9
Storing Your Area Code	10
Using a Headset	10
Using Page/Find	10
Memory Dialing	10
Storing a Number in Memory	10
Entering a Pause in a Memory Number	11
Dialing a Stored Number	11
Reviewing Stored Numbers	11
Deleting a Stored Number	11
Chain Dialing Service Numbers	12
Testing Stored Emergency Numbers	12
Message Waiting	12
Caller ID Operation	12
Call Waiting	12
Caller ID Messages	12
Reviewing Caller ID Records	13
Dialing a Number from a Caller ID Record	13
Storing a Caller ID Record in Memory	14
Deleting Caller ID Records	14
Troubleshooting	15

□ **Features**

Your RadioShack 900 MHz Cordless Phone offers the latest advances in cordless phone technology. It combines a cordless phone and a Caller ID unit in one system. It saves up to 40 Caller ID records that you can review and call back. Its headset jack lets you connect an optional headset (available at your local RadioShack store) for hands-free convenience. The base's space-saving design makes it perfect for areas where space is limited.

Its other features include:

3-Line LCD Display — lets you view a caller's name and number on one screen.

10-Memory Speed Dial — stores up to 10 frequently called phone numbers for easy dialing.

Call Waiting ID — displays Caller ID information about an incoming call when you are on the phone (if you subscribe to this service from your local phone company).

Message Waiting Indicator — lets you see at a glance that you have messages.

Review Scrolling — lets you scroll through all records in Caller ID memory and stored number memory.

Callback — lets you dial the phone number in a Caller ID record.

Caller ID Memory — stores up to 40 Caller ID records, including the time of the call.

Ample Talk and Standby Time — when fully charged (about 12 hours), the supplied battery pack provides about 7 hours of talk time or 7 days of standby time.

Security Access-Protection Code — prevents other cordless phone users from using

your phone line while the handset is off the base.

10-Channel Auto Scan — automatically selects a clear channel when you make or answer a call.

Volume Control — lets you control the volume of the sound you hear through the handset.

Page — lets you send a paging signal from the base to the handset to help locate a misplaced handset or page someone at the handset.

□ Installation

MOUNTING THE PHONE

You can place the phone on a desk or table, or mount it on a standard wall plate or directly on a wall.

Select a location that is:

- near an easily accessible AC outlet
- near a telephone line jack
- out of the way of normal activities
- away from electrical machinery, electrical appliances, metal walls, filing cabinets, wireless intercoms, security alarms, and room monitors

The base's location affects the phone's range. If you have a choice of several locations, try each to see which provides the best performance.

Your telephone connects directly to a modular telephone line jack. If your telephone wiring does not have a modular jack, you can update the wiring yourself using jacks and adapters (available at your local RadioShack store), or have the telephone company update the wiring for you. You must use compatible modular jacks that are compliant with Part 68 of *FCC Rules*.

Note: The USOC number of the jack to be installed is RJ11C (or RJ11W for a wall plate jack).

On a Desk

Follow these steps to use the supplied bracket (pre-installed into the lower tab slots) as a stand when mounting the base on a desk or table.

1. Press down on the tabs on the top of the bracket and lift the bracket from the clip slots. Remove the bracket completely from the lower tab slots.
2. Rotate the bracket 180°, then insert the bracket's tabs into the upper tab slots and snap into place.
3. Plug the modular cord's other end into a modular phone line jack.
4. Route the adapter and phone cords through the strain relief slot on the bracket if necessary.
5. Plug the adapter into a standard AC outlet.
6. Lift the base's antenna to a vertical position.

On a Wall Plate

1. Route the adapter and phone cords through the strain relief grooves on the bottom of the bracket if necessary.
2. Plug the modular cord into the wall plate jack, then align the bracket's keyhole slots with the wall plate studs and slide the base downward to secure it.
3. Plug the adapter into a standard AC outlet.
4. Press up on the handset holder and slide it out of place. Turn it upside down so its tabbed edge faces up, then slide it back down into its slot.
5. Lift the base's antenna to a vertical position.

Directly On a Wall

For this mounting method, you need two screws (not supplied) with heads that fit into the keyhole slots on the bottom of the base.

1. Drill two holes $3^{15}/_{16}$ inches (100 mm) apart. Then thread a screw into each hole, letting the heads extend about $3/_{16}$ inch (4 mm) from the wall.
2. Route the modular and adapter cords through the grooves on the bottom of the bracket if necessary.
3. Align the keyhole slots with the mounting screws and slide the base downward to secure it.
4. Plug the modular cord into a modular phone line jack.
5. Plug the adapter into a standard AC outlet.
6. Press up on the handset holder and slide it out of place. Turn it upside down so its tabbed edge faces up, then slide it back down into its slot.
7. Lift the base's antenna to a vertical position.

CONNECTING, CHARGING, AND REPLACING THE BATTERY PACK

The phone comes with a rechargeable nickel-cadmium battery pack. You must connect the battery pack and charge it for at least 12 hours before you use the phone for the first time.

1. Slide off the battery compartment cover.
2. Unfasten the retainer strap and lift the battery pack out of the compartment.

3. Plug the battery pack's connector into the socket in the compartment (the connector fits only one way), then replace the battery pack and fasten the retainer strap.
4. Replace the cover.

To charge the battery pack, place the handset either faceup or facedown on the base. The CHARGE/IN USE/MESSAGE indicator lights.

Notes:

- Recharge the battery pack if the handset beeps and LOW BATTERY appears, or if LOW BATTERY appears when the phone is not in use.
- If the phone does not work immediately after charging or recharging the battery pack, return the keypad to the base for about 5 seconds to reset the security access-protection code.
- About once a month, fully discharge the battery pack by keeping the phone off the base until the low battery warning tone sounds. Otherwise, the battery pack loses its ability to fully recharge.
- When the handset is on the base, the CHARGE/IN USE/MESSAGE indicator lights even when the battery pack is not connected. If your phone does not work, be sure the battery pack is properly connected.
- If the CHARGE/IN USE/MESSAGE indicator does not light when you place the handset on the base, be sure the battery pack and AC adapter are correctly and securely connected.
- Check the charging contacts on the handset and base. If the contacts are dirty or tarnished, clean them with a pencil eraser.

- If the battery pack becomes completely discharged or the base loses power while the handset is away from it, place the handset on the base for about 5 seconds to reset the security access protection code. If the handset loses power, leave it on the base to charge the battery pack.
- If you are not going to use your phone for an extended period, disconnect its battery pack. This helps increase the battery pack's life.

The supplied battery pack should last about a year. If the battery pack does not hold a charge for more than 2 hours after overnight charge, replace it with a new 3.6-volt, 600 mAh battery pack with a connector that fits the socket in the battery compartment. You can order a replacement battery pack through your local RadioShack store. Install the new battery pack, place the handset on the base, and charge the battery for 12 hours before using it.

Note: To avoid losing numbers stored in memory, you must install and begin charging the new battery pack within 2 minutes of removing the old one.

Warning: Dispose of the old battery pack promptly and properly. Do not burn or bury it.

Cautions:

- You must use a replacement battery pack of the same size and type.
- Do not dispose of the battery pack in a fire because it might explode.
- Do not open or mutilate the battery pack.
- Be careful not to short the battery pack by touching the connector's pins with conducting materials, such as rings, bracelets, and keys. The battery pack or conductor might overheat and burn.

If you have trouble replacing the battery pack, take the phone to your local RadioShack store for assistance.

Important: The EPA certified RBRC® Battery Recycling Seal on the nickel-cadmium (Ni-Cd) battery indicates RadioShack is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful life, when taken out of service in the United States or Canada. The RBRC program provides a convenient alternative to placing used Ni-Cd batteries into the trash or the municipal waste stream, which may be illegal in your area. Please call 1-800-THE-SHACK (1-800-843-7422) for information on Ni-Cd battery recycling and disposal bans/restrictions in your area. RadioShack's involvement in this program is part of the company's commitment to preserving our environment and conserving our natural resources.



□ Operation

A QUICK LOOK AT THE HANDSET

TALK — To make a call, lift the handset from the base, then press **TALK**. You hear a dial tone and the **CHARGE/IN USE/MESSAGE** indicator lights.

Dial the number you want to call.

To answer a call, lift the handset from the base, then press **TALK**. The **CHARGE/IN USE/MESSAGE** indicator lights.

To end a call, place the handset on the base or press **TALK**.

This phone has a call duration timer that starts counting from 00:00 when you press **TALK** to make or receive a call. The time stops counting when you press **TALK** again to end the call. The call duration display remains for 12 seconds after you end the call.

Notes:


When you press a button, a single tone indicates that the phone has accepted the command. Three tones indicate that you pressed a button in error or there is severe interference. If interference is severe, the handset might lose communication with the base and the call might disconnect. If this happens, return the handset to the base for about 5 seconds to reset the security access-protection code.

CH — Every time you press **TALK**, the phone automatically selects a clear channel it uses for communication between the handset and the base. If you hear interference during a call, repeatedly press **CH** to change the channel until you get a clear one.

REDIAL — To quickly redial the last number dialed, press **TALK** then **REDIAL/CALLBACK**. To redial a busy number, press **REDIAL/CALLBACK** without hanging up the phone. **FLASH** appears and a dial tone sounds for about 2 seconds, then the number automatically redials.

Notes:

The redial memory holds up to 32 digits, so you can redial long-distance as well as local numbers.



VOL/CID ▲/▼ — To adjust the handset's volume level, repeatedly press **VOL/CID** ▲ or ▼ during a call. The volume level remains set after you hang up. There are four volume levels. **Note:** The handset sounds 3 beeps when you reach the lowest or highest listening level.

FLASH/DELETE — provides the electronic equivalent of a switchhook signal for special phone services such as Call Waiting. For example, if you have Call Waiting, press **FLASH/DELETE** to answer an incoming call without disconnecting the current call. Press **FLASH/DELETE** again to return to the first call. **Note:** If you do not have any special phone services, pressing **FLASH/DELETE** might disconnect your current call.

RINGER — To have the phone ring when a call comes in, set **RINGER** to **ON**. To turn the ringer off, set **RINGER** to **OFF**.

With **RINGER** set to **OFF**, the phone does not ring, but you can still make outgoing calls. If you hear an extension telephone ring, you can answer the incoming call on this phone. The **CHARGE/IN USE/MESSAGE** indicator flashes and the display backlight lights until you answer the call.

STORING YOUR AREA CODE

To dial a number from a Caller ID record (see “Dialing a Number from a Caller ID Record” on Page 13), you must first store your local area code in the phone’s memory. Then, when you dial from a Caller ID record, the system skips the area code if it matches the one you stored. Follow these steps to store your area code.

1. Make sure the CHARGE/IN USE/MES- SAGE indicator is not lit.
2. Hold down **FUNC** for 2 seconds. **AREA CODE= ---** appears.
3. Enter your three-digit area code. The handset sounds two long beeps. The area code is stored.

To replace a stored area code, store a new one in its place.

USING A HEADSET

You can make or answer calls with hands-free convenience using an optional headset with a $\frac{3}{32}$ -inch (2.5 mm) plug. Contact your local RadioShack store for a suitable headset. To connect the headset, insert the headset plug into the jack on the top of the headset.

USING PAGE/FIND

To send a page to the handset to locate it when it is away from the base and not in use, press **PAGE** on the base. **PAGING** appears and the handset rings for about 15 seconds.

To locate the handset, hold down **PAGE**. The handset rings for about 1 minute. Press any key on the handset or **PAGE** on the base to silence it sooner.

MEMORY DIALING

You can store up to 10 numbers of 24 digits each in the phone’s memory.

Notes:

- To keep your accounts secure, we recommend you do not store your personal access code for services such as bank-by-phone in a memory location.
- When storing numbers for special services (such as alternate long-distance or bank-by-phone), store the service’s main phone number in one memory location and numbers for additional information in other locations.

Storing a Number in Memory

1. Press **MEM** on the handset.
2. Press the memory location number (1–0) where you want to store a number.

Note: To enter a number into the 10th memory location, press **0**.

3. Press **MEM** again. **ENTER NAME** appears.
4. If you have name-only or name-and-number Caller ID, enter the name (up to 15 characters) using this table:

# of Presses	1	2	3	4	5	6	7	8	9
1		A	D	G	J	M	P	T	W
2	–	B	E	H	K	N	Q	U	X
3	*	C	F	I	L	O	R	V	Y
4	!	()	\$	'	;	S	?	Z

Notes:

- If you make a mistake, press **FLASH/DELETE** to delete a letter.

- Press **1** to enter a space between names.
 - If you are using two consecutive letters that reside in the same number key, press **FUNC** between the letters. For example, for "Tammy Smith," enter **8 2 6 FUNC 6 999 1 7777 6 444 8 44**.
5. Press **MEM** again. **ENTER TEL NUMBER** appears.
 6. Dial the desired number (up to 24 digits).
 7. Press **MEM** again to store the number. The handset sounds two long beeps.

Note: If you hear three short beeps, you did not store the number successfully. Start again from Step 1.
 8. Write down the stored name and number on the memory index sticker provided.

Notes:

- If the low battery warning tone sounds, recharge or replace the battery within two minutes, or the numbers stored in memory will be lost.
- If you receive a call while you are storing a number in memory, press **TALK** to answer the call. After the call, begin at Step 1 to store a number.
- To change a number stored in memory, simply store a new number in that memory location.

Entering a Pause in a Memory Number

In some telephone systems, you must dial an access code (9, for example) and wait for a

second dial tone before you can dial an outside number. You can store the access code with the phone number. However, if you do, you should also store a pause after the access code to allow the outside line time to connect. After entering the access code, press **REDIAL** to enter a 2-second pause.

Dialing a Stored Number

Press **TALK**. When you hear the dial tone, press **MEM** then the memory location number (**1-0**). The memory location number appears and the phone dials the number.

To pre-dial a stored number, press **MEM** then **VOL/CID ▲** or **▼** to find the desired number, then press **REDIAL/CALL BACK**.

Reviewing Stored Numbers

Press **MEM**. Enter the desired memory location number (**1, 2, 3,** and so on), or press **VOL/CID ▲** or **▼** to scroll through the memory locations.

Deleting a Stored Number

1. Make sure the **CHARGE/IN USE/MESSAGE** indicator is not lit.
2. Press **MEM** then enter the memory location number of the number to be deleted, press **VOL/CID ▲** or **▼** to select the memory location.
3. Press **FLASH/DELETE. ERASE MEMO?** appears.
4. Press **FLASH/DELETE** again to clear the memory. Two long beeps sound to confirm the number is deleted.

Or, press any other button to cancel the deletion. Three short beeps sound.

Chain Dialing Service Numbers

For quick recall of numbers for special services (such as alternate long distance or bank by phone), store each group of numbers in its own memory location.

When calling special services, dial the service's main number first. Then, at the appropriate place in the call, press **MEM**, then the number for the location where the additional numbers are stored.

Testing Stored Emergency Numbers

If you store an emergency service's number (police department, fire department, ambulance) and you want to test the stored number, make the test call during the late evening or early morning to avoid peak demand periods. Remain on the line to explain the reason for your call.

Message Waiting

If you subscribe to a message waiting service with your local telephone company, the CHARGE/IN USE/MESSAGE indicator flashes and **MESSAGE WAITING** appears for about six seconds when you have a new message waiting. The indicator continues to flash until you listen to all of your messages.

CALLER ID OPERATION

If you subscribe to Caller ID service from your phone company, the system automatically displays information about calls you receive and stores the information in Caller ID memory. The system can store up to 40 number records (the most recent is 40), then replaces the oldest call with each new one.

The first line of the Caller ID record shows the calling time, date and the number of calls. The second line shows the caller's phone number. The third line shows the call-

er's name, if available (See "Caller ID Messages").

Note: The CHARGE/IN USE/MESSAGE indicator flashes during an incoming call, and **NEW CALL #** appears. The latest Caller ID record appears when the phone rings, then **NEW CALLS #** or **REPT** remains on the display after the last incoming call.

Call Waiting

If you subscribe to Call Waiting and a call comes in while you are on the phone, you hear a tone that indicates you have another call. The system displays the Caller ID/Call Waiting information for about 10 seconds, then stores the information.

To answer the incoming call, press **FLASH/DELETE**. To resume the previous phone conversation, press **FLASH/DELETE** again.

Caller ID Messages

Display	Description
NEW CALL #	Indicates the number of new calls. Note: NEW does not appear after you review the display information.
NEW= XX TOTAL= XX	Indicates the total numbers of all calls and new calls. XX is the number of calls.
PRIVATE	The caller chose not to send Caller ID information.
OUT OF AREA	The caller is not within a Caller ID service area.
REPT	You have received a call from the same phone number more than once.

Display	Description
NO DATA	Caller's information was distorted before reaching the system.
MSG WAITING OFF	All new messages have been reviewed.
LONG DISTANCE	Your phone company sends information indicating that the incoming call is long distance.
CALL FORWARD	The call was forwarded from a number set to forward all calls. The display toggles between the caller's name and CALL FORWARD .
CALL FWD BUSY	The call was forwarded from a number set to forward a call if the line is busy. The display toggles between the caller's name and CALL FWD BUSY .
END OF LIST	You have reached the last call.
MESSAGE WAITING	A message is waiting. (You must subscribe to your phone company's message waiting service.)
ERROR	The Caller ID information was garbled.

Reviewing Caller ID Records

Each time you receive a call, your system stores a Caller ID record that you can review later, even during a call. Each record includes:

- call number
- time and date of the call
- caller's telephone number (if available)

- caller's name (if available)

Follow these steps to review Caller ID records.

1. Make sure the CHARGE/IN USE/MESSAGE indicator is not lit.
2. Repeatedly press **VOL/CID ▲** to review from **CALL # 01** forward, or **VOL/CID ▼** to review records from the most recent call back.
3. To review the last number dialed, press **REDIAL/CALLBACK**.

Notes:

- The handset display shows the first 15 characters of the caller's name and the last 15 digits of the phone number.
- Empty Caller ID memory locations do not appear.
- When the list is full, the oldest caller's information is replaced by the newest one.

Dialing a Number from a Caller ID Record

Note: The system cannot dial a number if the Caller ID record consists of a name only.

1. Make sure the CHARGE/IN USE/MESSAGE indicator is not lit.
2. Press **VOL/CID ▲** or **▼** to find the desired number.
3. Press **FUNC** to dial the long distance prefix (1) plus the area code and local number. For example, if the area code is 604 and the local number is 555-1212, the phone dials 1-604-555-1212.

Press **FUNC** twice to dial the local phone number (555-1212).

Press **FUNC** three times to dial the long distance prefix and local number (1-555-1212).

Press **FUNC** four times to dial the area code and local number (604-555-1212).

4. Press **REDIAL/CALL BACK**. The system dials the caller's phone number.

Storing a Caller ID Record in Memory

1. Make sure the **CHARGE/IN USE/MESSAGE** indicator is not lit.
2. Press **CID/VOL ▲** or **▼** to find the desired caller ID record. The caller ID memory shows the phone number with area code.
3. Press **FUNC** to store the number as specified in Step 3 of "Dialing a Number from a Caller ID Record."
4. Press **MEM** once. **SELECT MEMO 0-9?** appears.
5. Enter the memory location number. The handset sounds two long beeps.

Notes:

- If the handset sounds three short beeps, the caller's number is not stored. Start again from Step 1.
- You cannot store a Caller ID record without the caller's number or name in the phone's memory.

Deleting Caller ID Records

1. Make sure the **CHARGE/IN USE/MESSAGE** indicator is not lit.
2. To delete a single record, repeatedly press **VOL/CID ▲** or **▼** to find the

desired number, then press **FLASH/DELETE**. **ERASE CALL ID?** appears.

To delete all records, hold down **FLASH/DELETE** for 3 seconds. **ERASE ALL?** appears.

3. Press **FLASH/DELETE** again to confirm the deletion. The handset sounds two long beeps and the selected number is deleted.

Or, press any button other than **FLASH/DELETE** to cancel the deletion. The handset sound three short beeps.

Troubleshooting

We do not expect you have any problems with your telephone, but if you do, the following suggestions might help.

Problem	Suggestion
The handset does not work.	Move the handset closer to the base.
	Raise the base's antenna to a vertical position.
	Ensure the phone's modular cord and the AC adapter are correctly and securely connected.
	Recharge the handset's battery pack.
	Return the handset to the base for about 5 seconds to reset the security access-protection code.
Call is noisy.	Keep the handset and the base away from interference sources such as computers, remote control toys, wireless alarm systems, wireless intercoms and room monitors, fluorescent lights, and electrical appliances.
	If the interference is severe, turn off the interfering device.
	Move the handset closer to the base.
	Hang up and redial the number.
	Press CH to change the channel.
The range decreases.	Ensure the base's antenna is raised and is not touching a metal surface.
	Recharge the handset's battery pack.
The handset battery pack does not charge.	Check the charging contacts on the handset and base. If they are dirty, clean them with a pencil eraser.
	Be sure the battery pack is connected correctly.
	Be sure the handset is properly seated on the base.
	Replace the battery pack (see "Connecting, Charging, and Replacing the Battery Pack" on Page 7).
You have an incoming call, but do not receive any Caller ID information.	Check that the phone is correctly and securely connected.
	Check with your phone company to verify that your Caller ID service is active.

If you still have problems, disconnect the phone. If other phones on the same line work properly, the fault is in this phone or its installation. If you cannot locate the problem, take your phone to your local RadioShack store for assistance.

Limited One-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for one (1) year from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99

RadioShack Corporation
Fort Worth, Texas 76102

43-3504 **A**
086-002147-017
08A01
Printed in China