

# VSE 002

## RS-485 module

Publication version: VVSE2/EN M/B006

## User manual



**Table of Contents**

<b>1. General .....</b>	<b>3</b>
<b>2. Power supply .....</b>	<b>3</b>
<b>3. Module interface to the VAMP relays or master device .....</b>	<b>3</b>
<b>4. RS-485 interface .....</b>	<b>4</b>
<b>5. Module layout .....</b>	<b>5</b>
<b>6. Module mounting .....</b>	<b>5</b>
<b>7. Module connection to a PC .....</b>	<b>6</b>
<b>8. Ordering codes.....</b>	<b>6</b>

# 1. General

External RS-485 Module VSE 002 is used to connect VAMP protection relays to a RS-485 bus.

Additionally this module can be used with any device, which has a RS-232 or TTL serial interface, when an RS-485 interface is required.

# 2. Power supply

The power for the module is taken from pin 9 of the D-connector or from an external power supply interface. There is a screw terminal (X1, see figure 1) for connecting an external +9...12Vdc power supply.

# 3. Module interface to the VAMP relays or master device

The physical interface to the device is a 9-pin D-connector. The signal levels may be either TTL or RS-232.

**The TTL/RS-232 interface of the modules is:**

Pin number	TTL mode	RS-232 mode
1	-	-
2	RXD (in)	RXD (in)
3	TXD (out)	TXD (out)
4	RTS (in)	RTS (in)
5		
6		
7	GND	GND
8		
9	+8V (in)	+8V (in)


## NOTICE

The active state of the RTS signal is positive voltage (> +3V) in both TTL and RS-232 modes.

## 4.

# RS-485 interface

The RS-485 interface supports 2-wire connection. The dip switch S1 is used to switch the termination and signal biasing resistors on or off.







Termination	
ON	OFF
	
Interface type	
TTL	RS-232
	

Figure 1. Dipswitch positions of VSE 002

The direction control of the RS-485 transceiver is done with the RTS signal or automatically. The automatic direction control turns the transceiver to transmit mode after detecting the falling edge of a 0-bit. The direction is kept in transmit mode for 0,5ms. This enables the use of the automatic mode with 9,6 kb/s and 19,2 kb/s speeds. When the transceiver is changed to receive mode, the RS-485 line changes state to logic 1 state due to the biasing resistors.

## 5. Module layout




Figure 2. Component layout

## 6. Module mounting




Figure 3. Mounting picture of module

## 7.

# Module connection to a PC

The module can be used with a PC, the required cable is described in figure 4. When used with a PC an external power supply is needed (e.g. type Phoenix Contact 100 – 240 AC/10-15 DC/2, Order-No. 29 83 75 6).

PC serial interface		VSE 002	
Function	Pin number	Pin number	Function
CD (in)	1	1	-
RXD (in)	2	2	RXD (in)
TXD (out)	3	3	TXD (out)
DTR (out)	4	4	RTS (in)
GND	5	5	-
DSR (in)	6	6	-
RTS (out)	7	7	GND
CTS (in)	8	8	-
-	9	9	+8V (in)

Figure 4. PC interface cable

## 8.

# Ordering codes

**VSE 002**    RS-485interfacemodule





## **Customers Care Center**

<http://www.schneider-electric.com/ccc>

### **Schneider Electric**

35 rue Joseph Monier  
92506 Rueil-Malmaison  
FRANCE

Phone: +33 (0) 1 41 29 70 00  
Fax: +33 (0) 1 41 29 71 00

[www.schneider-electric.com](http://www.schneider-electric.com)

**Publication version: VVSE2/EN M/B006**

Publishing: Schneider Electric  
02/2013