

INSTALLER: THESE INSTRUCTIONS MUST BE CONVEYED TO AND REMAIN WITH THE HOMEOWNER.



INSTALLATION AND OPERATION INSTRUCTIONS


CERTIFIED UNDER CANADIAN AND AMERICAN NATIONAL STANDARDS: ANSI Z21.88, CSA 2.33 FOR VENTED GAS FIREPLACE HEATERS.

**If the information in these
instructions is not followed exactly,
a fire or explosion may result
causing property damage, personal
injury or death.**

The Bayfield™

GDS25N
NATURAL GAS

GDS25P
PROPANE



W415-0547 / B / 05.08.06

Wolf Steel Ltd., 24 Napoleon Rd., Barrie, ON, L4M 4Y8, Canada
(705)721-1212 • fax(705)722-6031 • www.napoleonfireplaces.com • ask@napoleon.on.ca

WARNINGS & SAFETY PRECAUTIONS



Do not store gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.



Installation and service must be performed by a qualified installer, service agency or the gas supplier. Follow the installation directions.


WHAT TO DO IF YOU SMELL GAS



Do not try to light any appliance.



Do not use any phone in your building. Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.



Do not touch any electrical switch.



If you cannot reach your gas supplier, call the fire department.



If this fireplace is not properly installed, a house fire may result.

TABLE of CONTENTS

- | | |
|--|---|
| <p>2. Warnings and Safety Precautions What to do if you smell gas</p> <p>4. Warranty</p> <p>5. General Instructions General Information Care of Glass and Plated Parts</p> <p>6. Location and Clearances Stove Dimensions Clearances to Combustibles Mantel or Shelf Clearances</p> <p>7. Blower Installation</p> <p>8. Terminal Installation</p> <p>9. Venting Venting Lengths and Air Terminal Locations</p> <p>10. Typical and Special Vent Installations</p> <p>11. Venting Termination</p> <p>16. Wall and Ceiling Protection</p> <p>17. Horizontal and Vertical Venting</p> <p>18. Stove Vent Connection Mobile Home Installation Restricting Vertical Vents Gas Installation</p> | <p>19. Finishing Glass door install and removal Cast Front Installation and removal</p> <p>20. Logo Placement Log Placement</p> <p>21. Optional Switch / Wiring Diagram</p> <p>22. Lighting / Operation Instructions</p> <p>23. Adjustments Maintenance Pilot Injector Replacement Venturi Adjustment Orifice Replacement</p> <p>24. Replacements Replacement Parts Accessories</p> <p>26. Trouble Shooting</p> <p>28. Service History</p> |
|--|---|

PLEASE RETAIN THIS MANUAL FOR FUTURE REFERENCE

WARNING

- The stove is a vented gas-fired heater. Do not burn wood or other materials in this stove.
- Adults and especially children should be alerted to the hazards of high surface temperatures and should stay away to avoid burns or clothing ignition. Keep young children and animals away when the stove is hot.
- Due to high temperatures, the stove should be located out of traffic and away from furniture and draperies.
- Clothing or other flammable material should not be placed on or near the stove.
- Any safety screen or guard removed for servicing must be replaced prior to operating the stove.
- It is imperative that the control compartments, burners and circulating blower and its passageway in the stove and venting system are kept clean. The stove and its venting system should be inspected before use and at least annually by a qualified service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etc. The stove area must be kept clear and free from combustible materials, gasoline and other flammable vapours and liquids.
- Under no circumstances should this stove be modified.
- This stove must not be connected to a chimney flue pipe serving a separate solid fuel burning appliance.
- Do not use this stove if any part has been under water. Immediately call a qualified service technician to inspect the stove and to replace any part of the control system and any gas control which has been under water.
- Do not operate the stove with the glass door opened, cracked or broken. Replacement of the glass should be done by a licensed or qualified service person.
- Do not strike or slam shut the stove glass door.

NOTE: changes, other than editorial, are denoted by a vertical line in the margin.

*NAPOLEON products are manufactured under the strict Standard of the world recognized
ISO 9001 : 2000 Quality Assurance Certificate.*

NAPOLEON products are designed with superior components and materials, assembled by trained craftsmen who take great pride in their work. The burner and valve assembly are leak and test-fired at a quality test station. The complete fireplace is test-fired and thoroughly inspected by a qualified technician before packaging to ensure that you, the customer, receives the quality product that you expect from NAPOLEON.

NAPOLEON GAS FIREPLACE PRESIDENT'S LIFETIME LIMITED WARRANTY

The following materials and workmanship in your new NAPOLEON gas fireplace are warranted against defects for as long as you own the fireplace. This covers: combustion chamber, heat exchanger, stainless steel burner, phazer™ logs and embers, ceramic glass (thermal breakage only), gold plated parts against tarnishing, porcelainized enamelled components and aluminium extrusion trims.

Electrical (110V and millivolt) components and wearable parts such as catalytic tiles, blowers, gas valves, thermal switch, switches, wiring, remote controls, ignitor, gasketing, and pilot assembly are covered and NAPOLEON will provide replacement parts free of charge during the first year of the limited warranty. Light bulbs are not covered by this warranty.

Labour related to warranty repair is covered free of charge during the first year. Repair work however, requires the prior approval of an authorized company official. Labour costs to the account of NAPOLEON are based on a predetermined rate schedule and any repair work must be done through an authorized NAPOLEON dealer.

CONDITIONS AND LIMITATIONS

NAPOLEON warrants its products against manufacturing defects to the original purchaser only -- i.e., the individual or legal entity (registered customer) whose name appears on the warranty registration card filed with NAPOLEON -- provided that the purchase was made through an authorized NAPOLEON dealer and is subject to the following conditions and limitations:

This factory warranty is nontransferable and may not be extended whatsoever by any of our representatives.

The gas fireplace must be installed by a licenced, authorized service technician or contractor. Installation must be done in accordance with the installation instructions included with the product and all local and national building and fire codes.

This limited warranty does not cover damages caused by misuse, lack of maintenance, accident, alterations, abuse or neglect and parts installed from other manufacturers will nullify this warranty.

This limited warranty further does not cover any scratches, dents, corrosion or discolouring caused by excessive heat, abrasive and chemical cleaners nor chipping on porcelain enamel parts, mechanical breakage of PHAZER™ logs and embers, nor any venting components used in the installation of the fireplace.

NAPOLEON warrants its stainless steel burners against defects in workmanship and material for life, subject to the following conditions: During the first 10 years NAPOLEON will replace or repair the defective parts at our option free of charge. From 10 years to life, NAPOLEON will provide replacement burners at 50% of the current retail price.

In the first year only, this warranty extends to the repair or replacement of warranted parts which are defective in material or workmanship provided that the product has been operated in accordance with the operation instructions and under normal conditions.

After the first year, with respect to this President's Limited Lifetime Warranty, NAPOLEON may, at its discretion, fully discharge all obligations with respect to this warranty by refunding to the original warranted purchaser the wholesale price of any warranted but defective part(s).

After the first year, NAPOLEON will not be responsible for installation, labour or any other costs or expenses related to the reinstallation of a warranted part, and such expenses are not covered by this warranty.

Notwithstanding any provisions contained in this President's Limited Lifetime Warranty, NAPOLEON'S responsibility under this warranty is defined as above and it shall not in any event extend to any incidental, consequential or indirect damages.

This warranty defines the obligations and liability of NAPOLEON with respect to the NAPOLEON gas fireplace and any other warranties expressed or implied with respect to this product, its components or accessories are excluded.

NAPOLEON neither assumes, nor authorizes any third party to assume, on its behalf, any other liabilities with respect to the sale of this product. NAPOLEON will not be responsible for: over-firing, downdrafts, spillage caused by environmental conditions such as rooftops, buildings, nearby trees, hills, mountains, inadequate vents or ventilation, excessive venting configurations, insufficient makeup air, or negative air pressures which may or may not be caused by mechanical systems such as exhaust fans, furnaces, clothes dryers, etc.

Any damages to fireplace, combustion chamber, heat exchanger, brass trim or other component due to water, weather damage, long periods of dampness, condensation, damaging chemicals or cleaners will not be the responsibility of NAPOLEON.

The bill of sale or copy will be required together with a serial number and a model number when making any warranty claims from your authorized dealer. The warranty registration card must be returned within fourteen days to register the warranty.

NAPOLEON reserves the right to have its representative inspect any product or part thereof prior to honouring any warranty claim.

GENERAL INSTRUCTIONS

THIS GAS STOVE SHOULD BE INSTALLED AND SERVICED BY A QUALIFIED INSTALLER to conform with local codes. Installation practices vary from region to region and it is important to know the specifics that apply to your area, for example: in Massachusetts State:

- The fireplace damper must be removed or welded in the open position prior to installation of a fireplace insert or gas log.
- The appliance off valve must be a "T" handle gas cock.
- The flexible connector must not be longer than 36 inches.
- The appliance is not approved for installation in a bedroom or bathroom unless the unit is a direct vent sealed combustion product.
- **WARNING:** This product must be installed by a licensed plumber or gas fitter when installed within the commonwealth of Massachusetts.

In absence of local codes, install to the current CAN1-B149 Installation Code in Canada or to the National Fuel Gas Code, ANSI Z223.1, and NFPA 54 in the United States. Mobile home installation must conform with local codes. In the absence of local codes, install to the current standard for gas equipped mobile housing CAN/CSA Z240 MH Series in Canada or the manufactured home construction and safety standard, Title 24 CFR, part 3280, or the Fire Safety Criteria for manufactured home installations, Sites and Community Standard ANSI/NFPA 501A in the United States.

Purge all gas lines with the glass door of the stove removed. Assume that a continuous gas flow is at the burner before re-installing the door.

Under extreme vent configurations, allow several minutes (5-15) for the flame to stabilize after ignition.

It is recommended that all horizontal runs have a ¼ inch rise per foot.

Objects placed in front of the stove must be kept a minimum of 48" away from the front face of the unit.

The stove and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa). The stove must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½ psig (3.5 kPa).

The stove, when installed with a blower, must be electrically connected and grounded in accordance with local codes. In the absence of local codes, use the current CSA C22.1 CANADIAN ELECTRICAL CODE in Canada or the ANSI/NFPA 70 NATIONAL ELECTRICAL CODE in the United States.

GENERAL INFORMATION

The blower power cord must be connected into a properly grounded receptacle. The grounding prong must not be removed from the cord plug.

FOR YOUR SATISFACTION, THIS STOVE HAS BEEN TEST-FIRED TO ASSURE ITS OPERATION AND QUALITY!

Minimum inlet gas supply pressure is 4.5 inches water column for natural gas and 11 inches water column for propane. Maximum inlet gas pressure is 7 inches water column for natural gas and 13 inches water column for propane. When the valve is set to "HI", the manifold pressure under flow conditions is 3.5 inches water column for natural gas and 10 inches water column for propane. When the fireplace is installed at elevations above 4,500ft, and in the absence of specific recommendations from the local authority having jurisdiction, the certified high altitude input rating shall be reduced at the rate of 4% for each additional 1,000ft.

Expansion / contraction noises during heating up and cooling down cycles are normal and to be expected.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

CARE OF GLASS, AND PLATED PARTS

Do not use abrasive cleaners to clean these parts. Buff lightly with a clean dry cloth.

The glass is 3/16" ceramic glass available from your Napoleon / Wolf Steel Ltd. dealer. **DO NOT SUBSTITUTE MATERIALS.** Clean the glass after the first 10 hours of operation with a recommended gas fireplace glass cleaner. Thereafter clean as required. **DO NOT CLEAN GLASS WHEN HOT!** If the glass is not kept clean permanent discolouration and / or blemishes may result.

GDS25: Maximum input is 24,500 BTU/hr for natural gas. Maximum output for natural gas is 19,600 BTU/hr at an efficiency of 80%. Maximum input is 23,000 BTU/hr for propane. Maximum output for propane gas is 18,400 BTU/hr at an efficiency of 80%.

This stove is approved for closet or recessed installations, as well as for bathroom, bedroom and bed-sitting room installations and is suitable for mobile home installations. The natural gas model can be installed in a mobile home that is permanently positioned on its site and fueled with natural gas.



We suggest that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Gas Specialists.

LOCATION & CLEARANCES

Provide adequate accessibility clearance for servicing and operating the stove.


Never obstruct the front opening of the stove.

*AT A DISTANCE OF 2" FROM THE WALL, INSTALLATION OR SERVICE TO THE BLOWER MAY NOT BE PRACTICAL. A MINIMUM OF 5" WILL BE REQUIRED IN ORDER TO INSTALL THE BLOWER.


As long as clearance to combustibles is kept within the required distances, the most desirable and beneficial location for a Napoleon stove is in the centre of a building, thereby allowing the most efficient use of the heat created. The location of windows, doors and the traffic flow in the room where the stove is to be located should be considered. If possible, you should choose a location where the vent will pass through the house without cutting a floor or roof joist.

STOVE DIMENSIONS

FIGURE 1



MAINTAIN THESE MINIMUM CLEARANCES TO COMBUSTIBLES:



A. 4" B. 2"* C. 2" FIGURE 2

STOVE SHOULD NOT BE INSTALLED DIRECTLY ON CARPETING.
MINIMUM 48" FROM STOVE TOP TO CEILING

TO CEILING FROM STOVE TOP.....48"

HORIZONTAL VENT

SIDES AND BOTTOM1"

TOP.....2"


VERTICAL VENT

ALL SIDES.....1"

*AT A DISTANCE OF 2" FROM THE WALL, INSTALLATION OR SERVICE TO THE BLOWER MAY NOT BE PRACTICAL. A MINIMUM OF 5" WILL BE REQUIRED IN ORDER TO INSTALL THE BLOWER.

If less than 5" clearance is maintained between the back of the stove and the back wall, it will be necessary to disconnect the venting and gas pipe to move the stove out for installation or service of the blower.

MANTEL OR SHELF CLEARANCES:





When the fireplace is rear vented, a mantel or shelf may be installed above the GDS25 at a minimum distance of 8".

BLOWER INSTALLATION

Blower (SEE LOCATION AND CLEARANCES)


1. Cut and remove the tie securing the blower switch wires to the heat shield.
2. Connect the white wire coming from below the unit to the terminal on the blower.
3. Connect the black blower wire to the black wire coming from below the unit.
4. Insert the clips on the blower housing into the cutouts in the rear shield. Push down to lock the clips into position.
5. Secure the blower using the screw and lock washer supplied.

Note: Ensure that all the wires are tucked into the blower switch housing.



Switches

6. Open the switch housing by removing the top screw.
 7. Install the thermodisc bracket as shown, using 2 of the screws supplied. Connect the flagged leads to the terminals of the thermodisc.
- Remove the knock out from the housing label.
8. Install the variable speed switch (rheostat) into the housing with the wires facing up. Secure the switch to the housing using the pal nut and the knob supplied.
 9. Connect the male connector on the switch to the female connector coming from the unit.
 10. Tuck all of the wires into the housing and close. Secure using the screw removed in step 6.



ACCENT LITE REPLACEMENT


Your Bayfield comes equipped with our "Accent Lite". If in the event the lamp or lens needs to be replaced, follow these instructions.

Disconnect the two wire leads at the wire nut. Remove the four screws securing the accent lite assembly from the relief door. Disassemble the lite and the lamp now can be accessed

Note: Do not handle the lamp (bulb) with bare fingers, protect with a clean dry cloth.

The lamp will pull straight out of the socket. Replace with Wolf Steel parts only, as lamp and lens are special "high temperature" products.

When re-installing, ensure integrity of gasket seal.




THE FIREBOX MUST BE SEALED.

When re-assembling the light assembly, care must be taken with all gaskets.

"Light Leakage" from above the cast doors may be noticed. The holes in the lamp housing are necessary for ventilation and must not be covered.

W415-0547 / B / 05.08.06

AIR TERMINAL LOCATIONS



| INSTALLATIONS | | | |
|---------------|-------------|---------------|--|
| | CANADIAN | U.S.A. | |
| A | 12 INCHES | 12 INCHES | Clearance above grade, veranda porch, deck or balcony. |
| B | 12 INCHES | 9 INCHES | Clearance to windows or doors that open. |
| C | 12 INCHES* | 12 INCHES* | Clearance to permanently closed windows. |
| D | 18 INCHES** | 18 INCHES** | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet from the centerline of the terminal. |
| E | 12 INCHES** | 12 INCHES** | Clearance to unventilated soffit. |
| F | 0 INCHES | 0 INCHES | Clearance to an outside corner wall. |
| G | 0 INCHES*** | 0 INCHES*** | Clearance to an inside non -combustible corner wall or protruding non -combustible obstructions (chimney, etc.). |
| | 2 INCHES*** | 2 INCHES*** | Clearance to an inside combustible corner wall or protruding combustible obstructions (vent chase, etc.). |
| H | 3 FEET | 3 FEET**** | Clearance to each side of the centerline extended above the meter / regulator assembly to a maximum vertical distance of 15ft. |
| I | 3 FEET | 3 FEET**** | Clearance to a service regulator vent outlet. |
| J | 12 INCHES | 9 INCHES | Clearance to a non-mechanical air supply inlet to the building or a combustion air inlet to any other appliance. |
| K | 6 FEET | 3 FEET† | Clearance to a mechanical air supply inlet. |
| L | 7 FEET‡ | 7 FEET**** | Clearance above a paved sidewalk or paved driveway located on public property unless fitted with a heat shield kit GD-301. |
| M | 12 INCHES†† | 12 INCHES**** | Clearance under a veranda, porch, deck or balcony. |
| N | 16 INCHES | 16 INCHES | Clearance above the roof. |
| O | 2 FEET†* | 2 FEET†* | Clearance from an adjacent wall including neighbouring buildings. |

* Recommended to prevent condensation on windows and thermal breakage

** It is recommended to use a heat shield and to maximize the distance to vinyl clad soffits.

*** The periscope GD-201 requires a minimum 18 inches clearance from an inside corner.

**** This is a recommended distance. For additional requirements check local codes.

† Three feet above if within 10 feet horizontally.

‡ A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.

†† Permitted only if the veranda, porch, or deck is fully open on a minimum of two sides beneath the floor.

†* Recommended to prevent recirculation of exhaust products. For additional requirements check local codes.

VENTING

VENTING LENGTHS & AIR TERMINAL LOCATIONS

Use only Wolf Steel, Simpson Dura-Vent, Selkirk Direct Temp or American Metal Amerivent venting components.

For Simpson Dura-Vent, Selkirk Direct Temp and American Metal Amerivent, follow the installation procedure provided with the venting components.

All outer pipe joints of these venting systems must be sealed using Red RTV High Temperature Sealant.

Wolf Steel, Simpson Dura-Vent, Selkirk Direct Temp and American Metal Amerivent venting systems must not be combined.

A starter adaptor must be used and may be purchased from the corresponding supplier:


| PART | SUPPLIER |
|-----------------------|----------------|
| Duravent - GDS924N | Wolf Steel |
| Amerivent - 4DSCB-N1 | American Metal |
| Direct Temp - 4DT-AAN | Selkirk |

For vent systems that provide seals on the inner exhaust flue, only the outer air intake joints must be sealed using a red high temperature silicone (RTV). This same sealant may be used on both the inner exhaust and outer intake vent pipe joints of all other approved vent systems except for the exhaust vent pipe connection to the fireplace flue collar which must be sealed using the black high temperature sealant Mill Pac. High temperature sealant must be ordered separately.

When using Wolf Steel venting components, use only the following vent kits: **WALL TERMINAL KIT GD175** (7-1/2' of venting included), **WALL TERMINAL KIT GD176** (24" of venting included), or **1/12 TO 7/12 PITCH ROOF TERMINAL KIT GD110**, **8/12 TO 12/12 ROOF TERMINAL KIT GD111**, **FLAT ROOF TERMINAL KIT GD112** or **STOVE PERISCOPE KIT GD180** (for wall penetration below grade) in conjunction with the appropriate venting components.

For optimum performance, it is recommended that all horizontal runs have a minimum 1/4 inch rise per foot.

- These vent kits allow for either horizontal or vertical venting of the stove.
- The maximum number of 4" flexible connections is 3 horizontally or three vertically (excluding the stove and the air terminal connections).
- When terminating vertically, the minimum vertical rise is 3 feet above the stove and the maximum vertical rise is 40 feet. **FIGURE 4.**




Deviation from the minimum vertical vent length can create difficulty in burner start-up and/or carboning.


Use an adjustable pipe as the final length of rigid piping to the stove for ease of installation.

- For optimum flame appearance and stove performance, keep the vent length and number of elbows to a minimum.
- The air terminal must remain unobstructed at all times. Examine the air terminal at least once a year to verify that it is unobstructed and undamaged.

The maximum horizontal run with a 57 inch vertical rise immediately above the stove is 20 feet. **FIGURES 6a-b.**



TYPICAL CORNER INSTALL WITH ZERO RISE




TYPICAL VENT INSTALLATIONS

NOTE:

When terminating vertically above 15', the restrictor plate must be in the fully closed position. Refer to Restricting Vertical Vents.

FIGURES 3 a-c



SPECIAL VENT INSTALLATIONS

PERISCOPE TERMINATION

Use the GD201 periscope kit to locate the air termination above grade. The periscope must be installed so that when final grading is completed, the bottom air slot is located a minimum of 12 inches above grade. The maximum allowable vent length depends on the fireplace, as illustrated.




FIGURE 4

DEFINITIONS

for the following symbols used in the venting calculations and examples are:

> - greater than

≥ - equal to or greater than

< - less than

≤ - equal to or less than

H_T - total of both horizontal vent lengths (H_R) and offsets (H_O) in feet

H_R - combined horizontal vent lengths in feet

H_O - offset factor: $.03(\text{total degrees of offset} - 135^\circ)$ in feet

V_T - combined vertical vent lengths in feet

ELBOW VENT LENGTH VALUES

| | feet | inches |
|------|------|--------|
| 1° | 0.03 | 0.5 |
| 15° | 0.45 | 6.0 |
| 30° | 0.9 | 11.0 |
| 45°* | 1.35 | 16.0 |
| 90°* | 2.7 | 32.0 |

* the first 45° and 90° offset has a zero value and is shown in the formula as **-45°** and **-90°** respectively or **-135°** when combined.

HORIZONTAL TERMINATION

when $(H_T) \leq (V_T)$




FIGURE 5

Simple venting configuration (only one 45° and 90° elbow)

For vent configurations requiring more than one 45° and 90° elbow, the following formulas apply:

Formula 1: $H_T \leq V_T$

Formula 2: $H_T + V_T \leq 40$ feet

Example 1:





FIGURE 6



REQUIRED
VERTICAL
RISE IN
FEET (V_T)

CALCULATED HORIZONTAL VENT RUN
PLUS OFFSETS IN FEET (H_T)

The shaded area within the lines represents acceptable values for H_T and V_T .

$$\begin{aligned}
 V_1 &= 8 \text{ ft} \\
 V_T &= V_1 = 8 \text{ ft} \\
 H_1 &= 2.5 \text{ ft} \\
 H_2 &= 2 \text{ ft} \\
 H_R &= H_1 + H_2 = 2.5 + 2 = 4.5 \text{ ft} \\
 H_O &= .03(\text{one } 45^\circ \text{ elbow} + \text{two } 90^\circ \text{ elbows} - 135^\circ) \\
 &= 0.3(225 - 135^\circ) = 2.7 \text{ ft} \\
 H_T &= H_R + H_O = 4.5 + 2.7 = 7.2 \text{ ft}
 \end{aligned}$$

$$H_T + V_T = 7.2 + 8 = 15.2 \text{ ft}$$

$$\text{Formula 1: } H_T \leq V_T$$

$$7.2 \leq 8$$

$$\text{Formula 2: } H_T + V_T \leq 40 \text{ feet}$$

$$15.2 \leq 40$$


Since both formulas are met, this vent configuration is acceptable.

HORIZONTAL TERMINATION


when $(H_T) > (V_T)$

Simple venting configuration (only one 45° and 90° elbow)

See graph to determine the required vertical rise V_T for the required horizontal run H_T .



REQUIRED VERTICAL RISE IN INCHES (V_T)



HORIZONTAL VENT RUN PLUS OFFSETS IN FEET

The shaded area within the lines represents acceptable values for H_T and V_T .


For vent configurations requiring more than one 45° and 90° elbow the following formulas apply:

Formula 1: $H_T \leq 4.2 V_T$

Formula 2: $H_T + V_T \leq 24.75$ feet

Example 2:

FIGURE 8



$$V_1 = 4 \text{ ft}$$

$$V_2 = 1.5 \text{ ft}$$

$$V_T = V_1 + V_2 = 4 \text{ ft} + 1.5 \text{ ft} = 5.5 \text{ ft}$$

$$H_1 = 2 \text{ ft}$$

$$H_2 = 1 \text{ ft}$$

$$H_3 = 1 \text{ ft}$$

$$H_4 = 1.5 \text{ ft}$$

$$H_R = H_1 + H_2 + H_3 + H_4 = 2 + 1 + 1 + 1.5 = 5.5 \text{ ft}$$

$$H_O = .03(\text{one } 45^\circ \text{ elbow} + \text{three } 90^\circ \text{ elbow} - 135^\circ) = .03(315 - 135) = 5.4 \text{ ft}$$

$$H_T = H_R + H_O = 5.5 + 5.4 = 10.9 \text{ ft}$$

$$H_T + V_T = 10.9 + 5.5 = 16.4 \text{ ft}$$

$$\text{Formula 1: } H_T \leq 4.2 V_T$$

$$4.2 V_T = 4.2 \times 5.5 = 23.1 \text{ ft}$$

$$10.9 \leq 16.8$$

$$\text{Formula 2: } H_T + V_T \leq 24.75 \text{ feet}$$

$$16.4 \leq 24.75$$

Since both formulas are met, this vent configuration is acceptable.


VERTICAL TERMINATION

when $(H_T) \leq (V_T)$

See graph to determine the required vertical rise V_T for the

$$\begin{aligned} V_2 &= 10 \text{ ft} \\ V_T &= V_1 + V_2 = 5 + 10 = 15 \text{ ft} \end{aligned}$$


FIGURE 9




required horizontal run H_T .

For vent configurations requiring more than one 45° and one

FIGURE 10



**REQUIRED VERTICAL RISE
IN FEET (V_T)**



$$\begin{aligned} H_1 &= 3 \text{ ft} \\ H_2 &= 2.5 \text{ ft} \\ H_R &= H_1 + H_2 = 3 + 2.5 = 5.5 \text{ ft} \\ H_O &= .03(\text{one } 45^\circ \text{ elbow} + \text{three } 90^\circ \text{ elbows} - 135^\circ) \\ &= .03(45+90+90+90-135)=5.4 \\ H_T &= H_R + H_O = 5.5 + 5.4 = 10.9 \text{ ft} \\ H_T + V_T &= 10.9 + 15 = 25.9 \text{ ft} \end{aligned}$$

Formula 1: $H_T \leq V_T$
 $10.9 \leq 15$

Formula 2: $H_T + V_T \leq 40 \text{ feet}$
 $25.9 \leq 40$

Since both formulas are met, this vent configuration is acceptable.

**HORIZONTAL VENT RUN
PLUS OFFSETS IN FEET**

The shaded area within the lines represents acceptable values for H_T and V_T

90° elbow, the following formulas apply:

Formula 1: $H_T \leq V_T$

Formula 2: $H_T + V_T \leq 40 \text{ feet}$

Example 3:

$V_1 = 5 \text{ ft}$


VERTICAL TERMINATION

when $(H_T) > (V_T)$

Simple venting configurations

See graph to determine the required vertical rise V_T for the


FIGURE 11



required horizontal run H_T .

For vent configurations requiring more than one 45° and one 90° elbow, the following formulas apply:

**REQUIRED
VERTICAL
RISE IN
FEET (V_T)**



HORIZONTAL VENT RUN PLUS OFFSET IN FEET

The shaded area within the lines represents acceptable values for H_T and V_T .


Formula 1: $H_T \leq 3V_T$

Formula 2: $H_T + V_T \leq 40$ feet

Example 4:

$V_1 = 1$ ft

FIGURE 12



$V_2 = 1.5$ ft
 $V_T = V_1 + V_2 = 1 + 1.5 = 2.5$ ft
 $H_1 = 6$ ft
 $H_2 = 2$ ft
 $H_R = H_1 + H_2 = 6 + 2 = 8$ ft
 $H_O = .03(\text{one } 45^\circ \text{ elbow} + \text{three } 90^\circ \text{ elbow} - 135^\circ)$
 $= .03(45 + 90 + 90 + 90 - 135) = 5.4$ ft
 $H_T = H_R + H_O = 8 + 5.4 = 13.4$ ft
 $H_T + V_T = 13.4 + 2.5 = 15.9$ ft

Formula 1: $H_T \leq 3V_T$
 $3V_T = 3 \times 2.5 = 7.5$
 $13.4 > 7.5$

Since this formula is not met, this vent configuration is **unacceptable**.

Formula 2: $H_T + V_T \leq 40$ feet
 $15.9 \leq 40$

Since only formula 2 is met, this vent configuration is unacceptable and a new fireplace location or vent configuration will need to be established to satisfy both formulas.

Example 5:




FIGURE 13

$V_1 = 1.5$ ft
 $V_2 = 8$ ft
 $V_T = V_1 + V_2 = 1.5 + 8 = 9.5$ ft
 $H_1 = 1$ ft
 $H_2 = 1$ ft
 $H_3 = 10.75$ ft
 $H_R = H_1 + H_2 + H_3 = 1 + 1 + 10.75 = 12.75$ ft
 $H_O = .03(\text{three } 90^\circ \text{ elbows} + \text{two } 45^\circ \text{ elbow} - 135^\circ)$
 $= .03(90 + 90 + 90 + 45 + 45 - 135) = 6.75$ ft
 $H_T = H_R + H_O = 12.75 + 6.75 = 19.5$ ft
 $H_T + V_T = 19.5 + 4.5 = 29$ ft

Formula 1: $H_T \leq 3V_T$
 $3V_T = 3 \times 9.5 = 28.5$
 $19.5 \leq 28.5$

Formula 2: $H_T + V_T \leq 40$ feet
 $29 \leq 40$

Since both formulas are met, this vent configuration is acceptable.

VERTICAL THROUGH EXISTING CHIMNEY


INSTALLATION

This appliance is designed to be attached to a 3" co-linear aluminum flex vent system running the full length of a masonry chimney.

The flexliner accommodates any contours of a masonry chimney, however, it is necessary to keep the flexible liner as straight as possible. The inlet air collar of the termination cap must be connected to the air intake pipe.


Use Simpson DuraVent Chimney Liner Termination Kit - 923GK (Baseplate and Co-Linear to Co-Axial Adaptor). Follow manufacturers (Simpson Dura-Vent) installation instructions.

When installing the unit to this system, DuraVent vent components must be used. You must start with a DuraVent adaptor, GDS924N, directly off the unit. The GDS924N is only available at your Napoleon dealer.



WALL AND CEILING PROTECTION

FIGURE 16



HORIZONTAL INSTALLATION

This application occurs when venting through an exterior wall. Having determined the air terminal location, cut and frame a hole in an exterior wall with a minimum rectangle opening of 10" x 9".

IMPORTANT: FOR OPTIMUM PERFORMANCE, THE STOVE PIPE SHOULD RISE ¼" PER FOOT OF RUN.

1. Assemble the shield to the spacer as shown, using the 3 shorter screws supplied.


The shield is meant to protect combustible materials within the wall. If the shield is deeper than the combustible portion of the wall, cut to fit.

2. Apply a bead of caulking all around and place the firestop spacer over the framework to restrict cold air from being drawn into the room or around the stove. Ensure that both spacer and shield maintain the required clearance to combustibles. Secure the spacer in place using the 4 longer screws supplied. Once the vent pipe is installed in its final position, apply sealant between the pipe and the firestop spacer.

VERTICAL INSTALLATION


This application occurs when venting through a roof.

Installation kits for various roof pitches are available from your Napoleon dealer. See Accessories to order the specific kit required.



1. Determine the air terminal location and move the stove into position. Cut and frame 9" x 10" openings in the ceiling and the roof to provide the minimum 1 inch clearance between the stove pipe and any combustible material. Try to center the exhaust pipe location midway between two joist to prevent having to cut them. Use a plumb bob to line up the center of the openings.


DO NOT FILL THIS SPACE WITH ANY TYPE OF MATERIAL.



A vent pipe shield will prevent any materials such as insulation, from filling up the 1" air space around the pipe. Nail headers between the joist for extra support.

2. Apply a bead of caulking (not supplied) to the framework or to the Wolf Steel vent pipe shield plate or equivalent (in the case of a finished ceiling), and secure over the opening in the ceiling. A firestop must be placed on the bottom of each framed opening in a roof or ceiling that the venting system passes through. Apply a bead of caulking all around and place a firestop spacer over the vent shield to restrict cold air from being drawn into the room or around the stove. Ensure that both spacer and shield maintain the required clearance to combustibles. Once the vent pipe is installed in its final position, apply sealant between the pipe and the firestop spacer.

3. In the attic, after the pipe has been installed, slide the vent pipe collar down to cover up the open end of the shield and tighten. This will prevent any materials, such as insulation, from filling up the 1" air space around the pipe.



HORIZONTAL VENTING INSTALLATION

FOR SAFE AND PROPER OPERATION OF THE STOVE, FOLLOW THE VENTING INSTRUCTIONS EXACTLY.

ALL HORIZONTAL VENT RUNS MAY HAVE A 0" RISE PER FOOT.

FOR OPTIMUM PERFORMANCE IT IS RECOMMENDED THAT ALL HORIZONTAL RUNS HAVE A MINIMUM 1/4 INCH RISE PER FOOT.

ALL INNER EXHAUST AND OUTER INTAKE VENT PIPE JOINTS MAY BE SEALED USING EITHER RED RTV HIGH TEMP SILICONE SEALANT OR BLACK HIGH TEMP MILL PAC WITH THE EXCEPTION OF THE FIREPLACE EXHAUST FLUE COLLAR WHICH MUST BE SEALED USING MILL PAC (NOT SUPPLIED).

1. Stretch the 4" diameter aluminium flexible liner to the required length taking into account the additional length needed for the finished wall surface.

Spacers are attached to the 4" inner flex liner at predetermined intervals to maintain a 1-1/4" air gap to the 7" outer stove pipe. These spacers must not be removed.


Slip a 4" diameter length of aluminium flexible liner a minimum of 2" over the inner sleeve of the air terminal. Secure to the sleeve using 3 screws. Seal the joint and screw heads using the high temperature sealant.

2. Slip the first section of 7" diameter stove pipe a minimum of 2" over the outer sleeve of the air terminal. Secure to the sleeve using 3 screws. Seal the joint and screw heads using high temperature sealant.

3. Insert the liners through the firestop / vent pipe shield. Holding the air terminal (lettering in an upright, readable position), secure to the exterior wall. Make weather tight by sealing with caulking (not supplied). The air terminal mounting plate may be recessed (up to 1 1/2" maximum) into the exterior wall or siding.

4. If more than one length of liner needs to be used to reach the stove, couple them together as illustrated in **FIGURE 21**. Seal the joints using the same procedure as described above.

The vent system must be supported approximately every 10 feet along a horizontal run. Use supports or equivalent non-combustible strapping to maintain the 1" clearance from combustibles.



VERTICAL VENTING INSTALLATION

1. Fasten the roof support to the roof using the screws provided. The roof support is optional. In this case the venting is to be adequately supported using either an alternate method suitable to the authority having jurisdiction or the optional roof support.

2. Stretch the inner aluminum flex liner to the required length. Slip the liner a minimum of 2" over the inner sleeve of the air terminal connector and secure with 3 #8 screws. Seal using a heavy bead of the high temperature sealant.



3. Repeat using the outer aluminum flex liner.

4. Thread the air terminal connector / liner assembly down through the roof. The air terminal must be located vertically and plumb. Attach the air terminal connector to the roof support, ensuring that the top of the air terminal is 16" above the highest point that it penetrates the roof.


5. Remove nails from the shingles, above and to the sides of the chimney. Place the flashing over the air terminal connector leaving a min. 3/4" of the air terminal connector showing above the top of the flashing. Slide the flashing underneath the sides and upper edge of the shingles. Ensure that the air terminal connector is properly centred within the flashing, giving a 3/4" margin all around. Fasten to the roof. Do not nail through the lower portion of the flashing. Make weather-tight by sealing with caulking. Where possible, cover the sides and top edges of the flashing with roofing material.

6. Aligning the seams of the terminal and air terminal connector, place the terminal over the air terminal connector making sure the liner goes into the hole in the terminal. Secure with the three screws provided.

7. Apply a heavy bead of weatherproof caulking 2 inches above the flashing. Note: Maintain a minimum 2" space between the air inlet base and the storm collar. Install the storm collar around the air terminal and slide down to the caulking. Tighten to ensure that a weather-tight seal between the air terminal and the collar is achieved.



DO NOT CLAMP THE FLEXIBLE ALUMINIUM LINER.




Spacers are attached to the inner flex liner at predetermined intervals to maintain a 1-1/4" air gap to the outer flex liner. These spacers must not be removed.

STOVE VENT CONNECTION

1. Attach the adjustable pipe to the last section of rigid piping. Secure with screws and seal.

2. Install the 4" aluminium flexible liner to the stove. Secure with 3 screws and flat washers. Seal the joint and screw holes using high temperature sealant.

3. Run a bead of high temperature sealant Mill Pac around the inside of the air intake collar. Pull the adjustable pipe a minimum 2" into the air intake collar.



ENSURE THAT THE SEALANT IS NOT VISIBLE ON THE EXTERIOR PIPES ONCE INSTALLATION IS COMPLETED. AN OPTIONAL DECORATIVE BRASS BAND IS AVAILABLE FOR THIS USE. (STANDARD WITH A GD175 KIT AND GD-176). IN THE EVENT THAT THE VENTING MUST BE DISASSEMBLED, CARE MUST BE TAKEN TO RESEAL THE VENTING.


MOBILE HOME INSTALLATION

In Canada, mobile home installation may be vented horizontally or vertically. In the United States, it may only be installed vertically. See "Vertical Venting" or "Horizontal Air Terminal Installation" for installation.


For mobile home installations, the fireplace must be fastened in place. It is recommended that the fireplace be secured in all installations. Use the levelling/securing kit, GDSLL-KT for this purpose.

RESTRICTING VERTICAL VENTS

FIGURE 27




Vertical installations may display a very active flame. Loosen the two screws and slide the restrictor plate blocking the exhaust path. This reduces the velocity of the exhaust gases, slowing down the flame pattern and creating a more traditional flame appearance. For vertical vents greater than 15 feet, this restrictor must be fully closed.



GAS INSTALLATION

1. Install rigid black pipe, or 1/2" type L copper tubing with a shut-off valve to the stove.

2. Seal and tighten the gas line securely to a flex connector.



DO NOT KINK FLEXIBLE CONNECTOR.

3. Check for gas leaks by brushing on a soap and water solution. **DO NOT USE OPEN FLAME.**

FINISHING

GLASS DOOR INSTALLATION AND REMOVAL

1. Lift the top cast piece off of the unit.
2. Detach the front cast piece from the side pieces by removing the screws from the brackets located in the upper inside corners.
3. Slide the front straight up to remove.




FIGURE 30

CAST FRONT INSTALLATION AND REMOVAL

1. Lift the top cast piece off of the unit.
2. Unlatch the door latches from the door.
3. Slide the door straight up to remove.





FIGURE 31

SWITCH FUNCTIONS




Follow the above steps in reverse in order to reinstall the door. Ensure that the bottom of the door meets the door retainer before closing the latches.

Follow the above steps in reverse in order to reinstall the cast front. Ensure that the tabs on the underside of the front fit behind the front legs.


Note: It is not necessary to remove the cast front, in order to remove the door.

FIGURE 32



LOGO PLACEMENT

Remove the backing from the the logo and position onto the control door as shown.



LOG PLACEMENT

It is not necessary to remove the cast front, however, this will make for a more simple log installation.

In order to assemble the log set, the door must be removed, see **Cast Front / Glass Door Removal** in the **FINISHING** section of this manual.

FIGURE 33a-d



2. Place the hole in the underside of log #2 onto the locating screw, on the left side of the burner. The fibre burner is formed to cradle the centre of the log.



1. Place the rear log, as shown, onto the rear log support brackets. Ensure the cutout on the left underside of the log, fits over the pilot assembly. Bend the bracket on the right side to help retain the rear log.



3. Place the hole in the underside of log #3 onto the locating screw, on the right side of the burner. The bottom branch of log #3 sits in front of, and against, the right end of log #2.

4. Reinstall the glass door & front.


OPTIONAL SWITCH / WIRING DIAGRAM

The on/off switch is located on the back of the GDS25 at the top right corner. For ease of accessibility, an optional remote wall switch or millivolt thermostat may be installed in a convenient location. The recommended maximum lead length depends on wire size:

| WIRE SIZE | MAX. LENGTH |
|-----------|-------------|
| 14 gauge | 100 feet |
| 16 gauge | 60 feet |
| 18 gauge | 40 feet |

Route 2-strand (solid core) wire through the electrical hole located at the bottom left side of the unit. Connect the wires from the wall switch / thermostat to the two brown wires extending from the fireplace mounted ignition control box.

Purge all gas lines with the glass door of the fireplace open.
Assure that a continuous gas flow is at the burner before closing the door.





Purge all gas lines with the glass door removed. Assure that a continuous gas flow is at the burner before reinstalling the door.


FOR YOUR SAFETY READ BEFORE OPERATING

WARNING: IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.


- | | |
|--|---|
| <p>A. THIS FIREPLACE IS EQUIPPED WITH AN IGNITION DEVICE WHICH AUTOMATICALLY LIGHTS THE PILOT. DO NOT TRY TO LIGHT BY HAND.</p> <p>B. BEFORE OPERATING SMELL ALL AROUND THE FIREPLACE AREA FOR GAS AND NEXT TO THE FLOOR BECAUSE SOME GAS IS HEAVIER THAN AIR AND WILL SETTLE ON THE FLOOR.</p> <p>C. USE ONLY YOUR HAND TO TURN THE GAS CONTROL KNOB. NEVER USE TOOLS. IF THE KNOB WILL NOT TURN BY HAND, DO NOT TRY TO REPAIR IT. CALL A QUALIFIED SERVICE TECHNICIAN. FORCE OR ATTEMPTED REPAIR MAY RESULT IN A FIRE OR EXPLOSION.</p> <p>D. DO NOT USE THIS FIREPLACE IF ANY PART HAS BEEN UNDER WATER. IMMEDIATELY CALL A QUALIFIED SERVICE TECHNICIAN TO INSPECT THE FIREPLACE AND</p> | <p>REPLACE ANY PART OF THE CONTROL SYSTEM AND ANY GAS CONTROL WHICH HAS BEEN UNDER WATER.</p> <p>WHAT TO DO IF YOU SMELL GAS:</p> <ul style="list-style-type: none"> • TURN OFF ALL GAS TO THE FIREPLACE. • OPEN WINDOWS. • DO NOT TRY TO LIGHT ANY APPLIANCE. • DO NOT TOUCH ANY ELECTRIC SWITCH; DO NOT USE ANY PHONE IN YOUR BUILDING. • IMMEDIATELY CALL YOUR GAS SUPPLIER FROM A NEIGHBOUR'S PHONE FOLLOW THE GAS SUPPLIER'S INSTRUCTIONS. • IF YOU CANNOT REACH YOUR GAS SUPPLIER, CALL THE FIRE DEPARTMENT. |
|--|---|

OPERATING INSTRUCTIONS

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. STOP! READ THE ABOVE SAFETY INFORMATION ON THIS LABEL. 2. TURN REMOTE WALL SWITCH TO OFF POSITION. 3. TURN OFF ALL ELECTRIC POWER TO THE FIREPLACE AND REMOVE BATTERIES. 4. THIS FIREPLACE IS EQUIPPED WITH AN IGNITION DEVICE WHICH AUTOMATICALLY LIGHTS THE PILOT. DO NOT TRY TO LIGHT THE PILOT BY HAND. 5. TURN MANUAL SHUTOFF VALVE CLOCKWISE  TO OFF. 6. OPEN THE GLASS DOOR. 7. WAIT FIVE (5) MINUTES TO CLEAR OUT ANY GAS. IF YOU SMELL GAS INCLUDING NEAR THE FLOOR, STOP! | <p>FOLLOW "B" IN THE ABOVE SAFETY INFORMATION ON THIS LABEL. IF YOU DON'T SMELL GAS GO TO THE NEXT STEP.</p> <ol style="list-style-type: none"> 8. CLOSE THE GLASS DOOR. 9. TURN MANUAL SHUTOFF VALVE COUNTER-CLOCKWISE  TO ON. 10. TURN ON ALL ELECTRIC POWER TO THE FIREPLACE AND RE-INSTALL BATTERIES. 11. TURN ON REMOTE WALL SWITCH TO ON POSITION. 12. IF FIREPLACE WILL NOT OPERATE, FOLLOW INSTRUCTIONS "TO TURN OFF GAS" AND CALL YOUR SERVICE TECHNICIAN OR GAS SUPPLIER. |
|---|--|



TO TURN OFF GAS

1. TURN OFF REMOTE WALL SWITCH TO THE FIREPLACE.
2. TURN OFF ALL ELECTRICAL POWER TO THE FIREPLACE IF SERVICE IS TO BE PERFORMED.
3. TURN MANUAL SHUTOFF VALVE CLOCKWISE  TO OFF. DO NOT FORCE.

MAINTENANCE

TURN OFF THE GAS AND UNPLUG ELECTRICAL POWER BEFORE SERVICING THE STOVE!

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing. This stove and its venting system should be inspected before use and at least annually by a qualified service person. The fireplace area must be kept clear and free of combustible materials, gasoline or other flammable vapours and liquids. The flow of combustion and ventilation air must not be obstructed.

1. In order to properly clean the burner and pilot assembly, remove the logs exposing both assemblies.
2. Keep the control compartment, logs, burner, air shutter opening and the area surrounding the logs clean by vacuum-

ing or brushing, at least once a year.

3. Check to see that all burner ports are burning. Clean out any of the ports which may not be burning or are not burning properly.

4. Check to see that the pilot flames are large enough to engulf the thermocouple and the thermopile on one leg and reaches toward the burner on the other leg.

5. Replace the cleaned logs.

6. Check to see that the main burner ignites completely on all openings when the gas knob for the burner is turned on. A 5-10 second total light-up period is satisfactory. If ignition takes longer, consult your Napoleon dealer/distributor.

7. Check that the door gasketing is not broken or missing.

ADJUSTMENTS

PILOT INJECTOR AND ORIFICE REPLACEMENT

1. Turn off the electrical and gas supply to the fireplace.

2. Remove the cast front, glass viewing door and log set.

3. Remove the 2 securing screws. Slide the burner assembly to the right and lift out.

4. Using a deep $\frac{9}{16}$ " socket wrench, remove the main burner orifice. A $\frac{7}{8}$ " back-up wrench must be used on the manifold, located below the housing to ensure that the aluminum tubing does not twist or kink. Replace the correct burner orifice using pipe thread compound.

5. Loosen nut and replace with appropriate injector

6. Reinstall the burner ensuring that the Venturi tube fits over the orifice.




FIGURE 37




FIGURE 35

NOTE: Check and adjust, if necessary, the primary air to $\frac{7}{16}$ " for propane and $\frac{1}{4}$ " for natural gas. Replace the screws.

7. Turn on the gas supply and check for gas leaks by brushing on a soap and water solution.

Do not use open flame.

8. Replace the log set. Then light the pilot and main burner to ensure that the gas lines have been purged.

9. Replace the glass viewing door and cast front. Turn on the electrical supply to the fireplace.

Purge all gas lines with the glass door removed. Assure that a continuous flow is at the burner before re-installing the door.

This must be carried out by an AUTHORIZED REPRESENTATIVE OF WOLF STEEL LTD. or a QUALIFIED GAS INSTALLER in accordance with local codes or in the absence of local codes with the requirements of the provincial / state authorities having jurisdiction and in accordance with the requirements of the CAN1-B149 Installation Code in Canada and the ANSI Z223.1 National Fuel Gas Code in the United States.

VENTURI ADJUSTMENT

Remove the 2 screws securing the burner. Natural gas models have air shutters set to 0.25" open ($\frac{1}{4}$ "). Propane models have air shutters set to 0.438" open ($\frac{7}{16}$ ").

After making adjustments replace the burner ensuring that the venturi tube fits over the orifice and replace the screws.




FIGURE 36

Air shutter adjustment must only be done by a qualified gas installer!

Closing the air shutter will cause a more yellow flame, but can lead to carboning. The flame may not appear yellow immediately; allow 15 to 30 minutes for the final flame colour to be established.

REPLACEMENTS

Contact your dealer for questions concerning prices and availability of replacement parts. Normally all parts can be ordered through your Napoleon dealer or distributor. When ordering replacement parts always give the following information:

FOR WARRANTY REPLACEMENT PARTS, A PHOTOCOPY OF THE ORIGINAL INVOICE WILL BE REQUIRED TO HONOUR THE CLAIM.

REPLACEMENT PARTS

| # | PART # | DESCRIPTION |
|-----|-------------|---------------------------------|
| 1 | W135-0248 | LOG #1- REAR |
| 2 | W135-0249 | LOG #2 - LEFT |
| 3 | W135-0250 | LOG #3 - RIGHT |
| 4 | GL-651 | LOG SET |
| 5 | W725-0032 | DEXEN VALVE - NG |
| 5 | W725-0049 | DEXEN VALVE - LP |
| 6 | W100-0084 | BURNER (NATURAL GAS) |
| 6 | W100-0086 | BURNER (PROPANE) |
| 7 | W455-0017 | #42 BURNER ORIFICE - NG |
| 7 | W455-0003 | #54 BURNER ORIFICE - LP |
| 7 | W455-0001 | #44 BURNER ORIFICE - NG-HA |
| 7 | W455-0050 | #55 BURNER ORIFICE - LP-HA |
| 8 | W455-0049 | PILOT INJECTOR - LP |
| 9 | W455-0071 | PILOT INJECTOR - NG |
| 10 | W720-0092 | PILOT TUBE |
| 11 | W100-0069 | PILOT ASSEMBLY - NG |
| 11 | W100-0093 | PILOT ASSEMBLY - LP |
| 12* | W385-0245 | NAPOLION LOGO |
| 13* | W660-0009 | ON/OFF SWITCH |
| 14* | W387-0006 | HALOGEN BULB 10W T320 |
| 15* | W290-0108 | TOP LENS GASKET |
| 16* | W290-0109 | BOTTOM LENS GASKET |
| 17* | N402-0001 | HIGH TEMPERATURE LIGHT ASSEMBLY |
| 18* | W690-0002 | THERMIDISC |
| 16 | KB-35 | VARIABLE SPEED SWITCH |
| 17* | GZ552 | REPLACEMENT BLOWER |
| 18 | W135-0256** | FRONT CAST |
| 19 | W135-0232** | SIDE (LEFT OR RIGHT) CAST |
| 20 | W135-0257** | TOP CAST |
| 21 | W225-0258** | DOOR RIGHT CAST |
| 21 | W225-0259** | DOOR LEFT CAST |
| 22 | W010-1446 | GLASS w/ GASKET |
| 23 | W430-0013 | CONTROL DOOR MAGNET |
| 24 | W010-1408 | CONTROL COVER |
| 25 | W010-1313 | FIRESTOP SPACER |
| 26 | W585-0198 | FIRESTOP SPACER SHIELD |

TERMINAL KITS

| | | |
|-----|-----------|---|
| 27* | GD175 | - WALL TERMINAL KIT |
| 28 | BM6790 | 90° ELBOW - 7" DIAMETER |
| 29 | GD222 | TERMINAL ASSEMBLY |
| 30 | BM67ADJ | 30" TO 53" ADJUSTABLE PIPE - 7" DIA |
| 31 | W500-0077 | FIRESTOP / WALL PLATE |
| 32* | W020-0032 | HARDWARE |
| 33 | BRTC7 | BRASS TRIM COLLAR |
| 34 | BM6724 | 24" STOVE PIPE - 7" DIAMETER |
| 35 | W010-0300 | 10' ALUMINIUM FLEX LINER C/W SPACERS - 4" DIA |
| 36 | W025-0001 | DECORATIVE BRASS BAND |
| 37* | GD180 | - PERISCOPE TERMINAL KIT |
| 28 | BM6790 | 90° ELBOW - 7" DIAMETER |
| 38* | GD201 | PERISCOPE |
| 30 | BM67ADJ | 30" TO 53" ADJUSTABLE PIPE - 7" DIA |
| 31 | W500-0077 | FIRESTOP / WALL PLATE |
| 32* | W020-0032 | HARDWARE |
| 33 | BRTC7 | BRASS TRIM COLLAR |
| 34 | BM6724 | 24" STOVE PIPE - 7" DIAMETER |
| 35 | W010-0300 | 10' ALUMINIUM FLEX LINER C/W SPACERS - 4" DIA |
| 39* | GD176 | - WALL TERMINAL KIT |
| 29 | GD222 | TERMINAL ASSEMBLY |
| 33 | BRTC7 | BRASS TRIM COLLAR |
| 34 | BM6724 | 24" STOVE PIPE - 7" DIAMETER |
| 36 | W025-0001 | DECORATIVE BRASS BAND |
| 40 | BM6745 | 45° ELBOW |
| 41* | W410-0027 | 2 PLY FLEX ALUMINIUM LINER - 4" x 32.5" |

1. MODEL & SERIAL NUMBER OF FIREPLACE
2. INSTALLATION DATE OF FIREPLACE
3. PART NUMBER
4. DESCRIPTION OF PART
5. FINISH

* IDENTIFIES ITEMS WHICH ARE NOT ILLUSTRATED. FOR FURTHER INFORMATION, CONTACT YOUR

NAPOLION DEALER.

ROOF TERMINAL KITS

| | |
|-------|------------------------------------|
| GD110 | - 1/12 TO 7/12 PITCH |
| 42 | W670-0006 AIR TERMINAL |
| 43 | W490-0073 4/7 INNER / OUTER SLEEVE |
| 44 | W010-0567 ROOF SUPPORT |
| 45 | W170-0063 STORM COLLAR |
| 46 | W263-0054 ROOF FLASHING |
| GD111 | - 8/12 TO 12/12 PITCH |
| 42 | W670-0006 AIR TERMINAL |
| 43 | W490-0073 4/7 INNER / OUTER SLEEVE |
| 44 | W010-0567 ROOF SUPPORT |
| 45 | W170-0063 STORM COLLAR |
| 46 | W263-0055 ROOF FLASHING |
| GD112 | - FLAT ROOF |
| 42 | W670-0006 AIR TERMINAL |
| 43 | W490-0073 4/7 INNER / OUTER SLEEVE |
| 44 | W010-0567 ROOF SUPPORT |
| 45 | W170-0063 STORM COLLAR |
| 46 | W263-0056 ROOF FLASHING |


ACCESSORIES

| | | |
|-----|------------|-----------------------------------|
| 47* | W690-0001 | MILLIVOLT THERMOSTAT |
| 48* | W690-0011B | REMOTE CONTROL - ADVANTAGE PLUS |
| 49 | GS-65KT | BLOWER KIT |
| 50* | GDSLL-KT | LEG LEVELLING KIT |
| 51* | W175-0244 | CONVERSION KIT - NG 2,000-4,500 |
| 51* | W175-0245 | CONVERSION KIT - LP 2,000-4,500 |
| 52* | W175-0246 | CONVERSION KIT - NG-LP 0-2,000 |
| 52* | W175-0247 | CONVERSION KIT - LP-NG 0-2,000 |
| 40 | BM6745 | 45° ELBOW |
| 53 | GD-301 | HEAT GUARD |
| 54* | W175-0001 | 4" COUPLER |
| 38* | GD201 | PERISCOPE |
| 36 | W025-0001 | DECORATIVE BRASS BAND |
| 55* | GS331S | STOVE TOP INSET - SOAPSTONE |
| 55* | GS-331F | STOVE TOP INSET - GRANITE - GREEN |
| 55* | GS-331N | STOVE TOP INSET - GRANITE - BROWN |

GDS25 UNIT COLOURS

**FOR OTHER AVAILABLE COLOURS, ADD THESE LETTERS TO THE BASE PART NUMBER:


| COLOR | | FINISH |
|----------------|-----|-----------|
| SUMMER MOSS | -M | PORCELAIN |
| MAJOLICA BROWN | -N | PORCELAIN |
| WINTER FROST | -W | PORCELAIN |
| WROUGHT IRON | -WI | PAINTED |



*** WARNING:** This is a fast acting thermocouple. It is an integral safety component. Replace only with a fast acting thermocouple supplied by Wolf Steel Ltd.

TROUBLE SHOOTING GUIDE

BEFORE ATTEMPTING TO TROUBLESHOOT, PURGE YOUR UNIT AND INITIALLY LIGHT THE PILOT AND THE MAIN BURNER WITH THE GLASS DOOR REMOVED.

| SYMPTOM | PROBLEM | TEST SOLUTION |
|---|---|---|
| Pilot will not light. Makes noise with no spark at pilot burner  | - Wiring | Verify the "S" wire for the sensor and the "I" wire for the ignitor are connected to the correct terminals (not reverse) on the module and pilot assembly. |
| | - Loose connection | Verify no loose connections, electrical shorts in the wiring or ground out to any metal object. |
| | - Module | Turn the ON/OFF switch to the "OFF" position. Remove the igniter wire "I" from the module. Place the ON/OFF switch to the "ON" position. Hold a grounded wire about 3/16" away from the "I" terminal on the module. If no spark the "I" terminal module must be replaced. If there is a spark the "I" terminal is fine. Inspect pilot assembly for a shorted wire or cracked insulator around the electrode. |
| | - Igniter Spark gap is incorrect | - spark gap of the ignitor to the pilot should be .17" tor 1/8" |
| | - Out of propane gas. | - fill the tank. |
| Pilot will not light. Makes no noise with no spark at pilot burner | - Transformer | Verify the transformer is installed and plugged into the module. Check voltage of the transformer under load at the spade connections on the module with the ON/OFF switch in the "ON" position. Acceptable readings of a good transformer are between 3.2 and 2.8 volts A.C. |
| | - A shorted or loose Connection | Remove and reinstall the wiring harness that plugs into the module. Remove and verify continuity of each wire in wiring harness. |
| | - Improper switch wiring | Troubleshoot the system with the simplest ON/OFF switch |
| | - Module is not grounded | Verify the value and pilot assemblies are properly grounded to the metal chassis of the fireplace or log set. |
| | - Faulty module | Turn the ON/OFF switch to the "OFF" position. Remove the igniter wire "I" from the module. Place the ON/OFF switch to the "ON" position. Hold a grounded wire about 3/16" away from the "I" terminal on the module. If no spark the "I" terminal module must be replaced. If there is a spark the "I" terminal is fine. Inspect pilot assembly for a shorted wire or cracked insulator around the electrode. |
| Pilot sparks but will not light | - Gas supply | Verify that the incoming gas line ball valve is "Open". Verify that the inlet pressure reading is within acceptable limits, inlet pressures must not exceed 14" W.C. |
| | - Module is not grounded | Verify the value and pilot assemblies are properly grounded to the metal chassis of the fireplace or log set. |
| Continues to sparks and pilot lights, but main burner will not light | - Short or loose connection in sensor rod | Verify all connccetions. Verify the connections from the pilot assembly are tight; also verify these connections are not grounding out to any metal. |
| | - Poor flame rectification or contaminated sensor rod | Verify the flame is engulfing the sensor rod. This will increase the flame rectification. Verify correct pilot orifice is installed and inlet gas specifications to manual. <i>(Remember, the flame carries the rectification current, not the gas. If the flame lifts from pilot hood, the curcuit is broken. A wrong orifice or too high of an inlet pressure can cause the pilot flame to lift.)</i> The sensor rod may need cleaning. |
| | - Poor grounding between pilot assembly and gas valve | Verify that the wire harness is firmly connected to module |
| | - Damaged pilot or dirty sensor rod | Verify that the ceramic insulator around the sensor rod is not cracked, damaged, or loose. Verify the connection from the sensor rod to the sensor wire. Clean sensor rod wih an enery cloth to remove any contamination that may have accumulated on the sensor rod. Verify continuity with multimeter with olms set at the lowest range. |

| SYMPTOM | PROBLEM | TEST SOLUTION |
|---|---|---|
| Pilot lights Stops sparking / pilot remains lit but burner will not turn on | - Wiring / Connection | Inspect all wires, ensure good tight connections. Verify that all wiring is installed exactly as specified. |
| | - Wiring harness | Inspect the wiring harness, and verify the harness is tightly connected to the module. Verify that you have 7 wires and they are connected in the right order. |
| | - Module or Valve | Conduct the following test to verify if the problem is the module or valve. To measure voltages, turn multimeter to "DC" place the red lead from multimeter on the screw on the terminal block for the wire you are checking, touch black lead to ground (valve body). Importantly, a "Zero" volts reading does not automatically indicate a bad module, there may be too little resistance in the valve solenoid. Check the Green wire disconnected from valve that the voltage output from the module should be between 2 and 3 volts |
| Exhaust fumes smelled in room, headaches. | - Fireplace is spilling. | Check all seals. |
| Carbon is being deposited on glass, logs or combustion chamber surfaces. | - Air shutter has become blocked | Ensure air shutter opening is free of lint or other obstructions. |
| | - Flame is impinging on the logs or combustion chamber. | Check that the logs are correctly positioned. Open air shutter to increase the primary air. Check the input rate: check the manifold pressure and orifice size as specified by the rating plate values. Check that the door gasketing is not broken or missing and that the seal is tight. Check that both vent liners are free of holes and well sealed at all joints. Check that minimum rise per foot has been adhered to for any horizontal venting. |
| Flames are very aggressive. | - Door is ajar | Tighten door clamps |
| | - Venting action is too great. | Restrict vent exit with restrictor plate. See Restricting Vents. |
| Main burner flame is a blue, lazy, transparent flame. | - Blockage in vent. | Remove blockage. In really cold conditions, ice buildup may occur on the terminal and should be removed as required. |
| | - Incorrect installation (vertical termination only). | Refer to Figure 24 to ensure correct location of storm collars. |
| White / grey film forms. | - Sulphur from fuel is being deposited on glass, logs or combustion chamber surfaces. | Clean the glass with a recommended gas fireplace glass cleaner. DO NOT CLEAN GLASS WHEN HOT. If deposits are not cleaned off regularly, the glass may become permanently marked. |

WOLF STEEL Fireplace Service History

This fireplace must be serviced annually depending on usage

[illegible]