# **SE-S10** Electronic Cash Register



(SE-S10 small drawer model)

# **User's Manual**

# **START-UP is QUICK and EASY!** Simple to use!

20 departments and 500 PLUs Automatic Tax Calculations Calculator function

**CASIO COMPUTER CO., LTD.** 6-2, Hon-machi 1-chome Shibuya-ku, Tokyo 151-8543, Japan





Thank you very much for purchasing this CASIO electronic cash register.

START-UP is QUICK and EASY!

Part-1 of this User's Manual can help you make a quick start.

Once you have mastered the QUICK START operations, you will undoubtedly want to expand your use of this machine by studying other sections of Part-2.

### **Original Carton/Package**

If for any reason, this product is to be returned Your cash register is designed to operate to the store where purchased, it must be on standard household current (120V, 220V, packed in the original carton/package.

### Location

Locate the Cash register on a flat, stable surdirect sunlight, humidity or dust.

### **Power Supply**

230V or 240V; 50/60Hz). Do not overload the outlet by plugging in too many appliances.

### Cleaning

Clean the cash register exterior with a soft face, away from heaters or areas exposed to cloth which has been moistened with a solution of a mild neutral detergent and water, and wrung out.

> Be sure that the cloth is thoroughly wrung out to avoid damage to the printer.

> Never use paint thinner, benzene, or other volatile solvents.

The mains plug on this equipment must be used to disconnect mains power. Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

## INTRODUCTION

### Safety precautions

- To use this product safely and correctly, read this manual thoroughly and operate as instructed. After reading this guide, keep it close at hand for easy reference. Please keep all informations for future reference.
- Always observe the warnings and cautions indicated on the product.

### About the icons

In this guide various icons are used to highlight safe operation of this product and to prevent injury to the operator and other personnel and also to prevent damage to property and this product. The icons and definitions are given below.



Indicates that there is a risk of severe injury or death if used incorrectly.

Indicates that injury or damage may result if used incorrectly.

### **Icon examples**

To bring attention to risks and possible damage, the following types of icons are used.



The  $\triangle$  symbol indicates that it includes some symbol for attracting attention (including warning). In this triangle the actual type of precautions to be taken (electric shock, in this case) is indicated.



The  $\otimes$  symbol indicates a prohibited action. In this symbol the actual type of prohibited actions (disassembly, in this case) will be indicated.



The symbol indicates a restriction. In this symbol the type of actual restriction (removal of the power plug from an outlet, in this case) is indicated.



Handling the register



Should the register malfunction, start to emit smoke or a strange odor, or otherwise behave abnormally, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of fire and electric shock.

Contact CASIO service representative.



Do not place containers of liquids near the register and do not allow any foreign matter to get into it. Should water or other foreign matter get into the register, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of short circuit, fire and electric shock. • Contact CASIO service representative.



Should you drop the register and damage it, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of short circuit, fire and electric shock.

· Attempting to repair the register yourself is extremely dangerous. Contact CASIO service representative.



Never try to take the register apart or modify it in any way. High-voltage components inside the register create the danger of fire and electric shock.

· Contact CASIO service representative for all repair and maintenance.

### Power plug and AC outlet



Use only a proper AC electric outlet. Use of an outlet with a different voltage from the rating creates the danger of malfunction, fire, and electric shock. Overloading an electric outlet creates the danger of overheating and fire.



Make sure the power plug is inserted as far as it will go. Loose plugs create the danger of electric shock, overheating, and fire.

· Do not use the register if the plug is damaged. Never connect to a power outlet that is loose.

	Warning!
	Use a dry cloth to periodically wipe off any dust built up on the prongs of the plug. Humidity can cause poor insulation and create the danger of electric shock and fire if dust stays on the prongs.
$\bigcirc$	Do not allow the power cord or plug to become damaged, and never try to modify them in any way. Continued use of a damaged power cord can cause deterioration of the insulation, exposure of internal wiring, and short circuit, which creates the danger of electric shock and fire.
	Contact CASIO service representative whenever the power cord or plug requires repair or maintenance.
$\bigcirc$	Caution!
V	Do not place the register on an unstable or uneven surface. Doing so can cause the register — especially when the drawer is open — to fall, creating the danger of malfunction, fire, and electric shock.
$\bigcirc$	<ul> <li>Do not place the register in the following areas.</li> <li>Areas where the register will be subject to large amounts of humidity or dust, or directly exposed to hot or cold air.</li> <li>Areas exposed to direct sunlight, in a close motor vehicle, or any other area subject to very high temperatures.</li> </ul>
	The above conditions can cause malfunction, which creates the danger of fire.
	Do not overlay bend the power cord, do not allow it to be caught between desks or other furniture, and never place heavy objects on top of the power cord. Doing so can cause short circuit or breaking of the power cord, creating the danger of fire and electric shock.
	Be sure to grasp the plug when unplugging the power cord from the wall outlet. Pulling on the cord can damage it, break the wiring, or cause short, creating the danger of fire and electric shock.
$\bigcirc$	Never touch the plug while your hands are wet. Doing so creates the danger of electric shock. Pulling on the cord can damage it, break the wiring, or cause short, creating the danger of fire and electric shock.
$\bigcirc$	At least once a year, unplug the power plug and use a dry cloth or vacuum cleaner to clear dust from the area around the prongs of the power plug.
	Never use detergent to clean the power cord, especially power plug.
	Keep small parts out of the reach of small children to make sure it is not swallowed accidentally.
	Disposing of batteries:
	Make sure that you dispose of used batteries in accordance with the rules and regulations in your local area.

# Contents

0 , 0	6 8
Part-1 QUICK START OPERATION	9
1.Loading Memory Protection Battery2.Loading Paper Roll3.Setting the Cash Register4.If you want to use a printer as journal printer5.To remove receipt paper6.To remove journal paper7.Caution (in handling the thermal printer)8.Basic Programming for QUICK START9.Basic Operation after Basic Programming10.Daily Management Report	0 1 1 2 4
Part-2 CONVENIENT OPERATION	20
1. Various Programming202. Various Operations30	
Part-3 CALCULATOR FUNCTION	43
1. Calculator Mode 43	3
Part-4 USEFUL INFORMATION	45
1. Troubleshooting       4         2. Specifications       4	-

# **Basic Components and Accessories**



### Weld lines

Lines may be visible on the exterior of the product. These are "weld lines" that result from the plastic molding process. They are not cracks or scratches.

### Getting to know your cash register

# Getting to know your cash register

OFF

## Mode Switch



OP key

PGM key



An error is generated (E01 displayed) whenever the position of the Mode Switch is changed during registration.

## Display

The position of the Mode Switch controls the type of operations you can perform on the cash register. The PROGRAM key (marked PGM) can be select any Mode Switch setting, while OPERATOR key (marked OP) can be used to select OFF, REG or CAL only.



In this position, the power of the cash register is off.

### **REG** (Register)

This is the position used for registration of normal transactions.

### RF (Refund)

This is the position used for registration of refunds.

### CAL (Calculator)

This is the position used for calculator mode.

### **PGM** (Programming)

This is the position used to program the cash register to suit the needs of your store.

### X (Read)

This is the position used to produce reports of daily sales totals without clearing the totals.

### Z (Reset)

This is the position used to produce reports of daily sales totals. This setting clears the totals.



## **(1) Department Number Display**

Anytime you press a department key to register a unit price, the corresponding department number appears here.

## 2 PLU Number Display

Anytime you perform a PLU registration, the corresponding PLU number appears here.

### **③ Number of Repeat Display**

Anytime you perform "repeat registration" (page the last entered character. 14), the number of repeats appears here.

Note that only one digit is displayed for the num- total, or change is obtained. ber of repeats.

### Customer display



### (4) Numeric Display

Entered values (unit prices or quantities) and calculated values (subtotals, totals or change amount due) are displayed here. The capacity of the display is 8 digits.

This part of the display can be used to show the current time or date between registrations (page 40).

## **(5)** Character Display

In the character programming (P2) mode, it shows

The total (7) or change (5) appears when a subtotal,

In the paper saving mode, it shows \*.

6

## Getting to know your cash register

## Keyboard



Certain keys have two functions; one for register mode and one for calculator mode.

In this manual, we will refer to specific keys as noted below to make the operations as easy to understand as possible:

### **Register Mode**

- 1 FEED Feed key
- 2 Multiplication/ Date Time key
- ③ [AC C] Clear key
- (4) Minus/ Error Correction key
- 5 PLU PLU (Price Look Up) key
- 6 Keference Number/Department Shift key
- ⑦ <sup>%</sup>/<sub>KI</sub> Percent/Cashier ID No. Assignment key
- 8 RC Received on Account key
- PD Paid Out key
- 10 сн Charge key
- (1) CHK Check/No Sale key
- 12 Subtotal key
- (3)  $= \frac{CA/AMT}{TEND}$  Cash Amount Tendered key
- 1, ~ 9, 00
   Numeric keys and 2-zero key



Department 6 through 20 are specified by pressing the two respectively as follows:

 $\underbrace{\texttt{H}_{\text{SEFF}}}_{\texttt{rest}} \underbrace{\texttt{+1}}_{\texttt{rest}} \sim \underbrace{\texttt{H}_{\text{SEFF}}}_{\texttt{5}} \underbrace{\texttt{5}}_{\texttt{5}} \rightarrow \text{Department } 6 \sim 10$ 

 $\overset{\texttt{\#}_{\text{SEFF}}}{\xrightarrow{\texttt{H}_{\text{SEFF}}}}\overset{\texttt{\#}_{\text{SEFF}}}{\xrightarrow{\texttt{H}_{\text{SEFF}}}}\overset{\texttt{H}_{\text{SEFF}}}{\xrightarrow{\texttt{H}_{\text{SEFF}}}}\overset{\texttt{H}_{\text{SEFF}}}{\xrightarrow{\texttt{H}_{\text{SEFF}}}}\overset{\texttt{D}_{\text{SEFF}}}{\xrightarrow{\texttt{D}}} \rightarrow Department 16 \sim 20$ 

17 Reper saving key

Paper saving key is the key to save printing paper (Journal compressed printing/ No re ceipt issuing). In these cases, "\*" is lit on the character display.

18 **POST** Post receipt key

Post receipt key is used for issuing receipt after transaction. This key is effective if the printer is defined as printing receipts. Refer to page 38.

Tax Program key

HELP Help key

(19)

(20)

Help key is used for issuing assistant receipts such as programming date/ time, paper installation etc.

### **Calculator Mode**

- ③ AC AC key
- ⑦ <sup>%</sup><sub>CLK#</sub> Percent key
- ⑧ Memory Recall key
- (1) CHK Drawer Open key
- (13) = CA/AMT Equal key
- (14) 0, 1, ~ 9, 00

Numeric keys and 2-zero key

- 15 Decimal key
- (16)  $(+^{1}), (-^{2}), (\times^{3}), (\div^{4})$

Arithmetic Operation key

# Daily Job Flow





# QUICK START OPERATION

# 1. Loading Memory Protection Battery



- 1. Remove the printer cover.
- 2. Open the battery compartment cover.
- 3. Load 2 new UM-3, or R6P (SUM-3) type batteries into the compartment. Be sure that the plus (+) and minus (-) ends of each battery are facing in the directions indicated by the illustrations inside the battery compartment (Figure 1).
- 4. Replace the memory protection battery compartment cover back into place.



(Figure 1)

- Note: To prevent to lose all of your settings and sales data, we recommend you to install the memory protection batteries.
- REPLACE MEMORY PROTECTION BATTERIES AT LEAST ONCE EVERY YEAR.

# 2. Loading Paper Roll

## To load receipt paper

① Open platen arm.



② Ensuring the paper is being fed from the bottom of the roll, lower the roll into the space behind the paper.



③Put the leading end of the paper over the printer.



④ Close the platen arm slowly until it locks steadily.



CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS. Dart-1

# 3. Setting the Cash Register

- ① Plug the power cord of the cash register into AC outlet.
- ② Please choose your language followed by printed message.
- ③ When the display shows blinking "0", such as

## Щ́О-00-00

Enter current date in Day, Month, Year.When the display shows blinking "0", such as

## `Ĭ́Ω - 00

Enter current time in Hour, Minute.

- (5) Set the mode switch to REG.
- 6 Tear off any excess paper.



Replace the printer cover slowly.



\*Default printer definition is receipt printer.

# 4. If you want to use a printer as journal printer

① Set printing system as journal.



- 1 SUB TOTAL
- 1 Сн
- ② Remove the printer cover by lifting up the back.



③ Press the FEED key until approximately 20cm of the paper is fed from the register.

④ Roll the paper onto the take up real a few turns.



- (5) Set the left plate of the take up need and place the reel into the register.
- 6 Press the FEED key to take up any slack in the paper.
- $\bigcirc$  Replace the printer cover slowly.



Е

### To remove receipt paper 5.

(1) Open the platen arm.



(2) Remove the core of the paper.



### 6. To remove journal paper

1) Remove the printer cover by 4) Remove the take-up reel 7) Remove the core of the palifting up the back.



- 2 Press the FEED key until approximately 20cm of the paper is fed from the printer.
- ③ Cut off the roll paper.



- from the printer and take off the left plate of the reel.
- ⑤ Remove the journal paper from the take-up reel.



6 Open the platen arm.



per.



⑧ Load new paper following the instructions "1. To load journal paper".

- Caution (in handling the thermal printer) 7.
- 1. Never touch the printer head and platen.
- 2. Unpack the paper just before you use.
- 3. Avoid heat/ direct sunlight.
- 4. Avoid dusty and humid places for strage.
- 5. Do not scratch the paper.
- 6. Do not keep the paper under the following circumstances: High humidity and temperature/ direct sunlight/ contact with glue, thinner or rubber eraser.

-E

# 8. Basic Programming for QUICK START

Mode Switch REG CAL X OFF • D RF • PGM

Procedur	Purpose	
1. To select the date format and monetary mode		
You can select the date format and monetary the requirements in your area. Default date for monetary mode is add 2.		
3 SUB TOTAL P3 appears in mode display 0 1 2 2 SUB TOTAL Program set code No. 2 0 = CA/AMT Select number from list A - Select number from list B SUB TOTAL (To end the setting)	Date Format SelectionsYear/ Month/ Day0Day/ Month/ Year1Day/ Month/ Day/ Year2Monetary Mode SelectionsAdd 0(0.)Add 1(0.0)1Add 2(0.00)2	Select date format and monetary mode
<ul> <li>2. Input the desired add-in tax rate to the appropriate of the programs add-in tax rate or tax with special rounding, refer to page 27 of A) Enter 1 and press the SUB rotal key.</li> <li>B) Press the key.</li> <li>C) Enter tax rate. (Example: For 6% enter "6", 5.</li> <li>D) Press the appropriate department key.</li> <li>E) Repeat step B) and C) to set other department key.</li> <li>E) Repeat step B) and C) to set other department key.</li> <li>F) Press the SUB rotal key to end tax programmination of the setting of this proceed.</li> <li>F) Press the SUB rotal keys above, and quit the and start from the beginning of this proceed.</li> <li>Example :</li> <li>Set add-in tax 8% to department 2, 3, 15% to depart tax rate and press</li> <li>8 2 Enter tax rate and press</li> <li>1 5 2 Enter tax rate and press</li> <li>SUB rotal To end the setting.</li> </ul>	te only. If you want to set add-on tax of this manual.) .75% enter "5.75".) ent key. ing. e key, please enter <b>1</b> and press is procedure by pressing <b>SUB</b> is procedure by pressing <b>SUB</b> dure. epartment 4 key. s dept key. s dept key.	Setting the tax rates

Procedure	Purpose
<ul> <li>3. In case of accepting two (the Euro and the local) currencies.</li> <li>3. In case of accepting two (the Euro and the local) currencies.</li> <li>3. In case of accepting two (the Euro and the local) currencies.</li> <li>3. In case of accepting two (the Euro and the local) currencies.</li> <li>3. In case of accepting two (the Euro and the local) currency.</li> <li>3. In case of accepting two (the Euro and the local) currencies.</li> <li>3. In case of accepting two (the Euro and the main currency/print out currency of the subtotal.</li> <li>3. In case of accepting two (the Euro and the main currency/print out currency of the subtotal.</li> <li>3. In case of accepting two (the Euro and the main currency = Local, Print out subtotal = Local: 0</li> <li>4. Main currency = Local, Print out subtotal = Both: 2</li> <li>4. Main currency = Euro, Print out subtotal = Both: 2</li> <li>4. Main currency = Euro, Print out subtotal = Both: 3</li> <li>3. Press the following keys to set the currency exchange rate against the Euro.</li> <li>1. Interact a the setting)</li> <li>Interact within the range of 0.00001 to 999999.</li> </ul>	Setting the Euro
<ul> <li>4. In case of becoming to accept the Euro only. You can restrict the registable currency to the Euro only by the following procedure.</li> <li>1. Turn the mode switch to Z position.</li> <li>2. Issue all reset report including periodic data.</li> <li>3. Press the following keys to set. 0 1 0 7 2 0 0 2 SUB (TOTAL) = CA/AMT (TOTAL) = CA/AMT (TOTAL)</li> </ul>	Restricting the Cur- rency to the Euro
<ul> <li>5.For Australia only. You can set some programmable options to suit the Australian GST by the following procedure.</li> <li>1. Turn the mode switch to Z position.</li> <li>2. Press the following keys to program.</li> <li>1 0 1 2 0 0 1 SUB _ CA/AMT _ CA/AMT _ Instead of _ CA/AMT _ C</li></ul>	Setting the Australian GST

Part-1

# 9. Basic Operation after Basic Programming

## Note:

Whenever an error is generated, the input figures reset to 0. All printout samples are journal images and the header (date, time and consecutive no.) are eliminated from the samples.



Cash amount tendered

Departments 6 through 10, 11 through 15, 16 through 20 can also be registered in combination with the  $\boxed{1}$  and  $\boxed{1}$ ,  $\boxed{2}$ ,  $\boxed{3}$ ,  $\boxed{4}$  or  $\boxed{5}$  keys, respectively. The  $\boxed{1}$  key should be entered just before entering unit price manually.

Mode Switch

REG

OFF

RF

PGM

### 08-01-2010 09:05 9-3 Multiple registra-REG 0003 tion of the same Department 1 Unit Price DEPT01 ·1.00 + 1 items Repeat DEPT01 · 1.00-3 Sales Quantity/ Unit Price З Х @1.35 Example Quantity DEPT02 ·4.05 Multiple key Unit Price \$1.00 \$1.35 CASH ·6.05 -**2** 3 5 Quantity 2 3 SUB TOTAL Dept. 1 2 = CA/AMT

Note that repeat registration can be used with unit prices up to 6 digits long.

9-4 Cha Example	irge s	sales	;	1 0 0 + 1 2 0 0 - 2 - 2	08-01-2010 REG	09:10 0004	
Unit Price	\$1.00	\$2.00	\$3.00	3 0 0 + 1 entrie	DEPT01 DEPT02	·1.00 ·2.00	
Quantity	1	1	1	SUB TOTAL	DEPT01	· 3.00	
Dept.	1	2	1	СН	CHARGE	$\cdot 6 \cdot \mathbf{OO} + \text{Charge Sa}$	ales

Charge key

You cannot perform the amount tendered operation using the CH key.

14

## 9-5 Split cash/ charge sales

Example						
Unit Price	\$2.00	\$3.00	\$4.00			
Quantity	1	1	1			
Dept.	1	2	1			
Cash Amount tendered		\$5.00				

Operation	Printou	ıt	
2 0 0 +1 3 0 0 -2 7227	08-01-2010 REG	09:25 0005	-•
4 0 0 + 1 SUB TOTAL 5 0 0 = CA/ANT CH	DEPT01 DEPT02 DEPT01 TOTAL CASH CHARGE	·2.00 ·3.00 ·4.00 · <b>9</b> . <b>00</b> ·5.00- ·4.00-	– Cash Amount Tendered – Charge Sales

## 9-6 Corrections

9-6-1 Before you

press a depart-

Corrections can be made while you are registering the item (before you press a department key), or after it has already been registered into the memory (by pressing a department key).

### **key clears the last item entered.**

ment key			
-	Operation	Printout	
Example			
<ol> <li>Entered 400 for unit price by mistake in-</li> </ol>		DEPT01	· 1.00
stead of 100.	Wrong entry Clears the last item entered.		
	Correct entry Registered Department 1		
<ol> <li>Entered unit price first instead of quantity</li> </ol>		5 X	@2.00
and then pressed $\mathbb{X}_{\text{me}}$ .	Unit price Multiplication	DEPT02	· 10.00
	AC C		
	Clears the last item entered.		
	5 XATE		
	Quantity Multiplication		
	<b>200-2</b> <u>71277</u>		
	Unit price Registered Department 2		
3. Entered 150 for unit			ed 05
price by mistake in- stead of 105.	Quantity Multiplication	10 X DEPT03	@1.05 ·10.50
	Wrong entry Clears the last item entered.		
	Quantity		
	Correct entry Registered Department 3		



·5.50

-5.50

·5.05

**Printout** 

## 9-6-2 After you pressed a department key

### Example

1. Entered unit price 550 by mistake instead of 505 and pressed a department key.

Operation



5     5     0       Wrong entry     Image: Comparison of the second s	DEPT01 ERR CORR DEPT01
Cancels the last item registered.	
Correct entry Registered Department 1	

2. Entered unit price 220 by mistake instead of 230 and pressed a department key.



3 x	@2.20
DEPT02	·6.60
ERR CORR	-6.60
3 X	@2.30
DEPT02	·6.90



Press  $\underline{=}^{\text{ca/HM}}$  to finalize the transaction. The change amount in the main currency is shown on the display. \*2

- \*1 If the payment is the same as the subtotal amount, you can omit this operation. Press = CA/AMT key directly after the subtotal.
- \*2 If the payment is less than the subtotal amount, the cash register specifies it as a partial payment and shows the balance in the main currency on the display.

Printo	ut	
08-01-2010	09:30	
REG	0010	
3 x	@2.00	
DEPT01	· 6.00	
TOTAL	$\cdot 6$ . $\mathbf{OO}$ – Subtotal in the main curre	ency
	€7.50+ Subtotal after conversi	on
EURO	Payment in the Euro	
CASH	€10.00	
CASH	·8.00 Payment after convers	ion
CHANGE	$\cdot 2.00$ Change in the main curre	ency
EURO CG	€2.50 — Change in the sub currer	ncy

E

## **10. Daily Management Report**

This section tells you the procedures to use to produce reports of the transaction data stored in the cash register's memory.

### Important

Remember that when you issue a reset (Z) report, the data that is reported is cleared from the applicable totalizers. To view data without clearing totalizers, issue a read (X) report.



## 10-2 Read/Reset Report



\* If you want to designate read range, enter date and/ or cosecutive No.. If you want to reset the electronic journal, just press **5 8**  $= \frac{ca/AET}{TEN}$  in Z mode.

• Journal is saved in the memory and you can take a report any time you want.





# **CONVENIENT OPERATION**

- 1. Various Programming
- 1-1 Unit price for Departments



Example						
Unit Price	\$1.00	\$2.20	\$11.00			
Dept.	1	2	3			



• Unit prices within the range of 0.01~9999.99.

# 1-2 Rate for percent key



# 1-4 Status for Department



## 1-5 Status for percent key

1-5-1 To change taxable status The percent key is initialized as Non-taxable. for the percent key

Example Change Percent key registra- tion as a Taxable status 1.	P appears in mode display	()		
	(To end the setting)			
	Selections			
	Taxable status 1	RC		
	Taxable status 2	PD		
	Taxable status 3			
	Taxable status 4	СН	A	
	All taxable status (1, 2, 3 and 4)			
	Non-taxable status	CHK /NS		



Taxable status 3

Taxable status 4

Non-taxable status

All taxable status (1, 2, 3 and 4)

Сн

CHK

RC/PD

Α



E





## 1-8 PLU setting

### 1-8-1 Linkage with Departments

Example		
PLU No.	1	100
Link dept. No.	4	4



- 500 PLUs can be set.
- When the linked department is not specified, the PLU is linked to department 20.
- Status for a single-item sale and tax status are followed the specified linked department.

## 1-8-2 Unit Prices for PLUs

Example		
PLU No.	1	2
Unit Price	\$1.00	\$3.00



• Unit prices within the range of \$0.01~9999.99.

26



See page 20 (department key), 21 (percent key), 22 (minus key) to change the fixed tax status.
\*2: In case of defining Danish rounding, the Euro should be set to the sub currency and the local to the main currency.

Part-2

27



No

Yes

No

Yes

No

Yes

0

1

2

3

Β

## 1-11 To program department, PLU, clerk name, receipt message

1-11-1 Simple character<br/>list fror HELPYou can set department and PLU name by<br/>using a simple character list fror HELP



## 1-1. Issue category list.



## 1-2. Issue category list.



## 2-1. Programming department name.

Example

Department	2	8	
Name	JEWELRY	SHOES	
Character code	401	404	
		2 SUB TOTAL P2 appears in mode	display
		4 0 1 - <b>2</b>	
			]

(To end the setting)

E

## 2-2. Reset department name.

Department	2
Name	DEPT01
Character code	0



(To end the setting)

## 2-3. Programming department PLU



2-4.	Reset	PLU	name.
------	-------	-----	-------

PLU(1-1200)	30
Name	PLU0030
Character code	0



E-

## 1-11-2 Character keyboard

(1) Double size key

character.

Alphabet keys

③ Right arrow key

(4) Delete key

entered.

(5) PLU key

(6) Department keys

⑧ Clerk number key

(7) Department shift key

In the PGM 2 mode, the keyboard becomes character setting keyboard illustrated below after specifying a department, a PLU, or a clerk.



Use this key to terminate character pro-

1-11-3 Programming department name



gramming.

## 1-11-4 Programming PLU name



## 1-11-5 Programming clerk name



## 1-11-6 Programming receipt message



## 1-11-7 Alphabetical order

Characters are assigned to each numeric key. You can enter "A" by pressing **8** once, "B" twice, "C" three times ...

The following tables indicate character assignment and the depression numbers of the key to enter the appropriate character.





E

Я

П

## 1-12 Printing to read All Preset Data

• Printing preset data.

Operation

= CA/AMT TEND

1-12-1 Printing preset data except PLU settings



Print	out	-
DEPT01 DEPT02	T1 @1.00 0000 @10.00 @5.00 0000	+ Tax Status/Normal Dep Digit Limit/Single Item
- %-(12.34%) 1EURO 10200 10800 0122 0522 0622 0822 1022 0326 2422 CLERK01 CLERK01 CLERK02 CLERK03 CLERK04 CLERK05 CLERK06 CLERK07	· 1.2973	Tax Control
	. ,	- Tax Rate 2 - Receipt message

E




# 2-4 Split cash/ check sales

Example			
Unit Price	\$30.00	\$25.00	
Quantity	1	1	
Depts.	2	3	
Cash amount tendered	\$20.00		
Check	\$35.00		

_		08-01-2010	16:15
)	2 5 0 0 × 3	REG	0044
_	SUB	DEDTOO	00.00
		DEPT02	·30.00
	$\begin{bmatrix} 2 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ = \frac{CA/AMT}{TEND}$	DEPT03	·25.00
	Снк	TOTAL	·55.00
	/NS	CASH	·20.00
		CHECK	·35.00

# 2-5 Post receipt issuance

You can issue a post receipt after finalizing a transaction by pressing RECEPT.

Note that all of the following condition must be satisfied:

- Print "receipt" option is selected.
- Paper Saving mode must be "ON".

			r upor ouving modo muoti		
Example			<ul> <li>The transaction must be find</li> </ul>	nalized in the REG/RF mode using $[$	CA/AMT, CH Or CHK/NS.
Unit Price	\$1.00	\$2.00		Note:	
Quantity	1	1	1 0 0 + 1	You can issue only one post rece	ipt per transaction.
Depts.	1	2	2 0 0 <u>- 2</u>	(Post re	
Cash amount	\$5	.00	SUB	08-01-2010	16:25
tendered	ψŪ		$500 = \frac{cA/AMT}{TEND}$	REG	0045
			(Receipt is not is	/ DEFIUI	·1.00
			POST RECEIPT	DEPT02	·2.00
				TOTAL	·3.00

If the transaction contains more than 40 lines (including receipt header), then the total formatted post receipt is issued.

(Receipt is issued.)

	(Total formatted post receipt)		
	08-01-2010	16:25	
	REG	0045	
(	CASH	·3.00	

·5.00

·2.00

CASH

CHANGE



### 2-7 PLU operation Mode Switch CAL X REG OFF RF PGM 2-7-1 PLU registration Printout Operation (Programming: See page 26) PLU 1 08-01-2010 17:00 Example PLU REG 0051 PLU No. 1 2 4 Unit Price \$1.00 \$2.00 PLU0001 ·1.00 PLU PLU0001 ·1.00-Repeat Quantity 2 4 Multiplication 4 X @2.00 Depts. 1 1 n 0 0 = CA/AMT PLU0002 - Preset Unit Price ·8.00-Cash amount \$10.00 TOTAL · 10.00 tendered CASH ·10.00 Cash Amount Tendered CHANGE ·0.00

# 2-7-2 PLU Single-Item Sale

1

2-1-2 FL	0 Single-item		eration	Print	out	
(Pi	rogramming: Se	e page 26)	1 PLU	08-01-2010 REG	17 : 10 0052	
Example				PLU0001	· 1.00	
PLU No.	1			CASH	· 1.00	
Status	Single item sale	• For this	s evampla lin	ked departmen	t 1 is progra	mmo
Unit Price	\$1.00	item-se		ikeu uepartinen	t is plogid	unne

ed for a singleitem-sale.

**Part-2 CONVENIENT OPERATION** 

· Single-item sale cannot be finalized if an item is registered previously.

# 2-7-3 PLU report

Quantity





• If you have changed the date order (refer to page 12), enter date of that order.

40





Cashier assignment system is used to control each cashier (or clerk) sales total. When you select this function on page 23, you can get 8 cashiers (or clerk) sales data.

Cashier assignment must be performed prior to starting registration or any other operation, except Program mode.



- Currently assigned cashier (or clerk) ID number is printed on the receipt or journal for each transaction.
- The assigned clerk memory number is automatically signed off when the mode key is set to OFF position.
- The assigned cashier (or clerk) sales totals with ID number are printed on the receipt or journal when you perform daily X/Z sales report.



Part-3

# **Part-3 CALCULATOR FUNCTION**

1-3 Setting for calculator operation





\*Drawer does not open during registration procedures even if you press  $= \frac{CA/AMT}{TEND}$  or  $\frac{CHK}{NS}$  by turning the mode switch to CAL position.



# **USEFUL INFORMATION**

# 1. Troubleshooting

# 1-1 If the following things happen

	Symptom/Problem	Most common causes	Solutions
1	E01 appears on the display.	Changing modes without complet- ing transaction.	Return mode switch to where it stops buzz- ing and press $\left[=\frac{CA/AMT}{FEND}\right]$ .
2	E08 appears on the display.	Sign on operation is not performed.	Prior to starting registration of any other operation, press <b>1</b> ~ <b>8</b> and then X(1).
3	E10 appears on the display.	Printer head (platen arm) is opened or no papaer roll.	Close the platen arm firmly or enter paper roll.
4	<b>E90</b> appears on the display.	Totals remain in the memory.	Issue the general control reset report, peri- odic reset report and PLU reset report.
5	E81 appears on the display.	Electronic journal memory be- comes/ is full.	Issue electronic journal reset report. (refer to page 18)
6	No date on receipt. Paper is not advancing enough.	Printer is programmed as a journal.	Program printer to print receipts.
7	Drawer opens up after ringing up only one time.	Department is programmed as a single item dept.	Program the dept. as a normal dept.
8	Not clearing totals at end of day after taking report.	Using X mode to take out reports.	Use Z mode to take out reports.
9	Programming is lost whenever register is unplugged or there is a power outage.	Bad or no batteries.	Put in new batteries.
10	Register is inoperative. Can't get money out of drawer.	No power.	Pull lever underneath register at rear.

1-2 In case of power failure

If the power supply to the cash register is cut by a power failure or any other reason, simply wait for power to be restored. The details of any ongoing transaction as well as all sales data in memory are protected by the memory backup batteries.

- Power failure during a registration
  - The subtotal for items registered up to the power failure is retained in memory. You will be able to continue with the registration when power is restored.
- Power failure during printing a read/reset report The data already printed before the power failure is retained in memory. You will be able to issue a report when power is restorted.
- Power failure during printing of a receipt and the journal Printing will resume after power is restored. A line that was being printed when the power failure occurred is printed in full.
- · Other

The power failure symbol is printed and any item that was being printed when the power failure occurred is reprinted in full.

# 1-3 When the L sign appears on the display

# About the low battery indicator...

The following shows the low battery indicator.

L 0.00

If this indicator appears when you switch the cash register on, it can mean one of three things:

- · No memory backup batteries are loaded in the cash register.
- The power of the batteries loaded in the unit is below a ceratain level.
- · The batteries loaded in the unit are dead.

To clear this sign, press acc key.

### Important!

Whenever the low battery indicator appears on the display, load a set of 2 new batteries as soon as possible. If there is a power failure or you unplug the cash register when this indicator appears, you will lose all of your sales data and settings.

# BE SURE TO KEEP THE POWER CORD OF THE CASH REGISTER PLUGGED IN WHENEVER YOU REPLACE THE BATTERIES.

# 2. Specifications

# **INPUT METHOD**

Entry: 10-key system; Buffer memory 8 keys (2-key roll over) Display (LED): Amount 8 digits (zero suppression); Department/PLU No.; No. of repeats

# PRINTER

# CALCULATIONS

Entry 8 digits; Registration 7 digits; Total 8 digits

# CALCULATOR FUNCTION

8 digits; Arithmetic calculations; Percent calculations

Memory protection batteries:

The effective service life of the memory protection batteries 2 (UM-3, or R6P (SUM-3) type batteries) is approximately one year from installation into the machine.

Power source/Power consumption: See the rating plate.

Operating temperature: 0°C to 40°C (32°F to 104°F)

Humidity: 10 to 90%

Dimensions/Weight: 188 mm(H)  $\times$  330 mm(W)  $\times$  360 mm(D) with S drawer

4 kg with S drawer

 $205 \text{ mm}(\text{H}) \times 410 \text{ mm}(\text{W}) \times 450 \text{ mm}(\text{D})$  with M drawer

8 kg with M drawer

# Specifications and design are subject to change without notice.

# **Part-4 USEFUL INFORMATION**

# <text><text><image><image>

Laite on liitettävä suojamaadoituskostkettimilla vaurstettuun pistrasiaan Apparatet må tiloples jordet dtikkontakt Apparaten skall anslutas till jordat nätuttag



This mark applies in EU countries only.



Please keep all information for future reference.

Part-



CASIO COMPUTER CO., LTD.

6-2, Hon-machi 1-chome Shibuya-ku, Tokyo 151-8543, Japan CR0906-A

SE-S10\*E Printed in Indonesia Printed on recycled paper.