

---

# **Universal IP**

## **AT Commands Reference Guide**



## Universal IP AT Commands Reference Guide for the following products:

SocketModem® iCell GPRS (MTSMC-G2-IP, MTSMC-G2-GP)  
 SocketModem® iCell CDMA (MTSMC-C1-IP, MTSMC-C1-GP)  
 SocketModem® iCell HSPA (MTSMC-H4-IP, MTSMC-H4-GP)  
 SocketModem® iCell EV-DO (MTSMC-EV2-IP, MTSMC-EV2-GP)  
 SocketModem® IP (MT5692SMI-IP) This SocketModem uses these commands when the modem is in IP mode  
 SocketEthernet IP® (MT100SEM-IP)  
 SocketWireless® Wi-Fi® (MT810SWM-IP)  
 MultiModem® iCell GPRS (MTCMR-G2, MTCMR-G2-GP) Uses these commands when the modem is in IP mode  
 MultiModem® iCell CDMA (MTCMR-C1, MTCMR-C1-GP) Uses these commands when the modem is in IP mode  
 MultiModem® iCell EDGE (MTCMR-E1, MTCMR-E1-GP) Uses these commands when the modem is in IP mode  
 MultiModem® iCell HSPA (MTCMR-H4, MTCMR-H4-GP) Uses these commands when the modem is in IP mode  
 MultiModem® iCell EV-DO (MTCMR-EV2, MTCMR-EV2-GP) Uses these commands when the modem is in IP mode

## Product Number of This Document: S000457K, Version K

### Copyright

This publication may not be reproduced, in whole or in part, without prior expressed written permission from Multi-Tech Systems, Inc. All rights reserved. Copyright © 2008-2010 by Multi-Tech Systems, Inc.

Multi-Tech Systems, Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Furthermore, Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc. to notify any person or organization of such revisions or changes.

### Revisions

<b>Revision Level</b>	<b>Date</b>	<b>Description</b>
I	07/12/10	Added more detail to Global Positioning System Fix Data. Added a Note to the #FTPAPPEND and #FTPGET commands. Moved #PERSISTENTSOCKET and #OUTPORT commands from Chapter 1 to both UDP and TCP chapters. Updated Pin Function Descriptions for Digital Input. Changed the response values for #WLANGERSSI to -256 through -1 dBm. Updated the list of products that use this command set.
J	08/24/10	Added a note to Chapter 15 introduction. In chapter 15 changed the word <i>pin</i> to <i>GPIO</i> .
K	06/17/11	Added new commands: #SHIELDCHAR, #ESCAPECHAR, #SMTPNETWORKTIMER, #TCPACKETMIN, #TCPACKETMAX, #TCPINACTIVITYTIMER, #TCPNETWORKTIMER, #TCPTELNETMODE, #TCPTELNETPW, #TCPTELNETUN, #FTPNETWORKTIMER, #VSHOWSERIAL, #VSHOWUPTIME, #VSHOWUPTIMES, #SMSPHRASE, #UDPPACKETMIN, #UDPPACKETMAX, #UDPINACTIVITYTIMER, #UDPIGNORESRCPORT, #UDPDLEMODE, #GPIO, #HOSTNAME. Changed Defaults to 1 in #TCPPORT, #UDPPORT, #KEEPALIVEPORT, #GPSPORT. Added value 4 to #ANSWERMODE. Removed #WLANPROFILE (Load the WLAN Profile); use #WLANPROFILEn=n instead.

**Note:** This product used the FreeRTOS.org real time kernel. The FreeRTOS.org source code can be obtained by visiting <http://www.FreeRTOS.org>

### Trademarks

Multi-Tech Systems, Inc. registered trademarks include **SocketModem**, **MultiModem** and the Multi-Tech logo.  
 SkyTraq is a trademark of SkyTraq Technology, Inc.

### World Headquarters

Multi-Tech Systems, Inc.  
 2205 Woodale Drive  
 Mounds View, Minnesota 55112  
 Phone: 763-785-3500 or 800-328-9717  
 Fax: 763-785-9874  
 Internet Address: <http://www.multitech.com>

### Technical Support

Please refer to the Copyright/Technical Support page in the product User Guide or Developer Guide.

# Contents

<b>Part 1 – .....</b>	<b>9</b>
<b>AT Commands for All Universal IP Devices .....</b>	
<b>Chapter 1 – General AT Commands for All Universal IP Devices.....</b>	<b>10</b>
<b>    Set Commands.....</b>	<b>10</b>
AT – Command Mode .....	10
E – Turn Echo ON/OFF .....	10
I – Identification .....	10
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
&C – RLSD (DCD) Option Turn On or Off .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults.....	11
&S – DSR ON or OFF .....	11
&W – Store Factory Defaults to NVM .....	12
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control.....	13
+IPR – Set Serial Speed .....	13
#AUTORESET - Reset the Processor at a Given Time.....	13
#DELFLASH – Erase Flash Memory Parameter Values .....	13
#LEGACYMODE – Legacy Mode Enable/Disable.....	14
#RESET – Reset Main Processor or Internal Modem .....	14
#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15
<b>    Display Commands .....</b>	<b>15</b>
#VVERSION – Display Software Version .....	16
#VSTATE – Display Current State of Physical Connection .....	16
#VALL – Display All Parameters .....	17
<b>Chapter 2 – SMTP AT Commands for All Universal IP Devices .....</b>	<b>19</b>
<b>    Set Commands.....</b>	<b>19</b>
#SENDERNAME – Set Sender Name .....	19
#SENDERADDR – Set Sender Address.....	19
#CCRECi – Set Additional Recipient CC .....	19
#DOMAIN – Set Domain Name of the Sender .....	20
#RECIADD – Set Email Address .....	20
#SUBJi – Set Email Pre-Defined Subject Text .....	20
#BODYi – Set Pre-Defined Email Combinations .....	21
#SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value .....	21
#SMTPPORT – Set SMTP Server Port .....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SENDMAILi – Send Mail without Interactive Mode.....	23
#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#SMTPAUTH – Authentication ON or OFF .....	25
<b>    Display Commands .....</b>	<b>25</b>
#VSIMTP – Display SMTP Parameters .....	25
#VMAILi – Display Email Parameters for Respective Mail ID.....	25
<b>Chapter 3 – POP3 AT Commands for All Universal IP Devices.....</b>	<b>26</b>
<b>    Set Commands.....</b>	<b>26</b>
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26

#POP3PW – Set POP3 Password.....	26
#POP3SERV – Set POP3 Server Address.....	26
#POP3UN – Set POP3 User Name .....	27
#GETMAIL – Retrieve Host Mail.....	27
<b>Display Command .....</b>	<b>27</b>
#VPOP3 – POP3 Module Parameters.....	27
<b>Chapter 4 – FTP AT Commands for All Universal IP Devices .....</b>	<b>28</b>
<b>Set Commands.....</b>	<b>28</b>
#FTPPORT – Enter FTP Server Port.....	28
#FTPMODE – Enter FTP Mode .....	28
#FTPCTYPE – Specify Data Type .....	28
#FTPSERV – Specify FTP Server Address.....	29
#FTPUN – Set FTP User Name.....	29
#FTPPW – Set FTP Password .....	29
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPPUTFILENAME – Set FTP Upload File Name.....	29
#FTPGET – Download Files from FTP Server .....	30
#FTPPUT – Upload Files to FTP Server.....	30
#FTPGETPATH – Set Path to Get a File from FTP Server .....	31
#FTPPUTPATH – Set Path to Send Files to FTP Server .....	31
#FTAPPEND – Append Data to Server.....	31
#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value.....	31
<b>Display Command .....</b>	<b>32</b>
#VFTP – Display FTP Parameters.....	32
<b>Chapter 5 – TCP AT Commands for All Universal IP Devices .....</b>	<b>33</b>
<b>Set Commands.....</b>	<b>33</b>
#PERSISTENTSOCKET - Persistent Socket .....	33
#DLEMODE – Set DLE Mode.....	33
#TCPPORT – Set TCP Port for Remote Peer .....	34
#TCPSERV – Set Address of Remote TCP Server.....	34
#TCPTXDELAY – Time Delay .....	34
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size.....	35
#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size .....	35
#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value .....	36
#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value.....	36
#TCPTELNETMODE – Enable/Disable TCP Client Telnet Protocol .....	37
#TCPTELNETPW – Configure the TCP Client Telnet Protocol Login Password .....	37
#TCPTELNETUN – Set the TCP Client Telnet Protocol User Name .....	38
#LTCPSTART – Open Listening Mode .....	38
#LTCPSTOP – Close TCP Listening Mode .....	39
#OUTPORT – UDP/TCP Local Port Number.....	39
#OTCP – Open a TCP Connection.....	39
<b>Display Command .....</b>	<b>40</b>
#VTCP – Display TCP Parameters.....	40
<b>Chapter 6 – UDP AT Commands for All Universal IP Devices.....</b>	<b>41</b>
<b>Set Commands.....</b>	<b>41</b>
#PERSISTENTSOCKET - Persistent Socket .....	41
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size .....	41
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size .....	42
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value .....	42
#UDPIGNORESRCPORT – Ignore Send Source Port.....	43
#UDPREMOTEPORT – Remote Port Number .....	43
#UDPPORT – UDP Port Number .....	43
#UDPSERV – UDP Server Address .....	44
#UDPTXDELAY – Delay before Sending UDP Datagram.....	44
#UDPDELEMODE – Set DLE Mode .....	45
#LUDPSTART – Initiate the UDP Session in Listen Mode .....	45

#LUDPSTOP – Close UDP Listening Mode .....	46
#OUTPORT – UDP/TCP Local Port Number.....	46
#OUDP – Initiate UDP Session in Active Mode .....	46
<b>Display Command .....</b>	<b>46</b>
#VUDP – Display UDP Module Configuration .....	46
<b>Chapter 7 – PING AT Commands for All Universal IP Devices .....</b>	<b>47</b>
<b>Set Commands.....</b>	<b>47</b>
#PINGNUM – Number of PING Requests .....	47
#PINGREMOTE – IP Address of PING Request.....	47
#PING – Start PING Request .....	47
#PINGDELAY – PING Delay Time .....	47
<b>Display Command .....</b>	<b>48</b>
#VPING – Display PING Parameters.....	48
<b>Part 2 – AT Commands for the SocketEthernet IP .....</b>	<b>49</b>
<b>Chapter 8 – General AT Commands for the SocketEthernet IP .....</b>	<b>50</b>
<b>Set Commands.....</b>	<b>50</b>
#DHCP – DHCP On or Off .....	50
#IPADDR – Set Static IP Address .....	50
#IPGATEWAY – Set Gateway Address.....	50
#IPNETMASK – Set Subnet Mask.....	51
#DNSSERV1 – Set DNS Server IP Address .....	51
#DNSSERV2 – Set Secondary DNS Server.....	51
#EMACSPD – Set Ethernet Connection .....	51
#HOSTNAME – Configure the DHCP Client Host Name .....	52
<b>Display Commands .....</b>	<b>52</b>
#ETHIFSTATUS – View Network Interface Settings .....	52
#VDNS – Display Configuration of DNS Servers.....	52
#VIP – View Address Settings .....	53
<b>Chapter 9 – Auto Discovery AT Commands for the SocketEthernet IP .....</b>	<b>54</b>
<b>Set Commands.....</b>	<b>54</b>
#AUTODISC – Auto Discovery On/Off.....	54
#AUTODISCTIMER – Auto Discovery Timer.....	54
#AUTODISCPORT – Auto Discovery Port.....	54
#AUTODISCHOST – Set Auto Discover Host Name .....	54
#AUTODISCUERNAME – Set Auto Discover User Name.....	55
#AUTODISCPASSWORD – Sets Auto Discover Password.....	55
<b>Display Command .....</b>	<b>55</b>
#VAUTODISC – Display Auto Discovery Commands .....	55
<b>Part 3 – AT Commands for SocketWireless Wi-Fi Devices.....</b>	<b>56</b>
<b>Chapter 10 – IP AT Commands for the SocketWireless Wi-Fi.....</b>	<b>57</b>
<b>Set Commands.....</b>	<b>57</b>
#DHCP – DHCP On or Off .....	57
#IPADDR – Set Static IP Address .....	57
#IPGATEWAY – Set Gateway Address.....	57
#IPNETMASK – Set Subnet Mask.....	58
#IPDNSSERV – Configure the DNS Server .....	58
#DNSSERV1 – Set DNS Server IP Address .....	58
#DNSSERV2 – Set Secondary DNS Server.....	58
#IPRELEASE – Release a DHCP Address Assigned by the Server.....	59
#IPRENEW – Renew the DHCP Information from the Server.....	59
#IPQUERY – Give a Domain Name .....	59
#IPRESOLV – Is There a Connection with DNS or Not.....	59
S0= – Automatic Answer.....	59

<b>Display Commands .....</b>	<b>60</b>
#IPDNSTABLE – Display DNS Table .....	60
#VDNS – Display Configuration of DNS Servers.....	60
#VIP – View Address Settings .....	60
<b>Chapter 11 – General AT Commands for the SocketWireless Wi-Fi.....</b>	<b>61</b>
<b>Set Commands.....</b>	<b>61</b>
A – Manual Answer of TCP or UDP Connection .....	61
S2 – Escape Sequence.....	61
A/ – Previous Command .....	61
#BOOTMSG – Enable/Disable Boot Message .....	62
#WATCHDOG – Enable/Disable Watchdog .....	62
#WATCHDOGTIMER – Watchdog Timer.....	62
<b>Chapter 12 – Telnet AT Commands for the SocketWireless Wi-Fi and the SocketEthernet IP.....</b>	<b>63</b>
<b>Set Commands.....</b>	<b>63</b>
#TELNET – Start/Stop Telnet Session .....	63
#TELNETPORT – Set Telnet Port .....	63
#TELNETUSER – Set Telnet User .....	63
#TELNETPASSWORD – Set Telnet Password .....	64
<b>Display Command .....</b>	<b>64</b>
#VTELNET – View Telnet Settings .....	64
<b>Chapter 13 – WLAN AT Commands for the SocketWireless Wi-Fi .....</b>	<b>65</b>
<b>Set Commands.....</b>	<b>65</b>
#WLANSECURITYMODE – Security Mode of WLAN Module .....	65
#WLANNETWORKMODE – WLAN Network Mode.....	65
#WLANCOUNTRYCODE – Country Code .....	65
#WLANSANMODE – Scanning Mode.....	66
#WLANSSID – SSID of WLAN .....	66
#WLANDATARATE – WLAN Transmission Data Rate .....	66
#WLANIBSSCHANNEL – Channel for Ad-Hoc Mode .....	66
#WLANCONNECT – Connect with AP .....	67
#WLANDISCONNECT – Disconnect with AP .....	67
#WLANENABLE – Auto Connect Module with AP .....	67
#WLANDOZE= – Moves Module into or out of Power Save .....	67
#WLANPROFILEn=n – Change the WLAN Profile.....	68
#WLANSCAN – Scan Wireless Networks.....	68
#WLANUSEPROFILE – User Profile .....	69
#WLANGETRSSI – Received Signal Strength .....	69
#WLANACTIVATE – Move Module out of Power Save .....	69
#WLANROAM – Enable/Disable Roaming .....	69
#WEP64KEY – Keys for WEP64 Security Mode .....	69
#WEP128KEY – Keys for WEP128 Security Mode .....	70
#WPAPSKKEY – Keys for WPA PSK Security Mode.....	70
#WPA2PSKKEY – Keys for WPA2 PSK Security Mode.....	70
#WEPKEYID – Set the Default TX Key Index .....	70
#WLANPOWERSAVE – Enable Power Save at Boot .....	70
<b>Display Commands .....</b>	<b>71</b>
#WEP? – See the Value of the WEP Keys .....	71
#WLANPROFILE – Display the WLAN Profile.....	71
#WLAN? – WLAN Module.....	72
#WLANASSOCINFO – Display Association Information .....	72
<b>Part 4 – AT Commands for the SocketModem iCell, SocketModem IP, MultiModem iCell .....</b>	<b>73</b>
<b>Chapter 14 – AT Commands for the SocketModem iCell, SocketModem IP, MultiModem iCell.....</b>	<b>74</b>
<b>Set Commands.....</b>	<b>74</b>
+WOPEN – Set IP Mode or Modem Mode .....	74
#AUTHENT – Authentication Type .....	74

#ANSWERMODE – Set Answering Mode .....	75
#SMSPHRASE – Set Incoming SMS Phrase .....	75
#CALLBACKTIMER – Set Automatic Call-Back Wait .....	76
#CALLSCREENNUM – Set Caller ID Service .....	76
#KEEPALIVEMODE – Keep-Alive Mode .....	76
#KEEPALIVEPORT – Keep-Alive Port Number .....	77
#KEEPALIVESERV – Keep-Alive Server Address .....	77
#KEEPALIVEDELAY – Keep-Alive Delay .....	77
#OUTPORT – UDP/TCP Local Port Number .....	77
#ATCMD – Customize Dial-Up Commands .....	78
#REDIALCOUNT – Set Connection Attempts Allowed .....	78
#REDIALDELAY – Set Call Retry Delay .....	78
#PHYTIMEOUT – Set Inactivity Time .....	78
#RINGCOUNT – Set Number of Rings/Automatic Operation .....	79
#DIALN1 – Set Primary Dial-Up Number .....	79
#DIALN2 – Set Secondary Dial-Up Number .....	79
#DIALSELECT – Set Internet Connection Number .....	80
#ISPPW – Set ISP Password .....	80
#ISPUN – Set ISP User Name .....	80
<b>Incoming Call Management Commands .....</b>	<b>81</b>
#ACCEPT – Answer Incoming Call .....	81
#CONNECTIONSTOP – Stop Communication .....	81
#CONNECTIONSTART – Start Communication .....	82
#AUTOCONNECT – Automatically Connect the PPP Link .....	83
#PPPMODE – Set TCP/IP Behavior .....	83
#PPPMYIP – Set IP Address When Using PPP .....	83
#PPPPEERIP – Set IP Address for Remote PPP .....	83
#PPPSERVUN – Set User Name for Remote PPP Client .....	84
#PPPSERVPW – Set Remote PPP Client Password .....	84
#APNPW – Set Access Point Name Password .....	84
#APNSERV – Set Access Point Name .....	84
#APNUN – Set Access Point User Name .....	84
#GPRSCID – Set PDP Context Identifier .....	85
#GPRS MODE – Activate Switching Between GSM and GPRS .....	85
<b>Display Commands .....</b>	<b>85</b>
#DISPLAYIP – Display IP Addresses .....	85
#VPPP – Display PPP Parameters .....	86
#VPHY – Display Physical Parameters .....	86
<b>Part 5 – GPIO AT Commands .....</b>	<b>87</b>
<b>Chapter 15 – GPIO AT Commands .....</b>	<b>88</b>
<b>About GPIO .....</b>	<b>88</b>
#GPIO – Enable/Disable and Configure External GPIO Driven Events .....	88
#GPIOR – Read the Current Register Status of the Specified GPIO Pin .....	89
#GPIOtrigger – Configure the GPIO pin and trigger type .....	90
<b>Part 6 – AT Commands for GPS-Enabled Device .....</b>	<b>91</b>
<b>Chapter 16 – AT Commands for GPS-Enable Products .....</b>	<b>92</b>
#GPSSERV – Set GPS Host Server Address .....	92
#GPSPORT – Set GPS Host Port .....	92
#GPSPROTO – Set GPS Host Protocol .....	92
#GPSPREFIX – Set GPS Message Prefix .....	92
#GPSURAIS – Set GPS Unique Remote Asset Identification String .....	93
#GPSINTERVAL – Set GPS Server Transmission Interval .....	93
#GPSPW – Set GPS Host Login Password .....	93
#GPSGPGGA – Enable/Disable GPGGA Message .....	93
#GPSGPGLL – Enable/Disable GPGLL Message .....	94
#GPSGPGSA – Enable/Disable GPGSA Message .....	94
#GPSGPGSV – Enable/Disable GPGSV Message .....	94

---

#GPSGPRMC – Enable/Disable GPRMC Message.....	94
#GPSGPVTG – Enable/Disable GPVTG Message .....	95
#GPSINTERVALLOC – GPS Local Transmission Interval.....	95
#GPSGETMESSAGE – Get Queued GPS Message .....	95
<b>GPS Message Syntax .....</b>	<b>96</b>
<b>GPS Message Examples .....</b>	<b>96</b>
<b>GPS Configuration Examples.....</b>	<b>97</b>
<b>Application Note – GPS NMEA Messages .....</b>	<b>98</b>
Introduction .....	98
NMEA Protocol Overview.....	98
SUPPORTED MESSAGE LIST .....	99
NMEA MESSAGES.....	99
GGA – Global Positioning System Fix Data.....	99
GLL – Latitude/Longitude.....	100
GSA – GNSS DOP and Active Satellites .....	100
GSV – GNSS Satellites in View .....	101
RMC – Recommended Minimum Specific GNSS Data .....	102
VTG – Course Over Ground and Ground Speed.....	102
<b>Part 7 – Appendixes.....</b>	<b>103</b>
<b>Appendix A – Response Messages &amp; Error Codes .....</b>	<b>104</b>
<b>Response Messages .....</b>	<b>104</b>
<b>Error Codes .....</b>	<b>105</b>
<b>Appendix B – Response Message Examples.....</b>	<b>106</b>
<b>Response Messages Examples .....</b>	<b>106</b>
Sending/Retrieving Email Response Messages .....	106
FTP: Download / Upload Files Response Messages .....	108
TCP Socket Response Messages .....	109
<b>Index .....</b>	<b>110</b>

# **Part 1 – AT Commands for All Universal IP Devices**

**Chapter 1 – General AT Commands for the All Universal IP Devices**

**Chapter 2 – SMTP AT Commands for All Universal IP Devices**

**Chapter 3 – POP3 AT Commands for All Universal IP Devices**

**Chapter 4 – FTP AT Commands for All Universal IP Devices**

**Chapter 5 – TCP AT Commands for All Universal IP Devices**

**Chapter 6 – UDP AT Commands for All Universal IP Devices**

**Chapter 7 – PING AT Commands for All Universal IP Devices**

# Chapter 1 – General AT Commands for All Universal IP Devices

## Set Commands

### AT – Command Mode

**Description:** If the modem responds OK to an **AT** command, the modem is likely in command mode. Many commands will respond with ERROR when the modem is connected to the network.

### E – Turn Echo ON/OFF

**Description:** Use this command to turn ON/OFF echoing command at the serial terminal.

**Syntax:** **ATE[<setting>]**

**Values:** 0 – turn echo off.  
1 – turns echo on.

### I – Identification

**Description:** Displays identification parameters.

**Syntax:** **ATI[<value>]**

**Responses:** For MT100SEM: "1.00 to 1.00g"  
For MT810SWM-IP: "1.xx" (Note: "xx" is the number.)  
OK  
**Values:** 3 – Identifies the firmware version.  
Example: Version:MT810swm Release V1.0 (12-August-09)  
OK  
5 – Identifies the country.  
Example: "B5" (MT100SEM example)

### V – Terse or Verbose

**Description:** Sets terse or verbose responses.

**Syntax:** **ATV[<value>]**

ATV? Displays the current **V** setting or use AT#VALL to view all settings.

**Values:** 0 – Sets terse mode (ATV also sets terse mode)  
1 – Sets verbose mode

**Default:** ATV1

## Z – Default Configuration

**Description:** This command restores the configuration profile from NVM. Settings are recalled on power up.  
**Syntax:** ATZ  
**Response:** OK (Command valid)

## &C – RLSD (DCD) Option Turn On or Off

**Description:** The modem controls the RLSD output in accordance with the parameter supplied. This command sets the DCD On or Off.  
**Syntax:** AT&C[<value>]  
AT&C? Read or show the current value.  
**Values:** 0 – Sets DCD to remain On at all times.  
1 – Sets DCD to follow the physical connection.  
2 – DCD follows the state of the TCP/UDP connection.  
**Default:** 1  
**Response:** OK  
Otherwise ERROR

## &D – DTR Option

**Description:** The modem reads the DTR to determine if the Data Terminal is Ready. This command allows the modem to act on the DTR.  
**Syntax:** AT&D[<value>]  
AT&D? Read or show the current value.  
**Values:** 0 – DTR is ignored (AT&D with no parameter).  
1 – An Active to Inactive transition disconnects an active TCP/UDP connection  
2 – (For Non-MT100SEM) An active to inactive transition disconnects the physical connection  
**Default:** 0  
**Response:** OK  
Otherwise ERROR

## &F – Reset Factory Defaults

**Description:** **For MT100SEM:** This command replaces all settings with the factory defaults but does not store them to memory. Use &W to store them to the memory.  
**For NON-MT100SEM:** This command replaces the factory defaults of &D, &S, &C, E, and V only.  
**Note:** The module must be RESET to put this command into effect.  
**Syntax:** AT&F  
**Values:** None/No parameters

## &S – DSR ON or OFF

**Description:** This command sets the DSR to ON or OFF.  
**Syntax:** AT&S[<value>]  
AT&S? Read or show the current value.  
**Values:** 0 – Sets DSR to remain ON at all times  
1 – Sets DSR to follow DCD  
2 – DSR follows the state of the TCP/UDP connection  
**Default:** 1  
**Response:** OK  
Otherwise ERROR

## &W – Store Factory Defaults to NVM

**Description:** **For MT100SEM:** Stores factory defaults to the NVM.  
**For NON-MT100SEM:** Stores the current settings of &D, &S, &C, E, and V only.

**Syntax:** AT&W  
**Values:** None

## +ICF – DTE-DCE Character Framing

**Description:** This command determines the local serial port start-stop (asynchronous) character framing that the DCE uses

**Syntax:** AT+ICF=[<format value>],[<parity value>]

AT+ICF? Read or show the current value.

**Values:** <format>

- 0 – Autodetect (not supported)
- 1 – 8 Data 2 Stop (supported)  
 <parity> parameter is ignored
- 2 – 8 Data 1 Parity 1 Stop (supported)  
 If no <parity> provided, 3 is used by default as <parity> value
- 3 – 8 Data 1 Stop (supported)  
 <parity> parameter is ignored
- 4 – 7 Data 2 Stop (supported)  
 <parity> parameter is ignored
- 5 – 7 Data 1 Parity 1 Stop (supported)  
 If no <parity> provided, 3 is used by default as <parity> value
- 6 – 7 Data 1 Stop (supported)  
 <parity> parameter is ignored

**<parity>**

- 0 – Odd (supported)
- 1 – Even (supported)
- 2 – Mark (supported)
- 3 – Space (supported)
- 4 – None (supported)

**Default:** Format: 2

Parity: 4

**Examples:**

+ICF input values		Resulting affect		
Format	Parity	Data bits	Stop bits	Parity
1	0-4, blank (ignored)	8	2	None
2	0-4, blank	8	1	0-4; 3 if the input is left blank
3	0-4, blank (ignored)	8	1	None
4	0-4, blank (ignored)	7	2	None
5	0-4, blank	7	1	0-4; 3 if the input is left blank
6	0-4, blank (ignored)	7	1	None

**Note:** The input for the command always requires the format value. However, the parity value is optional and will be set as defined in the table.

### +IFC – Set Flow Control

**Description:** Turns flow control on and off.  
**Syntax:** **AT+IFC=<flow control value>**  
**Values:** **0,0** Flow Control Off  
          **2,2** Hardware Flow Control On  
**Default:** **2,2** Hardware Flow Control On

### +IPR – Set Serial Speed

**Description:** Sets the serial speed.  
**Syntax:** **AT+IPR=<serial speed value>**  
**Values:** **300** to **921600**  
**Display:** AT+IPR? Displays the current serial speed.  
          AT+IPR=? Displays a list of all possible values (serial speeds).  
**Default:** For All Products: **115200**

### #AUTORESET - Reset the Processor at a Given Time

**Description:** Set an amount of time when the modem will reset after no input has been detected on the serial port.  
**Note:** This command is not supported on the SocketEthernet IP (MT100SEM-IP).  
**Syntax:** **Set Value:** AT#AUTORESET=<time in minutes>  
          **View Values:** AT#AUTORESET? or AT#VALL  
**Values:** 0-65535 the time in minutes  
          From 1 to 5 numeric digits (0 to 9).  
**Default:** **0**

### #DELFLASH – Erase Flash Memory Parameter Values

**Description:** This command erases the contents of the flash memory and loads with defaults values.  
**Syntax:** **AT#DELFLASH**  
**Values:** No parameter values.

## #LEGACYMODE – Legacy Mode Enable/Disable

### About Legacy Mode:

**Note: This command is for all devices except the SocketEthernet IP (MT100SEM-IP)**

Legacy mode allows for smoother transition to TCP/IP based connectivity from standard analog interface connections.

When #LEGACYMODE=1, the stack will be in pseudo legacy mode where the commands &S, &D, &C, A, D, S0, E, V operate independently of the stack. The commands will be saved to a different NVRAM location and will not affect the IP stack once legacy mode has been exited.

Once in legacy mode, the user can configure the #TCP values and issue an ATD command to make a connection to the remote host. If necessary, the user can also issue

ATDxxxxxxxxxxxxpppp where x is the decimal address and pppp is the remote port. The stack will perform the physical connection and present the user with the proper messages:

NO CARRIER  
NO ANSWER  
CONNECT  
OK  
ERROR

**Description:** If legacy mode is enabled, the AT interface tries to behave like a legacy analog modem. ATD and ATA will function on the TCP stack instead of the physical connection. Responses will behave like that of an analog modem.

**Syntax:** **Set Value:** AT#LEGACYMODE=1

**View Values:** AT#LEGACYMODE?

**Values:** 0 Disable legacy mode  
1 Enable legacy mode

**Default:** 0

## #RESET – Reset Main Processor or Internal Modem

**Description:** This command will force a reset on the Stack and internal radio or just the internal radio.

**Syntax:** AT#RESET =<value>

**Values:** 0 Reset the Stack and internal modem  
1 Reset the internal modem only.

**Note: This value is not valid for the SocketEthernet IP (MT100SEM-IP) and the SocketWireless Wi-Fi (MT810SWM-IP)**

**Example:** AT#RESET=0

**Note:** After issuing AT#RESET, it can take up to 45 seconds before the MT810SWM-IP is ready to accept AT Commands. When configuring the MT810SWM-IP using security mode WPA or WPA2, the bootup time will take longer.

## #SHIELDCHAR – Configure the Shielding Character for DLEMODE

**Description:** This parameter defines the shield character for the clients that use shielding (also known as DLE shielding with regards to UIP).

**Note: This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)**

**Syntax:** AT#SHIELDCHAR=[<parameter1>]

AT#SHIELDCHAR?

**Values:** 0-255 (an integer value between 0 and 255)

**Responses:**  
'\r\n#SHIELDCHAR: VALUE\r\n'\r\nOK\r\n'\r\nERROR\r\n'

**Examples:**

send: AT#SHIELDCHAR=20\r

reply: '\r\nOK\r\n'

send: AT#SHIELDCHAR?\r

reply: '\r\n#SHIELDCHAR: 20\r\n'

reply: '\r\nOK\r\n'

## #ESCAPECHAR – Configure the Escape Character for DLEMODE

**Description:** This parameter defines the escape character for the clients that use an escape character (also known as DLE shielding with regards to Universal IP).

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#ESCAPECHAR=<parameter1>

AT#ESCAPECHAR?

**Values:** 0-255; Integer value between 0 and 255

**Responses:** \r\n#ESCAPECHAR: VALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#ESCAPECHAR=3\r

**reply:** \r\nOK\r\n

**send:** AT#ESCAPECHAR?\r

**reply:** \r\n#ESCAPECHAR: 3\r\n

**reply:** \r\nOK\r\n

## Display Commands

### #VSHOWSERIAL – Display RS-232 Signal Status of the User Serial Port

**Description:** Displays the RS-232 signal status; used for engineering.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#VSHOWSERIAL

**Values:** na

**Responses:** \r\nSERIAL information\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#VSHOWHARDWARE\r

**reply:** \r\n+-----+\r\n

**reply:** \r\n| Serial EIA Signal Status (DCE interface) |\r\n

**reply:** \r\n+-----+\r\n

**reply:** \r\n| CTS : ON |\r\n

**reply:** \r\n| DSR : OFF |\r\n

**reply:** \r\n| DCD : OFF |\r\n

**reply:** \r\n| RTS : ON |\r\n

**reply:** \r\n| DTR : ON |\r\n

**reply:** \r\n+-----+\r\n

**reply:** \r\nOK\r\n

## #VSHOWUPTIME – Displays the Current Uptime in Days, Hours, Minutes, Seconds

**Description:** Displays the current uptime of the UIP stack.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#VSHOWUPTIME

**Values:** na

**Responses:** \r\nVALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#VSHOWUPTIME\r

**reply:** \r\n00000:00:03:46\r\n

**reply:** \r\nOK\r\n

## #VSHOWUPTIMES – Displays the Current Uptime in Seconds

**Description:** Displays the current uptime of the UIP stack in seconds.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#VSHOWUPTIMES

**Values:** na

**Responses:** \r\nVALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#VSHOWUPTIMES\r

**reply:** \r\n304\r\n

**reply:** \r\nOK\r\n

## #VVERSION – Display Software Version

**Description:** This command directs the TCP/IP stack to display the software version.

**Syntax:** AT#VVERSION

**Values:** No TCP/IP parameters.

## #VSTATE – Display Current State of Physical Connection

**Description:** This command displays the status of the physical network connection.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Syntax:** AT#VSTATE

**Possible Responses:**

#STATE: "IDLE"	Physical connection is idle and ready to connect
#STATE: "DIALING"	Physical connection is attempting to contact the network
#STATE: "AUTHENTICATING"	Physical connection is complete; PPP authentication is being performed
#STATE: "CONNECTED"	Physical connection is complete and PPP negotiation is complete; stack is ready for client commands
#STATE: "DISCONNECTING"	Physical connection is in the process of disconnecting from the network
#STATE: "DISCONNECTED"	Physical connection is disconnected from the network (Only used on the MT100SEM-IP)
#STATE: "CHECKING"	Checking current status; try again

## #VALL – Display All Parameters

**Note:** The MT100SEM display of Possible Responses differs slightly from the MT5692SMI-IP display. An example of the **MT100SEM Possible Responses** screen is included on this page. See the next page for an example of the other **Possible Responses** screen.

**Description:** This command directs the TCP/IP stack to display all AT# parameters. The parameters are displayed by blocks of categories separated by a <CR><LF> sequence, all at the same time.

**Syntax:** AT#VALL

Possible Responses – <i>MT100SEM-IP</i>	
#FTPGETFILENAME: " " #FTPGETPATH: " " #FTPMODE: 0 #FTPPORT: 21 #FTPPUTFILENAME: " " #FTPPUTPATH: " " #FTPPW: "ftppassword" #FTPSERV: " " #FTPTYPE: 1 #FTPUN: "ftplogin"  #POP3HEADERMODE: 1 #POP3PORT: 110 #POP3PW: "password" #POP3SERV: "pop3.domain.com" #POP3UN: "module@domain.com"  #DOMAIN: "domain.com" #SENDERADDR: "module@domain.com" #SENDERNAME: "Test module" #SMTPPORT: 25 #SMTPPW: " " #SMTPSERV: "smtp.domain.com" #SMTPUN: " " #SMTPAUTH: 1  #BODY1: " " #CCREC1: " " #REC1: " " #SUBJ1: "Email Subject"  #BODY2: " " #CCREC2: " " #REC2: " " #SUBJ2: " "  #BODY3: " " #CCREC3: " " #REC3: " " #SUBJ3: " "  #DLEMODE: 1 , 1 #TCPSERV: 1 , " " #TCPPORT: 1 , 0 #TCPTXDELAY: 1 , 100 #DLEMODE: 2 , 1 #TCPSERV: 2 , " " #TCPPORT: 2 , 0 #TCPTXDELAY: 2 , 100  #UDPSERV: 1 , " " #UDPPORT: 1 , 0 #UDPTXDELAY: 1 , 100 #UDPSERV: 2 , " " #UDPPORT: 2 , 0 #UDPTXDELAY: 2 , 100	#PINGDELAY: 1 #PINGNUM: 4 #PINGREMOTE: " "  #DHCP: 0 #IPADDR: "192.168.2.3" #IPGATEWAY: "192.168.2.1" #IPNETMASK: "255.255.255.0" #EMACSPD: 0 #DNSSERV1: "0.0.0.0" #DNSSERV2: "0.0.0.0"  #TELNET: 0 #TELNETPORT: 23 #TELNETUSER: "admin" #TELNETPASSWORD: " "  +IPR: 115200 +ICF: 2,4  +IFC: 2,2  #AUTODISC: 1 #AUTODISCPORT:1020 #AUTODISCTIMER: 10 #AUTODISCHOST: "MT100SEM" #AUTODISCUSER: "admin" #AUTODISCPASSWORD: " "  V: 1 &S: 0 &C: 0  OK

**Syntax:****AT#VALL**

<b>Possible Responses – Applies to All Except MT100SEM-IP</b>	
#ANSWERMODE: 0 #CALLBACKTIMER: 2 #CALLSCREENNUM: "0" #DIALN1: "" #DIALN2: "" #DIALSELECT: 1 #GPRSMODE: 1 #PHYTIMEOUT: 15 #REDIALCOUNT: 0 #REDIALDELAY: 5 #RINGCOUNT: 0 #AUTOCONNECT: 0 #ISPUN: "" #ISPPW: "" #PPPMODE: 3 #PPPMYIP: 0.0.0.0 #PPPPEERIP: 0.0.0.0 #PPPSERVPW: "" #PPPSERVUN: "" #APNPW: "" #APNSERV: "" #APNUN: "" #GPRSCID: 1 #DNSSERV1: "0.0.0.0" #DNSSERV2: "0.0.0.0" #FTPGETFILENAME: "" #FTPGETPATH: "" #FTPPORT: 21 #FTPPUTFILENAME: "" #FTPPUTPATH: "" #FTPPW: "" #FTPSERV: "" #FTPTYPE: I #FTPUN: "" #FTPMODE: 0 #POP3HEADERMODE: 1 #POP3PORT: 110 #POP3PW: "" #POP3SERV: "" #POP3UN: "" #DOMAIN: "" #SENDERADDR: "" #SENDERNAME: "" #SMTPPORT: 25 #SMTPPW: "" #SMTPSERV: "" #SMTPUN: "" #BODY1: "" #CCREC1: "" #REC1: "" #SUBJ1: "" #BODY2: "" #CCREC2: "" #REC2: "" #SUBJ2: "" #BODY3: "" #CCREC3: "" #REC3: "" #SUBJ3: "" #DLEMODE: 1,1 #TCPPORT: 1,0 #TCPSERV: 1,""	#TCPTXDELAY: 1,100 #UDPPORT: 0 #UDPSERV: "" #UDPTXDELAY: 100 #PINGDELAY: 1 #PINGNUM: 4 #PINGREMOTE: "" #AUTHENT: NONE +IPR: 115200 +ICF: 2,4 +IFC: 2,2 V: 1 E: 1 &S: 1 &C: 1 &D: 0 #KEEPALIVEMODE: 0 #KEEPALIVEPORT: 0 #KEEPALIVEDELAY: 100 #KEEPALIVESERV: "" #LEGACYMODE: 0 #AUTORESET: 0 #ATCMD: 1,"" #ATCMD: 2,"" #ATCMD: 3,"" #ATCMD: 4,"" #PERSISTENTSOCKET: 0 #OUTPORT: 37500 #GPIO: 1,1,0,0,0,0 #GPIO: 2,1,0,0,0,0 #GPIO: 3,0,0,0,0,0 #GPIO: 4,0,0,0,0,0 #GPIO: 5,3,0,0,0,0 OK

# Chapter 2 – SMTP AT Commands for All Universal IP Devices

## Set Commands

### #SENDERNAME – Set Sender Name

- Description:** The sender's literal name (different from the SENDERADDR parameter, which is the sender's email address). This parameter will appear in the header of the email sent by the TCP/IP stack software, in the field: "From:"
- Syntax:** **AT#SENDERNAME=<value>**  
AT#SENDERNAME? Read or display current value (also AT#VSMTPL or AT#VALL).
- Values:** Alphanumeric ASCII text string up to 120 characters. The address must be provided in literal format (for instance, "machine 245"). No default.

### #SENDERADDR – Set Sender Address

- Description:** To send emails, the TCP/IP stack software must know the email address of the sender. The "sender" is the email identification of the hardware platform itself or the optional attached equipment. This email address will appear in the header of the email sent by the TCP/IP stack software, in the field "From:"
- Syntax:** **AT#SENDERADDR=<value>**  
AT#SENDERADDR? Read or display current value (also AT#VSMTPL or AT#VALL).
- Values:** Alphanumeric ASCII text string up to 60 characters. The address must be provided in literal format (for instance xxxxxxxx@web.zyx). No default.

### #CCRECi – Set Additional Recipient CC

- Description:** The software can send email messages to an additional recipient as a "carbon copy". This parameter contains the email address of the additional recipient. This email address will appear in the header of the email sent by the TCP/IP stack software in the field "Cc:"  
For a given value n, the CCRECn parameter is directly associated with the RECx parameter.
- Syntax:** **AT#CCRECi=<value>**  
AT#CCRECi? (replace i with 1, 2, or 3) or AT#VMAILi, AT#VALL
- Values:** CCRECi (i = 1, 2, or 3)  
Alphanumeric ASCII text string up to 120 characters. The address must be provided in literal format (for instance xxxx@web.com). No default.

## #DOMAIN – Set Domain Name of the Sender

**Description:** When sending an email message, the TCP/IP stack software must provide the SMTP server with the domain name of the sender. In some cases, this domain name may be different from the domain name included in the sender's email address.

**Syntax:** **AT#DOMAIN=<value>**

AT#DOMAIN? Read or display current value (also AT#VSMTP or AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #RECiADD – Set Email Address

**Description:** To send email messages, the TCP/IP stack software must know the e-mail address of the recipient. This email address will appear in the email header sent by the TCP/IP stack software, in the field 'To':

The RECi parameter can hold a maximum of 10 email addresses, each email address being at the most 120 characters long.

**Syntax:** **AT#RECi=<Value>**

AT#RECi? (replace i with 1, 2, or 3) or AT#VMAILi, AT#VALL

**Values:** RECi (i = 1, 2, or 3)

Alphanumeric ASCII text string up to 120 characters. The address must be provided in literal format (for instance xxxx@company.com). No default.

### Setting One Email Address / Resetting the Parameter / Getting:

Set value / reset the parameter: AT#RECi=<Value>" (replace i with 1, 2, or 3)

View value: AT#REC? (replace i with 1, 2, or 3) or AT#VMAILi, AT#VALL

### Setting One to Ten Email Address to the RECi Parameter / Resetting the Parameter:

To set 1 to 10 email addresses to the RECi parameter, enter the AT#RECiADD<CR> overwriting command.

Each email address has to be an alphanumeric ASCII text string, in literal format (for instance, dev12345678@web.xyz). To add another email address, enter the <CR><LF> pair. To end the setting, enter the following character: 1A (in ASCII code), generated in a keyboard by CTRL+Z escape sequence.

**Note 1:** This command overwrites all previously set email addresses of the RECi parameter.

**Note 2:** If more than ten addresses are entered, the 11th and subsequent addresses until the end character will be ignored.

**Example:** AT#REC1ADD<CR>

Email1@domain.fr<CR><LF>

Email2@domain.com<CR><LF>

<CTRL+Z>

## #SUBJi – Set Email Pre-Defined Subject Text

**Description:** These parameters contain the pre-defined subject text that will be used by the TCP/IP stack to compose the email header.

**Syntax:** **AT#SUBJi=<value>** (replace i with 1, 2, or 3)

AT#SUBJ? (replace i with 1, 2, or 3) or AT#VMAILi, AT#VALL

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #BODYi – Set Pre-Defined Email Combinations

- Description:** These parameters store pre-defined message bodies. They allow the host application to send pre-defined email combinations.
- Syntax:** **AT#BODY<value>** Interactive mode enter the body followed by CTRL-Z  
**AT#BODY<value>=<string>** Set the Body<value> string to "<string>"  
**AT#BODY<value>?** Read or display the current setting of BODY<value>
- Values:** 1 – 3 Predefined email message body  
The body content has to be entered after the AT#BODY1<CR> command. It has to be an alphanumeric ASCII text string up to 120 characters followed this character: 1A (in ASCII code) and generated on a keyboard by CTRL+Z. No default.
- Example:** AT#BODY1<CR>  
Text string  
<CTRL+Z>

## #SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value

- Description:** This parameter determines the inactivity time in seconds of the TCP TX buffer.  
**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)
- Syntax:** **AT#SMTPNETWORKTIMER=<parameter1>**
- Values:** 0-65535 – the time in seconds the client will wait for the TCP available TX buffer to be greater than 0. A setting of 0 will disable the function.
- Responses:** \r\n#SMTPNETWORKTIMER: VALUE1\r\n  
\r\nOK\r\n  
\r\nERROR\r\n
- Examples:**  
**send:** AT#SMTPNETWORKTIMER=100\r  
**reply:** \r\nOK\r\n  
**send:** AT#SMTPNETWORKTIMER?\r  
**reply:** \r\n#SMTPNETWORKTIMER: 100\r\n  
**reply:** \r\nOK\r\n

## #SMTPPORT – Set SMTP Server Port

- Description:** To reach the SMTP server, the TCP/IP stack software must know the port of the SMTP server used for sending email.  
Note: This parameter should be changed only by your network administrator since it depends on network infrastructure configuration including firewalls, proxy or specific TCP port translation settings.
- Syntax:** **AT#SMTPPORT=<value>**  
**AT#SMTPPORT?** Read or display the current setting (or AT#VSMP, AT#VALL).
- Values:** From 1 to 5 digits (each digit between 0 and 9 inclusive). Note that numbers above 65,535 are illegal as the port identification fields are 16 bits long in the TCP header.
- Default:** 25

## #SMTPPW – Set SMTP Password

- Description:** To send email messages, some SMTP servers are using an authentication process. In these cases, the TCP/IP stack software will provide the SMTP password (associated to the SMTP user name) for the email sending process.  
If this parameter is an empty string, the authentication mode is inactive.  
If both this parameter and the SMTPUN parameter are not empty, the authentication mode is active.
- Syntax:** **AT#SMTPPW=<value>**  
AT#SMTPPW? Read or display the current setting (or AT#VSMTPL, AT#VALL).
- Values:** Alphanumeric ASCII text string up to 64 characters. No default.

## #SMTPSERV – Set SMTP Server Address

- Description:** To send email messages the TCP/IP stack software must know the address of the SMTP server that is to be used. In most cases, the local ISP maintains the SMTP server.
- Syntax:** **AT#SMTPSERV=<value>**  
AT#SMTPSERV? Read or display the current setting (or AT#VSMTPL, AT#VALL).
- Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or  
Alphanumeric ASCII text string up to 120 characters if DNS is available. No default.

## #SMTPUN – Set SMTP User Name

- Description:** To send email messages, some SMTP servers use an authentication process. In these cases, the TCP/IP stack software will provide the SMTP user name (associated with a SMTP password) for the email sending process.  
If this parameter is an empty string, the authentication mode is inactive. If both this parameter and the SMTPPW parameter are not empty, the authentication mode is active.
- Syntax:** **AT#SMTPUN=<value>**  
AT#SMTPUN? Read or display the current setting (or AT#VSMTPL, AT#VALL).
- Values:** Alphanumeric ASCII text string up to 64 characters. No default.

## #SENDMAIL*i* – Send Mail without Interactive Mode

**Important Note:** MT5692SMI-IP supports only SENDMAIL1 options.

**Description:** This command sends one of the 3 pre-defined email combinations. Once an IP link is established, the attached host can direct the TCP/IP stack to send an email message at any time (except when the TCP/IP stack software is already in a process using TCP resources).

The header of this email is built using the REC1/2/3, CCREC1/2/3 and SUBJ1/2/3 parameters while the body is filled in the BODY1/2/3 parameter.

This command is similar to a “send email” operation issued by a standard messaging client on a PC.

**Syntax:** AT#SENDMAIL*i*

**Example:** **Note:** In #SENDMAIL*i*, the *i* is to be replaced with #SENDMAIL1, #SENDMAIL2, or #SENDMAIL3.

Command	Possible Responses
AT#SENDMAIL1 Note: Send predefined mail #1	<b>OK</b> Note: Mail 1 has been successfully sent
AT#SENDMAIL2 Note: Send predefined mail #2	<b>OK</b> Note: Mail 2 has been successfully sent
AT#SENDMAIL3 Note: Send predefined mail #3	<b>OK</b> Note: Mail 3 has been successfully sent
AT#SENDMAIL2	<b>#CME ERROR: 38027</b> Notes: The address of the SMTP server has not been resolved by the secondary DNS server. TCP/IP stack is not able to reach the primary or secondary DNS servers or a wrong SMTP server address has been entered.
AT#SENDMAIL1	<b>#CME ERROR: &lt;value&gt;</b> Notes: An error has occurred during the communication with the remote SMTP server. It may also happen during the data transfer (after the OK message). This error can be due to one of the following reasons: - The DNS servers are not able to resolve the SMTP server address - The SMTP server is temporarily out of service - The authentication (SMTPUN, SMTPPW) is not valid - Email address specified in REC1 or CCREC1 is not valid See section ‘Response messages and error codes’.

To view parameters, use #VMAIL and #VSIMTP. They are also listed in #VMAIL*i* (where *i* = 1, 2, or 3)

## #PUTMAIL – Send Mail to Recipient with Interactive Mode

**Description:** This command allows the attached host to send an email message containing body text passed to the TCP/IP stack over the serial port. Once an IP link is established, the attached host can send an email message at any time (except when the TCP/IP stack software is already in a process using TCP resources).

The header of this email is built using the REC1, CCREC1 and SUBJ1 parameters.

This command is similar to a “send email” operation issued by a standard messaging client on a PC.

**Syntax:** **AT#PUTMAIL**

### IMPORTANT NOTE:

You must issue the <CR><LF> bytes (binary value: 0D 0A) as the first data bytes if a header is NOT being constructed in order to finish the internal headers correctly. This mechanism is in place to allow for the addition of custom headers such as MIME data.

Command	Possible Responses
<b>AT#PUTMAIL</b> Note: You have to configure only receiver address1, copy address1, and subject1 before or during the session, but content (body) of the email is typed when the TCP/IP session is established. Content is not echoed.	Ok_Info_WaitingForData Notes: An SMTP session has been successfully opened with the remote SMTP server. Once the TCP/IP stack has displayed this message, all the data received on the serial port is sent within the email body. The (CR)(LF).(.) (CR)(LF) sequence sent by the attached host indicates the TCP/IP stack the end of the email body.
<b>&lt;CR&gt;&lt;LF&gt;</b> <b>Note:</b> See <a href="#">Important Note</a> above.	
<b>&lt;content&gt;</b> Note: Content is not written when typing	
<b>&lt;CR&gt;&lt;LF&gt; . &lt;CR&gt;&lt;LF&gt;</b> Note: Termination sequence <CR> = <Enter>, <LF> = <Ctrl Enter>	OK Note: The mail has been successfully sent.
<b>AT#PUTMAIL</b>	#CME ERROR: 38027 Notes: The address of the SMTP server has not been resolved by the secondary DNS server. TCP/IP stack is not able to reach the primary or secondary DNS servers or a wrong SMTP server address has been entered.
<b>AT#PUTMAIL</b>	#CME ERROR: <value> Notes: An error has occurred during the communication with the remote SMTP server. It may also happen during the data transfer (after the OK message). This error can be due to one of the following reasons: <ul style="list-style-type: none"><li>- DNS servers are not able to resolve the SMTP server address.</li><li>- SMTP server is temporarily out of service.</li><li>- Authentication (SMTPUN, SMTPPW) is not valid.</li><li>- An email address specified in REC1 or CCREC1 is not valid.</li><li>- n = inactivity period of 50 seconds on the serial port.</li></ul> See section 'Response messages and error codes'

To view parameters, use #VMAIL and #VSMTPL. They are also listed in #VMAILi (where i = 1, 2, or 3)

## #SMTPAUTH – Authentication ON or OFF

**Description:** Turns authentication ON or OFF.

**Syntax:** Set Value: AT#SMTPAUTH=<value>

View Value: AT#SMTPAUTH? or AT#VSSMTP, AT#VALL

**Values:** 0 – OFF

1 – ON

**Default:** 0

## Display Commands

### #VSSMTP – Display SMTP Parameters

**Description:** Directs the TCP/IP stack to display all the AT# parameters related to the email sender configuration.

**Syntax:** AT#VSSMTP

**Example:**

Command	Possible Responses
AT#VSSMTP Note: View SMTP parameters	#DOMAIN: "a2myoper.com" #SENDERADDR: "toto@myoper.com" #SENDERNAME: "toto" #SMTPPORT: 25 #SMTPPW: "mysmtppw" #SMTPSERV: "smtp.a2myoper.com" #SMTPUN: "mysmpun" #SMTPAUTH: 1 OK

### #VMAILi – Display Email Parameters for Respective Mail ID

**Description:** This command directs the TCP/IP stack to display all the AT# parameters related to the email combinations configuration.

**Syntax:** AT#VMAILi (replace i with 1, 2, or 3)

Command	Possible Responses
AT#VMAIL1 Note: View predefined (nb 1) mail header elements	#Body 1= #REC1= #CCREC1= #SUBJ1= OK

# Chapter 3 – POP3 AT Commands for All Universal IP Devices

## Set Commands

### #POP3HEADERMODE – POP3 Header

**Description:** When receiving an email message, the TCP/IP stack can be configured to send or not to send the POP3 header over the serial port. The POP3 header contains the From, Cc and Subject fields.

**Syntax:** **AT#POP3HEADERMODE=<value>**  
AT#POP3HEADERMODE? Read or display the current setting (or AT#VPOP3, AT#VALL).

**Values:** 0 – The email header will not be sent over the serial port while retrieving.  
1 – The email header will be sent over the serial port while retrieving.

**Default:** 1

### #POP3PORT – Set POP3 Server Port

**Description:** To reach the POP3 server, the TCP/IP stack software must know the port of the POP3 server used for retrieving email.

**Note:** This parameter should be changed only by your network administrator since it depends on network infrastructure configuration including firewalls, proxy or specific TCP port translation settings.

**Syntax:** **AT#POP3PORT=<value>**  
AT#POP3PORT? Read or display the current setting (or AT#VPOP3, AT#VALL).

**Values:** 5 digits (each digit between 0 and 9 inclusive). Note that numbers above 65,535 are illegal as the port identification fields are 16 bits long in the TCP header.

**Default:** 110

### #POP3PW – Set POP3 Password

**Description:** Password for POP3 account. To retrieve email messages sent to a specified email address, the TCP/IP stack software must know the POP3 password that has been set for that email account.

**Syntax:** **AT#POP3PW="<value>"**  
AT#POP3PW? Read or display the current setting (or AT#VPOP3, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 64 characters. No default.

### #POP3SERV – Set POP3 Server Address

**Description:** To retrieve email messages, the TCP/IP stack software must know the address of the POP3 server that is to be used. The POP3 server must be the one where the specified email account is hosted (which is not necessarily maintained by the local ISP).

**Syntax:** **AT#POP3SERV="<value>"**  
AT#POP3SERV? Read or display the current setting (or AT#VPOP3, AT#VALL).

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or  
Alphanumeric ASCII text string up to 120 characters if DNS is available. No default.

## #POP3UN – Set POP3 User Name

- Description:** User name for POP3 account. To retrieve email messages sent to a specified email address, the TCP/IP stack software must know the POP3 user name that has been set for that email account.
- Syntax:** **AT#POP3UN=<value>**  
AT#POP3UN? Read or display the current setting (or AT#VPOP3, AT#VALL).
- Values:** Alphanumeric ASCII text string up to 64 characters. No default.

## #GETMAIL – Retrieve Host Mail

- Description:** This command allows the attached host to direct the TCP/IP stack to retrieve the first mail present in the POP3 server list. Once an IP link is established, the attached host can retrieve an email message at any time (except when the TCP/IP stack software is already in a process using TCP resources). This command is similar to a “check email box” feature issued by a standard messaging client on a PC.

**Syntax:** **AT#GETMAIL**

Command	Possible Responses
AT#GETMAIL  Note: Retrieve mail	Ok_Info_Mail <mail content> <b>Notes:</b> This message is issued when one email message is located in the specified POP3 mailbox. Depending on the #POP3HEADERMODE parameter, the TCP/IP stack sends the email header over the serial port to the attached host. The (CR)(LF).(.) (CR)(LF) sequence indicates the end of the email body.
AT#GETMAIL	Ok_Info_NoMail <b>Note:</b> There is no email to retrieve in the POP3 mailbox.
AT#GETMAIL	#CME ERROR: 38027 <b>Notes:</b> The address of the POP3 server has not been resolved by the secondary DNS server. TCP/IP stack is not able to reach the primary and secondary DNS servers or a wrong POP3 server address has been entered.
AT#GETMAIL	#CME ERROR: <value> <b>Notes:</b> An error has occurred during the communication with the remote POP3 server. It may also happen during the data transfer after the MAIL message. In this case, it is preceded by a (CR)(LF).(.) (CR)(LF) sequence. This error can be due to one of the following reasons: - The DNS servers are not able to resolve the POP3 server address - The POP3 server is temporarily out of service - The authentication (POP3UN, POP3PW) is not valid See section ‘Response messages and error codes’.

To view parameters, use #VPOP3

## Display Command

### #VPOP3 – POP3 Module Parameters

- Description:** Directs the TCP/IP stack to display all the AT# parameters related to the email retriever configuration.
- Syntax:** **AT#POP3?**
- Values:** POP3HEADERMODE  
POP3PORT  
POP3PW  
POP3SERV  
POP3UN  
POP3VERBOSE (for MT810SWM-IP only).  
No default

# Chapter 4 – FTP AT Commands for All Universal IP Devices

## Set Commands

### #FTPPORT – Enter FTP Server Port

**Description:** To reach the FTP server, the TCP/IP stack software must know the control port of the FTP server used for file transfer.

**Note:** This parameter should be changed only upon request of your network administrator since it applies to network infrastructure including firewalls, proxy or specific TCP port translation.

**Syntax:** **AT#FTPPORT=<value>**

AT#FTPPORT? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** From 1 to 5 digits (each digit between 0 and 9 inclusive).

Numbers above 65,535 are illegal as port identification fields are 16 bits long in the TCP header.

**Default:** 21

### #FTPMODE – Enter FTP Mode

**Description:** Define the FTP behavior for file transfer.

**Syntax:** **AT#FTPMODE=<value>**

AT#FTPMODE? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** 0 FTP Active Mode

1 FTP Passive Mode

**Default:** 0

### #FTPTYPE – Specify Data Type

**Description:** Before transferring files from a specified FTP server, the TCP/IP stack software must specify the type of data to be transferred within the FTP session.

**Syntax:** **AT#FTPTYPE=<value>**

AT#FTPTYPE? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** A – FTP ASCII sessions (Not all products support this option)

I – FTP Binary sessions.

**Note:** When this value is set to A, all the data sent by the TCP/IP stack to the FTP server is made of 7 bits characters (NVT-ASCII: the MSB is set to 0). As a consequence binary data containing 8 bits characters will be corrupted during the transfer if the FTPTYPE is set to A.

**Default:** I

## #FTPSERV – Specify FTP Server Address

**Description:** FTP server address. To connect to an FTP server to download files, the TCP/IP stack software must know the address of the FTP server that is to be used.

**Syntax:** **AT#FTPSERV=<value>"**

AT#FTPSERV? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or

Alphanumeric ASCII text string up to 120 characters if DNS is available. No default.

## #FTPUN – Set FTP User Name

**Description:** Before transferring files from a specified FTP server, the TCP/IP stack software must open an FTP session using a valid FTP user name.

**Syntax:** **AT#FTPUN=<value>"**

AT#FTPUN? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 64 characters. No default.

## #FTPPW – Set FTP Password

**Description:** Before transferring files from a specified FTP server, the TCP/IP stack software must open an FTP session using a valid FTP password.

**Syntax:** **AT#FTPPW=<value>"**

AT#FTPPW? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 64 characters. No default.

## #FTPGETFILENAME – Set FTP Download File Name

**Description:** In order to download a file from the FTP server, the TCP/IP stack software must know the name of the relevant file.

**Syntax:** **AT#FTPGETFILENAME=<value>"**

AT#FTPGETFILENAME? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #FTPPUTFILENAME – Set FTP Upload File Name

**Description:** In order for the TCP/IP stack software to upload a file to the FTP server, the TCP/IP stack software must know the name of the relevant file

**Syntax:** **AT#FTPPUTFILENAME=<value>"**

AT#FTPPUTFILENAME? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 120 characters. No default.

## #FTPGET – Download Files from FTP Server

**Description:** This command, sent by the attached host, directs the TCP/IP stack to connect to the specified FTP server and to retrieve the specified file from this server. Once the operation is completed, the TCP/IP stack closes the FTP connection.

Once an IP link is established, the attached host can retrieve a file from an FTP server at any time (except when the TCP/IP stack software is already in a process using TCP resources).

This command is similar to a GET operation (with an automatic connect/disconnect) issued by a standard FTP client on a PC. The TCP/IP stack handles the global FTP process by itself.

**Note:** The TCP/IP stack will signal the attached host of the end of the file that is being downloaded with a single <ETX> character. The <ETX> characters that are part of the file data will be shielded as <DLE><ETX>. The <DLE> characters that are part of the file data will be shielded as <DLE><DLE>. The attached host will need to remove the shielding <DLE> characters.

**Syntax:** AT#FTPGET

**Values:** FTPGETFILENAME  
FTPGETPATH  
FTPPORT  
FTPSERV  
FTPTYPE  
FPTMODE  
FTPPW  
FTPUN  
FTPFILSIZE

## #FTPPUT – Upload Files to FTP Server

**Description:** This command sent by the attached host directs the TCP/IP stack to connect to the specified FTP server and to upload the data received on the serial port to the specified file on this server. Once the operation is completed, the TCP/IP stack closes the FTP connection.

Once an IP link is established, the attached host can send a file to a FTP server at any time (except when the TCP/IP stack software is already in a process using TCP resources).

This command is similar to a PUT operation (with an automatic connect/disconnect) issued by a standard FTP client on a PC. The TCP/IP stack handles the global FTP put process by itself.

**Note:** The TCP/IP stack will interpret only an <ETX> character as the end of the file to be transferred if it's not preceded by a <DLE> character. As a consequence, the attached host must send <ETX> characters preceded by <DLE> characters, and it must also code <DLE> characters as <DLE><DLE>.

**Syntax:** AT#FTPPUT

**Values:** FTTPUTFILENAME  
FTPDIR  
FTPPORT  
FTPSERV  
FTPTYPE  
FPTMODE  
FTPPW  
FTPUN  
No default

## #FTPGETPATH – Set Path to Get a File from FTP Server

**Description:** In order for the TCP/IP stack software to get a file from the FTP server, the TCP/IP stack software must know the path of the relevant file. For example: *ftp.companyx.com/wireless/WPST* or, if you are in the root *ftp.companyx.com*, you can then simply type /

**Syntax:** **AT#FTPGETPATH=<value>"**

AT#FTPGETPATH? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 120 characters.

**Note:** Depending on the FTP server, the value can be used for getting a file from the root directory of the FTP server. No default.

## #FTPPUTPATH – Set Path to Send Files to FTP Server

**Description:** In order for the TCP/IP stack software to send a file to the FTP server, the TCP/IP stack software must know the path of the relevant file. For example: *ftp.companyx.com/wireless/WPST* or, if you are in the root *ftp.companyx.com*, you can then simply type /

**Syntax:** **AT#FTPPUTPATH=<value>"**

AT#FTPPUTPATH? Read or display the current setting (or AT#VFTP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 120 characters.

**Note:** Depending on the FTP server, the value can be used for getting a file from the root directory of the FTP server. No default.

## #FTAPPEND – Append Data to Server

**Description:** This command sent by the attached host directs the TCP/IP stack to connect to the specified FTP server and to append the data received on the serial port to the specified file on this server. Once the operation is completed, the TCP/IP stack closes the FTP connection.

Once an IP link is established, the attached host can send a file to a FTP server at any time (except when the TCP/IP stack software is already in a process using TCP resources).

This command is similar to a PUT operation (with an automatic connect/disconnect) issued by a standard FTP client on a PC. The TCP/IP stack handles the global FTP put process by itself.

**Note:** Certain conditions must be met in order to use this command. First, the FTP server must support this command as some servers do and some servers don't. Also, the client performing the APPEND operation must read/write to the FTP server as well.

**Syntax:** **AT#FTAPPEND**

## #FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value

**Description:** This parameter determines the inactivity time in seconds of the TCP TX buffer.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** **AT#FTPNETWORKTIMER=<parameter1>**

**Values:** 0-65535 – the time in seconds the client will wait for the TCP available TX buffer to be greater than 0. A setting of 0 will disable the function.

**Responses:**  
`AT#FTPNETWORKTIMER: VALUE1\r\n`  
`OK\r\n`  
`ERROR\r\n`

### Command Example(s):

```
send: AT#FTPNETWORKTIMER=100\r
reply: \r\nOK\r\n
send: AT#FTPNETWORKTIMER?\r
reply: \r\n#FTPNETWORKTIMER: 100\r\n
reply: \r\nOK\r\n
```

## Display Command

### #VFTP – Display FTP Parameters

**Description:** This command directs the TCP/IP stack to display all AT# parameters for the FTP client configuration.

**Syntax:** **AT#VFTP**

**Values:** **FTPSERV**  
**FTPPORT**  
**FTPUN**  
**FTPPW**  
**FTPGETFILENAME**  
**FTPPUTFILENAME**  
**FTPPUTPATH**  
**FTPTYPE**  
**FPTMODE**

# Chapter 5 – TCP AT Commands for All Universal IP Devices

## Set Commands

The **id** parameter is used for setting up profiles; Profile 1 and Profile 2. To view parameters including profile settings, use **AT#<cmd>=id** or **AT#VTCP=id** or **AT#VALL**.

### #PERSISTENTSOCKET - Persistent Socket

**Description:** If enabled and the physical connection is present, a socket will be created automatically.  
**Note:** This command is for all devices except the SocketEthernet IP (MT100SEM-IP).

**Syntax:** **AT#PERSISTENTSOCKET=<Persistentsocket value>,<Result Codes>**  
**AT#PERSISTENTSOCKET?** Read or display the current setting (or AT#VALL).

**Values:**

- 0** – Persistent socket is disabled
- 1** – The TCP originate is started (#OTCP=1)
- 2** – The TCP listener is started (#LTCPSTART=1)
- 3** – The UDP originate is started (#OUDP=1)
- 4** – The UDP listener is started (#LUDPSTART=1)
- 5** – The TCP originate is started (#OTCP=2)
- 6** – The TCP originate is started (#LTCPSTART=2)

**Result Codes:**

- 0** All result codes will be suppressed during socket connection/disconnection
- 1** All result codes will be displayed during socket connection/disconnection

**Defaults:** **0,1**

**Example:** **AT#PERSISTENTSOCKET=1,0**

### #DLEMODE – Set DLE Mode

**Description:** When using socket TCP, the attached host has the choice whether or not to code the ETX character.

**Syntax:** **AT#DLEMODE=id,<DEL Mode value>**  
**AT#DLEMODE=id** Read or display the current setting (or AT#VTCP=id, AT#VALL).

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** Set the value that the Profile will use:

- 0** When DLEMODE is set to 0, no specific process is needed on [ETX] characters.  
 It means that it is not possible for a host to request an end of connection or to receive a clear indication of the end of a connection from the TCP/IP stack.
- 1** When DLEMODE is set to 1, the [ETX] character means a request or an indication of end of connection.  
 As a consequence, [ETX] characters that belong to the payload data must be sent by the host on the serial port preceded by a DLE character. Similarly, ETX characters received by the TCP/IP stack from the Internet are sent to the host through the serial port preceded by a DLE character.

**Default:** **1**

## #TCPPORT – Set TCP Port for Remote Peer

**Description:** To exchange data over TCP, the TCP/IP stack software must know the port of the remote peer used for the TCP session.

**Syntax:** **AT#TCPPORT=id,<TCP Port number for remote peer value>**  
AT#TCPPORT=id Read or display the current setting (or AT#VTCP=id, AT#VALL).

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** Set the value that the Profile will use:  
From 1 to 5 digits (each digit between 0 and 9 inclusive). Note that numbers above 65,535 are illegal as the port identification fields are 16 bits long in the TCP header.

**Default:** 1

## #TCPSEERV – Set Address of Remote TCP Server

**Description:** To exchange data over TCP, the TCP/IP stack software must know the address of the remote TCP server (or host) that is to be used.

**Syntax:** **AT#TCPSEERV=id,"<Address of remote TCP server value>"**  
AT#TCPSEERV=id Read or display the current setting (or AT#VTCP=id, or AT#VALL).

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** Set the value that the Profile will use:  
32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or  
Alphanumeric ASCII text string up to 120 characters if DNS is integrated. No default.

## #TCPTXDELAY – Time Delay

**Description:** This command determines the time delay introduced before sending a TCP frame that has not been entirely filled with user data. The time is entered in milliseconds, and it should be noted that a value of 0 initiates the sending of a TCP frame as soon as possible after the reception of a single character value from the host.

**Syntax:** **AT#TCPTXDELAY=id,<Time Delay value>**  
AT#TCPTXDELAY=id Read or display the current setting (or AT#VTCP=id or AT#VALL).

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** Set the value that the Profile will use:  
Integer multiple of 20 between 0 and 32760 inclusive.

**Default:** 0

## #TCPPACKETMIN – TCP Client Transmit Packet Minimum Size

**Description:** This parameter determines the minimum packet size the TCP Client will transmit.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPPACKETMIN=<parameter1>, <parameter2>

**Values:** parameter 1

1 TCP profile 1

2 TCP profile 2

**parameter 2**

0-65535 – the size of the packet in bytes; a setting of 65535 will allow the max packet size allowed by the UIP stack

**Responses:** \r\n#TCPPACKETMIN: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#TCPPACKETMIN=1,100\r

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMIN=1\r

**reply:** \r\n#TCPPACKETMIN: 1,100\r\n

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMIN=2,300\r

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMIN=2\r

**reply:** \r\n#TCPPACKETMIN: 2,300\r\n

**reply:** \r\nOK\r\n

## #TCPPACKETMAX – TCP Client Transmit Packet Maximum Size

**Description:** This parameter determines the maximum packet size the TCP Client will transmit.

**Note:** This value cannot be larger than the internal maximum UIP TCP payload size.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPPACKETMAX=<parameter1>, <parameter2>

**Values:** parameter 1 1 TCP profile 1

2 TCP profile 2

**parameter 2**

0-65535 – the size of the packet in bytes; a setting of 65535 will allow the max packet size allowed by the UIP stack

**Responses:** \r\n#TCPPACKETMAX: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#TCPPACKETMAX=1,100\r

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMAX=1\r

**reply:** \r\n#TCPPACKETMAX: 1,100\r\n

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMAX=2,300\r

**reply:** \r\nOK\r\n

**send:** AT#TCPPACKETMAX=2\r

**reply:** \r\n#TCPPACKETMAX: 2,300\r\n

**reply:** \r\nOK\r\n

## #TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value

**Description:** This parameter determines the inactivity time in seconds as to when a socket connection will automatically disconnect.

**Note:** Data transmission from either the remote or local side will reset the internal timer to the #TCPINACTIVITYTIMER value

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPINACTIVITYTIMER=<parameter1>, <parameter2>

**Values:** parameter 1

- 1 TCP profile 1
- 2 TCP profile 2

parameter 2

0-65535 – the time in seconds of inactivity before a socket will automatically disconnect. A setting of 0 will disable the function.

**Responses:**

```
\r\n#TCPINACTIVITYTIMER: VALUE1,VALUE2\r\n
\r\nOK\r\n
\r\nERROR\r\n
```

**Examples:**

```
send: AT#TCPINACTIVITYTIMER=1,100\r
reply: \r\nOK\r\n

send: AT#TCPINACTIVITYTIMER=1\r
reply: \r\n#TCPINACTIVITYTIMER: 1,100\r\n
reply: \r\nOK\r\n

send: AT#TCPINACTIVITYTIMER=2,300\r
reply: \r\nOK\r\n

send: AT#TCPINACTIVITYTIMER=2\r
reply: \r\n#TCPINACTIVITYTIMER: 2,300\r\n
reply: \r\nOK\r\n
```

## #TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value

**Description:** This parameter determines the inactivity time in seconds of the TCP TX buffer.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPNETWORKTIMER=<parameter1>, <parameter2>

**Values:** parameter 1

- 1 TCP profile 1
- 2 TCP profile 2

parameter 2

0-65535 – the time in seconds the client will wait for the TCP available TX buffer to be greater than 0. A setting of 0 will disable the function.

**Responses:** \r\n#TCPNETWORKTIMER: VALUE1,VALUE2\r\n

```
\r\nOK\r\n
\r\nERROR\r\n
```

**Examples:**

```
send: AT#TCPNETWORKTIMER=1,100\r
reply: \r\nOK\r\n

send: AT#TCPNETWORKTIMER=1\r
reply: \r\n#TCPNETWORKTIMER: 1,100\r\n
reply: \r\nOK\r\n

send: AT#TCPNETWORKTIMER=2,300\r
reply: \r\nOK\r\n

send: AT#TCPNETWORKTIMER=2\r
reply: \r\n#TCPNETWORKTIMER: 2,300\r\n
reply: \r\nOK\r\n
```

## #TCPTELNETMODE – Enable/Disable TCP Client Telnet Protocol

**Description:** Enables or disables the TCP Client Telnet protocol.

**Note:** Allows the TCP Client Telnet to handle a minimal telnet protocol.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Note:** TCP Client raw mode requires the username and password each to be followed by a line feed character not just any key.

**Syntax:** AT#TCPTELNETMODE=<parameter1>, <parameter2>

**Values:** parameter 1

1 TCP profile 1

2 TCP profile 2

parameter 2

0 Disable TCP Client Telnet protocol function

1 Enable TCP Client Telnet protocol function with username and password login

2 Enable TCP Client Telnet protocol function without username and password login

3 Enable TCP Client raw mode function with username and password login

**Responses:** \r\n#TCPTELNETMODE: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#TCPTELNETMODE=1,1\r

**reply:** \r\nOK\r\n

**send:** AT#TCPTELNETMODE=1\r

**reply:** \r\n#TCPTELNETMODE: 1,1\r\n

**reply:** \r\nOK\r\n

## #TCPTELNETPW – Configure the TCP Client Telnet Protocol Login Password

**Description:** Configures the login password for the TCP Client Telnet protocol.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPTELNETPW=<parameter1>, <parameter2>

**Values:** parameter 1

1 TCP profile 1

2 TCP profile 2

parameter 2

64 character alphanumeric string

**Responses:** \r\n#TCPTELNETPW: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#TCPTELNETPW=1,"PASSWORD"\r

**reply:** \r\nOK\r\n

**send:** AT#TCPTELNETPW=1\r

**reply:** \r\n#TCPTELNETPW: 1,"PASSWORD"\r\n

**reply:** \r\nOK\r\n

## #TCPTELNETUN – Set the TCP Client Telnet Protocol User Name

**Description:** Configure the TCP Client Telnet protocol login user name.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#TCPTELNETUN=<parameter1>, <parameter2>

**Values:** parameter 1

1 TCP profile 1

2 TCP profile 2

parameter 2

64 character alphanumeric string

**Responses:** \r\n#TCPTELNETUN: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#TCPTELNETUN=1,"USER"\r

**reply:** \r\nOK\r\n

**send:** AT#TCPTELNETUN=1

**reply:** \r\n#TCPTELNETUN: 1,"USER"\r\n

**reply:** \r\nOK\r\n

## #LTCPPSTART – Open Listening Mode

**Description:** This command, sent by the attached host, directs the TCP/IP stack to open a listening TCP connection on the specified TCP port.

Once an IP link is established, the attached host can open a listening TCP socket at any time (except when the TCP/IP stack software is already in a process using TCP resources).

The TCP connection will be active upon reception of a TCP connection request sent by a remote allowed TCP peer (TCPSEVR) on the appropriate TCP port (TCPPORT).

Once opened, this TCP connection may be closed by the remote TCP peer or by the attached host by sending an ETX character on the serial port (depending on the DLEMODE parameter).

### Notes:

The LTCPP command can be aborted before an incoming TCP request has been received by issuing an <ETX> character on the serial port.

If the DLEMODE parameter is set to 1, the TCP/IP stack will interpret an <ETX> character only as a close request if a <DLE> character does not precede it. As a consequence, the attached host must send <ETX> characters preceded by <DLE> characters, and it must also code <DLE> characters in <DLE><DLE>. Similarly, each <ETX> character present in the payload data of the TCP frame will be coded by the TCP/IP stack on the serial port as <DLE><ETX>. Each <DLE> character will be coded as <DLE><DLE>. The attached host must then decode the TCP socket flow to remove these escape characters.

If the DLEMODE parameter is set to 0, the TCP/IP stack will never close the TCP connection (unless an error occurs).

**Syntax:** AT#LTCPPSTART=id

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** DLEMODE

TCPPORT

TCPSEVR

TCPTXDELAY

## #LTCSTOP – Close TCP Listening Mode

**Description:** This command directs the TCP/IP stack to close a TCP listening mode (previously launched by the AT#LTCSTART command).

**Syntax:** **AT#LTCSTOP=id**

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** DLEMODE

TCPPORT

TCPSERV

TCPTXDELAY

## #OUTPORT – UDP/TCP Local Port Number

**Description:** Controls the local port that the UDP/TCP connection is bound to.

**Syntax:** **AT#OUTPORT=<Port Number value>**

AT#OUTPORT? Read or display the current setting (or AT#VALL ).

**Values:** Set the port number local connection will use:

From 1 to 5 numeric digits (0 to 9).

**Note:** Numbers above 65,535 are illegal since port identification fields are 16-bits long in the IDP header.

**Default:** 37500

## #OTCP – Open a TCP Connection

**Description:** This command sent by the attached host directs the TCP/IP stack to open a TCP connection to the specified TCP server. Once an IP link is established, the attached host can open a TCP connection at any time (except when the TCP/IP stack software is already in a process using TCP resources).

This TCP connection may be closed by the remote TCP server or by the attached host via sending an ETX character on the serial port (**depending on the DLEMODE parameter**).

### DLEMODE Value Notes:

Depending on the DLEMODE value, the attached host may close this TCP connection by sending an ETX character.

- If the DLEMODE parameter is set to 1, the TCP/IP stack will only interpret an <ETX> character as a close request if it's not preceded by a <DLE> character. As a consequence, the attached host must send <ETX> characters preceded by <DLE> characters, and it must also code <DLE> characters in <DLE><DLE>. Similarly, each <ETX> character present in the payload data of the TCP frame will be coded by the TCP/IP stack on the serial port as <DLE><ETX>. Each <DLE> character will be coded as <DLE><DLE>. The attached host must then decode the TCP socket flow to remove these escape characters.

- If DLEMODE is set to 0, the host cannot close the TCP connection (unless an error occurs).

If the remote TCP server closes the connection, the TCP/IP stack sends an ETX character on the serial port.

**Syntax:** **AT#OTCP=id**

**id:** Enter a Profile Setting: 1 or 2 {1,2}

**Values:** DLEMODE

TCPPORT

TCPSERV

TCPTXDELAY

## Display Command

### #VTCP – Display TCP Parameters

**Description:** This command directs the TCP/IP stack to display all the AT# parameters related to the TCP socket configuration.

**Syntax:** AT#VTCP=id or AT#VTCP

**Note:** If you use **AT#VTCP=id**, the parameters for profile 1 **or** profile 2 will display. If you use **AT#VTCP**, the parameters for both Profile 1 and Profile 2 will display.

**Example:**

Command	Possible Responses
AT#VTCP Note: View TCP parameters of the TCP socket 2	#DLEMODE: 1 , 1 #TCPSSERV: 1 , "... " #TCPSSPORT: 1 , 0 #TCPPTXDELAY: 1 , 100 #DLEMODE: 2 , 1 #TCPSSERV: 2 , "... " #TCPSSPORT: 2 , 0 TCPPTXDELAY: 2 , 100 OK

# Chapter 6 – UDP AT Commands for All Universal IP Devices

## Set Commands

### #PERSISTENTSOCKET - Persistent Socket

**Description:** If enabled and the physical connection is present, a socket will be created automatically.  
**Note:** This command is for all devices except the SocketEthernet IP (MT100SEM-IP).

**Syntax:** **AT#PERSISTENTSOCKET=<Persistentsocket value>,<Result Codes>**  
**AT#PERSISTENTSOCKET?** Read or display the current setting (or AT#VALL ).

**Values:**

- 0** – Persistent socket is disabled
- 1** – The TCP originate is started (#OTCP=1)
- 2** – The TCP listener is started (#LTCPSTART=1)
- 3** – The UDP originate is started (#OUDP=1)
- 4** – The UDP listener is started (#LUDPSTART=1)

**Result Codes:**

- 0** – All result codes will be suppressed during socket connection/disconnection
- 1** – All result codes will be displayed during socket connection/disconnection

**Defaults:** 0,1

**Example:** AT#PERSISTENTSOCKET=1,0

### #UDPPACKETMIN – UDP Client Transmit Packet Minimum Size

**Description:** This parameter determines the minimum packet size the UDP Client will transmit.

**Note:** This value cannot be larger than the internal maximum UIP UDP payload size.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Syntax:** **AT#UDPPACKETMIN=<parameter1>**

**AT#UDPPACKETMIN?** Read or display the current setting.

**Values:**

- parameter 1
- value = 0-65535 – the size of the packet in bytes; a setting of 65535 will allow the min packet size allowed by the UIP stack

**Responses:** \r\n#UDPPACKETMIN: VALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#UDPPACKETMIN=300\r  
**reply:** \r\nOK\r\n

**send:** AT#UDPPACKETMIN?\r  
**reply:** \r\n#UDPPACKETMIN: 300\r\n  
**reply:** \r\nOK\r\n

## #UDPPACKETMAX – UDP Client Transmit Packet Maximum Size

**Description:** This parameter determines the maximum packet size the UDP Client will transmit.

**Note:** This value cannot be larger than the internal maximum UIP UDP payload size.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Syntax:** AT#UDPPACKETMAX=<parameter1>  
AT#UDPPACKETMAX? Read or display the current setting.

**Values:** parameter 1  
0-65535 – the size of the packet in bytes; a setting of 65535 will allow the max packet size allowed by the UIP stack

**Responses:** \r\n#UDPPACKETMAX: VALUE\r\n\r\nOK\r\n\r\nERROR\r\n

**Examples:**

```
send: AT#UDPPACKETMAX=300\r
      reply: \r\nOK\r\n

send: AT#UDPPACKETMAX?\r
      reply: \r\n#UDPPACKETMAX: 300\r\n
      reply: \r\nOK\r\n
```

## #UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value

**Description:** This parameter determines the inactivity time in seconds as to when a socket connection will automatically disconnect.

**Note:** Data transmission from either the remote or local side will reset the internal timer to the #UDPINACTIVITYTIMER value.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Syntax:** AT#UDPINACTIVITYTIMER=<parameter1>

**Values:** parameter 1  
0-65535 – the time in seconds of inactivity before a socket will automatically disconnect. A setting of 0 will disable the function.

**Responses:** \r\n#UDPINACTIVITYTIMER: VALUE1\r\n\r\nOK\r\n\r\nERROR\r\n

### Command Example(s):

```
send: AT#UDPINACTIVITYTIMER=100\r
      reply: \r\nOK\r\n

send: AT#UDPINACTIVITYTIMER?\r
      reply: \r\n#UDPINACTIVITYTIMER: 100\r\n
      reply: \r\nOK\r\n
```

## #UDPIGNORESRCPORT – Ignore Send Source Port

**Description:** Allows the UDP client to ignore the remote IP's source port.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Syntax:** AT#UDPIGNORESRCPORT=<parameter1>

AT#UDPIGNORESRCPORT? Read or display the current setting.

**Values:** parameter 1

0 Remote source port is respected; all packets not matching the first received source port are rejected

1 Remote source port is ignored; all packets matching the remote IP address are accepted

**Responses:** \r\n#UDPIGNORESRCPORT: VALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#UDPIGNORESRCPORT=0\r

**reply:** \r\nOK\r\n

**send:** AT#UDPIGNORESRCPORT?\r

**reply:** \r\n#UDPIGNORESRCPORT: 0\r\n

**reply:** \r\nOK\r\n

## #UDPREMOTEPORT – Remote Port Number

**Description:** Configure the UDP remote port.

**Notes:** When the UDP session is initiated in listen mode (#LUDPSTART), this value will override the return port derived from the first incoming packet.

**Syntax:** AT#UDPREMOTEPORT=<parameter1>

AT#UDPREMOTEPORT? Read or display the current setting.

**Values:** Parameter 1

0 (disabled) - 65535

**Default:** 0

**Responses:** \r\n#UDPREMOTEPORT: VALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#UDPREMOTEPORT=300\r

**reply:** \r\nOK\r\n

**send:** AT#UDPREMOTEPORT?\r

**reply:** \r\n#UDPREMOTEPORT: 300\r\n

**reply:** \r\nOK\r\n

## #UDPPORT – UDP Port Number

**Description:** If the UDP session is initiated in listen mode, use the local UDP port number.

If the UDP session is initiated in active mode, use the remote UDP port number.

**Syntax:** AT#UDPPORT=<Port Number Value>

AT#UDPPORT? Read or display the current setting.

**Values:** From 1 to 5 numeric digits (0 to 9).

**Notes:** Numbers above 65,535 are illegal as the port identification fields are 16-bits long in the IP header. Port number 0 is illegal.

**Default:** 1

## #UDPSERV – UDP Server Address

**Description:** If the UDP session is initiated in listen mode, use the IP address filter. This means that the remote must have a defined UDPSERV IP address. If the UDP session is initiated in active mode, use the remote IP address.

**Syntax:** **AT#UDPSERV=<Value>**

AT#UDPSERV? Read or display the current setting.

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or Alphanumeric ASCII text string up to 120 characters if DNS is integrated. No default.

## #UDPTXDELAY – Delay before Sending UDP Datagram

**Description:** This parameter determines the delay before sending an UDP datagram that has not been entirely filled with user data. The delay is expressed in milliseconds. The 0 value initiates the sending an UDP datagram as soon as possible after the reception of a single character value from the host.

**Syntax:** **AT#UDPTXDELAY=<Value>**

AT#UDPTXDELAY? Read or display the current setting.

**Values:** Integer, multiple of 20 and between 0 and 32760 inclusive.

**Default Value:** 100

## #UDPDLEMODE – Set DLE Mode

**Description:** The attached host has the choice whether or not to code the ETX character.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP).

**Notes:** If UDPDLEMODE is disabled, the user MUST use the RS232 DTR signal to perform a socket disconnect or disconnect the network connection

**Details:** If UDPDLEMODE is enabled, these rules must be followed: The user must shield all transmitted ETX ([x03]) and DLE (x10) characters by preceding these characters with a DLE (x10).

The UIP stack will shield all UDP received ETX ([x03]) and DLE (x10) characters by preceding these characters with a DLE (x10), the user must un-shield by removing the DLE (x10) shield character.

An example payload to transmit from user to UIP stack:

(x01 x02 x03 x04 x01 x10) must be sent to the UIP stack as: (x01 x02 x10 x03 x04 x01 x10 x10). Notice the x10 before the [x03] and before the x10.

An example received payload by the UIP over UDP:

(x01 x02 x03 x04 x01 x10) is received by the UIP stack, the user will receive: (x01 x02 x10 x03 x04 x01 x10 x10). Notice the x10 before the [x03] and before the x10.

In summary: Encoding - 0x03 == 0x10 0x03

Encoding - 0x10 == 0x10 0x10

Decoding - 0x10 0x03 == 0x03

Decoding - 0x10 0x10 == 0x10

The REMOTE user does NOT have to perform any function pertaining to this mechanism.

If the user receives an un-shielded 0x03, the socket is finished.

**Syntax:** **AT#UDPDLEMODE=<parameter1>**

AT#UDPDLEMODE? Read or display the current setting.

**Values:** parameter 1

0 No extra processing is needed on DLE (x10) and ETX ([x03]) characters

1 The ETX character is used as a socket disconnect or indicates a socket disconnect

**Responses:** \r\n#UDPDLEMODE: VALUE\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Command Example(s):**

**send:** AT#UDPDLEMODE=0\r

**reply:** \r\nOK\r\n

**send:** AT#UDPDLEMODE?\r

**reply:** \r\n#UDPDLEMODE: 0\r\n

**reply:** \r\nOK\r\n

## #LUDPSTART – Initiate the UDP Session in Listen Mode

**Description:** Once an IP link is established, and if no other TCP/IP stack resource is active, this command sent by the attached host directs the TCP/IP stack to initiate the UDP session in listen mode on the specified UDP local port UDPPORT.

**Syntax:** **AT#LUDPSTART**

**Values:** UDPPORT

UDPSESRV

UDPTXDELAY

No default

## #LUDPSTOP – Close UDP Listening Mode

**Description:** This command directs the TCP/IP stack to close a UDP listening mode session previously launched by the AT#UDPSTART command.

**Syntax:** **AT#LUDPSTOP**

**Values:** UDPPORT (No default)

## #OUTPORT – UDP/TCP Local Port Number

**Description:** Controls the local port that the UDP/TCP connection is bound to.

**Syntax:** **AT#OUTPORT=<Port Number value>**  
AT#OUTPORT? Read or display the current setting.(or AT#VALL).

**Values:** Set the port number local connection will use:  
From 1 to 5 numeric digits (0 to 9).  
**Note:** Numbers above 65,535 are illegal since port identification fields are 16-bits long in the IDP header.

**Default:** 37500

## #OUDP – Initiate UDP Session in Active Mode

**Description:** Once an IP link is established, and if no other TCP/IP stack resource is active, this command sent by the attached host directs the TCP/IP stack to initiate an UDP session in active mode on the specified UDP remote port UDPPORT to the specified remote IP address UDPserv. The host can then transmit to the UDPPORT or UDPserv address. Datagrams can only be received from this UDPPORT or UDPserv address.

**Syntax:** **AT#UDPOOPEN**  
**Values:** UDPPORT  
UDPSERV  
UDPTXDELAY  
No default

## Display Command

### #VUDP – Display UDP Module Configuration

**Description:** Directs the TCP/IP stack to display all the AT# parameters related to the UDP socket configuration.

**Syntax:** **AT#VUDP**  
**Values:** UDPPORT  
UDPSERV  
UDPTXDELAY  
No default.

# Chapter 7 – PING AT Commands for All Universal IP Devices

## Set Commands

**General Note:** Due to varying factors, PING response times may not be valid.

### #PINGNUM – Number of PING Requests

**Description:** This command sets the number of PING echo requests to issue to PINGREMOTE.  
**Syntax:** **AT#PINGNUM=<Value>**  
AT#PINGNUM? Read or display the current setting.(or AT#VPING, AT#VALL).  
**Values:** From 0 to 255 inclusive. (If 0, ping indefinite until ETX (0x03) is issued)  
**Default:** 4

### #PINGREMOTE – IP Address of PING Request

**Description:** Sets the IP address up of the remote device to ping.  
**Syntax:** **AT#PINGREMOTE="<IP Address Value>"**  
AT#PINGREMOTE? Read or display the current setting.(or AT#VPING, AT#VALL).  
**Values:** 32-bit number is dotted-decimal notation (i.e., xxx.xxx.xxx.xxx). No default.

### #PING – Start PING Request

**Description:** Directs the module to start PING requests to the configured PING remote address. No of requests to be sent is obtained from the PINGNUM parameter.  
**Syntax:** **AT#PING**  
AT#PING? Read or display the current setting.  
**Values:** Read parameters: (read from serial flash predefined before starting the ping command.)  
PINGNUM  
PINGREMOTE

### #PINGDELAY – PING Delay Time

**Description:** This command sets the waiting delay, in seconds, before an echo request is considered as a **no reply**. It is also the delay between two echo requests (if PINGNUM > 1).  
**Syntax:** **AT#PINGDELAY=<Value>**  
AT#PINGDELAY? Read or display the current setting.  
**Values:** From 1 to 255 inclusive.  
**Default:** 1

## Display Command

### #VPING – Display PING Parameters

**Description:** Display PING module related information.

**Syntax:** **AT#VPING**

AT#PING? Read or display the current setting.

**Values Displayed:**

PINGNUM  
PINGREMOTE  
PINGENABLE  
PINGDELAY

# **Part 2 – AT Commands for the SocketEthernet IP**

**Chapter 8 – General AT Commands for the SocketEthernet IP (MT100SEM-IP)**

**Chapter 9 – Auto Discovery AT Commands for the SocketEthernet IP (MT100SEM-IP)**

# Chapter 8 – General AT Commands for the SocketEthernet IP

## Set Commands

### #DHCP – DHCP On or Off

<b>Description:</b>	Enables or disables the DHCP client. If the DHCP client is enabled, the module will take the IP address from DHCP server. If DHCP client is disabled, the module will take the static IP address configured for the module.
	<b>Note:</b> The module must be reset to put the command into effect.
<b>Syntax:</b>	<b>AT#DHCP=&lt;0,1&gt;</b> AT#DHCP? Read or display the current setting.
<b>Responses:</b>	<b>AT#DHCP=0</b> returns <b>OK</b> <b>AT#DHCP?</b> returns <b>0</b> and <b>OK</b>
<b>Values:</b>	<b>AT#DHCP=0</b> Turn off DHCP (sets IP Address, Netmask, and Gateway back to defaults) <b>AT#DHCP=1</b> Turn on DHCP (automatically assigns IP Address, Netmask, and Gateway)
<b>Default:</b>	<b>0</b>

### #IPADDR – Set Static IP Address

<b>Description:</b>	Sets the static IP Address.
	<b>Note:</b> The module must be reset to put the command into effect.
<b>Syntax:</b>	<b>AT#IPADDR="&lt;IP Address value&gt;"</b> AT#IPADDR? Read or display the current setting.
<b>Responses:</b>	<b>AT#IPADDR =192.168.1.10</b> returns and <b>OK</b> <b>AT#IPADDR?</b> returns <b>192.168.1.10 (Manually Configured)</b> and <b>OK</b>
<b>Values:</b>	IP Address in dotted decimal notation ( <b>xxx.xxx.xxx.xxx</b> ) "x" stands for a number between 0-255. 255 is the maximum value in an xxx group.
<b>Default:</b>	<b>192.168.2.3</b>

### #IPGATEWAY – Set Gateway Address

<b>Description:</b>	Sets the default gateway address. The view of get command shows whether the address is statically configured or obtained from the DHCP server.
	<b>Note:</b> The module must be reset to put the command into effect.
<b>Syntax:</b>	<b>AT#IPGATEWAY="&lt;gateway address value&gt;"</b> AT#IPGATEWAY? Read or display the current setting.
<b>Responses:</b>	<b>AT#IPGATEWAY =192.168.1.11</b> returns and <b>OK</b> <b>AT#IPGATEWAY?</b> returns <b>192.168.1.11 (Manually Configured)</b> and <b>OK</b>
<b>Values:</b>	IP Address in dotted decimal notation ( <b>xxx.xxx.xxx.xxxx</b> ). "x" = a number between 0-255.
<b>Default:</b>	<b>192.168.2.1</b>

## #IPNETMASK – Set Subnet Mask

**Description:** Sets the subnet mask.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#IPNETMASK="<Subnet Mask value>"**

AT#IPNETMASK? Read or display the current setting.

**Responses:** **AT#IPNETMASK = 255.255.255.0** returns and **OK**

**AT#NETMASK?** returns **255.255.255.0 (Manually Configured)** and **OK**

**Values:** IP Address in dotted decimal notation (**xxx.xxx.xxx.xxxx**). "x" = a number between 0-255.

**Default:** **255.255.255.0**

## #DNSSERV1 – Set DNS Server IP Address

**Description:** In order to translate the server names from literal format into IP addresses, the TCP/IP stack software implements the Domain Name System (DNS) protocol. The DNS Server IP address must be specified for use by the TCP/IP stack software.

**Syntax:** **AT#DNSSERV1="<value>"**

AT#DNSSERV1? Read or display the current setting.

**Responses:** **AT# DNSSERV1=192.168.0.1** returns and **OK**

**AT# DNSSERV1?** returns **192.168.0.1** and **OK**

**Values:** 32-bit number in dotted-decimal notation (i.e., **xxx.xxx.xxx.xxx**).

**Default:** **202.56.215.6**

## #DNSSERV2 – Set Secondary DNS Server

**Description:** In order to translate the server names from literal format into IP addresses, the TCP/IP stack software implements the Domain Name System (DNS) protocol. The DNS Server IP address has to be specified for use by the TCP/IP stack software. This secondary DNS server is used in the case where the primary DNS server does not respond to a request.

**Syntax:** **AT#DNSSERV2="<value>"**

AT#DNSSERV2? Read or display the current setting.

**Values:** 32-bit number in dotted-decimal notation (i.e., **xxx.xxx.xxx.xxx**).

**Default:** **202.56.230.6**

**Note:** The Universal IP resolver (DNS Client) has a list that holds up to 4 DNS servers, the first 2 in the list are populated by the #DNSSERV1 and #DNSSERV2 commands, the 3rd and 4th are populated by DNS information provided by the ISP or cellular carrier. The list is checked in order (1-4). This means that user configured name servers will be checked before dynamically assigned name servers.

## #EMACSPD – Set Ethernet Connection

**Description:** Sets the Ethernet connection at 10 or 100 full or half duplex.

**Syntax:** **AT#EMACSPD=x** where x stands for 0,1,2,3,4

**Values:** 0 – Auto Sensing

1 – 10Mbis half duplex

2 – 10Mbis full duplex

3 – 100Mbis half duplex

4 – 100Mbis full duplex

AT#EMACSPD? View the current setting. Can view with AT#VALL or AT#VIP also.

**Default:** **AT#EMACSPD=0**

## #HOSTNAME – Configure the DHCP Client Host Name

**Description:** Configures the device host name reported to the DHCP server.

**Note:** This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)

**Syntax:** AT#HOSTNAME=<parameter1>

AT#HOSTNAME? Read or display the current setting.

**Values:** parameter 1  
Host name (up to 64 alpha-numeric characters)

**Responses:** \r\n#HOSTNAME: "VALUE"  
\r\nOK\r\n  
\r\nERROR\r\n\r\n

### Command Example(s):

**send:** AT#HOSTNAME="Device9876"\r

**reply:** \r\nOK\r\n

**send:** AT#HOSTNAME?\r

**reply:** \r\n#HOSTNAME: "Device9876"\r\n

**reply:** \r\nOK\r\n

## Display Commands

### #ETHIFSTATUS – View Network Interface Settings

**Description:** Display the address settings.

**Syntax:** AT#ETHIFSTATUS

**Values:** None

**Display Example:** INTERFACE: UP

LINK: UP

IPADDR: 192.168.2.3

IPGATEWAY: 192.168.2.1

IPNETMASK: 255.255.255.0

MACADDR: 00:00:00:00:00:00

DNSSERV1: 0.0.0.0

DNSSERV2: 0.0.0.0

DNSSERV3: 0.0.0.0

DNSSERV4: 0.0.0.0

### #VDNS – Display Configuration of DNS Servers

**Description:** This command the TCP/IP stack to display all AT# parameters related to the configuration of the DNS servers. Note: This is displayed only when DHCP is OFF.

**Syntax:** AT#VDNS

**Values:** None

## #VIP – View Address Settings

**Description:** Displays the address settings.

**Notes:** This command displays the programmed IP settings. To see IP settings in use, including DHCP parameters, use the #ETHIFSTATUS command.

Also, this command shows valid results only when DHCP is OFF. Otherwise, it displays the default or stored values.

**Syntax:** **AT#VIP**

**Values:** None

**Example:** The order and content is as follows:

DHCP (Enable/Disable)  
IP address  
Subnet Mask  
Default Gateway  
Speed setting (see #EMACSPD command)  
MAC address

# Chapter 9 – Auto Discovery AT Commands for the SocketEthernet IP

**A Note about Auto Discovery:** Auto Discovery will broadcast information; however, at this time, the information cannot be updated using the Auto Discovery Manager.

## Set Commands

### #AUTODISC – Auto Discovery On/Off

**Description:** This command turns Auto Discovery On or Off.

**Syntax:** **AT#AUTODISC=<value>**

AT#AUTODISC? Read or display the current setting (or AT#VAUTODISC, AT#VALL).

**Values:** 0 – OFF

1 – ON

**Default:** 1

### #AUTODISCTIMER – Auto Discovery Timer

**Description:** This command sets the Auto Discovery timer.

**Syntax:** **AT#AUTODISCTIMER=<value>**

AT#AUTODISCTIMER? Read or display the current setting (or AT#VAUTODISC, AT#VALL).

**Values:** 0 to 60 seconds

**Default:** 10

### #AUTODISCPORT – Auto Discovery Port

**Description:** This command sets the Auto Discovery port.

**Syntax:** **AT#AUTODISCPORT=<value>**

AT#AUTODISCPORT? Read or display the current setting (or AT#VAUTODISC, AT#VALL).

**Values:** 0 to 65535

**Default:** 1020

### #AUTODISCHOST – Set Auto Discover Host Name

**Description:** This command sets the Host Name that will appear in the Auto Discovery Manager.

**Syntax:** **AT#AUTODISCHOST = "<value>"**

AT#AUTODISCHOST? Read or display the current setting (or AT#VAUTODISC or AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters.

**Default:** MT100SEM

## #AUTODISCUSERNAME – Set Auto Discover User Name

**Description:** This command sets the User Name that will appear in the Auto Discovery Manager.

**Syntax:** **AT#AUTODISCUSERNAME =<setting>**  
AT#AUTODISCUSERNAME? Read or display the current setting (or AT#VAUTODISC or AT#VALL).

**Values:** Text string up to 120 characters. No default.

## #AUTODISCPASSWORD – Sets Auto Discover Password

**Description:** This command sets the Password that will appear in the Auto Discovery Manager.

**Syntax:** **AT#AUTODISCPASSWORD =<setting>**  
AT#AUTODISCPASSWORD? Read or display the current setting (or AT#VAUTODISC or AT#VALL).

**Values:** Text string up to 120 characters. No default.

## Display Command

### #VAUTODISC – Display Auto Discovery Commands

**Description:** This command displays all the AT# parameters related to the Auto Discovery configuration.

**Syntax:** **AT#VAUTODISC**

**Example:**

```
#AUTODISC: 1
#AUTODISCPORT: 1020
#AUTODISCTIMER: 10
#AUTODISCHOST: MT100SEM
#AUTODISCUSERNAME: "admin"
#AUTODISCPASSWORD: ""
```

# **Part 3 – AT Commands for SocketWireless Wi-Fi Devices**

**Chapter 10 – IP AT Commands for the SocketWireless Wi-Fi**

**Chapter 11 – General AT Commands for the SocketWireless Wi-Fi**

**Chapter 12 – Telnet AT Commands for the SocketWireless Wi-Fi**

**Chapter 13 – WLAN AT Commands for the SocketWireless Wi-Fi**

# Chapter 10 – IP AT Commands for the SocketWireless Wi-Fi

## Set Commands

### #DHCP – DHCP On or Off

**Description:** Enables or disables the DHCP client. If the DHCP client is enabled, the module will take the IP address from DHCP server. If DHCP client is disabled, the module will take the static IP address configured for the module.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#DHCP=<0,1>**

AT#DHCP? Read or display the current setting.

**Values:** **0** - Turn off DHCP (sets IP Address, Netmask, and Gateway back to defaults)

**1** - Turn on DHCP (automatically assigns IP Address, Netmask, and Gateway)

**Default:** **0**

### #IPADDR – Set Static IP Address

**Description:** Sets the static IP Address.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#IPADDR="<IP Address value>"**

AT#IPADDR? Read or display the current setting.

**Values:** IP Address in dotted decimal notation (**xxx.xxx.xxx.xxx**) "x" stands for a number between 0-255. 255 is the maximum value in an xxx group.

**Default:** **192.168.2.3**

### #IPGATEWAY – Set Gateway Address

**Description:** Sets the default gateway address. The view of get command shows whether the address is statically configured or obtained from the DHCP server.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#IPGATEWAY="<gateway address value>"**

AT#IPGATEWAY? Read or display the current setting.

**Values:** IP Address in dotted decimal notation (**xxx.xxx.xxx.xxxx**). "x" = a number between 0-255.

**Default:** **192.168.2.1**

## #IPNETMASK – Set Subnet Mask

**Description:** Sets the subnet mask.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#IPNETMASK="<Subnet Mask value>"**

AT#IPNETMASK? Read or display the current setting.

**Values:** IP Address in dotted decimal notation (xxx.xxx.xxx.xxxx). "x" = a number between 0-255.

**Default:** **255.255.255.0**

## #IPDNSSERV – Configure the DNS Server

**Description:** Enables the DNS server. By default, DNS is enabled. Use this command before using DNS services.

**Syntax:** **AT#IPDNSSERV**

**Values:** **0** - Disables DNS

**1** - Enable DNS

**Default:** **1** (Enable DNS)

## #DNSSERV1 – Set DNS Server IP Address

**Description:** In order to translate the server names from literal format into IP addresses, the TCP/IP stack software implements the Domain Name System (DNS) protocol. The DNS Server IP address must be specified for use by the TCP/IP stack software.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#DNSSERV1="<value>"**

AT#DNSSERV1? Read or display the current setting.

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx).

**Default:** **202.56.215.6**

## #DNSSERV2 – Set Secondary DNS Server

**Description:** In order to translate the server names from literal format into IP addresses, the TCP/IP stack software implements the Domain Name System (DNS) protocol. The DNS Server IP address has to be specified for use by the TCP/IP stack software. This secondary DNS server is used in the case where the primary DNS server does not respond to a request.

**Syntax:** **AT#DNSSERV2="<value>"**

AT#DNSSERV2? Read or display the current setting.

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx).

**Default:** **202.56.230.6**

**Note:** The Universal IP resolver (DNS Client) has a list that holds up to 4 DNS servers, the first 2 in the list are populated by the #DNSSERV1 and #DNSSERV2 commands, the 3rd and 4th are populated by DNS information provided by the ISP or cellular carrier. The list is checked in order (1-4). This means that user configured name servers will be checked before dynamically assigned name servers.

## #IPRELEASE – Release a DHCP Address Assigned by the Server

**Description:** In order to gracefully release a DHCP address assigned by the server, the module should issue a command of DHCPRELEASE.

**Syntax:** **AT#IPRELEASE**

**Response:** **AT#IPRELEASE** returns **OK**

## #IPRENEW – Renew the DHCP Information from the Server

**Description:** The DHCP client can renew the DHCP information from the server. On completion of lease time, the DHCP client will automatically renew the DHCP information. Before that, if the client wants to renew the information, it can use this command.

**Syntax:** **AT#IPRENEW**

**Response:** **AT#IPRENEW** returns **OK**

## #IPQUERY – Give a Domain Name

**Description:** Sends a query to the DNS server to resolve the name

**Syntax:** **AT#IPQUERY=<Host Name>**

**Response:** **OK**

**Values:** Host name in alpha-numeric string format. Example: [www.google.com](http://www.google.com). No default.

## #IPRESOLV – Is There a Connection with DNS or Not

**Description:** If the DNS client is successful in resolving the host name, this command shows the IP address of the resolved host name. If the DNS client fails to resolve, it shows error message.

**Syntax:** **AT#IPRESOLV=<Host Name>**

**Values:** Host name in alpha-numeric string format. No default.

## S0= – Automatic Answer

**Description:** Sets automatic answering of TCP or UDP connections.

**Syntax:** **ATS0=**

**Values:** 0 - Manually answer  
1 - Automatically answer  
No default.

## Display Commands

### #IPDNSTABLE – Display DNS Table

**Description:** This command displays the DNS table containing the list of queried Host names, corresponding to their resolved IPs.

**Syntax:** AT#IPDNSTABLE

**Response:** AT#IPDNSTABLE returns Name: WWW.GOOGLE.COM, IP Address: 59.100.107.97  
OK

**Values:** None

### #VDNS – Display Configuration of DNS Servers

**Description:** This command displays all AT# parameters related to the configuration of the DNS servers.

**Syntax:** AT#VDNS

**Response:**

```
#DNSSERV1: "0.0.0.0"  
#DNSSERV2: "0.0.0.0"  
OK
```

**Values:** None

### #VIP – View Address Settings

**Description:** Displays the address settings.

**Syntax:** AT#VIP

**Response:**

```
#DHCP: 0  
#IPADDR: "192.168.1.100"  
#IPNETMASK: "255.255.255.0"  
#IPGATEWAY: "192.168.1.1"  
#MACADDR: "00:08:00:12:34:dd" (Mac address is displayed)  
#DNSSERV1: "0.0.0.0"  
#DNSSERV2: "0.0.0.0"  
OK
```

**Values:** None

**Example:** The order and content is as follows:

```
DHCP (Enable/Disable)  
IP address  
Subnet Mask  
Default Gateway  
MAC address  
Primary DNS  
Secondary DNS
```

# Chapter 11 – General AT Commands for the SocketWireless Wi-Fi

## Set Commands

### A – Manual Answer of TCP or UDP Connection

**Description:** Manual answer of a TCP or UDP connection.

**Syntax:** ATA

**Example:**

1. AT#WLANENABLE=1
2. Give command ATS0=0
3. Connect a TCP connection using command AT#TCPSTART=1/2  
OK  
RING... <ATA is issued>
4. Ok\_Info\_WaitingForData

### S2 – Escape Sequence

**Description:** Use this command to change the character for the escape sequence.

**Syntax:** Set Value: **ATS2=<+>**

**Values:** 'c' value, which is used as the escape sequence

**Default:** '+'

**Example:**

```
ATS2?  
+  
OK  
ATS2=+  
OK  
ATS2?  
+  
OK
```

### A/ – Previous Command

**Description:** This command executes the previous command.

**Syntax:** A/

**Values:** No parameter values.

## #BOOTMSG – Enable/Disable Boot Message

**Description:** Enables/disables the boot message.

**Syntax:** **AT#BOOTMSG=<0,1>**  
AT#BOOTMSG? Read or display the current setting.

**Values:** **0** - Disable  
**1** - Enable

**Default:** **1** Enable

**Examples:** AT#BOOTMSG?  
0  
OK  
AT#BOOTMSG=1  
OK  
AT#BOOTMSG?  
1  
OK  
AT#BOOTMSG=0  
OK

## #WATCHDOG – Enable/Disable Watchdog

**Description:** Enable/disable Watchdog for the system – reset on HANG.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WATCHDOG=<0,1>**  
**AT#WATCHDOG?**

**Values:** **0** - Disable Watchdog  
**1** - Enable Watchdog

**Default Value:** **1** Enable Watchdog

**Example:** AT#WATCHDOG?  
1  
OK

## #WATCHDOGTIMER – Watchdog Timer

**Description:** Sets the Watchdog timer in milliseconds.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WATCHDOGTIMER=<value>**  
AT#WATCHDOGTIMER? Read or display the current setting.

**Values:** Maximum milliseconds that can be entered is 7000

**Default:** 1000ms

**Example:** AT#WATCHDOGTIMER?  
4000  
OK

# Chapter 12 – Telnet AT Commands for the SocketWireless Wi-Fi and the SocketEthernet IP

**NOTE:** The Telnet commands are used by the SocketEthernet IP (MT100SEM-IP) and the SocketWireless Wi-Fi (MT810SWM-IP).

## Set Commands

### #TELNET – Start/Stop Telnet Session

**Description:** Starts and stops a Telnet session.  
**Note:** The module must be reset to put the command into effect.  
**Syntax:** **AT#TELNET=<0,1>**  
                AT#TELNET? Read or display the current setting.  
**Values:**      **0** - Stop Telnet session.  
                **1** - Start Telnet session; wait for remote to Telnet in.  
**Default:**     **0**  
**Example:**    AT#TELNET?  
                0  
                OK

### #TELNETPORT– Set Telnet Port

**Description:** Sets Telnet port.  
**Note:** The module must be reset to put the command into effect.  
**Syntax:** **AT#TELNETPORT = <port number>**  
                AT#TELNETPORT? Read or display the current setting (or AT#VTELNET or AT#VALL)  
**Values:**      1 to 65535  
**Default:**     **23**  
**Example:**    AT#TELNETPORT?  
                23  
                OK

### #TELNETUSER – Set Telnet User

**Description:** Sets Telnet user.  
**Note:** The module must be reset to put the command into effect.  
**Syntax:** **AT#TELNETUSER= “<64 char string>”**  
                AT# TELNETUSER? Read or display the current setting (or AT#VTELNET or AT#VALL).  
**Default:**     **admin**  
**Example:**    AT#TELNETUSER?  
                admin  
                OK

## #TELNETPASSWORD – Set Telnet Password

**Description:** Sets Telnet password.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT# TELNETPASSWORD = “<64 char string>”**

AT# TELNETPASSWORD? Read or display the current setting (or AT#VTELNET or AT#VALL).

**Default:** “ ”

**Example:** AT#TELNETPASSWORD?

admin

OK

## Display Command

### #VTELNET – View Telnet Settings

**Description:** Displays all Telnet settings.

**Syntax:** **AT# VTELNET**

**Example:** AT#VTELNET

#TELNET: 0

#TELNETPORT: 23

#TELNETUSER: "admin"

#TELNETPASSWORD: "admin"

OK

# Chapter 13 – WLAN AT Commands for the SocketWireless Wi-Fi

## Set Commands

### #WLANSECURITYMODE – Security Mode of WLAN Module

**Description:** Sets the Wireless LAN security mode.  
**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANSECURITYMODE =<value>**  
**AT#WLANSECURITYMODE?** Read or display the current setting.

**Values:** **0** - Security Disable  
**1** - WEP64 Security  
**2** - WEP128 Security  
**3** - WPA Security  
**4** - WPA2 Security

**Default:** **0** Security Disable

### #WLANNETWORKMODE – WLAN Network Mode

**Description:** Sets the wireless LAN network mode.  
**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANNETWORKMODE =<value>**  
**AT#WLANNETWORKMODE?** Read or display the current setting.

**Values:** **0** - Infrastructure mode  
**1** - Ad – Hoc mode

**Default:** **0** Infrastructure mode

### #WLANCOUNTRYCODE – Country Code

**Description:** Sets country code. Different countries have different restrictions on Wireless LAN parameters like operating channels and transmit power. To make it operable, the country code can be set by using this AT command.  
**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANCOUNTRYCODE = "<value>"**  
**AT#WLANCOUNTRYCODE?** Read or display the current setting.

**Values:**

- Country Code FCC - US:**
  - AT#WLANCOUNTRYCODE="DOMAIN\_FCC"
  - Supported Channels - Channel 1 to channel 11
- Country Code IC - Canada:**
  - AT#WLANCOUNTRYCODE="DOMAIN\_IC"
  - Supported Channels - Channel 1 to channel 11
- Country Code ETSI - Europe:**
  - AT#WLANCOUNTRYCODE="DOMAIN\_ETSI"
  - Supported Channels - Channel 1 to channel 13
  - Supported Channels - Channel 10 to channel 13

**Default:** **DOMAIN\_FCC (For US)**

## #WLANSCANMODE – Scanning Mode

**Description:** Sets scanning mode. The module can work in both active scanning and passive scanning modes. In active scanning, the module actively sends a probe request to associate with the AP, and in passive scanning, the module waits for a beacon from the AP and then it associates.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANSCANMODE=<value>**  
AT#WLANSCANMODE? Read or display the current setting.

**Values:** **0** - Active scanning  
**1** - Passive scanning

**Default:** **0** Active scanning

## #WLANSSID – SSID of WLAN

**Description:** Sets the WLAN network SSID.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANSSID="<value>"**  
AT#WLANSSID? Read or display the current setting.

**Values:** Alphanumeric ASCII Text String of up to 32 characters. It will take a blank space also.

**Default:** mt810swm\_disable

## #WLANDATARATE – WLAN Transmission Data Rate

**Description:** Sets the WLAN transmission data rate. "Auto" can be used for auto data rate during data transfer.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANDATARATE=<value>**  
AT#WLANDATARATE? Read or display the current setting.

**Values:** Auto, 1, 2, 5.5, 9, 11, 12, 24, 36, 48, 54 (in Mbps)

**Default:** 11 (in Mbps)

## #WLANIBSSCHANNEL – Channel for Ad-Hoc Mode

**Description:** Sets channel for Ad-Hoc mode.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANIBSSCHANNEL=<value>**  
AT#WLANIBSSCHANNEL? Read or display the current setting.

**Values:** 1 – 13 (See Country Code for limit)

**Default:** 9

## #WLANCONNECT – Connect with AP

**Description:** Connects the module with AP.

**Syntax:** **AT#WLANCONNECT**

**Values:** None

**Example:** AT#WLANCONNECT

SSID : WestConfRoom

RSSI : -52

Network : BSS

Security : No Enc

Capability : 0x1

Channel : 5

WLAN Mode : B Mode

BSSID : 00:13:D3:7B:A3:6A

OK

## #WLANDISCONNECT – Disconnect with AP

**Description:** Disconnects the module with AP.

**Syntax:** **AT#WLANDISCONNECT**

**Values:** None

**Example:** AT#WLANDISCONNECT

OK

## #WLANENABLE – Auto Connect Module with AP

**Description:** On power up, this parameter determines whether to connect to the AP automatically or manually. Connection to the AP can be established by **AT#WLANCONNECT** command. A value of 0 means the module will not connect to AP automatically. A value of 1 means that on power up the module tries to connect to the AP for configured settings.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANENABLE=<value>**

AT#WLANENABLE? Read or display the current setting.

**Values:** 0 - Manual connection to the AP

1 - Automatic connection to the AP

**Default:** 0

## #WLANDOZE= – Moves Module into or out of Power Save

**Description:** This command moves the module into or out of Power Save during an active connection.

**Syntax:** **AT#WLANDOZE=**

AT#WLANDOZE? Read or display the current setting.

**Values:** 0 - Power active mode

1 - Power doze mode

## #WLANPROFILEn=n – Change the WLAN Profile

**Description:** This command changes the WLANPROFILE.

**Syntax:** AT#WLANSETPROFILEn=n,"<SSID>",<Security Mode>,<Key Index>,"< Passphrase>"  
AT#WLANSETPROFILEn?

**Values:** 1, 2, 3, 4

**Parameters:** **ssid** = up to 32 characters ssid  
**security mode** = 0 (no encryption)

1 (wep64)

2 (wep128)

3 (wpa-psk)

4 (wpa2-psk)

**keyindex** = 1 to 4 applicable for security option (1-4)

**passphrase** = ASCII text string of *hexadecimal numbers* applicable for security modes 1-2.

passphrase = ASCII *text string* applicable for security modes 3-4.

(10 ASCII text string of *hexadecimal numbers* for wep64)

(26 ASCII text string of *hexadecimal numbers* for wep128)

(8-63 ASCII *text string* for wpa-psk)

(8-63 ASCII *text string* for wpa2-psk)

**Notes:** **Keyindex** and **passphrase** are not applicable for security option (0)

**Examples:** AT#WLANPROFILE1=1,"MT\_NOENC",0 (for no encryption mode)

AT#WLANPROFILE2=2,"MT\_WEP64",1,1,"1234567890" (for wep64 key)

AT#WLANPROFILE3=3,"MT\_WEP128",2,1,"12345678901234567890123456" (for wep128)

AT#WLANPROFILE4=4,"MT\_WPA",3,1,"12345678" (for WPA psk mode)

AT#WLANPROFILE4=4,"MT\_WPA2",4,1,"12345678" (for WPA2 psk mode)

## #WLANSAN – Scan Wireless Networks

**Description:** Scans all the APs (access points) in the environment and displays information about their settings and capabilities on HyperTerminal or similar program.

**Syntax:** AT#WLANSAN

**Example:** ESSID: Plan B

BSSID: 00:08:00:C0:30:99

Channel Num: 6

RSSI: -61

Network Type: BSS

Security: No Enc

Capability: 0x1

WLAN Mode: B Mode

## #WLANUSEPROFILE – User Profile

**Description:** Sets and displays the user profile value. If user profile value is set to any value between 1 and 4, then at the time of user name association, the module first scans for the selected user profile parameters.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANUSEPROFILE=<value>**

AT#WLANUSEPROFILE? Read or display the current setting.

**Values:** 1 – 4

## #WLANGETRSSI – Received Signal Strength

**Description:** This command displays the current received signal strength.

**Syntax:** **AT#WLANGETRSSI**

**Values:** The response returns a signal strength value from -256 dBm through -1 dBm.

**Note:** A value of 0 equals no connection to an access point.

**Example:** AT#WLANGETRSSI

RSSI : 0

OK

## #WLANACTIVATE – Move Module out of Power Save

**Description:** This command moves the module out of Power Save during an active connection. See #WLANDOZE

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANACTIVATE**

**Values:** NA

## #WLANROAM – Enable/Disable Roaming

**Description:** This command enables/disables automatic roaming of the module when the wireless connection is lost by the Access Point.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WLANROAM**

**Values:** 0 - Disable Auto Roam

1 - Enable Auto Roam

**Default:** 1

## #WEP64KEY – Keys for WEP64 Security Mode

**Description:** Sets keys for WEP64 Security mode.

**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WEP64KEYn = "<value>"**

AT#NWEP64KEYn? Read or display the current setting.

**Values:** ASCII text string of 10 hexadecimal characters. Valid characters include 0-9, a-f or A-F

**Default:** 6162636465

## #WEP128KEY – Keys for WEP128 Security Mode

**Description:** Sets keys for WEP128 Security mode.  
**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WEP128KEYn = "<value>"**  
**AT#WEP128KEYn?** Read or display the current setting.

**Values:** ASCII text string of 26 hexadecimal characters; valid characters include: 0-9, a-f or A-F

**Default:** 12345678901234567890123456

## #WPAPSKKEY – Keys for WPA PSK Security Mode

**Description:** Sets keys for WPA PSK security mode.

**Syntax:** **AT# WPAPSKKEYn = "<value>" n=1-4**  
**AT# WPAPSKKEYn?** Read or display the current setting.

**Values:** ASCII text string of 8 to 64 hexadecimal characters; e.g., 1234567890. They can include any ASCII character from 32-126 decimal.

**Default:** 1234567890

## #WPA2PSKKEY – Keys for WPA2 PSK Security Mode

**Description:** Sets keys for WPA2 PSK security mode.

**Syntax:** **AT# WPA2PSKKEYn = "<value>" n=1-4**  
**AT# WPA2PSKKEYn?** Read or display the current setting.

**Values:** ASCII text string of 8 to 64 hexadecimal characters; e.g., 1234567890. They can include any ASCII character from 32-126 decimal.

**Default:** 1234567890

## #WEPEKEYID – Set the Default TX Key Index

**Description:** Sets the default Transmission Key used for data encryption in WEP.  
**Note:** The module must be reset to put the command into effect.

**Syntax:** **AT#WEPEKEYID=<value>**

**Values:** 1 – 4

**Default Value:** 1

**Example:** AT#WEP?  
WEPEKEYID:1  
OK

## #WLANTPOWERSAVE – Enable Power Save at Boot

**Description:** This command sets the Power Save at the Boot Works after the Power Cycle.

**Syntax:** **AT#WLANTPOWERSAVE=<value>**

**Values:** 0 - Power Save Disabled  
1 - Power Save Enabled

**Default:** 0

## Display Commands

### #WEP? – See the Value of the WEP Keys

**Description:** This command displays the values of the WEP keys.

**Syntax:** **AT#WEP?**

**Values:**

```
WEP64KEY1:"6162636465"
WEP64KEY2:"6162636465"
WEP64KEY3:"6162636465"
WEP64KEY4:"6162636465"
WEP128KEY1:"12345678901234567890123456"
WEP128KEY2:"12345678901234567890123456"
WEP128KEY3:"12345678901234567890123456"
WEP128KEY4:"12345678901234567890123456"
WPAPSKKEY1:"1234567890"
WPAPSKKEY2:"1234567890"
WPAPSKKEY3:"1234567890"
WPAPSKKEY4:"1234567890"
WPA2PSKKEY1:"1234567890"
WPA2PSKKEY2:"1234567890"
WPA2PSKKEY3:"1234567890"
WPA2PSKKEY4:"1234567890"
```

### #WLANPROFILE – Display the WLAN Profile

**Description:** This command displays the WLAN profile parameters based on the profile ID.

**Syntax:** **AT#WLANSETPROFILE<value>?**

**Values:** 1 – 4

**Examples:** AT#WLANPROFILE1?

```
profile id :1
SSID :Adhoc
security :0
OK

AT#WLANPROFILE2?
profile id :2
SSID :mt810swm_wep64
security :1
Keyindex :1
passphrase :1234567890
OK
```

```
AT#WLANPROFILE3?
profile id :3
SSID :mt810swm_wep128
security :2
Keyindex :1
passphrase :12345678901234567890123456
OK
```

```
AT#WLANPROFILE4?
profile id :4
SSID :mt810swm_wpapsk
security :3
Keyindex :1
passphrase :12345678
OK
```

## #WLAN? – WLAN Module

**Description:** Displays WLAN module-related information.

**Syntax:** **AT#WLAN?**

<b>Values:</b>	SECURITYMODE	SSID
	NETWORKMODE	IBSSCHANNEL
	COUNTRYCODE	DATARATE
	SCANMODE	WLANENABLE
	TXPOWER(dBm)	MACADDR

**Default:** None

**Example:** AT#WLAN?

```
#SECURITYMODE: 0
#NETWORKMODE: 0
#COUNTRYCODE: "DOMAIN_FCC"
#SCANMODE: 0
#TXPOWER: NA
#SSID: "WestConfRoom"
#IBSSCHANNEL: 9
#DATARATE: 11.0
#WLANENABLE: 0
#MACADDR: "00:08:00:12:34:dd"
OK
```

## #WLANASSOCINFO – Display Association Information

**Description:** This command displays the channel and BSSID of the current association.

**Syntax:** **AT#WLANASSOCINFO**

**Values:** NA

**Example:** AT#WLANASSOCINFO

```
SSID : WestConfRoom
RSSI : -52
Network : BSS
Security : No Enc
Capability : 0x1
Channel : 5
WLAN Mode : B Mode
BSSID : 00:13:D3:7B:A3:6A
OK
```

# **Part 4 – AT Commands for the SocketModem iCell, SocketModem IP, MultiModem iCell**

**Chapter 14– AT Commands for the Following Devices:**

- SocketModem iCell**
- SocketModem IP (when in IP mode)**
- MultiModem iCell (when in IP mode)**

# Chapter 14 – AT Commands for the SocketModem iCell, SocketModem IP, MultiModem iCell

**These commands are for the following products**

SocketModem iCell (MTSMC-G2-IP)

SocketModem iCell (MTSMC-C1-Nx-IP)

SocketModem IP (MT5692SMI-IP) This SocketModem uses these commands when it is in IP mode.

MultiModem iCell (MTCMR-xx-xx) This MultiModem uses these commands when it is in IP mode.

## Set Commands

### +WOPEN – Set IP Mode or Modem Mode

**Description:** This command sets the mode of operation.

**Syntax:** **AT+WOPEN=<value>**

AT+WOPEN? (Displays the current mode of operation).

**Values:** 0 – Modem Mode

1 – IP Mode

**Default:** 1

### #AUTHENT – Authentication Type

**Description:** This command sets the PPP authentication type: PAP, CHAP, or NONE.

**Syntax:** **AT#AUTHENT="<value>"**

AT#AUTHENT? (Displays current PPP authentication type).

**Values:** PAP

CHAP

NONE

**Default:** NONE

## #ANSWERMODE – Set Answering Mode

<b>Description:</b>	The TCP/IP stack can handle incoming calls. This parameter defines how the TCP/IP stack will behave when receiving an incoming call.
<b>Syntax:</b>	<b>AT#ANSWERMODE=&lt;value&gt;</b> AT#ANSWERMODE? Read or display the current setting (or AT#VPHY, AT#VALL).
<b>Values:</b>	<p><b>0 - Ignore.</b> Ignores the incoming call. In this case, it is the responsibility of the host to accept/not accept the incoming call by issuing the AT#ACCEPT command.</p> <p><b>1 - Automatic Answer.</b> The TCP/IP stack goes off hook and accepts the incoming call. As described below, the calling number must match the one specified in the CALLSCREENNUM parameter. (The RINGCOUNT parameter must be &gt; 0).</p> <p><b>2 - Static Callback.</b> The TCP/IP stack ignores the incoming call and then automatically dials (DIALN1 or DIALN2 determined by the DIALSELECT parameter) by issuing an AT#CONNECTIONSTART command. The calling number must match the one specified in the CALLSCREENNUM parameter. The RINGCOUNT parameter must be &gt; 0.</p> <p><b>3 - Dynamic Callback.</b> The TCP/IP stack ignores the incoming call and then automatically dials the calling number by issuing an AT#CONNECTIONSTART command. For this feature, the Caller ID service is mandatory. As described below, the calling number must match the one specified in the CALLSCREENNUM parameter.</p> <p><b>4 - Automatic Connection Using SMS.</b> The TCP/IP stack matches the message from an incoming SMS message to the #SMSPHRASE parameter. If a match occurs, #CONNECTIONSTART is issued. (The RINGCOUNT parameter must be 0).</p>
<b>Default:</b>	<b>0</b>
	<p><b>Note:</b> If #ANSWERMODE is set to a value other than 0, the user must enable caller ID. To enable caller ID, use the command <b>AT+CLIP=1</b>.</p> <p><b>Note:</b> A wake-up SMS message will <b>NOT</b> work if the device is busy.</p>

## #SMSPHRASE – Set Incoming SMS Phrase

<b>Description:</b>	When receiving an incoming SMS and #ANSWERMODE=4, the SMS message allows the TCP/IP stack to identify a specific message from the sender. This information is helpful in preventing unauthorized SMS to trigger actions on the TCP/IP stack.
	<p><b>Notes:</b> <b>A setting of 0 (zero) disables all remote SMS messages.</b>  <b>This command is for all devices except the SocketWireless Wi-Fi (MT810SWM-IP)</b></p>

<b>Syntax:</b>	<b>AT#SMSPHRASE="&lt;parameter1&gt;"</b> AT#SMSPHRASE? Read or display the current setting.
<b>Values:</b>	parameter 1 value = 160 character alphanumeric string
<b>Responses:</b>	\r\n#SMSPHRASE: "VALUE"\r\n\r\nOK\r\n\r\nERROR\r\n

### Command Example(s):

```
send : AT#SMSPHRASE="password"\r
reply : \r\nOK\r\n
send : AT#SMSPHRASE?\r
reply : \r\n#SMSPHRASE: "password"\r\n
reply : \r\nOK\r\n
```

## #CALLBACKTIMER – Set Automatic Call-Back Wait

**Description:** This parameter defines the number of seconds the TCP/IP stack will wait before an automatic call-back operation occurs after receiving an incoming call. It applies only when the ANSWERMODE parameter is set to an automatic call-back mode (value>1). This timer starts at the end of the ringing signal.

**Syntax:** **AT#CALLBACKTIMER=<value>**

AT#CALLBACKTIMER? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Integer between 2 and 255 inclusive. This timer is set in seconds.

**Default:** 2

## #CALLSCREENNUM – Set Caller ID Service

**Description:** When receiving an incoming call, the caller identification (Caller ID) service allows the TCP/IP stack to identify the phone number of the remote caller. This information is helpful in preventing unauthorized callers to trigger actions on the TCP/IP stack.

This parameter allows the user to filter the incoming calls when the ANSWERMODE parameter is set to an automatic mode (value>0). This filtering doesn't apply when the ANSWERMODE parameter is set to 0. In this case, it is the host's responsibility to accept or reject the incoming call. If an incoming phone number is not authorized, the TCP/IP stack will ignore it.

**Syntax:** **AT#CALLSCREENNUM=<value>**

AT#CALLSCREENNUM? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** 0 - Zero. Remote caller not authorized.

\* - All. No filtering is applied on incoming calls. All remote phone numbers are authorized. This value must be set to receive incoming calls when Caller ID service is not available.

**Not valid for Analog Devices.**

**Decimal Phone Number.** Only the phone number configured here is authorized for incoming calls. Alphanumeric ASCII text string up to 64 characters.

**Default:** 0

## #KEEPALIVEMODE – Keep-Alive Mode

**Description:** If the keep-alive mode is not equal to zero, then the keep-alive function will trigger. The function allows a persistent physical connection to be established. If enabled and a remote host is not reached, the physical connection is disconnected (if connected) and reestablished.

**Syntax:** **AT#KEEPALIVEMODE=<Keepalivemode value>**

AT#KEEPALIVEMODE? Read or display the current setting (or AT#VKEEPALIVE or AT#VALL).

**Values:** 0 - Keep-Alive mode is disabled

1 - Keep-Alive mode is enabled using a TCP connection

2 - Keep-Alive mode is enabled using ICMP

**Default:** 0

**Example:** AT#KEEPALIVEMODE=1

## #KEEPALIVEPORT – Keep-Alive Port Number

**Description:** If the keep-alive session is TCP, then keep alive port controls the remote host port number.

**Syntax:** **AT#KEEPALIVEPORT=<Port Number value>**  
**AT#KEEPALIVEPORT?** Read or display the current setting (or AT#VKEEPALIVE or AT#VALL)

**Values:** Set the port number that the Profile will use:  
From 1 to 5 numeric digits (0 to 9).

**Note:**  
Numbers above 65535 are illegal since port identification fields are 16-bits long in the IDP header.

**Default:** 1

**Example:** AT#KEEPALIVEPORT=xxxxx

## #KEEPALIVESERV – Keep-Alive Server Address

**Description:** The remote address for both TCP and ICMP keep-alive.

**Syntax:** **AT#UDPSERV=""**  
**AT#KEEPALIVESERV?** Read or display the current setting (or AT#VKEEPALIVE or AT#VALL).

**Values:** Set the Remote Server Address value that the Profile will use:  
32-bit number is dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or  
Alphanumeric ASCII text string up to 120 characters if DNS is working.

**Default:** None

**Example:** AT#KEEPALIVESERV="xxx.xxx.xxx.xxx" or AT#KEEPALIVESERV="some.address.com"

## #KEEPALIVEDELAY – Keep-Alive Delay

**Description:** This parameter determines the delay before the keep-alive mechanism will check the remote host for connectivity.

**Syntax:** **AT#KEEPALIVEDELAY=<Data Delay value>**  
**AT#KEEPALIVEDELAY?** Read or display the current setting (or AT#VKEEPALIVE or AT#VALL).

**Values:** Set the delay value in minutes  
Integer between 0 and 65535

**Default:** 100

**Example:** AT#KEEPALIVEDELAY=xxxxx

## #OUTPORT – UDP/TCP Local Port Number

**Description:** Controls the local port that the UDP/TCP connection is bound to.

**Syntax:** **AT#OUTPORT=<Port Number value>**  
**AT#OUTPORT?** Read or display the current setting (or AT#VKEEPALIVE or AT#VALL).

**Values:** Set the port number local connection will use:  
From 1 to 5 numeric digits (0 to 9).

**Note:**  
Numbers above 65,535 are illegal since port identification fields are 16-bits long in the IDP header.

**Default:** 0

**Example:** AT#OUTPORT=xxxxx

## #ATCMD – Customize Dial-Up Commands

**Description:** This command allows the user to customize AT commands on dial up.

**Syntax:** **AT#ATCMD=id,"Valid AT command"**

AT#ATCMD=id or AT#VALL

**id:** Enter a Profile Setting: 0, 1, 2, 3 {0,1,2,3}

**Values:** Set the valid AT command (Do not include AT or issue &F, as the command will error)

**Defaults:** **For Analog Devices:** 0, "-STE=1"  
1, "+MS=V34"  
2, ".."  
3, ".."

**For All Other Devices:** 0, ".."  
1, ".."  
2, ".."  
3, ".."

## #REDIALCOUNT – Set Connection Attempts Allowed

**Description:** This parameter indicates how many unsuccessful connection attempts the TCP/IP stack software will make before terminating the connection attempt activity.

**Syntax:** **AT#REDIALCOUNT=<value>**

AT#REDIALCOUNT? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Integer between 0 and 14, inclusive.

If the value is set to 0, the TCP/IP stack software will not make any call retry.

**Default:** 5

## #REDIALDELAY – Set Call Retry Delay

**Description:** This parameter controls the delay (in seconds), if any, that will exist between each call retry.

**Syntax:** **AT#REDIALDELAY=<value>**

AT#REDIALDELAY? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Integers 0 and 5–14 inclusive.

If this parameter is configured to zero, the TCP/IP stack software will attempt another connection immediately after terminating the previous unsuccessful attempt.

**Default:** 5

## #PHYTIMEOUT – Set Inactivity Time

**Description:** This parameter is used by the TCP/IP stack software in order to terminate connections to the telephone line when a long period elapses without activity. “Without activity” is defined as a period when no data is transferred between the Internet and the TCP/IP stack software or between the TCP/IP stack software and the attached equipment. This timer prevents the telephone line from being connected indefinitely for any reason.

**Note:** When the inactivity timer expires, the modem ends the communication.

**Syntax:** **AT#PHYTIMEOUT=<value>**

AT#PHYTIMEOUT? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Integer between 1 and 255 inclusive. This timer is set in minutes.

**Default:** 15

**Return Codes:** TIMEOUT: The inactivity timer is reached; the modem ends the communication.

## #RINGCOUNT – Set Number of Rings/Automatic Operation

**Description:** This parameter defines the number of rings that will be counted before an automatic operation occurs when receiving an incoming call.

It applies only when the ANSWERMODE parameter is set to an automatic mode (value>0).

If the ANSWERMODE parameter is used, the RINGCOUNT value must also be >0.

**Syntax:** **AT#RINGCOUNT=<value>**

AT#RINGCOUNT? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Integer between 0 and 15 inclusive.

0 = modem will not answer.

1-15 = modem will answer on the ring number selected.

**Default:** 0

## #DIALN1 – Set Primary Dial-Up Number

**Description:** This parameter is the primary dial-up phone number that will connect with the local ISP. Length depends on country/region.

**Syntax:** **AT#DIALN1="<value>"**

AT#DIALN1? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Decimal phone numbers.

**Default:** None

## #DIALN2 – Set Secondary Dial-Up Number

**Description:** This parameter is the secondary dial-up phone number that will connect with the local ISP. Length depends on country.

**Syntax:** **AT#DIALN2="<value>"**

AT#DIALN2? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** Decimal phone numbers.

**Default:** None

## #DIALSELECT – Set Internet Connection Number

**Description:** The value of this command determines the number called to establish an Internet connection. It configures the TCP/IP stack software to use the primary dial-up number or the secondary dial-up number.

**Syntax:** **AT#DIALSELECT=<value>**  
AT#DIALSELECT? Read or display the current setting (or AT#VPHY, AT#VALL).

**Values:** 1 - se primary dial-up number.  
2 - Use secondary dial-up number

**Default:** 1

## #ISPPW – Set ISP Password

**Description:** This parameter sets the password for the ISP account. When communication is initiated and once the physical (modem) connection has been established with the ISP, the TCP/IP stack software must provide the ISP with the password associated with the account to be used.

**Syntax:** **AT#ISPPW="<value>"**  
AT#ISPPW? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 64 characters.

**Default:** None

## #ISPUN – Set ISP User Name

**Description:** This parameter sets the user name of the ISP account. When communication is initiated and the physical (modem) connection has been established with the ISP, the TCP/IP stack software must provide the ISP with the user name associated with the account to be used.

**Syntax:** **AT#ISPUN="<value>"**  
AT#ISPUN? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 64 characters.

**Default:** None

## Incoming Call Management Commands

### #ACCEPT – Answer Incoming Call

**Description:** This command directs the TCP/IP stack to answer an incoming call. When the TCP/IP stack receives an incoming call, it sends over the serial port the “RING” messages. Depending on the value of the ANSWERMODE parameter, the TCP/IP stack may answer automatically or not. If ANSWERMODE is set to 0, it is the host that is responsible for answering the incoming call. Once the physical layer is up, the TCP/IP stack runs. The AT#CONNECTIONSTOP command ends the connection by going on hook.

**Values:** **Read parameters:**

ANSWERMODE  
IPSPW  
ISPUN  
PPPMYIP

**Syntax:** **AT#ACCEPT**

Command	Possible Responses
AT#ACCEPT	OK Note: Beginning of the call setting process CONNECT <speed> Note: Modem speed negotiated between both sides xxx.xxx.xxx.xxx Note: IP address indication attributed to the TCP/IP stack PPP OK Note: The software is ready to run IP applications to send/receive data
AT#ACCEPT	NO CARRIER Note: The modem handshaking process with the remote host is interrupted or unsuccessful
AT#ACCEPT	PPP ERROR Note: The PPP negotiation has failed (check ISPUN, ISPPW, PPPMODE, and the configuration of the PPP peer)

### #CONNECTIONSTOP – Stop Communication

**Description:** This command directs the TCP/IP stack to end a communication previously established with a CONNECTIONSTART command or AT#ACCEPT.

**Values:** No TCP/IP parameter is used for the execution of this command.

**Syntax:** **AT#CONNECTIONSTOP**

Command	Possible Responses
AT#CONNECTIONSTOP	OK Note: Disconnect

## #CONNECTIONSTART – Start Communication

**Description:** This command directs the TCP/IP stack to originate an outgoing call. Upon receiving this command, the TCP/IP stack attempts to complete a connection session. The TCP/IP stack will dial the number according to the #GPRSMODE value and Dial Option parameter (DIALN1 or DIALN2 depending on DIALSELECT). If an error occurs, the TCP/IP stack automatically re-attempts the call origination attempt, according to the REDIALCOUNT parameter. Once the physical layer is up, the TCP/IP stack runs.

**Values:** **Read Parameters:**

DIALN1  
DIALN2  
DIALSELECT  
ISPPW  
ISPUN  
REDIALCOUNT  
REDIALDELAY

**Syntax:** AT#CONNECTIONSTART

Command	Possible Responses
AT#CONNECTIONSTART	<p>DIALING Note: Phone line is available 2124560123 Note: Dial DIALN1 or DIALN2 number depending on DIALSELECT CONNECT 9600 Note: Modem speed negotiated between both sides. If the TCP/IP stack is configured for modem only operation (PPPMODE parameter), there are no more return codes 213.192.200.4 Note: IP address attributed to the TCP/IP stack Ok_Info_PPP Note: As soon as the TCP/IP stack software displays this message, it is ready to receive commands</p>
AT#CONNECTIONSTART	<p>Notes: Request connection to network. This is for GPRSMODE=0.</p> <p>Ok_Info_GprsActivation Note: As soon as the TCP/IP stack software displays this message, it is ready to receive commands 213.192.200.4 Note: IP address attributed to the TCP/IP stack</p>
AT#CONNECTIONSTART	<p>BUSY Note: A busy signal is detected on the remote site TCP/IP stack will wait REDIALDELAY seconds then dial again. The redialing will continue until success or until the number of call retries defined in parameter REDIALCOUNT has been reached.</p>
AT#CONNECTIONSTART	<p>NO CARRIER Note: A physical connection could not be completed. The TCP/IP stack will wait REDIALDELAY seconds then dial again. The redialing will continue until success or until the number of call retries defined in parameter REDIALCOUNT has been reached.</p>

## #AUTOCONNECT – Automatically Connect the PPP Link

**Description:** #AUTOCONNECT enables/disables the automatic link connection. The APN or ISP values need to be set correctly.

**Values:** 0 - AUTOCONNECT disabled  
1 - AUTOCONNECT enabled

**Syntax:** AT#AUTOCONNECT=<value>  
AT#AUTOCONNECT? Read or display the current setting (or AT#VALL).

**Default:** 0

## #PPPMODE – Set TCP/IP Behavior

**Description:** The TCP/IP stack can manage the access layer in different ways. This parameter selects the way the TCP/IP stack must run once the physical layer successfully established.

**Syntax:** AT#PPPMODE=<value>  
AT#PPPMODE? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** 3 - Standard PPP. The TCP/IP stack behaves as a PPP client for outgoing calls and as a PPP client for incoming calls.

**Default:** 3

## #PPPMYIP – Set IP Address When Using PPP

**Description:** When the TCP/IP stack behaves as a PPP server (according to the PPPMODE parameter setting), it is in charge of the IP address attribution mechanism.

Once the PPP authentication is successfully achieved, the remote PPP peer asks the TCP/IP stack for an IP address. Then the related PPP layer, called IPCP, suggests an IP address to the peer that has been previously stored in the TCP/IP stack parameters. If the remote accepts this address, the IP link is then established.

This parameter defines the IP address to be attributed to the TCP/IP stack when the PPP Server mode is running.

**Syntax:** AT#PPPMYIP=<value>  
AT#PPPMYIP? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx).

**Default:** 0.0.0.0

## #PPPPEERIP – Set IP Address for Remote PPP

**Description:** When the TCP/IP stack behaves as a PPP server (according to the PPPMODE parameter setting), it is in charge of the IP address attribution mechanism.

Once the PPP authentication is successfully achieved, the remote PPP peer asks the TCP/IP stack for an IP address. Then the related PPP layer, called IPCP, suggests an IP address to the peer that has been previously stored in the TCP/IP stack parameters. If the remote accepts this address, the IP link is then established.

This parameter defines the IP address to be attributed to the remote PPP peer when the PPP Server mode is running.

**Syntax:** AT#PPPPEERIP=<value>  
AT#PPPPEERIP? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx).

**Default:** 0.0.0.0

## #PPPSERVUN – Set User Name for Remote PPP Client

**Description:** When the TCP/IP stack behaves as a PPP server (according to the PPPMODE parameter), it checks the remote PPP client login/password before granting access to the server. This parameter defines the user name that must be specified by the remote PPP client.

**Syntax:** **AT#PPPSERVUN=<value>**  
AT#PPPSERVUN? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 64 characters. No default.

## #PPPSERVPW – Set Remote PPP Client Password

**Description:** When the TCP/IP stack behaves as a PPP server (according to the PPPMODE parameter setting), it checks the remote PPP client login/password before granting access to the server. This parameter defines the password that must be specified by the remote PPP client.

**Syntax:** **AT#PPPSERVPW=<value>**  
AT#PPPSERVPW? Read or display the current setting (or AT#VPPP, AT#VALL).

**Values:** Alpha-numeric ASCII text string up to 64 characters. No default.

## #APNPW – Set Access Point Name Password

**Description:** #APNPW is the Access Point Name password parameter coming with the APNUN from the GSM operator and provides GPRS access.

**Syntax:** **AT#APNPW=<value>**  
AT#APNPW? Read or display the current setting (or AT#VGPRS, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #APNSERV – Set Access Point Name

**Description:** #APNSERV is the Access Point Name parameter coming from the GSM operator for providing GPRS access.

**Syntax:** **AT#APNSERV=<value>**  
AT#APNSERV? Read or display the current setting (or AT#VGPRS, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #APNUN – Set Access Point User Name

**Description:** #APNUN is the Access Point Name User Name parameter coming with the APNPW from the GSM operator for providing GPRS access.

**Syntax:** **AT#APNUN=<value>**  
AT#APNUN? Read or display the current setting (or AT#VGPRS, AT#VALL).

**Values:** Alphanumeric ASCII text string up to 120 characters. No default.

## #GPRSCID – Set PDP Context Identifier

**Description:** #GPRSCID is the PDP context identifier which specifies a particular PDP context definition. This parameter is local and may be used in other PDP context-related commands.

**Syntax:** **AT#GPRSCID=<value>**

AT#GPRSCID? Read or display the current setting (or AT#VGPRS, AT#VALL).

**Values:** Numeric between 1 and 4 inclusive.

**Default:** 1

## #GPRS MODE – Activate Switching Between GSM and GPRS

**Description:** #GPRS MODE configures the activation of the software for switching between GSM and GPRS.

**Syntax:** **AT#GPRS MODE=<value>**

AT#GPRS MODE? Read or display the current setting (or AT#VGPRS, AT#VALL).

**Values:** 0 – Configured for GSM use.

1 – Configured for GPRS use.

2 – Configured for CDMA use.

**Default:** 1

# Display Commands

## #DISPLAYIP – Display IP Addresses

**Description:** This command allows the attached host to view the attributed IP addresses that have been attributed during the IPCP phase of the PPP negotiation. Both local and remote PPP peer IP addresses are displayed. This command should be issued only once the PPP OK message has been received from the TCP/IP stack.

**Syntax:** **AT#DISPLAYIP**

**Response:** MY IP: xxx.xxx.xxx.xxx

PEER IP: **xxx.xxx.xxx.xxx**

**Values:** **Read Parameters:**

PPPMYIP

PPPPEERIP

## #VPPP – Display PPP Parameters

**Description:** This command directs the TCP/IP stack to display all the AT# parameters related to the PPP layer configuration.

**Values:** **Read Parameters:**

- ISPPW
- ISPUN
- PPPMYIP
- PPPPEERIP

**Syntax:** **AT#VPPP**

Command	Possible Responses
AT#VPPP	#ISPUN: "myispun" #ISPPW: "myisppwd: #PPPMODE: 1 #PPPMYIP: "0.0.0.0" #PPPPEERIP: "0.0.0.0" OK

## #VPHY – Display Physical Parameters

**Description:** This command directs the TCP/IP stack to display all the AT# parameters related to the physical layer configuration.

**Syntax:** **AT#VPHY**

Command	Possible Responses
AT#VPHY	#ANSWERMODE: 0 #CALLBACKTIMER: 2 #CALLSCREENNUM: "0" #DIALN1: "" #DIALN2: "" #DIALSELECT: 1 #PHYTIMEOUT: 15 #REDIALCOUNT: 5 #REDIALDELAY: 5 #RINGCOUNT: 0 OK

**Values:** ANSWERMODE  
CALLBACKTIMER  
CALLSCREENNUM  
DIALN1  
DIALN2  
DIALSELECT  
PHYTIMEOUT  
REDIALCOUNT  
REDIALDELAY  
RINGCOUNT

# **Part 5 – GPIO AT Commands**

## **Chapter 15 – GPIO AT Commands**

# Chapter 15 – GPIO AT Commands

## About GPIO

If the specific hardware allows GPIO (check availability with AT#GPIO=1), then you may specify certain external events from the GPIOs to trigger specific stack functions; i.e., email, upload files, download files. **In order for this to work, you must configure the specific function first.** For instance, if SENDMAIL1 will be called, then all settings pertaining to SENDMAIL1 must be configured before the #GPIO command is configured.

**Note:**

**MultiModem iCell:** The MultiModem iCell allows for the following GPIO IDs and GPIO function combinations:  
 GPIO 1 - 2: GPIO function 0 may be selected  
 GPIO 3 - 4: GPIO functions 0, 1, 2 and 3 may be selected  
 GPIO 5: GPIO function 3 may be selected

**SocketModem iCell:** The SocketModem iCell allows for the following GPIO IDs and GPIO function combinations:  
 GPIO 1 - 2: GPIO function 0 may be selected  
 GPIO 3 - 4: GPIO functions 0, 1, 2 and 3 may be selected  
 GPIO 5: GPIO 5 is non-functional

## #GPIO – Enable/Disable and Configure External GPIO Driven Events

**Description:** If GPIO is enabled and configured correctly, a specific external trigger (Digital HI/LOW or Analog value from 0-3.3V) will trigger a specified function from the stack.

**Syntax:** **AT#GPIO=ID**, GPIO Function, Trigger Level, Debounce, Stack Function, Hangup  
**AT#GPIO=<n>** where n is the GPIO number or AT#VALL

**ID:** GPIO number as described in the hardware documentation

**Values:** 1 - 5

**GPIO Function:** Allows the GPIO to be a Digital Input, Digital Output or ADC input

**Values:**  
 0 - Digital Input without internal pullup  
 1 - Digital Input with internal pullup  
 2 - Digital Output  
 3 - ADC input

**Trigger Level:** The Voltage level at which GPIO will trigger.

For Digital input, a value greater than 0 indicates high. 0 indicates low.

For Digital output, a positive value will drive the line high. A zero value will drive the line low.

For ADC input, the trigger value will be in the range of 0 to 3300 millivolts.

**Values:** 0 - 3300 in millivolts

**Debounce:** The time between successive reads on the GPIO.

**Values:** 0 - 65535 milliseconds

**Stack Function:** The desired stack function to be **specified** on a GPIO trigger. The stack function must be properly configured; i.e., for a sendmail function, all proper sendmail items must be configured.

**Values:**  
 0 - Disabled (The GPIO will not trigger)  
 1 - #SENDMAIL1  
 2 - #SENDMAIL2  
 3 - #SENDMAIL3  
 4 - #PUTMAIL  
 5 - #GETMAIL  
 6 - #LTCSTART=1  
 7 - #OTCP=1  
 8 - #OUDP=1  
 9 - #LUDPSTART=1

**Hangup:** Determines whether to disconnect from the network after GPIOs have been processed.  
**Values:** 0 - Physical connection will disconnect when all GPIOs have been processed  
 1 - Physical connection will stay connected.  
 2 - Physical connection will disconnect when all GPIOs have been processed; suppress responses  
 3 - Physical connection will stay connected; suppress responses

**Default:** 1,1,0,0,0,0,x  
 2,1,0,0,0,0,x  
 3,0,0,0,0,0,x  
 4,0,0,0,0,0,x  
 5,3,0,0,0,0,x

**Note:** The final number (represented by 'x') is variable and not supported at this time.

**Example:** AT#GPIO=1,0,1,180,1,0  
 GPIO 1 would be configured as a Digital Input with internal pullup (0).  
 A positive voltage will trigger the GPIO (1).  
 A Debounce time of 180 ms (180) will be used.  
 #SENDMAIL1 will be called if the GPIO triggers (1).  
 After processing the GPIO, the physical connection will be disconnected (0) and all responses will be printed to the user.

## #GPIOR – Read the Current Register Status of the Specified GPIO Pin

**Description:** The current status of the specific GPIO pin is displayed according to its configuration.

**Syntax:** AT#GPIOR=<parameter>

**Values:** parameter

- 1 GPIO Port 1
- 2 GPIO Port 2
- 3 GPIO Port 3
- 4 GPIO Port 4
- 5 GPIO Port 5

**Responses:** \r\n#GPIOR: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:**

**send:** AT#GPIOR=1\r

**reply:** \r\n#GPIOR: 1,1\r\n

**reply:** \r\nOK\r\n

## #GPIOtrigger – Configure the GPIO pin and trigger type

**Description:** Configure the GPIO pin and trigger type.

**Syntax:** AT#GPIOtrigger=<parameter1>,<parameter2>

**Values:** parameter 1 (GPIO pin)

- 1 - GPIO Port 1
- 2 - GPIO Port 2
- 3 - GPIO Port 3
- 4 - GPIO Port 4
- 5 - GPIO Port 5

parameter 2 (trigger type)

- 0 - Trigger at (or above for analog) (default for backwards compatibility)
  - 1 - Trigger on active to inactive
  - 2 - Trigger on inactive to active
  - 3 - Trigger on both edges
  - 4 - Trigger at (or below for analog)
- (Default is 0)

**Responses:** \r\n#GPIOtrigger: VALUE1,VALUE2\r\n

\r\nOK\r\n

\r\nERROR\r\n

**Examples:** **send:** AT#GPIOtrigger=1,1\r

**reply:** \r\nOK\r\n

**send:** AT#GPIOtrigger=1\r

**reply:** \r\n#GPIOtrigger: 1,1\r\n

**reply:** \r\nOK\r\n

**send:** AT#GPIOtrigger=2,2\r

**reply:** \r\nOK\r\n

**send:** AT#GPIOtrigger=2\r

**reply:** \r\n#GPIOtrigger: 2,2\r\n

**reply:** \r\nOK\r\n

# **Part 6 – AT Commands for GPS-Enabled Device**

**Chapter 16 – Commands for GPS-Enabled Device**

# Chapter 16 – AT Commands for GPS-Enable Products

## #GPSSERV – Set GPS Host Server Address

**Description:** This command sets the server IP address or name to which the GPS data will be sent.

**Syntax:** **AT#GPSSERV=<value>**  
AT#GPSSERV? or AT#VGPS or AT#VALL

**Values:** 32-bit number in dotted-decimal notation (i.e., xxx.xxx.xxx.xxx) or  
Alphanumeric ASCII text string up to 120 characters if DNS is available. No default.

**Responses:** OK  
Otherwise ERROR

## #GPSPORT – Set GPS Host Port

**Description:** This command sets the GPS host port (TCP, UDP).

**Syntax:** **AT#GPSPORT=<port number>**  
AT#GPSPORT? or AT#VGPS or AT#VALL

**Values:** 1 to 65535

**Default:** 1

**Responses:** OK  
Otherwise ERROR

## #GPSPROTO – Set GPS Host Protocol

**Description:** This command sets the server protocol that the GPS will use (TCP, UDP).

**Syntax:** **AT#GPSPROTO=<value>**  
AT#GPSPROTO? or AT#VGPS or AT#VALL

**Values:** 0 UDP  
1 TCP

**Default:** 0

**Responses:** OK  
Otherwise ERROR

## #GPSPREFIX – Set GPS Message Prefix

**Description:** This command is used to set a unique identification for each device or vehicle.

**Syntax:** **AT#GPSPREFIX=<value>**  
AT#GPSPREFIX? or AT#VGPS or AT#VALL

**Values:** Up to 4 characters in an alphanumeric string

**Note:** The prefix is appended to the NMEA message before transit

**Default:** " "

**Responses:** OK  
Otherwise ERROR

## #GPSURAIS – Set GPS Unique Remote Asset Identification String

**Description:** This command is used to set a unique remote access identification string for each device or vehicle.

**Syntax:** **AT#GPSURAIS=<value>**  
AT#GPSURAIS? or AT#VGPS or AT#VALL

**Values:** Up to 20 characters in an alphanumeric string  
**Note:** The ID precedes the GPSPREFIX.

**Default:** " "

**Responses:** OK  
Otherwise ERROR

## #GPSINTERVAL – Set GPS Server Transmission Interval

**Description:** This command sets the interval of time between messages transmitted to the server.

**Syntax:** **AT#GPSINTERVAL=<value>**  
AT#GPSINTERVAL? or AT#VGPS or AT#VALL

**Values:** 0 to 65535 (seconds)

**Default:** 0 (Disabled)

**Responses:** OK  
Otherwise ERROR

## #GPSPW – Set GPS Host Login Password

**Description:** This command sets the GPS host login password, if required. Some GPS hosts may require a simple password login mechanism.

**Syntax:** **AT#GPSPW=<value>**  
AT#GPSPW? or AT#VGPS or AT#VALL

**Values:** Alphanumeric ASCII text string up to 64 characters.

**Default:** None

**Responses:** OK  
Otherwise ERROR

## #GPSGPGGA – Enable/Disable GPGGA Message

**Description:** This command enables or disables the reporting of NMEA GPGGA messages.

**Syntax:** **AT#GPSGPGGA=<value>**  
AT#GPSGPGGA? or AT#VGPS or AT#VALL

**Values:** 0 Disable  
1 Enable

**Default:** 1

**Responses:** OK  
Otherwise ERROR

## #GPSGPGLL – Enable/Disable GPGLL Message

**Description:** This command enables or disables the reporting of NMEA GPGLL messages.

**Syntax:** **AT#GPSGPGLL =<value>**  
AT#GPSGPGLL? or AT#VGPS or AT#VALL

**Values:** **0** Disable  
**1** Enable

**Default:** **0**

**Responses:** OK  
Otherwise ERROR

## #GPSGPGSA – Enable/Disable GPGSA Message

**Description:** This command enables or disables the reporting of NMEA GPGSA messages.

**Syntax:** **AT#GPSGPGSA =<value>**  
AT#GPSGPGSA? or AT#VGPS or AT#VALL

**Values:** **0** Disable  
**1** Enable

**Default:** **0**

**Responses:** OK  
Otherwise ERROR

## #GPSGPGSV – Enable/Disable GPGSV Message

**Description:** This command enables or disables the reporting of NMEA GPGSV messages.

**Syntax:** **AT#GPSGPGSV =<value>**  
AT#GPSGPGSV? or AT#VGPS or AT#VALL

**Values:** **0** Disable  
**1** Enable

**Default:** **0**

**Responses:** OK  
Otherwise ERROR

## #GPSGPRMC – Enable/Disable GPRMC Message

**Description:** This command enables or disables the reporting of NMEA GPRMC messages.

**Syntax:** **AT#GPSGPRMC =<value>**  
AT#GPSGPRMC? or AT#VGPS or AT#VALL

**Values:** **0** Disable  
**1** Enable

**Default:** **0**

**Responses:** OK  
Otherwise ERROR

## #GPSGPVTG – Enable/Disable GPVTG Message

**Description:** This command enables or disables the reporting of NMEA GPVTG messages.

**Syntax:** **AT#GPSGPVTG=<value>**  
AT#GPSGPVTG? or AT#VGPS or AT#VALL

**Values:** 0 Disable  
1 Enable

**Default:** 0

**Responses:** OK  
Otherwise ERROR

## #GPSINTERVALLOC – GPS Local Transmission Interval

**Description:** This command sets the interval of time between messages transmitted to the local port.

**Syntax:** **AT# GPSINTERVALLOC =<value>**  
AT# GPSINTERVALLOC? or AT#VGPS or AT#VALL

**Values:** 0 to 65535 (seconds)

**Default:** 0 (Disabled)

**Responses:** OK  
Otherwise ERROR

## #GPSGETMESSAGE – Get Queued GPS Message

**Description:** This command gets the current queued GPS message. The response depends on which messages have been enabled.

**Syntax:** **AT#GPSGETMESSAGE**

**Responses:** #GPSGETMESSAGE:  
<enabled NMEA messages with prefix and urais>  
OK

## GPS Message Syntax

**GPS message syntax that is sent from the UIP device to the backend server:**

<GPSPREFIX><GPSURAIS><NMEA\_MESSAGE><CR><LF>

### Where

<GPSPREFIX> is the unique prefix. Length is 0 to 4 characters (Character format or requirements usually provided by backend service)

<GPSURAIS> is the unique remote asset identification string. Length is 0 to 20 characters (This string may be provided by the backend service)

<NMEA\_MESSAGE> is a standard NMEA sentence received from the internal GPS receiver

<CR><LF> is a Carriage Return and a Line feed

The message that will be transmitted can be viewed with the #GPSGETMESSAGE command. The difference from the viewed message and the transmitted message will be the NMEA message parameters due to timestamp changes and or location changes.

The <GPSPREFIX><GPSURAIS><NMEA\_MESSAGE><CR><LF> is a popular format used by numerous services. Along with the format, the following rules are followed:

Typical transmission protocol is UDP (format provided by backend service) due to low overhead, however TCP is available

Multiple GPS message can and will be transmitted granted the specific message type is enabled (GPGPVTG, GPGPRMC, etc)

Typical minimum message type needed by the backend services is usually the GPRMC or GPGGA and GPVTG messages (Requirement provided by the backend server)

Do not use the \$ character in either the <GPSPREFIX> or <GPSURAIS> sections

Typical transmission intervals to the backend service are 5sec and greater (Requirement provided by backend server)

## GPS Message Examples

The following examples use a <GPSPREFIX> configured to && and a <GPSURAIS> configured with ID1111

```
&&ID1111$GPGSA,A,3,07,09,11,20,28,31,,,,,,3.0,2.2,2.1*36<CR><LF>
&&ID1111$GPGSV,3,1,09,04,40,193,41,07,79,354,50,08,02,171,00,09,28,305,31*78<CR><LF>
&&ID1111$GPGSV,3,2,09,11,15,048,45,20,21,078,37,24,08,205,27,28,55,122,46*77<CR><LF>
&&ID1111$GPGSV,3,3,09,31,67,052,43*43<CR><LF>
&&ID1111$GPGGA,223750.00,4502.2467,N,09302.4844,W,1,05,5.4,287.0,M,-27.6,M,,*58<CR><LF>
&&ID1111$GPRMC,223750.00,A,4502.2467,N,09302.4844,W,57.00,97.29,131104,2.5,E,A*20<CR><LF>
```

## GPS Configuration Examples

AT#GPSPREFIX="&&"<CR>	Prefix (Requirements provided by backend service)
AT#GPSURAIS="ID1111"<CR>	Unique ID (Requirements provided by backend service)
AT#GPGPRMC=1<CR>	Enable GPRMC message (Requirements provided by backend service)
AT#GPGPGGA=0<CR>	Disable GPGGA message (Requirements provided by backend service)
AT#GPGPGLL=0<CR>	Disable GPGLL message (Requirements provided by backend service)
AT#GPGPGSA=0<CR>	Disable GPGSA message (Requirements provided by backend service)
AT#GPGPGSV=0<CR>	Disable GPGSV message (Requirements provided by backend service)
AT#GPGPVTG=0<CR>	Disable GPVLL message (Requirements provided by backend service)
AT#VGPS<CR>	View settings

**The following command starts the GPS sending. The message will be sent if the UIP device is connected to the network. (CONNECTIONSTART has been issued)**

AT#GPSINTERVAL=5<CR>	Timer in seconds that the device will contact the remote server
AT#GPSINTERVAL=0<CR>	Disables sending messages

**The following example message would be sent over the network using UDP every 5 seconds (The \$GPRMC would have different data however).**

```
&ID1111$GPRMC,223750.00,A,4502.2467,N,09302.4844,W,57.00,97.29,131104,2.5,E,A*20<CR><LF>
```

# Application Note – GPS NMEA Messages

## Introduction

The *NMEA (National Marine Electronics Association) 0183 Standard* is a standard protocol for interfacing navigational devices; e.g., GPS and DGPS receivers over a serial interface. The complete document of this standard may be obtained from NMEA at <http://www.nmea.org>. We wish to thank SkyTraq Technology, Inc. for providing the following summary of NMEA Messages.

## NMEA Protocol Overview

### Message Format

The structure of an NMEA message is shown below.

Checksum Range				
Start of Sequence	Address Field	Data Field(s)	Checksum Field	End of Sequence
\$ or !	<Address>	[,<data field>] [,<data field>]	*<checksum>	<CR><LF>

### Start of Sequence

All sentences begin with the sentence start delimiter character “\$” or “!”.

### Address Field

The address field is used to define the sentence. Characters with digits and upper case letters are permitted to be in the address field. Note that the address field is required. It cannot be a null field. This field is subdivided into 2 fields.

<XX>	<XXX>
Talker Identifier	Sentence Formatter

*Talker Identifier* is always **GP** for a GPS receiver. The sentence formatter defines the format and the type of data.

### Data Field(s)

Data fields are delimited by a “,” and contain valid characters specified in NMEA 0183 standard. It can consist of fields of variable lengths.

### Checksum

The checksum field is the 8-bit exclusive OR (no start or stop bits) of all characters in the sentence. Checksum consists of 2 characters and is represented as a hex number.

### End of Sequence

All sentences always end with sentence termination delimiter character “\$” or “!”.

## SUPPORTED MESSAGE LIST

The following NMEA messages are supported.

Sentence	Descriptions
GGA	Global Positioning System Fix Data
GLL	Geographic Position – Latitude/Longitude
GSA	GNSS DOP and Active Satellites
GSV	GNS Satellites in View
RMC	Recommended Minimum Specific GNSS Data
VTG	Course Over Ground and Ground Speed

## NMEA MESSAGES

The full descriptions of supported NMEA messages are provided at the following paragraphs.

### GGA – Global Positioning System Fix Data

Time, position and fix related data for a GPS receiver.

**Structure:**

\$GPGGA, hhmmss.sss, ddmm.mmmm, a, dddmm.mmmm, a, x, xx, x.x, x.x, M, ,,, xxxx\*hh<CR><LF>

**Example:**

\$GPGGA, 111636.932, 2447.0949, N, 12100.5223, E, 1, 11, 0.8, 118.2, M, ,,, 0000\*02<CR><LF>

Name	Example	Description
Message ID	\$GPGGA	GGA Protocol Header
UTC Time	111636.932	UTC of position in hhmmss.sss format, (000000.000 ~ 235959.999)
Latitude	2447.0949	Latitude in ddmm.mmmm format
N/S Indicator	N	Latitude hemisphere indicator, 'N' = North, 'S' = South
Longitude	12100.5223	Longitude in dddmm.mmmm format
E/W Indicator	E	Longitude hemisphere indicator, 'E' = East, 'W' = West
GPS quality indicator	1	0: position fix unavailable 1: valid position fix, SPS mode 2: valid position fix, differential GPS mode 3: GPS PPS Mode, fix valid 4: Real Time Kinematic. System used in RTK mode with fixed integers 5: Float RTK. Satellite system used in RTK mode. Floating integers 6: Estimated (dead reckoning) Mode 7: Manual Input Mode 8: Simulator Mode
Satellites Used	11	Number of satellites in use, (00 ~ 12)
HDOP	0.8	Horizontal dilution of precision, (00.0 ~ 1023)
Altitude	118.2	Antenna Altitude above/below mean sea level (geoid), (-9999.9 ~ 17999.9)
Units	M	Unit of antenna altitude (meters)
Null	,	Field not available on GPS cards
Null	,	Field not available on GPS cards
DGPS Station ID	0000	Differential reference station ID, 0000 ~ 1023 (NULL when DGPS not used)
Checksum	02	
<CR><LF>	<CR><LF>	End of message (termination)

## GLL – Latitude/Longitude

Latitude and longitude of current position, time, and status.

**Structure:**

\$GPGLL,ddmm.mmmm,a,dddmm.mmmm,a,hhmmss.sss,A,a\*hh<CR><LF>

**Example:**

\$GPGLL,2447.0944,N,12100.5213,E,112609.932,A,A\*57<CR><LF>

Name	Example	Description
Message ID	\$GPGLL	GLL Protocol Header
Latitude	2447.0949	Latitude in ddmm.mmmm format
N/S Indicator	N	Latitude hemisphere indicator 'N' = North 'S' = South
Longitude	12100.5213	Longitude in dddmm.mmmm format
E/W Indicator	E	Longitude hemisphere indicator 'E' = East 'W' = West
UTC Time	112609.932	UTC Time in hhmmss.sss format (000000.000 ~ 235959.999)
Status	A	Status, 'A' = Data valid; 'V' = Data not valid
Mode Indicator	A	Mode indicator 'N' = Data not valid 'A' = Autonomous mode 'D' = Differential mode 'E' = Estimated (dead reckoning) mode 'M' = Manual input mode 'S' = Simulator mode
Checksum	*57	
<CR><LF>	<CR><LF>	End of message (termination)

## GSA – GNSS DOP and Active Satellites

GPS receiver operating mode, satellites used in the navigation solution reported by the GGA or GNS sentence and DOP values.

**Structure:**

\$GPGSA,A,x,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,x.x,x.x,x.x,x\*x\*hh<CR><LF>

**Example:**

\$GPGSA,A,3,05,12,21,22,30,09,18,06,14,01,31,,1.2,0.8,0.9\*36<CR><LF>

Name	Example	Description
Message ID	\$GPGSA	GSA Protocol Header
Mode	A	Mode 'M' = Manual, forced to operate in 2D or 3D mode 'A' = Automatic, allowed to automatically switch 2D/3D
Mode	3	Fix type 1 = Fix not available 2 = 2D 3 = 3D
Satellite used 1~12	05,12,21,22, 30,09,18,06, 14,01,31,,	Satellite ID number, 01 to 32 of satellite used in solution, up to 12 transmitted
PDOP	1.2	Position dilution of precision (00.0 to 99.9)
HDOP	0.8	Horizontal dilution of precision (00.0 to 99.9)
VDOP	0.9	Vertical dilution of precision (00.0 to 99.9)
Checksum	*36	
<CR><LF>	<CR><LF>	End of message (termination)

## GSV – GNSS Satellites in View

Number of satellites (SV) in view, satellite ID numbers, elevation, azimuth, and SNR value. Four satellites maximum per transmission.

**Structure:**

\$GPGSV,x,x,xx,xx,xxx,xx,...,xx,xx,xxx,xx \*hh<CR><LF>

**Example:**

\$GPGSV,3,1,12,05,54,069,45,12,44,061,44,21,07,184,46,22,78,289,47\*72<CR><LF>

\$GPGSV,3,2,12,30,65,118,45,09,12,047,37,18,62,157,47,06,08,144,45\*7C<CR><LF>

\$GPGSV,3,3,12,14,39,330,42,01,06,299,38,31,30,256,44,32,36,320,47\*7B<CR><LF>

Name	Example	Description
Message ID	\$GPGSV	GSV Protocol Header
Number of messages <sup>1</sup>	3	Total number of GSV messages to be transmitted in this group (1-3)
Message Number <sup>1</sup>	1	Message number in this group of GSV messages
Satellites in View <sup>1</sup>	12	Total number of satellites in view (00 ~ 12)
Satellite ID	05	Satellite ID number, GPS: 01 ~ 32, SBAS: 33 ~ 64 (33 = PRN120)
Elevation	54	Satellite elevation in degrees, (00 ~ 90)
Azimuth	069	Satellite azimuth angle in degrees, (000 ~ 359 )
SNR	45	C/No in dB (00 ~ 99). Null when not tracking
,,	12,44,061,44,	Next Satellite ID number, elevation, azimuth, SNR
,,	21,07,184,46,	Next Satellite ID number, elevation, azimuth, SNR
,,	22,78,289,47	Last Satellite ID number, elevation, azimuth, SNR
Checksum	*72	
<CR><LF>	<CR><LF>	End of message (termination)

<sup>1</sup> Depending on the number of satellites tracked, multiple messages of GSV data may be required. In some software versions, the maximum number of satellites reported as visible is limited to 12, even though more may be visible.

## RMC – Recommended Minimum Specific GNSS Data

Time, date, position, course and speed data provided by a GNSS navigation receiver.

**Structure:**

\$GPRMC,hhmmss.sss,A,dddmm.mmmm,a,dddmm.mmmm,a,x.x,x.x,ddmmyy,,a\*hh<CR><LF>

**Example:**

\$GPRMC,111636.932,A,2447.0949,N,12100.5223,E,000.0,000.0,030407,,,A\*61<CR><LF>

Name	Example	Description
Message ID	\$GPRMC	RMC Protocol Header
UTC time	111636.932	UTC of position in hhmmss.sss format (000000.00 ~ 235959.999)
Status	A	Status: 'V' = Navigation receiver warning; 'A' = Data Valid
Latitude	2447.0949	Latitude in dddmm.mmmm format d
N/S indicator	N	Latitude hemisphere indicator: 'N' = North, 'S' = South
Longitude	12100.5223	Longitude in dddmm.mmmm format
E/W Indicator	E	Longitude hemisphere indicator: 'E' = East, 'W' = West
Speed over ground	000.0	Speed over ground in knots (000.0 ~ 999.9)
Course over ground	000.0	Course over ground in degrees (000.0 ~ 359.9)
UTC Date	030407	UTC date of position fix, ddmmyy format
	,	Magnetic variation, degrees
	,	East or West
Mode indicator	A	'N' = Data not valid 'A' = Autonomous mode 'D' = Differential mode 'E' = Estimated (dead reckoning) mode 'M' = Manual input mode 'S' = Simulator mode
Checksum	*61	
<CR><LF>	<CR><LF>	End of message (termination)

## VTG – Course Over Ground and Ground Speed

The Actual course and speed relative to the ground.

**Structure:**

GPVTG,x.x,T,,M,x.x,N,x.x,K,a\*hh<CR><LF>

**Example:**

\$GPVTG, 000.0,T,,M,000.0,N,0000.0,K,A\*3D<CR><LF>

Name	Example	Description
Message ID	\$GPVTG	VTG Protocol Header
Course	000.0	True course over ground in degrees (000.0 ~ 359.9)
Reference	T	True
Course	,	Measured heading (degrees)
Reference	M	Magnetic
Speed	000.0	Speed over ground in knots (000.0 ~ 999.9)
Units	N	Knots
Speed	0000.0	Speed over ground in kilometers per hour (0000.0 ~ 1800.0)
Units	K	Kilometers per hour
Mode	A	'N' = not valid 'A' = Autonomous mode 'D' = Differential mode 'E' = Estimated (dead reckoning) mode 'M' = Manual input mode 'S' = Simulator mode
Checksum	*3D	
<CR><LF>	<CR><LF>	End of message (termination)

# **Part 7 – Appendixes**

**Appendix A – Response Messages and Error Codes**

**Appendix B – Response Message Examples**

# Appendix A – Response Messages & Error Codes

## Response Messages

Standard AT Messages		
Numeric	Verbose	Description
0	OK	Operation or command success
3	NO CARRIER	No physical layer connection
7	BUSY	Destination busy
8	NO ANSWER	No answer from destination
4	ERROR	Operation or command unsuccessful
2	RING	Incoming call indication

Information Messages		
Numeric	Verbose	Description
1025	Ok_Info_DataBegin	Start of data
1028	Ok_Info_WaitingForData	Send data
3074	Ok_Info_SocketClosed	Socket connection closed successfully
3072	Ok_Info_NoMail	No mail to retrieve on server
3073	Ok_Info_Mail	Mail ready to be retrieved on server
3077	Ok_Info_PPP	PPP connection successful

## Error Codes

Error Codes	
Numeric	Description
34817	Bad command : Unknown command
34819	Bad command : Syntax error
34824	Bad command : EEPROM write failed
34881	Bad command : Command too long
34882	Bad command : Bad command argument value
34883	Bad command : High level Internet configuration only command
35840	Physical layer : Modem is already running
35862	Physical layer : Timeout, no activity on network connection
35865	Physical layer : Module is not attached to the network
35866	Physical layer : Invalid event during activation process
35867	Physical layer : Physical layer connection is currently not active
35869	Physical layer : Invalid incoming call type
35870	Physical layer : Incoming call CLI not provided
36872	IP Connectivity library internal error : internal resource unavailable.
36929	IP Connectivity library : Bad parameter configuration attempt
37122	IP Connectivity library : Another internal application is already running
37123	IP Connectivity library : Service is running. Unable to set parameter
37124	IP Connectivity library : Data buffer oversized
37125	IP Connectivity library : No UDP datagram received
37952	Distant : TCP session closed (TCP Context cancelled)
37964	Distant : No response from server
37966	Distant : TCP session closed by peer (FIN received from peer)
38016	Distant : Open session attempt failed
38017	Distant : Data send attempt failed
38018	Distant : Close session attempt failed
38023	Distant : File deletion attempt failed
38024	Distant : Data retrieve attempt failed
38025	Distant : Email retrieve attempt failed
38026	Distant : Email header receive failed
38027	Distant : No answer from DNS servers or domain name resolution could not be completed by the server.
38028	Distant : Sender email address rejected by server
38029	Distant : Recipient email address rejected by server
38030	Distant : CC Recipient email address rejected by server
38031	Distant : Email body send request rejected by server
38080	Distant : Username rejected by server
38081	Distant : Password rejected by server

# Appendix B – Response Message Examples

## Response Messages Examples

### Sending/Retrieving Email Response Messages

#### Sending an Email: AT#PUTMAIL

Commands	Responses
AT#SMTPSERV="smtp.domain.com" <i>Note: SMTP server used</i>	OK
AT#DOMAIN="domain.com" <i>Note: Domain name</i>	OK
AT#SENDERNAME="Test module" <i>Note: Sender name</i>	OK
AT#SENDERADDR="module@domain.com" <i>Note: Sender email address</i>	OK
AT#SMTPUN="Name" <i>Note: SMTP user name</i>	OK
AT#SMTPPW="Password" <i>Note: SMTP user password</i>	OK
AT#SMTPORT="Port" <i>Note: Port used by SMTP server</i>	OK
AT#REC1=recipient@domain.com or AT#REC2 or AT#REC3 <i>Note: Recipient email address</i>	OK
AT#CCREC1=ccrecipient@domain.com or AT#CCREC2 or AT#CCREC3 <i>Note: Carbon Copy recipient</i>	OK
AT#SUBJ1="Email Subject" <i>Note: Email Subject</i>	OK
1. AT#PUTMAIL <i>Note: Send an email (type the email text and then the end sequence)</i>	<p>Ok_Info_WaitingForData  <i>Note: The software is ready to receive incoming data (not echoed)</i>  <i>At the end of date, the [CR][LF] . [CR][LF] sequence ends the email. This sequence can be sent by a keyboard using:</i></p> <p style="margin-left: 20px;">ENTER</p> <p style="margin-left: 20px;">CTRL+ENTER</p> <p style="margin-left: 20px;">.</p> <p style="margin-left: 20px;">ENTER</p> <p style="margin-left: 20px;">CTRL+ ENTER</p> <p style="text-align: center;"><b>OR</b></p> <p>1. AT#BODY1 (or AT#BODY2 or AT#BODY3)  <i>Note: Write an email for a predefined message.</i></p> <p style="text-align: center;">AND</p> <p>2. AT#SENDMAIL1 (or AT#SENDMAIL2,  AT#SENDMAIL3)  <i>Note: Send the predefined message.</i></p>
	OK
	OK

**Retrieving an Email: AT#GETMAIL**

<b>Commands</b>	<b>Responses</b>
AT#POP3SERV="pop3.domain.com" Note: POP3 server used	OK
AT#POP3UN="module@domain.com" Note: POP3 username (not always the complete email address). It is the POP3 login	OK
AT#POP3PW="password" Note: POP3 password	OK
AT#POP3PORT="110" Note: POP3 port	OK
AT#GETMAIL Note: Retrieve an email	Ok_Info_Mail Note: The software switches from command mode to data mode for receiving the email content. Data Data . Note: At the end of data, the [CR][LF] . [CR][LF] sequence notifies the end of the data mode OK Note: The email is successfully retrieved

## FTP: Download / Upload Files Response Messages

### Upload a file to an FTP Server: AT#FTPPUT

Commands	Responses
AT#FTPSERV="ftp.domain.com" Note: FTP server used	OK
AT#FTPUN="ftplogin" Note: FTP username	OK
AT#FTPPW="ftppassword" Note: FTP password	OK
AT#FTPPUTFILENAME="upload.text" Note: Name of the file that will be written in the FTP server	OK
AT#FTPPUTPATH=". " Note: Path in the server where the file will be written	OK
AT#FTPPUT Note: FTP put	Ok_Info_WaitingForData Note: Switch from command to data mode. The host can send the data that will compose the file. (Data not echoed). To notify the end of data, the host has to send [ETX] (CTRL+C on the keyboard). This character is echoed. OK
Note: End of data notified	OK

### Download a file from an FTP Server: AT#FTPGET

Commands	Responses
AT#FTPSERV="ftp.domain.com" Note: FTP server used	OK
AT#FTPUN="ftplogin" Note: FTP username	OK
AT#FTPPW="ftppassword" Note: FTP password	OK
AT#FTPGETFILENAME="upload.text" Note: Name of the file stored in the FTP server	OK
AT#FTPGET Note: FTP get	Ok_Info_DataBegin Note: Switch from command to data mode. The data is sent over the serial port. To end of data is notified by [ETX] sent over the serial port. It switches from data to command mode. Character is echoed. OK

## TCP Socket Response Messages

Open a TCP socket between machines. One machine acts as a caller (TCP client); the other acts as a listener (TCP server). Both machines have to be connected to the Internet and set to the same TCP port.

### Act as a TCP Server: AT#LTCPPSTART

Commands	Responses
AT#TCPSEERV=1,"255.255.255.255" Note: No filter of the incoming TCP client	OK
AT#TCPPORT=1,"23" Note: TCP port between the TCP client and the TCP server must be the same	OK
AT#LTCPPSTART=1 Note: Launch the listening mode; waiting for an incoming TCP connection from a TCP client	OK  Ok_Info_WaitingForData Note: Message sent over the serial port in case of successful TCP socket opening (Telnet for example in the IP address)
Data Note: Data flow is bidirectional	Data Note: Data flow is bidirectional
Note: The socket can be closed locally by the attached host sending an [ETX] character (CTRL+C on the keyboard)	OK
	Note: The socket can be closed by the remote Ok_Info_SocketClosed OK

### Act as a TCP Client: AT#OTCP

Commands	Responses
AT#TCPSEERV=1,"xxx.xxx.xxx.xxx" Note: No filter of the incoming TCP client	OK
AT#TCPPORT=1,"23" Note: TCP port between the TCP client and the TCP server must be the same	OK
AT#OTCP=1 Note: Open as a TCP client, a socket TCP with remote TCP server	Ok_Info_WaitingForData Note: Message notifying the socket opening and the switch in data mode
Data Note: Data flow is bidirectional	Data Note: Data flow is bidirectional
Note: The socket can be closed locally by the attached host sending an [ETX] character (CTRL+C on the keyboard)	OK
	Note: The socket can be closed by the remote Ok_Info_SocketClosed OK

Note: The closing of the socket can be performed either locally or remotely.

# Index

## #

#ACCEPT – Answer Incoming Call.....	81
#ANSWERMODE – Set Answering Mode .....	75
#APNPW – Access Point Name Password.....	84
#APNSERV – Access Point Name .....	84
#APNUN – Access Point User Name.....	84
#ATCMD – Customize Dial-Up AT Commands .....	78
#AUTHENT – Authentication Type .....	74
#AUTOCONNECT – Automatically Connect the PPP Link .....	83
#AUTODISC – Auto Discovery On or Off.....	54
#AUTODISCHOST – Set Auto Discovery Host Name .....	54
#AUTODISCPASSWORD – Set Auto Discovery Password .....	55
#AUTODISCPORT – Auto Discovery Port.....	54
#AUTODISCTIMER – Auto Discovery Timer .....	54
#AUTODISCUSERNAME – Set Auto Discovery User Name .....	55
#AUTORESET – Reset Main Processor at a Given Time.	13
#BODYi – Set Pre-Defined Email Combinations.....	21
#CALLBACKTIMER – Automatic Call-Back Wait.....	76
#CALLSCREENNUM – Caller ID .....	76
#CCRECi – Set Additional Recipient CC .....	19
#CONNECTIONSTART – Start Communication.....	82
#CONNECTIONSTOP – Stop Communication.....	81
#DELFLASH – Erase Flash Memory Parameter Values .....	13
#DHCP – DHCP On or Off .....	50, 57
#DIALN1 – Primary Dial-Up Number .....	79
#DIALN2 – Secondary Dial-Up Number.....	79
#DIALSELECT – Internet Connection Number .....	80
#DISPLAYIP – Display IP Addresses .....	85
#DLEMODE – Set DLE Mode .....	33
#DNSSERV1 – Set DNS Server IP Address.....	51, 58
#DNSSERV2 – Set Secondary DNS Server .....	51, 58
#DOMAIN – Set Domain Name of the Sender .....	20
#EMACSPD – Set Ethernet Connection .....	51
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15
#ETHIFSTATUS – View Network Interface Settings.....	52
#FTPAPPEND – Append Data to Server .....	31
#FTPGET – Download Files from FTP Server .....	30
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPGETPATH – Set Path to Get Files from FTP Server	31
#FTPMODE – Enter FTP Mode .....	28
#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value.....	32
#FTPPORT – Enter FTP Server Port .....	28
#FTPPUT – Upload Files to FTP Server .....	30
#FTPPUTFILENAME – Set FTP Upload File Name .....	29
#FTPPUTPATH – Set Path to Send Files to FTP Server .....	31
#FTPPW – Set FTP Password .....	29
#FTPSERV – Specify FTP Server Address .....	29
#FTPTYPE – Specify Data Type .....	28
#FTPUN – Set FTP User Name .....	29
#GETMAIL – Retrieve Host Mail .....	27

#GPIO – Enable/Disable and Configure External GPIO Driven Events .....	89
#GPIOR – Read the Current Register Status of the Specified GPIO Pin .....	89
#GPIOTRIGGER – Configure the GPIO pin and trigger type .....	90
#GPRSCID – PDP Context Identifier .....	85
#GPRS MODE – Switch Between GSM and GPRS .....	85
#GPSGETMESSAGE – Get Queued GPS Message .....	95
#GPSGPGLA – Enable/Disable GPGLA Message .....	93
#GPSGPGLL – Enable/Disable GPGLL Message .....	94
#GPSGPGSA – Enable/Disable GPGSA Message .....	94
#GPSGPGSV – Enable/Disable GPGSV Message .....	94
#GPSGPRMC – Enable/Disable GPRMC Message .....	94
#GPSGPVTG – Enable/Disable GPVTG Message .....	95
#GPSINTERVAL – Set GPS Server Transmission Interval .....	93
#GPSINTERVALLOC – GPS Local Transmission Interval	95
#GPSPORT – Set GPS Host Port .....	92
#GPSPREFIX – Set GPS Message Prefix .....	92
#GPSPROTO – Set GPS Host Protocol .....	92
#GPSPW – Set GPS Host Login Password .....	93
#GPSSERV – Set GPS Host Server Address .....	92
#GPSURAIS – Set GPS Unique Remote Asset Identification String .....	93
#HOSTNAME – Configure the DHCP Client Host Name ..	52
#IPADDR – Set Static IP Address .....	50, 57
#IPDNSSERV – Configure the DNS Server .....	58
#IPDNSTABLE – Display DNS Table .....	60
#IPGATEWAY – Set Gateway Address .....	50, 57
#IPNETMASK – Set Subnet Mask .....	51, 58
#IPQUERY – Give a Domain Name .....	59
#IPRELEASE – Release a DHCP Address Assigned by the Server .....	59
#IPRENEW – Renew DHCP Information from Server .....	59
#IPRESOLV – Is There a Connection with DNS or Not ..	59
#ISPPW – ISP Password .....	80
#ISPUN – ISP User Name .....	80
#KEEPALIVEDELAY – Keep-Alive Delay .....	77
#KEEPALIVEMODE – Keep-Alive Mode .....	76
#KEEPALIVEPORT – Keep-Alive Port Number .....	77
#KEEPALIVESERV – Keep-Alive Server Address .....	77
#LEGACYMODE – Legacy Mode Enable/Disable .....	14
#LTCPCSTART – Open Listening Mode .....	38
#LTCPCSTOP – Close TCP Listening Mode .....	39
#LUDPCSTART – Initiate the UDP Session in Listen Mode .....	45
#LUDPCSTOP – Close UDP Listening Mode .....	46
#OTCP – Open a TCP Connection .....	39
#OUDP – Initiate UDP Session in Active Mode .....	46
#OUTPORT – UDP/TCP Local Port Number .....	39, 46, 77
#PERSISTENTSOCKET – Persistent Socket .....	33, 41
#PHYTIMEOUT – Inactivity Timer .....	78
#PING – Start PING Request .....	47
#PINGDELAY – PING Delay Time .....	47
#PINGNUM – Number of PING Requests .....	47
#PINGREMOTE – IP Address of PING Request .....	47
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26

#POP3PW – Set POP3 Password.....	26
#POP3SERV – Set POP3 Server Address.....	26
#POP3UN – Set POP3 User Name.....	27
#PPPMODE – TCP/IP Behavior.....	83
#PPPMYIP – IP Address When Using PPP.....	83
#PPPPEERIP – IP Address for Remote PPP.....	84
#PPPSERVPW – Remote PPP Client Password.....	84
#PPPSERVUN – User Name for Remote PPP Client.....	84
#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#RECIADD – Set Email Address .....	20
#REDIALCOUNT – Connection Attempts Allowed .....	78
#REDIALDELAY – Call Retry Delay .....	78
#RESET – Reset Main Processor or Internal Modem.....	14
#RINGCOUNT – Set Number of Rings.....	79
#SENDERADDR – Set Sender Address.....	19
#SENDERNAME – Set Sender Name .....	19
#SENDMAILi – Send Mail without Interactive Mode .....	23
#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
#SMTPAUTH – Authentication ON or OFF .....	25
#SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value.....	21
#SMTPPORT – Set SMTP Server Port.....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SUBJi – Set Email Pre-Defined Subject Text .....	20
#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value.....	36
#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value.....	36
#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size .....	35
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size .....	35
#TCPPORT – Set TCP Port for Remote Peer .....	34
#TCPSERV – Set Address of Remote TCP Server .....	34
#TCPTELNETMODE – Enable/Disable TCP Listener Telnet Protocol.....	37
#TCPTELNETPW – Configure the TCP Client Telnet Server Login Password.....	37
#TCPTELNETUN – Set the TCP Client Telnet Server User Name .....	38
#TCPTXDELAY – Time Delay .....	34
#TELNET – Start/Stop Telnet Session.....	63
#TELNETPASSWORD – Set Telnet Password .....	64
#TELNETPORT – Set Telnet Port .....	63
#TELNETUSER – Set Telnet User .....	63
#UDPDLEMODE – Set DLE Mode .....	45
#UDPIGNORESRCPORT – Ignore Send Source Port .....	43
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value .....	42
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size .....	42
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size .....	41
#UDPPORT – UDP Port Number .....	43
#UDPREMPOTEPORT – Remote Port Number .....	43
#UDPSERV – UDP Server Address .....	44
#UDPTXDELAY – Delay before Sending UDP Datagram .....	44
#VALL – Display All Parameters .....	18
#AUTODISC – Display Auto Discover Commands.....	55
#VDNS – Display Configuration of DNS Servers .....	52, 60
#VFTP – Display FTP Parameters .....	32
#VIP – View Address Settings .....	53, 60
#VMAILi – Display Email Parameters for Mail ID .....	25
#VPHY – Display Physical Parameters.....	86
<b>#VPING – Display PING Parameters.....</b>	48
#VPOP3 – POP3 Module Parameters .....	27
#VPPP – Display PPP Parameters .....	86
#VSHOWSERIAL – Configure the Escape Character for DLEMODE .....	15
#VSHOWUPTIME – Displays the Current Uptime in Days, Hrs, Mins, Secs.....	16
#VSHOWUPTIMES – Displays the Current Uptime Secs .....	16
#VSMTPL – Display SMTP Parameters .....	25
#VSTATE – Display Current State of Physical Connection .....	16
<b>#VTCP – Display TCP Parameters.....</b>	40
#VTELNET – View Telnet Settings .....	64
<b>#VUDP – Display UDP Module Configuration.....</b>	46
#VVERSION – Display Software Version .....	16
#WEP? – View Values of WEP Keys .....	71
#WEP128KEY – Keys for WEP128 Security Mode .....	70
#WEP64KEY – Keys for WEP64 Security Mode .....	69
#WEPEKEYID – Set Default TX Key Index .....	70
#WLAN?' – WLAN Module .....	72
#WLANACTIVATE – Move Module out of Power Save .....	69
#WLANASSOCINFO – Display Association Information .....	72
#WLANCONNECT – Connect with AP .....	67
#WLANCOUNTRYCODE – Country Code .....	65
#WLANDATARATE – WLAN Transmission Data Rate .....	66
#WLANDISCONNECT – Disconnect with AP .....	67
#WLANDOZE= – Moves Module into or out of Power Save .....	67
#WLANENABLE – Auto Connect Module with AP .....	67
#WLANGETRSSI – Received Signal Strength .....	69
#WLANIBSSCHANNEL – Channel for Ad-Hoc Mode .....	66
#WLANNETWORKMODE – WLAN Network Mode .....	65
#WLANPOWERSAVE – Enable Power Save at Boot .....	70
#WLANPROFILE – Display the WLAN Profile .....	71
#WLANPROFILEn=n – Change the WLAN Profile .....	68
#WLANROAM – Enable/Disable Roaming .....	69
#WLANSCAN – SCAN Wireless Networks .....	68
#WLANSCANMODE – Scanning Mode .....	66
#WLANSECURITYMODE – Security Mode of WLAN Module .....	65
#WLANSSID – SSID of WLAN .....	66
#WLANUSEPROFILE – User Profile .....	69
#WPA2PSKKEY – Keys for WPA2 PSK Security Mode .....	70
#WPAPSKKEY – Keys for WAP PSK Security Mode .....	70
<b>&amp;</b>	
&C – RLSD (DCD) Option .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM .....	12
<b>#</b>	
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control .....	13
+IPR – Set Serial Speed .....	13
+WOPEN – Mode of Operation .....	74
<b>A</b>	
A – Manual Answer of TCP or UDP .....	61
Access Point Name – #APNSERV .....	84
Access Point Name Password – #APNPW .....	84
Access Point User Name – #APNUN .....	84
Answer Incoming Call – #ACCEPT .....	81
Append Data to Server – #FTPAPPEND .....	31
AT – Command Mode .....	10

Authentication ON or OFF – #SMTPAUTH.....	25	#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value.....	32
Authentication Type – #AUTHENT .....	74	#FTPPORT – Enter FTP Server Port.....	28
Auto Connect Module with AP – #WLANENABLE .....	67	#FTPPUT – Upload Files to FTP Server.....	30
Auto Discovery On or Off – #AUTODISC .....	54	#FTPPUTFILENAME – Set FTP Upload File Name .....	29
Auto Discovery Port – #AUTODISCPORT .....	54	<b>#FTPPUTPATH – Set Path to Send Files to FTP Server .....</b>	31
Auto Discovery Timer – #AUTODISCTIMER .....	54		
Automatic Answer – S0= .....	59	#FTPPW – Set FTP Password .....	29
Automatic Call-Back Wait – #CALLBACKTIMER .....	76	#FTPSERV – Specify FTP Server Address .....	29
Automatically Connect the PPP Link – #AUTOCONNECTION .....	83	#FTPTYPE – Specify Data Type.....	28
<b>C</b>			
Call Retry Delay – #REDIALDELAY .....	78	#FTPUN – Set FTP User Name.....	29
Caller ID – #CALLSCREENNUM .....	76	#GETMAIL – Retrieve Host Mail .....	27
Change the WLAN Profile – #WLANPROFILEn=n .....	68	#GPRSCID – PDP Context Identifier .....	85
Channel for Ad-Hoc Mode – #WLANIBSSCHANNEL .....	66	#GPRS MODE – Switch Between GSM and GPRS .....	85
<b>Close TCP Listening Mode – #LTCSTOP .....</b>	39	#ISPFW – ISP Password.....	80
<b>Close UDP Listening Mode – #LUDPSTOP .....</b>	46	#ISPUN – ISP User Name .....	80
Command Mode – AT .....	10	<b>#KEEPALIVEDELAY – Keep-Alive Delay .....</b>	77
Commands for Modems with GPS		#KEEPALIVEMODE – Keep-Alive Mode .....	76
#GPSGETMESSAGE – Get Queued GPS Message .....	95	#KEEPALIVEPORT – Keep-Alive Port Number .....	77
#GPSGPGGA – Enable/Disable GPGGA Message .....	93	#KEEPALIVESERV – Keep-Alive Server Address .....	77
#GPSGPGLL – Enable/Disable GPGLL Message .....	94	#LEGACYMODE – Legacy Mode Enable/Disable .....	14
#GPSGPGSA – Enable/Disable GPGSA Message .....	94	<b>#LTCSTART – Open Listening Mode .....</b>	38
#GPSGPGSV – Enable/Disable GPGSV Message .....	94	<b>#LTCSTOP – Close TCP Listening Mode .....</b>	39
#GPSGPRMC – Enable/Disable GPRMC Message .....	94	<b>#LUDPSTART – Initiate the UDP Session in Listen Mode .....</b>	45
#GPSGPVTG – Enable/Disable GPVTG Message .....	95	<b>#LUDPSTOP – Close UDP Listening Mode .....</b>	46
#GPSINTERVAL – GPS Server Transmission Interval .....	93	<b>#OTCP – Open a TCP Connection .....</b>	39
#GPSINTERVALLOC – GPS Local Transmission Interval .....	95	<b>#OUDP – Initiate UDP Session in Active Mode .....</b>	46
#GPSPORT – GPS Host Port .....	92	#OUTPORT – UDP/TCP Local Port Number .....	39, 46, 77
#GPSPREFIX – GPS Message Prefix .....	92	#PERSISTENTSOCKET – Persistent Socket .....	33, 41
#GPSPROTO – GPS Host Protocol .....	92	#PHYTIMEOUT – Inactivity Timer .....	78
#GPSPW – GPS Host Login Password .....	93	<b>#PING – Start PING Request .....</b>	47
#GPSSERV – GPS Host Server Address .....	92	<b>#PINGDELAY – PING Delay Time .....</b>	47
#GPSURAIS – GPS Unique Remote Asset Identification String .....	93	<b>#PINGNUM – Number of PING Requests .....</b>	47
Commands for MultiModem iCell		<b>#PINGREMOTE – IP Address of PING Request .....</b>	47
#ACCEPT – Answer Incoming Call .....	81	#POP3HEADERMODE – POP3 Header .....	26
#ANSWERMODE – Set Answering Mode .....	75	#POP3PORT – Set POP3 Server Port .....	26
#APNPW – Access Point Name Password .....	84	#POP3PW – Set POP3 Password .....	26
#APNSERV – Access Point Name .....	84	#POP3SERV – Set POP3 Server Address .....	26
#APNUN – Access Point User Name .....	84	#POP3UN – Set POP3 User Name .....	27
#ATCMD – Customize Dial-Up Commands .....	78	#PPPMODE – TCP/IP Behavior .....	83
#AUTHENT – Authentication Type .....	74	#PPPMYIP – IP Address When Using PPP .....	83
#AUTOCONNECT – Automatically Connect the PPP Link .....	83	#PPPPEERIP – IP Address for Remote PPP .....	84
#AUTORESET – Reset Main Processor at a Given Time .....	13	#PPPSERVPW – Remote PPP Client Password .....	84
#BODYi – Set Pre-Defined Email Combinations .....	21	#PPPSERVUN – User Name for Remote PPP Client .....	84
#CALLBACKTIMER – Automatic Call-Back Wait .....	76	#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#CALLSCREENNUM – Caller ID .....	76	#RECIADD – Set Email Address .....	20
#CCRECi – Set Additional Recipient CC .....	19	#REDIALCOUNT – Connection Attempts Allowed .....	78
#CONNECTIONSTART – Start Communication .....	82	#REDIALDELAY – Call Retry Delay .....	78
#CONNECTIONSTOP – Stop Communication .....	81	#RESET – Reset Main Processor or Internal Modem .....	14
#DELFLASH – Erase Flash Memory Parameter Values .....	13	#RINGCOUNT – Set Number of Rings .....	79
#DIALN1 – Primary Dial-Up Number .....	79	#SENDERADDR – Set Sender Address .....	19
#DIALN2 – Secondary Dial-Up Number .....	79	#SENDERNAME – Set Sender Name .....	19
#DIALECT – Internet Connection Number .....	80	#SENDMAILi – Send Mail without Interactive Mode .....	23
#DISPLAYIP – Display IP Addresses .....	85	#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
<b>#DLEMODE – Set DLE Mode .....</b>	33	#SMTPAUTH – Authentication ON or OFF .....	25
#DOMAIN – Set Domain Name of the Sender .....	20	<b>#FTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value .....</b>	21
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15	#SMTTPORT – Set SMTP Server Port .....	21
<b>#FTAPPEND – Append Data to Server .....</b>	31	#SMTTPW – Set SMTP Password .....	22
#FTPGET – Download Files from FTP Server .....	30	#SMTPSERV – Set SMTP Server Address .....	22
#FTPGETFILENAME – Set FTP Download File Name .....	29	#SMPUN – Set SMTP User Name .....	22
#FTPGETPATH – Set Path to Get Files from FTP Server .....	31	#SUBJi – Set Email Pre-Defined Subject .....	20
#FTPMODE – Enter FTP Mode .....	28	<b>#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value .....</b>	36
		<b>#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value .....</b>	36

#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size .....	35
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size .....	35
#TCPPORT – Set TCP Port for Remote Peer .....	34
#TCPSEERV – Set Address of Remote TCP Server .....	34
#TCPTELNETMODE – Enable/Disable TCP Listener Telnet Protocol .....	37
#TCPTELNETPW – Configure the TCP Client Telnet Server Login Password .....	37
#TCPTELNETUN – Set the TCP Client Telnet Server User Name .....	38
#TCPTXDELAY – Time Delay .....	34
#UDPDLEMODE – Set DLE Mode .....	45
#UDPIGNORESRCPORT – Ignore Send Source Port .....	43
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value .....	42
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size .....	42
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size .....	41
#UDPPORT – UDP Port Number .....	43
#UDPREMPOTEPORT – Remote Port Number .....	43
#UDPSERV – UDP Server Address .....	44
#UDPTXDELAY – Delay before Sending UDP Datagram .....	44
#VALL – Display All Parameters .....	18
#VFTP – Display FTP Parameters .....	32
#VMAILi – Display Email Parameters for Mail ID .....	25
#VPHY – Display Physical Parameters .....	86
#VPING – Display PING Parameters .....	48
#VPOP3 – POP3 Module Parameters .....	27
#VPPP – Display PPP Parameters .....	86
#VSHOWSERIAL – Configure the Escape Character for DLEMODE .....	15
#VSHOWUPTIME – Displays the Current Uptime in Days, Hrs, Mins, Secs .....	16
#VSHOWUPTIMES – Displays the Current Uptime in Secs .....	16
#VSMBT – Display SMTP Parameters .....	25
#VSTATE – Display Current State of Physical Connection .....	16
#VTCP – Display TCP Parameters .....	40
#VUDP – Display UDP Module Configuration .....	46
#VVERSION – Display Software Version .....	16
&C – RLSD (DCD) Option .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM .....	12
+IFC – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control .....	13
+IPR – Set Serial Speed .....	13
+WOPEN – Mode of Operation .....	74
AT – Command Mode .....	10
E – Turn Echo ON/OFF .....	10
I – Identification .....	10
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
Commands for SocketEthernet IP	
#AUTODISC – Auto Discovery On or Off .....	54
#AUTODISCHOST – Set Auto Discovery Host Name .....	54
#AUTODISCPASSWORD – Set Auto Discovery Password .....	55
#AUTODISCPORT – Auto Discovery Port .....	54
#AUTODISCTIMER – Auto Discovery Timer .....	54
#AUTODISCUSERNAME – Set Auto Discovery User Name .....	55
#BODYi – Set Pre-Defined Email Combinations .....	21
#CCRECi – Set Additional Recipient CC .....	19
#DELFLASH – Erase Flash Memory Parameter Values .....	13
#DHCP – DHCP On or Off .....	50
#DLEMODE – Set DLE Mode .....	33
#DNSSERV1 – Set DNS Server IP Address .....	51
#DNSSERV2 – Set Secondary DNS Server .....	51
#DOMAIN – Set Domain Name of the Sender .....	20
#EMACSPD – Set Ethernet Connection .....	51
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15
#ETHIFSTATUS – View Network Interface Settings .....	52
#FTAPPEND – Append Data to Server .....	31
#FTPGET – Download Files from FTP Server .....	30
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPGETPATH – Set Path to Get Files from FTP Server .....	31
#FTPMODE – Enter FTP Mode .....	28
#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value .....	32
#FTPPORT – Enter FTP Server Port .....	28
#FTPPUT – Upload Files to FTP Server .....	30
#FTPPUTFILENAME – Set FTP Upload File Name .....	29
#FTPPUTPATH – Set Path to Send Files to FTP Server .....	31
#FTPPW – Set FTP Password .....	29
#FTPSERV – Specify FTP Server Address .....	29
#FTPTYPE – Specify Data Type .....	28
#FTPUN – Set FTP User Name .....	29
#GETMAIL – Retrieve Host Mail .....	27
#HOSTNAME – Configure the DHCP Client Host Name .....	52
#IPADDR – Set Static IP Address .....	50
#IPGATEWAY – Set Gateway Address .....	50
#IPNETMASK – Set Subnet Mask .....	51
#LTCPSTART – Open Listening Mode .....	38
#LTCPSTOP – Close TCP Listening Mode .....	39
#LUDPSTART – Initiate the UDP Session in Listen Mode .....	45
#LUDPSTOP – Close UDP Listening Mode .....	46
#OTCP – Open a TCP Connection .....	39
#OUDP – Initiate UDP Session in Active Mode .....	46
#OUTPORT – UDP/TCP Local Port Number .....	39, 46
#PING – Start PING Request .....	47
#PINGDELAY – PING Delay Time .....	47
#PINGNUM – Number of PING Requests .....	47
#PINGREMOTE – IP Address of PING Request .....	47
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26
#POP3PW – Set POP3 Password .....	26
#POP3SERV – Set POP3 Server Address .....	26
#POP3UN – Set POP3 User Name .....	27
#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#RECIADD – Set Email Address .....	20
#RESET – Reset Main Processor or Internal Modem .....	14
#SENDERADDR – Set Sender Address .....	19
#SENDERNAME – Set Sender Name .....	19
#SENDMAILi – Send Mail without Interactive Mode .....	23
#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
#SMTPAUTH – Authentication ON or OFF .....	25
#SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value .....	21
#SMTPPORT – Set SMTP Server Port .....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SUBJi – Set Email Pre-Defined Subject .....	20
#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value .....	36

#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value.....	36
#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size.....	35
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size.....	35
#TCPPORT – Set TCP Port for Remote Peer .....	34
#TCPSEERV – Set Address of Remote TCP Server .....	34
#TCPTELNETMODE – Enable/Disable TCP Listener Telnet Protocol.....	37
#TCPTELNETPW – Configure the TCP Client Telnet Server Login Password.....	37
#TCPTELNETUN – Set the TCP Client Telnet Server User Name .....	38
#TCPTXDELAY – Time Delay .....	34
#TELNET – Start/Stop Telnet Session.....	63
#TELNETPASSWORD – Set Telnet Password .....	64
#TELNETPORT – Set Telnet Port .....	63
#TELNETUSER – Set Telnet User .....	63
#UDPDLEMODE – Set DLE Mode .....	45
#UDPIGNORESRCPORT – Ignore Send Source Port .....	43
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value.....	42
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size.....	42
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size.....	41
#UDPPORT – UDP Port Number .....	43
#UDPREMPOTEPORT – Remote Port Number .....	43
#UDPSERV – UDP Server Address .....	44
#VALL – Display All Parameters .....	18
#VAUTODISC – Display Auto Discover Commands .....	55
#VDNS – Display Configuration of DNS Servers .....	52
#VFTP – Display FTP Parameters .....	32
#VIP – View Address Settings .....	53
#VMAILi – Display Email Parameters for Mail ID .....	25
#VPING – Display PING Parameters .....	48
#VPOP3 – POP3 Module Parameters .....	27
#VSHOWSERIAL – Configure the Escape Character for DLEMODE .....	15
#VSHOWUPTIME – Displays the Current Uptime in Days, Hrs, Mins, Secs .....	16
#VSHOWUPTIMES – Displays the Current Uptime in Secs .....	16
#VSMTP – Display SMTP Parameters .....	25
#VTCP – Display TCP Parameters .....	40
#VTELNET – View Telnet Settings .....	64
#VUDP – Display UDP Module Configuration .....	46
#VVERSION – Display Software Version .....	16
&C – RLSD (DCD) Option .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM .....	12
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control .....	13
+IPR – Set Serial Speed .....	13
AT – Command Mode .....	10
E – Turn Echo ON/OFF .....	10
I – Identification .....	10
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
Commands for SocketModem iCell	
#ACCEPT – Answer Incoming Call .....	81
#ANSWERMODE – Set Answering Mode .....	75
#APNPW – Access Point Name Password .....	84
#APNSERV – Access Point Name .....	84
#APNUN – Access Point User Name .....	84
#ATCMD – Customize Dial-Up Commands .....	78
#AUTHENT – Authentication Type .....	74
#AUTOCONNECT – Automatically Connect the PPP Link .....	83
#AUTORESET – Reset Main Processor at a Given Time .....	13
#BODYi – Set Pre-Defined Email Combinations .....	21
#CALLBACKTIMER – Automatic Call-Back Wait .....	76
#CALLSCREENNUM – Caller ID .....	76
#CCRECi – Set Additional Recipient CC .....	19
#CONNECTIONSTART – Start Communication .....	82
#CONNECTIONSTOP – Stop Communication .....	81
#DELFLASH – Erase Flash Memory Parameter Values .....	13
#DIALN1 – Primary Dial-Up Number .....	79
#DIALN2 – Secondary Dial-Up Number .....	79
#DIALSELECT – Internet Connection Number .....	80
#DISPLAYIP – Display IP Addresses .....	85
#DLEMODE – Set DLE Mode .....	33
#DOMAIN – Set Domain Name of the Sender .....	20
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15
#FTPAPPEND – Append Data to Server .....	31
#FTPGET – Download Files from FTP Server .....	30
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPGETPATH – Set Path to Get Files from FTP Server .....	31
#FTPMODE – Enter FTP Mode .....	28
#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value .....	32
#FTPPORT – Enter FTP Server Port .....	28
#FTPPUT – Upload Files to FTP Server .....	30
#FTPPUTFILENAME – Set FTP Upload File Name .....	29
#FTPPUTPATH – Set Path to Send Files to FTP Server .....	31
#FTPPW – Set FTP Password .....	29
#FTPSERV – Specify FTP Server Address .....	29
#FTPTYPE – Specify Data Type .....	28
#FTPUN – Set FTP User Name .....	29
#GETMAIL – Retrieve Host Mail .....	27
#GPRSCID – PDP Context Identifier .....	85
#GPRS MODE – Switch Between GSM and GPRS .....	85
#ISPPW – ISP Password .....	80
#ISPUN – ISP User Name .....	80
#KEEPALIVEDELAY – Keep-Alive Delay .....	77
#KEEPALIVEMODE – Keep-Alive Mode .....	76
#KEEPALIVEPORT – Keep-Alive Port Number .....	77
#KEEPALIVESERV – Keep-Alive Server Address .....	77
#LEGACYMODE – Legacy Mode Enable/Disable .....	14
#LTCPCSTART – Open Listening Mode .....	38
#LTCPCSTOP – Close TCP Listening Mode .....	39
#LUDPSTART – Initiate the UDP Session in Listen Mode .....	45
#LUDPSTOP – Close UDP Listening Mode .....	46
#OTCP – Open a TCP Connection .....	39
#OUDP – Initiate UDP Session in Active Mode .....	46
#OUTPORT – UDP/TCP Local Port Number .....	39, 46, 77
#PERSISTENTSOCKET – Persistent Socket .....	33, 41
#PHYTIMEOUT – Inactivity Timer .....	78
#PING – Start PING Request .....	47
#PINGDELAY – PING Delay Time .....	47
#PINGNUM – Number of PING Requests .....	47
#PINGREMOTE – IP Address of PING Request .....	47
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26
#POP3PW – Set POP3 Password .....	26
#POP3SERV – Set POP3 Server Address .....	26
#POP3UN – Set POP3 User Name .....	27
#PPPMODE – TCP/IP Behavior .....	83
#PPPMYIP – IP Address When Using PPP .....	83
#PPPPEERIP – IP Address for Remote PPP .....	84
#PPPSERVPW – Remote PPP Client Password .....	84
#PPPSERVUN – User Name for Remote PPP Client .....	84

#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#RECIADD – Set Email Address .....	20
#REDIALCOUNT – Connection Attempts Allowed .....	78
#REDIALDELAY – Call Retry Delay .....	78
#RESET – Reset Main Processor or Internal Modem.....	14
#RINGCOUNT – Set Number of Rings.....	79
#SENDERADDR – Set Sender Address.....	19
#SENDERNAME – Set Sender Name .....	19
#SENDMAILi – Send Mail without Interactive Mode .....	23
#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
#SMTPAUTH – Authentication ON or OFF .....	25
#SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value.....	21
#SMTPPORT – Set SMTP Server Port.....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SUBJi – Set Email Pre-Defined Subject.....	20
#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value.....	36
#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value.....	36
#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size .....	35
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size .....	35
<b>#TCPPORT – Set TCP Port for Remote Peer .....</b>	34
<b>#TCPSERV – Set Address of Remote TCP Server .....</b>	34
<b>#TCPTELNETMODE – Enable/Disable TCP Listener Telnet Protocol.....</b>	37
#TCPTELNETPW – Configure the TCP Client Telnet Server Login Password.....	37
#TCPTELNETUN – Set the TCP Client Telnet Server User Name .....	38
<b>#TCPTXDELAY – Time Delay .....</b>	34
<b>#UDPDLEMODE – Set DLE Mode .....</b>	45
#UDPIGNORESRCPORT – Ignore Send Source Port .....	43
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value.....	42
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size .....	42
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size .....	41
<b>#UDPPORT – UDP Port Number .....</b>	43
#UDPREMPOTEPORT – Remote Port Number.....	43
<b>#UDPSSERV – UDP Server Address .....</b>	44
<b>#UDPTXDELAY – Delay before Sending UDP Datagram .....</b>	44
#VALL – Display All Parameters .....	18
#VFTP – Display FTP Parameters .....	32
#VMAILi – Display Email Parameters for Mail ID .....	25
#VPHY – Display Physical Parameters.....	86
<b>#VPING – Display PING Parameters .....</b>	48
#VPOP3 – POP3 Module Parameters .....	27
#VPPP – Display PPP Parameters .....	86
#VSHOWSERIAL – Configure the Escape Character for DLEMODE .....	15
#VSHOWUPTIME – Displays the Current Uptime in Days, Hrs, Mins, Secs.....	16
#VSHOWUPTIMES – Displays the Current Uptime in Secs .....	16
#VSMBTP – Display SMTP Parameters .....	25
#VSTATE – Display Current State of Physical Connection .....	16
<b>#VTCP – Display TCP Parameters .....</b>	40
<b>#VUDP – Display UDP Module Configuration .....</b>	46
#VVERSION – Display Software Version .....	16
&C – RLSD (DCD) Option.....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM.....	12
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control.....	13
+IPR – Set Serial Speed .....	13
+WOPEN – Mode of Operation.....	74
AT – Command Mode.....	10
E – Turn Echo ON/OFF .....	10
I – Identification.....	10
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
Commands for SocketModem IP .....	
#ACCEPT – Answer Incoming Call .....	81
#ANSWERMODE – Set Answering Mode .....	75
#APNPW – Access Point Name Password .....	84
#APNSERV – Access Point Name.....	84
#APNUN – Access Point User Name .....	84
#ATCMD – Customize Dial-Up Commands .....	78
#AUTHENT – Authentication Type .....	74
#AUTOCONNECT – Automatically Connect the PPP Link .....	83
#AUTORESET – Reset Main Processor at a Given Time ..	13
#BODYi – Set Pre-Defined Email Combinations .....	21
#CALLBACKTIMER – Automatic Call-Back Wait .....	76
#CALLSCREENNUM – Caller ID .....	76
#CCRECi – Set Additional Recipient CC .....	19
#CONNECTIONSTART – Start Communication .....	82
#CONNECTIONSTOP – Stop Communication .....	81
#DELFLASH – Erase Flash Memory Parameter Values ..	13
#DIALN1 – Primary Dial-Up Number .....	79
#DIALN2 – Secondary Dial-Up Number .....	79
#DIALSELECT – Internet Connection Number .....	80
#DISPLAYIP – Display IP Addresses .....	85
<b>#DLEMODE – Set DLE Mode .....</b>	33
#DOMAIN – Set Domain Name of the Sender .....	20
#ESCAPECHAR – Configure the Escape Character for DLEMODE .....	15
<b>#FTAPPEND – Append Data to Server .....</b>	31
#FTPGET – Download Files from FTP Server .....	30
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPGETPATH – Set Path to Get Files from FTP Server ..	31
#FTPMODE – Enter FTP Mode .....	28
#FTPNETWORKTIMER – FTP Client Network Transmit Safety Timeout Value .....	32
#FTPPORT – Enter FTP Server Port .....	28
#FTPPUT – Upload Files to FTP Server .....	30
#FTPPUTFILENAME – Set FTP Upload File Name .....	29
<b>#FTPPUTPATH – Set Path to Send Files to FTP Server .....</b>	31
#FTPPW – Set FTP Password .....	29
#FTPSERV – Specify FTP Server Address .....	29
#FTPTYPE – Specify Data Type .....	28
#FTPUN – Set FTP User Name .....	29
#GETMAIL – Retrieve Host Mail .....	27
#GPRSCID – PDP Context Identifier .....	85
#GPRS MODE – Switch Between GSM and GPRS .....	85
#ISPPW – ISP Password .....	80
#ISPUN – ISP User Name .....	80
#KEEPALIVEDELAY – Keep-Alive Delay .....	77
#KEEPALIVEMODE – Keep-Alive Mode .....	76
#KEEPALIVEPORT – Keep-Alive Port Number .....	77
#KEEPALIVESERV – Keep-Alive Server Address .....	77
#LEGACYMODE – Legacy Mode Enable/Disable .....	14
<b>#LTCPCSTART – Open Listening Mode .....</b>	38
<b>#LTCPCSTOP – Close TCP Listening Mode .....</b>	39

#LUDPSTART – Initiate the UDP Session in Listen Mode .....	45
#LUDPSTOP – Close UDP Listening Mode .....	46
#OTCP – Open a TCP Connection .....	39
#OUDP – Initiate UDP Session in Active Mode .....	46
#OUTPORT – UDP/TCP Local Port Number .....	39, 46, 77
#PERSISTENTSOCKET – Persistent Socket .....	33, 41
#PHYTIMEOUT – Inactivity Timer .....	78
#PING – Start PING Request .....	47
#PINGDELAY – PING Delay Time .....	47
#PINGNUM – Number of PING Requests .....	47
#PINGREMOTE – IP Address of PING Request .....	47
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26
#POP3PW – Set POP3 Password .....	26
#POP3SERV – Set POP3 Server Address .....	26
#POP3UN – Set POP3 User Name .....	27
#PPPMODE – TCP/IP Behavior .....	83
#PPPMYIP – IP Address When Using PPP .....	83
#PPPPEERIP – IP Address for Remote PPP .....	84
#PPPSERVPW – Remote PPP Client Password .....	84
#PPPSERVUN – User Name for Remote PPP Client .....	84
#PUTMAIL – Send Mail to Recipient with Interactive Mode .....	24
#RECIADD – Set Email Address .....	20
#REDIALCOUNT – Connection Attempts Allowed .....	78
#REDIALDELAY – Call Retry Delay .....	78
#RESET – Reset Main Processor or Internal Modem .....	14
#RINGCOUNT – Set Number of Rings .....	79
#SENDERADDR – Set Sender Address .....	19
#SENDERNAME – Set Sender Name .....	19
#SENDMAILi – Send Mail without Interactive Mode .....	23
#SHIELDCHAR – Configure the Shielding Character for DLEMODE .....	14
#SMTPAUTH – Authentication ON or OFF .....	25
#SMTPNETWORKTIMER – SMTP Client Network Transmit Safety Timeout Value .....	21
#SMTPPORT – Set SMTP Server Port .....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SUBJi – Set Email Pre-Defined Subject .....	20
#TCPINACTIVITYTIMER – TCP Client Inactivity Timeout Value .....	36
#TCPNETWORKTIMER – TCP Client Network Transmit Safety Timeout Value .....	36
#TCPPACKETMAX – TCP Client Transmit Packet Maximum Size .....	35
#TCPPACKETMIN – TCP Client Transmit Packet Minimum Size .....	35
#TCPPORT – Set TCP Port for Remote Peer .....	34
#TCPSERV – Set Address of Remote TCP Server .....	34
#TCPTELNETMODE – Enable/Disable TCP Listener Telnet Protocol .....	37
#TCPTELNETPW – Configure the TCP Client Telnet Server Login Password .....	37
#TCPTELNETUN – Set the TCP Client Telnet Server User Name .....	38
#TCPTXDELAY – Time Delay .....	34
#UDPDLEMODE – Set DLE Mode .....	45
#UDPIGNORESRCPORT – Ignore Send Source Port .....	43
#UDPINACTIVITYTIMER – UDP Client Inactivity Timeout Value .....	42
#UDPPACKETMAX – UDP Client Transmit Packet Maximum Size .....	42
#UDPPACKETMIN – UDP Client Transmit Packet Minimum Size .....	41
#UDPPORT – UDP Port Number .....	43
#UDPREMPOTEPORT – Remote Port Number .....	43
#UDPSERV – UDP Server Address .....	44
#UDPTXDELAY – Delay before Sending UDP Datagram .....	44
#VALL – Display All Parameters .....	18
#VFTP – Display FTP Parameters .....	32
#VMAILi – Display Email Parameters for Mail ID .....	25
#VPHY – Display Physical Parameters .....	86
#VPING – Display PING Parameters .....	48
#VPOP3 – POP3 Module Parameters .....	27
#VPPP – Display PPP Parameters .....	86
#VSHOWSERIAL – Configure the Escape Character for DLEMODE .....	15
#VSHOWUPTIME – Displays the Current Uptime in Days, Hrs, Mins, Secs .....	16
#VSHOWUPTIMES – Displays the Current Uptime in Secs .....	16
#VSMTPL – Display SMTP Parameters .....	25
#VSTATE – Display Current State of Physical Connection .....	16
#VTCP – Display TCP Parameters .....	40
#VUDP – Display UDP Module Configuration .....	46
#VVERSION – Display Software Version .....	16
&C – RLSD (DCD) Option .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM .....	12
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control .....	13
+IPR – Set Serial Speed .....	13
+WOPEN – Mode of Operation .....	74
AT – Command Mode .....	10
E – Turn Echo ON/OFF .....	10
I – Identification .....	10
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
Commands for SocketWireless Wi-Fi	
#AUTORESET – Reset Main Processor at a Given Time .....	13
#BODYi – Set Pre-Defined Email Combinations .....	21
#BOOTMSG – Enable/Disable Boot Message .....	62
#CCRECi – Set Additional Recipient CC .....	19
#DELFLASH – Erase Flash Memory Parameter Values .....	13
#DHCP – DHCP On or Off .....	57
#DLEMODE – Set DLE Mode .....	33
#DNSSERV1 – Set DNS Server IP Address .....	58
#DNSSERV2 – Set Secondary DNS Server .....	58
#DOMAIN – Set Domain Name of the Sender .....	20
#FTAPPEND – Append Data to Server .....	31
#FTPGET – Download Files from FTP Server .....	30
#FTPGETFILENAME – Set FTP Download File Name .....	29
#FTPGETPATH – Set Path to Get Files from FTP Server .....	31
#FTPMODE – Enter FTP Mode .....	28
#FTPPORT – Enter FTP Server Port .....	28
#FTPPUT – Upload Files to FTP Server .....	30
#FTPPUTFILENAME – Set FTP Upload File Name .....	29
#FTPPUTPATH – Set Path to Send Files to FTP Server .....	31
#FTPPW – Set FTP Password .....	29
#FTPSERV – Specify FTP Server Address .....	29
#FTPTYPE – Specify Data Type .....	28
#FTPUN – Set FTP User Name .....	29
#GETMAIL – Retrieve Host Mail .....	27
#IPADDR – Set Static IP Address .....	57
#IPDNSSERV – Configure the DNS Server .....	58
#IPDNSTABLE – Display DNS Table .....	60
#IPGATEWAY – Set Gateway Address .....	57
#IPNETMASK – Set Subnet Mask .....	58
#IPQUERY – Give a Domain Name .....	59

#IPRELEASE – Release a DHCP Address Assigned by the Server .....	59
#IPRENEW – Renew DHCP Information from Server .....	59
#IPRESOLV – Is There a Connection with DNS or Not .....	59
#LEGACYMODE – Legacy Mode Enable/Disable .....	14
#LTCPSSTART – Open Listening Mode .....	38
#LTCPSSTOP – Close TCP Listening Mode .....	39
#LUDPSSTART – Initiate the UDP Session in Listen Mode .....	45
#LUDPSSTOP – Close UDP Listening Mode .....	46
#OTCP – Open a TCP Connection .....	39
#OUDP – Initiate UDP Session in Active Mode .....	46
#OUTPORT – UDP/TCP Local Port Number .....	39, 46
<b>#PERSISTENTSOCKET – Delay before Sending UDP Datagram</b> .....	44
#PERSISTENTSOCKET – Persistent Socket .....	33, 41
<b>#PING – Start PING Request</b> .....	47
<b>#PINGDELAY – PING Delay Time</b> .....	47
<b>#PINGNUM – Number of PING Requests</b> .....	47
<b>#PINGREMOTE – IP Address of PING Request</b> .....	47
#POP3HEADERMODE – POP3 Header .....	26
#POP3PORT – Set POP3 Server Port .....	26
#POP3PW – Set POP3 Password .....	26
#POP3SERV – Set POP3 Server Address .....	26
#POP3UN – Set POP3 User Name .....	27
<b>#PUTMAIL – Send Mail to Recipient with Interactive Mode</b> .....	24
#RECIADD – Set Email Address .....	20
#RESET – Reset Main Processor or Internal Modem .....	14
#SENDERADDR – Set Sender Address .....	19
#SENDERNAME – Set Sender Name .....	19
#SENDMAILi – Send Mail without Interactive Mode .....	23
#SMTPAUTH – Authentication ON or OFF .....	25
#SMTPPORT – Set SMTP Server Port .....	21
#SMTPPW – Set SMTP Password .....	22
#SMTPSERV – Set SMTP Server Address .....	22
#SMTPUN – Set SMTP User Name .....	22
#SUBJi – Set Email Pre-Defined Subject .....	20
<b>#TCPPORT – Set TCP Port for Remote Peer</b> .....	34
<b>#TCPSERV – Set Address of Remote TCP Server</b> .....	34
<b>#TCPTXDELAY – Time Delay</b> .....	34
#TELNET – Start/Stop Telnet Session .....	63
#TELNETPASSWORD – Set Telnet Password .....	64
#TELNETPORT – Set Telnet Port .....	63
#TELNETUSER – Set Telnet User .....	63
<b>#UDPDLEMODE – Set DLE Mode</b> .....	45
<b>#UDPPORT – UDP Port Number</b> .....	43
<b>#UDPSERV – UDP Server Address</b> .....	44
#VALL – Display All Parameters .....	18
#VDNS – Display Configuration of DNS Servers .....	60
#VFTP – Display FTP Parameters .....	32
#VIP – View Address Settings .....	60
#VMAILi – Display Email Parameters for Mail ID .....	25
<b>#VPING – Display PING Parameters</b> .....	48
#VPOP3 – POP3 Module Parameters .....	27
#VSIMTP – Display SMTP Parameters .....	25
#VSTATE – Display Current State of Physical Connection .....	16
<b>#VTCP – Display TCP Parameters</b> .....	40
#VTELNET – View Telnet Settings .....	64
<b>#VUDP – Display UDP Module Configuration</b> .....	46
#VVERSION – Display Software Version .....	16
#WATCHDOG – Enable/Disable Watchdog .....	62
#WATCHDOGTIMER – Watchdog Timer .....	62
#WEP? – View Values of WEP Keys .....	71
#WEP128KEY – Keys for WEP128 Security Mode .....	70
#WEP64KEY – Keys for WEP64 Security Mode .....	69
#WEPEKEYID – Set Default TX Key Index .....	70
#WLAN?' – WLAN Module .....	72
<b>#WLANACTIVATE – Move Module out of Power Save</b> .....	69
<b>#WLANASSOCINFO – Display Association Information</b> .....	72
<b>#WLANCONNECT – Connect with AP</b> .....	67
<b>#WLANCOUNTRYCODE – Country Code</b> .....	65
<b>#WLANDATARATE – WLAN Transmission Data Rate</b> .....	66
<b>#WLANSDisconnect – Disconnect with AP</b> .....	67
<b>#WLANDOZE= – Moves Module into or out of Power Save</b> .....	67
<b>#WLANENABLE – Auto Connect Module with AP</b> .....	67
<b>#WLANGETRSSI – Received Signal Strength</b> .....	69
<b>#WLANIBSSCHANNEL – Channel for Ad-Hoc Mode</b> .....	66
<b>#WLANNETWORKMODE – WLAN Network Mode</b> .....	65
<b>#WLANPOWERSAVE – Enable Power Save at Boot</b> .....	70
<b>#WLANPROFILE – Display the WLAN Profile</b> .....	71
<b>#WLANPROFILEn=n – Change the WLAN Profile</b> .....	68
<b>#WLANROAM – Enable/Disable Roaming</b> .....	69
<b>#WLANS SCAN – SCAN Wireless Networks</b> .....	68
<b>#WLANS SCAN MODE – Scanning Mode</b> .....	66
<b>#WLANSECURITYMODE – Security Mode of WLAN Module</b> .....	65
<b>#WLANSSID – SSID of WLAN</b> .....	66
<b>#WLANUSEPROFILE – User Profile</b> .....	69
<b>#WPA2PSKKEY – Keys for WPA2 PSK Security Mode</b> .....	70
<b>#WPAPSKKEY – Keys for WAP PSK Security Mode</b> .....	70
&C – RLSD (DCD) Option .....	11
&D – DTR Option .....	11
&F – Reset Factory Defaults .....	11
&S – DSR On or Off .....	11
&W – Store Factory Defaults to NVM .....	12
+ICF – DTE-DCE Character Framing .....	12
+IFC – Set Flow Control .....	13
+IPR – Set Serial Speed .....	13
A – Manual Answer of TCP or UDP .....	61
A/ – Previous Command .....	61
AT – Command Mode .....	10
E – Turn Echo ON/OFF .....	10
I – Identification .....	10
S0= – Automatic Answer .....	59
S2 – Escape Sequence .....	61
V – Terse or Verbose .....	10
Z – Default Configuration .....	11
Configure the DHCP Client Host Name – #HOSTNAME .....	52
Configure the DNS Server – #IPDNSSERV .....	58
Configure the Escape Character for DLEMODE – #ESCAPECHAR .....	15
Configure the Escape Character for DLEMODE – #VSHOWSERIAL .....	15
Configure the GPIO pin and trigger type – #GPIOTRIGGER .....	90
Configure the Shielding Character for DLEMODE – #SHIELDCHAR .....	14
Configure the TCP Client Telnet Server Login Password – #TCPTELNETPW .....	37
Connect with AP – #WLANCONNECT .....	67
Connection Attempts Allowed – #REDIALCOUNT .....	78
Country Code – #WLANCOUNTRYCODE .....	65
Customize Dial-Up Commands – #ATCMD .....	78
<b>D</b>	
Default Configuration – Z .....	11
<b>Delay before Sending UDP Datagram – #UDPTXDELAY</b> .....	44
<b>DHCP On or Off – #DHCP</b> .....	50, 57
Disconnect with AP – #WLANSDisconnect .....	67
Display All Parameters – #VALL .....	18
Display Association Information – #WLANASSOCINFO .....	72
Display Auto Discovery Commands – #VAUTODISC .....	55
Display Configuration of DNS Servers – #VDNS .....	52, 60

Display Current State of Physical Connection – #VSTATE .....	16	Ignore Send Source Port – #UDPIGNORESRCPORT ....	43
Display DNS Table – #IPDNSTABLE .....	60	Inactivity Timer – #PHYTIMEOUT .....	78
Display Email Parameters for Mail ID – #VMAILi .....	25	<b>Initiate the UDP Session in Listen Mode –</b>	
Display FTP Parameters – #VFTP .....	32	#LUDPSTART .....	45
Display IP Addresses – #DISPLAYIP .....	85	<b>Initiate UDP Session in Active Mode – #OUDP .....</b>	46
Display Physical Parameters – #VPHY .....	86	Internet Connection Number – #DIALSELECT .....	80
<b>Display PING Parameters – #VPING .....</b>	48	IP Address for Remote PPP – #PPPPEERIP .....	84
Display PPP Parameters – #VPPP .....	86	<b>IP Address of PING Request – #PINGREMOTE .....</b>	47
Display SMTP Parameters – #VSMTP .....	25	IP Address When Using PPP – #PPPMYIP .....	83
Display Software Version – #VVERSION .....	16	Is There a Connection with DNS or Not – #IPRESOLV .....	59
<b>Display TCP Parameters – #VTCP .....</b>	40	ISP Password – #ISPPW .....	80
Display the WLAN Profile – #WLANPROFILE .....	71	ISP User Name – #ISPUN .....	80
<b>Display UDP Module Configuration – #VUDP .....</b>	46		
Displays the Current Uptime in Days, Hrs, Mins, Secs – #VSHOWUPTIME .....	16		
Displays the Current Uptime in Secs – #VSHOWUPTIMES .....	16		
Download Files from FTP Server – #FTPGET .....	30		
DSR On or Off – &S .....	11		
DTE-DCE Character Framing – +ICF .....	12		
DTR Option – &D .....	11		
<b>E</b>			
E – Turn Echo ON/OFF .....	10		
Enable Power Save at Boot – #WLANPOWERSAVE .....	70		
<b>Enable/Disable and Configure External GPIO Driven Events – #GPIO .....</b>	89		
Enable/Disable Boot Message – #BOOTMSG .....	62		
Enable/Disable GPGGA Message – #GPSGPGGA .....	93		
Enable/Disable GPGLL Message – #GPSGPGLL .....	94		
Enable/Disable GPGSA Message – #GPSGPGSA .....	94		
Enable/Disable GPGSV Message – #GPSGPGSV .....	94		
Enable/Disable GPRMC Message – #GPSGPRMC .....	94		
Enable/Disable GPVTG Message – #GPSGPVTG .....	95		
Enable/Disable Roaming – #WLANROAM .....	69		
Enable/Disable TCP Listener Telnet Protocol – #TCPTELNETMODE .....	37		
Enable/Disable Watchdog – #WATCHDOG .....	62		
Enter FTP Mode – #FTPMODE .....	28		
Enter FTP Server Port – #FTPPORT .....	28		
Erase Flash Memory Parameter Values – #DELFLASH .....	13		
Error Codes .....	105		
Escape Sequence – S2 .....	61		
<b>F</b>			
FTP Client Network Transmit Safety Timeout Value – #FTPNETWORKTIMER .....	32		
<b>G</b>			
Get Queued GPS Message – #GPSGETMESSAGE .....	95		
Give a Domain Name – #IPQUERY .....	59		
GLL – Latitude/Longitude .....	100		
GPS Configuration Examples .....	97		
GPS Local Transmission Interval – #GPSINTERVALLOC	95		
GPS Message Examples .....	96		
GPS Message Syntax .....	96		
GPS NMEA Messages .....	99		
GPS NMEA Protocol .....	98		
GSA – GNSS DOP and Active Satellites .....	100		
GSV – GNSS Satellites in View .....	101		
<b>I</b>			
I – Identification .....	10		
id parameter .....	33		
<b>K</b>			
Keep-Alive Delay – #KEEPALIVEDELAY .....	77		
Keep-Alive Mode – #KEEPALIVEMODE .....	76		
Keep-Alive Port Number – #KEEPALIVEPORT .....	77		
Keep-Alive Server Address – #KEEPALIVESERV .....	77		
Keys for WAP PSK Security Mode – #WPAPSKEY .....	70		
Keys for WEP128 Security Mode – #WEP128KEY .....	70		
Keys for WEP64 Security Mode – #WEP64KEY .....	69		
Keys for WPA2 PSK Security Mode – #WPA2PSKKEY .....	70		
<b>L</b>			
Legacy Mode Enable/Disable – #LEGACYMODE .....	14		
<b>M</b>			
Manual Answer of TCP or UDP – A .....	61		
Mode of Operation – +WOPEN .....	74		
Move Module out of Power Save – #WLANACTIVATE .....	69		
Moves Module into or out of Power Save – #WLANDOZE= .....	67		
<b>N</b>			
Number of PING Requests – #PINGNUM .....	47		
<b>O</b>			
Open a TCP Connection – #OTCP .....	39		
Open Listening Mode – #LTCPSTART .....	38		
<b>P</b>			
PDP Context Identifier – #GPRSCID .....	85		
Persistent Socket – #PERSISTENTSOCKET .....	33, 41		
<b>PING Delay Time – #PINGDELAY .....</b>	47		
POP3 Header – #POP3HEADERMODE .....	26		
POP3 Module Parameters – #VPOP3 .....	27		
Previous Command – A/ .....	61		
Primary Dial-Up Number – #DIALN1 .....	79		
<b>R</b>			
Read the Current Register Status of the Specified GPIO Pin – #GPIOR .....	89		
Received Signal Strength – #WLANGERSSI .....	69		
Release a DHCP Address Assigned by the Server – #IPRELEASE .....	59		
Remote Port Number – #UDPREMPOTEPORT .....	43		
Remote PPP Client Password – #PPPSERVPW .....	84		
Renew DHCP Information from Server – #IPRENEW .....	59		
Reset Factory Defaults – &F .....	11		
Reset Main Processor at a Given Time – #AUTORESET .....	13		
Reset Main Processor or Internal Modem – #RESET .....	14		
Response Messages .....	104		
Response Messages Examples .....	106, 107, 108, 109		

Retrieve Host Mail – #GETMAIL .....	27
RLSD (DCD) Option – &C .....	11
RMC – Recommended Minimum Specific GNSS Data .....	102
<b>S</b>	
S0= – Automatic Answer .....	59
Scan Wireless Networks – #WLANSCAN .....	68
Scanning Mode – #WLANSCANMODE .....	66
Secondary Dial-Up Number – #DIALN2 .....	79
Security Mode of WLAN Module – #WLANSECURITYMODE .....	65
Send Mail to Recipient with Interactive Mode – #PUTMAIL .....	24
Send Mail without Interactive Mode – #SENDMAIL .....	23
Set Additional Recipient CC – #CCRECI .....	19
<b>Set Address of Remote TCP Server – #TCPSEERV</b> .....	34
Set Answering Mode – #ANSWERMODE .....	75
Set Auto Discovery Host Name – #AUTODISCHOST .....	54
Set Auto Discovery Password – #AUTODISCPASSWORD .....	55
Set Auto Discovery User Name – #AUTODISCUSERNAME .....	55
Set Default TX Key Index – #WEPEKEYID .....	70
<b>Set DLE Mode – #DLEMODE</b> .....	33
<b>Set DLE Mode – #UPDDEMODE</b> .....	45
Set DNS Server IP Address – #DNSSERV1 .....	51
Set DNS Server IP Address – #DNSSERV1 .....	58
Set Domain Name of the Sender – #DOMAIN .....	20
Set Email Address – #RECIADD .....	20
Set Email Pre-Defined Subject Text – #SUBJ .....	20
Set Ethernet Connection – #EMACSPD .....	51
Set Flow Control – +IFC .....	13
Set FTP Download File Name – #FTPGETFILENAME .....	29
Set FTP Password – #FTPPW .....	29
Set FTP Upload File Name – #FTPPUTFILENAME .....	29
Set FTP User Name – #FTPUN .....	29
<b>Set Gateway Address – #IPGATEWAY</b> .....	50, 57
Set GPS Host Login Password – #GPSPW .....	93
Set GPS Host Port – #GPSPORT .....	92
Set GPS Host Protocol – #GPSPROTO .....	92
Set GPS Host Server Address – #GPSSERV .....	92
Set GPS Message Prefix – #GPSPREFIX .....	92
Set GPS Server Transmission Interval – #GPSINTERVAL .....	93
Set GPS Unique Remote Asset Identification String Host Protocol – #GPSURAIS .....	93
Set Number of Rings – #RINGCOUNT .....	79
Set Path to Get Files from FTP Server – #FTPGETPATH .....	31
<b>Set Path to Send Files to FTP Server – #FTPPUTPATH</b> .....	31
Set POP3 Password – #POP3PW .....	26
Set POP3 Server Address – #POP3SERV .....	26
Set POP3 Server Port – #POP3PORT .....	26
Set POP3 User Name – #POP3UN .....	27
Set Pre-Defined Email Combinations – #BODYi .....	21
Set Secondary DNS Server – #DNSSERV2 .....	51, 58
Set Sender Address – #SENDERADDR .....	19
Set Sender Name – #SENDERNAME .....	19
Set Serial Speed – +IPR .....	13
Set SMTP Password – #SMTPPW .....	22
Set SMTP Server Address – #SMTPSERV .....	22
Set SMTP Server Port – #SMTPPORT .....	21
Set SMTP User Name – #SMTPUN .....	22
<b>Set Static IP Address – #IPADDR</b> .....	50, 57
Set Subnet Mask – #IPNETMASK .....	51, 58
<b>T</b>	
TCP Client Inactivity Timeout Value – #TCPINACTIVITYTIMER .....	36
TCP Client Network Transmit Safety Timeout Value – #TCPNETWORKTIMER .....	36
TCP Client Transmit Packet Maximum Size – #TCPPACKETMAX .....	35
TCP Client Transmit Packet Minimum Size – #TCPPACKETMIN .....	35
TCP/IP Behavior – #PPPMODE .....	83
Terse or Verbose – V .....	10
<b>Time Delay – #TCPTXDELAY</b> .....	34
<b>U</b>	
UDP Client Inactivity Timeout Value – #UDPINACTIVITYTIMER .....	42
UDP Client Transmit Packet Maximum Size – #UDPPACKETMAX .....	42
UDP Client Transmit Packet Minimum Size – #UDPPACKETMIN .....	41
<b>UDP Port Number – #UDPPORT</b> .....	43
<b>UDP Server Address – #UDPSERV</b> .....	44
UDP/TCP Local Port Number – #OUTPORT .....	39, 46, 77
Upload Files to FTP Server – #FTPPUT .....	30
User Name for Remote PPP Client – #PPPSERVUN .....	84
User Profile – #WLANUSEPROFILE .....	69
<b>V</b>	
V – Terse or Verbose .....	10
View Address Settings – #VIP .....	53, 60
View Network Interface Settings – #ETHIFSTATUS .....	52
View Telnet Settings – #VTELNET .....	64
View Values of WEP Keys – #WEP? .....	71
VTG – Course Over Ground and Ground Speed .....	102
<b>W</b>	
Watchdog Timer – #WATCHDOGTIMER .....	62
WLAN Module – #WLAN?' .....	72
WLAN Network Mode – #WLANNETWORKMODE .....	65
WLAN Transmission Data Rate – #WLANDATARATE .....	66
<b>Z</b>	
Z – Default Configuration .....	11