



AudioLab
IAG House,
Sovereign Court,
Ermine Business Park,
Huntingdon PE29 6XU
Tel: 01480 447700
Fax: 01480 431767
<http://www.audiolab.co.uk>
CODE: AH10-MNL0001



8200A User Instructions

audiolab

1: Statutory & Safety Information



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.

Read these instructions.

Keep these instructions. In the event that you pass the product to a third party this instruction manual should be provided along with the product.

Heed all warnings.

Follow all instructions.

Do not use this apparatus near water.

Clean only with dry cloth.

Do not block any ventilation openings.

Install in accordance with the manufacturer's instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Use only attachments/accessories specified by the manufacturer.



Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Warning: To reduce the risk of fire or electrical shock, do not expose this product to rain or moisture. The product must not be exposed to dripping and splashing and no object filled with liquids such as a vase of flowers should be placed on the product.

No naked flame sources such as candles should be placed on the product.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Re-orientate or re-locate the receiving antenna. Increase the separation between the equipment and the receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Important Note: The batteries supplied with this unit should be treated with care and not punctured or damaged. Used batteries should be disposed of in full conformity with recycling regulations in your area. NEVER dispose of batteries in a fire or in the general rubbish.


Mains supply and safety

Mains Supply: The mains operating voltage of all Audiolab units is shown on the rear panel. If this does not match the voltage in your area, consult your dealer.

The mains supply fuse is located on the rear panel of the unit. If it has broken, check for any obvious cause before replacing the fuse with one of the correct rating and type. The fuse values are:

220 - 230V (UK, Korea, etc.)
100 - 120V (USA, Japan, etc)

T 2.5AL 20mm Slow Blow
T 4.0AL 20mm Slow Blow



The fuse is located in a slide-in carrier which also contains a spare fuse. The fuse carrier can only be pulled out after the IEC power cord is unplugged. When the carrier is opened the first fuse to be seen is the spare fuse. Remove and safely dispose of the fuse with the blown link before replacing it.



Class II construction double insulated. This product must not be connected to earth.

Power Cord: An AC power cord is normally supplied with a mains plug suitable for your area. If you have any doubts, consult your dealer about obtaining a suitable power cord.

Important notice to UK users


The appliance cord is terminated with a UK approved mains plug fitted with a 5A fuse. If the fuse needs to be replaced, an ASTA or BSI approved BS1362 fuse rated at 5A must be used. If you need to change the mains plug, remove the fuse and dispose of this plug safely immediately after cutting it from the cord.

Connecting a Mains Plug

The wires in the mains lead are coloured in accordance with the code:
Blue: NEUTRAL; Brown: LIVE;

As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:

The BLUE wire must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The BROWN wire must be connected to the terminal marked with the letter L or coloured BROWN or RED.



6: Specifications

Rated Output Power

60 W (18 dBW) per channel into rated load impedance (8 Ohms) with both channels driven

Inputs

CD, TUNER, AUX, VIDEO, TAPE 1, TAPE 2: 125mV/20k Ω IHF
POWER AMP: 782 mV/47 k Ω

Gain

PRE-AMP: 9dB @ 1 kHz
POWER AMP: 29.0 dB @ 1 kHz.

Signal To Noise Ratio

CD, TUNER, AUX, VIDEO, TAPE 1, TAPE 2:
Better than 80dB(IHF, rel. 0.5 V pre-amp output)
POWER AMP: better than 80dB(IHF, rel. 0 dBW)

Frequency Response

CD, TUNER, AUX, VIDEO, TAPE 1, TAPE 2 and POWER AMP:
20 Hz-20 kHz \pm 0.5 dB: 1 Hz-65 kHz -3 dB.

Total Harmonic Distortion & Noise

Less than 0.07 %

Channel Balance

Within 1 dB

Channel Separation

Better than 60 dB @ 1 kHz any input

Crosstalk

Better than 80 dB @ 1 kHz

Polarity (phase)

Non-inverting for all inputs and outputs

Pre-amp Output

PRE OUT 1 and PRE OUT 2: Output Impedance 100 Ω
Maximum Output > 7.3V RMS

Headphone Output

Output impedance: 330 Ω
(Suitable for headphones 8 Ω -2 k Ω impedance)

Record Output

VIDEO OUT, TAPE 1 OUT, TAPE 2 OUT:

Output impedance: 1 k Ω .

Gain from input to record output 0 dB (x1)

Muting

Muting controlled manually or automatically

Accessories Supplied

AC Power Cord
Instruction Manual
8200RC Remote Control with 2 x AA batteries
Operating Temperature Range

10-35 $^{\circ}$ C

Power Requirements (Depending on Region)

50-60Hz 100 V, 110-120 V, and 220-230 V models available
Maximum Power Consumption: 440 VA

Dimensions (WXHxD)

445x74x335 mm - including feet, terminals and controls
445 x 64 x 302 mm- excluding feet, terminals and controls

Weight

Net: 7.4 kg
Shipping: 8.8 kg

Audiolab reserves the right to alter design and specification without notice. Specification may vary for different countries.

Audiolab is a member of the International Audio Group.



IAG-A.LAB

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

5: Service and Warranty

Servicing

Servicing of Audiolab products should only be carried out by authorised service agents. If service is required the equipment should be returned, securely packaged, preferably using original packaging, to your dealer.

In the UK equipment may be returned to the IAG Service Centre.

Always telephone before returning any equipment.

A note should be enclosed giving your name, address, telephone number, and a brief description of the reason for return.

If you require Service outside the Warranty period, do not hesitate to contact your dealer.

While cleaning is in progress the AC power cord must be unplugged from the AC power supply socket.

Any grease or dirt on the equipment may be removed with a soft, lint-free cloth slightly moistened with a mild solution of warm water and detergent or washing-up liquid. Do not use any other solutions or solvents.

Retain original packaging for transporting equipment.

If you have any queries regarding the use of Audiolab equipment, consult your dealer.

Service Addresses, UK

IAG Service Centre
Unit 4
St Margaret's Way
Stukeley Meadows Ind. Estate
Huntingdon
Cambs
PE29 6EB
England
Tel: +44 (0)1480 452561
Fax: +44 (0)1480 13403

Audiolab limited warranty

Audiolab Ltd. warrants this product, subject to the terms and conditions below, to be free from defects in materials and workmanship. During the warranty period Audiolab will repair or replace (at Audiolab's option) this product, or any defective part in this product, if it is found to be defective due to faulty materials, workmanship or function. The warranty period may vary from country to country.

Terms and conditions:

The warranty starts on the date of purchase (or the date of delivery if this is later).

You must provide proof of purchase / delivery before work can be carried out. Without this proof, any work carried out will be chargeable to you.

All work will be carried out by Audiolab or its authorised agents or distributors. Any unauthorised repair or modification will void this warranty.

If any part is no longer available it will be replaced with a functional replacement part.

Any parts that are replaced will become the property of Audiolab.

Any repair or replacement under this warranty will not extend the period of warranty.

This warranty is valid only in the country of purchase, applies only to the first purchaser and is not transferable.

The following are not covered:

- Products on which the serial number has been removed, altered or otherwise made illegible.
- Normal wear and tear and cosmetic damage.
- Transportation or installation of the product.
- Accidental damage, faults caused by commercial use, acts of God, incorrect installation, connection or packaging, misuse, neglect or careless operation or handling of the product which is not in accordance with Audiolab's user instructions.
- Equipment that has been operated in conjunction with unsuitable, inappropriate or faulty apparatus.
- Repairs or alterations carried out by parties other than

Audiolab or its authorised agents or distributors.

- Products not purchased from an Audiolab authorised dealer.
- Products that were not new at the time of original purchase.
- Products sold 'as is', 'as seen' or 'with all faults'.

Repairs or replacements as provided under this warranty are the exclusive remedy of the consumer. Audiolab shall not be liable for any incidental or consequential damages for breach of any express or implied warranty in this product. Except to the extent prohibited by law, this warranty is exclusive and in lieu of all other warranties whatsoever, both express and implied, including, but not limited to, the warranty of merchantability and fitness for a practical purpose.

This warranty provides benefits that are additional to and do not affect your statutory rights as a consumer.

Some countries and US states do not allow the exclusion or limitation of incidental or consequential damages or implied warranties so the exclusions in the paragraph above may not apply to you. This warranty gives you specific legal rights, and you may have other statutory rights, which vary from state to state or country to country.

How to claim:


To obtain warranty service contact the Audiolab authorised dealer from which you purchased this product. Do not despatch goods without the prior agreement of the dealer, Audiolab or their authorised distributors.

If asked to return products for inspection and/or repair, pack carefully, preferably in the original cartons or packaging affording an equal degree of protection, and return prepaid. If unsuitable packaging is used, Audiolab may make a charge for the supply of new packaging.

Insurance is recommended as goods are returned at owner's risk. Audiolab or their authorised distributors cannot be held liable for loss or damage in transit.

Packing, insurance and freight on the return journey will be paid by Audiolab or their authorised agents or distributor if corrective work proves to be necessary.

2: Introduction



Unpacking

Unpack the product fully. The carton should contain

- The Audiolab 8200A integrated amplifier
- One IEC power cord suitable for your area
- One Remote Handset with two AA batteries
- This instruction manual.

If any item is missing or damaged report this to your dealer as soon as possible.

Retain the packing for future safe transport of your amplifier. If you dispose of the packing, do so with regard to any recycling regulations in your area.

Inserting Batteries in the Handset

The battery compartment is on the rear of the handset. Unwrap the batteries, open the compartment cover and insert the batteries. Follow the polarity indications in the battery compartment.

Always replace batteries in pairs. Use new batteries of the same type and rating, ideally from the same manufacturer.

Controls And Functions

Power Switch

When power is switched on the 8200A is muted for 8 seconds.

Always switch the power off before changing connections.

Input Selector

Turn to select the listening source. The 8200A mutes briefly when a new input is selected.

Volume Control

Adjusts playing volume. Always turn the volume up gradually.

Record Selector

Turn to select source to record to Tape 1, Tape 2 or Video. The connections can also be used to connect to any recorder with analogue inputs such as a CD, DAT recorder, etc.

Record selector and input selector operate independently. It is possible to record from any source whilst listening to another.

Mode Switch

Select "integrated" when using 8200A as an integrated amplifier. Select "mute" to turn off pre-amplifier outputs, loudspeakers or headphones. See section 4 for further details.

Headphone Socket

Socket for connection of headphones. Unplug headphones when not in use. Connecting headphones mutes the loudspeakers and disconnects the pre-amplifier outputs and power amplifier inputs.

Remote Handset

Buttons shown in white control the 8200A.

Buttons shown in grey operate Audiolab CD players and have no effect on the 8200A.

As the handset uses RCS coding it will operate many other players. Check with your dealer.

Mute

Toggles mute On/off. Does not function if the MODE switch on the front panel is set to mute.


Input

Press to select listening source. The INPUT selector on the front panel turns.


If you wish to record, the record input must be selected manually.

Volume

Press VOL+/- to raise or lower the volume. The VOLUME control on the front panel turns.



3: Input & Output Connections



Signal Connections

CD, TUNER, AUX, VIDEO IN, TAPE 1 IN, TAPE 2 IN

The six inputs may be used for connecting any line level source.

VIDEO OUT, TAPE 1 OUT, TAPE 2 OUT

Three sets of record outputs for connection of up to three stereo audio recorders, e.g. tape recorder, CD recorder, audio recording input of DVD, MP3, etc.

PRE-AMP OUT 1 & 2

Low impedance (100 ohm) pre-amplifier outputs for driving external power amplifiers, sub-woofers or signal processors. Long cables may be used if required. Pre-amp outputs are switched off when integrated mode is selected or whenever amplifier is muted.

POWER AMP IN

For driving the power amplifier input directly from an external source. Only operates when pre power AV mode is selected.


LOUDSPEAKER TERMINALS

Two sets of loudspeaker output terminals connected in parallel.

GROUND

Use only if phono pre-amplifier and turntable are used and both are Class II double insulated (no earth connection). In this case the ground terminal can be connected to the metalwork of these units to eliminate residual hum. The ground terminal must not be used as a safety earth. If in doubt consult your dealer.


Standard Loudspeaker Connection



You can connect a speaker switching box or headphone adaptor to the unused set of speaker terminals

Bi-Wired Loudspeaker Connection

Loudspeaker bi-wiring offers improved sound quality because high and low frequency signals are carried individually to the loudspeaker drive units.




Connecting Loudspeakers

Switch power off when connecting loudspeakers. Use good quality low resistance loudspeaker cable. Connect the Positive RED (+) terminal of the amplifier to the Positive (+) RED terminal of the loudspeaker. Connect the Negative (-) BLACK terminals similarly.

When connecting loudspeakers tighten the terminals securely by hand.

Make there are no loose strands of wire which could cause shorts.



4: Operation

Operating Modes

Although the 8200A is an integrated amplifier, it can function as a separate pre-amplifier and power amplifier. This allows the unit to be used in a variety of stereo and multichannel modes.

NOTE: When switching modes, the making and breaking of connections may momentarily operate the muting function on the 8200A.

Integrated Mode

The pre-amplifier section is internally connected to the power amplifier. Pre-amp outputs are not operational. External subwoofers, processors, or amplifiers will not receive any signal.

MODE	POWER AMP IN	PRE-AMP OUT 1&2	PRE-POWER INTERNAL LINK	LOUDSPEAKERS
pre	-	ACTIVE	-	-
mute	-	-	ACTIVE	-
integrated	-	-	ACTIVE	OPERATIONAL
pre - power	-	ACTIVE	-	OPERATIONAL
pre power AV	ACTIVE	ACTIVE	-	OPERATIONAL


Pre-Power Mode

The pre-amplifier section is internally connected to the power amplifier. The pre-amplifier outputs are operational.

A powered subwoofer can be connected to the pre-amplifier outputs

A second power amplifier can be connected for bi-amplifying as shown in the diagram.


An additional power amplifier can also be connected to drive a second pair of speakers in a remote location.



Pre Mode

All signals to and from the power amplifier of the 8200A are disconnected. In this mode, the 8200A functions as a stand-alone pre-amplifier.


The pre-amplifier section of the 8200A can be connected to a stereo power amplifier, or to two monobloc amplifiers.



Pre-Power AV

The pre-amplifier and power amplifier sections operate independently. This mode can be used to connect a multichannel AV processor.

The processor should be connected via any spare tape output or, as an alternative, one of the pre-amp outputs.



Switching On

Make sure all the connections to and from the amp are secure and correct.

Make sure the operating mode is correctly set.

Plug the power cord into the wall socket and the amplifier. Switch on at the mains and then switch on the 8200A. The power indicator lights. The unit is operational. The amplifier may be operated via the front panel or the remote handset.

NOTE: Selecting MUTE from the front panel will disable the mute function on the handset. To restore normal operation, select an operating mode.