



EPSON

dreamio™

Home Projector EMP-TW2000

User's Guide



HDMI™
HIGH DEFINITION MULTIMEDIA INTERFACE

About the Manuals and Notations Used

Types of Manual

The documentation for your EPSON projector is divided into the following two manuals. Refer to the manuals in the order given below.

① Safety Instructions/Support and Service Guide

This manual contains information on using the projector safely, and also includes a guide for warranty service, and a troubleshooting check sheet.








Be sure to read this manual thoroughly before using the projector.

② User's Guide (this manual)

This User's Guide contains information on installing the projector, basic operations, using the configuration menus, troubleshooting and maintenance.

Notations used in this User's Guide

General information

	Indicates procedures where personal injury or damage to the projector may occur if the procedures are not followed correctly.
	Indicates additional information and points which may be useful to know regarding a topic.
	Indicates a page where useful information regarding a topic can be found.
	Indicates that an explanation of the underlined word or words in front of this symbol appears in the glossary of terms. Refer to the "Glossary" in the "Appendix".  p.53
 ,  etc.	Indicates buttons on the remote control or projector's control panel.
" (Menu Name) "	Indicates configuration menu items. Example: "Image"-"Color Mode"
[(Name)]	Indicates the port name of the projector. Example: [Video]


Meaning of "unit" and "projector"

When "unit" or "projector" appears in the text of this *User's Guide*, they may refer to items which are accessories or optional equipment in addition to the main projector unit itself.


Checking the Components

When you unpack the projector, make sure that you have all these components.


If any of the components are missing or incorrect, please contact the place of purchase.



☐ **Projector (with lens cover)**



☐ **Remote control**




☐ **Power cable (3.0m)**
Connect to the projector and to a wall outlet.



☐ **AA alkali batteries (2 pcs.)**
Insert into the remote control.

Documentation



☐ **Document CD-ROM**
(Safety Instructions/Support and Service Guide, User's Guide)

☐ **Quick Start Guide**

* Some regions may have paper manuals instead of a CD-ROM, or may not have the Quick Start Guide.

■ Features of the Projector	4	Remote control	7
■ Part Names and Functions	6	Rear.....	8
Front / Top.....	6	Base	8
Control panel	6	■ Appearance	9

Installing the Projector

■ Setting up	10	■ Preparing the Remote Control	13
Adjusting the projection size.....	10	Inserting batteries into the remote control ..	13
■ Connecting Image Sources	12		

Basic Operations

■ Projecting Images	14	■ Adjusting the Projection Screen	16
Turning the power on and projecting images	14	Focus adjustment	16
		Fine adjustments to image size (Zoom adjustment)	16
		Projection image position adjustment (Lens shift)	16

Image Quality Adjustments

■ Basic Image Quality Adjustments	18	■ Examining Image Quality Further	23
Selecting the colour mode.....	18	Sharpness (Advanced) adjustment	23
Selecting the aspect	18	Auto Iris (automatic aperture) setting	23
■ Advanced Colour Adjustments	20	■ Viewing Images at a Preset Image Quality (Memory Function)	24
Skin tone adjustment.....	20	Saving, Loading and Erasing Memory	24
Absolute colour temperature adjustment....	20		
Gamma adjustment	20		
RGB adjustment (Offset, Gain)	22		
Hue, saturation, and brightness adjustment	22		

Configuration Menu

■ Configuration Menu Functions	26	"Settings" menu	33
Using the configuration menus.....	26	"Memory" menu	35
List of configuration menus	28	"Reset" menu.....	35
"Image" menu	30		
"Signal" menu	31		



Troubleshooting

■ Problem Solving	36
Reading the indicators	36
• When the (warning) indicator is lit or flashing	36
• When the (operation) indicator is lit or flashing	37

When the indicators provide no help	37
• Problems relating to images	38
• Problems when projection starts	43
• Problems with the remote control	43

Appendix


■ Maintenance	44
Cleaning	44
• Cleaning the air filter	44
• Cleaning the projector case	44
• Cleaning the lens	44
Consumable replacement periods	45
• Air filter replacement period	45
• Lamp replacement period	45
Replacing consumables	46
• Replacing the air filter	46
• Replacing the lamp	46
• Resetting the lamp operating time	46

■ Optional Accessories / Consumables	48
■ List of Supported Monitor Displays	49
• Component Video	49
• Composite Video/S-Video	49
• Computer image (analog RGB)	50
• Input signal from the [HDMI1] / [HDMI2] input port	50
■ Specifications	51
■ Glossary	53
■ Index	55

▶ Image appearance can be selected to match the projection environment (Color Mode)

The optimum images for the location can be projected simply by selecting the desired colour mode from the following seven preset modes.

If "Natural", "Cinema Night", "x.v.Color", "HD" or "Silver Screen" is selected, the Epson Cinema Filter effect is applied automatically to increase the contrast and to make skin tones appear with more natural tints. 📖 p.18



▶ "x.v.Color" mode realizes more natural colour reproduction

This mode is compatible with the extended-gamut colour space standard for video (xvYCC).




Extended-gamut colour images output by equipment supporting this standard are more faithful to the original, and the viewer can enjoy clearer, more natural images. 📖 p.18

▶ Sophisticated colour adjustment

In addition to the "Color Mode", the absolute colour temperature and skin tones can be adjusted by simple procedures to render the picture even more to your own liking. Further, you can adjust gamma, the offset and gain for RGB colours, and the hue, saturation, and brightness of RGBCMY colours, to create colours that match the image. 📖 p.20

▶ Equipped with a wide-angle lens shift function

The lens shift function allows the position of the projected images to be adjusted vertically and horizontally without distorting the images. This can allow the projector to be set up with greater freedom, even if it is suspended from a ceiling or at an angle to the screen. 📖 p.16



▶ Equipped with 2.1x short throw zoom lens

For zoom adjustment, 2.1x short throw zoom lens is provided. Images can be projected onto an 100" screen (16:9 screen only) even at a distance of approximately 3 m (10 ft.). 📖 p.10

▶ Advanced image quality adjustment functions

Advanced image quality adjustment functions such as "Auto Iris" and "Sharpness (Advanced)" can be used to enjoy even sharper images. With the Auto Iris function turned on, the amount of light can be automatically adjusted to match the images being projected, to create images with depth and perspective. The Sharpness function is used to adjust not only the entire image, but also to emphasize specific regions, such as hair and clothing.


📖 p.23

▶ A variety of image setting functions

Some of the other many functions that are available are as follows.


- EPSON Super White is used to prevent overexposure that can result in images that are too bright. 📖 p.32
- A progressive▶ conversion that lets you obtain ideal results both for images with large amounts of movement and for still images. 📖 p.32
- An aspect▶ function that allows images to be viewed in wide-screen format. 📖 p.18
- Memory functions that allow adjustment results to be stored and later retrieved easily using the remote control. 📖 p.24
- Lock settings that can be used to lock the projector's control panel after adjustments have been made so that they cannot be changed by mistake, or to prevent children from accidentally turning on the power and looking into the lens. 📖 p.33

Front / Top




Control panel











Buttons with no explanation function in the same way as the corresponding buttons on the remote control. Refer to "Remote control" for further details on these buttons.




Remote control






Rear


- [Component] input port**  p.12
 Connects to the component (YCbCr or YPbPr) out port of the video equipment.
- [PC] input port**  p.12
 Connects to the RGB out port of the computer.
- [HDMI1] input port**  p.12
 Connects to video equipment or a computer that is HDMI-compatible.
- [HDMI2] input port**  p.12
 Connects to video equipment or a computer that is HDMI-compatible.
- Remote control light-receiving area**  p.13
 Receives signals from the remote control.
- Security lock**  p.54
- [RS-232C] port**
 Connects the projector to a computer using an RS-232C cable. This port is for control use and should not be used by the customer.
- Main power switch**  p.14
- Power inlet**  p.14
 Connects the power cable.
- [Video] input port**  p.12
 Connects to general video out ports of the video equipment.
- [S-Video] input port**  p.12
 Connects to the S-Video out ports of the video equipment.
- [Trigger out] port**
 When the projector power is turned on, a 12 V DC signal is output from this port. When the projector's power is turned off or a problem with operation occurs, the output becomes 0 V to send the projector's power ON/OFF status to an external device.

Base

- Suspension bracket fixing points (4 points)**  p.48
 Install the optional ceiling mount here when suspending the projector from a ceiling.




- Lamp cover**  p.46
 Open this cover when replacing the lamp inside.
- Air filter (air intake vent)**  p.44, 46
 Prevents dust and other foreign particles from being drawn into the projector. It should be cleaned periodically.



*1 Distance from centre of lens to suspension bracket fixing point
(Lens shift amount: Max. 8.8 mm vertically)


*2 Distance from centre of lens to centre of projector
(Lens shift amount: Max. 7.7 mm horizontally)



Units:mm

Adjusting the projection size

The size of the projected image is basically determined by the distance from the projector's lens to the screen.



The height from the centre of the lens to the bottom of the screen will vary depending on the lens shift setting.

While referring to the table below, position the projector so that the images are projected onto the screen at the optimum size.


The values should be used as a guide for setting up the projector.

Units: cm (in.)

16:9 screen size		Projection distance		Offset (A) to Offset (B)
		Shortest (Wide)	Longest (Tele)	
30"	66×37 (26×15)	87 to 188 (34 to 74)		17 to -17 (6.8 to -6.8)
40"	89×50 (35×20)	117 to 252 (46 to 99)		23 to -23 (9.1 to -9.1)
60"	130×75 (51×28)	177 to 380 (70 to 150)		35 to -35 (13.6 to -13.6)
80"	180×100 (71×39)	238 to 508 (94 to 200)		46 to -46 (18.2 to -18.2)
100"	220×120 (87×47)	298 to 636 (117 to 250)		58 to -58 (22.7 to -22.7)
120"	270×150 (106×59)	359 to 764 (141 to 301)		69 to -69 (27.2 to -27.2)
150"	330×190 (130×75)	450 to 956 (177 to 376)		86 to -86 (34.0 to -34.0)


Units: cm (in.)

4:3 screen size		Projection distance		Offset (A) to Offset (B)
		Shortest (Wide)	Longest (Tele)	
30"	61×46 (24×18)	106 to 230 (42 to 91)		21 to -21 (8.3 to -8.3)
40"	81×61 (32×24)	143 to 309 (56 to 121)		28 to -28 (11.1 to -11.1)
60"	120×90 (47×35)	217 to 465 (85 to 183)		42 to -42 (16.7 to -16.7)
80"	160×120 (63×47)	291 to 622 (115 to 245)		56 to -56 (22.2 to -22.2)
100"	200×150 (79×59)	365 to 778 (144 to 306)		71 to -71 (27.8 to -27.8)
120"	240×180 (94×71)	439 to 935 (173 to 368)		85 to -85 (33.3 to -33.3)
150"	300×230 (118×91)	550 to 1170 (217 to 461)		106 to -106 (41.7 to -41.7)



If the projector is placed at an angle to the screen, then the projected image will be distorted.

Lens shift adjustment

The lens shift dials can be used to position the image and is especially useful when using the projector in the following locations.  p.16

- Hanging from the ceiling
- A screen in a high location
- Projector situated to the side so that the screen can be viewed sitting right in front of it
- Projector situated on a shelf, etc.


When positioning an image using the lens shift dial, hardly any deterioration of the image occurs because the lens shift correction is adjusted optically. However, for optimal image quality the lens shift function should not be used.

Projection methods


CAUTION

- Avoid setting the projector up in a place which is very dusty or humid, or where there will be cigarette or other smoke, especially oily smoke.
- Clean the air filter at least once every 3 months.
Clean the air filter more frequently if using the projector in a dusty environment.
- A special method of installation is required when suspending the projector from the ceiling (ceiling mount). If it is not installed correctly, it could fall causing an accident and injury.
- If you use adhesives on the ceiling mount to prevent the screws from loosening, or if you use things such as lubricants or oils on the projector, the projector case may crack causing it to fall from its ceiling mount. This could cause serious injury to anyone under the ceiling mount and could damage the projector.
When installing or adjusting the ceiling mount, do not use adhesives to prevent the screws from loosening and do not use oils or lubricants and so on.
- Do not use the projector on its side. This may cause malfunctions to occur.


■ When projecting from directly in front




■ When projecting from the side of the screen




■ When projecting from a ceiling



* Even if projection will be from the screen side, set up the screen and projector so that they are parallel.

* When suspending the projector from a ceiling, change the configuration menu settings.  p.34


Configuration menu



CAUTION


- Turn the power off for both the projector and the signal source before connecting them. If the power for either device is on at the time of connection, damage may result.
- Check the shapes of the cable connectors and the device ports before making the connections. If you try to force a connector to fit a device port with a different shape or number of terminals, a malfunction or damage to the connector or port may result.

Video equipment (VHS VCR, DVD player, game console, etc.)



*Port names may vary depending on the equipment being connected.

Computer



TIP


- Some signal sources may have specially-shaped ports. In such cases, use the accessory or optional cables that are supplied with the signal source to make the connections.
- The cable that should be used to connect video equipment to the projector will depend on the type of video signal that the equipment outputs. Some kinds of video equipment output several different types of video signal. The image quality ranking of the video signal types is generally held to be as follows, in descending order of quality: Digital component video » [HDMI] » Analog component video [Component] » S-Video » [S-Video] » Composite video » [Video]
You should refer to the documentation provided with the video equipment being used to check what types of video signal formats the equipment can output. The composite video format is sometimes simply called "video output".

Inserting batteries into the remote control

The remote control is not supplied with batteries already inserted. Insert the accessory batteries before using the remote control.


1 Remove the battery cover.

While pressing the knob, lift up.



3 Install the battery cover.


- ① Insert the tab.
- ② Press down until the battery cover clicks into place.



2 Insert the batteries.

CAUTION

Check the (+) and (-) indications inside the battery compartment and insert the batteries so that they face correctly.




TIP


If delays in the responsiveness of the remote control occur or if it does not operate after it has been used for some time, it probably means that the batteries are becoming flat. If this happens, replace the batteries with two new batteries. Use two new AA batteries as replacement batteries.

Using the remote control


■ Operating range (horizontal)



■ Operating range (vertical)




Turning the power on and projecting images



If there is a problem with projection even though the projector is set up and connected correctly, refer to [p.15, 36](#).



TIP

- If you set the "Direct Power On" to "On", the power of the unit will turn ON when the main power switch is turned ON, without having to press the power button of the remote control or the projector's control panel.
- The projector is equipped with a "Child Lock" function that prevents young children from accidentally turning the power on and looking into the lens, and also an "Operation Lock" function that prevents mis-operations. [p.33](#)
- When using above an altitude of about 1500 m, make sure you set the "High Altitude Mode" to "On". [p.34](#)
- This projector is equipped with an automatic adjustment function that automatically optimizes it when a computer input signal is switched.
- If a laptop computer or a computer with a LCD screen has been connected to the projector, you may need to use keyboard or function settings to change the output destination. While holding down the **Fn** key, press **F0** (the key with a symbol such as  on it). After the selection is made, projection will soon start.
[Computer documentation](#)


Example of output selection

NEC	
Panasonic	Fn + F3
SOTEC	
HP	Fn + F4
Toshiba	Fn + F5
IBM	
LENOVO	Fn + F7
SONY	
DELL	Fn + F8
Fujitsu	Fn + F10
Macintosh	Set mirror setting or display detection. Depending on OS, you can change the output selection by pressing F7 .

When the expected images are not projected



If more than one signal source has been connected, or if no images are projected, use the remote control or the projector's control panel buttons to select the signal source. For video devices, press the [Play] button on the video equipment first, then select the signal source.




Using the remote control




Press the button that has the name of the port on it that the desired signal source is connected to.

Using the control panel










When you press , the menu is displayed. Each press of  moves the pointer. Move the pointer to the target input source to select it. Press  to accept. The input source is automatically changed if no operations are performed for about 3 seconds with the pointer at the target input source.



When the colour of the image projected from the [Component] input port is unnatural, select an appropriate signal according to the signal from the device connected at "Input Signal" in the Configuration menu.  p.34

Turning the power off



- 1 Turn the power off for the signal sources that are connected to the projector.
- 2 Press  on the remote control or  on the projector's control panel. If you press  on the projector's control panel, the following message will be displayed. Press  again to continue.
- 3 When the projector has cooled down  (takes about 16 seconds), turn off the main power switch.
Simply pressing  or  does not stop electricity consumption.
- 4 Attach the lens cover.

Power OFF?

Yes: Press [Power] button
No : Press any other button



Focus adjustment

Turn the focus ring to adjust the focus.



Fine adjustments to image size (Zoom adjustment)

Turn the zoom ring to adjust the size of the projected image.





Projection image position adjustment (Lens shift)

The lens shift function can be used to move the image display position vertically and horizontally within the range shown in the figure on the right when you cannot set up this projector directly in front of the screen, or when the image is projected too low or too high.

When you turn the lens shift dial and hear a click, the lens position is almost centred.

The image display position cannot be moved to the maximum positions in both the vertical and horizontal positions.

Ex) The image cannot be shifted vertically when it has been shifted horizontally by the full amount. When the image has been shifted vertically by the full amount, it can be shifted up to 9% of the horizontal width of the screen.




Standard projection position
(centre position for lens shift)


Range that the picture can be shifted
from the standard projection position

CAUTION

When transporting the projector, make sure to turn the lens position down by the full amount. Otherwise the lens shift mechanism may be damaged.


Correcting projector tilt


If the projected images are tilted horizontally () , use the front adjustable feet to adjust the projector so that it is horizontal.



Displaying a test pattern


You can project a test pattern at times such as when setting up the projector in order to perform zoom and focus adjustments without having to connect video equipment.

If  on the remote control is pressed, the test pattern appears.



To stop displaying the test pattern, press  again.

Selecting the colour mode



[Color Mode]

◆ Vivid ◆
 Cinema Day
 Natural
 Cinema Night
 HD
 Silver Screen

Press **Color Mode** and select the colour mode from the menu. Setting is also possible using the configuration menu.

[Color Mode]

◆ Vivid ◆
 Cinema Day
 Natural
 Cinema Night
 HD
 Silver Screen
 x.v.Color

Inputting a signal to the HDMI1/HDMI2 terminals.

Selecting the aspect

[Aspect]

◆ Auto ◆
 Normal
 Full
 Zoom
 Wide

Press **Aspect** and select the aspect mode from the menu.

Select Menu Operations

Press **▲** or **▼** on the remote control or **▲** or **▼** on the projector's control panel to select an item.

Press **Enter** or **Select** to confirm the selection.

*If you press **Esc**, the Select menu disappears.



TIP









If you project an image that is compressed, enlarged or separated using the aspect function in public places such as a store or hotel for the purposes of profit-making or public display, it may result in infringing on the author's right that is protected by copyright law.

When projecting using **Auto**


- For 4:3 input signals → Normal
- For input images recorded in squeeze mode → Full
- For letterbox input signals → Zoom
- Not usable during computer input. Not compatible with certain component video signals.
- If Auto is not suitable, the setting will become Normal.

Vivid	: Ideal for using in bright rooms.	HD/Silver Screen	: Suitable for use in a completely darkened room.
Cinema Day	: Ideal for using in rooms in which the curtains are closed.	HD	A clear tone of colour one might see in professional monitors used when creating DVD software.
Natural	: Ideal for using in dark rooms. It is recommended that you start in this mode when making colour adjustments.	Silver Screen	A deep warm tone of colour that gives you the feeling of enjoying a movie at the theatre.
Cinema Night	: Ideal for using in dark rooms.	x.v.Color	: You can select from either of the signals being input to the HDMI1 and HDMI2 terminals. Suitable for reproducing colours much more naturally.


When you select the colour mode indicated with , the Epson Cinema Filter will be applied automatically to increase the contrast and makes skin tones more natural.

Input signal	<ul style="list-style-type: none"> ● Normal TV broadcasts ● Images with standard aspect ratio (4:3) ● Computer images 	Images recorded by a video camera or DVD software in squeeze mode	Letterbox images	<ul style="list-style-type: none"> ● Normal TV broadcasts ● Images with standard aspect ratio (4:3)
Recommended aspect mode	Normal	Full	Zoom	Wide
Result	 <p>Black bands will appear at the left and right of the images.</p>	 <p>Input signals will be projected at the same width as the projector's panel resolution.</p>	 <p>Input signals will be projected at the same height as the projector's panel resolution.</p>	 <p>Input signals will be projected at the same height as the projector's panel resolution. At this time, the image enlargement ratio will be smaller near the middle of the images but become larger towards the left and right edges of the images.</p>
Remarks	 <p>When HDTV images are projected, the images appear in 16:9 size.</p>	 <p>When 4:3 images are projected, the images will be elongated horizontally.</p>	<ul style="list-style-type: none"> ● When a 4:3 image is projected, the top and bottom of the image are hidden from view. If this happens, the part of the image hidden from view at the top and bottom can be reduced in size in the vertical direction so that it can be viewed by "Zoom Size" in the Configuration menu.  p.31 ● When images with subtitles are projected and the subtitles are truncated, use the "Zoom Caption Pos." menu command to adjust.  p.31 	<p>This is useful for when 4:3 images are projected onto a wide screen. Because there is almost no distortion due to enlargement in the middle of the images, the images appear close to what they would be at their original size. And because both ends of the images are enlarged, movement at the edges of the images appears faster and gives an impression of greater speed, making it ideal for viewing sporting events.</p>

If you would like to create your own images with settings adjusted the way you want them, you can adjust "Abs. Color Temp.", "Skin Tone" and/or "Advanced" in the "Image" menu.

The adjustment values can be stored in the memory so that you can retrieve them and apply them to the projected images at any time. ( p.24)

"Skin Tone", "Abs.Color Temp." and "Gamma" are adjusted in a single operation using the respective remote control buttons.



Skin tone adjustment



Absolute colour temperature adjustment









Gamma adjustment



Adjustment is not possible when "Color Mode" is set to "x.v. Color".

Differences between equipment may result in a slight variation in the colouring when images are projected, and you may want to adjust this. (Projection will stop temporarily during such adjustment.) There are two methods of doing so. One is to select one of the gamma correction values [2.0], [2.1], [2.2], [2.3], [2.4]. The other is customized adjustment, which is done with reference to the projected image or a gamma graph. The gamma graph's horizontal axis represents the input signal level and its vertical axis the output signal level.

■ Adjusting from the gamma correction values

From among the gamma correction values [2.0], [2.1], [2.2], [2.3], [2.4], select one that suits the connected equipment, or one of your own liking, using   or  , and press  or  to confirm the selection.

Observe the gamma graph to check the result of the adjustment.

Lower values will increase the contrast of the dark portions but will tend to blur the bright portions. This is indicated by bulging in the upper portion in the gamma graph.

Higher values will darken the bright portions. This is indicated by bulging in the lower portion in the gamma graph.

Adjustment is not possible when "Color Mode" is set to "x.v. Color".

This can be used to adjust the skin tones for images of people.







The Epson Cinema Filter effect that is automatically applied to images when a "Color Mode" setting is made creates natural-looking skin tones. If you would like to further enhance skin tones, use this "Skin Tone" setting to make the adjustment.

Adjustment is not possible when "Color Mode" is set to "x.v. Color".

You can adjust the overall tint of images.











If you select a higher value, images appear bluish, and if you select a lower value, images appear reddish. The absolute colour temperature can be set to one of 12 settings within the range of 5000K to 10000K.


■ Customized ("Adjust it from the image")








Use   or   to select first "Customized", then "Adjust it from the image". Press  or  to confirm the selection each time.

A gamma icon will appear in the projected image.









Use   or   to move the gamma icon to the place where you want to adjust the brightness, and press  or  to confirm the selection. The place selected and the regions of the same brightness will flash, and a gamma graph will appear. Press any of   or   again to reconfirm. A screen for adjusting the tone will appear.












Use   or   to make the adjustment, and press  or  to confirm it. Press  to go back and do it again.


■ Customized ("Adjust it from the graph")

Use   or   to select first "Customized", then "Adjust it from the graph". Press  or  to confirm the selection each time.

A gamma adjustment graph will appear.



Use   or   to select the point where you want to adjust the tone brightness, and press any of   or   to confirm the selection. A screen for adjusting the tone will appear.



Use   or   make the adjustment, and press  or  to confirm it.

RGB adjustment (Offset, Gain)

Adjustment is not possible when "Color Mode" is set to "x.v. Color".

The image brightness can be adjusted by adjusting the individual R (red), G (green) and B (blue) components of the dark areas (offset) and bright areas (gain).


■ Offset

If you would like dark areas to appear more clearly, change the setting to the + (right) side. If you change it to the – (left) side, the whole image will become sharper, but the contrast in dark areas will become poorer.

■ Gain

If you would like bright areas to appear more clearly, change the setting to the – (left) side. If you change it to the + (right) side, you will feel that the image is becoming brighter and closer to white, but the contrast in light areas will become poorer.

- 1 Press **Menu** and then select "Image" - "Advanced" - "RGB" in that order and confirm the selection.



- 2 Use **Up/Down** or **Left/Right** to select a menu item, and use **Left/Right** or **Up/Down** to make adjustments.

To return the adjustment results to their default settings, press **Memory**.

- 3 Press **Menu** to exit the menu.

Hue, saturation, and brightness adjustment

Adjustment is not possible when "Color Mode" is set to "x.v. Color".

The hue, saturation, and brightness for each of the red (R), green (G), blue (B), cyan (C), magenta (M) and yellow (Y) colour components can be adjusted.

■ Hue

Adjusts the tone of the entire image to bluish, greenish and reddish.


■ Saturation

Adjusts the overall vividness of the images.


■ Brightness

Adjusts the brightness of the overall image.

- 1 Press **Menu** and then select "Image" - "Advanced" - "RGBCMY" in that order and confirm the selection.



- 2 Press **Up/Down** or **Left/Right** to select a colour and press **Select** or **Enter** to confirm. Select either hue, saturation, or brightness and use **Left/Right** or **Up/Down** to adjust.



To adjust another colour, press **Esc**.

To return the adjustment results to their default settings, press **Memory**.

- 3 Press **Menu** to exit the menu.

In addition to colour adjustments, adjustments to advanced sharpness and the amount of light from the lamp can also be made to match the image in search of the best picture.

Sharpness (Advanced) adjustment


This cannot be adjusted during input of computer image signals.

If "High-band Enhancement" is set in the + direction, hair and the detailed areas of clothing will be emphasized.

If "Low-band Enhancement" is set in the + direction, the areas emphasized by "High-band Enhancement" will be hardly emphasized. Instead, the rough areas of the entire subject, such as contour and background, will be emphasized, resulting in a sharp image.

Setting "Horiz. Line Enhancement" / "Vert. Line Enhancement" to the + side will enhance the image sharpness in the horizontal / vertical direction. Setting them to the - side will give a soft image.

- 1 Press **Menu**, and then select "Image" - "Sharpness". Select "Advanced" at the top-right corner of the screen to confirm the selection.



- 2 Use **Up/Down** or **Left/Right** to select a menu item, and use **Left/Right** or **Up/Down** to make adjustments. You can adjust "High-band Enhancement" and "Low-band Enhancement" at the same time by using the bar on the top in the screen. To return the adjustment results to their default settings, press **Memory**.

- 3 Press **Menu** to exit the menu.


Auto Iris (automatic aperture) setting

Setting is not possible when "Color Mode" is set to "x.v. Color."

When "Auto Iris" is set to "On", the amount of light will be automatically adjusted to the brightness of the image, creating a picture with depth and perspective.

* An operation sound of Auto Iris function may be emitted while projecting some images. This is not a failure of the projector.


- 1 Press **Menu**, and then select "Image" - "Auto Iris".



- 2 Select "On".
- 3 Press **Menu** to exit the menu.


After menu commands such as "Image" has been used to adjust the projected images, the adjustment values can then be saved (Save Memory).

In addition, the saved data can be retrieved easily, so that you can enjoy viewing images with the adjusted settings at any time (Load Memory).




The adjustments that can be saved to memory are as follows.

Up to ten adjustments can be saved to memory.




■ Displayed for input sources other than computer

Saving, Loading and Erasing Memory




Save Memory

- 1 Adjust each of the settings to the values to be saved.
- 2 Press **Memory**, and select "Save Memory".
The Save Memory screen is displayed.



- 3 Select the memory name to register the adjustments to from ISFDayR to Custom2, and press **Select** or **Enter**.

When  preceding the memory name is green, this indicates that adjustments are already saved to memory.

Select an already saved memory name, and press **Select** or **Enter**.

A confirmation message will be displayed.

If you select "Yes", the previous memory content is erased, and the current adjustment values are saved.

Load Memory

Load saved memories.

- 1 Press **Memory**, and select "Load Memory".
The Load Memory screen will be displayed.
- 2 Select the target memory name.



TIP

- The colour mode selected when the memory was registered is displayed on the right side.
- Memory settings that have been applied to images will be retained even when the projector's power is turned off. The same memory adjustment settings will be applied to images that are projected the next time the projector's power is turned on.
- The aspect \gg setting retrieved from memory may not be applied to the images if they are 16:9 images or if the input signal images have a particular resolution.

■ Erase Memory

This feature can be used to erase and clean up unwanted memories.

- 1 Press **Memory**, and select "Erase Memory". The Erase Memory screen will be displayed.
- 2 Select the memory name to erase.
A confirmation message will be displayed. If you select "Yes", the memory will be erased. The contents of a locked memory cannot be deleted. Perform deletion once the lock has been released.


To erase all saved memories, select "Reset" - "Reset Memory" in the Configuration menu.
p.35

It is not possible to erase a locked memory by selecting "Reset" - "Reset Memory" in the Configuration menu.


■ Locking/Unlocking the Memory


Among the registered memories, the eight from ISFDayR to ISFNightX can be locked.

- 1 Press **Memory**, and select "Save Memory". The Save Memory screen will be displayed.



- 2 Select the name of the memory to be locked, press and hold the \odot button on the remote control for at least 7 seconds, and then, within 4 seconds, press **Memory** twice.

Once a memory has been locked,  is displayed to the left of the memory name, as shown below.



When a locked memory is called, "Image" cannot be adjusted.



TIP


To release the lock on a memory, select the name of the memory to release, press and hold the \odot button on the remote control for at least 7 seconds, and then, within 4 seconds, press **Memory** twice.

The configuration menus can be used to make a variety of adjustments and settings involving image quality and input signals.

The following two types of menu are available.

■ Full menu

All items in the configuration menu can be checked while the settings are being made.



■ Line menu

Some of the items in the "Image" menu in the Configuration menu can be adjusted.

This menu is useful for viewing the effects of adjustments in the images being projected while the adjustments are being made.



Navigation Bar

Refer to "Using the configuration menus" (p.26) for details on menu operations.




The Configuration menu can be used to change the colour pattern and display position of the menus.

"Settings" - "Display" - "Menu Position", "Menu Color"

Using the configuration menus

1 Displaying a menu

Full menu: Press **Menu**.



Line menu: Press **Select** or **Select**.





2 Selecting a menu item


Use **Select** or **Select** to select a menu item, then press **Select**.


3 Changing settings




Example:






Use  or  to adjust values.



 (green): Current setting value

Use  or  to select an item, then press .

If you press  when an item with  next to it is selected, the selection screen for that item will be displayed.















To return to a previous display, press .



















4 When setting is complete

Press .

List of configuration menus

When no image signals are being input, the "Image" menu and the "Signal" menu cannot be adjusted. Also, the items displayed in the "Image" menu, the "Signal" menu and the "Info" menu will vary depending on the type of image signals that are being projected.

		 Displayed for input sources other than computer	 * This is displayed in the line menu.
Image	Color Mode	 p.30	Vivid, Cinema Day, Natural, Cinema Night, HD, Silver Screen, x.v.Color ("x.v. Color" is displayed when a signal is being input through the HDMI1/HDMI2 input terminals.)
	Brightness	 p.30	*
	Contrast	 p.30	*
	Color Saturation	 p.30	*
	Tint	 p.30	*
	Sharpness	 p.30	*
	Abs. Color Temp.	 p.30	*
	Skin Tone	 p.30	*
	Advanced	 p.30	<ul style="list-style-type: none"> Standard Advanced Thin Line Enhancement, Thick Line Enhancement Vert. Line Enhancement, Horiz. Line Enhancement Gamma 2.0, 2.1, 2.2, 2.3, 2.4 Customized Adjust it from the image Adjust it from the graph Reset RGB Offset R, G, B Gain R, G, B RGBCMY R (Hue/Saturation/Brightness), G (Hue/Saturation/Brightness), B (Hue/Saturation/Brightness), C (Hue/Saturation/Brightness), M (Hue/Saturation/Brightness), Y (Hue/Saturation/Brightness)
	Brightness Control	 p.31	High, Low
	Auto Iris	 p.31	On, Off
	Reset	 p.31	Yes, No

		 Displayed for input sources other than computer	 Only displayed for Computer input (does not appear when signals from the [HDMI1]/[HDMI2] input port are being input)
Signal	Aspect	 p.31	Auto, Normal, Full, Zoom, Wide
	Zoom Size	 p.31	
	Zoom Caption Pos.	 p.31	
	Tracking	 p.31	
	Sync.	 p.31	
	Position	 p.31	
	Auto Setup	 p.31	On, Off
	Progressive	 p.32	Off, Video, Film/Auto
	Motion Detection	 p.32	
	Noise Reduction	 p.32	Off, NR1, NR2, NR3
	Output Scaling	 p.32	Auto, 100%, 98%, 96%, 94%, 92%
	Setup Level	 p.32	0%, 7.5%
	EPSON Super White	 p.32	On, Off
	HDMI Video Range	 p.33	Normal, Expanded
	2-2 Pull-down	 p.33	On, Off
	Reset	 p.33	Yes, No

This will be 100% when a 720p, 1080i, or 1080p signal is being input through the [HDMI1]/[HDMI2] input terminals.

Settings	Direct Power On	p.33	On, Off
	Sleep Mode	p.33	Off, 5min., 10min., 30min.
	Child Lock	p.33	On, Off
	Operation Lock	p.33	On, Off
	Trigger Out	p.34	On, Off
	High Altitude Mode	p.34	On, Off
	Projection	p.34	Front, Front/Ceiling, Rear, Rear/Ceiling
	Display	p.34	<div>Menu Position</div> <div>Top-left, Top-center, Top-right, Center-left, Center, Center-right, Bottom-left, Bottom-center, Bottom-right</div> <div>Menu Color</div> <div>Color 1, Color 2</div> <div>Messages</div> <div>On, Off</div> <div>Display Background</div> <div>Black, Blue, Logo</div> <div>Startup Screen</div> <div>On, Off</div>
	Input Signal	p.34	<div>Video Signal</div> <div>Auto, <u>NTSC</u>», NTSC4.43, <u>PAL</u>», M-PAL, N-PAL, PAL60, <u>SECAM</u>»</div> <div>Component</div> <div>Auto, <u>YCbCr</u>», <u>YPbPr</u>»</div>
	Language	p.35	日本語, English, Français, Deutsch, Italiano, Español, Português, 中文, 한국어, Nederlands, Dansk, Polski, Magyar, Český, Norsk, Svenska, Suomi, Русский, Ελληνικά, Türkçe
	Reset	p.35	Yes, No


 Only displayed for composite video/S-Video input
 Only displayed for component video/Computer input

 Only displayed for Computer input

Info	Lamp Hours	<ul style="list-style-type: none"> The message text will be displayed in yellow when it is time to replace the lamp. Time from 0H to 10H will be displayed as 0H. From 10H onwards, the display will be in units of 1H.
	Source	
	Input Signal	
	Resolution	
	Scan Mode	
	Refresh Rate »	
	Sync Info	
	Video Signal	The "Info" menu is only used to display the projector status.
	Deep Color	Display the color depth of HDMI transmission.
	Status	This is information about errors that have occurred on the projector. This value is sometimes referred to when inquiries are made.

Memory	Load Memory	p.35	ISFDayR to Custom2
	Save Memory	p.35	ISFDayR to Custom2
	Erase Memory	p.35	ISFDayR to Custom2
Reset	Reset All	p.35	
	Reset Memory	p.35	
	Reset Lamp Hours	p.35	

"Image" menu

 Displayed for input sources other than computer

Color Mode ^{*1}

Seven different settings can be selected for the Color Mode, to match the images being projected or the projection environment.  p.18

Brightness ^{*2}

Adjustment is not possible when "Color Mode" is set to "x.v. Color".
Adjust this when the output level of the connected equipment is weak and you feel that images are dark.

Contrast ^{*2}

Adjustment is not possible when "Color Mode" is set to "x.v. Color".
Adjusts the difference between bright and dark areas.
When the contrast is increased, images with greater modulation are obtained.

Color Saturation ^{*2}

Adjustment is not possible when "Color Mode" is set to "x.v. Color".
This adjusts the colour intensity for the images.

Tint ^{*2}

(Adjustment is only possible when composite video^{**} and S-Video^{**} signals in NTSC^{**} format are being input. Adjustment is not possible, however, when "Color Mode" is set to "x.v. Color.")
This adjusts the image tint.


Sharpness ^{*2}

This adjusts the image sharpness.


Standard

The adjustment results are applied to the entire image.


Advanced

This can be used to adjust a specific region.  p.23

Abs. Color Temp. ^{*2}

Adjustment is not possible when "Color Mode" is set to "x.v. Color".
This adjusts the overall tints of the images.  p.20


Skin Tone ^{*2}

Adjustment is not possible when "Color Mode" is set to "x.v. Color".
This adjusts the skin tones of people who appear in the images.  p.20

Advanced

Adjustment is not possible when "Color Mode" is set to "x.v. Color".


Gamma ^{*1}

This adjusts gamma. You can select a value, or make adjustments while viewing an image or a graph.
 p.20

RGB ^{*1}

This lets you adjust the offset and gain for each of the R/G/B colour components.  p.22

RGBCMY ^{*1}

This lets you adjust the hue, saturation, and brightness for each of the R/G/B/C/M/Y colour components.
 p.22

^{*1} The setting values are stored separately for each image source and signal type.

^{*2} The setting values are stored separately for each image source and colour mode setting.

☐ Only displayed for Computer input
(does not appear when signals from the [HDMI1] / [HDMI2] input port are being input)


Brightness Control ^{*2}

This lets you set the lamp brightness to one of two settings.

Select "Low" if the images being projected are too bright such as when projecting images in a dark room or onto a small screen. Use of "Low" prolongs the life of the lamp, and reduces the amount of power and noise produced by fan rotation during projection.

Auto Iris ^{*3}

Setting is not possible when "Color Mode" is set to "x.v. Color."


The amount of light is adjusted appropriately depending on images (On)/ or not adjusted (Off).  p.23

Reset

This returns all settings in the "Image" menu to their default settings.

"Signal" menu

Aspect ^{*1}

Selects the aspect mode.  p.18

Zoom Size ^{*1}

This can be set only when "Aspect" is set to "Zoom".

This function enables the image to be reduced in size in the vertical direction so that the top and bottom of images that are hidden from view can be viewed when "Zoom" is set. The larger the adjustment value (reduction ratio) set here, the more the image is compressed and displayed squashed in the vertical direction.

Zoom Caption Pos. ^{*1}

This can be set only when "Aspect" is set to "Zoom".


This function moves the display position of the image in one direction, up or down, to display captions when projecting images with captions.

Tracking ^{*1}

This adjusts the images if vertical stripes appear in the images.





Sync. ^{*1}

This adjusts the images if flickering, fuzziness or interference appear in the images.

- Flickering and fuzziness may also occur when the brightness, contrast  and sharpness settings are adjusted.
- Clearer adjustments can be obtained if you adjust the "Tracking" first and then adjust the "Sync".

Position ^{*1}

(Setting is not possible when signals are being input from the [HDMI1] / [HDMI2] input port.)

When part of the image is clipped, move the image display position vertically and horizontally so that the entire image is projected. Press , ,  and  to adjust the position.


Auto Setup

This sets automatic adjustment to on or off in order to set whether the projector automatically adjusts images to their optimum condition when the input signal is changed. The three automatically adjusted items are "Tracking", "Position" and "Sync."

*1 The setting values are stored separately for each image source and signal type.

*2 The setting values are stored separately for each image source and colour mode setting.

*3 The setting values are stored separately for each colour mode setting.

 Displayed for input sources other than computer

Progressive^{*1}

(This can be set only when signals are being input from the [Video] / [S-Video] input port, or 480i, 576i, 1080i signals are being input from the [Component] / [HDMI1] / [HDMI2] input port.)

Interlace[»] (i) signals are converted to progressive (p) signals using a method appropriate for the image.

- Off :This is ideal for using when viewing images with a large amount of movement.
- Video :This is ideal for general video images.
- Film/Auto :Optimum conversion is performed for movie, computer graphics, and animation input signals.

Motion Detection^{*1}

(This can be set only when signals are being input from the [Video] / [S-Video] input port, or 480i, 576i, 1080i signals are being input from the [Component] / [HDMI1] / [HDMI2] input port.)

Select whether the progressive conversion operation mode is for fast-moving images or for slow-moving images. The smaller the value, the more suitable the mode is for viewing still images. The larger the value, the more suitable the mode is for viewing video images.

Noise Reduction^{*1}

This reduces flickering of images.


Three modes are available. Select the mode to suit your liking.

Set "Off" when the image source, such as DVD, contains little electrical interference.

Output Scaling^{*1}

(Setting is not possible when **composite video[»]**, **S-Video[»]**, or computer signals are being input.)

This changes the display area (the part of projected images).

- 100% - 92% :When 100% is set, the top and bottom of the image is sometimes affected by electrical interference depending on the image signal. In such cases, try to adjust the display position ("Position").  p.31
- Auto :Displayed when the signals from [HDMI1] / [HDMI2] input port are being input. Signals are automatically projected at 100% or 92% size depending on the input signals. (Not displayed when the equipment's DVI port is connected to the projector's [HDMI1] / [HDMI2] input port.)

Setup Level^{*1}


(This can be set when **NTSC[»]** signals are being input from the [Video] / [S-Video] input ports, or when component video signals are being input from the [Component] input port.)

If using products designed for destinations such as South Korea that have different black level (setup level) settings, use this function to obtain correct images. Check the specifications of the connected equipment when changing this setting.

EPSON Super White^{*1}

(Setting is only possible when Color Mode is "Natural", "Cinema Night", "HD", or "Silver Screen", and composite video, S-video, or component video signals are being input.)

If bright white areas of images such as clouds and T-shirts on the beach in summer appear uneven and overexposed, set to "On". When set to "On", the "HDMI Video Range" setting will be ignored.

 Displayed for input sources other than computer

HDMI Video Range^{*1}

(Setting is possible only when "EPSON Super White" is "Off". Setting is not possible, however, when "Color Mode" is set to "x.v. Color.")

When the [HDMI1] / [HDMI2] input port of the projector is connected to a DVD player, for example, set the video range of the projector to suit the video range setting of the DVD player. The setting at the DVD player can be either Normal or Expand.

2-2 Pull-down

(This setting can be made only when a 1080p/24Hz signal is being input to the [Component] or [HDMI1], [HDMI2] input terminals.)



For a 1080p/24Hz input signal, you can select between 2-2 pull-down projection or 2-3 pull-down projection. Selecting "On" sets the 2-2 pull-down.

Reset

All the adjustment values on the "Signal" menu, except "Aspect▶", are returned to their default values.

"Settings" menu


Direct Power On

When the main power switch is turned on, you can set for projection to start (On) / not start (Off) without pressing  or .




When set to "On" with the main power switch left on, be aware that sudden surges of electricity that may occur when the power comes back on after a power outage may cause the projector to turn on.

Sleep Mode

The projector is equipped with a power-saving function that causes the power to turn off automatically and the projector to switch to standby if no signal is input to the projector for a continuous length of time. The length of time before the power-saving function operates can be selected from four available settings. If "Off" is selected, the power-saving function will not operate.

If you press  while the projector is in standby mode, projection will start again.



Child Lock

This locks the power on function of the  button on the projector's control panel, so that a child cannot accidentally turn the projector's power on and look into the projector's lens. When the lock is applied, the power will only turn on if  is pressed down for about 3 seconds.  can be used to turn off the power, and the remote control will continue to operate as normal.

If you change the setting, the new setting will take effect after the power has been turned off and the cool-down period is complete.

Even if "Child Lock" is set to "On", be aware that projection starts merely by turning the main power switch on when "Direct Power On" is set to "On".

Operation Lock

If this is set to "On", you can't operate the projector's control panel buttons and a  icon appears on the screen when a button is pressed. To cancel, press and hold  on the projector's control panel for about seven seconds or more.

If you change the setting, the new setting will take effect after exiting the configuration menu.

*1 The setting values are stored separately for each image source and signal type.

Trigger Out

This turns the trigger function on and off to determine whether the projector's power on/off status and problems with projector operation are communicated to an external device.

If you change the setting, the new setting will take effect after the power has been turned off and the cool-down period is complete.

High Altitude Mode

A fan is set at a certain speed of rotation so as to bring down internal temperature.

When using above an altitude of about 1500m, set to "On".

Projection

This should be set in accordance with the method used to set up the projector.

- Front : Select when the projector is set up in front of the screen.
- Front/Ceiling : Select when the projector is set up in front of the screen and suspended from a ceiling.
- Rear : Select when the projector is set up behind the screen.
- Rear/Ceiling : Select when the projector is set up behind the screen and suspended from a ceiling.

Display

Menu Position

Press , ,  and  to specify the position for the menus to be displayed.

Menu Color

Selects the color for the main configuration menu.

- Color 1:Black
- Color 2:Blue

Messages

This sets whether the following message displays appear (On) or don't appear (Off).

- Image signal, colour mode, aspect and item name when memory settings are retrieved.
- Messages such as when no image signals are being input, when an incompatible signal is input, and when the internal temperature rises.

Display Background

Displays a menu for selecting the screen status for when using the blank function or when no image signal is input.

Startup Screen

This sets whether the start-up screen (the image that is projected when projection starts) is displayed (On) or not displayed (Off).

If you change the setting, the new setting will take effect after the power has been turned off and the cool-down period is complete.

Input Signal

Video Signal

Sets the signal format in accordance with the video equipment that is connected to the [Video] or [S-Video] input port. If set to "Auto", the video signal format is set automatically.

If there is a lot of interference in the image, or if a problem such as no image being projected occurs even though "Auto" has been selected, select the correct signal format manually.

Component

Change this setting depending on the type of signal that is being output from the video equipment that is connected to the [Component] input port.

If "Auto" is selected, appropriate signal is automatically set. If colours appear unnatural even though "Auto" is selected, select appropriate signal name in the menu.

Language


This sets the display language for messages and menus.

Reset

Adjustment values for the "Settings" menu functions are returned to their default settings, except for the "High Altitude Mode", "Projection", "Component", and "Language".

"Memory" menu

Load Memory

This retrieves settings previously saved using "Save Memory".  p.24

This cannot be selected when nothing is saved at "Save Memory".

Save Memory

This can be used to save "Image" menu settings.  p.24

Erase Memory

This is used to erase unwanted saved memory.  p.24


"Reset" menu

Reset All

This resets all configuration menu settings to their default settings. "Component" and "Language" in the "Settings" menu, and the settings of "Memory" menu are not returned to their default even if "Reset All" is executed.

Reset Memory

This resets (erases) all settings that have been made using the "Save Memory".

A locked memory cannot be initialized.  p.25

Reset Lamp Hours


Clear the cumulative lamp operating time and reset to "0H". Perform this procedure when you replace the lamp.

Reading the indicators

The projector is provided with the following two indicators which notify you of the operating status of the projector.

The following tables show what the indicators mean and how to remedy the problems that they indicate.

* If all indicators are switched off, check that the power cable is connected correctly and that the main power switch is on.




When the ⚠ (warning) indicator is lit or flashing

warning/problem








● : Lit ⚡ : Flashing

<p>Red</p> <p>⚠ ⚡</p> <p>(Lit/off for 1 sec)</p>	<p>Internal problem / Fan problem / Sensor problem / Cinema filter problem / Auto iris problem</p> <div> <p>CAUTION</p> <p>Disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the <i>Support and Service Guide</i>. Epson Projector Contact List</p> </div>
<p>Red</p> <p>⚠ ⚡</p> <p>(Lit/off for 0.5 sec)</p>	<p>Lamp problem / Lamp on error / Lamp cover open error</p> <p>Check if the lamp is broken. p.46 Clean the air filter. p.44</p> <div> <p>If the lamp is not broken</p> <p>Replace the lamp and then turn the power on.</p> <p>If the problem is still not solved after the lamp is replaced, stop using the projector and disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the <i>Support and Service Guide</i>. Epson Projector Contact List</p> </div> <div> <p>If the lamp is broken</p> <p>Contact your local dealer or the nearest address provided in the <i>Epson Projector Contact List</i>.</p> </div>
<p>Red</p> <p>⚠ ⚡ ●</p>	<p>High internal temperature (overheating)</p> <p>The lamp will switch off automatically and projection will stop. Wait for approximately 5 minutes. When the cooling fan stops, turn off the main power switch at the rear of the projector.</p> <div> <p>If the projector is installed against a wall, leave a space of 20 cm or more between it and the wall.</p> <p>Clean the air filters if they are blocked. p.44</p> </div> <p>If the problem is not solved when the power is turned back on, stop using the projector, turn off the main power switch, and disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the <i>Support and Service Guide</i>. Epson Projector Contact List</p>
<p>Orange</p> <p>⚠ ⚡</p>	<p>High-speed cooling in progress</p> <p>You can continue using the projector, but if the temperature rises again, it will switch off automatically.</p>

When the (operation) indicator is lit or flashing **normal**

When the  (warning) indicator is off

● : Lit  : Flashing

<div>Orange</div> <div> ●</div>	Standby condition If you press  , projection will start after a brief interval.
<div>Green</div> <div> </div>	Warm-up in progress Warm-up time is approximately 30 seconds. Power off operations are ignored while warm-up is in progress.
<div>Green</div> <div> ●</div>	Projection in progress Normal operation is in progress.
<div>Orange</div> <div> </div>	Cool-down[▶] in progress Cool-down time is approximately 16 seconds. After cool-down is complete, the projector goes to standby mode. You cannot use the remote control or the projector's control panel during cool-down. If the main power switch at the rear of the projector is turned off before cool-down is complete, wait for the lamp to cool down (normally about one hour is required) before turning the power back on again.

When the indicators provide no help

If any of the following problems occur and the indicators do not offer a solution, refer to the pages given for each problem.

Problems relating to images

● No images appear p.38

Projection does not start, the projection area is completely black, the projection area is completely blue, etc.

● Moving images are not displayed p.38

Moving images played on computer are not displayed.

● The message "Not Supported" is displayed p.39

● The message "No Signal" is displayed p.39

● Images are fuzzy or out of focus p.39

● Interference or distortion appear in images p.40

Problems such as interference, distortion or black & white checked patterns appear.

● Image is truncated (large) or small p.40

Only part of the image is displayed.

● Image colours are not right p.41

The whole image appears purplish or greenish, images are black & white, colours appear dull, etc.

(Computer monitors and LCD screens have different colour reproduction performance, so that the colours projected by the projector and the colours appearing on the monitor may not necessarily match, but this is not a sign of a problem.)

● Images appear dark p.41

● Projection stops automatically p.42

Problems when projection starts











● Power does not turn on p.43

Problems with the remote control


● The remote control does not work p.43

Problems relating to images

■ No images appear

Have you pressed the [Power] button?	Press  on the remote control or  on the projector's control panel.
Is the main power switch turned off?	Turn on the main power switch at the rear of the projector.
Are all of the indicators switched off?	Disconnect the power cable and then reconnect it.  p.14 Check the circuit breaker to see if power is being supplied.
Is blank mode active?	Press  on the remote control to cancel the blank function.
Is a video signal being input?	Check that the power for the connected equipment is turned on. If the "Messages" menu command has been set to "On", messages relating to the image signals will be displayed.  "Settings" - "Display" - "Messages" p.34
Are the image signal format settings correct?	<p>If a <u>composite video</u>  or <u>S-Video</u>  signal is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source.  "Settings" - "Input Signal" - "Video Signal" p.34</p> <p>If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment.  "Settings" - "Input Signal" - "Component" p.34</p>
Have the configuration menu settings been made correctly?	Try resetting all of the current settings.  p.35
Were the projector and computer connected while their power was already turned on?	If the connection is made while the power is already turned on, the function [Fn] key that switches the computer's video signal to external output may not work. Turn the power for the computer that is connected to the projector off and then back on again.
<div>When a computer is connected</div>	






■ Moving images are not displayed

Is the computer image signal set to output simultaneously both externally and to the LCD monitor?	Set the image signal to output only externally.  Computer documentation, under a title such as "External output" or "Connecting an external monitor"
<div>Only when projecting images from a laptop computer or computer with a built-in LCD screen</div>	

■ The message "Not Supported" is displayed

Are the image signal format settings correct?	<p>If a <u>composite video</u> or <u>S-Video</u> is being input</p> <p>If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source.</p> <p>☞ "Settings" - "Input Signal" - "Video Signal" p.34</p>
Does the mode match the frequency and resolution of the image signals? <div style="background-color: black; color: white; padding: 5px; margin-top: 10px;"> Only when projecting computer images </div>	<p>If the signal source is connected to the [Component] input port</p> <p>If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. ☞ "Settings" - "Input Signal" - "Component" p.34</p>
	<p>Use the "Resolution" menu command to check the signals being input, and check the "List of Supported Monitor Displays" to make sure that the signals are compatible.</p> <p>☞ "Info" - "Resolution" p.29</p> <p>☞ "List of Supported Monitor Displays" p.49</p>

■ The message "No Signal" is displayed

Are the cables connected correctly?	<p>Check that all of the cables required for projection are securely connected. ☞ p.12</p>
Has the correct video input port been selected?	<p>Press , ,  or  on the remote control or  on the projector's control panel to change the image source. ☞ p.15</p>
Is the power for the connected equipment turned on?	<p>Turn the power on for the devices.</p>
Are the image signals being output to the projector? <div style="background-color: black; color: white; padding: 5px; margin-top: 10px;"> Only when projecting images from a laptop computer or computer with a built-in LCD screen </div>	<p>If the image signals are only being output to the computer's LCD monitor, you need to change the output.</p> <p>For some computer models, when the image signals are output externally, they no longer appear on the LCD monitor.</p> <p>☞ Computer documentation, under a title such as "External output" or "Connecting an external monitor"</p> <p>If the connection is made while the power is already turned on, the function [Fn] key that switches the computer's video signal to external output may not work. Turn the power for the projector and the computer off and then back on again. ☞ p.14</p>

■ Images are fuzzy or out of focus


Has the focus been adjusted correctly?	<p>Adjust the focus. ☞ p.16</p>
Is the lens cover still attached?	<p>Remove the lens cover.</p>
Is the projector at the correct distance?	<p>The recommended distance from the projector to the screen is within 87 to 956 cm (2.8 to 31.4 ft.) for a screen size of 16:9, and 106 to 1170 cm (3.5 to 38.4 ft.) for a screen size of 4:3. Set up the projector so that the projection distance is within this range. ☞ p.10</p>

Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room approximately one hour before it is to be used. If condensation forms on the lens, turn the power off and wait for the condensation to disappear.
---	--

■ Interference or distortion appear in images

Are the image signal format settings correct?	<p>If a <u>composite video</u> or <u>S-Video</u> is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source. ☞ "Settings" - "Input Signal" - "Video Signal" p.34</p> <p>If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. ☞ "Settings" - "Input Signal" - "Component" p.34</p>
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. ☞ p.12
Is an extension cable being used?	If an extension cable is used, interference may increase. Try connecting a signal amplifier.
Have the "Sync." and "Tracking" settings been adjusted correctly?	<p>The projector has an automatic adjustment function that causes the optimum images to be projected. However, for some types of signal, the correct adjustments may not be obtained even after automatic adjustment is carried out. In such cases, use the "Tracking" and "Sync." menu commands to make the adjustments. ☞ "Signal" - "Tracking", "Sync." p.31</p>
Has the correct resolution been selected?	<p>Set the computer so that the signals that are output are compatible with this projector. ☞ "List of Supported Monitor Displays" p.49 Computer documentation</p>

■ Image is truncated (large) or small

Has the correct <u>aspect</u> been selected?	<p>Press  to select the aspect that corresponds to the input signal. ☞ p.18</p> <p>If images with subtitles are being projected using "Zoom", use the "Zoom Caption Pos." menu command to adjust the images. ☞ p.31</p>
Has the "Position" setting been adjusted correctly?	<p>Use the "Position" the menu command to make the adjustment. ☞ "Signal" - "Position" p.31</p>
Has the computer been set for dual display?	<p>If dual display has been activated in the Display Properties of the computer's Control Panel, the projector will only project about half of the image on the computer screen. To display the whole of the image on the computer screen, turn off the dual display setting. ☞ Computer video driver documentation</p>

Has the correct resolution been selected? <div>Only when projecting computer images</div>	Set the computer so that the signals that are output are compatible with this projector. ☞ "List of Supported Monitor Displays" p.49 Computer documentation
---	---




■ Image colours are not right

Are the image signal format settings correct?	If a <u>composite video</u> or <u>S-Video</u> is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source. ☞ "Settings" - "Input Signal" - "Video Signal" p.34
	If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. ☞ "Settings" - "Input Signal" - "Component" p.34
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. ☞ p.12
Has the image <u>contrast</u> been adjusted correctly?	Use the "Contrast" menu command to adjust the color. ☞ "Image" - "Contrast" p.30
Has color been adjusted appropriately?	Use the "Advanced" menu command to adjust the colour. ☞ "Image" - "Advanced" p.30
Have the colour intensity and tint been adjusted correctly? <div>Only when projecting images from a video source</div>	Use the "Color Saturation" and "Tint" menu commands to adjust the colour and tint. ☞ "Image" - "Color Saturation", "Tint" p.30

■ Images appear dark










Has the image brightness been adjusted correctly?	Use the "Brightness" menu commands to make the adjustments. ☞ "Image" - "Brightness" p.30
Has the image contrast been adjusted correctly?	Use the "Contrast" menu command to adjust the color. ☞ "Image" - "Contrast" p.30
Is the lamp due for replacement?	When the lamp is nearly due for replacement, the images will become darker and the colour quality will become poorer. When this happens, the lamp should be replaced with a new one. ☞ p.46

■ Projection stops automatically

Is sleep mode active?	<p>When "Sleep Mode" has been set to On, the lamp turns off automatically if no signal is input for about 30 minutes, and the projector switches to standby mode. Press the  button on the remote control or the  button on the projector's control panel to turn the projector's power back on. To cancel the sleep mode setting, change "Sleep Mode" menu command to "Off".</p> <p> "Settings" - "Sleep Mode" p.33</p>
------------------------------	---




Problems when projection starts

■ Power does not turn on

Have you pressed the [Power] button?	Press  on the remote control or  on the projector's control panel.
Is "Child Lock" set to "On"?	If the "Child Lock" menu command is set to "On", press  on the projector's control panel for about 3 seconds or press  on the remote control to turn the power on.  "Settings" - "Child Lock" p.33
Is "Operation Lock" set to "On"?	If the "Operation Lock" menu command is set to "On", all buttons on the projector's control panel are disabled. Press  on the remote control.  "Settings" - "Operation Lock" p.33
Are all of the indicators switched off?	Disconnect the power cable and then reconnect it.  p.14 Check the circuit breaker to see if power is being supplied.
Do the indicators turn off and on when the power cable is touched?	Turn the power off, disconnect the power cable and then reconnect it. If this does not solve the problem, there may be a problem with the power cable. Then contact your local dealer or the nearest address provided in the <i>Support and Service Guide</i> .  <i>Epson Projector Contact List</i>

Problems with the remote control

■ The remote control does not work

Is the remote control light-emitting area facing towards the remote control light-receiving area when it is operated?	Face the remote control towards the remote control light-receiving area. The operating angle for the remote control is approximately $\pm 30^\circ$ horizontally and approximately $\pm 30^\circ$ vertically.  p.13
Is the remote control too far from the projector?	The operating range for the remote control is approximately 10m.  p.13
Is direct sunlight or strong light from fluorescent lamps shining onto the remote control light-receiving area?	Set the projector up in a location where strong light will not shine onto the remote control light-receiving area.
Are the batteries dead, or have the batteries been inserted correctly?	Insert new batteries, while making sure that they face correctly.  p.13

This section describes maintenance tasks such as cleaning the projector and replacing consumable parts.


Cleaning

You should clean the projector if it becomes dirty or if the quality of projected images starts to deteriorate.


CAUTION Be sure to read the separate *Safety Instructions/Support and Service Guide* for details on safe handling of the projector during cleaning.

Cleaning the air filter

If the air filter becomes blocked with dust and the message "The projector is overheating. Make sure nothing is blocking the air vent, and clean or replace the air filter" is displayed, clean the air filter.

Turn the projector upside-down and use a vacuum cleaner to clean the air filter  p.8


CAUTION If the air filter becomes clogged with dust, it can result in overheating which may cause operating problems or reduce the operating life of the optical parts. It is recommended that you clean the air filter about once every three month. If using the projector in a dusty location, the air filter should be cleaned more often.



Cleaning the projector case

Clean the projector case by wiping it gently with a soft cloth. If the projector is particularly dirty, moisten the cloth with water containing a small amount of neutral detergent, and then firmly wring the cloth dry before using it to wipe the projector case. Then wipe the case again with a soft, dry cloth.


CAUTION Do not use volatile substances such as wax, alcohol or thinner to clean the projector case. These can cause the case to warp and make the coating finish peel off.



Cleaning the lens

To clean the lens it is preferable to use an air blower purchased for the purpose. But alternatively you can wipe it gently clean with a spectacle-cleaning cloth.

CAUTION Do not rub the lens with harsh materials or subject the lens to shocks, as it can easily become damaged.




Consumable replacement periods

Air filter replacement period


- If the air filter has been broken or the "Replace" message is displayed even though the air filter has been cleaned.

Replace with an optional air filter.

 Replacing the air filter p.46

Lamp replacement period

- The message "Replace the lamp." appears on the screen when projection starts.



A message will be displayed.

- The projected images get darker or start to deteriorate.



- The replacement warning message is set to appear after a minimum of about 2400 hours of lamp use in order to maintain the initial brightness and quality of the projected images. The time taken for the message to appear will vary depending on usage conditions such as Color Mode settings. If you continue to use the lamp after this period, the possibility of the lamp breaking becomes greater. When the lamp replacement message appears, replace the lamp with a new one as soon as possible, even if it is still working.
- Depending on the characteristics of the lamp and on the way it has been used, the lamp may become darker or stop working before the lamp warning message appears. You should always have a spare lamp ready in case it is needed.
- Contact your local dealer or the nearest address provided in the *Epson Projector Contact List*.



Replacing consumables

Replacing the air filter



TIP

Dispose of used air filters properly in accordance with your local regulations.
Air Filter:
Polypropylene

- 1 Press  or  to turn the power off, wait until the projector cools down, and then turn off the main power switch.

- 2 Remove the air filter cover.





Put your finger under the latch and pull it upward.

Replacing the lamp


CAUTION

If the lamp stops working and needs to be replaced, there is the danger that the lamp may already be broken. If replacing the lamp of a projector which has been installed to the ceiling, you should always assume that the lamp is broken and handle it with extreme care during removal. Furthermore, you should stand to the side of the projector, not underneath it.


- 1 Press  or  to turn the power off, wait until the projector cools down, and then turn off the main power switch.

* Wait until the lamp cools down (takes approximately 1 hour).


- 2 Remove the lamp cover.



- 6 Securely tighten the lamp fixing screws.




- 7 Install the lamp cover.




Resetting the lamp operating time

The lamp operating time must always be reset after the lamp has been replaced with a new one.


The projector has a built-in counter which keeps track of the lamp operating time. When the cumulative operating time reaches a certain point, it causes the replacement warning message to be displayed.

- 1 Press  to turn on the power.


- 2 Press  to display the configuration menu.




- 3** Remove the old air filter.




- 4** Insert the new air filter.




- 5** Install the air filter cover.



- 3** Loosen the lamp fixing screws.




- 4** Remove the old lamp.



Pull out straight.

- 5** Insert the new lamp.




Make sure that it faces the correct way.


CAUTION

- Install the lamp and the lamp cover securely. The lamp will not turn on if the lamp or the lamp cover is not installed correctly.
- This product includes a lamp component that contains mercury (Hg). Please consult your local regulations regarding disposal or recycling. Do not dispose of it with normal waste.

- 3** Select "Reset Lamp Hours" from the "Reset" menu.



- 4** Select "Yes" and then press .




The following optional accessories / consumables are available for purchase if required. This list of optional accessories and consumables is current as of November, 2007. Details of accessories are subject to change without notice.

Varies depending on country of purchase.

■ Optional Accessories

50" Portable Screen ELPSC06

A compact screen which can be carried easily.
(Aspect  4:3)

60" Portable Screen	ELPSC07
80" Portable Screen	ELPSC08
100" Portable Screen	ELPSC10

A portable roll-type screen. (Aspect 4:3)

VGA-HD15 PC Cable (1.8 m)	ELPKC02
VGA-HD15 PC Cable (3 m)	ELPKC09
VGA-HD15 PC Cable (20 m)	ELPKC10

(For mini D-Sub 15-pin/mini D-Sub 15-pin)
Use to connect the projector to a computer.

Ceiling Mount* ELPMB20

(with ceiling plate)
Use when installing the projector to a ceiling.

Celling Pipe 600 (600 mm/white)* ELPFP07

Use when installing the projector to a high ceiling or a ceiling with veneer panels.

* A special method of installation is required in order to suspend the projector from the ceiling. Please contact the place of purchase if you would like to use this installation method.

■ Consumables

Lamp Unit ELPLP39

(1 spare lamp, 1 spare screwdriver)
Use as a replacement for spent lamps.

Air Filter Set ELPAF09

(1 air filter)
Use as a replacement for old air filters.

Depending on the setting, the output screen resolution will change slightly.

Component Video

4:3 16:9 : Aspect Units: Dots

Signal	Resolution	Aspect mode			
		Normal	Full	Zoom	Wide
SDTV(480i, 60Hz)	720×480 720×360 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9
SDTV(576i, 50Hz)	720×576 720×432 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9
SDTV(480p)	720×480 720×360 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9
SDTV(576p)	720×576 720×432 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9
HDTV(720p) 16:9	1280×720	1920×1080 16:9	-	-	-
HDTV(1080i) 16:9	1920×1080	1920×1080 16:9	-	-	-
HDTV(1080p) 16:9	1920×1080	1920×1080 16:9	-	-	-

*Letterbox signal

Composite Video/S-Video

4:3 16:9 : Aspect Units: Dots

Signal	Resolution	Aspect mode			
		Normal	Full	Zoom	Wide
TV(NTSC)	720×480 720×360 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9
TV(PAL, SECAM)	720×576 720×432 *	1440×1080 4:3	1920×1080 16:9	1920×1080 16:9	1920×1080 16:9

*Letterbox signal

Computer image (analog RGB)

Units: Dots

Signal	Resolution	Aspect mode			
		Normal	Full	Zoom	Wide
<u>VGA</u> 60	640×480 640×360 *2	1440×1080	1920×1080	1920×1080	1920×1080
VESA72/75/85, iMac *1	640×480 640×360 *2	1440×1080	1920×1080	1920×1080	1920×1080
<u>SVGA</u> 56/60/72/ 75/85, iMac *1	800×600 800×450 *2	1440×1080	1920×1080	1920×1080	1920×1080
<u>XGA</u> 60/70/75/ 85, iMac *1	1024×768 1024×576 *2	1440×1080	1920×1080	1920×1080	1920×1080
WXGA60-1	1280×768	1800×1080	1920×1080	1920×1080	-
WXGA60-2	1360×768	1912×1080	1920×1080	1920×1080	-
<u>SXGA</u> 60	1280×1024	1350×1080	1920×1080	1920×1080	-
	1280×960	1440×1080			1920×1080
MAC13"	640×480	1440×1080	1920×1080	1920×1080	1920×1080
MAC16"	832×624	1440×1080	1920×1080	1920×1080	1920×1080
MAC19"	1024×768	1440×1080	1920×1080	1920×1080	1920×1080

*1 Connection is not possible if the equipment does not have a VGA output port.

*2 Letterbox signal

It may be possible to project signals which are not listed in the above table. However, some functions may be limited in that case.

Input signal from the [HDMI1] / [HDMI2] input port

Units: Dots

Signal	Resolution	Aspect mode			
		Normal	Full	Zoom	Wide
<u>VGA</u> 60	640×480 640×360 *2	1440×1080	1920×1080	1920×1080	1920×1080
<u>SDTV</u> (480i, 60Hz)	720×480 720×360 *2	1440×1080	1920×1080	1920×1080	1920×1080
SDTV(480p)	720×480 720×360 *2	1440×1080	1920×1080	1920×1080	1920×1080
SDTV(576i, 50Hz)	720×576 720×432 *2	1440×1080	1920×1080	1920×1080	1920×1080
SDTV(576p)	720×576 720×432 *2	1440×1080	1920×1080	1920×1080	1920×1080
<u>HDTV</u> (720p)	1280×720	1920×1080	-	-	-
HDTV(1080i)	1920×1080	1920×1080	-	-	-
HDTV(1080p)	1920×1080	1920×1080	-	-	-

*1 Connection is not possible if the equipment does not have a VGA output port.

*2 Letterbox signal

It may be possible to project signals which are not listed in the above table. However, some functions may be limited in that case.

Product name	Home Projector EMP-TW2000		
Dimensions	406 (W) × 124 (H) × 310 (D) mm (not including feet)		
Panel size	0.74 inch wide		
Display method	Polysilicon TFT active matrix		
Resolution	2,073,600 pixels (1920 (W) × 1080 (H) dots) × 3		
Scanning frequencies	Analogue	Pixel clock : 13.5 to 150 MHz	
		Horizontal : 15 to 80 kHz	
		Vertical : 24, 50 to 85 Hz	
	Digital	Pixel clock : 13.5 to 150 MHz	
		Horizontal : 15 to 80 kHz	
		Vertical : 24, 50 to 85 Hz	
Focus adjustment	Manual		
Zoom adjustment	Manual (approx. 1 : 2.1)		
Lens shift	Manual (Maximums: Approx. 96% vertically, 47% horizontally)		
Lamp (light source)	UHE lamp, 170 W, Model No.: ELPLP39		
Power supply	100 to 240V AC 50/60Hz 2.7 to 1.2A Power Consumption Operating: 245W(100 to 120V area), 240W(220 to 240V area) Standby: 4.0W(100 to 120V area), 5.0W(220 to 240V area)		
Operating altitude	0 to 2286m (0 to 7500ft.)		
Operating temperature	+5 to +35°C (No condensation)		
Storage temperature	-10 to +60°C (No condensation)		
Mass	Approx. 5.6kg		
Ports	Component input	1	RCA pin jack × 3
	PC input	1	Mini D-sub 15-pin (female) blue
	HDMI1 ^{▶▶} input	1	HDMI
	HDMI2 input	1	HDMI
	Video input	1	RCA pin jack
	S-Video input	1	Mini DIN 4-pin
	RS-232C	1	D-sub 9-pin (male)
	Trigger out	1	3.5 mm mini jack


Other detailed spec, please access your location (country/area) from Epson homepage, <http://www.epson.com>



Pixelworks DNXTM ICs are used in this Projector.

This product is also designed for IT power distribution system with phase-to-phase voltage 230V.

■ Angle of tilt




If you set the projector higher than 15°, it could damage the projector and cause an accident.



■ RS-232C cable layout

- Connector shape : D-Sub 9-pin (male)
- Projector input connector : RS-232C

<At projector>



<At computer>



<At projector> (PC serial cable) <At computer>

GND	5	—————	5	GND
RD	2	←————	3	TD
TD	3	————→	2	RD
DTR	4	————→	6	DSR
DSR	6	←————	4	DTR

Signal	Function
GND	Signal wire earth
TD	Transmit data
RD	Receive data
DSR	Data set ready
DTR	Data terminal ready

Following is an explanation of some of the terms used in this guide which may be unfamiliar or which were not explained in the manual itself. Further information can be obtained by referring to other commercially-available publications.

Aspect

The ratio between an image's length and its height. **HDTV** images have an aspect of 16:9 and appear elongated. The aspect for standard images is 4:3.

Component video

Video signals which have the video brightness signals and color signals separated, in order to provide better image quality.

In high-definition TV (HDTV), it refers to images which consist of three independent signals: Y (luminance signal), and Pb and Pr (color difference signals).

Composite video

Video signals which have the video brightness signals and color signals mixed together. The type of signals commonly used by household video equipment (**NTSC**, **PAL** and **SECAM** formats).

Video signals which consist of a carrier signal Y (luminance signal) within the color bar signal, and a chroma or color signal (CbCr).

Contrast

The relative brightness of the light and dark areas of an image can be increased or decreased in order to make text and graphics stand out more clearly, or to make them appear softer.

Cool-down

This is the process by which the projector's lamp is cooled down after it has become hot through use. It is carried out automatically when the [Power] button on either the remote control or the projector's control panel has been pressed to turn off the projector. Do not turn off the main power switch while cool-down is in progress, otherwise the cool-down process will not work properly. If the cool-down period is not allowed to finish normally, the projector's lamp and internal components will remain at high temperatures, and this may shorten the useful life of the lamp or cause problems with the operation of the projector. The projector takes about 16 seconds to cool down. The actual time will vary depending on the external air temperature.

HDMI

An abbreviation for High Definition Multimedia Interface, and refers to a standard for digital transmission of high-definition images and multi-channel audio signals.

HDMI is a standard that is targeted towards household digital equipment and computers that allows digital signals to be transmitted in their original high quality without compression, and it also includes a digital signal encryption function.

HDTV

An abbreviation for High-Definition Television. It refers to high-definition systems which satisfy the following conditions.

- Vertical resolution of 720p or 1080i or greater (p = **progressive**, i = **interlaced**)
- Screen aspect of 16:9
- Dolby Digital audio reception and playback (or output)

Interlace

A method of image scanning whereby the signal bandwidth used is approximately half that required for sequential scanning when images with the same still picture resolution are broadcast.

NTSC

An abbreviation for National Television Standards Committee, and a format for ground-based analogue colour television broadcasts. This format is used in Japan, North America and Central and South America.

PAL

An abbreviation for Phase Alternation by Line, and a format for ground-based analogue colour television broadcasts. This format is used in Western European countries except France, and also in Asian countries such as China and in Africa.

Progressive

A method of image scanning whereby the image data from a single image is scanned sequentially from top to bottom to create a single image.

Refresh rate

The light-emitting element of a display maintains the same luminosity and color for an extremely short time. Because of this, the image must be scanned many times per second in order to refresh the light emitting element. The number of refresh operations per second is called the "refresh rate", and is expressed in hertz (Hz).

S-Video

A video signal which has the luminance component and color component separated in order to provide better image quality.

It refers to images which consist of two independent signals: Y (luminance signal), and C (color signal).

SDTV

An abbreviation for Standard Definition Television. It refers to standard television systems which do not satisfy the conditions for HDTV.

SECAM

An abbreviation for Sequential Couleur A Memoire, and a format for ground-based analogue colour television broadcasts. This format is used in France, Eastern Europe and the former Soviet Union, the Middle East and Africa.

Security lock

A device consisting of a protector case with a hole in it that a commercially-available theft-prevention cable can be passed through in order to secure the device to a table or pillar. This projector is compatible with the Microsaver Security System manufactured by Kensington.

SVGA

A type of image signal with a resolution of 800 (horizontal) x 600 (vertical) dots which is used by IBM PC/ AT-compatible computers.

SXGA

A type of image signal with a resolution of 1280 (horizontal) x 1024 (vertical) dots which is used by IBM PC/ AT-compatible computers.

Sync. (Synchronization)

The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images will not be of a good quality. The process of matching the phases of these signals (the relative position of the crests and troughs in the signal) is called "synchronization". If the signals are not synchronized, problems such as flickering, blurriness and horizontal interference can occur.

Tracking

The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images will not be of a good quality. The process of matching the frequency of these signals (the number of crests in the signal) is called "tracking". If tracking is not carried out correctly, wide vertical stripes will appear in the projected images.

VGA

A type of image signal with a resolution of 640 (horizontal) x 480 (vertical) dots which is used by IBM PC/ AT-compatible computers.

XGA

A type of image signal with a resolution of 1,024 (horizontal) x 768 (vertical) dots which is used by IBM PC/ AT-compatible computers.

YCbCr

The carrier signal which is contained in the color bar signal used in modern TV transmissions. The name comes from the Y (luminance) signal and the CbCr (chroma [color]) signals.

YPbPr

The carrier signal which is contained in the color bar signal used in high-definition TV (**HDTV**) transmissions. The name comes from the Y (luminance) signal and the PbPr (color difference) signals.

- A**
- Absolute Color Temperature 20,28,30
 - Advanced 28,30
 - Air filter 8
 - Aspect 7,18,28,31,49
 - Auto 18
 - Auto Iris 23,28,31
 - Auto Setup 24,28,31
- B**
- Battery replacement period (Remote control) 13
 - Brightness 28,30
 - Brightness Control 28,31
- C**
- Ceiling 11,29,34
 - Child Lock 29,33
 - Cinema Filter 21
 - Cleaning the air filter 44
 - Cleaning the lens 44
 - Cleaning the projector case 44
 - Color Mode 7,18,28,30
 - Color Saturation 28,30
 - [Component] input port 8,12,15,51
 - Component Video 12,49
 - Composite Video 12,49
 - Configuration menu 26
 - Connecting to a computer 12
 - Connecting to a video source 12
 - Consumables 48
 - Contrast 7,28,30
 - Control panel 6
 - Cool-down 15,36
 - Correcting projector tilt 6,17
- D**
- Direct Power On 29,33
 - Display 29,34
 - Display Background 27,34
- E**
- Epson Cinema Filter 21
 - EPSON Super White 28,32
 - Erase Memory 29,35
- F**
- Focus adjustment 6,16
 - Front adjustable foot 6,17
 - Full 18
 - Full Menu 26
- G**
- Gain 22,28
 - Gamma 20,28,30
- H**
- HDTV 49
 - [HDMI] input port 8,12,50,51
 - HDMI-Video Range 28,33
 - High Altitude Mode 29,34
 - Hue, saturation, and brightness adjustment 22
- I**
- Image size 10
 - "Image" menu 28,30
 - Indicators 6,36
 - "Info" menu 29
 - Input Signal 29,34
- L**
- Lamp cover 8,46
 - Lamp Hours 29
 - Language 29,35
 - Lens cover 6,14
 - Lens shift 6,16
 - Line menu 26
 - Load Memory 24,29,35
- M**
- Main power switch 8,14,15
 - Memory 7,24
 - "Memory" Menu 29,35
 - Menu Color 29,34
 - Menu Position 29,34
 - Menus 26
 - Messages 29,34
 - Motion Detection 28,32
- N**
- Noise Reduction 28,32
 - Normal 19
- O**
- Offset 22,28
 - Operation indicator 6,36
 - Operation Lock 29,33
 - Optional accessories 48
 - Output Scaling 28,32
 - Overheating 36
- P**
- [PC] input port 8,12,51
 - Port 8,12,51
 - Position 28,31
 - Power cable 14
 - Power inlet 8,14
 - Progressive 28,32
 - Projection 11,29,34
 - Projection distance 10
 - Projection image position adjustment 16
 - Projection methods 11

R

Refresh Rate.....	29
Remote control.....	7,13
Replacing the air filter	46
Replacing the battery	13
Replacing the lamp	46
Reset.....	28,29,31,33,35
Reset All	29,35
"Reset" menu	29,35
Reset Lamp Hours	29,35,46
Reset Memory.....	29,35
Resolution	29,49
RGB	22,28,30
RGBCMY	22,28,30
[RS-232C] port	8,51,52

S

Save Memory	24,29,35
Screen size	10
SDTV	49
Selecting the image source	6,7,15
Setup Level	28,32
"Settings" menu	29,33
Sharpness	28,30
Sharpness (Advanced)	23,28,30
"Signal" menu	28,31
Skin Tone	7,20,28,30
Sleep Mode	29,33
Source	29
Specifications.....	51
Startup Screen.....	29,34
Sub-menu	26
Supported Monitor Displays	49
S-Video	12,49
[S-Video] input port.....	8,12,51
Sync Info.....	29
Sync.	28,31

T

Test Pattern.....	7,17
Tint.....	28,30
Top menu	26
Tracking	28,31
Trigger Out.....	29,34
[Trigger out] port	8,51
Turning off	15

U

Using the configuration menus	26
-------------------------------------	----

V

[Video] input port.....	8,12,51
Video Signal.....	29,34

W

Warning indicator	6,36
Wide.....	19

X

x.v.Color	4,18
-----------------	------

Y

YCbCr.....	12,29
YPbPr.....	12,29

Z

Zoom.....	19
Zoom adjustment	6,16
Zoom Caption Pos.	19,28,31
Zoom Size.....	28,31

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorised modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations and screens used in this publication may differ from actual illustrations and screens.

General Notice:

x.v.Color is a trademark of Sony Corporation.

Macintosh, Mac, and iMac are trademarks of Apple Inc.

IBM is a registered trademark of International Business Machines Corporation.

Windows, WindowsNT and PowerPoint are trademarks or registered trademarks of Microsoft Corporation in the United States.

Dolby is a trademark of Dolby Laboratories.

HDMI and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

Pixelworks and DNX are trademarks of Pixelworks, Inc.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.