

Thank you for purchasing this Esco Pharmacy Isolator. Please read this manual thoroughly to familiarize yourself with the many unique features and exciting innovations we have built into your new equipment. Esco provides many other resources at our website, www.escoglobal.com, to complement this manual and help you enjoy many years of productive and safe use of your Esco products.

For Technical Service, contact North America Esco Technologies, Inc. 2940 Turnpike Drive, Units 15-16 • Hatboro, PA 19040, USA Toll-Free USA and Canada 1-877-479-3726 Tel 215-441-9661 • Fax 215-441-9660 us.escoglobal.com • usa@escoglobal.com

Rest of World

Esco Micro Pte. Ltd. 21 Changi South Street 1 • Singapore 486 777 Tel +65 6542 0833 • Fax +65 6542 6920 www.escoglobal.com • mail@escoglobal.com

User Manual

Isoclean Pharmacy Isolators

Copyright Information

© Copyright 2011 Esco Micro Pte. Ltd. All rights reserved. The information contained in this manual and the accompanying product is copyrighted and all rights are reserved by Esco. Esco reserves the right to make periodic minor design changes without obligation to notify any person or entity of such change. Isoclean® and Sentinel® are registered trademarks of Esco.

"Material in this manual is provided for informational purposes only. The contents and the product described in this manual (including any appendix, addendum, attachment or inclusion), are subject to change without notice. Esco makes no representations or warranties as to the accuracy of the information contained in this manual. In no event shall Esco be held liable for any damages, direct or consequential, arising out of or related to the use of this manual."

Table of Contents

INTRODUCTORY PAGES

i	Table of Contents
iii	Warranty Terms and Conditions
v	Introduction
v	1. Products Covered
v	2. Safety Warning
v	3. Limitation of Liability
vi	4. European Union Directives on WEEE and RoHS
vii	Declaration of Conformity
	USER SECTION
1	Chapter 1 -Product Information
1	1.1 Quick View
1	1.1.1 Esco Pharmacy Compounding Aseptic Containment Isolator (HPI-N)
2	1.1.2 Esco Pharmacy Compounding Aseptic Isolator (HPI-P)
3	Chanton J. Control System
3	Chapter 2 -Control System
3	2.1 Sentinel Control System
	2.2 Menu Options
5	2.2.1 Settings
5	2.2.2 Setting Mode
5	2.2.3 Field Calibration
6	2.2.4 Admin Settings
7	2.3 Alarm and Warnings
8	2.4 Diagnostic Mode
9	Chapter 3 - Basic Isolator Operation
9	3.1 Starting and Shutting Down the Isolator
9	3.1.1 Turning on the Isolator
9	3.1.2 Turning off the Isolator
9	3.2 Working in the Isolator
9	3.3 Working Ergonomics
10	3.4 UV Lamps
11	Chapter 4 - Maintenance
11	4.1 Scheduled Maintenance
11	4.1 Scheduled Maintenance 4.2 Glove Changing Procedure
12	4.3 Sleeve Changing Procedure
12	4.5 Sherve Changing Procedure 4.4 Sharps Container Removal Procedure
13	4.5 Maintenance/Service Log
13	4.5 Maintenance/Service Log

APPENDIX

i

ii

Warranty Terms and Conditions

Esco products come with a limited warranty. The warranty period will vary depending on the product purchased, beginning on the date of shipment from any Esco international warehousing location. To determine which warranty applies to your product, refer to the appendix below.

Esco's limited warranty covers defects in materials and workmanship. Esco's liability under this limited warranty shall be, at our option, to repair or replace any defective parts of the equipment, provided if proven to the satisfaction of Esco that these parts were defective at the time of being sold, and that all defective parts shall be returned, properly identified with a Return Authorization.

This limited warranty covers parts only, and not transportation/insurance charges.

This limited warranty does not cover:

- Freight or installation (inside delivery handling) damage. If your product was damaged in transit, you must file a claim directly with the freight carrier.
- Products with missing or defaced serial numbers.
- Products for which Esco has not received payment.
- Problems that result from:
 - External causes such as accident, abuse, misuse, problems with electrical power, improper operating environmental conditions.
 - Servicing not authorized by Esco.
 - \circ ~ Usage that is not in accordance with product instructions.
 - \circ Failure to follow the product instructions.
 - Failure to perform preventive maintenance.
 - Problems caused by using accessories, parts, or components not supplied by Esco.
 - Damage by fire, floods, or acts of God.
 - $\circ \quad \mbox{Customer modifications to the product}$
- Consumables such as filters (HEPA, ULPA, carbon, pre-filters) and fluorescent / UV bulbs.
- Esco is not liable for any damage incurred on the objects used on or stored in Esco equipment. If the objects are highly valuable, user is advised to have in place independent external preventive measures such as connection to a centralized alarm system.

Factory installed, customer specified equipment or accessories are warranted only to the extent guaranteed by the original manufacturer. The customer agrees that in relation to these products purchased through Esco, our limited warranty shall not apply and the original manufacturer's warranty shall be the sole warranty in respect of these products. The customer shall utilize that warranty for the support of such products and in any event not look to Esco for such warranty support.

Esco encourages all users to register their equipment online at www.escoglobal.com/warranty or complete the warranty registration form included with each product.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN TIME TO THE TERM OF THIS LIMITED WARRANTY. NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE LIMITED WARRANTY PERIOD HAS EXPIRED. ESCO DOES NOT ACCEPT LIABILITY BEYOND THE REMEDIES PROVIDED FOR IN THIS LIMITED WARRANTY OR FOR SPECIAL, INDIRECT, CONSEQUENTIAL OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LIABILITY FOR THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES, FOR PRODUCTS NOT BEING AVAILABLE FOR USE, OR FOR LOST WORK. ESCO'S LIABILITY WILL BE NO MORE THAN THE AMOUNT YOU PAID FOR THE PRODUCT THAT IS THE SUBJECT OF A CLAIM. THIS IS THE MAXIMUM AMOUNT FOR WHICH ESCO IS RESPONSIBLE.

These Terms and Conditions shall be governed by and construed in accordance with the laws of Singapore and shall be subject to the exclusive jurisdiction of the courts of Singapore.

Technical Support, Warranty Service Contacts

USA: 1-877-479-3726 Singapore: +65 65420833 Global Email Helpdesk: support@escoglobal.com Visit http://www.escoglobal.com/ to talk to a Live Support Representative Distributors are encouraged to visit the Distributor Intranet for self-help materials.

Product Appendix, Warranty Listings

The warranty periods for BSC may vary by country. Contact			
your local distributor for specific warranty details.			
2 years limited.			
4 years limited for Ascent Opti, 6 years for Ascent Max.			
1 year limited.			
1 year limited.			
2 years limited.			
2 years limited.			
5 years limited. 60 months on Compressor.			

The warranty period starts two months from the date your equipment is shipped from Esco facility for international distributors. This allows shipping time so the warranty will go into effect at approximately the same time the equipment is delivered to the user. The warranty protection extends to any subsequent owner during the warranty period. Distributors who stock Esco equipment are allowed an additional four months for delivery and installation, providing the product is registered with Esco. User can register product online at www.escoglobal.com/warranty or complete the warranty registration form included with each product.

Policy updated on 1st December 2011 (This limited warranty policy applies to products purchased on or after 1st January 2012)

Introduction

1. Products Covered

Esco Isoclean Pharmacy Isolator						
Electrical Rating	1.2 meters (4 feet)	1.8 meters (6 feet)				
	HPI – 4N1 – 0	HPI – 6N1 – 0				
220-240 V AC, 50Hz, 1Φ	HPI – 4N1 – S	HPI – 6N1 – S				
220-240 V AC, 30Π2, 1Φ	HPI – 4P1 – 0	HPI – 6P1 – 0				
	HPI – 4P1 – S	HPI – 6P1 – S				
	HPI – 4N2 – 0	HPI – 6N2 – 0				
110-130 V AC, 60Hz, 1Φ	HPI – 4N2 – S	HPI – 6N2 – S				
110-150 V AC, δ0H2, 1Φ	HPI – 4P2 – 0	HPI – 6P2 – 0				
	HPI – 4P2 – S	HPI – 6P2 – S				
	HPI – 4N3 – 0	HPI – 6N3 – 0				
220 240 1/ 40 001- 10	HPI – 4N3 – S	HPI – 6N3 – S				
220-240 V AC, 60Hz, 1Φ	HPI – 4P3 – 0	HPI – 6P3 – 0				
	HPI – 4P3 – S	HPI – 6P3 – S				

Model with – 0 indicate that the isolator doesn't have sharps container

Model with – S indicate that the isolator have sharps container and the hole for the container in the work zone.

2. Safety Warning

- Anyone working with, on or around this equipment should read this manual. Failure to read, understand and follow the instructions given in this documentation may result in damage to the unit, injury to operating personnel, and / or poor equipment performance.
- Any internal adjustment, modification or maintenance to this equipment must be undertaken by qualified service personnel.
- The use of any hazardous materials in this equipment must be monitored by an industrial hygienist, safety officer or some other suitably qualified individual.
- Before you process, you should thoroughly understand the installation procedures and take note of the environmental / electrical requirements.
- In this manual, important safety related points will be marked with the symbol.



• If the equipment is used in a manner not specified by this manual, the protection provided by this equipment may be impaired.

3. Limitation of Liability

The disposal and / or emission of substances used in connection with this equipment may be governed by various local regulations. Familiarization and compliance with any such regulations are the sole responsibility of the users. Esco's liability is limited with respect to user compliance with such regulations.

4. European Union Directive on WEEE and RoHS

The European Union has issued two directives:

• Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE)

This product is required to comply with the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. It is marked with the following symbol:

Esco sells products through distributors throughout Europe. Contact your local Esco distributor for recycling/disposal.

• Directive 2002/95/EC on Restriction on the use of Hazardous Substances (RoHS)

With respect to the directive on RoHS, please note that this hood falls under category 8 (medical devices) and category 9 (monitoring and control instruments) and is therefore exempted from requirement to comply with the provisions of this directive.



Declaration of Conformation

In accordance to EN ISO/IEC 17050-1:2010

We, Esco Micro Pte. Ltd. of 21 Changi South Street 1 Singapore, 486777 Tel: +65 6542 0833 Fax: +65 6542 6920



declare on our sole responsibility that the product:

Category	: Pharmacy Compounding Aseptic Containment Isolator
Brand	: Isoclean
Model	: HPI – 4N1 – 0, HPI – 4N1 – S, HPI – 6N1 – 0, HPI – 6N1 – S

in accordance with the following directives:

2006/95/EEC	: The Low Voltage Directive and its amending directives
92/31/EEC	: The Electromagnetic Compatibility Directive and its amending
	directives

has been designed to comply with the requirement of the following Harmonized Standard:

Low Voltage	: EN 61010-1:2010
EMC	: EN 61326-1:2006 Class B

More information may be obtained from Esco's authorized distributors located within the European Union. A list of these parties and their contact information is available on request from Esco.

XQ Lin Group CEO, ESCO

This Declaration of Conformity is only applicable for 230V AC 50/60Hz units

CE

declare on our sole responsibility that the product:

Declaration of Conformation

In accordance to EN ISO/IEC 17050-1:2010

Esco Micro Pte. Ltd.

21 Changi South Street 1 Singapore, 486777 Tel: +65 6542 0833 Fax: +65 6542 6920

Category	: Pharmacy Compounding Aseptic Isolator
Brand	: Isoclean
Model	: HPI – 4P1 – 0, HPI – 4P1 – S, HPI – 6P1 – 0, HPI – 6P1 – S

in accordance with the following directives:

2006/95/EEC	: The Low Voltage Directive and its amending directives
92/31/EEC	: The Electromagnetic Compatibility Directive and its amending
	directives

has been designed to comply with the requirement of the following Harmonized Standard:

Low Voltage	: EN 61010-1:2010
EMC	: EN 61326-1:2006 Class B

More information may be obtained from Esco's authorized distributors located within the European Union. A list of these parties and their contact information is available on request from Esco.

XQ Lin Group CEO, ESCO

We,

of

This Declaration of Conformity is only applicable for 230V AC 50Hz units

1.1 Quick View

1.1.1 Esco Pharmacy Compounding Aseptic Containment Isolator (HPI-N)



- 1. Exhaust ULPA filter.
- 2. Front cover.
- 3. Esco Sentinel Gold microprocessor.
- 4. Pass-thru outer door
- 5. Stainless steel sliding tray.
- 6. Optional motorized support stand.
- 7. Casters.
- 8. Intake pre-filter and ULPA filter.
- 9. Glove ports.
- 10. Hinged access window with viewscreen.
- 11. Optional sharps / garbage disposal system for hazardous drugs.
- 12. Optional exhaust carbon filter.

1



1.1.2 Esco Pharmacy Compounding Aseptic Isolator (HPI-P)

- 1. Exhaust ULPA filter.
- 2. Front cover.
- 3. Esco Sentinel Gold microprocessor.
- 4. Transfer chamber outer door.
- 5. Stainless steel sliding tray.
- 6. Optional motorized support stand.
- 7. Castors.
- 8. Intake filter.
- 9. Oval glove ports.
- 10. Hinged access window with viewscreen.
- 11. Optional sharps / garbage disposal system.

2.1 Sentinel Control System



- 1. Fan Button
 - Turns on and turn off the fan.
- 2. Lamp Button
 - \circ \quad Turns on and turn off the fluorescent lamps.
- 3. Socket Button
 - Turns on and turn off the electrical socket (retrofit kit).
 - The maximum rating of all the outlets in the cabinet is 5 A. If overload, the fuse will blow.
- 4. UV Button
 - Turns on and turn off the UV lamp.
 - UV lamp can only be activated when the sash window is fully closed. Since the sash is capable of filtering UV rays, users are protected from the harmful UV radiation.
- 5. Up (\blacktriangle) and Down (\triangledown) Arrow Button
 - Move the menu options upwards and downwards.
 - o Increase and decrease corresponding value inside one of the menu options.
- 6. Set or Mute or Diagnostic Button
 - o Proceed to the next step, level or sequence inside the menu options.
 - o Enter diagnostic mode
- 7. Menu Button

When you are entering menu options, the alarm will sound to indicate that the microprocessor is not monitoring the operation of the isolator. No further warnings will be given.

- To enter and exit from the menu options.
- \circ \quad To go back to the previous level of the menu options.
- To access maintenance mode from error condition.

2.2 Menu Options

Please refer to the following diagram for complete reference to all menu options available.



2.2.1 Settings

Users may use the settings menu function to customize the operation of the isolator to meet specific application requirements. The settings menu can be entered using both FAN PIN and ADMIN PIN.

2.2.1.1 Set Clock (Time)

Users can set the time by increasing/decreasing the hour and minute values. The correct time will be maintained even after the unit is turned off.

	MENU	> [SETTINGS		SET TIME		HH:MM
--	------	---------------	----------	--	----------	--	-------

2.2.1.2 Warm Up Time

There will be a period of warm-up, before the fan is fully functioning. This is to ensure that the sensors, the blower, and the control system are stabilized, as well as purging the work zone of contaminants. The default setting is 3 minutes and the user can set it between 3 to 15 minutes.

MENU		SETTINGS	⊢	WARM UP TIME	├	XX MINUTES
-	-		J	-	J	

2.2.1.3 PostPurge Time

After the user switches off the isolator blower, there will be a post-purge period, to ensure that all contaminants are purged from the work zone. The default setting is zero minute (disable) and user can set it between 0 to 15 minutes. However, it is recommended to purge the isolator for around 3 minutes after the work is complete.

MENU	 SETTINGS	 POSTPURGE TIME	├ ──►	XX MINUTES
			-	

2.2.1.4 Inner Door Timeout

The inner door cannot be left open for more than a certain period. This period can be set in the inner door timeout option. The default timeout period is 30 seconds.

		/ENU	SETTINGS	}►	INNER DOOR TIMEOUT	►	XX SECONDS
--	--	------	----------	----	--------------------	---	------------

2.2.1.5 Measurement Unit

Using this option, the user can select the unit in which air velocity is measured and displayed. The user can choose between metric (m/s) and imperial (fpm).



2.2.2 Setting Mode

The isolator has three working mode. The menu can be entered using both FAN PIN and ADMIN PIN.



2.2.2.1 Normal Mode

The normal mode is activated by factory default. In this mode, all alarms and interlocks are enabled.

2.2.2.2 Advanced Mode

The advanced mode is used when the alarm is to be enabled. It is disabled by default and the alarm enabling can only be done at the factory. Please contact Esco if you want to enable the alarm.

2.2.2.3 Maintenance Mode

Maintenance mode should only be accessed by qualified personnel during maintenance. In this mode, all alarms are disabled and all interlocks are defeated.

2.2.3 Field Calibration

The purpose of calibration is to ensure the accuracy of the airflow display and alarm (if present). This involves measuring airflow with reference instrumentation and establishing reference between airflow sensor(s) on the isolator to the standard reference. Calibration should only be carried out by trained personnel. This section presents a brief overview of the calibration menu function. For more information, refer to test report.



2.2.3.1 Downflow Calibration

This option allows proper calibration and operation of the airflow sensor alarm.

2.2.3.2 Reset Calibration

This option allows the user to reset all value calibrated in the field and return it to the values gathered in factory calibration.

2.2.4 Admin Settings

The admin menu allows you to change both FAN and ADMIN PIN. The reset blower and UV hour meter functions are usually used after you change the blower or UV lamp as they can easily give you the indication on when to do isolator maintenance. While the reset default function will return the options in the settings menu to their factory settings.

2.2.4.1 New ADMIN PIN (default 0009)

ADMIN PIN restricts access to some of the more delicate menu functions, namely admin and field calibration, which should only be accessed by a qualified personnel. User must enter four digits ADMIN PIN before accessing these menus.

ADMIN PIN can also be used to switch to maintenance mode from error condition.

			-			
ME	NU	ADMIN SETTINGS	╞──►	NEW ADMIN PIN	►	XXXX

2.2.4.2 New FAN PIN (default 0000 - DISABLED)

FAN PIN restricts access to fan control and some parts of the menu, settings and set mode. User must enter four-digit PIN before switching fan on or off. As such, it can restrict access to operating the BSC by unauthorized personnel. It will also prevent unauthorized shutdown of the isolator when continuous operation is required. Note that continuous operation is recommended for better safety. Fan PIN is also needed to disable the alarm when the sash is fully raised and cleaning needs to be performed.

Setting the PIN to 0000 will disable this feature. The FAN PIN is disabled by default. When the FAN PIN is disabled, the isolator can be turned on and off without requiring PIN, however to access the menu, the user is still required to enter the FAN PIN (0000).

MENU	 ADMIN SETTINGS	┝	NEW FAN PIN	⊢	XXXX	

2.2.4.5 Reset B/H/M

This option is used to reset the blower hour meter. The blower hour meter indicates how long the blower has been in operation. There's no maximum value in blower hour meter. The counter value can be checked while in the diagnostic mode. The value can also provide some help in setting up maintenance schedule.

	•	•	• •	
MENU	→	ADMIN SETTINGS		RESET B/H/M

2.2.4.6 Reset UV/H/M

This option is used to reset the UV lamp hour meter. The UV lamp hour meter indicates how long the UV lamp has been in operation. Maximum counter is set at 2000 hours (100%). The counter value can be checked while in the diagnostic mode. Please reset the UV lamp hour meter after each UV lamp replacement.

		•		
MENU	}	ADMIN SETTINGS]►[RESET UV/H/M

2.2.4.8 Reset Default

User can reset the default setting by choosing this option. The features being reset are warm-up period (3 minutes), post-purge period (0 minute), measurement unit (Metric), ADMIN PIN (0009), Filter Life Display (disabled) and FAN PIN (0000).

Note that the calibration settings cannot be reset as it may cause the isolator to operate in an unsafe manner. The hour meters cannot be reset either.

MENU ADMIN SETTINGS RESET DEFAULT	MENU	►	ADMIN SETTINGS	►	RESET DEFAULT
-----------------------------------	------	---	----------------	---	---------------

2.2.4.10 Alarm Mute Duration

To mute airfail alarm for a certain period. The mute period can be set between 0 to 299 seconds, the default value is 30 seconds.

MENU ADMIN SETTINGS ALM MUTE DURATION XXX

2.3 Alarms and Warnings

Isolator uses alarms to indicate that the condition inside the Isolator is not safe for the operator, so check the LCD display to understand the cause of these alarms.

2.4 Diagnostic Mode

Diagnostic mode can be accessed by pressing the SET button. The diagnostic mode allows the user to know the condition of the isolator or help the service engineer during maintenance and troubleshooting.

On Screen	Explanation
MODE	Shows which mode is active: NORMAL or MAINTENANCE
VERSION	Shows the version of the software; eg: CP103C V 1.0
TEMPERATURE	Shows the temperature in the chamber
ADC TEMP	ADC for temperature in the chamber
B/H/M	Blower Hour Meter – increase by the hour
UV/H/M	UV Hour Meter – increase by the hour
MONITOR	Alarm monitor status
PREPURGING	Shows the pre purging (warm up) time value - in minutes
MUTE TIMER	Shows the mute timer value – in seconds
DOWNFLOWMIN	Downflow minimum value (calibrated)
DOWNFLOWNOM	Downflow nominal value (calibrated)
WZN	Nominal pressure value in work zone (calibrated)
PTN	Nominal pressure value in pass through chamber (calibrated)
WZIDO	Work zone inner door open pressure value (calibrated)
PTIDO	Pass through chamber inner door pressure value (calibrated)
CONSTANT	Sensor constant
ADC DFMIN	ADC for field calibrated minimum downflow
ADC DFNOM	ADC for field calibrated nominal downflow
ADC DF	ADC for actual downflow velocity reading
ADC DF0	ADC for calibrated zero point downflow
ADC DF1	ADC for minimum downflow
ADC DF2	ADC for nominal downflow
ADC WZONE	ADC actual pressure value in work zone
ADC WZ0	ADC zero point pressure value in work zone (calibrated)
ADC WZN	ADC nominal pressure value in work zone (calibrated)
ADC WZIDO	ADC inner door open pressure value in work zone (calibrated)
ADC PTHRU	ADC actual pressure value in pass through chamber
ADC PT0	ADC zero point pressure value in pass through chamber (calibrated)
ADC PTN	ADC nominal pressure value in pass through chamber (calibrated)
ADC PTIDO	ADC inner door open pressure value in pass through chamber (calibrated)
WZONE MAX	Maximum (limit) value of Pressure sensor on work zone chamber.
RQ.PRES.DF	Differential value between pressure sensor on main chamber and Pass-Through.

8

Chapter 3 – Basic Isolator Operation

3.1 Starting and Shutting Down the Isolator

3.1.1 Turning on the Isolator

- 1. Turn on the fan by pressing the FAN button. Input the Fan PIN if asked (if PIN ≠ 0000). This will start the warm up procedure (default: 3 minutes). All buttons are diabled during warm up period.
- 2. The isolator is ready for work.

3.1.2 Turning off the Isolator

- 1. Turn off the fan by pressing the FAN button. Input the Fan PIN if asked (if PIN ≠ 0000). This will start the post purge procedure (default: 0 minute). All buttons are diabled during post purge period.
- 2. Turn on the UV lamp (when present) to decontaminate the work area by pressing the UV button. Leave the UV lamp on to make sure the decontamination is done effectively. The UV lamp can only be turned on after the post purge procedure is finished.

3.2 Working in the Isolator

- Surface-decontaminate the work area (work surface, back and side wall, UV lamp) before and after using the isolator.
- Allow the isolator to purge any contaminant by allowing the blower to operate at least 3 minutes before and after using the isolator.
- Surface-decontaminate any item or apparatus with appropriate disinfectant before entering or exiting the work area.
- Place all items and apparatus in the safe working area.
- While working in isolator, move your hands slowly and in a controlled manner.
- The use of Bunsen burner inside the work zone is not recommended. However if the use of Bunsen burner is unavoidable, place the burner in the right side of the work zone.
- Place aerosol-generating instruments as far inside the isolator as possible and at least 150 mm (6 inches) from clean items/materials.
- Place air turbulence generating equipment such as centrifuges, blenders or sonicators towards the back of the isolator. Stop other work while any of this equipment is in operation.

3.3 Working Ergonomics

On most occasions, you would most likely be operating the BSC in sitting rather than standing posture. There are some obvious advantages of the sitting posture:

- The physiological energy cost and fatigue involved in sitting are relatively less
- Sitting posture provides the body with a stable support

However, sitting position has some drawbacks too:

- The working area available is fairly limited
- There is a potential risk of being constrained in the same posture for a long time
- Sitting posture is one of the most stressful postures for one's back

Therefore you should pay careful attention to the following guidelines in order to achieve comfortable and healthy working conditions:

- Always ensure that your legs have enough legroom.
- Keep your lower back comfortably supported by your chair. Adjust the chair or use a pillow behind your back whenever necessary.

- You should place your feet flat on the floor or on a footrest. Don't dangle your feet and compress your thighs.
- You should keep varying your sitting position throughout the day at regular intervals so that you are never in the same posture for too long.
- Observe the following precautions with respect to your eyes:
 - Give your eyes frequent breaks. Periodically look away from the work area and focus at a distant point.
 - Keep your glasses clean.
- Arrange the items/apparatus frequently used in your work in such a way that you can minimize the physical strain involved in handling them.
- Exercise regularly

The BSC's noise emission has been tested and found to be in compliance with EN 12469, ISO 4871 and NSF/ANSI 49 which is important to ensure health and comfort for the operator. Ergonomics accessories available with Esco include:

- Armrest padding
- Lab chair
- Footrest

Please contact your local distributor or Esco for more information.

3.4 UV Lamps

The UV light is a germicide and virucide. Even at the minimum acceptable irradiance in a BSC – 40 μ W/cm² (US Department of Health and Human Services et. al., 2000), it would only take 12.5 minutes to reach 30,000 μ W/cm² (1 W = 1 J/sec), which has been listed as germicidal for spore forming organism. Unlike many other type of decontamination agent, UV light doesn't leave any residue. The decontamination action stops upon de-energizing of the lamp.

However, due to the short wavelength, the UV light does not penetrate well. Thus UV light can only be used to effectively disinfect the work area of an empty BSC. For any container stored inside the BSC's work area, the UV radiation will only disinfect the outer surface of the material, leaving the inner surface and the content inside the material untouched.

- UV light decontamination method may be used before and after working with vegetative organisms and viruses. However, it should not be the sole decontamination agent; the use of chemical decontamination agent is still encouraged.
- Minimize the material inside the BSC's work area during the process of UV light decontamination. A direct interaction with UV light can degenerate plastic- or rubber-based material and can cause other hazard.
- Make sure that the BSC sash is in the fully closed position and the interlock is working properly before activating the UV lamp. Avoid direct contact with skin and eyes as UV light is classified as a probable human carcinogen.
- The UV lamp should be activated for around 60 minutes to work effectively. Use the UV timer feature to easily control the period of decontamination (UV timer is disabled by default). Leaving the UV lamp on for over 60 minutes or even overnight is not recommended because it shortens the lifespan of the lamp. The UV lamps used in Esco BSC have a lifespan of 2,000 hours.
- The UV lamp should be cleaned of any dust and dirt weekly and changed annually to ensure its effectiveness.
- The use of UV lamp in BSC has been explicitly discouraged in all major international standards and recommendations.

4.1 Scheduled Maintenance

Proper and timely maintenance is crucial for trouble free functioning of any device and your Esco BSC is no exception to this rule. We strongly recommend that you follow the maintenance schedule suggested hereunder in order to obtain optimal performance from your Esco BSC.

NI-	Description of Task to Deufsun	Maintenance to be carried out every					
No.	Description of Task to Perform	Day	Week	Month	Quarter	1 Year	2 Years
1	Surface decontaminate the work zone	v					
2	BSC power-up alarm verification	V					
3	Thoroughly surface decontaminate the drain pan		V				
4	Check the paper catch for retained materials		V				
5	Clean the exterior surfaces of the BSC			V			
6	Clean the sash window			V			
7	Check all service fixtures (where present) for proper operation			V			
8	Inspect the BSC for any physical abnormalities or malfunction				V		
9	Clean up stainless steel surfaces with MEK				v		
10	Re-certification					V	
11	Change UV Lamp (where present)					V	
12	Change the fluorescent lamps						V

Cleaning the Isolator

- Clean the work surface and walls with appropriate disinfectant agent and soap water afterward
- Clean the window using an appropriate disinfectant agent and glass cleaner afterward
- Use a damp cloth to clean the exterior surface of the isolator, particularly on the front and top in order to remove dust that accumulated there
- Use clean water to finish the cleaning and wash away any residue of disinfectant agent, soap water and glass cleaner
- For removing stubborn stains or spots on the stainless steel surface, make use of MEK (Methyl-Ethyl-Ketone). In such cases, make sure that you wash the steel surface immediately afterwards with clean water and some liquid detergent. Use a polyurethane cloth or sponge for washing. Regularly cleaning the stainless steel surface can help you retain the attractive factory finish.

Check the cabinet's functionality

- Check the isolator's mechanical functionality; ex: window opening lubricate if necessary
- Check the isolator's electrical functionality; ex: fluorescent lamp replace if necessary
- Check the isolator for any defect, repair immediately

Re-certification

All isolator must be re-certified annually by a certified engineer. See test report for recertification procedure.



Note: You only have to use the Esco factory supplied sleeves and cuff ring. You do not have to use the Esco factory supplied gloves. One can just replace the gloves supplied by Esco with sterile medical disposable/surgical gloves based on operator preference of material and size.

4.3 Sleeve Changing Procedure



12

4.4 Sharps Container Removal Procedure



Sharps Disposal Container -

- 1. Release the latch on both sides; gently allow the base tray to swing downwards.
- 2. Unhook the safety rope from one end.
- 3. Remove sharps container from mounting base, secure container lid and disposed of through the proper procedures of the facility.
- 4. Remove garbage container from base tray and empty the container.
- 5. Replace new sharps container or garbage container.
- 6. Ensure container top is completely sealed against the gasket.

4.5 Maintenance/Service Log

It is good practice (and in some cases regulatory requirement) to maintain a log of all maintenance work carried out on your cabinet.

14

APPENDIX

LOG RECORD

Isolator	:	
Serial Number	:	
Person in Charge	:	

- 1. This log record should be used by the operator to record any new agent that has been introduced to the isolator during its operation, problems encountered, etc.
- 2. Please also record any major maintenance procedure performed by the service technician, for example: parts replacement, recertification, etc.

Date	Event	User Signature	Supervisor Signature
Date	Event	Oser Signature	Supervisor Signature
•			
-			

In case of emergencies, please call:

Name	:	
Cell Phone Number	:	
E-mail	:	