

## quick start guide

**ATTENTION! UTILISATEURS WINDOWS 98: TO AVOID PROBLEMS WITH PLAYBACK, DO NOT CONNECT THE PLAYER TO THE USB PORT UNTIL AFTER YOU COMPLETE STEP 1, INSTALLATION.**

Thank you for buying this Philips wearable digital product. To get started, follow the **4 steps** as shown.

### 1 Installation

Insert the supplied installation CD into your computer's CD-ROM drive. The installation process is automatically launched for first-time application users.

### 2 Charging

Charge up your player 4 hours maximum before using it. Adjust the function switch on the player to **OFF/CHARGE**. Switch on your computer and connect the player to your computer's USB port.

### 3 Downloading

Adjust the function switch to **PLAYBACK/ DOWNLOAD**. Connect the player to the USB port of your computer to download your MP3/WMA files. You can transfer your files with **MUSICMATCH Jukebox** or use **Windows Explorer!**

### 4 Playback

Adjust the function switch to **PLAYBACK/ DOWNLOAD**. To listen to your music, connect the remote control & headphones to your player and press **▶||**.

## encendido rápido

**¡ATENCIÓN! USUARIOS DE WINDOWS 98: PARA EVITAR PROBLEMAS CON LA REPRODUCCIÓN, NO CONECTE EL REPRODUCTOR AL PUERTO USB HASTA HABER CONCLUIDO EL PASO 1, INSTALACIÓN DEL SOFTWARE.**

Gracias por comprar este producto digital para llevar de Philips. Como preparación, siga los **4 pasos** según se muestra.

### 1 Instalación del Software

Introduzca el CD de instalación suministrado, en el drive del CD-ROM de su ordenador. El proceso de instalación se inicia automáticamente para los usuarios que utilizan la aplicación por primera vez.

### 2 Proceso de carga

Cargue su reproductor (4 horas como máximo) antes de su utilización. Ajuste el interruptor de función del reproductor a la posición **OFF/ CHARGE**. Encienda su ordenador y conecte el reproductor al puerto USB de su ordenador.

### 3 Descargar

Ajuste el interruptor de función del reproductor a la posición **PLAYBACK/ DOWNLOAD**. Conecte el reproductor al puerto USB de su ordenador para descargar sus archivos MP3/WMA. Vd. puede transferir sus archivos con **MUSICMATCH** o utilizar **Windows Explorer!**

### 4 Reproducción

Ajuste el interruptor de función del reproductor a la posición **PLAYBACK/ DOWNLOAD**. Para escuchar su música, conecte el mando a distancia y los auriculares a su reproductor y pulse **▶||**.

3140 115 30691

die-cut