Reading Messages

When you receive a new message, use the 9501's One-Button feature to read the entire message by repeatedly pressing ●.

Setting the Pager Alarm

1. From the main menu, press ◀ or ▶ to move to ⊕(settings).
2. Press ● and use ◀ or ▶ to move to ♫ (set alarm).
3. Press ● to enter "Settings" mode.
4. Press ▲ or ▼ to choose either "Enabled Daily", "Enabled One-time", or "Disabled".
5. Press ◀ or ▶ to move to the hour digit and press ▲ or ▼ to set the hour you want for the alarm.
6. Press ◀ or ▶ to move to each entry selection (minute, AM/PM, day, month, year) and press ▲ or ▼ to set each field.
7. Press ● to save your settings.

Satellite Series 9501 Pager Quick Reference Card

Main Menu Icons

✉	Message Envelope
✉	Message Envelope (5 unread)
i	Information Folder
ï	Information Folder (unread)
🗁	Personal Folder
📖	PhoneBook
⊕	Time Alert Settings
⏻	Power On/Off
☾	Quiet Time Enabled
♪	Audible Alert Enabled
△	Alarm Enabled
🏠	Home Time
✈	Travel Time

Control Buttons

◀▶	Move Left/Right
●	Select
▲ ▼	Move Up/Down
◣	Escape

Pager Icons

- ☼ Alarm Enabled
- ☄ Alarm Disabled
- ℂ Quiet Time
- ℐ Quiet Time Disabled
- 👓 View Message
- ⮌ Return to Previous Screen
- ⮍ Add to Folder
- ☎ Add to PhoneBook
- ▥" Receive PhoneBook
- ▰▰▰ Battery Full Indicator
- ▰▰▱ Battery 2/3 Full Indicator
- ▰▱▱ Battery 1/3 Full Indicator
- ▱▱▱ Battery Low Indicator
- ▽ₐₗₗ Signal Strength Strong
- ▽ₐₗ Signal Strength Moderate
- ▽ₐ Signal Strength Low
- ▽ No Signal, Out of Range
- ⧌ Set to Vibrate
- ♪ Set Audible Alerts
- ♤ Set Alarm
- ♩ Set Alert to Silent
- ▼ View Next Message
- ✄ Delete Message
- ✓ Message Read
- ↑↓ Scroll Up and Down
- ◀ Truncated Message

Wearing Your Pager

Your 9501 pager comes with a multi-functional holster that orients the pager for the best possible performance. It is recommended that you place the pager in the holster (display side facing in) and wear it on your belt. The holster can also be used effectively off the body as a stand for your pager. To ensure optimum reception, extend the belt clip, stand it up on a desk or table, and point it toward the nearest window.

Note: Improper positioning of the 9501 pager will impair message reception.

Checking Satellite Strength

Note: Availability of the satellite feature described herein may vary, depending on the region of the world that you are in and the type of service provided.

It is possible that you may have difficulty receiving messages in the interior of large urban buildings. When you arrive in an unfamiliar office, hotel room, or meeting room, you may want to check the pager's ability to receive messages in that location. To determine the likelihood of receiving messages in a given environment, perform the following steps:

1. Position the pager correctly.
2. Press and hold ━ for 2 seconds. The LED blinks yellow while the pager is looking for the nearest satellite.
3. It can take up to 26 seconds to locate the nearest satellite. Upon completion your pager alerts with a single chirp. The LED will be either green (in range), or red (out of range). *If you press any button during the test, the test will be cancelled.*
4. When complete, remove the pager from the holster to view the display.
5. If your signal strength indicator shows you are out-of-range (antenna with no strength bars), or weak (antenna with 1 or 2 strength bars), move to an outer part of the building or room with a window, where you may obtain better reception results.