

# GXDB Remote

## Basic Operation Guide

Check Battery Installation information in owner's manual first.

For controlling other devices see the Remote Control Programming sheet.

**TV** Allow the remote to function with your Sanyo HDTV.

**Power On/Off** Power On or power Off your HDTV.

**MENU** Displays the on-screen menu.

**OK/ENTER** Move the cursor in the menu screens. Select highlighted menu options.

**RESET** Press twice to restore your HDTV to its original factory settings.

**VOL** Set the loudness level of the audio output.  
+ to increase  
- to decrease

**MUTE** Sets the volume level to 0. Restores the volume to the previous level before muting.

**INPUT** Switch from one Video input source to another. *NOTE: Hold for three seconds to open the Input List menu.*

**AUDIO** Selects the desired audio mode (when available).

**PIX SHAPE** Choose between available aspect ratio options Pix1 thru Pix7 and Pix-Auto (for digital channels) to enable or disable image stretch.

**PICTURE** Cycle through the predetermined picture modes.

**SOUND** Cycle through the predetermined sound modes.

**INFO** Display channel banner information.

**EXIT** Exit the the current on-screen menu and return to normal TV viewing.

**XACTI MENU W T** Activate Xacti functions when Xacti camera connected via HDMI.

**RECALL** Switch back and forth between the last two selected channels.

**CH** Scan through the channels in the HDTV's memory database.  
▲ for a higher channel  
▼ for a lower channel

**0 through 9** Tune to a channel directly. Ex: Press 0 then 6 for channel 6. *NOTE: Press and hold the 1 key to activate the first of three digits for channels 100 and higher.*

**USB** Switch directly to the USB input.

**CC CAPTION** Enable / disable digital caption options CC1-CC6 (digital) or CC1-CC4 (analog).

**SLEEP** Displays SLEEP timer. Pressing "0" key sets the Off Timer.

**ON TIMER** Displays the Switch On Time banner.

**HELP** Displays the On-screen Help menu with common problems and solutions.

**SET** (top left)

**DVD** (top row)

**STB** (top row)

**AUX** (top row)

**GUIDE** (middle left)

**LIST** (middle left)

**RESET** (middle left)

**EXIT** (middle right)

**1-9** (numeric keypad)

**0** (numeric keypad)

**PIX SHAPE** (bottom row)

**PICTURE** (bottom row)

**AUDIO** (bottom row)

**SOUND** (bottom row)

**CC** (bottom row)

**CAPTION** (bottom row)

**SLEEP** (bottom row)

**ON TIMER** (bottom row)

**HELP** (bottom row)

**SANYO** (bottom center)

**GXDB** (bottom center)

**1-800-877-5032** (bottom center)

For assistance call the toll free number 1.800.877.5032 or visit our website at [www.sanyoctv.com](http://www.sanyoctv.com)

# Control GXDB

## Guía de operación básica

Revise la información de Instalación de Baterías en el manual de usuario.

Para controlar otros aparatos refiérase a la hoja de Programación del Control Remoto.

**TV** Permite a su control funcionar con el televisor Sanyo.

Encender o apagar su televisor Sanyo.

**MENU** Desplegar el menú en pantalla.

Mover el cursor en los menús en pantalla.

Seleccionar la opción resaltada en el menú

**INFO** Desplegar el baner de información de canal.

**EXIT** Salir del menú en pantalla y regresar al modo normal de TV.

Activar funciones de la cámara Xacti al estar conectada por HDMI.

**RESET** Presionar dos veces para restaurar la HDTV a su configuración de fábrica.

Configurar el nivel de intensidad del volumen.

+ para incrementar  
- para disminuir

**MUTE** Establecer en 0 el nivel del volumen. Presionar de nuevo restaura el volumen al nivel anterior.

**RECALL** Cambiar entre uno y otro de los dos últimos canales accedidos.

Navegar por los canales almacenados en la base de datos de memoria de la TV.

▲ para canal más alto  
▼ para canal más bajo

**0** al **9**  
Accesar directamente un canal. Ejem.: 0 y 6 para el canal 6.  
*NOTA: Presione unos segundos la tecla 1 para activar el primer número de canales como el 100 y más altos.*

**INPUT** Cambiar entre una y otra de las entradas de Video.  
*NOTA: Mantenga presionada por 3 seg. para mostrar la Lista.*

Accesar directamente la entrada USB.

Seleccionar el modo de audio disponible.

Habilitar / deshabilitar los subtítulos digitales: CC1 – CC6 (en digital) o CC1-CC4 (en análogo)

**PIX SHAPE** Seleccionar entre las relaciones de aspecto disponibles de Pix1~Pix7 y Pix-Auto (para canales digitales).

**CC** CAPTION

**SLEEP** Desplegar contador SLEEP. La tecla "0" configura el tiempo de apagado.

**PICTURE** Seleccionar entre las diferentes configuraciones de imagen predeterminadas.

**ON TIMER** Desplegar la hora determinada de encendido.

**SOUND** Seleccionar entre las diferentes configuraciones de audio predeterminadas.

**HELP** Desplegar en pantalla el menú de ayuda con los problemas y soluciones más comunes.

**SANYO**  
GXDB  
1-800-877-5032

Si necesita mayor asistencia favor de comunicarse al 1.800.877.5032 o visite nuestra página de internet [www.sanyoctv.com](http://www.sanyoctv.com)