SYTECH



Electric Grill

GRILL, EAT & GO
Serie

USER MANUAL - SY-GR11

SAFETY INSTRUCTIONS

- The appliance must be connected to a voltage supply of 220 V – 240 V Only.
- This appliance is not intended for use by persons (Including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- If the supply cable is damaged, contact Sytech Hotline Service Center for a proper repair or exchange. This will avoid any hazard.
- Do not allow the power cable to hang down with easy reach. Keep children away from the packaging material (e.g. plastic bags).
- Never pull the plug out of the socket by the cable or with wet hands. Disconnect the mains plug in case of faults during use, before cleaning or moving the appliance from place to place, after use.
- Regularly check if the mains cable/ appliance/ extension lead are in perfect state. In the contrary, the appliance must not be put into operation (immediately pull out the plug). Contact the Sytech Service Centre for reparation.
- Only trained personal should repair electrical appliances. Unskilled repairs can cause considerable danger to the user.

- No warranty for any possible damage can be accepted if the appliance is used for improper purpose, wrongly operated or unprofessionally repaired. In such case, any warranty claim is void.
- Only use the temperature controller/power cable supplied by Sytech for this appliance (SY-GR11, 250V, 10A)
- Do not use any attachments that are not recommended by the manufacturer.
- The appliance should not be operated by means of an external timer or separate remote-control system.
- Never put the appliance / cable on hot surfaces or near open flames.
- The appliance is designed for household use and not for industrial operation. Do not operate the appliance outdoor.
- Never place the appliance on soft cushions/pillows or blankets during operation.
- Never carry or pull the appliance by the cable, don’t pull the cable over sharp edges. Do not jam or bend the cable.
- Switch the appliance off and pull the plug out of the mains when it is not in use. Don’t wind the cable around the appliance.

DISPOSAL



Not household waste. Make worn out appliance unusable. Pull out the mains plugs and sever the cable. Return electrical appliances to a shop of sale or disposals of products in accordance with local regulations

CLEANING



Before cleaning, unplug the power cable and remove temperature probe from the appliance.



Allow the appliance to cool down completely.



Grilling Surface
- Wipe the non-stick grilling surface using a soft cloth moistened with warm soapy water.
- Wipe thoroughly the full surface.

Do not use abrasive cleaners or scouring pads. Never immerse the appliance in water or any other liquid.



Temperature Controller
- Wipe the housing of the temperature controller and the temperature probe with a soft dry cloth.

Never immerse the power cable, plug or temperature selector in water or any liquid.



Drip Tray
- Carefully remove the drip tray
- Dry it thoroughly

BEFORE USE

Thank you for having purchased our Electrical Grill SY-GR11. Enjoy cooking the easy way.

- Please read these instructions carefully and retain them for future use.
- The appliance must only be used for the intended purpose according to these instructions
- Observe the safety instructions.

Keep the instructions.

- Remove the appliance from the packaging material.
- Wipe the non-stick grilling surface using a soft cloth moistened with warm washing-up water.
- Wipe thoroughly using a soft cloth moistened in warm water.

Never immerse the appliance, power cable, plug or temperature selector in water or any other liquid.
Do not use abrasive cleaners or scouring pads.

OVERVIEW


Handle
Non-stick grilling surface
Handle
Drip tray
Socket for temperature controller
Temperature control probe
Off / temperature selector
SELF CONTROL
Thermostat
Temperature control lamp

CONNECTING THE SY-GR11

1



Plug the temperature control probe into the appliance (set temperature controller to off)

2



Plug the power cable into the mains.

Only use the temperature controller / power cable supplied by the manufacturer for this appliance.

FIRST TIME USE

1



Apply a little cooking oil evenly to the grilling surface.

2



Connect the power cable

3



Switch it on for approximately 15 minutes.

COOKING

1



Set the temperature controller to the desired temperature (the temperature control lamp lights up)

2



When the desired temperature has been reached (the temperature control lamp will turn off) place the food onto the grilling surface using little or no oil.

Grilling surface becomes very hot – danger of burning!

During cooking, the temperature control lamp lights up and goes off constantly. This indicates that the temperature desired is being maintained.

Do not use metal utensils or cut any food on the grilling surface as this may cause damage to the non-stick surface.

3



When Finished:

- Set temperature selector to OFF (0)
- Unplug power cables from mains

PRECAUTIONS WHILE COOKING

- Do not apply large amounts of oil or butter to the grilling surface
- Be careful of spattering during cooking, wear oven gloves if necessary.

QUICK COOKING GUIDE

This cooking guide is for reference only

- Times and temperatures may vary depending on the amount of food and individual taste.
- Times for meat, poultry and fish are based on a thickness of 1 to 1.5 cm

COOKING TIME

Food	Cooking time (In Minutes)
Bacon	5-8
Fried eggs	3-5
Fish	5-10
Ham	10-12
Hamburgers	8-12
Potatoes	10-12
Sausages	20-30
Steak	18-20

TECHNICAL DATA

Voltage: 220 – 240 V
Output: 1700 – 2000 W
Frequency: 50 HZ
Unit Dimensions: 53.3X26.6X8.1CM
Weight: 2.3 Kg
Thickness: 1.7mm
Material: Aluminium

