

Hunter Pilot 14G

Läs noga igenom bruksanvisningen innan du börjar använda din lampa!

I förpackningen skall följande finnas

- Hunter PILOT 14G – LED lampa med grönt sken
- Laddkopp
- 230V AC Laddningsadapter
- 12V Laddningskabel för bil
- 2st laddningsbara batterier (Li-Ion)
- Fjärrströmbrytare
- Hållare för montering på gevär
- Denna bruksanvisning

Saknas något vänligen kontakta din återförsäljare.

Laddning

Anslut laddningsadaptern till uttaget på laddkoppens baksida och anslut därefter till 230V AC nät. Vill du ladda via bilens 12V cigarettuttag, anslut först laddkabeln till laddkoppen och därefter till bilens uttag. Laddkoppens två indikatorer lyser grönt. Placera ett eller båda batterierna i laddkoppen. Laddningsindikatorn lyser rött vid laddning. När batteriet är fulladdat lyser indikator grönt igen.

Obs!

- Var uppmärksam på att batterierna är rättvända när du placerar dem i laddkoppen. Se märkningen på batteriet och laddkoppen.
- Laddkoppen har separat laddning för respektive batteri och uppladdningen sker individuellt.
- Batteriet är ett uppladdningsbar Li-Ion batteri vilket innebär att man inte behöver tömma det helt mellan laddningarna. Laddning kan ske när som helst.
- Lämna inte batterierna i laddaren mer än 24 timmar och ha alltid uppsikt under laddning.
- Använd endast medföljande originalladdare för att inte skada batterierna.
- Laddaren laddar endast Li-Ion 18650 batterier.
- Laddaren är avsedd för inomhusbruk.

Komma igång

Skruva av bakstycket och placera ett batteri i lampan. Var uppmärksam på att batteriet är rättvänt. Batteriets pluspol skall vara riktad mot lampans front och minuspol mot bakstycket. Skruva sedan tillbaks bakstycket. För att slå på lampan tryck på strömbrytaren som sitter på bakstycket. För att stänga av tryck på strömbrytaren en gång till. Vill du använda fjärrströmbrytaren, skruva av bakstycket och ersätt den med den medföljande fjärrströmbrytaren.

Fjärrströmbrytarens funktion är momentan, dvs. lampan lyser under tiden man håller brytaren intryckt.

Använd medföljande hållare för att montera lampan på ditt gevär. Hållaren kan placeras på kikarsikte eller pipa. Fjärrströmbrytaren fästs mot kolven.

Om du inte ska använda lampan under en längre period, ta ur batteriet. Ladda batterierna varje halvår.

Rengör med en lätt fuktad trasa för att den ska hålla längre. Använd inte starka kemikalier eller lösningsmedel och doppa inte i vatten.

Felsökning

Om lampan inte tänds eller blinkar istället för att lysa: Kontrollera att skruven inuti bakstycket inte sitter lös. Det finns två små försänkningar i skruven där en tång med vassa spetsar passar. Dra åt skruven genom att vrida medsols.

Garantivillkor

Garantitiden är 24 månader om inte annat anges, från det datum produkten köptes från återförsäljaren. Garantins giltighet skall styrkas med faktura eller kassakvitto på vilken/ vilket inköpsdatum skall framgå. Laddningsbara batterier klassas som förbrukningsmaterial och för dessa tillämpas 3 månaders funktionsgaranti. Om fel upptäcks på produkten under garantitiden, kontakta din återförsäljare. Garanti gäller inte för fel som uppstår genom oaksamhet eller felaktigt handhavande av produkten. Garantin omfattar inte fel som beror på olyckshändelse, onormalt brukande, försummat underhåll, oriktig skötsel, felaktig spänning eller strömart, ändringar, fuktskador, egna ingrepp eller reparation. Saknas kassakvitto eller felbeskrivning omfattas produkten inte av garantin.

Teknisk specifikation

LED typ:	Cree® XLamp® XP-E R2 (Grön)
Sken:	Grönt
Lumen:	250
Lins:	Härdat glas
Reflektor:	Slät aluminium
Material:	Hårdanodiserad aluminium
Strömförsörjning:	1st Li-Ion batteri, 18650
Dimensioner:	155 x 45 mm (höjd x största diameter)
Vikt:	215 g (med batteri)
Miljötolighet:	Stöt och vattensäker

Designed and developed in Sweden
by Hunter Electronic AB.



Hunter Pilot 14G

Read the User Manual before using your flashlight.

Package content

- Hunter Pilot 14G – LED flashlight with green light
- Charger cup
- 230V AC Charger adapter
- 12V Charging cable for car
- 2st rechargeable batteries (Li-Ion)
- Remote control
- Fastener for gun mounting
- This User Manual

If anything is missing please contact your dealer.

Charging

Connect the charger adapter into the socket on the back of the charger cup and then connect to a 230V outlet. When using the car's 12V cigarette lighter socket, first connect the charging cable to the charging cup and then to the car's 12V outlet. Without batteries inserted the charger has two indicator diodes with green light. Place one or both batteries in the charger. The chargers indicator lights are red when charging. When the battery is fully charged, the indicator turns green.

Note carefully

- Place the batteries with correct polarity in the charger. Compare with labels on batteries and charger.
- The charging process is individual for the two battery slots.
- The Li-Ion battery can be charged at any energy level. There is no need to fully discharge the battery before charging.
- Do not charge for longer time than 24 hours. Always keep an eye on an active charger.
- Always use the original Hunter PILOT 14G charger to get the best battery life.
- Only use the charger for Li-Ion 18650 batteries.
- The charger is for indoor use only.

Using the flashlight

Unscrew the back cover and place the battery in the lamp. Be aware that the battery is oriented correctly. The positive battery terminal must be pointed towards the front of the lamp and the negative terminal on the rear panel. Then screw the back cover in place.

Turn on the lamp by a press on the power switch located on the back. To turn off with another press.

To use the remote control unscrew the back cover and replace it with the supplied remote switch. The remote Power Switch function is instantaneous, i.e. the lamp is lit during the time you hold the switch down.

Use the supplied bracket to mount the light on your rifle. The holder can be placed on the telescopic sight or barrel. The remote switch is to be attached at a comfortable position on your gun with the supplied Velcro sticker.

If you do not use the lamp for a long period, remove the battery. Recharge the batteries every 6 months.

Clean with a damp cloth for it to last longer. Do not use harsh chemicals or solvents and do not immerse in water.

Troubleshooting

If the lamp does not light up or is unstable: Make sure the screw inside the back piece does not sit loose. There are two small indentations in the screw where a pliers with sharp tips fit. Tighten the screw by turning clockwise.

Warranty

The warranty period is 24 months, unless otherwise indicated, from the date the product was purchased from the dealer. Warranty validity must be supported by an invoice or sales receipt on which / what purchase date shall be shown together with a problem description.

Rechargeable batteries are classified as consumables and a 3-month function warranty is given.

If errors are discovered during the warranty period, contact your dealer.

Warranty does not cover defects caused by negligence or improper handling of the product.

The warranty does not cover failure due to accident, abnormal usage, neglected maintenance, improper maintenance, improper voltage or current type, product modifications, moisture damage, tamper with or uncertified repairs.

Missing receipt or description of the defect, the product is not under warranty.

Technical specification

LED type	Cree® XLamp® XP-E R2 (Green)
Light	Green
Lumen	250LM
Lens	Hardened glass
Reflector	Polished aluminium
Material	T6061 aluminium
Power	1st Li-Ion battery, 18650
Dimensions	155 x 45 mm (height x diameter)
Weight	215 g (including battery)
Environment	Shock and water protected

Designed and developed in Sweden
by Hunter Electronic AB.

