

## Step 1: Install Batteries

Your OARH01B universal remote requires 2 new AAA alkaline batteries (sold separately).

### To install the batteries:

1. Turn the unit over, remove screw and remove the battery door compartment cover.

2. Insert the batteries, matching the batteries to the (+) and (-) marks inside the battery case.

### Battery Precautions:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with Local and National Regulations.

## Step 2: Program the Remote


To use this universal remote with your TV, first you need to program it to control your TV. There are three ways you can program the universal remote to operate your TV.

- The **Auto Code Search** goes automatically through all the codes for your TV. It's the easiest method, but it can sometimes take longer than some of the other programming methods.
- The **Direct Code Entry** lets you enter a code from the accompanying code list for your brand. It's not as easy as the other methods, but it's potentially the fastest method.
- The **Manual Code Search** lets you manually go through all the codes for your TV.

### Auto Code Search

The Auto Code Search goes automatically through all the codes for your TV. When you find the one that operates your TV, you can stop the search and store that code.

1. Manually turn on your TV.



2. Press and hold the **CODE SEARCH** key until the indicator light turns on.



**Important:** Find the **ENTER** key on your remote (don't press it yet). You will need to press this key quickly in step 4 below.

3. Point the remote directly at the front panel of your TV. Press the **POWER** key and wait for the indicator light to blink. Each time the indicator light blinks, the remote is testing a code with your TV. Make sure you keep the remote pointed at your TV.



4. As soon as your TV turns off, press the **ENTER** key within 4 seconds.

**Note:** If you wait longer than 4 seconds to press **ENTER**, the remote goes to the next code—you will need to start the code search from step 1 again.


The indicator light flashes 8 times and turns off when the remote has searched all the codes. If this happens, try one of the other programming methods.

5. Test the remote with your TV to make sure you can control most of your TV's functions. If some features don't work, try the Direct Code Entry method.

### Direct Code Entry

Direct Code Entry lets you enter a code from the code list at the end of this manual for your brand of TV. It's not as easy as the other methods, but it's potentially the fastest method.

1. Manually turn on your TV.



2. Find the four-digit code for your brand of TV in the code list at the end of this manual.

3. Press and hold the **CODE SEARCH** key until the indicator light turns on.



4. Enter the four-digit code, using the numeric keypad. After the code is entered, the indicator light turns off.



**Note:** If the indicator light blinks multiple times, you've entered an invalid code. Start from step 2 again.

5. Aim the remote at your TV and press the **POWER** key.

**If your TV turns off:** The remote is programmed to operate this TV.


**If your TV does NOT turn off:** Try the next code for your brand.

**Note:** If no codes work, or if your brand is not listed, try the Auto Code Search or Manual Code Search.

### Manual Code Search

The Manual Code Search lets you go one-by-one through all the codes for your TV. When you find the one that operates your TV, you can stop the search and store that code.

1. Manually turn on your TV.




2. Press and hold the **CODE SEARCH** key until the indicator light turns on.



**Important:** Find the **ENTER** key on your remote (don't press it yet). You will need to press this key quickly in step 4 below.

3. Point the remote directly at the front panel of your TV. Press the **POWER** key once every 2-3 seconds until your TV turns off.



**Note:** Since this remote has hundreds of codes, you may have to press the **POWER** key many (perhaps hundreds of) times using this method.

4. As soon as your TV turns off, press the **ENTER** key within 4 seconds.

**Note:** If you wait longer than 4 seconds to press **ENTER**, the remote goes to the next code—you will need to start the code search from step 1 again.

The indicator light flashes 8 times and turns off when the remote has searched all the codes. If this happens, try one of the other programming methods.

5. Test the remote with your TV to make sure you can control most of the TV's functions. If some features don't work, try the Direct Code Entry method.



### Accessing Menus

This remote supports menu access, navigation and selection for many makes and models of TV. The amount of menu functionality varies from model to model and from brand to brand.

#### To use the Menu function:

1. Press the **MENU** key. The menu of your TV is shown. While in Menu Mode the Red LED will blink until you exit or Menu function times out. the keys on this remote function as follows:

**Vol up/ down**      **Ch +/-**  
 Cursor moves right/left      Cursor moves up/down

**Note:** Some functions of some brands may not be fully supported.

2. To exit the menu mode press **MENU** key on the remote again.

### Accessing Digital Channels

The INPUT and — (dash) key lets you enter a digital sub-channel number, like 59.1, directly. Use the number keys to enter the main channel number (in this case, "59"). Then press the INPUT (-) key and press the subchannel number (in this case, "1"). When you're not entering channel numbers, the INPUT key toggles through all the video sources connected to your TV as well.

### Retrieving Remote Codes

Once you've found the code that works best with your TV, you might want to write it down so that you can use it if you ever need to program a remote for your TV again. That's easy if you used the Direct Code Entry method—just write down the code you used from the list. However, if you used the Auto Code Search or Manual Code Search, you will need to go through the following steps to know exactly which code you're using.

1. Press and hold the **CODE SEARCH** key until the indicator light turns on.

2. Press the **CODE SEARCH** key again. The indicator light turns off.

3. Starting with **0** on the keypad, press the number keys in order (**0-9**) until the indicator light turns on. The number that causes the indicator light to light up is the first digit of your code. Write it down in the space provided below.

4. Repeat step 4 until you have retrieved all four numbers of the code.



#### Additional Information

This product does not have any user-serviceable parts. Opening the case, except for the battery cover, may cause permanent damage to your OARH01B Cable Replacement Remote.

- For help via the Internet, visit us at: [www.oneforall.com](http://www.oneforall.com)
  - For help via our consumer help line, call 1 (800) 315-0990
- ONE FOR ALL® is the registered trademark of Universal Electronics Inc. Audiovox Accessories Corporation is the Licensee of the ONE FOR ALL® brand for North America.

© 2011 Universal Electronics Inc. No part of this publication may be reproduced, transmitted, transcribed, stored in any retrieval system, or translated to any language, in any form or by any means, electronic, mechanical, magnetic, optical, manual, or otherwise, without prior written permission of Universal Electronics Inc.

### 90-Day Limited Warranty

Audiovox Electronics Corporation warrants that for 90 days from date of purchase, it will replace this product if found to be defective in materials or workmanship. Return it to the address below for a replacement with a current equivalent. This replacement is the company's sole obligation under this warranty. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE IS DISCLAIMED. This warranty excludes defects or damage due to misuse, abuse, or neglect. Incidental or consequential damages are disclaimed where permitted by law. This warranty does not cover product purchased, serviced or used outside the United States or Canada.

To obtain replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (eg. dated bill of sale), specifications of defect(s), transportation prepaid to the Company at the address shown below.

**U.S.A.:** Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, NY 11788

**CANADA:** Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit 3, Door 16, Mississauga, Ontario L5T 3A5

#### Care and Maintenance

- Keep the remote dry. If it gets wet, wipe it dry immediately.
- Use and store the remote only in normal temperature environments.
- Handle the remote gently and carefully. Don't drop it.
- Keep the remote away from dust and dirt.
- Wipe the remote with a damp cloth occasionally to keep it looking new.
- Modifying or tampering with the remote's internal components can cause malfunction and invalidate its warranty.

## Paso 1: Instalar las Baterías

Su control remoto universal OARH01B requiere 2 baterías alcalinas AAA nuevas (vendidas por separado).

### Para instalar las baterías:

1. Voltee la unidad, retire el tornillo y remueva la cubierta del compartimiento de la puerta de baterías.

2. Inserte las baterías, de manera que las baterías coincidan con las marcas (+) y (-) dentro del compartimiento de baterías.

### Precaución con las baterías:

- No mezcle baterías nuevas y viejas.
- No mezcle baterías alcalinas, estándar (carbono-zinc) o recargables (níquel-cadmio).
- Siempre retire prontamente las baterías viejas, descargadas o gastadas y recíclelas o elimínelas de conformidad con las regulaciones nacionales y locales.

## Paso 2: Programar el Control Remoto


Para usar este control remoto universal con su sistema de entretenimiento en casa, usted primero necesita programarlo para controlar sus equipos. Hay tres formas en que usted puede programar el control remoto universal para que funcione con su TV:

- La opción **Auto Code Search (Búsqueda Automática de Código)** pasa automáticamente a través de todos los códigos para su TV. Este es el método más fácil, pero en ocasiones puede tomarse más tiempo que algunos de los otros métodos de programación.
- La opción **Direct Code Entry (Entrada Directa de Código)** le permite ingresar un código de la lista de códigos que le acompaña para la marca de su equipo. No es tan fácil como los otros métodos, pero potencialmente es el método más rápido.
- La opción **Manual Code Search (Búsqueda Manual de Código)** le permite pasar manualmente a través de todos los códigos para su TV.

### Búsqueda Automática de Código

La Búsqueda Automática de Código pasa automáticamente a través de todos los códigos para su TV. Cuando usted encuentra el que funciona con su TV, puede detener la búsqueda y guardar ese código.

1. Encienda manualmente su TV.



2. Presione y mantenga presionada la tecla **CODE SEARCH** hasta que la luz del indicador se encienda.



**Importante:** localice la tecla **ENTER** en su control remoto (no la presione todavía). Usted necesitará presionar esta tecla rápidamente en el paso cuatro más adelante.



### Búsqueda Manual de Código

La Búsqueda Manual de Código le permite ir uno por uno a través de todos los códigos para su TV. Cuando encuentre el que funciona con su aparato, usted puede detener la búsqueda y guardar ese código.

- 1. Encienda manualmente su TV




- 2. Presione y mantenga presionada la tecla **CODE SEARCH** hasta que la luz del indicador se encienda



**Importante:** localice la tecla **ENTER** en el control remoto (no la presione todavía). Usted necesitará presionar esta tecla rápidamente en el paso 4 más adelante).

- 3. Apunte el control remoto directamente al panel frontal de su TV. Presione la tecla **POWER** una vez cada 2-3 segundos hasta que su TV se apague.



**Nota:** puesto que este control remoto tiene cientos de códigos, puede ser que usted tenga que presionar la tecla **POWER** muchas veces (quizás cientos) usando este método.

- 4. Tan pronto como su TV se apague, presione la tecla **ENTER** en 4 segundos.



**Nota:** si usted espera más de 4 segundos para presionar **ENTER**, el control remoto pasará al siguiente código - usted necesitará comenzar la búsqueda de códigos desde el paso 1 otra vez.



La luz del indicador parpadea 8 veces y se apaga cuando el control remoto ha buscado todos los códigos. Si esto ocurre, intente uno de los otros métodos de programación

- 5. Pruebe el control remoto con su TV para asegurarse de que puede controlar la mayoría de las funciones de la TV. Si algunas características no funcionan, intente con el método de Entrada Directa de Código.

### Acceso a los Menús

Este control remoto soporta el acceso a menú, navegación y selección de muchas marcas y modelos de TV. La cantidad de funcionalidad de menú varía de modelo a modelo y de marca a marca.

Para usar la función Menú:

- 1. Presione la tecla **MENU**. El menú de su TV es mostrado. Mientras esté en modo Menú el LED Rojo parpadeará hasta que usted salga o la función de Menú se apague. Las teclas en este control remoto funcionan de la manera siguiente:

<b>Vol up/ down</b>	<b>Ch +/-</b>
---------------------	---------------

El cursor se mueve a derecha/izquierda. El cursor se mueve arriba/abajo

**Nota:** algunas funciones de algunas marcas pueden no estar completamente soportadas.

- 2. Para salir del modo menú presione la tecla **MENU** en el control remoto otra vez.

### Para Accesar Canales Digitales

La tecla **INPUT** y **—** (guion) le permiten ingresar un número de subcanal digital, como 59.1, directamente. Use las teclas numéricas para ingresar el número de canal principal (en este caso, "59"). Luego presione la tecla **INPUT (-)** y presione el número de subcanal (en este caso, "1"). Cuando usted no esté ingresando números de canal, la tecla **INPUT** alterna también a través de todas las fuentes de video conectadas a su TV.

### Para Recuperar los Códigos del Control Remoto

Una vez que usted haya encontrado el código que funcione mejor con su TV, quizás desee anotarlo de manera que pueda utilizarlo en el caso de que necesitara volver a programar un control remoto para su TV. Eso es fácil si usted usó el método de Entrada Directa de Código - sólo tome nota del código que usó de la lista. Sin embargo, si usted utilizó la Búsqueda Automática de Código o la Búsqueda Manual de Código, usted necesitará ir a través de los pasos siguientes para saber exactamente cuál código está usando.

- 1. Presione y mantenga presionada la tecla **CODE SEARCH** hasta que la luz del indicador se ilumine.
- 2. Presione la tecla **CODE SEARCH** otra vez. La luz del indicador se apaga.
- 3. Comenzando con **0** en el teclado, presione las teclas numéricas en orden (**0-9**) hasta que la luz del indicador se ilumine. El número que cause que la luz del indicador se encienda es el primer dígito de su código. Anótelo en el espacio provisto a continuación.
- 4. Repita el paso 4 hasta que usted haya recuperado los cuatro números del código.



### Información Adicional

Este producto no tiene partes que requieren servicio por parte del usuario. Abrir el estuche, excepto la cubierta para baterías, puede causar daño permanente a su Control Remoto de Reemplazo para Cable OARH01B.

- Para ayuda a través de Internet, visítenos en: [www.oneforall.com](http://www.oneforall.com)
- Para asistencia a través de la línea de ayuda al consumidor, llame al 1 (800) 315-0990

ONE FOR ALL® es marca registrada de Universal Electronics Inc. Audiovox Accesorios Corporation es el Licenciatario de la marca ONE FOR ALL® para América del Norte.

© 2011 Universal Electronics Inc. ninguna parte de esta publicación puede ser reproducida, transmitida, transcrita, almacenada en algún sistema de recuperación, o traducida a algún idioma, en alguna forma o por algún medio, electrónico, mecánico, magnético, óptico, manual, o de otra forma, sin el permiso previo por escrito de Universal Electronics Inc.



### Garantía Limitada por 90 Días

Audiovox Electronics Corporation garantiza que por 90 días desde la fecha de compra, reemplazará este producto si se encuentran defectos en materiales o mano de obra. Envíelo de regreso a la dirección a continuación para un reemplazo con un equivalente actual. Este reemplazo es la única obligación de la compañía bajo esta garantía. CUALQUIER GARANTÍA IMPLÍCITA DE COMERCIALIZACIÓN O DEDICIDAD PARA UN USO EN PARTICULAR ES RENUNCIADA. Esta garantía excluye defectos o daños debido a mal uso, abuso, o negligencia. Los daños consecuenciales o incidentales son renunciados donde sea permitido por la ley. Esta garantía no cubre el producto comprado, que haya recibido servicio o haya sido usado fuera de los Estados Unidos o Canadá.

Para obtener reemplazo dentro de los términos de esta Garantía, el producto debe ser entregado con cobertura de la prueba de garantía (por ejemplo, nota de venta fechada), especificaciones de defectos, transporte pagado a la Compañía a la dirección que se muestra a continuación.

**EEUU:** Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, NY 11788  
**CANADÁ:** Audiovox Return Center, c/o Genco, 6885 Kennedy Road, Unit 3, Door 16, Mississauga, Ontario L5T 3A5

### Cuidado y Mantenimiento

- Mantenga el control remoto seco. Si se moja, séquelo de inmediato
- Use y guarde el control remoto sólo en ambientes a temperatura normal.
- Maneje con suavidad y cuidado el control remoto. No lo tire.
- Mantenga el control remoto lejos del polvo y la suciedad.
- Limpie el control remoto con un paño húmedo ocasionalmente para mantenerlo con una apariencia de nuevo.
- Modificar o alterar los componentes internos del control remoto puede causar mal funcionamiento e invalidar su garantía.

### TV Codes / Códigos de TV

Admiral.....0093, 0463	Fural.....0001, 0171, 1963
Advent.....0761	Gateway.....1755
Aiko.....0812, 1675, 0702, 1535	GE.....1547, 1447, 0000, 0051, 0451, 0178
AOC.....1365, 1589, 2014, 2087, 2479	GF.....0171, 1665, 1963, 2167
Apex Digital.....0748, 0765, 1217, 2397	Gibralter.....0017
Audiovox.....0451, 0502, 1766,	GoldStar.....0178
.....1769, 1868, 2121	Hair.....1748, 1748, 2309
Aventura.....0171	Hallmark.....0178
Broksonic.....0463, 1935	Hanpre.....1348
Cenve.....0054	HamamKardon.....0054
Celebrity.....0001	Haverly.....0093
Celera.....0765	Hello Kitty.....0451
Changhong.....0765	Hisense.....0748, 1660, 2038, 2355
Citizen.....0060, 1935	Hitachi.....1643, 0145
Coby.....1634, 2306, 2315, 2344, 2345, 2348	iL.....1394, 1665, 1684
Commercial Solutions.....1447, 0000	Infinity.....0054
Cresley.....0001, 0054	Insignia.....1423, 1564, 0463, 0171,
Curtis.....2352, 2466	.....1660, 1710, 1892, 1963, 2049
Curtis Mathes.....0000, 0054, 0451, 0093,	Inteq.....0017
.....0090, 0702, 0145, 1661	JBL.....0054
Daewoo.....0451, 1661	JCB.....0001
Dell.....1264	Jensen.....0761
Demon.....0145	JVC.....0463, 0053, 1253, 1601, 1774, 2264
Dumont.....0017	KDS.....1498, 1687
Durabrand.....0463, 0178, 0171	KLH.....0765
Dynex.....1463, 2049, 2184	LD.....1423, 1447, 0017, 0178, 2358, 2424
Electroband.....0001	LX.....0000, 0054, 0156, 0178
Electrograph.....1755	MAG.....1498, 1687
Electrohome.....0463, 1670	Magnovox.....1494, 1866, 1755, 0054, 0051,
Element.....1687, 1866, 2183	.....0171, 0812, 1365, 1856, 1963, 2372
Emerson.....1864, 0451, 0463, 0178,	Manrantz.....1454, 0054
.....0171, 1661, 1394, 1665, 1963	Mitsubishi.....0250
Empire.....1422	Maxent.....1755
Envision.....1365, 1589, 2014, 2087	MB Quart.....1688
ESA.....0812, 0171, 1963	Megatron.....0178, 0145



Memorex.....0463, 0150, 0178, 1670, 1892	Sanyo.....0054, 1142
MGA.....0150, 0178	Scotpre.....0876, 1217, 1360, 1599, 2506
Melland.....0000, 0017, 0051	Scotch.....0178
Mitsubishi.....1250, 0093, 0150, 0178	Scott.....0178, 1711
Motorola.....0093	Sears.....0000, 0054, 0156, 0178, 0171
MTC.....0060	Sharp.....0618, 0093
NAD.....0156, 0178	Sheng Chia.....0093
NEC.....1797	Signature.....0054
NetTV.....1755	Sony.....0610, 0001
Nexus Electronics.....2183	Soundesign.....0178
Nikko.....0178	Soyo.....1826
Norcant.....0748, 1365, 1589	Spectroniq.....1498, 1687
Oavia.....1610, 1240, 1531	Squareview.....0171
Optima.....1348	Superscan.....0093
Optonica.....0093	Supreme.....0001
Orion.....0463, 1463	Sylvania.....1864, 0054, 0171,
Panasonic.....1480, 0250, 1457,	.....1394, 1665, 1886, 1963
.....0051, 1291, 2264	Symphonic.....0171
PARK.....2104, 2194	Syntax.....1610, 1240, 1531
Penney.....0000, 0156, 0051, 0060, 0178	Tandy.....0093
Petters.....1523	Technics.....0250, 0051
Phico.....0054, 0171, 1394, 1665, 1963	Techwood.....0051
Philips.....1454, 1866, 0054, 1744,	Teknika.....0054, 0150, 0060
.....1856, 2372, 2374	Telefunken.....0702
Polaroid.....1523, 0765, 1276, 1498,	.....0178
.....1687, 1766, 1769, 2121	TMK.....0463
Portland.....0451, 1661	TVS.....0054
Prima.....0791	Victor.....0093
Prism.....0051	Vidikron.....0054
Proscan.....1447, 0000, 2256	Vidtech.....0178
Proton.....0178	Viewsonic.....1755, 0885, 1330, 1365, 1576,
Proview.....1498, 1687	.....1627, 1640, 1742, 2014, 2087, 2277
Pulsar.....0017	Viore.....1684, 2104, 2352
Quasar.....0250, 0051	Vizio.....1755, 0685
RadioShack.....0000, 0178	Wards.....0001, 0000, 0054, 0017, 0156,
RCA.....1547, 1447, 0000, 0051, 0093,	.....0051, 0060, 0178
.....1661, 1781, 2187, 2247, 2434	Waycon.....0156
Realiste.....0178	Westinghouse.....1712, 0451, 0885, 1217
Runco.....0017	White Westinghouse.....0463, 1661
Sampo.....1755	Wylie.....1365
Samsung.....0812, 0900, 0702,	Zenith.....0001, 1423, 0000, 0017,
.....0178, 1060, 2051	.....0463, 0178, 0145, 1661, 1365
Sansui.....0463, 0171, 1670, 1892, 1935	



### OARH01B 1-Device Universal Remote Control User's Guide

Congratulations on your purchase of the OARH01B. This 1-Device Remote Control does just what a basic remote should: simplify! Made for streamlined 1-device TV, this remote is the ultimate in de-cluttering, leaving you just the buttons you need and none of the ones you don't. Like all One For All remotes, this 1-Device Remote is easy to program, with support for over 210 brands\* of TVs.

\*May not operate all models of all brands.

### OARH01B Guía del Usuario del Control Remoto Universal para 1 Aparato

Felicitaciones por la compra del OARH01B. Este Control Remoto para 1 Aparato hace justo lo que un control remoto básico debería hacer: ¡simplificar! Fabricado para configuraciones de 1 TV, este control remoto es lo más avanzado en sencillez, dejándole sólo los botones que usted necesita y ninguno de los que usted no requiere. Y con señales táctiles en las teclas de volumen y canal, todo lo que precisa es un toque para saber lo que está haciendo. Como todos los controles remotos One for All, este control remoto para 1 aparato es fácil de programar, con soporte para más de 210 marcas\* de TVs.

\*Puede no funcionar en todos los modelos de todas las marcas.