







**MANUAL DE INSTRUCCIONES
TELÉFONO CELULAR C/TV
CEL-4344TV**



ESTIMADO CLIENTE

Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia. Si necesita soporte adicional, no dude en escribir a: info@premiermundo.com



	PRECAUCIÓN RIESGO DE CHOQUE ELÉCTRICO , NO ABRA	
<p>Precaución: Para reducir el riesgo de choque eléctrico, no retire la cubierta, no hay partes manipulables por el usuario al interior de la unidad. Refiera todo mantenimiento o intervención técnica a personal técnico calificado.</p>		
	<p>Este símbolo indica la existencia de voltaje peligroso al interior de esta unidad que constituye un riesgo de choque eléctrico.</p>	
	<p>Este símbolo indica que hay importantes instrucciones de operación y mantenimiento en la literatura que acompaña a esta unidad.</p>	

LÍNEAS DE SERVICIO AL CLIENTE PREMIER

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panamá:	300-5185
Sitio Web:	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTA

Nos reservamos el derecho de modificar las especificaciones, características y/u operación de esta unidad sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

ÍNDICE

INTRODUCCIÓN	4
RECOMENDACIONES.....	4
 INSTRUCCIONES DE SEGURIDAD	4
TELÉFONO	5
BATERÍA	5
CARGADOR.....	6
LIMPIEZA Y MANTENIMIENTO.....	6
ESPECIFICACIONES	6
DESCRIPCIÓN	7
ICONOS EN LA PANTALLA.....	7
BOTONES	8
INSTALACIÓN DE LA TARJETA SIM Y LA TARJETA DE MEMORIA.....	8
TARJETA SIM	8
TARJETA DE MEMORIA.....	8
BATERÍA.....	9
INSTALAR LA BATERÍA	9
CARGAR	9
GUÍA DE USUARIO	9
FUNCIONES.....	9
TECLADO DE ACCESO DIRECTO	10
LLAMAR	10
RECHAZAR UNA LLAMADA.....	10
RECIBIR UNA LLAMADA.....	10
FINALIZAR UNA LLAMADA	10
SERVICIO DE EMERGENCIA	11
MARCADO RÁPIDO A EXTENSIONES.....	11
REGISTRO DE LLAMADAS.....	11
DESVÍO DE LLAMADAS	11
LLAMADA EN ESPERA	11
RESTRICCIÓN DE LLAMADA	11
APAGAR LA UNIDAD.....	11
MENÚ DE FUNCIONES.....	11
ESTRUCTURA DEL MENÚ DE FUNCIONES	11
CONTACTOS	13
REGISTRO DE LLAMADAS.....	13
MENSAJE.....	14
PERFILES	17
MULTIMEDIA	17
JAVA.....	17
TV	17
CÁMARA	18
VIDEO.....	18
REPRODUCTOR DE AUDIO	19
REPRODUCTOR DE VIDEO	19

RADIO FM	19
IMAGEN.....	20
LECTOR E-BOOK	20
JUEGOS	21
LISTA DE ARCHIVOS	21
HERRAMIENTAS	21
ALARMA	21
BLUETOOTH.....	21
CALENDARIO	22
CALCULADORA.....	22
GRABADORA	22
RELOJ MUNDIAL	22
TEMPORIZADOR.....	22
STK.....	22
INTERNET	22
ENTRADA URL	22
PÁGINA PRINCIPAL	23
FAVORITOS	23
HISTORIAL.....	23
NAVEGAR OFFLINE	23
AJUSTES WAP	23
AJUSTES	24
AJUSTES DE LLAMADAS	24
AJUSTES DEL TELÉFONO	25
AJUSTES DE PANTALLA	25
AJUSTE DE SEGURIDAD.....	25
ADMINISTRADOR DE CONEXIÓN	26
ENTRADA DE TEXTO	26
LETRA	27
NUMERO.....	27
PUNTUACIÓN	27
ACCESORIOS	27
CUIDADO Y MANTENIMIENTO	27
BATERÍA	27
UNIDAD	28
INFORMACIÓN DE SEGURIDAD ADICIONAL	28

INTRODUCCIÓN

Con el fin de que obtenga el mayor desempeño de su teléfono celular, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo.

RECOMENDACIONES

- Si pierde su equipo o es robado póngase en contacto con su compañía de telecomunicación o representante de ventas para hacer el procedimiento de bloqueo pertinente. Este evita que se hagan llamadas desde su equipo.
- Al contactar a su proveedor de servicio de telefonía, es probable que le soliciten el número IMEI de su equipo. Para conocerlo, retire la batería y anote el número que está impreso en el equipo y guárdelo en un lugar seguro.
- Con el fin de evitar un uso inadecuado de su teléfono, tenga en cuenta las siguientes medidas:
- Establezca un código PIN como contraseña y cámbielo de inmediato si llega a ser conocida por otra persona.
- Al estar manejando un automóvil, mantenga el equipo fuera de la vista de otros por seguridad. Lo mejor es llevarlo directamente con usted o asegurado en otra parte no visible.
- Ajuste las restricciones de llamadas personalizadas.

INSTRUCCIONES DE SEGURIDAD

- Apague el equipo en aviones, hospitales u otros lugares donde se restrinja el uso del celular, ya que el mantenerlo encendido puede afectar el funcionamiento de otros equipos externos. Siga las leyes establecidas en su localidad con relación al uso del celular.
- Al conducir un automóvil no utilice el celular directamente ya que su atención debe estar en la conducción para evitar accidentes. Utilice el dispositivo de manos libres según se requiera.
- En áreas de almacenamiento de combustible, químicos o materiales volátiles, también es importante que siga las instrucciones respectivas.
- Utilice únicamente las baterías y accesorios recomendados por el fabricante. El uso de otros elementos puede causar daño a su equipo.
- No utilice el celular en áreas de baja señal o cerca de equipos electrónicos de alta precisión electrónica ya que las ondas de radio pueden causar mal funcionamiento de tales equipos. Se debe tener especial cuidado con dispositivos de ayuda auditiva, marcapasos y otros equipos médicos, detectores de humo, puertas automáticas y controles de instalación automáticos. Para obtener más información sobre los efectos de los celulares en estos equipos, póngase en contacto con su operador de telecomunicaciones.
- El equipo cuenta con una función de encendido automático. Tenga en cuenta el ajuste de esta función para evitar que se encienda en áreas no permitidas en momentos inadecuados.
- No coloque las baterías o el teléfono mismo en hornos microondas o equipos de alta presión, ya que esto puede dar como resultado accidentes como daños en los circuitos o incendio.
- No utilice el celular cerca de fuentes de gases inflamables.
- No exponga el equipo a altas temperaturas, alta humedad o polvo.
- Mantenga el equipo en áreas firmes y estables para evitar que se caiga o se golpee.

TELÉFONO

- No desarme ni modifique el celular en forma alguna.
- Evite que la pantalla LCD sea golpeada ya que puede romperse e incluso salirse el cristal líquido. En un caso extremo, puede ocurrir que caiga cristal líquido en los ojos. Por ninguna razón refriegue sus ojos; limpie con agua y acuda de inmediato a un centro médico.
- En algunos casos muy especiales, es probable que utilizar el celular dentro de algunos automóviles afecte negativamente los equipos electrónicos internos. Para evitar esto, simplemente no utilice el equipo dentro del vehículo. Puede igualmente informarse acerca de la susceptibilidad de los equipos electrónicos del automóvil. Tampoco coloque el celular cerca de la bolsa de aire (air-bag) del conductor.
- No utilice agujas, puntas de esfero u otros objetos puntiagudos en el celular.
- Evite que el teléfono entre en contacto con objetos magnéticos tales como tarjetas magnéticas ya que la radiación del celular puede borrar la información de los discos y tarjetas de pago.
- Guarde los objetos pequeños, lejos del equipo ya que cuando está en uso se vuelve magnético y puede atraer estos objetos.
- Evite que el equipo entre en contacto con el agua o líquidos.
- En la medida de lo posible utilice el teléfono lejos de líneas telefónicas locales, televisores, radios y equipo de oficina automático con el fin de evitar afectar los equipos e el celular mismo.

BATERÍA

- No desarme o modifique la batería en forma alguna ya que pueden presentarse derrames del líquido interno, rompimientos o incendio.
- Cuando la batería cumpla su vida útil, no la deseche en la basura normal. Siga las instrucciones establecidas en su localidad para este tipo de artículos.
- No coloque las baterías en el fuego ya que esto puede hacer que exploten.
- No utilice cables, agujas u objetos de metal para manipular la batería.
- No sude los puntos de contacto de la batería ya que esto puede causar que la batería se derrame, se rompa o genere un incendio.
- Si la batería se sobre-calienta, cambia de color o se distorsiona de forma alguna durante su uso, carga o almacenamiento, detenga su uso y reemplácela de inmediato con una nueva batería.
- Si el líquido de la batería entra en contacto con la piel o la ropa podría causar quemaduras. Utilice agua para enjuagar y acuda a un centro médico de inmediato.
- No permita que la batería se moje ya que esto puede causar un sobre-calentamiento, humo o corrosión.
- No utilice ni coloque la batería en lugares con altas temperaturas o donde llegue como la luz directa del sol, ya que esto puede causar derrame, sobre-calentamiento, mal desempeño y acorta la vida útil de la batería.
- No la cargue por más de 24 horas seguidas.
- Coloque la batería en un lugar ventilado y alejado de los rayos directos del sol.
- La vida útil de una batería es limitada y el tiempo de uso después de cada recarga disminuye según pase el tiempo. Cuando la carga se vuelva inefectiva es momento de reemplazarla.

CARGADOR

- No desarme o modifique el cargador en forma alguna ya que puede causar daños o incendios.
- Utilice el cargador de 220 Voltios. El uso de otros cargadores puede dar como resultado derrame en la batería, daños al teléfono o incendio.
- Tenga precaución en no crear un corto-circuito en el cargador.
- No utilice el cargador si el cable de poder está dañado ya que esto puede crear incendios o choques eléctricos.
- Limpie cualquier suciedad que se presente en el cargador.
- No coloque recipientes con agua cerca del cargador para evitar que salpiquen y causen choques eléctricos.
- Si el cargador entra en contacto con el agua, desconecte de inmediato del tomacorriente.
- No utilice el cargador en el baño o en áreas húmedas.
- No toque el cargador con las manos mojadas.
- No coloque objetos pesados sobre el cable del cargador ni haga cambios de ningún tipo.
- Antes de hacer la limpieza, desconecte el cargador del tomacorriente.
- Al desconectar el cargador, no hale desde el cable sino desde el enchufe.
- No cargue el celular en lugares con suciedad, humedad o con excesiva vibración, televisores, radios o equipos electrónicos.

LIMPIEZA Y MANTENIMIENTO

- El teléfono, la batería y el cargador no son resistentes al agua. Por lo tanto, no los utilice en áreas húmedas ni permita que se mojen con ningún líquido.
- Utilice una prenda seca y suave para hacer la limpieza.
- No utilice alcohol, tiner o benzina u otros solventes ya que dañan el acabado de las partes.
- Un tomacorriente sucio causará contactos electrónicos débiles e incluso la inhabilidad para recargar. Tenga en cuenta esto para limpiar con frecuencia.

ESPECIFICACIONES

Cuerpo principal

Modelo:	CEL-4344TV
Dimensiones (WxHxT)	108 mmx 56mmx 13mm
Peso	100 g (Incluida la batería estándar)

Batería de Litio

Modelo	CEL-4344TV
Voltaje nominal	3.7V
Voltaje de carga limitado	4.2V
Capacidad nominal	650 mAh
Tiempo de modo de espera continuo	120 horas a 180 horas
Tiempo de llamada continuo	2.5 horas a 3.5 horas
	Depende de las condiciones de red




cargador de viaje

Modelo	
Entrada	100-240V, 50/60Hz, 100mA
Salida	DC 5.0V, 500mA

DESCRIPCIÓN

ICONOS EN LA PANTALLA

Icono	Descripción de las funciones
	Fuerza de la señal de red Las rayas significan la fuerza de la señal, entre más rayas mayor señal. Cuando la tarjeta SIM 1s es insertada en la ranura 1, la pantalla mostrará el icono.
	Fuerza de la señal de red Las rayas significan la fuerza de la señal, entre más rayas mayor señal. Cuando la tarjeta SIM 1s es insertada en la ranura 2, la pantalla mostrará el icono.
	Carga de la batería Indica la cantidad de carga de la batería. La pantalla mostrará el icono
	Alarma de encendido / apagado El icono indica que la alarma está activada. Cuando la alarma está desactivada el icono desaparecerá de la pantalla
	Mensajes SMS no leídos Cuando hay mensajes SMS no leídos en el buzón, la pantalla mostrará el icono
	Memoria de mensajes SMS llena Cuando la memoria para los mensajes SMS está llena, el icono aparecerá en la pantalla
	Mensajes MMS no descargados Cuando hay mensajes MMS no descargados en el buzón, la pantalla mostrará el icono
	Llamadas perdidas Cuando hay una llamada perdida, la pantalla mostrará el icono
	Desvío de llamadas en la tarjeta SIM 1 Cuando un desvío de llamadas en la tarjeta SIM 1 es iniciado, el icono aparecerá en la pantalla
	Desvío de llamadas en la tarjeta SIM 2 Cuando un desvío de llamadas en la tarjeta SIM 2 es iniciado, el icono aparecerá en la pantalla
	Desvío de llamadas en ambas tarjetas SIM Cuando el desvío de llamadas es ajustado en ambas tarjetas SIM, el icono aparecerá en la pantalla
	Modo de silencio Cuando el perfil es ajustado en modo de silencio, el icono aparecerá en la pantalla
	Modo vibración Cuando el perfil es ajustado en modo de vibración, el icono aparecerá en la pantalla
	Modo de vibración y timbre Cuando el perfil es ajustado en modo normal, el icono aparecerá en la pantalla.
	Modo de timbre bajo Cuando el perfil es ajustado en modo de timbre bajo, el icono aparecerá en la pantalla
	Audífonos Cuando los audífonos son conectados a la unidad, el icono aparecerá en la pantalla
	Modo de avión Cuando la unidad es ajustada en modo de avión, el icono aparecerá en la pantalla
	Tarjeta de memoria Cuando una tarjeta de memoria es insertada, el icono aparecerá en la pantalla
	Icono WIFI

	Cuando se ha activado el WIFI se ha realizado la conexión exitosamente sin una contraseña, el icono aparecerá en la pantalla
	Icono WIFI Cuando se ha activado el WIFI se ha realizado la conexión exitosamente con una contraseña, el icono aparecerá en la pantalla
	Bluetooth (visible) Cuando el Bluetooth se ha activado y selecciona visible, el icono aparecerá en la pantalla
	Bluetooth (Oculto) Cuando el Bluetooth se ha activado y selecciona oculto, el icono aparecerá en la pantalla

BOTONES

- **Botón de izquierda:** En modo de espera, presione este botón para ingresar al menú de función
- **Botones de navegación:** en otras interfaces, es igual a los botones de navegación y dirección, excepto por funciones especiales
- **Botón de encendido / apagado:** presione y sostenga este botón para apagar y encender la unidad.

INSTALACIÓN DE LA TARJETA SIM Y LA TARJETA DE MEMORIA

TARJETA SIM

Antes de usar el teléfono, inserte la tarjeta SIM (Subscriber Identity Module) en la ranura.

Toda la información relacionada con la conexión de red esta grabada en el chip de la tarjeta SIM, también los nombres, números de teléfono y mensajes SMS que están almacenados en los contactos de la tarjeta SIM. Puede retirar la tarjeta SIM de su teléfono e insertarla en cualquier teléfono móvil GSM (Teléfonos móviles nuevos pueden leer la tarjeta SIM automáticamente)

Con el fin de evitar pérdida de información guardada en la tarjeta SIM, no toque la superficie de contacto de metal, y coloque la tarjeta SIM en un lugar alejado de la electricidad y fuerzas magnéticas. Una vez la tarjeta SIM ha sido dañada, usted no podrá usar el teléfono normalmente.

Nota: asegúrese de apagar la unidad antes de retirar la tarjeta SIM. No retire o inserte la tarjeta SIM con la unidad conectada a la fuente de potencia externa, ya que esto puede dañar la tarjeta SIM o la unidad.

INSERTAR O RETIRAR LA TARJETA SIM

La superficie de contacto de metal de la tarjeta SIM puede rayarse con facilidad, por ende, retírela e insértela con mucha precaución.

- Apague la unidad, remueva la cubierta posterior, batería u otra fuente de potencia externa.
- Inserte la tarjeta SIM en la ranura con precaución
- Cuando retire la tarjeta SIM, hálala directamente hacia fuera y luego retírela.

Nota: Si inserta solo una tarjeta SIM, tal vez algunas opciones del menú no serán mostradas.

TARJETA DE MEMORIA

Retire la cubierta posterior y la batería, de acuerdo a la recomendación dada en la ranura de tarjeta de memoria, presione la ranura usando el dedo, y luego mueva en la dirección de OPEN, abra la ranura de la tarjeta de memoria, coloque la tarjeta en el compartimiento y cierre la cubierta.

Nota: Si la tarjeta de memoria no funciona correctamente, asegúrese que esta se encuentra correctamente instalada.

BATERÍA

INSTALAR LA BATERÍA

- Retire la cubierta posterior de la unidad
- Haga que el extremo metálico de la batería coincida con el conector de la batería
- Luego, presione la batería suavemente hacia abajo usando el dedo y luego presione el otro extremo para instalar la batería.

Nota: siga las indicaciones correctamente para evitar dañar el conector de la batería.

CARGAR

Inserte el conector del cargador en la unidad y luego al tomacorriente.

Cuando el icono que aparece en la pantalla de la unidad se detenga, esto significa que la batería esta completamente cargada y puede desconectarla.

Cuando la carga de la unidad se ha agotado completamente, esta se pagara automáticamente.

No deje la unidad descargada por mucho tiempo ya que esto puede dañar la batería o acortar la vida útil de la misma. Así mismo, evite carga la batería por periodos de tiempo prolongados.

Nota: Con el fin de asegurar una operación normal de la unidad, use el cargador que ha sido diseñado para esta unidad.

- **PIN (Personal Identification Number)**

Es usado para prevenir que su tarjeta SIM sea usada ilegalmente. El numero PIN es generalmente suministrado con la tarjeta SIM. Si ingresa el numero PIN de manera incorrecta al menos 3 veces, es necesario que ingrese el PUK para desbloquearla. Contacte a su operador de red para mas información.

- **PIN 2**

Necesita ingresar el PIN2 cuando ingrese a algunas funciones (Tales como llamadas de cobro); si ingresa el PIN2 de manera incorrecta 3 veces seguidas, es necesario que ingrese el PUK2 para desbloquearla. Contacte a su operador de red para mas información.

- **PUK (Personal Unlock Key)**

Al cambiar el PIN bloqueado, debe ingresar el PUK. El PUK es suministrado con la tarjeta SIM. Si este no es suministrado, contacte a su operador de red. Si el PUK es ingresado de manera incorrecta 10 veces seguidas, la tarjeta SIM no podrá ser usada de nuevo. El numero PUK no puede ser cambiado, si pierde el numero, contacte a su operador de red.

- **PUK2**

Cuando cambie el PIN2 bloqueado, necesita ingresar el PUK2. Si el PUK2 es ingresado de manera incorrecta 10 veces seguidas, no podrá usar las funciones que necesitan el PIN2. El numero PUK2 no puede ser cambiado, si pierde el numero, contacte a su operador de red.

GUÍA DE USUARIO

FUNCIONES


- Contactos: Cada contacto guardado en el teléfono puede ser relacionado con varios números de teléfono, pueden ser enviados mensajes SMS y MMS, y puede copiar el registro de contactos entre la tarjeta SIM y el teléfono.
- Perfiles: Le permite ajustar el timbre de acuerdo a los diferentes eventos ó al entorno.
- Registro de llamadas: la unidad almacena los registros de llamada automáticamente.
- Mensaje: la unidad soporta hasta 200 mensajes SMS. La capacidad máxima de cada mensaje MMS debe ser de 100Kb.

- Multimedia: la unidad suministra todos los servicios de entretenimiento incluyendo reproductor, cámara, administrador de archivos, grabación, E-book y otras funciones.
- Cámara: la unidad soporta la función de cámara y video.
- Juego: La unidad soporta la función de juegos
- Servicios de red: la unidad soporta servicio WAP.
- Herramientas: la unidad soporta bluetooth, alarma, calendario, calculadora, reloj mundial, cronometro y otras funciones.
- Configuración del sistema: puede ajustar las opciones de la unidad de acuerdo a sus necesidades, incluyendo el ajuste del teléfono, el ajuste de pantalla, ajustes de llamadas, ajustes de seguridad y otras funciones.
- Método de entrada: la unidad soporta varios modos de entrada; Ingles, letras, números, símbolos, etc.

TECLADO DE ACCESO DIRECTO

Función	Tecla de acceso directo	Descripción del status
Encender	Presione y sostenga la tecla de encender y apagar	Modo de apagado
Apagar	Presione y sostenga la tecla de encender y apagar	Modo de encendido
Ingresar a la lista de funciones	Presione el botón de izquierda	Modo de espera
Ingresar al registro de llamadas	Presione el botón de llamar	Modo de espera

LLAMAR

Ingrese el numero telefónico al cual desea llamar usando los botones numéricos de la unidad y luego presione el botón  para realizar la llamada. Durante la llamada puede acceder a las siguientes funciones:

- Llamada con manos libres
- Manos libres / Bluetooth: Puede conectar un audífono con Bluetooth para usar esta función
- Cambiar: sostener una llamada, cambie nuevamente para llamar normalmente
 - Contactos
 - Mensaje
 - Registro de llamadas
 - silenciar

RECHAZAR UNA LLAMADA

Presione el botón “END” para rechazar una llamada

RECIBIR UNA LLAMADA

Presione el botón izquierdo para recibir la llamada

FINALIZAR UNA LLAMADA

Después de finalizar la llamada, puede presionar el botón “END” para finalizar la llamada

SERVICIO DE EMERGENCIA

Puede marcar a un número de emergencia sin tener una tarjeta SIM en la unidad.

Los números de emergencia varían de acuerdo a las diferentes redes, contacte a su operador de red para más información.

MARCADO RÁPIDO A EXTENSIONES

Después de ingresar el número telefónico, si desea ingresar un número de extensión, presione y sostenga el botón “*” e ingrese el número de extensión después de que la pantalla le indique “P”. Después de realizar la llamada, la unidad marcará directamente al número de extensión.

REGISTRO DE LLAMADAS

Puede ingresar al registro de llamadas y revisar las llamadas marcadas, recibidas, perdidas, rechazadas.

DESVÍO DE LLAMADAS

Después de activar esta función, puede seleccionar enviar la llamada al buzón de voz o a otro número telefónico.

LLAMADA EN ESPERA

Después de activar la función, cuando este llamando, la otra llamada puede ser puesta en espera.

RESTRICCIÓN DE LLAMADA

Una vez activada esta función, puede restringir las llamadas bajo las condiciones correspondientes (Contacte a su proveedor de red para más información)

APAGAR LA UNIDAD

En modo de espera, presione y sostenga el botón de colgar para apagar la unidad

MENÚ DE FUNCIONES

ESTRUCTURA DEL MENÚ DE FUNCIONES

1. Contactos

- Nuevo
- Buscar
- Escribir mensaje
- Marcar
- Enviar Vcard
- Borrar
- Marcar
- Copiar
- Copiar todo
- Otros

2. Registro de llamadas

- Marcadas
- Recibidas
- Perdidas
- Rechazadas

- Borrar todo
- Temporizador de las llamadas
- Costo de las llamadas
- Volumen GPRS
- 3. Mensajes
 - Escribir mensaje
 - Buzón
 - Buzón de salida
 - Borrador
 - Enviados
 - Plantillas
 - Zona de difusión
 - Buzón de voz
 - Ajustes de SMS
 - Ajustes de MMS
 - Capacidad de mensajes
- 4. Perfiles
 - Estándar
 - Silencio
 - Vibración
 - Timbre bajo
 - Timbre alto y vibración
- 5. Multimedia
 - Java
 - TV
 - Cámara
 - Video
 - Reproductor de audio
 - Reproductor de video
 - Radio FM
 - Navegador de imagen
 - Lector E-Book
 - Juegos
 - Lista de archivo
- 6. Herramientas
 - Alarma
 - Bluetooth
 - Calendario
 - Calculadora
 - Grabador
 - Reloj mundial
 - Temporizador STK
- 7. Internet
 - Entrada URL
 - Pagina principal
 - Favoritos

 - Historial

- Offline
 - Ajustes WAP
8. Ajustes
- Ajustes de llamada
 - Ajustes del teléfono
 - Ajustes de pantalla
 - Ajustes de seguridad
 - Administrador de conexión

CONTACTOS

Con esta función puede guardar, editar y borrar los nombres y teléfonos en el teléfono y en la tarjeta SIM. Para facilitar la administración de los registros, esta unidad le permite guardar sus contactos por grupos. La capacidad de almacenamiento de la tarjeta SIM varía.

Elija las opciones en la lista del registro de contactos para la siguiente operación:

- Nuevo: Crear nuevos contactos en la tarjeta SIM o en la unidad
 - Buscar: buscar los registros almacenados en la tarjeta SIM o en la unidad
 - Escribir mensaje: escribir mensaje o mensaje multimedia a este registro
 - Marcar: Marcar a este registro directamente o por medio de llamadas IP.
 - Enviar Vcard: enviar este registro a otros a través de SMS ó Bluetooth
 - Borrar: borrar este registro
 - Marcar: elegir un registro o todos los registros
 - Copiar: copiar el registro las tarjetas SIM o a la tarjeta de memoria
 - Copiar todo: copiar todos los registros a la tarjeta SIM o a la tarjeta de memoria
 - Otros
1. Ajustes de marcación rápida: ajuste este registro en una tecla de marcación rápida. Después de ajustarlo, presione y sostenga el botón en el cual fue ajustado el registro y podrá marcar al número telefónico directamente.

Nota:

- En modo de espera, presione y sostenga el botón numérico 1 e ingresará al buzón de voz de la tarjeta SIM 1
- En modo de espera, presione y sostenga el botón numérico 2 e ingresará al buzón de voz de la tarjeta SIM 2

REGISTRO DE LLAMADAS

Muestra las llamadas recientes

• Llamadas realizadas

Muestra la lista de los números recientes marcados

Opciones:

- Detalles
- Llamar
- Guardar
- Mensaje enviado
- Añadir a nombre existente
- Ajustar como llamada rechazada
- Marcación IP

- Borrar
- Borrar todo

- **Recibidas**

Muestra la lista de llamadas recientes recibidas. La operación es igual a la sección de **Llamadas realizadas**.

- **Perdidas**

Muestra la lista de llamadas recientes perdidas. La operación es igual a la sección de **Llamadas realizadas**.

- **Rechazadas**

Muestra la lista de llamadas recientes rechazadas. La operación es igual a la sección de **Llamadas realizadas**.

- **Borrar todo**

- **Temporizador de llamadas**

- **Costo de llamadas**

(esta función debe ser soportada por el operador de red. Contacte a su operador de red para activar la contraseña)

- **Volumen GPRS**

Revise el volumen GPRS de la tarjeta SIM1 y SIM2 y elija la opción "Zeroing" y el flujo será cero.

MENSAJE

Escribir mensaje

- Crear mensaje SMS: puede escribir un nuevo mensaje usando esta función.

Opciones:

- Enviar
- Insertar Plantilla
- Añadir información de contacto
- Añadir símbolo
- Guardar

- Crear mensajes MMS: puede editar mensajes MMS, e insertar imágenes ó tonos con esta función. Seleccione "Crear MMS" y elija una las siguientes opciones para editar el mensaje.

Opciones:

- Enviar
- Recibir
- Reenviar
- Receptor confidencial
- Editar título
- Editar contenido
- Vista previa
- Guardar
- Establecer tiempo de enviado

Buzón

Guarda mensajes SMS, MMS y mensajes "Push" que haya recibido. Los anteriores mensajes pueden ser diferenciados por diferentes iconos.

Seleccione un SMS ó MMS y elija las opciones:

- Responder
- Borrar

- Llamar
- Bloquear / Desbloquear
- Marcar
- Ordenar

Buzón de salida

Guarda los mensajes SMS y MMS que no pudieron ser enviados. Los anteriores mensajes pueden ser diferenciados por diferentes iconos.

Seleccione SMS ó MMS y elija las opciones:

- Enviar
- Borrar
- Bloquear / Desbloquear
- Marcar
- Ordenar

Borradores

Guarda los mensajes SMS y MMS que ha editado. Los anteriores mensajes pueden ser diferenciados por diferentes iconos.

Seleccione SMS ó MMS y elija las opciones:

- Borrar
- Editar
- Bloquear / Desbloquear
- Marcar
- Ordenar

Buzón de enviados

Guarda los mensajes SMS y MMS que fueron enviado exitosamente. Los anteriores mensajes pueden ser diferenciados por diferentes iconos.

Seleccione SMS ó MMS y elija las opciones:

- Borrar
- Reenviar
- Bloquear / Desbloquear
- Marcar
- Ordenar

Ajuste de las plantillas

Puede editar o borrar las plantillas

Buzón de voz

Esta unidad soporta la función de buzón de voz. Puede elegir entre SIM1 y SIM2.

Cuando recibe la llamada de otras personas, esta pueden dejarle mensajes de voz en el buzón de voz. Bajo esta interfaz, puede editar y ajustar el numero de la línea 1, línea 2 fax ó datos.

- Escuchar el mensaje: marque el numero del buzón de voz y escuche los mensajes
- Ajuste del número: edite el numero del buzón de voz

Nota: Para mas información acerca del la función de buzón de voz, contacte a su operador de voz

Zona de difusión

El servicio de difusión del área envía diferentes tipos de mensajes. Cambie la configuración de este servicio y consulte la información de la zona mediante el uso de esta función.

Opciones:

- Leer: Leer los mensajes recibidos
- Iniciar difusión: Elegir entre iniciar / finalizar difusión
- Ajuste de canal: ajuste el canal receptor del mensaje del área
 Añadir el canal: Agregue el buzón del canal y el nombre del canal
 Lista de canales: muestra la lista de canales
- Ajuste de idioma

Ajuste de SMS

Opciones:

- Centro de servicio SIM1: Muestra el numero del centro de servicio de SMS en SIM1
- Centro de servicio SIM2: Muestra el numero del centro de servicio de SMS en SIM1
- Periodo de validez: Puede ajustar el periodo de validez del mensaje; por 1 hora, 6 horas, 24 horas, 72 horas, 1 semana y el valor máximo

Nota: este tiempo esta relacionado con el servicio del operador de red

- Informe de entrega: Si ha activado esta función, después de haber enviado el mensaje, el centro de servicio le enviara un informe de entrega, con el fin de informarle que el mensaje fue enviado exitosamente.
- Guardar mensaje enviado: hay tres opciones:
 - “Sugerir elección”: antes de enviar el mensaje, podrá elegir entre Enviar y guardar ó Solo enviar
 - “Guardar”: Guarda automáticamente los mensajes enviados
 - “No guardar”: No guarda automáticamente los mensajes enviados
- posición de almacenamiento preferencial: Puede elegir entre guardar en la tarjeta SIM o en el teléfono

Ajustes MMS

Opciones:

- Cuenta MMS: Puede elegir entre ajustar la cuenta MMS de SIM1 ó SIM2 con el fin de recibir los mensajes MMS correctamente
- Aplicar para informe de entrega: cuando esta función esta activada, después de enviar un mensaje MMS, recibirá un informe de entrega
- Enviar informe de lectura: cuando esta función esta activada, después que el receptor lee el mensaje MMS, se le preguntará si desea enviar el informe de lectura o no.
- Enviar anónimamente: después de activar esta función, después que el receptor ha leído el mensaje MMS, el nombre y numero del remitente será escondido. Esta función requiere un soporte de red
- Prioridad: ajuste la prioridad del mensaje MMS: Alta, Común, Baja
- Recibir MMS: Recepción manual, Recepción automática.
- Sonido de reproducción: cuando esta función esta activada, mientras visualiza los mensajes MMS, el sonido se reproducirá automáticamente.
- Aceptar publicidad: cuando esta función esta activada los avisos en MMS serán permitidos.
- Periodo de validez: ajuste el periodo de validez del MMS: 12 horas, 1 día, 1 semana y periodo máximo

Nota: este tiempo esta relacionado con los servicios del operador de red

- Regresar a los valores de fabrica

Capacidad

Puede visualizar la capacidad de los mensajes SMS, MMS, WAP “Push” y OTA

PERFILES

Puede ajustar diferentes perfiles

Estándar / Silencio / Vibración / Timbre bajo / Timbre alto y Vibración

Puede activar, definir ó renombrar cada modo

- Ajustes del “ringtone”

Opciones:

- “Ringtone” de SIM1
- “Ringtone” de SIM2
- Tono de mensaje de SIM1
- Tono de mensaje de SIM2

- Volumen del “Ringtone”

Opciones:

- Volumen del “Ringtone” para llamadas entrantes
- Volumen de la alerta del mensaje
- Volumen de llamada
- Volumen del sonido de las teclas
- Volumen de la alarma
- Volumen de encendido / apagado

MULTIMEDIA

JAVA

- Administración de la aplicación

Puede conocer que juegos tiene instalados desde la lista de juegos de JAVA. Puede reproducir ó borrar el juego JAVA o visualizar los detalles.

Opciones:

- Reproducir
- Detalles
- Borrar

Nota: los juegos preestablecidos de JAVA no pueden ser borrados

- Instalación local

Directamente en el administrador de archivos, seleccione el archivo de juego de la instalación JAVA

- Descargar

Después de ingresar al sitio web correcto, puede descargar variedad de aplicaciones JAVA a través del servicio WAP, pero antes de descargarlas debe asegurarse que el software de la aplicación es compatible con la unidad.

- Ajustes de conexión

Configure el juego JAVA disponible, cuenta de JAVA de tarjeta SIM.

TV

Ingresa a la interfaz de TV, puede elegir búsqueda local y cambiar los canales presionando los botones de izquierda y derecha. Presione los botones de arriba y abajo para ajustar el volumen.

En el interfaz de reproducción de TV, presione el botón OK para cambiar entre pantalla completa y media pantalla. Presione el botón de izquierda, para ir a las siguientes operaciones:

- Nación o región: puede ajustar diferentes países o regiones

- Remover ruido: cuando esta función esta encendida, los puntos de ruido se disminuyen, sin embargo la calidad de imagen disminuirá.
- Buscar el canal: ingrese al interfaz de búsqueda de canal

CÁMARA

Puede visualizar fotos en la pantalla y tomar fotos.

En el interfaz de visualización de fotos, elija la pantalla para ingresar a los ajustes del menú

- Modo de toma de foto: puede cambiar entre cámara y captura de video
- Tamaño
- Modos de medio ambiente: normal y Noche
- Brillo
- Nivel de contraste
- Compensación de exposición
- Balance de blancos
- Auto-temporizador: 3S y 10S
- Efectos especiales: Normal, blanco y negro, rojo, verde, azul, amarillo, reminiscente y negativo

En el interfaz de visualización de fotos, elija opciones para ingresar a las siguientes opciones del menú:

- Administrador de visualización de fotos
- Ajustes:
- Calidad de imagen
- Evitar el brillo
- Sonido del obturador
- Lugar de almacenamiento preferencial
- Guardar automáticamente
- Parámetro de foto
- Ayuda

Nota: No use la cámara de la unidad en lugares en los que no este permitido.

VIDEO

En modo de video elija la pantalla para ingresar al menú de video:

- Modo de toma de foto
- Tamaño
- Brillo
- Nivel de contraste
- Efecto especial

En el interfaz de visualización de cámara elija opciones para ingresar a las opciones del menú:

- Administrador de visualización de video
- Ajustes:
- Evitar el brillo

- Audio
- Formato de imagen
- Parámetros de video
- Ayuda

En modo de captura de video, después de la toma, puede seguir las siguientes opciones:

- Capturar un nuevo video

- Borrar
- Enviar
- Reproducir
- Administrador de visualización de video

REPRODUCTOR DE AUDIO

La unidad puede reproducir MPS almacenados en la tarjeta de memoria y soporta reproducción de música de fondo.

En la interfaz de reproducción de audio, use las siguientes teclas para operar rápidamente las funciones MP3:

- Presione ► Para reproducir MP3;
- Presione ||| Para pausar;
- Presione ■ Para detener la reproducción;

En el interfaz de lista MP3, elija el icono de opciones en la esquina superior derecha, luego puede elegir las siguientes opciones:

- Abrir: ingrese la tarjeta de memoria y abra los archivos MP3 guardados
- Reproducir lista de reproducción
- Lista de reproducción
- Ajustar como "Ringtone"
- Ajustes de ecualización: Clásico, Concierto, Jazz, Rock ó Rock suave
- Ajustes

En el interfaz de la lista de reproducción, elija las opciones, luego puede elegir las siguientes opciones:

- Reproducir
- Añadir nuevo MP3
- Borrar de la lista de reproducción
- Guardar lista
- Borrar reproducción actual

Nota: en el interfaz principal de "Reproducción MP3" elija regresar, el estado de difusión de fondo permanecerá.

REPRODUCTOR DE VIDEO

La unidad soporta el formato de video de 3GP y MP4, AVI. No soporta DIV XAVI

- Ingrese al interfaz de lista de reproducción de video, presione el botón izquierdo, para ir a las siguientes opciones:
lista de reproducción
- Reproducción en pantalla completa
- Orden de reproducción
- Atributo del archivo: Detalles del video, nombre, fecha, tiempo, relación de resolución, lapso de tiempo, tamaño, etc.

Nota: la resolución máxima soportada por esta unidad es de 320x240

RADIO FM

Puede escuchar radio FM en esta unidad. Ingrese a la interfaz de radio y ajuste la frecuencia con los botones de dirección.

En la interfaz de reproductor de radio, elija las opciones para ingresar al menú de opciones y elegir las siguientes opciones:

- Buscar automáticamente y guardar
- Emisora: Puede ver todas las emisoras guardadas
- Guardar
- Sintonización manual

Nota: cuando la batería de su celular es insuficiente, la unidad no permite ingresar a la frecuencia de radio y TV.

IMAGEN

Puede visualizar las imágenes guardadas en la tarjeta de memoria y editarlas libremente. En el interfaz de lista de imagen, puede elegir una de las siguientes opciones:

- Cambiar carpeta
- Enviar
- Diapositivas
- Borrar
- Ajustar como fondo de pantalla
- Renombrar
- Marcar
- Detalles
- Ajustes de diapositivas

LECTOR E-BOOK

Puede escoger leer E-book con formato txt con el AID de esta función

En el interfaz de la lista E-Book, puede elegir una de las siguientes opciones:

- Detalles
- Lectura reciente
- Enviar vía bluetooth
- Borrar
- Marcar
- Ajustes

En la pagina “Leer E-Book”, elija una opción, luego puede hacer lo siguiente:

- Añadir a favoritos
- Saltar a la pagina frontal
- Saltar a la pagina anterior de E-Book
- Saltar la pagina
- Encender / Apagar luz de fondo siempre activa

Siga la siguiente introducción para las funciones E-Book:

1. Función “Pagina Arriba/Abajo” es definido por los botones de derecha e izquierda. Cada “Pagina Arriba / Abajo” se mostrara en la primera línea de la pagina.
2. Cuando los usuarios se retiran de la función, el procedimiento memorizara la pagina existente.

JUEGOS

Opciones:

- Nuevo juego
- Continuar
- Elegir nivel

LISTA DE ARCHIVOS

Puede revisar los contenidos específicos y condiciones de servicio de la tarjeta de memoria a través de esta función. Mientras tanto, puede formatear la memoria también.

Elija una carpeta y una opción, luego puede realizar las siguientes operaciones:

1. Crear nueva carpeta
2. Borrar
3. Detalles: Revisar los detalles del folder, nombre, fecha, tamaño, posición, etc.
4. Editar: Renombrar o copiar la carpeta
5. Buscar: buscar el archivo en el folder
6. Ordenar: ordenar de acuerdo al nombre, fecha, tamaño y tipo
7. Marcar: marcar una o todas las carpetas en la tarjeta de memoria
8. Mas visualización de la condición de servicio de la tarjeta. En esta interfaz puede formatear la tarjeta de memoria eligiendo "Formatear", pero esta operación causara que el archivo se borre definitivamente.

HERRAMIENTAS

ALARMA

Puede editar la alarma, tiempo, timbre y el modo de repetición de timbre

En el modo de edición de alarma, elija los ajustes con los botones de dirección y confirme con el botón OK. Luego, seleccione los ajustes deseados.

BLUETOOTH

- Puede elegir entre activar o desactivar el bluetooth
- Puede elegir si desea que su dispositivo este visible o invisible ante otros dispositivos.
- Puede buscar diferentes equipos bluetooth y encontrar equipos compatibles (Siempre y cuando los números PIN de ambos equipos sean iguales, la compatibilidad sea un éxito. El código PIN del audífono inalámbrico es diferente gracias a que el tipo de dispositivo es diferente, y usted puede encontrar el código en el manual de operaciones del audífono bluetooth)
- Ajustes de archivos compartidos:
 - Derechos del directorio compartido: puede elegir entre "Acceso libre" y "Solo lectura".
 - Seleccionar directorio: puede seleccionar la carpeta que desee que reciba los archivos vía bluetooth en la tarjeta de memoria
- Nombre de teléfono
- Puede cambiar el nombre del teléfono
- Ayuda

CALENDARIO

Opciones:

- Configurar calendario
- Revisar recordatorio de calendario
- Todos los recordatorios de calendario
- Borrar recordatorio de calendario
- Borrar todos los recordatorios
- Consultar fecha
- Recordatorio semanal

CALCULADORA

Esta unidad tiene la función de calculadora, para que la pueda usar en cualquier momento y lugar.

GRABADORA

Con esta función puede grabar y escuchar su propia grabación. El formato de grabación es WAV

Opciones:

- Iniciar grabación
- Lista de grabaciones

Durante el proceso de grabación puede elegir si desea pausar ó detener si desea detener la grabación.

Opciones:

- Audición
- Borrar
- Enviar
- Lista de grabaciones

Nota: el registro de llamadas es guardado en la lista de grabaciones

RELOJ MUNDIAL

Con esta función puede ver la hora de diferentes lugares. Si viaja a otro lugar con diferente zona horaria, puede ajustar la hora de ese lugar en la unidad

TEMPORIZADOR

Puede ajustar el temporizador, y este le recordara cuando el tiempo ha finalizado

STK

Ingrese al submenú STK, puede usar servicios adicionales que sean suministrados por su operador de red.

INTERNET

La unidad es compatible con servicio WAP. Puede visitar varios servicios WAP para las noticias, clima, aerolíneas, etc. El servicio esta diseñado especialmente para el dispositivo y es mantenido por el proveedor de servicios WAP.

Consulte a su proveedor de red para mas información

ENTRADA URL

PÁGINA PRINCIPAL

FAVORITOS

Ingresando a la pagina de favoritos, puede agregar mas favoritos. Puede además realizar las siguientes operaciones con los favoritos:

- Inicio: visita las paginas web que están marcadas como favoritas
- Visualización: visualiza los sitios favoritos
- Editar: le permite editar los sitios web y los nombres de los favoritos
- Borrar
- Borrar todo

HISTORIAL

Graba los sitios web que usted visito. Puede además realizar las siguientes operaciones con el historial

- Inicio: visita las paginas web que están marcadas como favoritas
- Visualización: visualiza los sitios favoritos
- Borrar
- Borrar todo

NAVEGAR OFFLINE

Puede navegar por los sitios web sin conexión

AJUSTES WAP

- Ajustes del navegador:
 - Borrar archivos temporalmente: Borra temporalmente los archivos que visito
 - Cuanta de internet: Ajuste su cuenta de internet de la tarjeta SIM1 ó SIM2 con el fin de visitar internet correctamente
 - Descargar imágenes: puede activar o desactivar esta función
 - Reproducción de tono de fondo: puede activar o desactivar esta función
- Posición de almacenamiento preferencial: puede ajustar la posición de almacenamiento de los archivos que descarga vía WAP
- Ajustes GPRS
- Cuenta de internet: puede editar su cuenta de internet con esta función

introducción de los iconos

icono



Función

Ingresar a la pagina principal WAP



Refrescar la pagina



Detener de refrescar la pagina



Regresar a la pagina anterior



Ir a la siguiente pagina



Agregar a favoritos



Navegación offline, navegar las fotos guardadas



Revisar historial

Guardar documento, foto, imagen y musica

Regresar a pagina WAP

AJUSTES

AJUSTES DE LLAMADAS

- Ajuste de la tarjeta SIM1 y SIM2 del teléfono
 - Modo de espera
 - Ajustar la tarjeta SIM 1/2: Puede ajustar una tarjeta SIM como tarjeta preestablecida ó que la unidad le pregunte que tarjeta SIM desea usar cada vez que vaya a realizar una operación.
 - Ajustar el nombre de la ranura: Puede elegir el nombre de su preferencia como nombre de la ranura de la tarjeta SIM.
- Selección de red: cuando la unidad tiene la función de “roaming”, la red puede seleccionar la red automáticamente o manualmente. Este servicio solo puede ser usado cuando esta suscrito. Contacte a su operador de red para mas información.
 - Selección automática: seleccionando esta función el teléfono buscara automáticamente la red. La operación tendrá la unidad registrada independientemente con la red mas apropiada.
 - Selección manual: eligiendo esta función, el teléfono buscara las redes disponibles y seleccione la red compatible desde la lista de red.
- Desvío de llamadas: cuando esta función esta activada, puede transferir las llamadas entrantes al buzón de voz o a otro numero de acuerdo a las condiciones de desvío de llamadas programadas.
 - Desvío de llamadas incondicional: todas las llamadas entrantes serán transferidas al buzón de voz o a otro numero de acuerdo al ajuste realizado
 - Desvío de llamadas cuando este usando la unidad: cuando usted esta usando la unidad y hay una llamada entrante, esta será desviada al buzón de voz o a otro numero de acuerdo al ajuste realizado.
 - Desvío de llamadas perdidas: cuando entre una llamada y usted no la pueda contestar, esta será transferida al buzón de voz o a otro numero de acuerdo al ajuste realizado.
 - Desvío de llamadas por fallas: si la unidad esta apagada o esta fuera de área (Sin señal), las llamadas entrantes serán desviadas al buzón de voz ó a otro numero de acuerdo al ajuste realizado.
 - Borrar todos los desvíos de llamadas
- Restricción de llamadas: todas las llamadas salientes, entrantes, llamadas entrantes “roaming”, llamadas salientes internacionales, llamadas internacionales salientes “roaming” están disponibles.

Opciones:

- Todas las entrantes salientes
- Todas las llamadas entrantes
- Llamadas entrantes “roaming”
- Llamadas salientes internacionales
- Llamadas entrantes internacionales “roaming”
- Cancelar toda la restricción de llamadas
- Revisar contraseña de la restricción de llamadas

Nota: las funciones mencionadas anteriormente necesitaran soporte de red. Para usar la función, contacte su proveedor de red.

- Llamada en espera: la función puede ser activada o desactivada. Cuando la función esta activada, aun cuando este haciendo una llamada, puede recibir otra llamada al mismo tiempo
- Ocultar el numero de teléfono: esta función debe ser soportada por la red
- Selección de línea: hay dos líneas que pueden ser seleccionadas: Línea 1 y línea 2. Sin embargo, la función es solo para teléfonos que tienen una tarjeta SIM y dos números. Si su teléfono no es de ese tipo, solo seleccione la línea 1, ya que si elije la línea 2 las llamadas serán limitadas.
- Modo de avión: al usar esta función, todas las demás funciones que necesiten una conexión a la red, como por ejemplo SMS, MMS, llamadas, red WAP no estarán disponibles
- Otros:
 - IP todo en uno: puede seleccionar diferentes números IP o revisar el numero IP
 - Tono recordatorio de conexión de llamada: cuando la función esta activada, cada vez que una llamada es conectada, el sonido recordatorio puede ser escuchado.
 - Responder / Rechazar una llamada:
 - Responder SMS al rechazar una llamada: cuando una llamada entrante es rechazada, un recordatorio "Responder SMS" aparecerá.
 - Cualquier tecla contesta: cuando esta función esta activada, puede contestar las llamadas presionando cualquier tecla.
- Remarcado automático: cuando esta función esta activada y una llamada falla, esta se remarcara automáticamente.

AJUSTES DEL TELÉFONO

Opciones:

- Fecha y hora
- Idioma
- Encender / Apagar automáticamente
- Administración de energía
- Regresar a los valores de fabrica: la clave pre ajustada es 1234
- Inducción de orientación: Puede activar o desactivar el fondo de pantalla, cambiar el sonido y efectos de sonido.

AJUSTES DE PANTALLA

Opciones:

- Ajustes de fondo de pantalla
- Tema
- Luz de fondo
- Presionar la tecla de fondo de pantalla

Nota: cuando el modo nocturno esta activado, la luz del teclado no se encenderá de 6:00 am a 6:00pm

AJUSTE DE SEGURIDAD

- Código PIN: puede activar, desactivar o modificar el código PIN. Si la verificación del código PIN esta activada, tendrá que ingresarlo cada vez que encienda la unidad.

Si el numero PIN es ingresado tres veces seguidas de manera incorrecta, la tarjeta se bloqueara y deberá ingresar el código PUK para desbloquearla. Contacte a su operador de red para obtener la clave del código PUK de ser necesario.

La contraseña predeterminada del código PIN es 1234

- Código PIN2: Puede visualizar el código PIN2. Para detalles, contacte a su operador de red
- Protección de privacidad: la contraseña puede ser activada para algunos menús, de igual forma, necesitara ingresar la contraseña cada vez que desee ingresar a los menús.
- Bloqueo del teclado automático: cuando la unidad este en cualquier modo y no sea usada algún tiempo, el teclado se bloqueara de manera automática
- Oscurecer la pantalla con el botón rojo: si la función esta activada, presione el botón rojo en el interfaz de modo de espera y la pantalla ingresara al estado de luz de fondo y el teclado se bloqueara.
- Contraseña del teléfono: cuando la contraseña este activada, usted deberá ingresarla cada vez que desee usar el teléfono.
- Función antirrobo: la contraseña para esta función debe ser de 6 dígitos.

Cuando la función “Antirrobo” esta activada, usted puede usar solo su tarjeta SIM. Si una tarjeta SIM diferente es usada, la unidad la revisara automáticamente cuando es encendida, y le solicitara que ingrese la contraseña de protección. Si la contraseña es correcta, puede configurar la tarjeta SIM.

Si ingresa la contraseña tres veces seguidas de manera incorrecta cuando encienda la unidad, esta enviara un mensaje SMS de advertencia a su tarjeta SIM original cada 24 horas si la unidad es apagada, el mensaje será enviado cuando encienda la unidad. El mensaje indicara la existencia de la tarjeta SIM y el numero del vecindario. Cuando 15 mensajes hayan sido enviados el teléfono no podrá seguir siendo usado.

Para garantizar la seguridad de la unidad, recomendamos que active la función antirrobo tan pronto compre la unidad.


Para desactivar la clave de protección deberá ingresar la clave que ajusto anteriormente.

ADMINISTRADOR DE CONEXIÓN



- Cuenta de red
- WIFI
 - Activar o desactivar la red WIFI
 - Lista de redes WIFIOpciones:
 - Buscar: Buscar la red WIFI actual
 - Detalles
 - Editar: Editar el WIFI seleccionado actualmente
 - Nuevo: Crear WIFI
 - Borrar: borrar el WIFI seleccionado actualmente
 - Limpiar: Remover todo del WIFI
 - Ayuda

ENTRADA DE TEXTO


La unidad suministra algunos modos de entrada de texto, por lo tanto puede escribir texto o ingresar datos en sus contactos, editar el registro de contactos, buscar nombres en ingles y escribir SMS y hacer listas.

En modo de “Entrada de texto”, si desea cambiar el método de entrada, presione el botón  + la tecla “Space”, y los iconos de entrada seleccionados serán mostrados en la parte izquierda de la pantalla.

LETRA

Ingrese a la pagina editar, presione el botón  + la tecla “Space” para cambiar el método de entrada a “letra”. Con el teclado, ingrese las letras que aparecen en la pantalla. Presione el botón  para cambiar la letra entre Mayúscula y Minúscula.

NUMERO

Ingrese al modo editar, presione el botón  + la tecla “Space” para cambiar el método de entrada a “numero”. Con el teclado, ingrese los números que aparecen en la pantalla.

PUNTUACIÓN

Ingrese al modo editar. Puede ingresar la puntuación deseada presionando el botón correspondiente,

ACCESORIOS

Puede elegir las siguientes mejoras para la unidad.

- Batería adicional: puede comprar una batería de litio con una capacidad diferente a la suministrada por esta compañía.
- Cargador de viaje
- Audífonos
- Cable USB
- Cargador

Nota: Recuerde que los accesorios deben estar aprobados por el fabricante, para evitar accidentes y daños en la unidad

CUIDADO Y MANTENIMIENTO

BATERÍA

- La unidad usa una batería recargable. Es necesario cargar la batería cuando se este agotando la carga.
- El rendimiento optimo de una batería nueva solo se obtiene cuando esta se encuentra cargada completamente.
- Desconecte el cargador del tomacorriente cuando no este en uso. No deje la batería cargando por periodos de tiempo prolongados, ya que esto puede acortar la vida útil de la batería
- La temperatura puede afectar la carga de la batería. Si la temperatura de la batería excede los 40°C, esta no podrá ser cargada.
- Use la batería solo para el propósitos que ha sido diseñada para evitar cortos circuitos. Pueden ocurrir cortos circuitos accidentales cuando un objeto metálico ocasiona la conexión directa de las terminales negativa (-) y positiva (+) de la batería.
- No use una batería dañada
- Evite dejar la batería en lugares muy fríos o muy calientes, ya que esto puede reducir la vida útil de la misma. Un dispositivo que tenga la batería fría o caliente no podrá funcionar temporalmente, aun cuando la batería este completamente cargada.
- No deposite la batería en fuego ya que esta puede explotar. Deposite la batería siempre siguiendo las normas de su localidad.

UNIDAD

- Mantenga la unidad fuera del alcance de los niños
- Mantenga la unidad seca y evite exponerla a humedad, ya que esto puede corroer los circuitos electrónicos
- No guarde la unidad en áreas calientes. Las altas temperaturas pueden acortar la vida útil de dispositivos electrónicos o derretir algunas partes plásticas
- Evite abrir la unidad, ya que esto puede ocasionar daños en la unidad
- No use agentes químicos o corrosivos para limpiar la unidad
- Use únicamente los accesorio recomendados por el fabricante

INFORMACIÓN DE SEGURIDAD ADICIONAL

al conducir

- No use la unidad mientras este manejando, a menos que haya una emergencia. Use siempre equipos inalámbricos para su seguridad.
- En caso de que no haya una protección adecuada, ciertos sistemas electrónicos del vehículo pueden ser afectados por la honda eléctrica de la unidad.
- Sugerimos usar la unidad solo en vehículos con antena
- Solo personal calificado debe instalar la unidad en un vehículo

En aviones

- Apague la unidad antes de abordar un avión, ya que el uso de dispositivos inalámbricos en aviones esta prohibido.

Recomendaciones medioambientales

- Recuerde siempre acatar las normas sobre el uso de este tipo de dispositivos.
- Consulte a su medico sobre el uso de la unidad, debido a que el uso de dispositivos electrónicos esta prohibido en ciertos lugares que contienen equipos médicos.
- La unidad puede generar interferencia con algunos audífonos, marcapasos y otros dispositivos médicos. Siga siempre las recomendaciones dadas por su doctor y consúltele para mas información.
- Apague la unidad en lugares con una atmosfera potencialmente explosiva, como lo es una estación de gasolina, fabricas químicas, etc.



**INSTRUCTION MANUAL
CELPHONE W/TV
CEL-4344TV**







DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.

If you need extra support, please write to info@premiermundo.com



	CAUTION	
	RISK OF ELECTRIC SHOCK, DO NOT OPEN	
<p>Caution: To reduce the risk of electric shock do not open this device, there are not serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.</p>		
	<p>This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.</p>	
	<p>This sign means that there are important instructions of operation and handling in the manual that comes with this device.</p>	

PREMIER CUSTOMER SERVICE

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panama:	300-5185
Website	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTE

This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

INDEX

BASIC INFORMATION	4
BRIEF INTRODUCTION.....	4
SAFETY NOTICE	4
SAFETY ALERT AND CAUTIONS.....	4
GENERAL CAUTIONS	4
CAUTIONS OF USING THE PHONE.....	5
CAUTIONS OF USING THE BATTERY	6
CAUTIONS OF USING THE CHARGER.....	6
CLEANING AND MAINTENANCE.....	7
BEFORE USE	7
NAME AND EXPLANATION OF EACH PART	7
TECHNICAL PARAMETERS.....	7
APPEARANCE SKETCH MAP (THE PICTURE IS ONLY FOR YOUR REFERENCE).....	8
DESCRIPTION OF THE STANDBY PICTURES(THE PICTURE IS ONLY FOR YOUR REFERENCE)...	8
DESCRIPTION OF KEYS.....	9
INSTALL SIM CARD AND MEMORY CARD	9
SIM CARD	9
MEMORY CARD	10
BATTERY.....	10
INSTALL THE BATTERY	10
CHARGING	10
SECURITY PASSWORD	11
QUICK USER GUIDE.....	11
FEATURE FUNCTIONS	11
FUNCTION HOT KEY	12
DIAL A CALL	12
REJECT A CALL	12
RECEIVE A CALL.....	12
END A CALL.....	12
EMERGENCY SERVICES	13
EXTENSION SPEED DIAL.....	13
DIALED CALLS/MISSED CALLS/RECEIVED CALLS/REJECTED CALLS	13
CALL FORWARD	13
CALL WAITING	13
CALL BARRING	13
POWER OFF THE PHONE	13
FUNCTION MENU	13
STRUCTURE OF FUNCTION MENU	13
CONTACTS.....	15
CALL LOG	16
MESSAGE.....	17
PROFILES.....	21
MULTIMEDIA.....	21
TOOLS.....	26

INTERNET	27
SETTINGS	29
TEXT INPUT	32
ACCESSORIES	32
CARE AND MAINTENANCE.....	33
ADDITIONAL SAFETY INFORMATION.....	33

BASIC INFORMATION

BRIEF INTRODUCTION

Thanks for selecting CEL-4344TV color screen GSM/GPRS digital mobile phone. Through reading the manual, you can fully know how to use CEL-4344TV mobile phone, appreciate its complete function and simple operating method.

CEL-4344TV color screen mobile phone is designed aiming at GSM/GPRS network environment; the phone is Two Card Two Standby, but you can not call another SIM card when one SIM card is under phone call. Besides basic call functions, CEL-4344TV also provides many kinds of practical functions, such as Contacts, Profiles, message, audio and video player, radio, camera and video, E-book, game, GPRS internet access, Bluetooth, alarm clock, calculator, world clock, STK, time and date, auto power-on and shut-down and etc. so that convenient for your work and leisure activities. In addition, CEL-4344TV adopts personalized human-computer interface design, its complete function can meet your different requirements.

CEL-4344TV color screen mobile phone accords with GSM/GPRS criterion, has obtained the certification of competent authority.

The company reserves the rights to revise the contents of the manual without prior notice.

SAFETY NOTICE

If your phone is lost or stolen, please immediately inform the telecom department or commission agents of forbidding the use of SIM card, so that avoid the economic loss caused by false calling of others.

- When you contact with telecom department or commission agents, they need to know your phone IMEI number (printed on the label on the back of the phone and can be found after taking down the battery). Please copy the number and keep it safe for future use.

In order to use the phone more safely, please adopt preventive measures, for example: set up the PIN code of SIM card, PIN code can prevent your SIM card from being used by others without permission. When leaving the car, please don't place the phone in a place easy to be seen, you had better to carry with you or lock in the suitcase.

SAFETY ALERT AND CAUTIONS

Before using the phone, please read these cautions carefully so that make sure to use the phone correctly.

GENERAL CAUTIONS

- On the plane, in the hospital and other places that forbidden to use the mobile phone, please turn off the phone; otherwise it may affect the normal operation of electronic equipments and medical instruments. Please comply with the relevant regulations if using the phone in these places,
- Please strictly comply with the laws and regulations about the phone use in the driving place. If you use the phone while you are driving, please comply with the following rules: concentrate on driving, pay attention to the road conditions; if the phone has hands-free function, please make a phone call hands free; if the driving conditions are not good, please stop the car, and then dial or receive a call.
- When approaching the places that storing fuel, chemicals or explosives, and etc., please comply with the laws, regulations and the relevant signs.

- Please place the phone, battery and charger in the place out of children's reach for fear that the children use them as tools and cause personal injury.
- Your phone only can use the batteries, chargers and other accessories specified by the company for fear that the phone is damaged. If using other batteries and chargers, it may cause liquid leaking, overheat, explosion, fire breakout and other failures of batteries.
- Please don't use the phone close to weak signal or high precision electronic equipments. Wireless wave interference may cause the mis-operation of these electronic equipments.
- The phone has the function of timely auto power-on, please check the auto power-on and shut down settings of the phone, so that confirm that the phone will not power on automatically during the flight.
- Please don't strike, shake or sling the phone violently for fear that the phone is failed or fire breakout.
- Please don't place the battery, the phone and the charger in the micro-wave oven or high-voltage equipment; otherwise may cause circuit damage or fire breakout and other accidents.
- Please don't use the phone in the places with inflammable and explosive gas; otherwise may cause phone failure or fire hazard.
- Please don't place the phone in the places with high temperature, high humidity or a large amount of dust; otherwise it may cause phone failure.
- Please don't place the phone in the uneven or unstable phone, prevent the phone from falling off and then cause failure or damage.
- Please only use the original antenna or the antenna being approved by the company. Unapproved and modified antenna or the antenna with additional accessories may damage the phone. Please don't touch the antenna during a call. Touching the antenna may affect the call quality and make the phone power higher than the required power in normal use. In addition, using the unapproved antenna may violate the regulations in your country.

CAUTIONS OF USING THE PHONE

- Don't take down or modify the phone; otherwise it may cause the damage, creepage and circuit failure of the phone.
- Please don't knock the LCD by force or use the LCB to knock other things; otherwise may cause the damage of liquid crystal plate and the leaking of liquid crystal. If liquid crystal enters the eyes, it may cause ablespsia. At this time, please rinse the eyes immediately with clean water (don't rub the eyes), and see a doctor immediately.
- In very rare cases, if the phone is used in some types of vehicles, it may have bad effect on the electronic equipments in the vehicle. At this time, please don't use the phone for fear of losing the safety guarantee.
- If your vehicle is equipped with the air bag, please don't place the phone above the air bag or the area that can be touched after the air bag is swelled, for fear that the phone is applied very strong external force and cause serious damage on the vehicle owner when the air bag is swelled.
- Please don't touch the keystone using needles, pen nibs and other sharp objects; otherwise it may damage the phone or cause mis-operation.
- If the antenna is damaged, please don't use the phone; otherwise it may cause the personal injury.
- Don't make the phone approach to the magcard and other magnetic objects too closely; radiation wave of the phone may clean out the information stored in the floppy disks, stored value cards and credit cards.
- Please place the drawing pin and other small metal objects in the place that far from the headphone of the phone. The loudhailer is magnetic when it is working and will attract these small metal objects so that may cause personal injury or damage the phone.
- Avoid phone damping, prevent water and other liquid from entering the phone, and then cause short

circuit, creepage or other failures of the phone.

- Please use the phone in the place that far from fixed telephone, TV, radio and office automation equipments, for fear that it may affect the using effects of these equipments and the phone.

CAUTIONS OF USING THE BATTERY

- Please don't take down or modify the battery; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of battery.
- Don't throw the old battery into general life rubbish. Treat the battery according to the regulated indication in the place that definitely regulates the waste battery treatment.
- Please don't throw the battery into the fire, otherwise it may cause the fire breakout or explosion of the battery.
- When installing the battery, don't apply pressure forcefully; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- Please don't make the battery short circuit using the electrical wire, needle and other metal objects; don't place the battery, necklace and other metal objects together; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- Please don't solder the battery contact; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- If battery liquid enters the eyes, it may cause ablepsia; at this time, please don't rub the eyes using the hand, please rinse the eyes with clean water, and then see a doctor immediately.
- Please don't use or place the battery near the fire or oven and other high temperature places; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- If the battery is increasing the temperature abnormally, color change, distortion and other phenomena during the using, charging or storing process, please stop using it and then change new battery.
- If leaking liquid of the battery contacts with the skin and clothing, it may cause skin burn, please rinse it with clean water immediately, and see a doctor if necessary.
- If the battery is leaking liquid or giving out strange odor, please take the battery away from open fire immediately, avoid fire breakout or explosion.
- Please don't make the battery damp, otherwise it may cause overheat, smoking or corrosion of the battery.
- Please don't use or place the battery under direct sunlight and other high temperature places, otherwise it may cause liquid leaking or overheat, reduce the performance and shorten the service life.
- Please don't charge the battery continuously for more than 24 hours.
- Please place the battery in the cool and ventilated place away from direct sunlight.
- Service life of the battery is limited. Service time of the battery is gradually shortened after the frequent charging. If many times of charging is failed, it means that battery life is drained, please replace the new battery of designated type.

CAUTIONS OF USING THE CHARGER

- Please don't take down or modify the charger; otherwise it may cause personal injury, electric shock, fire breakout or charger damage.
- Please use 220V alternating current. Using other voltage may cause creepage, fire breakout and damage the phone and the charger.

- Short circuit of the charger is forbidden; otherwise it may cause electric shock, smoking and charger damage.
- Please don't use the charger when the power cord is damaged; otherwise it may cause fire breakout or electric shock.
- Please clean the dirt that accumulates in the power socket in time.
- Please don't place the water container, and etc. near the charger, for fear of water splashing and then cause short circuit, creepage or other failures.
- If the charger contacts water or other liquid, please cut off power supply immediately, so that prevent short circuit, fire breakout, electric shock or charger failure.
- Don't use the charger in the bathroom and other high humidity places; otherwise may cause electric shock, fire breakout or charger damage.
- Please don't contact the charger, electrical wire and power socket with wet hands; otherwise it may cause electric shock.
- Don't place heavy object on the power cord or reconstruct the electrical wire; otherwise may cause electric shock or fire breakout.
- Please pull out the charger plug from power socket before the cleaning and maintenance.
- Seize the charger when pulling the plug, pulling the power cord will damage the electrical wire, cause electric shock or fire breakout.
- Don't charge in the following places: direct sunlight and other high temperature places; wet and ashy place or the place with large vibration (will cause failure); near TV, radio and other home appliances (will affect the image and sound effects).

CLEANING AND MAINTENANCE

- Please don't use the phone, the battery and the charger in the bathroom and other high humidity places, and prevent them from rain.
- Please clean the phone, the battery and the charger using soft and dry cloth.
- Please don't wipe the phone using alcohol, thinner or benzene and other chemical reagents.
- The socket with dirt may cause poor contact and power-off, so that can't be charged, please clean it regularly.

BEFORE USE

NAME AND EXPLANATION OF EACH PART

TECHNICAL PARAMETERS















Main body	
Model	CEL-4344TV
Dimension (W×H×T)	108 mm× 56 mm×13mm
Weight	100g (includes standard battery)
Lithium battery	
Model	CEL-4344TV
Nominal voltage	3.7V
Limited charge voltage	4.2V
Rated capacity	650 mAh
Continuous standby time	120 hours to 180hours
Continuous call time	2.5 hours to 3.5 hours









* Depend on network conditions.

Travel charger
 Model
 Input 100-240V,50/60HZ,100mA
 Output DC 5.0V,500mA

APPEARANCE SKETCH MAP (THE PICTURE IS ONLY FOR YOUR REFERENCE)

DESCRIPTION OF THE STANDBY PICTURES(THE PICTURE IS ONLY FOR YOUR REFERENCE)

Icon	Description of functions
	Network signal strength The more the stripe is, the stronger the signal is. When SIM card 1s inserted in card slot 1, standby screen will show the icon.
	Network signal strength The more the stripe is, the stronger the signal is. When SIM card 1s inserted in card slot 2, standby screen will show the icon.
	Battery strength The full the fill is, the more electric quantity is. Standby screen will show the icon.
	Alarm clock on and off It means that alarm clock is set and started. If alarm clock is set as off, the icon will disappear automatically.
	Unread SMS When there is unread SMS in the inbox, standby screen will show the icon.
	Full SMS When SMS is full, standby screen will show the icon.
	Undownloaded MMS When there is undownloaded MMS in the inbox, standby screen will show the icon.
	Missed call When there is missed call, standby screen will show the icon.
	Call forward in SIM card 1 When call forward unconditionally is started in SIM card 1, standby screen will show the icon.
	Call forward in SIM card 2 When call forward unconditionally is started in SIM card 2, standby screen will show the icon.
	Call forward in both SIM cards When call forward unconditionally is started in SIM card 1 and SIM card 2 at the same time, standby screen will show the icon.
	Silent mode When Profiles is set as Silent mode, standby screen will show the icon.
	Vibrate mode When Profiles is set as Vibrate mode, standby screen will show the icon.
	High ring and vibrate mode

	When Profiles is set as normal mode, standby screen will show the icon.
	Low ring mode When Profiles is set as Low ring mode, standby screen will show the icon.
	Earphone When the earphone connects with the phone normally, standby mode will show the icon.
	Flight mode When the phone is set as flight mode, standby screen will show the icon.
	Memory card When the memory card is inserted in card slot, standby screen will show the icon.
	WIFI Icon When you turn on WIFI and successful WIFI connection without a password, the standby screen will display this symbol on the screen.
	WIFI Icon When you turn on WIFI and successful password WIFI connection, the standby display this symbol on the screen.
	Bluetooth (visible) When Bluetooth is started and select Visible, standby screen will show the icon.
	Bluetooth (hidden) When Bluetooth is started and select Hidden, standby screen will show the icon.

DESCRIPTION OF KEYS

Keys	Function
	Left soft key On the standby interface, press left soft key to enter function chart.
	Navigation key On other interfaces, it equals to navigation key and direction key except for special functions.
	Power-on and power-off Press and hold the key to power on and power off the phone.

INSTALL SIM CARD AND MEMORY CARD

SIM CARD

Before using the phone, you must insert valid SIM (Subscriber Identity Module) card in the phone. SIM card 1s provided by network supplier.

All the information related to network connection are recorded in the chip of SIM card, also the names, telephone numbers and SMS that storing in the Contacts of SIM card. You can take out SIM card from your phone, and use it in any GSM mobile phone (new mobile phone can read SIM card automatically).

In order to avoid losing or damaging the information saves in SIM card, please don't touch the metal contact surface, and place SIM card 1n the place that away from electricity and magnetic force. Once SIM card 1s damaged, you can't use the phone normally.

Prompt: Please make sure to power off the phone before taking out SIM card. It is absolutely forbidden to insert or take out SIM card with external power supply; otherwise it may

damage SIM card and the phone.

Inserting and Taking out SIM Card

Metal contact surface of SIM card is easily scratched. You must take out SIM card carefully before the assembly.

- Power off the phone, remove the rear cover, battery or other external power supply.
- Make the end of SIM card without cutting angle inside and aim at the card slot of the phone and metal surface of SIM card face downward, then insert SIM card to the card slot of the phone.
- When taking out SIM card, directly pull it outward and then can take out SIM card.

Prompt: Without special explanation inserting two SIM cards are defaulted in the manual. If you just insert one SIM card, maybe some options of the menu will not be shown.

MEMORY CARD

Take out the rear cover and battery, according to the prompt shown on the card slot of memory card, press the card slot of memory card using the finger, and then move at the direction of OPEN, open the card slot cover of memory card, make one end with metal card and metal surface face downward, place the memory card in the card slot, close the card slot of memory card, press the card slot of T card using the finger, and then moves at the direction of LOCK.

Prompt: If the memory card is failed, please check whether it is correctly placed and good contact of metal point.

BATTERY

INSTALL THE BATTERY

- Take off the back cover of the mobile.
- Make one end of battery with metal surface aim at the battery connector.
- Then gently press the battery downward using the finger, and then press the other end to install the battery.

Prompt: Please operate correctly to avoid damaging the battery connector.

CHARGING

Insert the charger on the charging interface at the side end of the phone.

After inserting the charging plug, battery strength icon stripe at the top right corner of the screen is scrolling, which means that the charging is processing; when the stripe is full of the whole icon and stop scrolling, which means that the battery charging is completed; when the charging is completed, please pull out the plug.

When electric quantity is not enough, warning message will be sent; and electric quantity shows empty. When electric quantity is too low, the phone will power off automatically. Please don't make the battery in the status of not enough electric quantity for a long time; otherwise it may damage the battery quality and service life. Please don't charge the battery for a long time.

Prompt: In order to ensure normal operation of the phone, please make sure to use the designated charger.

SECURITY PASSWORD

■ PIN

PIN (Personal Identification Number) is used to prevent your SIM card from being used illegally. PIN is usually provided with SIM card together. If you input wrong PIN for continuous three times, please input PUK to unlock it. Please contact with network operator for more details.

■ PIN 2

You need to input PIN2 when entering some functions (such as call charge); if you input wrong PIN2 for continuous three times, you need to input PUK2 to unlock it. Please contact with network operator for more details.

■ PUK

When changing the locked PIN, you need to input PUK (Personal Unlock Key). PUK is provided with SIM card together. If it is not provided, please contact with your service provider. If you input wrong PUK for continuous ten times, the SIM card can't be used again. Please contact with your service provider to buy new card. You can't change PUK. If you lose the code, please contact with your service provider.

■ PUK2

When changing the locked PIN2, you need to input PUK2. If you input wrong PUK2 for continuous ten times, you can't the functions that need PIN2. Please contact with your service provider to buy new card. You can't change PUK 2. If you lose the code, please contact with your service provider.

QUICK USER GUIDE

FEATURE FUNCTIONS

The phone has not only the basic functions of mobile phone, but also support rich, practical and rapid feature functions, can be briefly introduced as follows:


- **Contacts:** Each Contacts record stored in the phone can be related with several telephone numbers at most, can send SMS and MMS in the Contacts; you can copy Contacts record between SIM card and the phone.
- **Profiles:** Custom the ringtone (include ringtone settings, volume adjustment, incoming call prompt, message prompt, alarm clock prompt, key-press tone, low voltage warning tone, power-on and power-off tone) according to different events or environment.
- **Call log:** The phone will automatically store the information of call log for you to check; support to call the telephone number in the call log; support to save the telephone number in the call log to Contacts and set as rejected call; support the function of sending SMS, MMS, and etc. to the telephone numbers in the call log.
- **Message:** The phone supports storing SMS and 200 pieces at most; and the max capacity of each MMS should be 100KB. You can individualise various settings to MMS. The phone supports the storing status of SMS in SIM card and the phone.
- **Multimedia:** Your phone provides all kinds of entertainment services including player, camera, file management, record, E-book and other functions.
- **Camera:** The phone supports camera and video function. You can customize the camera and video.
- **Game:** The phone supports the game function.
- **Network services:** The phone supports WAP services. Using WAP browser to access and enjoy wireless network, obtain rich information.
- **Tools:** The phone supports various practical functions. Supports Bluetooth, alarm clock, calendar, calculator, world clock, countdown and other functions.

- System settings: You can customize the phone according to the needs, include phone settings, display settings, call settings, security settings and other functions.
- Input method: The phone supports various input modes, which is convenient for you to input English, letters, numbers, symbols, and etc.

FUNCTION HOT KEY

Function	Hot key	Status description
Power on	Press and hold power-on and power-off key	Power-off mode
Power off	Press and hold power-on and power-off key	Power-on mode
Enter function list	Press left soft key	Standby mode
Enter call log	Press Dial key	Standby mode

DIAL A CALL

In the standby mode, choose dial board icon to enter and then click number icon numbers will be shown on the screen, input the numbers you want to dial, and then click  icon to dial a call.

Click options and icons during a call, there are hands free call, handset/Bluetooth, switch, Contacts, message, call log, begin to record and Silent for your selection:

- Hands free call: You can make a call hands free.
- Handset/bluetooth: when connecting to Bluetooth earphone free activation successfully, you can switch the call sound to the phone or Bluetooth earphone by choosing the option when calling.
- Switch: Hold a call, switch again to call normally.
- Contacts: During a call, you can enter the Contacts and conduct the relevant operations.
- Message: During a call, you can enter SMS and conduct the relevant operations. During a call, you can't send and receive MMS.
- Call log: Enter the call log interface.
- Begin to record: Enter Record during a call, the file is stored in Record menu.
- Silent: When you choose the function, the person you calling to can't hear any sound from you.

REJECT A CALL

You can choose Hang up key to reject an incoming call.

RECEIVE A CALL

When an incoming call arrives, the phone will give out the corresponding prompt (such as vibration, ringtone, and etc.); if network support, the phone screen will show the name and telephone number of the caller; at this time, you can click answer icon to receive an incoming call.

END A CALL

After finishing a call, you can choose Hang up to end a call.

EMERGENCY SERVICES

You can directly dial a emergency service call without SIM card.

Different network uses different emergency numbers, please consult your network operations company for more details.

EXTENSION SPEED DIAL

After inputting telephone number, if you want to input branch number, please click and hold “*”, input your extension number after the display screen shows “P”. After getting through the call, it will directly dial the extension.

DIALED CALLS/MISSED CALLS/RECEIVED CALLS/REJECTED CALLS

You can enter call log to check the relevant details of dialed calls, missed calls, received calls and rejected calls.

Prompt: The record of incoming call from blacklist number will be saved in Rejected Calls.

CALL FORWARD

After call forward function is started, according to different forward conditions settings (Call Forward Unconditionally, Forward Busy, Forward No Answer, Forward Can Not Reach), you can select to switch the incoming call to voice inbox or other telephone numbers.

CALL WAITING

After call waiting function is started, when you are calling, the other call can be put through.

CALL BARRING

After call barring function is started, according to different restricted conditions settings (all the dialed calls, all the incoming calls, incoming calls when roaming, dialed international calls, outgoing international calls when roaming), you can restrict the call under the corresponding conditions (need to apply to network operator for business).

POWER OFF THE PHONE

In the standby mode, press and hold Hang Up key to power off the phone.

FUNCTION MENU

STRUCTURE OF FUNCTION MENU

The default structure of the function menu is as follows:

- 1-1 Contacts
 - 1-1-1 New
 - 1-1-2 Search
 - 1-1-3 Write Message
 - 1-1-4 Dial
 - 1-1-5 Send Vcard
 - 1-1-6 Delete

- 1-1-7 Mark
- 1-1-8 Copy
 - 1-1-9 Copy all
 - 1-1-10 Others

- 1-2. Call log
 - 1-2-1 Dialed
 - 1-2-2 Received
 - 1-2-3 Missed
 - 1-2-4 Rejected
 - 1-2-5 Delete All
 - 1-2-6 Call timers
 - 1-2-7 Call cost
 - 1-2-8 GPRS volume

- 1-3 Message
 - 1-3-1 Write Message
 - 1-3-2 Inbox
 - 1-3-3 Outbox
 - 1-3-4 Drafts
 - 1-3-5 Sentbox
 - 1-3-6 Templates
 - 1-3-7 Area Broadcasting
 - 1-3-8 Voice Mailbox
 - 1-3-9 SMS settings
 - 1-3-10 MMS settings
 - 1-3-11 Message capacity

- 1-4 Profiles
 - 1-4-1 Standard
 - 1-4-2 Silent
 - 1-4-3 Vibrate
 - 1-4-4 Low ring
 - 1-4-5 High ring and vibrate

- 1-5 Multimedia
 - 1-5-1 Java
 - 1-5-2 TV
 - 1-5-3 Camera
 - 1-5-4 Video
 - 1-5-5 Audio player
 - 1-5-6 Video player
 - 1-5-7 FM radio

 - 1-5-8 Image browser
 - 1-5-9 E-Book reader
 - 1-5-10 Games
 - 1-5-11 File list

- 1-6 Tools
 - 1-6-1 Alarm
 - 1-6-2 Bluetooth
 - 1-6-3 Calendar
 - 1-6-4 Calculator
 - 1-6-5 Recorder
 - 1-6-6 World clock
 - 1-6-7 Timer
 - 1-6-8 STK

- 1-7 Internet
 - 1-7-1 Input URL
 - 1-7-2 Homepage
 - 1-7-3 Bookmark
 - 1-7-4 History
 - 1-7-5 Offline
 - 1-7-6 WAP settings

- 1-8 Settings
 - 1-8-1 Call Settings
 - 1-8-2 Phone Settings
 - 1-8-3 Display Settings
 - 1-8-4 Security Settings
 - 1-8-5 Connection management

CONTACTS

This function could help you browse the Contacts, store, edit and delete the names and phone numbers in the phone and SIM card. To facilitate the management of the records, this phone sets the group function, collecting the similar items into a group. The storage capacity of the SIM card varies.

When the record of the Contacts is not empty, choose options in record list interface for the following operation:

Prompt: Take the records in SIM card 1 for example.

New

Create new Contacts records to SIM card or the mobile phone.

Search

Look up the record stored in the phone or the SIM cards.

Write Message

Send message or multimedia message to this record.

Dial

Dial this record directly or by means of IP call.

Send Vcard

Send this record to others via SMS or Bluetooth.

Delete

Delete this record.

Mark

Choose one record or all records, and cancel what you choose are also allowed.

Copy

Copy the record to SIM cards or memory card..

Copy all

Copy all the record to SIM cards or memory card..

Others

——Shortcut Dial Settings: Set this record into shortcut dial. After setting, on standby interface, long press the number key you've set can call this record.

Prompt: On standby interface, long press number key 1 will enter the voice mailbox of SIM card 1.

On standby interface, long press number key 2 will enter the voice mailbox of SIM card 2.

——Number of this Phone: You can view or edit the number of this phone.

——Capacity Enquiry: You could enquire the capacity of SIM1, SIM2 and the phone.

——Display in one/two lines: You can set the display mode of contact name list as one line or two lines.

CALL LOG

Display your recent call log.

Dialed

Display the list of your recent dialed numbers.

On the interface of Dialed, choose one record, and choose "Options" to enter the Options interface and you could go on the following operations.

- Details: You could inquire the details of the record, including the name, number, date, time, calling time, etc.
- Dial: Call this number directly.
- Save: You could save this number into the SIM card or certain group in the phone.
- Send message: You could send SMS or MMS to this number.
- Add to the existing name: Add this number to the existing record of the Contacts.
- Set as rejected call: Add this number to the blacklist.
- IP dial: Call this number by IP dialing.
- Delete: Delete this record.
- Delete all: Delete all the records in the Dialed list.

Received

Display the list of your recent received numbers. The operation is the same as the Dialed.

Missed

Display the list of your recent missed numbers. The operation is the same as the Dialed.

Rejected

Display the incoming call records in the blacklist. The operation is the same as the Dialed.

Delete All

You could delete all the records of the Dialed, Answered, Missed and Rejected.

Call timers

You could choose the view the time counting in SIM1 and SIM2, which displays the last call, answered call, dialed call and all the calls. Choose zeroing, the time counting will be zero.

Call Cost

Display the total call expense, the upper limit of the call, charges, rater reset, the functions of which shall be supported by the network operators.

Prompt: The call expense function shall be supported by the network operator. The design of the charging unit and the phone rate limit shall require you to input the PIN2 code. Please contact with your network operator to achieve the password.

GPRS volume

You could check the GPRS volume of the SIM1 and SIM2 and choose and click the option “zeroing” the flow will be zero.

MESSAGE**Write Message****■ Create SMS**

You could write new message by using this function. When you input the message to be sent, choose options to send, to insert the templates, to add contact person information and symbol, and to save, etc.

--Send: Enter the interface of input number, you can dial the phone number directly, or choose to enter the Contacts and select the number to send.

--Insert the templates: Enter the templates interface and you could insert the template to the message.

--Add the information of the contact person: Enter the Contacts interface and you could insert the Contacts information to the message.

--Add symbol: Enter the symbol interface and add the symbols to the message.

--Save: Save this message to the drafts.

■ Create MMS

You could edit the MMS, and insert pictures or ringtones with this function.

Select the “create MMS” and enter, you could edit the receiver, forwarder, confidential receiver, the title and content, and operate the functions of send, preview, save and set the timing send.

- Send: Send the edited MMS.
- Receiver: Edit the receiver of the MMS, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the receiver is also allowed.
- Forwarder: Edit the forwarder of the MMS, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the forwarder is also allowed.
- Confidential receiver: Edit the confidential receiver of the MMS, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the confidential receiver is also allowed.
- Edit title: Edit the theme of the MMS.
- Edit content: Enter the menu of the Edit Content, choose options to edit the words, insert new page or picture, insert the sound, , delete the picture, sound or the current page, previous page, next page and the playing time of the current page.
- Preview: Preview the edited MMS.
- Save: Save the edited MMS.
- Set the timing send: You could set the time to send the MMS. After edition and successful sending of the MMS, it will arrive at the receiver only at the time you've set.(Unicom Card temporarily does not support this function).

Inbox

Store the SMS, MMS and Push message you've received. The SMS, MMS and Push message could be differentiated by different icons. The icons before the message list means whether this message is SMS, MMS or Push message and which is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and choose options, then you will do several operations, for example, reply the SMS or MMS, delete, dial, lock and mark. Click directly you can read this SMS, downloaded MMS or Push message.

——Reply: You could choose to reply the addresser by SMS or MMS.

——Delete: Delete this message.

——Dial: Call the addresser.

— —Lock/unlock: Lock the message or unlock it.

——Mark: Choose this message or all messages in the inbox, or only choose the messages saved in SIM 1 or SIM 2.

——Sort: Sort the messages in the inbox by time, contact person, theme or message type.

Outbox

Store the SMS and MMS you've sent in failure. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and choose options, you could send, delete, lock, mark, sort, and so on.

— — Send: Send this SMS or MMS.

— — Delete: Delete this message.

— — Lock/unlock: Lock the message or unlock it.

——Mark: Choose this message or all messages in the inbox, or only choose the messages saved in SIM 1 or SIM 2.

——Sort: Sort the messages in the inbox by time, contact person, theme or message type.

Drafts

Store the SMS and MMS you've edited. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and choose options, you could delete, edit, lock, mark, sort, and so on.

--Delete: Delete this message.

--Edit: Edit this message.

--Lock/unlock: Lock the message or unlock it.

---Mark: Choose this message or all messages in the inbox, or only choose the messages saved in SIM 1 or SIM 2.

---Sort: Sort the messages in the inbox by time, contact person, theme or message type.

Sentbox

Store the SMS and MMS you've sent successfully. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and choose options, you could delete, forward, lock, mark, sort, and so on.

--Delete: Delete this SMS or MMS.

--Forward: Forward this message to others.

--Lock/unlock: Lock the message or unlock it.

---Mark: Choose this message or all messages in the inbox, or only choose the messages saved in SIM 1 or SIM 2.

---Sort: Sort the messages in the inbox by time, contact person, theme or message type.

Templates Settings

You could edit or delete the templates.

Voice Mailbox

This phone supports the function of the voice mailbox. You could choose either SIM1 or SIM2. When you receive the calls from others, they could give you a message in your voice mailbox. When you phone receives the message notice, you could listen to the messages. Under the voice mailbox interface you can edit and set the number of line 1, line 2, fax or data.

■ Listen to the message: Dial the number of the voice mailbox and listen to the message.

■ Number settings: Edit the number of the voice mailbox.

Prompt: The realization of the voice mailbox requires the support of the network operator and you may firstly apply for this service . For more information and the number of the voice mail, please inquire about your local network operator.

Area Broadcasting

The area info services send different kinds of messages. Change the settings of this service and inquire the area info by using this function.

■ Read: Read the messages received.

■ Start up the broadcasting. Choose to start up/shut down the broadcasting.

■ Channel settings: Set the channel to receive the area message.

- Add the channel: Add the channel index and channel name.
- Channel list: Display the channel list.

- Language settings: Set different languages.

SMS Settings

There are seven options: SIM 1 service center, SIM2 service center, validity period, delivery report, save sent message, preferential storage position, etc.

- SIM1 service center: Display the SMS service center number in SIM1.
- SIM2 service center: Display the SMS service center number in SIM2.
- Validity period: You could set the validity period of the message for 1 hour, 6 hours, 24 hours, 72 hours, 1 week and the maximum value.
Prompt: This time is related with the services of the network operator.
- Delivery report: May choose to start up or shut down the delivery report. After switching this function as on, when the receiver gets the message or doesn't get for some reason, the SMS service center will give you a delivery report, so you will know whether your message sent successfully or not conveniently.
- Save sent message: There are three options: "Suggest to choosing", "Save", "Not save".
Suggest to choosing: Before sending the message, you will be suggested to choose "Send and Save" or "Send only".
Save: Save automatically your sent message.
Not save: Not to save automatically your sent message.
- Preferential storage position: You could choose the preferential storage position at SIM card or phone.

MMS Settings

- MMS Account: You could choose to set the MMS account of SIM1 or SIM2 in order to send or receive the MMS correctly.
- Apply for delivery report: When this function is on, after the MMS is successfully received, the user will receive a delivery report.
- Send the reading report: When this function is on, after the receiver reads the MMS, he would be inquired whether send the reading report or not.
- Send anonymously: When this function is on, after the receiver reads your MMS, the sender's name and number are hidden. This function requires the network support.
- Priority: Set the priority of the MMS as: High priority/common priority/low priority.
- MMS receiving: Manual receiving, automatic receiving. Start up the automatic receiving, then the MMS is received and return to the standby interface, the MMS will be loaded automatically.
- Play sound: When this function is started up, while viewing the MMS, the sound will be played automatically.
- Accept advertisement: If this function is on, the advertisements in MMS are allowed.
- Validity period: Set the validity period of the MMS: 12 hours, 1 day, 1 week and maximum period.
Prompt: This time is related with the services of the network operator.
- Reset to default: You could reset MMS settings to default by this function.

Capacity

You could view the capacity of SMS, MMS, WAP Push and OTA.

PROFILES

You could set different Profiles.

Standard/Silent/Vibrate/Low ring /High ring and vibrate

You could start up, define or rename each mode.

■ Ringtone Settings

——Ringtone of SIM1: You could set the ringtone of SIM1 into fixed tone or more tones.

——Ringtone of SIM2: You could set the ringtone of SIM2 into fixed tone or more tones.

——Message tone of SIM1: You could set the message tone when the SIM1 receives the message.

——Message tone of SIM2: You could set the message tone when the SIM2 receives the message.

■ Ringtone Volume

——Ringtone volume: You could set the ringtone volume when there is an incoming call.

——Volume of message alert: You could set the ringtone volume when there is an incoming message.

——Call volume: You could set the volume when you are calling.

——Key-press volume: You could set the volume when pressing the keys.

——Volume of alarm clock: You could set the volume of the alarm clock when it rings.

——Volume of power on/off: You could set the volume when power on or power off.

■ Incoming Phone Alert

You could set the incoming call alert for the SIM1 and SIM2 and there are five options for you to choose: ringtone, vibration, Silent, ring after vibration and vibrating ring.

■ Message Alert

You could set the incoming message alert for the SIM1 and SIM2 and there are four options for you to choose: ringtone, vibration, Silent, and vibrating ring.

■ Alarm Clock Alert

You could set the alarm clock alerts as ring, vibration, Silent and vibrating ring.

■ Key-press Tone

You could set the key-press tone as Silent, tone 1 and tone 2.

■ Low Voltage Alarm

You could set to start or close the low voltage alarms. After starting this function, when the electric quantity of the battery is low, the low voltage alarm will ring.

■ Tone to Start up and Shut Down the Phone

You could set the tones when starting up and shutting down the phone.

MULTIMEDIA

JAVA

■ Application manager

You can know what games you have installed from the JAVA game list, and you can play or delete the JAVA game or view the details.

——Play: Play the selected JAVA game according to the instruction.

——Details: View the name, size, edition and other information of the JAVA game.

——Delete: Delete the selected JAVA game.

Tip: The default Java games can not be deleted.

■ **Local install**

Directly in the File Manager, select the game file into the Java installation.

■ **Download**

After inputting correct website you can download varied JAVA application software via WAP service, but before download you ought to ensure that the application software is compatible with your phone. The game will save to the JAVA catalog in files management automatically after downloading.

■ **Connection Settings**

Set Enable Java games, SIM cards Java account.

TV

Enter the TV interface, you could choose the local search and switch the channel by pressing the Left and Right keys. Press the Up and Down key to adjust the volume.

On the TV play interface, press OK key to switch between full screen and half screen; On the TV play interface, press left soft key, you could go on the following operation;

--Nation or region: You could set different countries or regions.

--Noise removal function: When this function is on, the noise point will decrease, however the picture quality will decrease. When this function is off, the noise point will increase, but the picture quality will increase.

--Search the channel: Enter the channel search interface.

Camera

You can view the photo on screen and choose take photo to get a picture. On the photo preview interface (screen rotate), choose screen to adjust menu settings:

——Shoot mode: You can switch between camera capture page and video capture page.

——Size: You can set the photo image size.

——Environment modes: You can set up the image modes as normal and nighttime.

——Brightness: Six levels of brightness are available.

——Contrast level: Six levels of contrast are available.

——Exposure compensation: Six level of exposure compensation are available.

——White balance: You can set as automatic white balance, incandescent lamp, fluorescent lamp, sunlight and cloudy.

——Self-timer delay: You can set up the timer as: shut down, 3S and 10S.

——Special effect: The special effect can be classified into: normal, black and white, red, green, blue, yellow, reminiscence and negative.

In camera preview interface choose options you can enter options menu as follows:

——View photo management: You can enter camera list page to view the photos you shot.

——Settings:

—Image quality: There are three options in photo image quality: fine, normal and concision.

—Avoiding glitter: You can set as 50Hz or 60Hz.

—Sound of shutter: You can set up the sound of shutter as: startup or shutdown.

—Preferential storage place: You can store the photos in T-card memory.

—Autosave: You can select startup or shutdown.

- Display photo-taking parameter: You can select startup or shutdown.
- Help: You can view the relevant operation instruction of the camera.

Prompt: Observe photographing related local laws and regulations. Do not use the function in illegal way.

Video

Through video mode in the menu you can switch to take video interface, and you can view video effect through phone screen. In video mode click and choose the screen will enter video menu:

- Shoot mode: You can switch between camera capture page and video capture page.
- Size: You can set the video image size.
- Brightness: Six levels of brightness are available.
- Contrast level: Six levels of contrast are available.
- Special effect: The special effect can be classified into: normal, black and white, red, green, blue, yellow, reminiscence and negative.

In view camera preview interface choose options you can enter options menu as follows:

- View video management: You can enter video list page to view the videos you shot, and concrete operation you could refer to video player.
- Settings:
 - Avoiding glitter: You can set as 50Hz or 60Hz.
 - Audio: You can set up audio as startup or shutdown.
 - Image format: You can set the mode of recording image as Avi or 3Gp.
 - Display video-taking parameter: You can select startup or shutdown.
- Help: You can view the relevant operation instruction of the camera.

In the take video mode, after shooting, you can choose options to operate as follows:

- take new video: Choose the option, you will enter video capture interface;
- Delete: Delete the video you took just now;
- Send: Send via by Bluetooth;
- Play: Play the video;
- View video management: Enter my video list page.

Audio player

This phone could play the MPS stored in the T-card memory and support the background play.

On the audio player interface, move cursor to the shortcut icons on the screen, you could rapidly operate the MP3 functions.

- Press ▶ can play the MP3;
- Press ||| can make a pause;
- Press ■ can stop playing;

Under the MP3 list interface, choose the options icon on the top right corner, then you can do operations as follows:

- Open: Enter the T-card memory and open the MP3 stored in it.
- Now playing list: Display MP3 files list which are playing now.
- Play list: Display all the MP3 or the play list you've saved.
- Set as ringtone: Set the selected MP3 as the ringtone of the incoming call.
- Equalizer settings: Set the music style as general, classical, concert, jazz, rock or soft rock.
- Settings: Set lyric display as not displayed, display and backlight always display. And set play mode as looped play and random play.

Under the now playing list interface, choose options, then you can do operations as follows:

- Play: Play the MP3 you selected.
- add new MP3: Choose new MP3 from the T-card memory and add it to play list.
- Delete from play list: Delete the selected MP3 from play list.
- Save list: Save the current play list.
- Clear current play: Clear all the MP3 in play list.

Prompt: In the main interface of "Play MP3" choose returning, the background broadcasting status will remain

Video player

This phone supports the video format of 3GP and MP4,AVI, not support DIVX AVI.

Enter the video play list interface, press left soft key, you could go on the following operations.

- Play list: play the video file list.
- Fullscreen play: you can play the video on fullscreen.
- Order play: you can play the video on order.
- Set as: Set the video as your startup image or shutdown image.
- File attribute: View the details of the video, name, date, time, resolution ratio, time span, size

and so on.

_Number2 is transver between 16:9 and 4:3.

Prompt: The maximum resolution supported by this phone is 320x240.

FM radio

You can listen to Fm radio freely. Enter the radio interface, fine adjust the frequency by clicking the up and down icon, and change previous or next frequency by clicking the left and right icon.

On the interface of the Radio playing, choose options you could enter the options menu and do operations as follows:

- Search automatically and save: Search frequency available automatically and save it to broadcasting station list.
- Broadcasting station: You can view all the broadcasting stations you saved.
- Save: Save the frequency you searched to the list.
- Manual input: Search the broadcasting station by input frequency manually.

Prompt: When the battery of your cell is insufficient, you may not enter the Radio frequency and TV.

Image browser

You can view the pictures saved in the T-card as well as edit them freely.

In the picture list interface choose you can do operations as follows:

- Change folder: Change the folder in which pictures are saved.
- Send: Send the pictures to others via MMS or Bluetooth.
- Slide show: Play the pictures in the list in a slide show manner.
- Delete: Delete the selected pictures.
- Set as wallpaper: Set the picture as standby wallpaper.
- Re-name: Rename the picture.
- Mark: Choose one or all of the pictures in the list.
- Details: View the details of the picture, including name, date, time and size.
- Slide settings: Set the play effect and delay time of the slide.

E-book reader

You can read e-book with txt format with the aid of this function.

In e-book list interface, choose options you can do the following.

- Details: View the details, name, size, storage place, pages and bookmarks of e-book.
- Recent reading: Display the e-book list of recent reading.
- Send via Bluetooth: Send e-book to others via Bluetooth.
- Delete: Delete the selected e-book.
- Mark: Choose one or all of the e-books in the list.
- Settings: Set the mode of turning page, background and font color.

In the page of “read e-book”, choose options, then you can do the following.

- Add to bookmark: You can save the existing page so that you can find it from bookmark next time.
- View bookmarks: You can read, delete and entirely delete bookmarks.
- Skip front-page: Skip to the homepage of e-book.
- Skip to the last page of e-book.
- Skip to page: You can edit the desired page.
- Turn on/turn off backlight always active: Turn on or turn off the backlight always active when you read.

Following is the introduction to e-book functions:

- 1、 “Page up/down” function is defined by left/right direction key. Each “ page up/down” will display on the first line of the page;
- 2、 When user retreats from the function, the procedure will memorize the existing page.

Games

- Push Cases
 - New game: You can start a new push cases game.
 - Continue: You can continue to play the game you didn’t finish last time.
 - Choose level: You can choose the level of the game.

File list

You can check the specific content and service condition of the T-card memory via this function. Meanwhile, you can format memory, too.

Choose one folder and choose options, then you can operate as follows:

1. Create new folder: Create a new folder.
2. Delete: Delete the folder.
3. Details: Check details of the folder, name, date, size, position and so on.
4. Edit: Re-name or copy the folder.
5. Look up: Look up the file in the folder.
6. Sorting: To sort according to name, date, size and type.
7. Mark: Mark one or all the folders in T-card.

8. More View the service condition of the T-card. In this interface you can format the T-card memory by choosing “format”, but this operation will cause the data in it lose forever.

TOOLS

Alarm

You can edit alarm, time, ring and repeated ring mode.

In “alarm edit” mode, you can scroll up or down direction key, when the cursor goes to the desired option, press “OK”, then you can select desired settings.

Bluetooth

■ Start up/shut down Bluetooth

You can choose to “start up” or “shut down” Bluetooth.

■ Device visible

You can choose “visible” or “invisible” Bluetooth. If the Bluetooth is invisible, others cannot search your phone.

■ Paired device

You can search different Bluetooth equipments and find compatible ones (as long as the PIN codes of two Bluetooth equipments are identical with each other, the match will be successful. The PIN code of Bluetooth earphone is different due to different type, and you can find the code in operating manual of the Bluetooth earphone.).

■ File share settings

--Rights of shared directory: You can choose “free access” or “read only”.

--Select directory: You can choose folder in the T-card memory as the storage position of received files by Bluetooth.

■ My phone’s name

You can change the name of the phone.

■ Help

You can view the operating instruction of Bluetooth.

Calendar

You can look up the calendar according to this function. Press left soft key on the Calendar interface, you can do the following.

■ Calendar Setup

You can set up a calendar reminder.

■ Check Calendar Reminder

You can check a calendar reminder of a certain date.

■ All Calendar Reminders

You can check all calendar reminders.

■ Clear Calendar Reminder

You can clear the calendar reminder of a certain date.

■ Clear All Reminders

You can clear all reminders.

■ Date Inquiry

You can check date.

■ Weekly Reminder

Display weekly calendar reminder.

Calculator

The function will make your device a calculator with which you can carry out simple math calculation.

Recorder

Use this function you can record or listen to your own record. The record file format: wav.

Click options and select "record". You can also do the following.

- —Start to record: Select "record" and continue the following steps;
- —Records list: Select "records list".

Enter "record" interface, choose record icon to record. During the process, you can choose pause to make a pause and choose continue to go on with the record. Choose stop can stop and save the record, at the time you choose options can do the following:

- —Audition: Audition the tape you just recorded.
- —Delete: Delete the tape you just recorded.
- —Send: Send the tape to others via Bluetooth or MMS.
- —Tapes list: Enter the tapes list.

Prompt: Call record is saved in the tapes list.

World Clock

You can view the time of different location. If you travel to a country or city with different time zone, you can move the time zone graph by pressing navigation key to the country or city in world map, and you can find the local time then.

Timer

You can set countdown of random time, and you will be reminded if time out.

STK

Enter STK submenu, you can use the additional services that the network service operator provided.

The device has STK function. The service is provided by network operator. If SIM card or network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

INTERNET

The device is compatible with WAP service. You can visit various WAP services, for instance, news, weather forecast and airlines etc. The services are specially designed for the device and are maintained by WAP service supplier.

WAP service requires network backup. You can consult the network operator or service supplier about the availability, rates and tax of WAP services.

Input URL

Input URL then visit it.

Homepage

Enter homepage and visit it.

Bookmark

Enter bookmark page, you can add new bookmark. You can also do the following operations with the bookmark: get started, view, edit, delete, and delete all.

- —Get started: Get started to visit the web page which bookmark marked.
- —View: View the bookmark website.

- Edit: Edit the website and name of bookmark.
- Delete: Delete the bookmark.
- Delete all: Delete all bookmarks.

History

Record the websites you visited before. On the history record interface you can also do the following operation with the visited web pages: get started, view, delete, and delete all.

- Get started: Get started to visit the web page which bookmark marked.
- View: View the bookmark website.
- Delete: Delete the history record.
- Delete all: Delete all the history records.









Offline Browse

You can browse the websites when you are offline.

WAP Settings

- Navigator Settings:
 - Clear temporary files: Clear the temporary files you visited.
 - Internet account: Set your internet account of SIM card 1 or SIM card 2 in order to visit internet correctly.
 - Download picture image: You can shut down or start up “picture download”.
 - Play background tone: You can shut down or start up “play background tone”.
 - Receive Push message: You can shut down or start up “receive Push message”.
- Preferential storage position:
 - You could set the storage position of files which downloaded by WAP.
- GPRS settings:
 - You can set GPRS connection as “always connect” or “connect when need”.
- Internet account:
 - You can edit your internet account by the function.

Introduction to the detailed functions of icons is as follows:

Icon	Introduction to Function
	Enter WAP homepage
	Refurbish the page
	Stop to refurbish the page
	Back to the previous page
	Turn to the next page
	Add to bookmark
	Offline browse, browse the saved photos
	Check history record.



Save document, photo,
picture and music.



Back to WAP page.

SETTINGS

You can customize the settings, such as time and date, language, call settings etc.

Call Settings

- Phone SIM card 1 and SIM card 2 settings
 - Standby mode: You can choose standby mode.
 - Settings of SIM card I/II: You can set as dialing number, SMS, MMS, website browse, shortcut dialing, reply from the same card when both cards in use. After setting default card, select dialing number, sending SMS or MMS, connecting web page or reply from the same card will use the default SIM card. If you set as reminding selection, then whenever you do aforementioned work, you will be asked to choose SIM card.
 - Setting the name of the slot: You can set any name you like as the name of SIM card slot.
- Network Selection: When your phone enjoys roaming service, the network can automatically or manually select network. The network roaming service can only be used when you subscribed the effective roaming service provided by the other network operator.
 - Automatic selection: Choose and click the function, the phone will automatically search network. The operation will have the phone independently registered with the most proper network.
 - Manual selection: Choose and click the function, the phone will search available network, and select the compatible network from the network list.
- Call divert: When “call divert” function is started up, you can transfer the incoming call to voice inbox or other phone number according to the scheduled “call divert” conditions.
 - Unconditional call divert: All incoming calls will be transferred to voice inbox or other phone number according to the setup.
 - Busy time call divert: When your number is busy, the incoming calls will be transferred to voice inbox or other phone number according to the setup.
 - Missed calls divert: When there are missed calls in your phone, they will be transferred to voice inbox or other phone number according to the setup.
 - Failed to be received calls divert: When your phone is power off or out of the service area, the incoming calls will be transferred to voice inbox or other phone number according to the setup.
 - Delete all calls divert: You can delete all settings of call divert.
- Call barring: All outgoing calls, incoming calls, roaming incoming calls, international outgoing calls, roaming international outgoing calls are available.
 - All outgoing calls: Start up the function will bar all outgoing calls.
 - All incoming calls: Start up the function will bar all incoming calls.
 - Roaming incoming calls: Start up the function will bar all roaming incoming calls.
 - International outgoing calls: Start up the function will bar all international outgoing calls.
 - Roaming international incoming calls: Start up the function will bar roaming international incoming calls.
 - Cancel all call barring: Cancel all restrictions on the call.
 - Revise password of call barring: You can consult your network operator about the call

barring password.

Prompt: The above-mentioned function will have to need network support. To use the function, please contact your network service provider.

- Call waiting: You can start up or shut down the function. When it is started up, even when you are making a call, you can also receive another income call.
- Conceal the number of the phone: This function must be supported by network.
- Line selection: There are two lines can be selected: line 1 and line 2. But the function just for the phone which has one SIM card and two numbers. If your phone is not the type like that, please just select line 1, because if you choose line 2, dialing will be limited.
- Flight mode: You can start up the function directly or choose when power on. It is used on flight. When flight mode is working all the functions connect with network, such as SMS, MMS, dialing back, WAP network, will be unavailable, to avoid interfering the signal of the flight you take.
- Others:
 - IP all-in-one: You can select different IP number or revise IP number.
 - Call connection reminder tone: When the function is started up, each time when a call is connected, the reminder sound can be heard.
 - Answer/ Reject a call:
 - Answer SMS to rejected call: When an incoming call is rejected, a reminder “answer SMS” will appear.
 - Anykey answer: When this function is on, you can answer a call by press any key except power-off key.
 - Automatic redial: You can start up or shut down the function. When it is on, a failed dialing will automatically redial.

Phone Settings

- Date and Time: You can set up the date and time on the phone as well as their display mode.
- Language: You can select phone language.
- Power on/off automatically: You can set the time and repeat mode of power-on and power-off.
- Power management: You can view the electric quantity of your battery.
- Restore factory settings: You can restore part of the phone settings as factory settings. The default code of restoring factory settings is: 1234.
- Orientation induction: You can start up or shut down the on-off of switching wallpaper, switching song and sound effects. If the function of switching wallpaper is on, wallpaper will be changed automatically by rocking the phone in standby interface; if the function of switching song is on, MP3 will be changed automatically by rocking the phone when MP3 is playing as background in standby interface; and if sound effects are on, sound will respond to the action of changing wallpaper.

Display Settings

- Wallpaper settings: You can set as default wallpaper image as well as more other wallpaper images.
- Theme: You can set theme 1 or theme 2.
- Backlight: “Always on”, “30seconds”, “20seconds”, “15seconds”, “10seconds” and “5seconds” are available.
- Key-press backlight: “20seconds”, “10seconds”, “5seconds”, “nighttime mode” and “shutdown” are available.
-

Prompt: When “nighttime” mode is turned on, the keypad light will not be on from am 6:00 to pm 6:00.

Security Settings

—PIN code

You can start up, shut down or modify PIN code. Correct PIN code shall be input when you unlock or shut down PIN code. If PIN code verification is started up, each time when you switch on your phone, you will have to input PIN code. If you input mistaken PIN codes three times in a row, SIM card will be locked. You will have to get PUK1 code to unlock it. Please contact network operator to get PUK1 code when necessary.

The default PIN code is 1234.

—PIN2 code

You can review PIN2 code. For details, please contact network operator.

—Privacy Protection

You can review privacy protection password. Besides, you can also set passwords for some menus, in this way, you will have to input password each time when you desire to open the menus.

The default password of privacy protection mode is 1234.

—Automatic keypad lock

Start up the function, when the phone is in any mode and without being touched, it will automatically lock the keypad.

—Darken screen by red key: If the function is on, press red key in standby interface the screen will enter the state of backlight and locked keypad.

—Phone password

You can start up or shut down “phone password” or revise it. When “phone password” is started up, you will have to input “password” each time when you use the phone.

—Anti-theft function

You can start up or shut down anti-theft function or revise anti-theft function password (the password shall be 6-digit).

When “anti-theft” function is started up, you can only use your SIM card. If different SIM card is used, the phone will automatically check it when you switch it on, and the phone will require you to input protection password. If the password is correct, you can set up the SIM card so that it is compatible with the anti-theft function.

If three mistaken passwords are input, when you switch on the phone, it will send warning SMS to your original SIM card every 24 hours. If the phone is switched off, the warning messages will be sent when you switch on the phone. The warning messages will indicate the existing SIM card and the neighborhood number. When 15 warning SMS were sent out, the phone cannot be used. You will have to take the purchase evidence to ask for the dealer’s help.

To guarantee the safety of your phone, you are suggested to start up the function when you purchased the phone.

— Start up: Start up anti-theft function.

— Shut down: To shut down anti-theft function, you will have to input the protection password you set for the phone.

— Revise password: To revise protection password, you will have to input the protection password you set for the phone.

Connection Manager

■ Network account

This feature allows you to account for various editors on the Internet.

■ WiFi

—On / off WiFi network

You can start or close the WiFi network .




—WiFi Networks list

Choose to enter the option, you can operate the following features:


- Search: search the currently available WiFi.
- Details: Displays the currently selected WiFi for more information.
- Edit: Edit the currently selected WiFi.
- New: Create a WiFi.
- Delete: Delete the currently selected WiFi.
- Clear: Remove all of the WiFi.
- Help: View help.


TEXT INPUT

The device provides several text input modes so that you can write text or input data in your “contacts”, edit “contacts” record, search English names and write SMS and to-do list.


In “text input” mode, if you want to change the input way, you can switch by pressing  key + “space” key, and the selected input icons will be shown on the left side of the screen. Press  key to shift up and then input you can get the character on the upper line of the key-press, and press  key twice to lock the function of shift up and then input you can get several characters on the upper line of the key-press.


Letter (Capital, Small)

Enter edit page, press  key + “space” key to switch the input mode into “letter”, and click the letter keys on soft keypad, selected letters will appear on the screen.


In letter input interface you can switch between capital letter and small letter by pressing  key.

Number

Enter “edit” mode, press  key + “space” key to switch the input mode into “number”. Then press the key on soft keypad, the number will be shown on the screen. 0-9 key stands for number 0-9, and you can press corresponding key to get desired number.

In other input mode if you need input number you can press corresponding number key to get after pressing  key to shift up.

Punctuation

Enter the “edit” mode, you can input desired punctuation by pressing corresponding key, and you can input the character on the upper line of the key-press by pressing  key to shift up.

ACCESSORIES

You may choose following enhancements of the device. You can also check with your dealer. Additional battery (The customer is suggested to confirm whether it is supplied.)

You can purchase the lithium batteries with different capacity provided by this company.

Travel Charger (The customer is suggested to confirm whether it is supplied.)

Ultra-light, applicable quick charger. It can quickly charge the phone. Plug the charger into electrical outlet, and the other terminal shall be plug into the charger connector at the bottom of the phone.

Earphone (The customer is suggested to confirm whether it is supplied.)

USB cable (The customer is suggested to confirm whether it is supplied.)

Charger (The customer is suggested to confirm whether it is supplied.)

You can check the charging status on display screen of the phone. You can press the power key and switch on the phone.

CARE AND MAINTENANCE

Maintenance of battery

- Your device is powered by a rechargeable battery. It is necessary to have the battery charged when it is going to wear out. The full performance of a new battery is achieved only when it is fully wore out.
- Unplug the charger from the electrical plug and the device when not in use. Do not leave fully a charged battery connected to a charger over a week, since overcharging may shorten its lifetime.
- Temperature tends to affect the limit of battery to be charged. Therefore, it is necessary for the battery to be cooled or warmed before it is charged. If the temperature of batter exceeds 40°C ,the battery cannot be charged.
- Use the battery only for its intended purpose and avoid short-circuiting. Accidental short-circuiting can occur when a metallic object causes direct connection of the positive (+) and negative (-) terminals of the battery.
- Do not use damaged battery.
- Leave the battery in hot or cold places will reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations.

Care of maintenance of your device

The suggestions below will help you protect your warranty coverage.

- Keep the device and accessories out of the reach of small children.
- Keep the device dry. All types of liquids or moisture will corrode electronic circuits.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- Do not attempt to open the device other than as instructed in this guide. Non-professional handling may damage the device.
- Do not use harsh chemicals or strong detergents to clean the device.
- Use only the supplied or an approved replacement attachments, for the unauthorized ones could invalidate the warranty of maintenance.

ADDITIONAL SAFETY INFORMATION

Remember to follow any special regulations in force and use the device only in its normal operation positions.

Traffic Safety

- Unless there is an emergency, otherwise do not use the device when you are driving a vehicle without safety wireless equipment. Please park the vehicle in a safe place before you use the device in order to guarantee that you pay all attention to drive. Observe related regulations.

- In case there is no adequate protection, certain electronic systems of the vehicle may be affected by the electric wave of the device.
- You are suggested to use the device only in vehicles with antenna.
- Only qualified personnel should install the device in a vehicle.

Aircraft Safety

Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal. The GSM service will be unavailable. When you are in flying aircraft, using your device is prohibited.

Environment Safety

- Remember to follow any special regulations in force in any area, and always switch off your device when its use is prohibited or when it may cause interference or danger.
- Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacture of the medical device to determine if you have any questions.
- Your device may interfere with some hearing aids, pacemakers and other medical devices. Please obey the suggestions provided by physicians or medical device manufacturers.
- You are suggested to switch off the device in any area with potentially explosive atmosphere, such as gas station, chemical factories etc.
- Observe restrictions on the use of radio equipment.